



**ASSEMBLY INSTRUCTIONS:**

- A) Layout plinth (item 1) on floor, square plinth, mark and drill 5/16" (8.0mm) dia. hole for 3/8 LAG bolts (4) - not supplied.
- B) LAG assembled plinth to floor. Assure that plinth is square and accurate.
- C) Open or remove doors on console (item 2) for ease of assembly. This will allow for visual alignment of mating parts. Remove .5 dia knockouts in bottom of console unit.
- D) Align console (item 2) over top opening in plinth unit. Side edges of console and plinth are to be flush.
- E) Front and rear holes in console bottom are to be aligned with mounting holes on plinth top.
- F) Once the console is seated properly on the plinth remove cover plates on plinth.
- G) Assemble using 3/8-16 x .75 hex head bolts and 3/8 nuts and sealing washers (item 3, 4, & 5) provided. Torque bolts and nuts to 180 in/lbs

PARTS LIST		
ITEM No.	DESCRIPTION	QTY
1	PLINTH	1
2	CONSOLE	1
3	3/8-16 X 3/4 HEX CAP SCREW	4 or 6
4	3/8 SEALING WASHER	4 or 6
5	3/8-16 KEP NUT	4 or 6

