

### FS3000

Air Velocity Sensor Module

The <u>FS3000</u> is a surface-mount type air velocity module that uses a MEMS thermopile-based sensor.

The FS3000 features a digital output with 12-bit resolution. The sensor comprises a "solid" thermal isolation technology and silicon-carbide coating to protect it from abrasive wear and water condensation.

The module features a compact design fit for low profile enclosures.

### **Features**

- Robust "solid" isolation technology
- Resistant to surface contamination
- Resistant to vibration and pressure shock
- Low power application
- Digital output: I<sup>2</sup>C
- Supply voltage: 3.3V
- Module operating temperature range: -20°C to +85°C
- Module size: 8 x 9 x 4 mm

### **Applications**

- Data center and servers
- HVAC and air control systems
- Laminar flow control systems
- Air filtration and collection systems





Figure 1. FS3000 Air Velocity Module

# **Contents**

1.	Pin I	nformation	
	1.1	Pin Assignments	3
	1.2	Pin Descriptions	
2.	App	lication Circuit	4
3.	Spec	cifications	5
	3.1	Absolute Maximum Ratings	
	3.2	Recommended Operating Conditions	5
	3.3	Electrical Characteristics	5
4.	Турі	cal Flow Graphs	6
5.	Fund	ctional Description	8
	5.1	I <sup>2</sup> C Sensor Interface	8
		5.1.1. Sensor Slave Address	8
		5.1.2. I <sup>2</sup> C Communication	8
	5.2	Digital Output Measurements	6
	5.3	Calculating Checksum	10
6.	Mod	ule Drawings	11
7.	Orde	ering Information	12
8.	Revi	sion History	12

# 1. Pin Information

# 1.1 Pin Assignments




# 1.2 Pin Descriptions

**Table 1. Pin Descriptions** 

Pin Number Pin Name Type		Туре	Description
1	1 V <sub>REG</sub> Input ADC refere		ADC reference input.
2	V <sub>IN</sub>	Input	Supply voltage.
3	GND	Ground	Ground.
4	NC	-	Do not connect.
5	NC	-	Do not connect.
6	SDA	Input/Output	Serial data.
7	SCL	Input	Serial clock.
8	TP1	Input/Output	Connect with capacitor.
9	TP2	Input/Output	Connect with capacitor.
10	V <sub>CM</sub>	Output	Common bias.

# 2. Application Circuit



### Note:

- C1, C2, C3 are 0.1µF capacitors
- C4 is a 1μF capacitor

## 3. Specifications

## 3.1 Absolute Maximum Ratings

The absolute maximum ratings are stress ratings only. Stresses greater than those listed below can cause permanent damage to the device. Functional operation of the FS3000 at absolute maximum ratings is not implied. Exposure to absolute maximum rating conditions may affect device reliability.

Symbol	Parameter	Conditions	Minimum	Maximum	Unit
V <sub>IN</sub>	Supply Voltage	-	-	5.5	٧
T <sub>STOR</sub>	Storage Temperature	-	-40	105	°C

## 3.2 Recommended Operating Conditions

Symbol	Parameter	Minimum	Typical	Maximum	Unit
V <sub>IN</sub>	Supply Voltage [1]	-	3.3	-	٧
T <sub>AMB</sub>	T <sub>AMB</sub> Ambient Operating Temperature		-	85	ô

<sup>1.</sup> Must be regulated; changes in supply voltage will affect accuracy.

### 3.3 Electrical Characteristics

Symbol	Parameter	Conditions	Minimum	Typical	Maximum	Unit	
I <sub>VIN</sub>	Current Consumption	-	-	10	-	mA	
_	A: 51 B	FS3000-1005	0	ı	7.23	m/200	
F <sub>AIR</sub>	Air Flow Range	FS3000-1015	0	ı	15	m/sec	
V <sub>OUT</sub>	Digital Output	Min to Max of Flow Range	409	-	3686	Count	
RES	Resolution	-	-	ı	12	bit	
E <sub>AIR</sub>	Flow Accuracy	At 25°C	-	5		% of F.S.	
t <sub>RESP</sub>	Response Time	-	-	125		ms	
f <sub>SCL</sub>	SCL Clock Frequency	-	-	ı	400	kHz	
V <sub>IL</sub>	I <sup>2</sup> C Input Logic Low Threshold	-	-	1	0.3V <sub>DD</sub> or 1.5	V	
V <sub>IH</sub>	I <sup>2</sup> C Input Logic High Threshold	-	0.7V <sub>DD</sub> or 3	-	-	V	
V <sub>OL</sub>	I <sup>2</sup> C Output Logic Low Threshold	-	-	-	0.4	V	

<sup>1.</sup> m/sec: meter per second.

<sup>2.</sup> F.S: Full scale flow range.

# 4. Typical Flow Graphs




Figure 2. FS3000-1005 Output

Air Velocity (m/sec)	Output (Count)
0	409
1.07	915
2.01	1522
3.00	2066
3.97	2523
4.96	2908
5.98	3256
6.99	3572
7.23	3686




Figure 3. FS3000-1015 Output

Air Velocity (m/sec)	Output (Count)
0	409
2.00	1203
3.00	1597
4.00	1908
5.00	2187
6.00	2400
7.00	2629
8.00	2801
9.00	3006
10.00	3178
11.00	3309
13.00	3563
15.00	3686

## 5. Functional Description

### 5.1 I<sup>2</sup>C Sensor Interface

The FS3000 includes an I<sup>2</sup>C digital, two-wire interface with a bidirectional data line (SDA) and a clock line (SCL). The two lines are open drain and connected to the supply voltage via two pull-up resistors (Rp). The FS3000 operates as a slave device on the I<sup>2</sup>C bus with support of 100kHz and 400kHz bit rates.




Figure 4. I<sup>2</sup>C Master-Slave Configuration

The recommended pull-up resistor (Rp) values depend on the system implementation, but a value between  $2.2k\Omega$  and  $10k\Omega$  can be used.

The capacitive load on both SDA and SCL should be the same; therefore, the signal lengths should be similar to avoid asymmetry.

#### 5.1.1. Sensor Slave Address

The FS3000 default I<sup>2</sup>C address is 28<sub>HEX</sub>. The device will respond only to this 7-bit address.

### 5.1.2. I<sup>2</sup>C Communication

The START condition is used to initiate I<sup>2</sup>C communication by the master. The sensor transmission is initiated when the master sends a 0 START bit (S). A HIGH-to-LOW transition on the SDA line while the SCL is HIGH indicates the beginning of a transmission.

The STOP condition is used to stop I<sup>2</sup>C communication by the master. The transmission is terminated when the master sends a 1 STOP bit (P). A LOW-to-HIGH transition on the SDA line while the SCL is HIGH indicates the end of a transmission.

All transfers consist of 8 bits and a response bit: 0 for Acknowledge (ACK) or 1 for Not Acknowledge (NACK). After the ACK is received, another data byte can be transferred or the communication can be stopped with a STOP bit.

The master expects an ACK back from the slave after each byte is transmitted. The slave pulls the SDA low to indicate that it has received a byte and then it frees the I<sup>2</sup>C bus again. If the slave does not initiate an ACK then it will consider it a NACK.

Data on the SDA line is always sampled on the rising edge of the SCL line and must remain stable while SCL is HIGH to prevent false START or STOP conditions.




Figure 5. START and STOP Condition Waveform

### 5.2 Digital Output Measurements

The FS3000 continuously measures during operation. The data is sent in byte packages. Each byte is followed by an ACK from the slave. The most significant bit (MSB) is transmitted first.

To read the data, the following command is sent to the FS3000.

After the START bit, the master device sends the 7-bit slave address followed by an eighth bit = 1 (READ). The READ bit indicates a transmission from the FS3000 (slave) to master (see Figure 6).

The checksum used for data integrity is returned from the FS3000 followed by the two bytes of flow data.

The flow data is a 12-bit integer. Only the least significant four bits in the high byte are valid (see Figure 7).




Figure 6. Flow Data Read Command




Figure 7. Flow Data from FS3000

### 5.3 Calculating Checksum

The checksum used for data integrity is the 2's complement (negative) of the 256-modulo (8-bit) sum of the data bytes (does not include I<sup>2</sup>C address).

Figure 7 shows the 5 bytes read:

Example:

Byte 1, 0xCC (Checksum)

Byte 2, 0x01

Byte 3, 0x99

Byte 4, 0x01 or 0x00

Byte 5, 0x99 or 0x00

The 256-modulo (8-bit) sum is calculated as:


$$sum = 0x01 + 0x99 + 0x01 + 0x99 = 0x134$$


Validating the data payload is done by calculating the sum and adding it to the checksum. If the result is 0x00, then the data is valid.


$$checksum + sum = 0xCC + 0x134 = 0x00$$


# 6. Module Drawings


All dimensions are in mm.












### **PCB Footprint**



# 7. Ordering Information

Part Number Description		MSL Rating	Carrier Type	Temperature Range
FS3000-1005 0 to 7 m/sec air velocity module		3	Reel	-20°C to +85°C
FS3000-1015	0 to 15 m/sec air velocity module	3	neei	-20 0 10 +65 0

# 8. Revision History

Revision Date   1.01 Feb 6, 2023   1.00 May 31, 2022		Description
		Corrected module dimension height in Features description on first page.
		Initial release.

#### IMPORTANT NOTICE AND DISCLAIMER

RENESAS ELECTRONICS CORPORATION AND ITS SUBSIDIARIES ("RENESAS") PROVIDES TECHNICAL SPECIFICATIONS AND RELIABILITY DATA (INCLUDING DATASHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for developers skilled in the art designing with Renesas products. You are solely responsible for (1) selecting the appropriate products for your application, (2) designing, validating, and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, or other requirements. These resources are subject to change without notice. Renesas grants you permission to use these resources only for development of an application that uses Renesas products. Other reproduction or use of these resources is strictly prohibited. No license is granted to any other Renesas intellectual property or to any third party intellectual property. Renesas disclaims responsibility for, and you will fully indemnify Renesas and its representatives against, any claims, damages, costs, losses, or liabilities arising out of your use of these resources. Renesas' products are provided only subject to Renesas' Terms and Conditions of Sale or other applicable terms agreed to in writing. No use o any Renesas resources expands or otherwise alters any applicable warranties or warranty disclaimers for these products.

(Disclaimer Rev.1.0 Mar 2020)

#### **Corporate Headquarters**

TOYOSU FORESIA, 3-2-24 Toyosu, Koto-ku, Tokyo 135-0061, Japan www.renesas.com

### **Trademarks**

Renesas and the Renesas logo are trademarks of Renesas Electronics Corporation. All trademarks and registered trademarks are the property of their respective owners.

#### **Contact Information**

For further information on a product, technology, the most up-to-date version of a document, or your nearest sales office, please visit:

www.renesas.com/contact/