




IQS550/572/525-B000 DATASHEET

Projected capacitive trackpad/touchscreen controller with proximity, touch, snap, trackpad outputs and gestures.

The IQS5xx-B000 is a projected capacitive touch and proximity trackpad/touchscreen controller implementation on the IQS550, IQS572 and IQS525 platforms. The IQS5xx-B000 features best in class sensitivity, signal-to-noise ratio and automatic tuning of electrodes. Low power proximity detection allows extreme low power operation.

Main Features

- > Proximity, touch and snap* on each channel
- > Multi-touch support up to 5 fingers
- > Single and multi-finger gestures
- > 3584 x 2304 max resolution (IQS550)
- > Scale, orientation and electrode layout selection
- > I²C communication interface
- > ATI: automatic tuning for optimum sensitivity
- > Supply Voltage 1.65V to 3.6V
- > Proximity low power operation (<10uA)
- > 3 Active and 2 low power modes
- > Event and streaming modes
- > Internal voltage regulator and reference capacitor
- > On-chip noise detection and suppression



	IQS550	IQS572	IQS525
Maximum channels	150	72	25
Typical report rate (with single touch / all channels active)	100Hz	135Hz	190Hz
Maximum resolution (for shown Tx Rx configurations)	3584 x 2304 (15 x 10)	2048 x 1792 (9 x 8)	1280 x 768 (6 x 4)

Applications

- Compact Capacitive Keyboards
- > Remote Control Trackpads
- > Appliances
- Navigation devices
- > Kiosks and POS terminals
- > E-reader

T_A	QFN(7x7)-48	QFN(4x4)-28	QFN(4x4)-28
-40°C to 85°C	IQS550	IQS572	IQS525

*Patented





Contents

1	0	VERVIEW	7
2	P	ACKAGING AND PIN-OUT	8
	2.1	IQS550 - QFN48	8
	2.2	IQS572 - QFN28	
	2.3	IQS525 - QFN28	
2			
3	P	ROXSENSE® MODULE	
	3.1	CHANNEL DEFINITION	
	3.2	ALTERNATE LOW-POWER CHANNEL (ALP)	
	3.3	COUNT VALUE	
		.3.1 Trackpad Count Values	
		.3.2 ALP Count Values	
		.3.3 Max Count	
	3.4	REFERENCE VALUE	
		.4.1 Reference Update Time	
		.4.2 ALP Long-Term Average	
		.4.3 Reseed	
	3.5	CHANNEL OUTPUTS	
		.5.1 Proximity	
	3.	.5.2 Touch	
	3.	.5.3 Snap	
		.5.4 Output Debounce	
		.5.5 Maximum Touch	
	3.6	AUTO TUNING (ATI)	
		.6.1 ATI C Multiplier	
	3.7	.6.2 ATI Compensation & Auto ATI	
		.7.1 Description	
		.7.2 Conditions for Re-ATI to activate	
		.7.3 ATI Error	
		.7.4 Design requirements	
	3.8	SENSING HARDWARE SETTINGS	
4	S	ENSING MODES	19
	4.1	REPORT RATE	20
		.1.1 Previous Cycle Time	
	4.2	Mode Timeout	
	4.3	Manual Control	
5		RACKPAD	
J			
	5.1	CONFIGURATION	
		.1.1 Size Selection	
		.1.2 Individual Channel Disabling	
		.1.4 Rx / Tx Selections	
	5.2	TRACKPAD OUTPUTS	
		.2.1 Number of Fingers	
		.2.2 Relative XY	
		.2.3 Absolute XY	





	5.2.4	Touch Strength	
	5.2.5	Area	
	5.2.6	Tracking / Identification	
	5.3	MAX NUMBER OF MULTI-TOUCHES	
	5.4	XY RESOLUTION	
	5.5	PALM REJECTION	
	5.6	Stationary Touch	
	5.7	Multi-touch Finger Split	22
	5.8	XY OUTPUT FLIP & SWITCH	22
	5.9	XY Position Filtering	22
	5.9.1	MAV Filter	22
	5.9.2	IIR Filter	22
6	GEST	URES	23
	6.1	SINGLE TAP	22
	6.2	Press and Hold	
	6.3	SWIPE (X-, X+, Y-, Y+)	
	6.4	TWO FINGER TAP	
	6.5	SCROLL	
	6.6	ZOOM	
	6.7	SWITCHING BETWEEN GESTURES	25
7	ADDIT	TIONAL FEATURES	25
	7.1	Non-volatile Defaults	25
	7.2	AUTOMATED START-UP	
	7.3	SUSPEND	
	7.3.1 7.3.2	I ² C Wake	
		Switch Input Pin Wake	
	7.4	RESET	
	7.4.1 7.4.2	Reset Indication	
	7.4.2 7.4.3	Software Reset	
	7.4.3		
		WATCHDOG TIMER (WDT)	
	7.6	RF IMMUNITY	
	7.7	ADDITIONAL NON-TRACKPAD CHANNELS	
	7.8	BOOTLOADER	
	7.8.1	Bootloader Status	
	7.9	VERSION INFORMATION	
	7.9.1	Product Number	
		Project Number	
	7.9.3	Major and Minor Versions	
	7.10	UNIQUE ID	
	7.11	SWITCH INPUT	27
8	I2C		27
	8.1	DATA READY (RDY)	27
	8.2	SLAVE ADDRESS	
	8.3	16-BIT ADDRESSING	
	8.4	I ² C READ	
	8.4.1	Default Read Address	
	8.5	I ² C Write	
	0.0	1 O WINTE	20





8.	6	I ² C TIMEOUT	
8.	7	END OF COMMUNICATION SESSION / WINDOW	28
8.	8	EVENT MODE COMMUNICATION	28
	8.8.1	Events	29
	8.8.2	Force Communication	29
8.	9	MEMORY MAP REGISTERS	30
8.	10	MEMORY MAP BIT / REGISTER DEFINITIONS	36
	8.10.1	Gesture Events 0	36
	8.10.2	Gesture Events 1	37
	8.10.3	System Info 0	
	8.10.4	System Info 1	
	8.10.5	Individual Channel Status / Config Bit Definitions	
	8.10.6	Count / Delta / Reference Data	
	8.10.7	System Control 0	
	8.10.8	System Control 1	
	8.10.9	System Config 0	
	8.10.10		
	8.10.11	<u> </u>	
	8.10.12 8.10.13		
	8.10.14		
	8.10.15		
	8.10.16		
	8.10.17		
	8.10.18	· ·	
	8.10.19		
	8.10.20	· · · · · · · · · · · · · · · · · · ·	
	8.10.21		
	8.10.22	Multi-finger Gestures	47
9	CIRCIII	T DIAGRAM	47
10	ELECTI	RICAL CHARACTERISTICS	52
10	0.1	ABSOLUTE MAXIMUM RATINGS	52
10	0.2	OPERATING CONDITIONS	53
	10.2.1	General Operating Conditions	
	10.2.2	Power-up / Power-down Operating Conditions	
	10.2.3	Supply Current Characteristic	54
	10.2.4	ProxSense® Current Consumption	
	10.2.5	Expected Total Current Consumption Scenarios	
	10.2.6	I/O Port Pin Characteristics	
	10.2.7	Output Driving Current	
	10.2.8	NRST Pin	
	10.2.9	I ² C Characteristics	
	10.2.10	,	
	10.2.11		
	10.2.12 10.2.13		
11	MECHA	NICAL DIMENSIONS	62
1.	1.4	IQS550 QFN(7x7)-48 MECHANICAL DIMENSIONS	62
	1.1		
1.			
	1.2	IQS550 LANDING PAD LAYOUT	63
1			63 64





12	PACKAG	SING INFORMATION	66
1	2.1 12.1.1 12.1.2 2.2 12.2.1 12.2.2 2.3 2.4	TAPE SPECIFICATION	67 68 69 69 70
13	DEVICE	MARKING	72
	3.1 3.2	IQS550 MARKINGIQS572/IQS525 MARKING	
14	ORDERII	NG INFORMATION	74
1	4.1 4.2 4.3	IQS550 ORDERING IQS572 ORDERING IQS525 ORDERING	74
15	CHANGE	:S:	75
16	CONTAC	T INFORMATION	76





List of Abbreviations

ALP Alternate Low Power

ATI Automatic Tuning Implementation
EMI Electromagnetic Interference

ESD Electrostatic Discharge

GND Ground

GUI Graphical User Interface

IC Integrated Circuit

ICI Internal Capacitor Implementation

IIR Infinite Impulse Response

LP Low Power

LTA Long Term Average

MAV Moving Average

ND Noise Detect

THR Threshold

TP Trackpad

WDT Watchdog Timer





1 Overview

The IQS550 / IQS572 / IQS525 are capacitive sensing controllers designed for multi-touch applications using projected capacitance touch panels. The device offers high sensitivity proximity wake-up and contact detection (touch) through a selectable number of sensor lines (Rxs and Txs).

The device has an internal voltage regulator and Internal Capacitor Implementation (ICI) to reduce external components. Advanced on-chip signal processing capabilities provide stable high performance with high sensitivity.

A trackpad consists of an array of sensors that are scanned at regular intervals. The controller uses the principle of projected capacitance charge transfer on the trackpad. When a conductive object such as a human finger approaches the sense plate it will decrease the detected capacitance. Thresholds are applied to the sensor data to identify areas that exhibit proximity and touch deviation. The contours of the touch areas are then translated to Cartesian position coordinates that are continuously monitored to identify gestures. A user has access to all of the data layers – the raw sensor data, the sensor proximity/touch status data, the XY coordinates as well as the gesture outputs.

Multiple filters are implemented to detect and suppress noise, track slow varying environmental conditions and avoid effects of possible drift. The Auto Tuning (ATI) allows for the adaptation to a wide range of touch screens without using external components.

An innovative addition, known as a snap*, is also available on each channel. This adds another channel output, additional to the proximity and touch.

The trackpad application firmware on the IQS5xx is very flexible in design, and can incorporate standard touch sensors, trackpad / touchscreen areas (giving XY output data) and conventional snap-dome type buttons, all providing numerous outputs such as proximity, touch, snap, touch strength, area and actual finger position all in one solution.

The IQS550, IQS572 and IQS525 devices ship with the bootloader only, since the designer must program custom IQS5xx-B000 firmware during production testing. The custom firmware is the IQS5xx-B000 trackpad firmware together with customer specific hardware settings exported by the GUI program.



This datasheet applies to the following **IQS550** version: Product Number 40 / Project Number 15 / Version Number 2





This datasheet applies to the following **IQS572** version: Product Number 58 / Project Number 15 / Version Number 2





This datasheet applies to the following **IQS525** version: Product Number 52 / Project Number 15 / Version Number 2

*Patented





2 Packaging and Pin-out

2.1 IQS550 - QFN48

The IQS550 is available in a QFN(7x7)-48 package.




Figure 2.1 QFN Top View





Table 2.1 QFN48 Pin-out

Pin	Name	Description	Pin	Name	Description
1	Tx14	Transmitter electrode	25	Rx6A	Receiver electrode
2	PGM	Programming Pin	26	Rx6B	Note1
3	SW_IN	Wake-up from suspend and switch input	27	Rx7A	Receiver electrode
4	n/c	~	28	Rx7B	Note1
5	SDA	I2C Data	29	Rx8A	Receiver electrode
6	SCL	I2C Clock	30	Rx8B	Note1
7	VDDHI	Supply Voltage	31	Rx9A	Receiver electrode
8	VSS	Ground Reference	32	Rx9B	Note1
9	VREG	Internal Regulator Voltage	33	Tx0	Transmitter electrode
10	NRST	Reset (active LOW)	34	Tx1	Transmitter electrode
11	RDY	I2C RDY	35	Tx2	Transmitter electrode
12	n/c	~	36	Tx3	Transmitter electrode
13	Rx0A	Receiver electrode	37	VSSIO	I/O Ground Reference
14	Rx0B	Note1	38	VDDIO	I/O Supply Voltage
15	Rx1A	Receiver electrode	39	Tx4	Transmitter electrode
16	Rx1B	Note1	40	Tx5	Transmitter electrode
17	Rx2A	Receiver electrode	41	Tx6	Transmitter electrode
18	Rx2B	Note1	42	Tx7	Transmitter electrode
19	Rx3A	Receiver electrode	43	Tx8	Transmitter electrode
20	Rx3B	Note1	44	Tx9	Transmitter electrode
21	Rx4A	Receiver electrode	45	Tx10	Transmitter electrode
22	Rx4B	Note1	46	Tx11	Transmitter electrode
23	Rx5A	Receiver electrode	47	Tx12	Transmitter electrode
24	Rx5B	Note1	48	Tx13	Transmitter electrode

Note1: Any of these can be configured through I^2C as the ProxSense $^{\$}$ electrode.





2.2 IQS572 - QFN28

The IQS572 is available in a QFN(4x4)-28 package. The production version is shown below.




Figure 2.2 IQS572 QFN Top View





Table 2.2 IQS572 QFN28 Pin-out

Pin	Name	Description	Pin	Name	Description
1	n/c	~	15	Rx5	Receiver electrode
2	SDA	I ² C Data	16	Rx6	Receiver electrode
3	SCL	I ² C Clock	17	Rx7	Receiver electrode
4	VDDHI	Supply Voltage	18	Tx0	Transmitter electrode
5	VSS	Ground Reference	19	Tx1	Transmitter electrode
6	VREG	Internal Regulator Voltage	20	Tx2	Transmitter electrode
7	NRST	Reset (active LOW)	21	Tx3	Transmitter electrode
8	RDY	I ² C RDY	22	Tx4	Transmitter electrode
9	n/c	~	23	Tx5	Transmitter electrode
10	Rx0	Receiver electrode	24	Tx6	Transmitter electrode
11	Rx1	Receiver electrode	25	Tx7	Transmitter electrode
12	Rx2	Receiver electrode	26	Tx8	Transmitter electrode
13	Rx3	Receiver electrode	27	PGM	Programming Pin
14	Rx4	Receiver electrode	28	SW_IN	Wake-up from suspend and switch input





2.3 IQS525 - QFN28

The IQS525 is available in a QFN(4x4)-28 package. The production version is shown below.




Figure 2.3 IQS525 QFN Top View





Table 2.3 QFN28 Pin-out

Pin	Name	Description	Pin	Name	Description
1	n/c	~	15	Rx5 / TX4	Receiver / Transmitter electrode
2	SDA	I ² C Data	16	Rx6 / TX3	Receiver / Transmitter electrode
3	SCL	I ² C Clock	17	Rx7 / TX2	Receiver / Transmitter electrode
4	VDDHI	Supply Voltage	18	Tx1	Transmitter electrode
5	VSS	Ground Reference	19	Tx0	Transmitter electrode
6	VREG	Internal Regulator Voltage	20	PD2	General purpose I/O
7	NRST	Reset (active LOW)	21	PD3	General purpose I/O
8	RDY	I ² C RDY	22	PD4	General purpose I/O
9	n/c	~	23	PD5	General purpose I/O
10	Rx0	Receiver electrode	24	PD6	General purpose I/O
11	Rx1	Receiver electrode	25	PD7	General purpose I/O
12	Rx2	Receiver electrode	26	PB0	General purpose I/O
13	Rx3	Receiver electrode	27	PGM	Programming Pin
14	Rx4	Receiver electrode	28	SW_IN	Wake-up from suspend and switch input







ProxSense® Module

The IQS5xx contains a ProxSense® module > that uses patented technology to measure and process the capacitive sensor data. trackpad sensors are scanned one Tx > transmitter at a time, until all have completed, with all enabled Rxs charging in each Tx time slot. The channel outputs (proximity, touch and > snap) are the primary outputs from the sensors. These are processed further to provide > secondary trackpad outputs that include finger position, finger size as well as on-chip gesture recognition.

button onto the customized sensor area. This gives an additional output above the traditional proximity and touch channel outputs.

For more information on capacitive sensing and charge transfers, please refer to the Azoteq Application Note AZD004.

For more information regarding design guidelines refer to the Application Note AZD068.

3.1 **Channel Definition**

A channel for a projected capacitive sensor consists of a Tx electrode that is in close proximity to an Rx electrode.

On a trackpad sensor (typically a diamond shape pattern), each intersection of an Rx and 3.3.2 Tx row/column forms a capacitive sensing element which is referred to as a channel. Each channel has an associated count value, reference value, proximity, touch and snap (if enabled) status. The maximum number of Tx and Rx electrodes on the IQS550 device is A count value filter is implemented on this 15x10, thus giving 150 channels in total.

3.2 Alternate Low-Power Channel (ALP)

If lower power consumption is required (ALP), LP1 and LP2 can be configured to utilise a The amount of filtering can be modified (ALP single custom channel sensor, instead of has a lot of setup flexibility:

- Sensing method (CHARGE TYPE): projected capacitive or self capacitive.
- Sensors: which Rxs (RX GROUP | ALP Rx select) / Txs (ALP Tx select) are active during conversions.
- Reverse sensing: If enabled, negative deviations can also trigger proximity detection (PROX REVERSE).
- Count value filtering: gives reliable proximity detection in noisy environments.
- Single channel: since the alternate channel is processed as only a single channel, much less processing is done, allowing for lower overall power consumption.

The additional snap state is a unique sensor Since all Rxs return a count measurement, it output that utilises capacitive technology to means that the ALP channel can be a sense the depression of a metal dome snap combination of numerous measurements. To reduce processing time (and this decrease current consumption) the measurements are added together and processed as a single 'channel'.

3.3 Count Value

The capacitive sensing measurement returns a count value for each channel. Count values are inversely proportional to capacitance, and all outputs are derived from this them.

3.3.1 **Trackpad Count Values**

The individual trackpad channel count values (Count values) are unfiltered.

ALP Count Values

The combined count value (ALP count value) used for this channel is a summation of the individual count values (ALP individual count values) from each active Rx.

channel to give stable proximity output for system wake-up from a low-power mode. It is recommended to leave this count filter enabled (ALP COUNT FILTER).

count beta) if required. This beta is used as sensing the trackpad channels. This channel follows to determine the damping factor of the filter:







Count damping factor = Beta / 256

If the beta is small, the filtering is stronger, and if the beta is larger, the filtering is weaker.

3.3.3 **Max Count**

Each channel is limited to having a count value smaller than the configurable limit (Max count limit). If the ATI setting or hardware causes measured count values higher than this, the conversion will be stopped, and a value of '0' will be read for that relevant count value. Note that a '0' is also returned for a disabled channel.

3.3.4 **Delta Value**

The delta values (*Delta values*) are simply:

Delta = Count - Reference

3.4 Reference Value

interaction.

The reference value is a two-cycle averaged of the count value, stored during a time of no user activity, and thus is a non-affected reference. The trackpad reference values are only For the trackpad channels, user interaction are managed automatically. must also be managed and updated manually by the host.

3.4.1 **Reference Update Time**

The reference value is updated or refreshed snap output. according to a configurable interval (*Reference* If the measured count value exceeds the update time), in seconds.

updated during user interaction, it only debounce parameter, the output becomes set. executes from the LP1 and LP2 states, where no user interaction is assumed.

Setting the Reference update time to '0' will disable the updating of the reference values.

3.4.2 **ALP Long-Term Average**

The ALP channel does not have a snapshot reference value as used on the trackpad, but utilises a filtered long-term average value (ALP LTA value). The LTA tracks the environment closely for accurate comparisons to the measured count value, to allow for small proximity deviations to be sensed. The speed of LTA tracking can be adjusted with the ALP LTA beta. There is an ALP1 and ALP2, which are implemented in LP1 and LP2 respectively. This is to allow different settings for different report rates, so that the LTA tracking rate can remain the same.

3.4.3 Reseed

User interaction is detected by comparing Since the Reference (or LTA for ALP channel) count values to reference values. The count is critical for the device to operate correctly, value of a sensor represents the instantaneous there could be known events or situations capacitance of the sensor. The reference value which would call for a manual reseed. A reseed of a sensor is the count value of the sensor that takes the latest measured counts, and seeds is slowly updated to track changes in the the reference/LTA with this value, therefore environment, and is not updated during user updating the value to the latest environment. A reseed command can be given by setting the corresponding bit (*RESEED* or *ALP RESEED*).

3.5 Channel Outputs

updated from LP1 and LP2 mode when modes typically causes the count values to increase. Thus, if the The amount of deviation relative to the system is controlled manually, the reference reference can be used to determine the output state of the channel, dependent on the sensitivities configured.

> For a snap actuation, the count values decrease, and a negative deviation cause a

selected threshold value for consecutive To ensure that the reference value is not cycles, equal in number to the selectable







3.5.1 **Proximity**

This output (*Prox status*) is set when a channels' count value deviates from the reference value by more than the selected threshold (Prox threshold).

The proximity threshold is the smallest difference between the count value and the reference value that would result in a proximity output. Small threshold values are thus more sensitive than large threshold values.

Note: For the trackpad channels (projected capacitive) the samples will increase with user interaction, thus the actual threshold is the reference value PLUS the threshold parameter.

However, if an ALP channel is implemented in self capacitive mode, the samples will decrease during user interaction, thus the actual threshold is the reference value MINUS the threshold parameter.

3.5.2 **Touch**

This output (*Touch status*) is set when a channels' count value increases by more than the selected threshold.

calculated as follows:

Threshold = Reference x (1 + Multiplier / 128)

A smaller fraction will thus be a more sensitive threshold.

A trackpad will have optimal XY data if all of the channels in the trackpad exhibit similar deltas under similar user inputs. In such a case all of the channels will have identical thresholds. In practise. sensor design and hardware restrictions could cause deltas which are not constant over the entire trackpad. It could then be required to select individual multiplier These (Individual touch multiplier adjustment) are signed 8-bit values and indicate how much the unsigned 8-bit global value (Global touch multiplier) must be adjusted. The threshold used for a specific channel (set and clear) is as follows:

Multiplier = Global + Individual adjust

A hysteresis can also be implemented because there are different touch multiplier parameters

for setting a touch and clearing a touch. This hysteresis allows the channels to not flicker in and out of touch with noise.

3.5.3 Snap

When adding a metal snap-dome overlay to the trackpad pattern, an additional snap output (Snap status) is available. The device is able to distinguish between a normal 'touch' on the overlay and an actual button 'snap', which depresses the metal dome onto the Rx/Tx pattern. The design must be configured so that a snap on the metal dome will result in a channels' count value falling well below the reference for that channel.

If required, the function must be enabled (Snap enabled channels) for each channel on which snap is designed. Only channels with snap must be marked as such, since channels are handled differently if they are snap channels, compared to non-snap channels.

One global snap threshold (Snap threshold) is implemented as a delta value BELOW the The touch threshold for a specific channel is reference. When a snap is performed, a sensor saturation effect causes the deviation to be negative.

> Because it is only necessary to read the individual snap registers if a state change has occurred, a status bit (SNAP TOGGLE) is added to indicate this. This is only set when there is a change of status of any snap channel.

> A reseed is executed if a snap is sensed for longer than the *Snap timeout* time (in seconds). A setting of 0 will never reseed. The timeout is reset if any snap is set or cleared.

3.5.4 **Output Debounce**

All the channel outputs (proximity, touch and snap) are debounced according to the selectable debounce values (Prox debounce / Touch snap debounce). Note that a debounce value of 1 means that two samples satisfying the condition must be met consecutively before the output is activated. The default touch debounce is set to 0 / no debouncing. This is due to the fact that with a 15x10 sensor,







movements on the touch panel cannot be parameter (ALP ATI C). debounced fast enough to provide reliable XY output data.

3.5.5 **Maximum Touch**

discrete buttons, to reject any adjacent keys if (ATI target | ALP ATI target). they are located in close proximity to each If the Rxs and Txs are switched (SWITCH XY AXIS), the columns are the Txs, seen, then this will output 0xFF.

3.6 Auto Tuning (ATI)

The ATI is a sophisticated technology implemented in the new ProxSense® devices to allow optimal performance of the devices for a The ALP channel has individual compensation wide range of sensing electrode capacitances, without modification to external components. The ATI settings allow tuning of two parameters. ATI C Multiplier ATI and Compensation, to adjust the sample value for an attached sensing electrode.

For detailed information regarding the on-chip ATI technology, please refer to AZD027 and AZD061.

The main advantage of the ATI is to balance small variations between trackpad hardware and IQS5xx variation, to give similar 3.7 Automatic Re-ATI performance across devices.

3.6.1 **ATI C Multiplier**

All trackpad channels can be adjusted globally by modifying the global parameter (Global ATI C).

Although it is recommended to keep the same ATI C value for all trackpad channels, if different values are required (possibly for different trackpads), individual adjustments can be made. The ATI C value for each channel can be adjusted using 8-bit signed values (ATI C individual adjust) as follows:

ATI C = Global + Individual Adjust

debouncing adds too much delay, and fast The ALP channel has its own global ATI C

3.6.2 **ATI Compensation & Auto ATI**

The ATI Compensation value for each channel (ATI compensation) is set by means of an An additional output is provided (Max Touch) automated ATI procedure. The algorithm is and indicates the column and row of the executed after the AUTO ATI bit is set. The ATI channel with the largest touch deviation. This Compensation values are chosen so that each is usually only utilised when implementing count value is close to the selected target value

> The AUTO ATI bit clears automatically on chip when the algorithm has completed.

and the rows are the Rxs. If no touches are The ATI routine will run for the channels of the current mode, for example, if the system is currently sensing the alternate low-power channel, the auto ATI will apply to it, similarly the algorithm will configure the trackpad channels if they are currently active.

> values (ALP ATI compensation) for each enabled Rx.

> The ALP ATI target value applies to each of the individual count values configured for the ALP channel.

> This routine will only execute after the communication window is terminated, and the I2C communication will only resume again once the ATI routine has completed.

3.7.1 **Description**

When enabled (REATI or ALP REATI) the ATI algorithm will be repeated if certain conditions are met. One of the most important features of the Re-ATI is that it allows easy and fast recovery from an incorrect ATI, such as when performing ATI during user interaction with the This could cause the wrong ATI sensor. Compensation to be configured, since the user affects the capacitance of the sensor. A Re-ATI would correct this.

When a Re-ATI is performed on the IQS5xx, a status bit will set momentarily to indicate that







this has occurred (<u>REATI_OCCURRED</u>/ <u>ALP_REATI_OCCURRED</u>).

3.7.2 Conditions for Re-ATI to activate

1. Reference drift

A Re-ATI is performed when the reference of a channel drifts outside of the acceptable range around the ATI Target.

After the second s

The boundaries where Re-ATI occurs for the trackpad channels and for the ALP channels are independently set via the drift threshold value (*Reference drift limit | ALP LTA drift limit*). The Re-ATI boundaries are calculated from the delta value as follows:

Re-ATI Boundary = ATI target ± Drift limit

For example, assume that the ATI target is configured to 800 and that the reference drift value is set to 50. If Re-ATI is enabled, the ATI algorithm will be repeated under the following conditions:

Reference > 850 or Reference < 750

The ATI algorithm executes in a short time, so goes unnoticed by the user.

2. Very large count values

The configurable <u>Max count limit</u> is used to sense for unexpectedly large count values. A Re-ATI is triggered if the max count limit is exceeded for 15 consecutive cycles.

This limit is configured to be a value higher than the maximum count possible through user interaction, plus worst-case noise on the count value, plus headroom. The monitoring of this assists in correcting for a Re-ATI which occurred during a snap press. If this does occur, after removing the snap, the counts are typically very high. If this was not monitored a stuck touch could occur.

3. Decreased count value

A considerable decrease in the count value of a non-snap channel is abnormal, since user interaction increases the count value. Therefore if a decrease larger than the configurable threshold (*Minimum count Re-ATI*

(<u>REATI OCCURRED</u>) is seen on such a channel, it is closely monitored. If this is continuously seen for 15 cycles, it will trigger a Re-ATI. If the channel is a snap channel, this decrease is allowed since snap does cause count values to decrease.

3.7.3 ATI Error

After the ATI algorithm is performed, a check is done to see if there was any error with the algorithm. An ATI error is reported if one of the following is true for any channel after the ATI has completed:

- ATI Compensation <= ReATI lower compensation limit
- > ATI Compensation >= ReATI upper compensation limit
- Count is already outside the Re-ATI range upon completion of the ATI algorithm.

If any of these conditions are met, the corresponding error flag will be set (<u>ATI_ERROR</u> / <u>ALP_ATI_ERROR</u>). The flag status is only updated again when a new ATI algorithm is performed.

Re-ATI will not be repeated immediately if an ATI Error occurs. A configurable time (*Re-ATI retry time*) will pass where the Re-ATI is momentarily suppressed. This is to prevent the Re-ATI repeating indefinitely. An ATI error should however not occur under normal circumstances.

3.7.4 Design requirements

The Re-ATI can be very useful when ATI parameters are selected for which successful Re-ATI operation can be expected. With the conditions for Re-ATI mentioned above, it is clear that when the designer sets the ATI parameters, it is beneficial to select the ATI C and ATI Target so that the resulting ATI Compensation values are near the centre of the This ensures that with changing sensitivity, the ATI Compensation has the ability to increase/decrease in value without it easily becoming 0 or 255. In general, ATI Compensation values between 100 and 150 are desirable as they provide ample room for adjustment. Note that the range is dependent on the sensitivity requirements, and on the capacitance of the sensor.





3.8 Sensing Hardware Settings

Settings specific to the ProxSense® Module transfer characteristics can changed.

The charge transfer frequency (fcc) can be calculated as:

$$f_{cc} = \frac{16.10^6}{(2^{(7-CK_FREQ}) \times (2 + \mathit{UP} + \mathit{PASS} + \mathit{INC_PHASE})} \text{ [Hz]}$$
 where
$$\mathit{UP} = 2^{(\mathit{UPLEN}-2)} \quad \text{(if UPLEN} > 4)$$

$$\mathit{UP} = \mathit{UPLEN} \quad \text{(if UPLEN} \leq 4)$$

$$\mathit{PASS} = 2^{(\mathit{PASSLEN}-2)} \quad \text{(if PASSLEN} > 4)$$

$$\mathit{PASS} = \mathit{PASSLEN} \quad \text{(if PASSLEN} \leq 4)$$

Note: CK_FREQ, UPLEN and PASSLEN are the The modes are best illustrated by means of the numerical values of the settings.

For example, the default frequency is:


$$f_{cc} = \frac{16.10^6}{(2^{(7-7)} \times (2+4+3+0)} = 1.77 MHz$$

The other hardware parameters are not discussed as they should only be adjusted under guidance of Azoteg support engineers.

Sensing Modes

The IQS5xx automatically switches between different charging modes dependent on user interaction and other aspects. This is to allow for fast response, and also low power consumption when applicable. The current mode can be read from the device (CHARGING MODE).

following state diagram.



System Mode State Diagram Figure 4.1





Report Rate 4.1

The report rate for each mode can be adjusted as required by the design. A faster report rate will have a higher current consumption but will give faster response to user interaction. Active mode typically has the fastest report rate, and the other modes are configured according to The master can manage various states and the power budget of the design, and the expected response time.

The report rate is configured by selecting the cycle time (in milliseconds) for each mode:

- > Report rate Active mode
- Report rate Idle touch mode
- > Report rate Idle mode
- Report rate LP1 mode
- Report rate LP2 mode

4.1.1 **Previous Cycle Time**

The achieved report rate can be read (*Previous*) cycle time) from the device each cycle; this is the previous cycles' length in milliseconds. If the desired rate is not achievable, that is, if processing and sensing takes longer than the specified time, a status flag (RR MISSED) indicates that the rate could not be achieved.

4.2 Mode Timeout

The timeout values can be configured, and once these times have elapsed, the system will change to the next state according to the state diagram.

These times are adjusted by selecting a 5.1.3 desired value (in seconds), for the specific timeout:

- Timeout Active mode
- Timeout Idle touch mode
- Timeout Idle mode
- Timeout LP1 mode

Note: the timeout for LP1 is set in multiples of 20s (thus a setting of '30' translates to 600s, or Tx mapping) the first byte relates to the

A timeout value of 255 will result in a 'never' timeout condition.

4.3 **Manual Control**

The default method allows the IQS5xx to automatically switch between modes and update reference values as shown in Figure This requires no interaction from the master to manage the IQS5xx.

implement custom power modes when *Manual* Control is enabled (MANUAL CONTROL). The master needs to control the mode and also manage the (MODE SELECT). reference values by reseeding (RESEED) or manually writing to the reference registers (Reference values).

Trackpad

Configuration

Size Selection 5.1.1

The total number of Rx and Tx channels used for trackpad purposes must be configured (*Total Rx* / *Total Tx*). This gives a rectangular area of channels, formed by rows and columns of Rx and Tx sensors.

5.1.2 Individual Channel Disabling

If the sensor is not a completed rectangle (this could be due to board cut-outs or trackpad shape), channels not implemented but falling within the *Total Rx / Total Tx* rectangle, must be individually disabled (Active channels).

Rx / Tx Mapping

The Rxs and Txs of the trackpad can be assigned to the trackpad in any order to simplify PCB layout and design. Rxs and Txs can however not be interchanged (for example you cannot use both Rxs and Txs for the columns of the trackpad).

For both the mapping registers (Rx mapping / mapping of the first row/column, the next byte in the memory map is the next row/column, and







Example: If a 5x5 trackpad was to be designed with Rx/Tx mapping to columns and rows as shown in Table 5.1, the Rx and Tx mapping registers would need to be set as follows:

5.2.1

This is the property of t

Rx Mapping = {3, 0, 8, 1, 2}

Tx Mapping = {0, 1, 13, 12, 11}

Each value shown here is a byte in the memory map. The rest of the mapping bytes are 'don't care' since they are not used.

Table 5.1 Mapping Example

	Col	Column number (mapped R					
Row number (mapped Tx)	0 (Rx3)	1 (Rx0)	2 (Rx8)	3 (Rx1)	4 (Rx2)		
0 (Tx0)							
1 (Tx1)	5x5 Trackpad						
2 (Tx13)							
3 (Tx12)			·				
4 (Tx11)							

5.1.4 Rx / Tx Selections

On the IQS525 and IQS572, some Rxs can be configured to take on Tx functionality. The preferred option is to keep them as Rxs, but if more Txs are needed in the design, they can be configured as such in the *RxToTx* register. This allows for elongated trackpads or sliders to be implemented on the two devices. The corresponding Rx or Tx number is then used in the mapping registers to configure the order of the electrodes.

5.2 Trackpad Outputs

The channel count variation (deltas) and touch status outputs are used to calculate finger location data.

5.2.1 Number of Fingers

This gives an indication of the number of active finger inputs on the trackpad (*Number of fingers*).

5.2.2 Relative XY

If there is only one finger active, a <u>Relative X</u> and <u>Relative Y</u> value is available. This is a signed 2's complement 16-bit value. It is a delta of the change in X and Y, in the scale of the selected output resolution.

Note: Gestures also use these registers to indicate swipe, scroll and zoom parameters.

5.2.3 Absolute XY

For all the multi-touch inputs, the absolute finger position (*Absolute X/Y*), in the selected resolution (*Resolution X/Y*) of the trackpad, is available.

5.2.4 Touch Strength

This value (<u>Touch strength</u>) indicates the strength of the touch by giving a sum of all the deltas associated with the finger, and therefore varies according to the sensitivity setup of the sensors.

5.2.5 Area

The number of channels associated with a finger is provided here. This area is usually equal to or smaller than the number of touch channels under the finger.

5.2.6 Tracking / Identification

The fingers are tracked from one cycle to the next, and the same finger will be located in the same position in the memory map. The memory location thus identifies the finger.

5.3 Max Number of Multi-touches

The maximum number of allowed multi-touches is configurable (<u>Max multi-touches</u>) up to 5 points. If more than the selected value is sensed, a flag is set (<u>TOO MANY FINGERS</u>) and the XY data is cleared.







5.4 XY Resolution

The output resolution for the X and Y coordinates are configurable (<u>X/Y Resolution</u>). The on-chip algorithms use 256 points between each row and column. The resolution is defined as the total X and total Y output range across the complete trackpad.

5.5 Palm Rejection

A maximum finger size/area (Palm reject threshold) can be set up to allow for palm rejection or similar input suppression. This enabled feature can be or disabled (PALM REJECT), and when a palm reject condition is sensed, a status flag will indicate this result (PALM DETECT). All XY outputs are also suppressed during palm detection. Palm reject is latched on for the timeout period (Palm reject timeout) to prevent erratic behaviour before and after the palm is seen. This timeout sets in increments of 32ms.

5.6 Stationary Touch

A stationary touch is defined as a point that does not move outside of a certain boundary within a specific time. This movement boundary or threshold can be configured (<u>Stationary touch movement threshold</u>), and is defined as a movement in either X or Y in the configured resolution.

The device will switch to *Idle-Touch* mode when a stationary point is detected, where a lower duty cycle can be implemented to save power in applications where long touches are expected.

If movement is detected, a status flag (<u>TP MOVEMENT</u>) is set.

5.7 Multi-touch Finger Split

The position algorithm looks at areas (polygons) of touches and calculates positional data from this. Two fingers in close proximity to each other could have areas touching, which would merge them incorrectly into a single point. A finger split algorithm is implemented to separate these merged polygons into multiple

fingers. There is a <u>finger split aggression factor</u> which can be adjusted to determine how aggressive this finger splitting must be implemented. A value of '0' will not split polygons, and thus merge any fingers with touch channels adjacent (diagonally also) to each other.

5.8 XY Output Flip & Switch

By default, X positions are calculated from the first column (usually Rx0) to the last column. Y positions are by default calculated from the first row (usually Tx0) to the last row. The X and/or Y output can be flipped (FLIP X / FLIP Y), to allow the [0, 0] co-ordinate to be defined as desired. The X and Y axes can also be switched (SWITCH XY AXIS) allowing X to be the Txs, and Y to be along the Rxs.

5.9 XY Position Filtering

Stable XY position data is available from the IQS5xx due to two on-chip filters, namely the Moving Average (MAV) filter, and the Infinite Impulse Response (IIR) filter. The filters are applied to the raw positional data in the aforementioned order. It is recommended to keep both of the filters enabled for optimal XY data.

5.9.1 MAV Filter

If enabled (<u>MAV FILTER</u>), raw XY points from the last two cycles are averaged to give the filter output.

5.9.2 IIR Filter

The IIR filter, if enabled (<u>IIR_FILTER</u>), can be configured to select between a dynamic and a static filter (<u>IIR_SELECT</u>).

The damping factor is calculated from the selected *Beta* as follows:

Damping factor = Beta / 256

5.9.2.1 Dynamic Filter

Relative to the speed of movement of a coordinate, the filter dynamically adjusts the amount of filtering (damping factor) performed.





When fast movement is detected, and quick response is required, less filtering is done. > Similarly, when a co-ordinate is stationary or moving at a slower speed, more filtering can be applied.

The damping factor is adjusted depending on the speed of movement. Three of these parameters are adjustable to fine-tune the dynamic filter if required (<u>XY dynamic bottom beta</u> / <u>XY dynamic lower speed</u> / <u>XY dynamic upper speed</u>).

The speed is defined as the distance (in the selected resolution) travelled in one cycle (pixels/cycle).




Figure 5.1 Dynamic Filter Parameters

5.9.2.2 Static Filter

Co-ordinates filtered with a fixed but configurable damping factor (XY static beta) are obtained when using the static filter. It is recommended that the dynamic filter is used due to the advantages of a dynamically changing damping value.

6 Gestures

The IQS5xx has an on-chip gesture recognition feature. The list of recognisable gestures includes:

- > 1 finger gestures (<u>GESTURE EVENTS 0</u>):
 - A single tap
 - A press and hold
 - Swipe X+
 - Swipe X-
 - Swipe Y+

- Swipe Y-
- > 2 finger gestures (GESTURE EVENTS 1):
 - 2 simultaneous taps
 - Scroll
 - Zoom

Each single finger gesture can individually be enabled and disabled by setting or clearing the corresponding bits in the register <u>SINGLE FINGER GESTURES</u>. The multi finger gestures can be enabled and disabled via the register <u>MULTI FINGER GESTURES</u>.

All gestures are calculated relative to their starting coordinates, i.e., the first coordinate at which the touch was detected. Furthermore, if at any time during a gesture, more than the required number of touches is detected, the gesture will be invalidated.

6.1 Single Tap

The single tap gesture requires that a touch is made and released in the same location and within a short period of time. Some small amount of movement from the initial coordinate must be allowed to compensate for shift in the finger coordinate during the release. This bound is defined in register <u>Tap distance</u>, which specifies the maximum deviation in pixels the touch is allowed to move before a single tap but gesture is no longer valid.

Similarly, the <u>Tap time</u> register defines the maximum duration in ms that will result in a valid gesture. That is, the touch should be released before the time period in <u>Tap time</u> is reached.

A valid single tap gesture will be reported (<u>SINGLE_TAP</u>) in the same processing cycle as the touch release was detected, and will be cleared on the next cycle. No movement will be reported in the relative XY registers (<u>Relative X</u> and <u>Relative Y</u>) during this gesture.

Since the gesture reports after the finger is removed, the location of the tap gesture is placed in the <u>Absolute X/Y</u> registers of finger 1 at this time. With <u>Number of fingers</u> set to 0, this will not look like an active finger, and is just







a repetition of the location of the tap that has occurred for the main controller to utilise

Press and Hold

The same register that defines the bounds for The respective swipe gesture will be reported the press and hold gesture. gesture is no longer valid.

However, if the touch remains within the given It is also possible to generate consecutive bound for longer that the period in ms, defined as the sum of the register values in <u>Tap time</u> gesture by defining the swipe gesture settings and *Hold time*, a press and hold gesture will be reported (PRESS AND HOLD). The gesture will continue to be reported until the touch is released or if a second touch is registered.

No data will be reported in Relative X and Relative Y before the defined maximum hold period is reached, however, the relative data will be reported thereafter. This allows for features such as drag-n-drop.

Swipe (X-, X+, Y-, Y+)

All four swipe gestures work in the same manner and are only differentiated in their direction. The direction is defined with respect to the origin (0, 0) of the trackpad, typically at Rx0, Tx0 (Channel 0). If the touch is moving away from the origin, it is considered a positive swipe (+) and if it is moving towards the origin, it is a negative swipe (-). Whether the swipe is of the type X or Y is defined by which axis the touch is moving approximately parallel to.

A swipe gesture event is only reported when a moving touch meets all three of the following conditions:

- 1. A minimum distance is travelled from its initial coordinates, as defined in pixels by the value in register *Swipe initial distance*.
- 2. The distance in (1) is covered within the time specified in Swipe initial time (in ms).
- 3. The angle of the swipe gesture, as determined by its starting coordinate and the coordinate at which conditions (1) and (2) were first met, does not exceed the

threshold in Swipe angle with regards to at least 1 of the axes. The value in register Swipe angle is calculated as $64 \tan \theta$, where θ is the desired angle (in degrees).

the single tap gesture (Tap distance) is used for for 1 cycle (SWIPE X-, X+, Y- Y+) when all of If the touch these conditions are met. The relative distance deviates more than the specified distance, the travelled will be reported in registers Relative X and Relative Y throughout.

> swipe gesture events during the same swipe in registers **Swipe consecutive distance** [pixels] and Swipe consecutive time [ms]. Once the initial swipe gesture conditions are met as defined above, the parameters of Swipe initial distance [pixels] and Swipe initial time [ms] will be replaced with these. Also, the gesture engine will reset its properties, thus evaluating the current touch's movement as if its initial coordinate was at the point at which the previous swipe gesture was recognised and as if it first occurred at that point in time.

> The consecutive events allow for continuous stream of swipe events for a single action by the user. However, once the initial conditions are satisfied, the direction of the swipe gesture is fixed. For example, if a swipe X+ gesture is recognised by the engine, the consecutive swipe gestures will also be of type X+. And the 3rd condition will only be evaluated against the X axis.

> In the case that only a single event is desired, the settings in *Swipe consecutive distance* can be set to its maximum value and Swipe consecutive time set to zero. This would make it impossible to meet these conditions on a standard trackpad.

6.4 Two Finger Tap

The simultaneous tap gesture simply requires two tap gestures to occur simultaneously. For this reason the gesture uses the same parameters (*Tap distance* and *Tap time*) as that of the tap gesture. It is also confined to the







same conditions for the output to be reported Zoom Consecutive Distance defines the (2 FINGER TAP).

6.5 Scroll

A scroll gesture is identified bv simultaneous and parallel moving touches. A Switching from a zoom in to a zoom out touches in pixels exceeds the value stored in before the switch can occur. scroll gesture will continuously be reported until the same. one of the touches is released or if a zoom gesture is validated.

Similar to the swipe gestures, the scroll gestures are also bounded by a given angle to gesture. the axis (Scroll angle). The value in this register is calculated as $64 \tan \theta$, where θ is the desired **6.7 Switching Between Gestures** angle (in degrees). This condition is only enforced during the initial validation stage of the scroll gesture.

(vertical scroll) data. For instance, a positive without releasing any touches. relative X value will correspond with the direction of a swipe X+ gesture. Unlike the swipe gestures, a scroll gesture may alternate between a positive and negative direction > without requiring the validation of the initial > conditions. However, switching between the > axes will require the validation.

At any given stage during a scroll gesture, only > the axis applicable to the gesture will have a > non-zero value in its relative data register. For example, a scroll parallel to the X-axis will have a non-zero Relative X value and a zero Relative Y value. This value relates to the movement of the scroll gesture.

6.6 Zoom

Zoom gestures require two touches moving toward (zoom out) or away (zoom in) from each other. Similar to the scroll and swipe gestures, the zoom requires that an initial distance threshold in the register **Zoom** initial distance [pixels] is exceeded before a zoom gesture is Thereafter, the register reported (ZOOM).

distance threshold for each zoom event that follows the initial event. The direction/axis along which the two touches move is not relevant.

scroll gesture will be reported (SCROLL) once gesture, or vice versa, requires that the initial the average distance travelled by the two conditions be met in the opposite direction register Scroll initial distance. Thereafter, a between a zoom and a scroll gesture requires

> The size of each zoom event will be reported in Relative X, where the negative sign indicates a zoom out gesture and a positive sign a zoom in

For all single finger gestures, it is necessary to release all touches before any new gesture can be made and validated. However, for the scroll The direction of the scroll gesture is defined by and zoom gestures, it is possible to alternate the reported relative X (horizontal scroll) and Y between the gestures and their directions

> switch between multi-touch gestures includes

- Alternating between scroll axes
- Alternating between zoom in and out
- Going from a scroll to a zoom gesture
- Going from a zoom to a scroll gesture
- Releasing any one of the two touches
- Having more than 2 touches on the trackpad at any given moment.

A release of 1 of the touches will require a new touch be generated before any multi-touch gesture can be validated. The multi-touch gestures require 2, and only 2, touches at all time during the gesture.

Additional Features 7

Non-volatile Defaults

The designer can use the supplied GUI to easily configure the optimal settings for different setups. The design specific firmware is then exported by the GUI and programmed







onto the IQS5xx. These parameters are used or a mechanical switch/button for example. For as the default values after start-up, without more details on the input see Section 7.11. requiring any setup from the master.

Two registers (Export file version number) are available so that the designer can label and identify the exported HEX file with the corresponding settings. This allows the master After a reset, the SHOW RESET bit will be set configuration as required.

7.2 Automated Start-up

The IQS5xx is programmed with the trackpad application firmware, bundled with settings specifically configured for the current hardware as described in Section 7.1. After power-up the The IQS5xx can be reset by means of an I2C IQS5xx will automatically use the settings and command (RESET). configure the device accordingly.

7.3 Suspend

The IQS5xx can be placed into a suspended the IQS5xx. For more details see Section 0. state (SUSPEND). No processing is performed, minimal power is consumed (<1uA), and the 7.5 Watchdog Timer (WDT) device retains existing data.

triggered after the IQS5xx is woken from ESD events or similar scenarios. suspend, since it cannot be guaranteed that the watchdog timeout is set to about 500ms. The reference values are still relevant.

7.3.1 I²C Wake

The device can be woken from suspend by addressing it on the I²C bus. It will respond with a not-acknowledge (NACK) on the first addressing attempt and with an acknowledge The IQS5xx has immunity to high power RF (ACK) on the second addressing attempt, providing that there was at least a time difference of ~150us between the two addressing attempts. The suspend bit must Place a 100pF in parallel with the 1uF ceramic then be disabled in that communication session to resume operations.

7.3.2 **Switch Input Pin Wake**

The SW IN input pin can be used to wake the device from suspend (when enabled). The input can be connected to an alternate longrange proximity sensing IC (such as IQS211),

Reset 7.4

7.4.1 **Reset Indication**

to verify if the device firmware has the intended by the system to indicate the reset event occurred. This bit will clear when the master sets the ACK RESET, if it becomes set again, the master will know a reset has occurred, and can react appropriately.

7.4.2 **Software Reset**

7.4.3 **Hardware Reset**

The NRST pin (active low) can be used to reset

A watchdog timer is implemented to prevent An automatic reseed of the trackpad is any stuck conditions which could occur from The watchdog can be disabled (WDT), however, this needs to be programmed into the non-volatile defaults, since this only takes effect after a reset.

7.6 RF Immunity

noise. To improve the RF immunity, extra decoupling capacitors are suggested on V_{REG} and V_{DDHI} .

on V_{REG} . Place a 1uF ceramic on V_{DDHI} . All decoupling capacitors should be placed as close as possible to the V_{DDHI} and V_{REG} pads.

PCB ground planes also improve noise immunity.





7.7 Additional Non-Trackpad Channels

be used to design additional buttons or sliders. project is 15 (decimal) for all devices. Note that the channels will still provide XY data output, which can be ignored (or utilised) by the 7.9.3 master

7.8 Bootloader

A bootloader is included to allow easy application firmware upgrading via the I²C bus, without the need to access the PGM and NRST pins for reprogramming.

For information. refer more to documentation "IQS5xx I2C Bootloader v2.x Technical User Guide.pdf'.

7.8.1 **Bootloader Status**

confirm the availability/presence of bootloader (Bootloader status).

Table 7.1 **Bootloader Status**

Register value	Status
0xA5	Bootloader is available
0xEE	No bootloader

*Note the bootloader is available on the standard IQS5xx-B000 firmware; this could possibly be unavailable on custom firmware versions.

7.9 Version Information

7.9.1 **Product Number**

The different IQS5xx devices can be identified by their relevant product numbers.

Table 7.2 **Product Number**

Product Number (decimal)	Device
40	IQS550
58	IQS572
52	IQS525

7.9.2 **Project Number**

Unused projected capacitance channels can The project number for the generic B000

Major and Minor Versions

These will vary as the B000 is updated, this datasheet relates to the version as indicated at the bottom of the Overview Section 1.

7.10 Unique ID

A 12-byte unique ID can be read from memory map address 0xF000 - 0xF00B. This number the gives each individual IC a unique identifier.

7.11 Switch Input

The SW IN (switch input) pin, when enabled (SW INPUT), will display the state of the input The bootloader status register can be used to pin to the master controller (SWITCH STATE). the This state is updated before each I²C session.

> The input can be configured as active LOW or active HIGH (SW INPUT SELECT). For active LOW, an internal pull-up resistor (typical value of $40k\Omega$) is connected to the SW IN pin.

> A change in the state of the SW IN can also trigger an event, see Section 8.8.1. This input can be used as an additional switch or proximity sensor and has the ability to wake the IQS5xx from the extreme (<1uA) low power suspend state.

I₂C 8

The IQS5xx communicates via the standard I²C communication protocol.

Clock stretching can occur, thus monitoring the availability of the SCL is required, as per standard I²C protocol.

8.1 Data Ready (RDY)

An additional RDY I/O indicates (active HIGH) when the communication window is available with new data for optimal response. Polling can however be used but is not recommended. RDY should be connected to an interrupt-on-





change input for easier implementation and 8.5 I2C Write optimal response time.

Slave Address

The default 7-bit device address is '1110100'. The device address can be modified during programming. The full address byte will thus be 0xE9 (read) or 0xE8 (write).

8.3 16-bit Addressing

The I²C employs a 16-bit address to access all individual registers in the memory map.

8.4 I²C Read

The master can read from the device at the current address if the address is already set up. or when reading from the default address.



Current Address Read Figure 8.1

The master can perform a random read by specifying the address. A WRITE is performed to set up the address, and a repeated start is used to initiate the READ section.




Figure 8.2 Random Read

8.4.1 **Default Read Address**

When a new communication window begins, the configurable *default read address* is used if sensed (*EVENT MODE*). window, allowing for faster data reading.

The master uses a *Data Write* to write settings to the device. A 16-bit data address is always required, followed by the relevant data bytes to write to the device.



Figure 8.3 **Data Write**

8.6 I²C Timeout

If the communication window is not serviced within the I^2C timeout period (in milliseconds), the session is ended (RDY goes LOW), and processing continues as normal. This allows the system to continue and keep reference values up to date even if the master is not responsive.

8.7 **End of Communication** Session / Window

Unlike the previous A000 implementation, an I²C STOP will **not** terminate the communication window. When all required I²C transactions have been completed, the communication session must be terminated manually. This is achieved by sending the End Communication Window command, by writing a single byte (any data) to the address 0xEEEE, followed by a This will end the communication window, RDY will go low and the IQS5xx will continue with a new sensing and processing cycle.

8.8 **Event Mode Communication**

The device can be set up to bypass the communication window when no activity is This is usually a current address read is performed (no enabled since the master does not want to be address is specified). If an application will interrupted unnecessarily during every cycle if always read from a specific register, the no activity occurred. The communication will IQS5xx can be configured to point to the resume (RDY will indicate available data) if an required register, negating the need to specify enabled event occurs. It is recommended that the address at each new communication the RDY be placed on an interrupt-on-pinchange input on the master.





8.8.1 **Events**

to trigger communication, they are:

- event > Trackpad events (TP EVENT): triggered if there is a change in X/Y value, or if a finger is added or removed from the trackpad
- > Proximity events (PROX EVENT): event only For optimal program flow, it is suggested that proximity state
- triggers if a channel has a change in a touch and Event Mode is active.
- Snap (SNAP EVENT): event only triggers if a channel has a change in a snap state
- indicate the Re-ATI (REATI OCCURRED).
- event given on state change
- state.

The proximity/touch/snap events are therefore mostly aimed at channels that are used for traditional buttons, where you want to know only when a status is changed.

8.8.2 **Force Communication**

Numerous events can be individually enabled The master can initiate communication with the IQS5xx, even while RDY is LOW. The IQS5xx will clock stretch until an appropriate time to complete the I²C transaction. The master firmware will not be affected (as long as clock stretching is correctly handled).

triggers if a channel has a change in a RDY is used to sync on new data from the IQS5xx. The forced method is only Touch events (TOUCH EVENT): event only recommended if the master must perform I2C

NOTE: If the IQS5xx is in a low-power state when the master forces the communication, the first addressing will respond with a NACK. The master must repeat Re-ATI (REATI EVENT): one cycle is given to the addressing (wait a minimum of 150us after the I²C occurred STOP before retrying), and the IQS5xx will be ready and ACK the transaction.

> Proximity on ALP (ALP PROX EVENT): Figure 8.4 shows a forced communication transaction. Communication starts with RDY = Switch input (SW INPUT EVENT): event LOW. The IQS5xx is in a low power state on triggers if there is a change in the input pin the first request, and a NACK is sent. After the second request the IQS5xx responds with an ACK. The IQS5xx clock stretches until the communication window becomes When the communication window is ready, the clock is released (and RDY is set) and the transaction completes as normal.



Figure 8.4 Forced communication





8.9 Memory Map Registers

The registers available in the memory map, via I^2C , are provided in this section. The memory map starts with a READ-ONLY section, followed by a READ/WRITE section. The read/write permissions are indicated by the

shading in the 'R' (read) and/or 'W' (write) columns.

Certain registers in the memory map have defaults loaded from non-volatile memory, which can be configured during programming; these are highlighted also in the 'E²' column.





Table 8.1 Direct-Addressable Memory Map

					тар							
Address	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0	Details	R	W	E^2
0x0000 - 0x0001			F	Product num	nber (2 bytes	3)						
0x0002 - 0x0003				(See <u>7.9</u>)								
0x0004				Major	version							
0x0005				Minor	version							
0x0006				Bootload	der status				(See <u>7.8.1</u>)			
0x0007 - 0x000A				Open (4 bytes)							
0x000B		Max touc	h column			Max to	uch row		(See <u>3.5.5</u>)			
0x000C				Previous cy	cle time [ms]			(See <u>4.1.1</u>)			
0x000D	-	-	SWIPE_ Y-	SWIPE_ Y+	SWIPE_ X+	SWIPE_ X-	PRESS_ AND_ HOLD	SINGLE _TAP	Gesture Events 0			
0x000E	-	_	-	-	-	ZOOM	SCROLL	2_ FINGER_ TAP	Gesture Events 1			
0x000F	SHOW_ RESET	ALP_ REATI_ OCCUR RED	ALP_ ATI_ ERROR	REATI_ OCCUR RED	ATI_ ERROR	CHA	ARGING_M	DDE	System Info 0			
0x0010	-	-	SWITCH _STATE	SNAP_ TOGGLE	RR_ MISSED	TOO_ MANY_ FINGERS	PALM_ DETECT	TP_ MOVE- MENT	System Info 1			
0x0011				Number	of fingers				(See <u>5.2.1</u>)			
0x0012 - 0x0013			R	elative X [pi	xels] (2 byte	es)			(0. 5.0.0)			
0x0014 - 0x0015			R	elative Y [pi	xels] (2 byte	es)			(See <u>5.2.2)</u>			
0x0016 - 0x0017	Absolute X position [pixels] (2 bytes)								(See <u>5.2.3</u>)			
0x0018 - 0x0019		Absolute Y position [pixels] (2 bytes)										
0x001A - 0x001B				Touch stren	gth (2 bytes)			(See <u>5.2.4</u>)			
0x001C				Touch a	rea / size				(See <u>5.2.5</u>)			





					peat:					_
0x001D : 0x0038					ı					
0x0039 - 0x0058										
0x0059 - 0x0076				Touch statu	us (30 bytes))			(See <u>8.10.5</u>)	
0x0077 - 0x0094				Snap statu	s (30 bytes)					
0x0095 - 0x01C0				Count value	s (300 bytes	5)				
0x01C1 - 0x02EC				Delta values	s (300 bytes)			(See <u>8.10.6</u>)	
0x02ED - 0x02EE			A	ALP count v	alue (2 bytes	s)				
0x02EF - 0x0302			ALP in	dividual cou	nt values (20) bytes)			(See <u>3.3.2</u>)	
0x0303 - 0x042E			(See <u>8.10.6</u>)							
0x042F - 0x0430				ALP LTA	(2 bytes)				(See <u>3.4.2</u>)	
0x0431	ACK_ RESET	-	AUTO_ ATI	ALP_ RESEED	RESEED	N	MODE_SELE	СТ	System Control 0	
0x0432	-	-	-	-	-	-	RESET	SUSPEND	System Control 1	
0x0433 - 0x0434				Open (2 bytes)					
0x0435 - 0x043E			ALP	ATI comper	nsation (10 b	oytes)			(0 2.6.2)	
0x043F - 0x04D4			АТ	I compensa	tion (150 by	tes)			(See <u>3.6.2</u>)	
0x04D5 - 0x56A										
0x056B	-	-	(See <u>3.6.1</u>)							
0x056C	-	-								
0x056D - 0x056E			(500 2 6 2)							
0x056F - 0x0570				ALP ATI tar	get (2 bytes)			(See <u>3.6.2</u>)	
0x0571				Referenc	e drift limit				(See <u>3.7.2</u>)	
0x0572				ALP LTA	A drift limit				(SEE <u>S.1.2</u>)	





0x0573			Re-	ATI lower co	mpensation	limit				
0x0574			Re-/	ATI upper co	mpensation	limit			(See <u>3.7.3</u>)	
0x0575 - 0x0576				Max count li	mit (2 bytes)			(See <u>3.3.3</u> and <u>3.7.2</u>)	
0x0577				Re-ATI re	try time [s]				(See <u>3.7.3</u>)	
0x0578 - 0x0579										
0x057A - 0x057B										
0x057C - 0x057D			Report rat	te [ms] – Idle	e touch mod	e (2 bytes)				
0x057E - 0x057F			Report	rate [ms] –	Idle mode (2	2 bytes)			(See <u>4.1</u>)	
0x0580 - 0x0581			Report	rate [ms] –	LP1 mode (2	2 bytes)				
0x0582 - 0x0583			Report	rate [ms] –	LP2 mode (2	2 bytes)				
0x0584			7	imeout [s] -	- Active mod	е			(See <u>4.2</u>)	
0x0585			Tir	neout [s] – I	dle touch mo	ode				
0x0586				Timeout [s]	Idle mode	!				
0x0587			Ti	meout [x 20	s] – LP1 mo	de				
0x0588			F	Reference u	pdate time [s	5]			(See <u>3.4.1</u>)	
0x0589				Snap tir	neout [s]				(See <u>3.5.3</u>)	
0x058A				I ² C time	out [ms]				(See <u>8.6</u>)	
0x058B - 0x058D				Open (3 bytes)					
0x058E	MANUAL_ CONTROL	SETUP_ COMPLETE	WDT	SW_ INPUT_ EVENT	ALP_ REATI	REATI	SW_ INPUT_ SELECT	SW_ INPUT	System Config 0	
0x058F	PROX_ TOUCH_ SNAP_ EVENT								System Config 1	
0x0590 - 0x0591										
0x0592 - 0x0593	Snap threshold (2 bytes)								(See <u>3.5.3</u>)	
0x0594	Prox threshold - trackpad								(See <u>3.5.1</u>)	
0x0595	Prox threshold - ALP channel								(See <u>S.S.1</u>)	
0x0596			G	lobal touch	multiplier - s	et			(See <u>3.5.2</u>)	
0x0597				(555 <u>5.5.2</u>)						





0x0598 - 0x062D		lı								
0x062E			Mi	inimum cour	nt Re-ATI de	lta			(See <u>3.7.2</u>)	
0x062F -				Open (2 hytoo)				(5.5.5 <u>2.1.1.2</u>)	
0x0631				Open (3 bytes)					
0x0632	-	-	-	-	ALP_ COUNT _FILTER	IIR_ SELECT	MAV_ FILTER	IIR_ FILTER	Filter Settings 0	
0x0633				XY sta	tic beta				(See <u>5.9.2.2</u>)	
0x0634				ALP co	unt beta				(See <u>3.3.2</u>)	
0x0635				ALP1 L	TA beta				(500 3 4 2)	
0x0636				ALP2 L	TA beta				(See <u>3.4.2</u>)	
0x0637			XY	dynamic filte	er – bottom l	oeta				
0x0638			XY	dynamic filte	er– lower sp	eed			(See 5.9.2.1)	
0x0639 – 0x063A			XY dyna	amic filter– u	pper speed	(2 bytes)			,	
0x063B - 0x063C				Open (2	2 bytes)					
0x063D				Tota	al Rx				(See <u>5.1.1</u>)	
0x063E				Tota	al Tx				(000 <u>0.7.7</u>)	
0x063F - 0x0648				Rx mappin	g (10 bytes)				(See <u>5.1.3</u>)	
0x0649 - 0x0657				Tx mapping	g (15 bytes)				(See <u>5.7.5</u>)	
0x0658	CHARGE _TYPE	RX_ GROUP	PROX_ REVERSE	ALP	-	-	-	-	ALP Channel Setup 0	
0x0659	_	_	_	_	_	_	ALP_ RX9	ALP_ RX8		
0.0054	ALP_	ALP_	ALP_	ALP_	ALP_	ALP_	ALP_	ALP_	ALP Rx Select	
0x065A	RX7	RX6	RX5	RX4	RX3	RX2	RX1	RX0		
0x065B	-	ALP_ TX14	ALP_ TX13	ALP_ TX12	ALP_ TX11	ALP_ TX10	ALP_ TX9	ALP_ TX8		
0x065C	ALP_ TX7	ALP_ TX6	ALP_ TX5	ALP_ TX4	ALP_ TX3	ALP_ TX2	ALP_ TX1	ALP_ TX0	ALP Tx Select	
0x065D	Rx7/Tx2	Rx6/Tx3	Rx5/Tx4	Rx4/Tx5	Rx3/Tx6	Rx2/Tx7	Rx1/Tx8	Rx0/Tx9	<u>RxToTx</u>	
0.0000	Rx7/Tx9 Rx6/Tx10 Rx5/Tx11 Rx4/Tx12 Rx3/Tx13 Rx2/Tx14								KATUIX	
0x065E	Open									
0x065F	-	-	ND	-	-	RX_ FLOAT	0	0	<u>Hardware</u> <u>Settings A</u>	
0x0660	-		CK_FREQ		-	-	ANA_ DEAD_ TIME	INCR_ PHASE	<u>Hardware</u> <u>Settings B1</u>	





0x0661	-		CK_FREQ		-	-	ANA_ DEAD_ TIME	INCR_ PHASE	Hardware Settings B2 (ALP)	
0x0662	STAB	_TIME	OPAMI	P_BIAS		VT	RIP	<u>Hardware</u> <u>Settings C1</u>		
0x0663	STAB _.	_TIME	OPAMI	P_BIAS		VT	RIP	Hardware Settings C2 (ALP)		
0x0664	-		UPLEN		-		PASSLEN		<u>Hardware</u> <u>Settings D1</u>	
0x0665	-		UPLEN		-		PASSLEN		Hardware Settings D2 (ALP)	
0x0666 - 0x0668				Open (3 bytes)					
0x0669	-	-	-	-	PALM_ REJECT	SWITCH _XY_ AXIS	FLIP_Y	FLIP_X	XY Config 0	
0x066A				Max mult	ti-touches				(See <u>5.3</u>)	
0x066B			Fir	nger split ag	gression fac	otor			(See <u>5.7</u>)	
0x066C	Palm reject threshold									
0x066D	Palm reject timeout [x 32ms]							(See <u>5.5</u>)		
0x066E - 0x066F			ΧF	Resolution [բ	pixels] (2 byt	tes)			(0 5.4)	
0x0670 - 0x00671			ΥF	Resolution [p	pixels] (2 byt	tes)			(See <u>5.4</u>)	
0x0672			Stationary	touch move	ment thresh	old [pixels]			(See <u>5.6</u>)	
0x0673 - 0x0674				Open (2 bytes)					
0x0675 - 0x0676			De	fault read ac	ddress (2 by	tes)			(See <u>8.4.1</u>)	
0x0677 - 0x0678			Expor	t file versior	n number (2	bytes)			(See <u>7.1</u>)	
0x0679		PROX_	DB_SET			PROX_D	B_CLEAR		Prox debounce	
0x067A	SNAF SI	P_DB_ ET		H_DB_ ET		P_DB_ EAR		H_DB_ EAR	Touch snap debounce	
0x067B - 0x0698		Active channels (30 bytes)								
0x0699 - 0x06B6			Snap	enabled ch	annels (30 k	oytes)			(See <u>8.10.5</u>)	
0x06B7	-	-	SWIPE_ Y-	SWIPE_ Y+	SWIPE_ X+	SWIPE_ X-	TAP_ AND_ HOLD	SINGLE _TAP	Single Finger Gestures	





0x06B8	-	-	-	-	-	ZOOM	SCROLL	2_ FINGER_ TAP	Multi Finger Gestures		
0x06B9 - 0x06BA			(see <u>6.1</u> and								
0x06BB - 0x06BC			<u>6.4</u>)								
0x06BD - 0x06BE				Hold time [r	ms] (2 bytes)				(see <u>6.2</u>)		
0x06BF - 0x06C0			Sw	pe initial tim	ne [ms] (2 by	tes)					
0x06C1 - 0x06C2			Swipe	initial distan	ce [pixels] (2	2 bytes)					
0x06C3 - 0x06C4			Swipe	consecutive	time [ms] (2	2 bytes)			(see <u>6.3</u>)		
0x06C5 - 0x06C6			Swipe cor	secutive dis	stance [pixels	s] (2 bytes)					
0x06C7			,	Swipe angle	[64tan(deg)]					
0x06C8 - 0x06C9			Scroll	nitial distan	ce [pixels] (2	bytes)			(see <u>6.5</u>)		
0x06CA				Scroll angle	[64tan(deg)]					
0x06CB - 0x06CC			(see <u>6.6</u>)								
0x06CD - 0x06CE											
0x06CF				Open	(1 byte)						

8.10 Memory Map Bit / Register Definitions

The bit definitions for the registers in the memory map are explained in this section. Also certain parameters that have a multiple number of bytes (registers) are also explained here.

8.10.1 Gesture Events 0

	Gesture Events 0								
Bit	7	6	5	4	3	2	1	0	
Name	-	-	SWIPE_ Y-	SWIPE_ Y+	SWIPE_ X+	SWIPE_ X-	PRESS_ AND_ HOLD	SINGLE_ TAP	

- > Bit 7-6: Unused
- > Bit 5: **SWIPE_Y-:** Swipe in negative Y direction status
 - 0 = No gesture
 - 1 = Swipe in negative Y-direction occurred





- > Bit 4: **SWIPE_Y+:** Swipe in positive Y direction status
 - 0 = No gesture
 - 1 = Swipe in positive Y-direction occurred
- > Bit 3: **SWIPE_X+:** Swipe in positive X direction status
 - 0 = No gesture
 - 1 = Swipe in positive X-direction occurred
- > Bit 2: **SWIPE_X-:** Swipe in negative X direction status
 - 0 = No gesture
 - 1 = Swipe in negative X direction occurred
- > Bit 1: PRESS_AND_HOLD: Press and hold gesture status
 - 0 = No gesture
 - 1 = Press and hold occurred
- > Bit 0: **SINGLE_TAP:** Single tap gesture status
 - 0 = No gesture
 - 1 = Single tap occurred

8.10.2 Gesture Events 1

		Gesture Events 1										
Bit	7	6	5	4	3	2	1	0				
Name	-	-	-	-	-	ZOOM	SCROLL	2_ FINGER_ TAP				

- > Bit 7-3: Unused
- > Bit 2: **ZOOM:** Zoom gesture status
 - 0 = No gesture
 - 1 = Zoom gesture occurred
- > Bit 1: SCROLL: Scroll status
 - 0 = No gesture
 - 1 = Scroll gesture occurred
- > Bit 0: **2_FINGER_TAP:** Two finger tap gesture status
 - 0 = No gesture
 - 1 = Two finger tap occurred

8.10.3 System Info 0

		System Info 0										
Bit	7	7 6 5 4 3 2 1 0										
Name	SHOW_ RESET	ALP_ REATI_ OCCURRED	ALP_ ATI_ ERROR	REATI_ OCCURRED	ATI_ ERROR	CHARGING_MODE						

- > Bit 7: SHOW_RESET: Indicates a reset
 - 0 = Reset indication has been cleared by host, writing to 'Ack Reset' bit





- 1 = Reset has occurred, and indication has not yet been cleared by host
- > Bit 6: ALP_REATI_OCCURRED: Alternate Low Power channel Re-ATI status
 - 0 = No Re-ATI
 - 1 = Re-ATI has just completed on the alternate LP channel
- > Bit 5: ALP ATI ERROR: Alternate Low Power channel ATI error status
 - 0 = Most recent ATI process was successful
 - 1 = Most recent ATI process had errors
- > Bit 4: **REATI_OCCURRED:** Trackpad Re-ATI status
 - 0 = No Re-ATI
 - 1 = Re-ATI has just completed on the trackpad
- > Bit 3: ATI_ERROR: Error condition seen on latest trackpad ATI procedure
 - 0 = Most recent ATI process was successful
 - 1 = Most recent ATI process had errors
- > Bit 2-0: CHARGING MODE: Indicates current mode
 - 000 = Active mode
 - 001 = Idle-Touch mode
 - 010 = Idle mode
 - 011 = LP1 mode
 - 100 = LP2 mode

8.10.4 System Info 1

		System Info 1										
Bit	7	6	5	4	3	2	1	0				
Name	-	-	SWITCH_ STATE	SNAP_ TOGGLE	RR_ MISSED	TOO_ MANY_ FINGERS	PALM_ DETECT	TP_ MOVE- MENT				

- > Bit 7-6: Unused
- > Bit 5: **SWITCH_STATE:** Status of input pin SW IN
 - 0 = SW IN is LOW
 - 1 = SW IN is HIGH
- > Bit 4: **SNAP_TOGGLE:** Change in any snap channel status
 - 0 = No change in any channels' snap status
 - 1 = At least one channel has had a change in snap status
- > Bit 3: **RR_MISSED:** Report rate status
 - 0 = Report rate has been achieved
 - 1 = Report rate was not achieved
- > Bit 2: TOO_MANY_FINGERS: Total finger status
 - 0 = Number of fingers are within the max selected value
 - 1 = Number of fingers are more than the max selected
- > Bit 1: PALM_DETECT: Palm detect status
 - 0 = No palm reject detected
 - 1 = Palm reject has been detected





- > Bit 0: **TP_MOVEMENT:** Activity or movement on trackpad status
 - 0 = No finger or no movement of fingers on trackpad
 - 1 = Movement of finger(s) seen on trackpad

8.10.5 Individual Channel Status / Config Bit Definitions

For all status outputs or configuration parameters where one bit relates to one channel, the structure is defined as shown in the tables below. Each row has a 16-bit value where the status/config of each bit corresponds to the status/config of the corresponding column.

Table 8.2 Status Bytes

Address	Data
X	Status/Config [Row0] – High Byte
X+1	Status/Config [Row0] – Low Byte
X+2	Status/Config [Row1] – High Byte
X+3	Status/Config [Row1] – Low Byte
	:
X+28	Status/Config [Row14] – High Byte
X+29	Status/Config [Row14] – Low Byte

^{*}Note that the proximity status bits have two extra bytes appended to the end to include the proximity status bit of the ALP channel. Its status is located at Bit0.

Table 8.3 Status/Config Bit Definitions

	High byte							Low byte								
	-	-	-	-	-	-	Col9	Col8	Col7	Col6	Col5	Col4	Col3	Col2	Col1	Col0
Row Z	Z Bit15 Bit14 Bit13 Bit12 Bit11 Bit10 Bit9 Bit8								Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0

^{*}Note that if the XY axes are switched, these registers do NOT switch. This means that the bits will always link to Rxs, and the registers will always link to Txs.

For the example above the parameter shown in the grey box in the table above is associated with the Z^{th} Tx and the 6^{th} Rx.

The bit definitions for these parameters are shown in the table below.

Table 8.4 Channel Status/Config Bit Definitions

Parameter	Bit = 0	Bit = 1
Prox status	Channel does not have a proximity	Channel does have a prox
Touch status	Channel does not have a touch	Channel does have a touch
Snap status	Channel does not have a snap	Channel does have a snap
Active channels	Channel disabled	Channel enabled
Snap enabled channels	Snap feature disabled on channel	Snap feature enabled on channel





8.10.6 Count / Delta / Reference Data

For the count, delta and reference values (2 bytes per channel), the structure is defined as shown in the table below.

Table 8.5 Count / Delta / Reference Value Bytes

Byte number	Data	Description
X	Count/Delta/Reference value[0][0] - High Byte	Count, delta or reference @ first Tx,
X+1	Count/Delta/Reference value[0][0] - Low Byte	and first Rx (thus top left)
X+2	Count/Delta/Reference value[0][1] - High Byte	Count, delta or reference @ first Tx,
X+3	Count/Delta/Reference value[0][1] - Low Byte	and 2nd Rx
:	:	:
X+298	Count/Delta/Reference value[14][9] – High Byte	Count, delta or reference @ last Tx,
X+299	Count/Delta/Reference value[14][9] – Low Byte	and last Rx (thus bottom right)

8.10.7 System Control 0

		System Control 0								
Bit	7	7 6 5 4 3 2 1 0								
Name	ACK_ RESET	-	AUTO_ ATI	ALP_ RESEED	RESEED	1	MODE_SELEC	Г		

- > Bit 7: ACK_RESET: Acknowledge a reset
 - 0 = nothing
 - 1 = Acknowledge the reset by clearing SHOW RESET bit
- > Bit 6: Unused
- > Bit 5: AUTO_ATI: Run ATI algorithm
 - 0 = nothing
 - 1 = Run ATI algorithm (affected channels depending on current mode)
- > Bit 4: ALP_RESEED: Reseed alternate low power channel
 - 0 = nothing
 - 1 = reseed the LTA of the alternate LP channel
- > Bit 3: **RESEED:** Reseed trackpad channels
 - 0 = nothing
 - 1 = Reseed reference values of trackpad
- > Bit 2-0: **MODE_SELECT:** Select mode (only applies in *Manual Mode*)
 - 000 = Active mode
 - 001 = Idle-Touch mode
 - 010 = Idle mode
 - 011 = LP1 mode
 - 100 = LP2 mode





8.10.8 System Control 1

		System Control 1									
Bit	7	6	5	4	3	2	1	0			
Name	-	-	-	-	-	-	RESET	SUSPEND			

- > Bit 7-2: Unused
- > Bit 1: RESET: Reset the IQS5xx
 - 0 = nothing
 - 1 = Reset the device after the communication window terminates
- > Bit 0: **SUSPEND:** Suspend IQS5xx
 - 0 = nothing
 - 1 = Place IQS5xx into suspend after the communication window terminates

8.10.9 System Config 0

		System Config 0									
Bit	7	6	5	4	3	2	1	0			
Name	MANUAL_ CONTROL	SETUP_ COMPLETE	WDT	SW_ INPUT_ EVENT	ALP_ REATI	REATI	SW_ INPUT_ SELECT	SW_ INPUT			

- > Bit 7: MANUAL_CONTROL: Override automatic mode switching
 - 0 = Modes are automatically controlled by IQS5xx
 - 1 = Manual control of modes are handled by host
- > Bit 6: **SETUP_COMPLETE**: Device parameters are set up
 - 0 = IQS5xx will remain in I²C setup window (no processing yet)
 - 1 = Setup is complete, run auto-start procedure
- > Bit 5: WDT: Watchdog timer enable/disable
 - 0 = Watchdog is disabled (only disables after a reset)
 - 1 = Watchdog is enabled
- > Bit 4: **SW_INPUT_EVENT:** Enable switch state change triggering event
 - 0 = Toggle of SW IN does not trigger an event
 - 1 = Toggle of SW IN triggers an event
- > Bit 3: ALP_REATI: Enable/Disable automatic Re-ATI on alternate LP channel
 - 0 = Re-ATI is disabled for alternate LP channel
 - 1 = Re-ATI is enabled for alternate LP channel
- > Bit 2: **REATI:** Enable/Disable automatic Re-ATI on trackpad
 - 0 = Re-ATI is disabled for trackpad channels
 - 1 = Re-ATI is enabled for trackpad channels
- > Bit 1: **SW_INPUT_SELECT:** Select I/O polarity
 - 0 = SW IN is active LOW
 - 1 = SW IN is active HIGH
- > Bit 0: **SW INPUT:** Enable/disable the input switch function on pin SW IN





- 0 = Input disabled
- 1 = Input enabled

8.10.10 System Config 1

		System Config 1									
Bit	7	6	5	4	3	2	1	0			
Name	PROX_ EVENT	TOUCH_ EVENT	SNAP_ EVENT	ALP_ PROX_ EVENT	REATI_ EVENT	TP_ EVENT	GESTURE_ EVENT	EVENT_ MODE			

- > Bit 7: **PROX_EVENT:** Enable proximity triggering event
 - 0 = Toggle of proximity status does not trigger an event
 - 1 = Toggle of proximity status triggers an event
- > Bit 6: **TOUCH_EVENT:** Enable touch triggering event
 - 0 = Toggle of touch status does not trigger an event
 - 1 = Toggle of touch status triggers an event
- > Bit 5: **SNAP_EVENT:** Enable snap triggering event
 - 0 = Toggle of snap status does not trigger an event
 - 1 = Toggle of snap status triggers an event
- > Bit 4: ALP_PROX_EVENT: Enable alternate LP channel proximity triggering event
 - 0 = Toggle of alternate channel proximity status does not trigger an event
 - 1 = Toggle of alternate channel proximity status triggers an event
- > Bit 3: **REATI_EVENT:** Enable Re-ATI generating an event
 - 0 = Re-ATI occurring does not trigger an event
 - 1 = Re-ATI occurring triggers an event
- > Bit 2: TP_EVENT: Enable trackpad events
 - 0 = Trackpad actions will not trigger event
 - 1 = Trackpad actions trigger event
- > Bit 1: **GESTURE_EVENT:** Enable gesture events
 - 0 = Gestures will not trigger event
 - 1 = Gestures will trigger event
- > Bit 0: **EVENT_MODE**: Enable event mode communication
 - 0 = I²C is presented each cycle
 - $1 = I^2C$ is only initiated when an enabled event occurs

8.10.11 Filter Settings 0

	Filter Settings 0										
Bit	7	6	5	4	3	2	1	0			
Name	-	-	-	-	ALP_ COUNT_ FILTER	IIR_ SELECT	MAV_ FILTER	IIR_ FILTER			

> Bit 7-4: Unused





- > Bit 3: ALP_COUNT_FILTER: Enable alternate LP channel count filtering
 - 0 = Alternate LP channel counts are unfiltered
 - 1 = Alternate LP channel counts are filtered
- > Bit 2: IIR_SELECT: Select the IIR filtering method for the XY data points
 - 0 = Damping factor for IIR filter is dynamically adjusted relative to XY movement
 - 1 = Damping factor for IIR filter is fixed
- > Bit 1: MAV_FILTER: Enable moving averaging filter
 - 0 = XY MAV filter disabled
 - 1 = XY MAV filter enabled
- > Bit 0: IIR FILTER: Enable IIR filter
 - 0 = XY IIR filter disabled
 - 1 = XY IIR filter enabled

8.10.12 Alternate Channel Setup

		ALP Channel Setup 0								
Bit	7	6	5	4	3	2	1	0		
Name	CHARGE_ TYPE	RX_ GROUP	PROX_ REVERSE	ALP	-	-	-	-		

- > Bit 7: CHARGE_TYPE: Charge type selection
 - 0 = Projected capacitive charging
 - 1 = Self capacitive charging
- > Bit 6: **RX_GROUP:** Select Rx group
 - 0 = Rx group A
 - 1 = Rx group B
- > Bit 5: PROX_REVERSE: Enable reverse proximity sensing
 - 0 = Allow proximity to only trigger in conventional direction (positive for projected, negative for self capacitive)
 - 1 = Proximity detects change in counts in both directions
- > Bit 4: **ALP:** Enable alternate low power channel
 - 0 = LP1 and LP2 use trackpad channels
 - 1 = LP1 and LP2 use alternate channel configuration
- > Bit 3-0: Unused

8.10.13 ALP Rx select

- > Bit Z: **ALP_RxZ:** Select Rx for alternate low power channel
 - 0 = RxZ is not part of ALP channel
 - 1 = RxZ is part of ALP channel

8.10.14 ALP Tx select

- > Bit Z: **ALP_TxZ:** Select Tx for alternate low power channel
 - 0 = TxZ is not part of ALP channel
 - 1 = TxZ is part of ALP channel





8.10.15 RxToTx

		RxToTx ⁽¹⁾							
Bit	7	7 6 5 4 3 2 1 0							
IQS525	Rx7/Tx2	Rx7/Tx2 Rx6/Tx3 Rx5/Tx4 Rx4/Tx5 Rx3/Tx6 Rx2/Tx7 Rx1/Tx8 Rx0/Tx9							
IQS572	Rx7/Tx9	Rx7/Tx9 Rx6/Tx10 Rx5/Tx11 Rx4/Tx12 Rx3/Tx13 Rx2/Tx14 0 0							

- > Bit 7-0: Rx/Tx: Change an Rx electrode to a Tx electrode
 - 0 = Activate indicated Rx
 - 1 = Activate indicated Tx
- 1: This register is only available on the IQS572 and IQS525 firmware

8.10.16 Hardware Settings A

	Hardware Settings A								
Bit	7	6	5	4	3	2	1	0	
Name	-	-	ND	-	-	RX_ FLOAT	0	0	

- > Bit 7-6: Unused
- > Bit 5: **ND:** Enable hardware noise detection
 - 0 = noise detect disabled
 - 1 = noise detect enabled
- > Bit 4-3: Unused
- > Bit 2: RX_FLOAT: Select Rx status when inactive
 - 0 = Rx is grounded when inactive
 - 1 = Rx is floating when inactive
- > Bit 1-0: Internal use, set to 0

8.10.17 Hardware Settings B

	Hardware Settings B									
Bit	7	6	5	4	3	2	1	0		
Name	-		CK_FREQ		-	-	ANA_ DEAD_ TIME	INCR_ PHASE		

- > Bit 7: Unused
- > Bit 6-4: **CK_FREQ:** Configure Prox module clock source
 - 000 = 125kHz
 - 001 = 250kHz
 - 010 = 500kHz
 - 011 = 1MHz
 - 100 = 2MHz
 - 101 = 4MHz





- 110 = 8MHz
- 111 = 16MHz
- > Bit 3-2: Unused
- > Bit 1: ANA_DEAD_TIME: Analog dead time between up and pass phase
 - 0 = Analog dead time disabled (dead time is half a prox clock cycle)
 - 1 = Analog dead time enabled (dead time is ~10ns, and UP increased by one cycle)
- > Bit 0: INCR_PHASE: Increase the phase length of UP and PASS
 - 0 = Phase (UP / PASS) not incremented
 - 1 = Phase (UP / PASS) increased by one half of a prox clock cycle

8.10.18 Hardware Settings C

	Hardware Settings C								
Bit	7	6	5	4	3	2	1	0	
Name	STAB_TIME OPAMP_BIAS VTRIP								

- > Bit 7-6: **STAB TIME:** Stabilisation time after module power-on before conversion starts
 - 00 = 1.7ms
 - 01 = 500us
 - 10 = 120us
 - 11 = no not use
- > Bit 5-4: **OPAMP_BIAS:** Opamp bias strength
 - 00 = 2.5uA
 - 01 = 5uA
 - 10 = 7.5uA
 - 11 = 10uA
- > Bit 3-0: VTRIP: Charge transfer trip voltage
 - Trip voltage = [0.5 + (VTRIP x 0.0267)] x Vreg

8.10.19 Hardware Settings D

	Hardware Settings D								
Bit	7	6	5	4	3	2	1	0	
Name	-		UPLEN		-		PASSLEN		

- > Bit 7: Unused
- > Bit 6-4: **UPLEN:** Length of UP phase
- > Bit 3: Unused
- > Bit 2-0: PASSLEN: Length of PASS phase





8.10.20 XY Config 0

		XY Config 0								
Bit	7	6	5	4	3	2	1	0		
Name	-	-	-	-	PALM_ REJECT	SWITCH_ XY_AXIS	FLIP_Y	FLIP_X		

- > Bit 7-4: Unused
- > Bit 3: PALM_REJECT: Enable palm reject sensing and suppression
 - 0 = Large fingers (palms) are allowed
 - 1 = Large fingers (palms) will block XY outputs
- > Bit 2: **SWITCH_XY_AXIS:** Switch X and Y outputs
 - 0 = Columns Rx0-Rx9 gives change in X, rows Tx0-Tx14 gives change in Y
 - 1 = Columns Tx0-Tx14 gives change in X, rows Rx0-Rx9 gives change in Y
- > Bit 1: FLIP_Y: Flip Y output values
 - 0 = Keep default Y values
 - 1 = Invert Y output values
- > Bit 0: FLIP X: Flip X output values
 - 0 = Keep default X values
 - 1 = Invert X output values

8.10.21 Single Finger Gestures

	Single Finger Gestures								
Bit	7	6	5	4	3	2	1	0	
Name	-	-	SWIPE_ Y-	SWIPE_ Y+	SWIPE_ X+	SWIPE_ X-	PRESS_ AND_ HOLD	SINGLE_ TAP	

- > Bit 7-6: Unused
- > Bit 5: **SWIPE_Y-:** Swipe in negative Y direction
 - 0 = Gesture disabled
 - 1 = Gesture enabled
- > Bit 4: **SWIPE_Y+:** Swipe in positive Y direction
 - 0 = Gesture disabled
 - 1 = Gesture enabled
- > Bit 3: **SWIPE_X+:** Swipe in positive X direction
 - 0 = Gesture disabled
 - 1 = Gesture enabled
- > Bit 2: **SWIPE_X-:** Swipe in negative X direction
 - 0 = Gesture disabled
 - 1 = Gesture enabled
- > Bit 1: PRESS_AND_HOLD: Press and hold gesture
 - 0 = Gesture disabled
 - 1 = Gesture enabled



- > Bit 0: SINGLE_TAP: Single tap gesture
 - 0 = Gesture disabled
 - 1 = Gesture enabled

8.10.22 Multi-finger Gestures

	Multi-finger Gestures								
Bit	7	6	5	4	3	2	1	0	
Name	-	-	-	-	-	ZOOM	SCROLL	2F_ TAP	

- > Bit 7-3: Unused
- > Bit 2: **ZOOM:** Zoom gestures
 - 0 = Gestures disabled
 - 1 = Gestures enabled
- > Bit 1: **SCROLL:** Scroll gestures
 - 0 = Gestures disabled
 - 1 = Gestures enabled
- > Bit 0: **2F_TAP:** Two finger tap gesture
 - 0 = Gesture disabled
 - 1 = Gesture enabled

9 Circuit Diagram




Figure 9.1 IQS550 Overview Diagram








Figure 9.2 IQS572 Overview Diagram




Figure 9.3 IQS525 Overview Diagram






Figure 9.4 IQS550 Application Circuit






Figure 9.5 IQS572 Application Circuit








Figure 9.6 IQS525 Application Circuit





10 Electrical Characteristics

10.1 Absolute Maximum Ratings

Exceeding these maximum ratings may cause permanent damage to the device.

Table 10.1 Voltage Characteristics

Symbol	Rating	Min	Max	Unit	
V _{DDHI} - V _{SS}	External supply voltage	-0.3	4.0		
	Receiver channel pins (Rx0ARx9	Rx0ARx9B)		V _{REG} (-1.55)	
V	Input voltage on transmit pins (Tx0Tx14))	PXS off	V _{SS} -0.3	4.0	V
Vin		PXS on ⁽¹⁾	V _{SS} -0.3	V _{REG} (-1.55)	
	Input voltage on any pin ⁽²⁾		V _{SS} -0.3	4.0	

- 1. If the ProxSense® peripheral is on, no injection must be performed on any pin having the transmit function (Tx) as an alternate function, even if this alternate function is not specified
- 2. I_{INJ(PIN)} must never be exceeded. This is implicitly insured if V_{IN} maximum is respected. If V_{IN} maximum cannot be respected, the injection current must be limited externally to the I_{INJ(PIN)} value. A positive injection is induced by V_{IN}>V_{DDHI} while a negative is induced by V_{IN}<V_{SS}.

Table 10.2 Current Characteristics

Symbol	Rating	Max.	Unit
Ivddhi	Total current into V _{DDHI} power line (source)	80	
Ivss	Total current out of Vss ground line (sink)	80	
l	Output current sunk by any other I/O and control pin	25	4
lio	Output current source by any I/Os and control pin	-25	mA
I _{INJ(PIN)} ⁽¹⁾	Injected current on any pin ⁽²⁾	±5	
∑ I _{INJ(PIN)} ⁽¹⁾	Total injected current (sum of all I/O and control pins)(2)	±25	

- 1. I_{INJ(PIN)} must never be exceeded. This is implicitly insured if V_{IN} maximum is respected. If V_{IN} maximum cannot be respected, the injection current must be limited externally to the _{IINJ(PIN)} value. A positive injection is induced by V_{IN}>V_{DDHI} while a negative injection is induced by V_{IN}<V_{SS}. For true open-drain pads, there is no positive injection current, and the corresponding V_{IN} maximum must always be respected.
- 2. When several inputs are submitted to a current injection, the maximum ΣΙ_{ΙΝJ(PIN)} is the absolute sum of the positive and negative injected currents (instantaneous values). These results are based on characterization with ΣΙ_{ΙΝJ(PIN)} maximum current injection on four I/O port pins of the device.





Table 10.3 Thermal Characteristics

Symbol	Rating	Max.	Unit
TSTG	Storage temperature range	-65 to +150	°C
TJ	Maximum junction temperature	150	C

10.2 Operating Conditions

10.2.1 General Operating Conditions

Table 10.4 General Operating Conditions

Symbol	Parameter	Conditions	Min	Тур	Max	Unit
f _{MASTER} ⁽¹⁾	Master clock frequency	1.65V ≤ V _{DDHI} ≤3.6V	-	16	-	MHz
V_{DDHI}	Standard operating voltage	-	1.65	-	3.6	V
P _D ⁽²⁾	Power dissipation at T _A = 85°C	-	-	-	625	mW
TA	Temperature range	1.65V ≤ V _{DDHI} ≤3.6V	-40	-	85	°C
TJ	Junction temperature range	-40°C ≤ V _{DDHI} ≤ 85°C	-40	-	105	°C

^{1.} $f_{MASTER} = f_{CPU}$

10.2.2 Power-up / Power-down Operating Conditions

Table 10.5 Operating Conditions at Power Up / Down

Symbol	Parameter	Conditions	Min	Тур	Max	Unit
tvddhi	V _{DDHI} rise time rate		20	-	1300	μs/V
t _{TEMP}	Reset release decay	V _{DDHI} rising	-	1	-	Ms
V _{POR}	Power on reset threshold		1.44	-	1.65 ⁽¹⁾	V
V _{PDR}	Power down reset threshold		1.30	-	1.60(2)	V

^{1.} Tested in production

^{2.} To calculate $P_{Dmax}(T_A)$ use the formula given in thermal characteristics $P_{Dmax}=(T_{Jmax}-T_A)/\theta_{JA}$ with T_{Jmax} in this table and θ_{JA} in Table 10.15.

^{2.} Data based on characterisation results, not tested in production.





10.2.3 Supply Current Characteristic

Table 10.6 Current Consumption(1)

Symbol	Parameter	Conditions	Тур	Max	Unit
I _{DD(CORE)}	Run current for processor core	16MHz master frequency (T _A = -40 °C to 85 °C)	2.8	3.5	mA
IDD(LP STATE)	Supply current in low-power sleep	T _A = -40 °C to 25 °C	1	2	uA
	state (which is added to cycle time to obtain desired report rate)	T _A = 85 °C	1.4	3.2	uA
I _{DD(SUSPEND)}	Supply current in suspend state	T _A = -40 °C to 25 °C	0.4	1.2	uA
		T _A = 85 °C	1	2.5	uA

^{1.} Data based on characterisation results, unless otherwise specified.

10.2.4 ProxSense® Current Consumption

The break-down of the consumption from the ProxSense peripheral is shown below.

Table 10.7 ProxSense® Current Consumption(1)

Symbol	ProxSense transmitter (Tx)	ProxSense receiver (Rx)	Тур	Unit
I _{DD(PXS)}	1	1	0.6	mA
	1	4	1.1	mA
	1	10	2.3	mA

^{1.} Data based on characterisation results, unless otherwise specified.

10.2.5 Expected Total Current Consumption Scenarios

The specific parameters configured on varying designs have a great impact on the obtained current consumption. Due to this, the following table is purely illustrative of the expected consumption for similar configurations. The device configurations used below are examples of practical setups expected in applications.





Table 10.8 Total Current Consumption(1)

Or words all	Sensors	Daniert Date		Current (Typ)	II'4
Symbol	Censors Report Nate	Report Rate	IQS550	IQS572	IQS525	Unit
	Trackpad ⁽²⁾	10ms	3.75	2.73	1.46	mA
	Trackpad ⁽²⁾	15ms	2.52	1.85	0.99	mA
	Trackpad ⁽²⁾	20ms	1.9	1.38	0.74	mA
	Trackpad ⁽²⁾	40ms	975	690	370	uA
	Trackpad ⁽²⁾	80ms	483	346	185	uA
	Trackpad ⁽²⁾	160ms	243	174	96	uA
	Trackpad ⁽²⁾	320ms	121	89	48	uA
	Trackpad ⁽²⁾	640ms	67	55	26	uA
	ALP ⁽³⁾	80ms	48			uA
	ALP ⁽³⁾	160ms		25		uA
I _{DD(Total)}	ALP ⁽³⁾	320ms		13	uA	
	ALP ⁽³⁾	640ms		7		uA
	ALP ⁽⁴⁾	80ms		43		uA
	ALP ⁽⁴⁾	160ms		22		uA
	ALP ⁽⁴⁾	320ms		12		uA
	ALP ⁽⁴⁾	640ms		7		uA
	ALP ⁽⁵⁾	80ms		41		uA
	ALP ⁽⁵⁾	160ms		21		uA
	ALP ⁽⁵⁾	320ms		12		uA
	ALP ⁽⁵⁾	640ms		6		uA

- 1. Based on bench measurements, not characterised
- 2. Tested with maximum number of sensors active (IQS550 15x10 / IQS572 9x8 / IQS525 5x5); ATI Target of 500 counts; Max number of multi-touches = 2 / default hardware (conversion) settings / 1 finger touch (8mm diameter) active / streaming 27 bytes (XY data and gestures) / I^2C pull-ups of $4.7k\Omega$ / V_{DDHI} = 3.3V
- 3. Tested with ALP channel configured in projected capacitive mode; ATI Target of 500; Alternating Txs enabled, all Rxs enabled; Event-Mode enabled
- 4. Tested with ALP channel configured in projected capacitive mode; ATI Target of 500; All Txs enabled, single Rxs around trackpad enabled; Event-Mode enabled
- Tested with ALP channel configured in self capacitive mode; ATI Target of 800; single Rx enabled; Event-Mode enabled





10.2.6 I/O Port Pin Characteristics

General characteristics

Subject to general operating conditions for V_{DDHI} and T_{A} unless otherwise specified. All unused pins must be kept at a fixed voltage: using the output mode of the I/O for example or an external pull-up or pull-down resistor.

Table 10.9 Standard I/O Static Characteristic (1) (2)

Symbol	Parameter	Conditions	Min.	Тур.	Max.	Unit
VIL	Input low level voltage ⁽³⁾	Standard I/Os	V _{SS} -0.3	-	0.3V _{DDHI}	V
ViH	Input high level voltage(3)	Standard I/Os	0.7 V _{DDHI}	-	V _{DDHI} +0.3	
V _{hys}	Schmitt trigger voltage hysteresis ⁽⁴⁾	Standard I/Os	-	200	-	mV
l _{lkg}	Input leakage current ⁽⁵⁾	V _{SS} ≤ V _{IN} ≤ V _{DDHI} Standard I/Os	-1	-	1	uA
		$V_{SS} \le V_{in} \le V_{REG}^{(6)} Rx,$ $Tx I/Os$	-1	-	1	
R _{PU}	Weak pull-up equivalent resistor ⁽⁷⁾	V _{IN} = V _{SS}	30	45	60	kΩ
C _{IO} (8)	I/O pin capacitance		-	5	-	pF

- 1. $V_{DDHI} = 3.0 \text{ V}$, $T_A = -40 \text{ to } 85^{\circ}\text{C}$ unless otherwise specified.
- 2. Not applicable to Rx and Tx pins.
- 3. Data based on characterisation results, not tested in production.
- 4. Hysteresis voltage between Schmitt trigger switching levels. Based on characterization results, not tested.
- 5. The maximum value may be exceeded if negative current is injected on adjacent pins.
- 6. V_{IN} must not exceed V_{REG} value if ProxSense[®] is enabled, even on port B and D (Tx), V_{REG} = 1.55V.
- 7. R_{PU} pull-up equivalent resistor based on a resistive transistor (corresponding I_{PU} current characteristics)
- 8. Data guaranteed by design, not tested in production





10.2.7 Output Driving Current

Subject to general operating conditions for V_{DDHI} and T_A unless otherwise specified.

Table 10.10 Output Driving Current (high sink ports)

I/O type	Symbol	Parameter Conditions	Conditions	Min.	Max.	Unit
			I _{IO} = +2mA, V _{DDHI} = 1.8V	-	0.45	
	V _{OL} ⁽¹⁾	Output low level voltage for an I/O pin	I_{IO} = +2mA, V_{DDHI} = 3.0V	-	0.45	
Charadavd	V _{OH} ⁽²⁾ Output high level voltage for an I/O pi			-	0.7	
Standard			I_{IO} = -1mA, V_{DDHI} = 1.8V	V _{DDHI} -0.45	-	V
		Output high level voltage for an I/O pin	I _{IO} = -1mA, V _{DDHI} = 3.0V	V _{DDHI} -0.45	-	
			I_{IO} = -10mA, V_{DDHI} = 3.0V	V _{DDHI} -0.7	-	
ProxSense I/O	VoL	Output low level voltage for Tx and Rx ProxSense I/Os	I _{RX} = TBD	-	TBD	
	Voн	Output high level voltage for Tx ProxSense I/O	$I_{TX} = 1mA$	1.45	-	
	VoH	Output high level voltage for Rx ProxSense I/O	$I_{PXS_RX} = 0.5 mA$	1.35	-	

^{1.} The I_{IO} current sunk must always respect the absolute maximum rating and the sum of I_{IO} (I/O ports and control pins) must not exceed I_{VSS}.

10.2.8 NRST Pin

The NRST pin input driver is CMOS. A permanent pull-up is present; thus an external component is not needed if NRST is unconnected in the design.

Subject to general operating conditions for V_{DDHI} and T_A unless otherwise specified.

^{2.} The I_{IO} current sourced must always respect the absolute maximum rating and the sum of I_{IO} (I/O ports and control pins) must not exceed I_{VDDHI}.





Table 10.11 NRST Pin Characteristics

Symbol	Parameter	Conditions	Min.	Тур.	Max.	Unit
V _{IL(NRST)}	NRST Input low level voltage ⁽¹⁾		Vss	-	0.8	
VIH(NRST)	NRST Input high level voltage ⁽¹⁾		1.4	-	V _{DDHI}	V
Vol(NRST)	NRST Output low level voltage	I _{OL} = 2mA	-	-	V _{DDHI} -0.8	
Rpu(NRST)	NRST pull-up equivalent resistor ⁽²⁾		30	45	60	kΩ
V _{F(NRST)}	NRST input filtered pulse ⁽³⁾		-	-	50	
top(NRST)	NRST output pulse width		20	-	-	ns
V _{NF(NRST)}	NRST input not filtered pulse ⁽³⁾		300	-	-	

- 1. Data based on characterization results, not tested in production.
- 2. The RPU pull-up equivalent resistor is based on a resistive transistor.
- 3. Data guaranteed by design, not tested in production.

The reset network shown in Figure 10.1 protects the device against parasitic resets. The user must ensure that the level on the NRST pin can go below the V_{IL} max. level specified in Table 10.11. Otherwise the reset is not taken into account internally.




Figure 10.1 Recommended NRST Pin Configuration





10.2.9 I²C Characteristics

Subject to general operating conditions for V_{DDHI}, f_{MASTER}, and T_A unless otherwise specified.

The IQS5xx I²C interface meets the requirements of the Standard I²C communication protocol described in the following table with the restrictions mentioned below.

Table 10.12 I2C Characteristics

Symbol	bol Parameter		ard I ² C kHz)		t I ² C kHz)	Unit	
		Min ⁽¹⁾ Max ⁽¹⁾		Min ⁽¹⁾	Max ⁽¹⁾		
tw(SCLL)	SCL clock low time	4.7	-	1.3	-	μs	
t _{w(SCLH)}	SCL clock high time	4.0	-	0.6	-	μs	
t _{su(SDA)}	SDA setup time	250	-	100	-	ns	
t _{h(SDA)}	SDA data hold time	0(2)	-	0	900(2)	ns	
t _{r(SDA)}	SDA rise time	-	1000	-	300	ns	
t _{r(SCL)}	SCL rise time	-	1000	-	300	ns	
t _{f(SDA)}	SDA fall time	-	300	-	300	ns	
t _{f(SCL)}	SCL fall time	-	300	-	300	ns	
th(STA)	START condition hold time	4.0	-	0.6	-	μs	
t _{su(STA)}	Repeated START condition setup time	4.7	-	0.6	-	μs	
t _{su(STO)}	STOP condition setup time	4.0	-	0.6	-	μs	
Сь	Capacitive load for each bus line	-	400	-	400	pF	

1. Data based on protocol requirement, not tested in production




Figure 10.2 Typical Bus Application and Timing Diagram





10.2.10 Package Moisture Sensitivity

Table 10.13 Moisture Sensitivity Level (MSL)

Parameter	IQS550	IQS572	IQS525
Package Moisture Sensitivity Level (MSL)	3	3	3

10.2.11 Electrostatic Discharge (ESD)

Electrostatic discharges (a positive then a negative pulse separated by 1 second) are applied to the pins of each sample according to each pin combination. The sample size depends on the number of supply pins in the device (3 parts*(n+1) supply pin). Two models can be simulated: human body model and charge device model. This test conforms to the JESD22-A114A/A115A standard.

Table 10.14 ESD Absolute Maximum Ratings

Symbol	Ratings	Conditions	Max Value	Unit
V _{ESD} (HBM)	Electrostatic discharge voltage (human body model)		2000(2)	V
V _{ESD} (CDM)	Electrostatic discharge voltage (charge device model)	T _A = +25 °C	1000	V

- 1. Data based on characterisation results, not tested in production.
- 2. Device sustained up to 3000 V during ESD trials.

10.2.12 Thermal Characteristics

The maximum chip junction temperature (T_{Jmax}) must never exceed the values given in Table 10.4.

The maximum chip-junction temperature, T_{Jmax} , in degrees Celsius, may be calculated using the following equation:

$$T_{Jmax} = T_{Amax} + (P_{Dmax} \times \theta_{JA})$$

Where:

- T_{Amax} is the maximum ambient temperature in °C
- ullet $heta_{JA}$ is the package junction-to-ambient thermal resistance in °C/W
- P_{Dmax} is the sum of P_{INTmax} and $P_{I/Omax}$ ($P_{Dmax} = P_{INTmax} + P_{I/Omax}$)
- P_{INTmax} is the product of I_{DD} and V_{DDHI}, expressed in watts. This is the maximum chip internal power.
- P_{I/Omax} represents the maximum power dissipation on output pins where:

 $P_{I/Omax} = \sum (V_{OL}*I_{OL}) + \sum ((V_{DDHI} - V_{OH})*I_{OH})$, taking into account the actual V_{OL}/I_{OL} and V_{OH}/I_{OH} of the I/Os at low and high level in the application.





Table 10.15 Thermal Characteristics(1)

Symbol	Parameter	Value	Unit
ОЈА	Thermal resistance junction ambient	32	°C/W

^{1.} Thermal resistances are based on JEDEC JESD51-2 with 4-layer PCB in a natural convection environment.

10.2.13 ProxSense Electrical Characteristics

Table 10.16 Rx / Tx Characteristics

Symbol	Parameter	Conditions	IQS550	IQS572	IQS525	Unit
C_{RG}	Rx capacitance to ground			60		pF
C_{TG}	Tx capacitance to ground		60	60	40	pF
См	Mutual capacitance between Rx and Tx			4		pF
Rrx	Total Rx resistance	16MHz Prox Clock		2		kΩ
Krx	Total RX resistance	4MHz Prox Clock		20		kΩ
Rtx	Total Tx resistance	16MHz Prox Clock		2		kΩ
		4MHz Prox Clock	20		kΩ	

Data based on characterisation results, not tested in production.





11 Mechanical Dimensions

11.1 IQS550 QFN(7x7)-48 Mechanical Dimensions




Figure 11.1 QFN(7x7)-48 Package

Table 11.1 Dimensions from Figure 11.1

Labal	Dir	nension (mm)	Labal	Dimension (mm)		
Label	Min	Typical	Max	Label	Min	Typical	Max
Р		0.500		Н	0.500	0.550	0.600
Т	0.300	0.400	0.500	A / B	6.900	7.00	7.100
W	0.200	0.250	0.300	Тр		0.152	
Tt	5.500	5.600	5.700	r		0.125	
Wt	5.400	5.500	5.600				





11.2 IQS550 Landing Pad Layout




Figure 11.2 QFN(7x7)-48 Footprint

Table 11.2 Dimensions from Figure 11.2

Label	Dimension (mm)	Label	Dimension (mm)
X	5.60	Y2	7.30
X1	6.20	Н	0.55
X2	7.30	W	0.30
X3	5.80	g	0.20
Υ	5.60	Р	0.50
Y1	6.20		

*Note1: It is recommended to connect and solder this back-side pad to PCB ground.





11.3 IQS572/IQS525 QFN(4x4)-28 Mechanical Dimensions




Figure 11.3 QFN(4x4)-28 Package

Table 11.3 Dimensions from Figure 11.3

Label	Dir	nension (mm)	Label	Dimension (mm)		
	Min	Typical	Max	Labei	Min	Typical	Max
А	0.5	0.55	0.6	L	0.3	0.4	0.5
A1	-0.05	0	0.05	L1	0.25	0.35	0.45
D	3.9	4.0	4.1	Т		0.152	
D1	2.9	3.0	3.1	b	0.2	0.25	0.3
Е	3.9	4.0	4.1	е		0.5	
E1	2.9	3.0	3.1				





11.4 IQS572/IQS525 Landing Pad Layout




Figure 11.4 QFN(4x4)-28 Footprint (dimensions in millimetres)





12 Packaging Information

12.1 Tape Specification

The IQS5xx products come packaged in a carrier tape on a reel. The carrier tape has a leader and trailer section where no products are populated. A 400mm (min) section at the start of the carrier tape is empty (leader part). The cover tape starts in this leader part and covers a 100mm (min) of carrier tape that has no products. From there the products are consecutively populated in the carrier tape. The trailer of 160mm (min) has no products.




Figure 12.1 Representation of Leader and Trailer for the Carrier Tape

Table 12.1 Tape Dimensions

Description	Measurement (mm)				
Description	IQS550	IQS572	IQS525		
Tape width	16	12	12		
Part pitch	12	8	8		
Sprocket hole diameter	1.5	2	2		
Sprocket hole pitch	4	4	4		
Cavity length	7.2	5.3	5.3		
Cavity width	7.2	5.3	5.3		
Cavity depth	1.2	1.1	1.1		
Cover tape width	13	9.5	9.5		

Please note: Cover tape does not cover the sprocket holes.





12.1.1 IQS550 Tape Description




Figure 12.2 IQS550 QFN48-7x7 Package in Carrier Tape Example

The IQS550 is packed in a carrier tape as shown above and placed on the reel. It fits in a long carrier tape that is moulded specifically for this product and a removable see-through cover tape is placed over. This cover can be peeled off and the product taken out of the tape with a pick-and-place machine. The Pin 1 corner indicator is closest to a side facing the sprocket holes in the carrier tape as illustrated.

12.1.2 IQS572 and IQS525 Tape Description

The IQS525 & IQS572 share the same tape and reel details, with an example of the IQS525 tape provided here.




Figure 12.3 IQS525 QFN28-4x4 Package in Carrier Tape Example

Again, the Pin 1 corner indicator is closest the side facing the sprocket holes in the carrier tape as illustrated.





12.2 Reel Specification

The reel is made from a high impact PS material. The physical dimensions are illustrated in the table and figure below.




Figure 12.4 Reel Dimensions: Front and Side View

Table 12.2 Reel Dimensions

Dimension	Value (in mm)				
Dimension	IQS550	IQS572	IQS525		
А	330 (max)	330 (max)	330 (max)		
В	1.5 (min)	1.5 (min)	1.5 (min)		
С	13 ±0.2	13 ±0.2	13 ±0.2		
D	20.2 (min)	20.2 (min)	20.2 (min)		
N	60	60	60		
G	16.4 + 2/-0	12.4 + 2/-0mm	12.4 + 2/-0mm		
Т	22.4 (max)	18.4mm (max)	18.4mm (max)		

Note: The reel could also have additional cut-outs not illustrated in the figure





12.2.1 Dry Packing

The IQS5xx is specifically dry packed to protect them from moisture absorption while shipping/storing which has a large effect on the quality and reliability of the IQS5xx after soldering. To improve the quality and reliability of soldering joints, it is advised to bake the IQS5xx before reflow soldering.

Below is a flow diagram which shows how Azoteq aims to minimise moisture absorption during shipping and storage. On the right side is a flow diagram specific for the customer to consult whether baking is needed.




Figure 12.5 Moisture Absorption Control Method / Guide

The flow diagram above informs the customer whether the baking process is needed. When opening the dry pack consult the humidity indicator (gel) inside the pack. If it turned pink, the product must be baked. If the gel is not pink, within the specified period there is no need for baking, as long as the humidity and temperature conditions are met.

12.2.2 **Baking**

The IQS5xx is packed in a tape and reel and can thus not be baked. It must first be transferred to a non-metal tube or tray, for example a glass tray. This is placed in an oven and baked according to the IPC/JEDEC J-STD-033C MSL specification. A picture of this baking method is shown below.








Figure 12.6 IQS550 Baking Example

Take the IQS5xx out of the carrier tape and place on for example a glass sheet. Ensure all the IQS5xx's are turned top side up and not lying on top of each other. Bake the product for 24 hours at 125 °C. Remove from oven and let cool for about 1 hour before handling.

12.3 Handling of the IQS5xx

When handling the IQS5xx product, ESD (Electrostatic discharge) must be avoided as far as possible. Make sure all equipment and personnel are grounded to avoid static build-up. Machines should be grounded, and personnel should wear grounding straps.

12.4 Reflow for IQS5xx

When soldering the IQS5xx to a board, the correct temperature curve must be followed to ensure good soldering joints and to avoid damaging the chip due to high temperatures.




Figure 12.7 Reflow Temperature Curve for the IQS5xx





The figure above shows the temperature profile to be used when soldering the IQS5xx onto a board. This is according to the JEDEC (J-STD-020D.1) standard lead-free reflow profile.

Table 12.3 JEDEC Standard Lead-Free Reflow Profile

Symbol	Description	Value
T _{Smax} to T _P	Average ramp-up rate	3 ⁰ C/second max
T _{Smin}	Temperature min	150 °C
T _{Smax}	Temperature max	200 °C
ts	Preheat time	60 – 120 seconds
TL	Temperature	217 °C
tL	Time maintained above temperature T_L	60 – 150 seconds
ТР	Peak/classification temperature	260 °C
t _P	Time within 5 °C of actual peak temperature (T _P)	30 seconds
	Ramp-down rate	6 ⁰ C/second max
t _{25C} to t _P	Time: 25 °C to peak temperature	8 minutes max


All temperatures refer to topside of the package, measured on the body surface.





13 Device Marking


13.1 IQS550 Marking







13.2 IQS572/IQS525 Marking






14 Ordering Information


Order quantities will be subject to multiples of full reels. For large orders, Azoteq can provide custom configured devices.

14.1 IQS550 Ordering




IC NAME	IQS550	=	IQS550
CONFIGURATION CODE	BL	=	Bootloader (ready for application firmware programming, B000 firmware NOT pre-loaded)
PACKAGE TYPE	QN	=	QFN(7x7)-48
BULK PACKAGING	R	=	Reel (2500pcs/reel)

14.2 IQS572 Ordering



IC NAME	IQS572	=	IQS572
CONFIGURATION CODE	BL	=	Bootloader (ready for application firmware programming, B000 firmware NOT pre-loaded)
PACKAGE TYPE	QN	=	QFN(4x4)-28
BULK PACKAGING	R	=	Reel (3000pcs/reel)

14.3 IQS525 Ordering



IC NAME	IQS525	=	IQS525
CONFIGURATION CODE	BL	=	Bootloader (ready for application firmware programming, B000 firmware NOT pre-loaded)
PACKAGE TYPE	QN	=	QFN(4x4)-28
BULK PACKAGING	R	=	Reel (3000pcs/reel)





15 Changes:

Release v1.00

> IQS5xx-B000 datasheet released

Release v1.01

- > Added 'Minimum count Re-ATI delta' to memory map, and updated Section 3.7.2.
- > Updated links (Sections 4.3 and 8.8.2)

Release v2.00

- Updated wake pin functionality and changed terminology from wake to switch input: Updated section 7.3.2 and 8.8.1, added <u>SWITCH_STATE</u> bit, added <u>SW_INPUT_EVENT</u> bit, Added section 7.11
- > Added export file version: Updated Section 7.1 and memory map
- > Updated Note 2 in Table 10.8 (525 setup added and ATI target fixed)
- > Fixed heading of Table 1.1
- > Updated Figure 11.4
- Updated <u>RxToTx</u> register to include IQS572 (memory map also updated), and updated Section 5.1.4
- > Added Section 7.9 and 7.10
- > Updated Section 8.8.1 with updated trackpad event definition
- Added tap location details to Section 6.1
- > Removed manual device setup description and startup flow diagram from Section 7.2
- > Updated overview diagrams and circuit diagrams (removed program interface on PGM and NRST, and updated SW_IN pin)

Release v2.01

- Corrected Figure 11.4 title
- Corrected bit 2 definition in Single Finger Gesture register (0x06B7) Updated Table 8.1 and Section 8.10.21
- > Fixed bit 2 description in Section 8.10.9
- Added updated IC markings in Section 13.1 and 13.2
- > Updated description of RDY functionality during forced comms in Section 8.8.2 and Figure 8.4
- > Updated document template/styles





	USA	Asia	South Africa
Physical Address	11940 Jollyville Suite 120-S Austin TX 78750 USA	Room 501A, Block A, T-Share International Centre, Taoyuan Road, Nanshan District, Shenzhen, Guangdong, PRC	1 Bergsig Avenue Paarl 7646 South Africa
Postal Address	11940 Jollyville Suite 120-S Austin TX 78750 USA	Room 501A, Block A, T-Share International Centre, Taoyuan Road, Nanshan District, Shenzhen, Guangdong, PRC	PO Box 3534 Paarl 7620 South Africa
Tel	+1 512 538 1995	+86 755 8303 5294 ext 808	+27 21 863 0033
Email	info@azoteq.com	info@azoteq.com	info@azoteq.com

Visit <u>www.azoteq.com</u> for a list of distributors and worldwide representation.

Patents as listed on www.azoteq.com/patents-trademarks/ may relate to the device or usage of the device.

Azoteq®, Crystal Driver , IQ Switch®, ProxSense®, ProxFusion®, LightSense™, SwipeSwitch™, and the Ulogo are trademarks of Azoteq.

The information in this Datasheet is believed to be accurate at the time of publication. Azoteq uses reasonable effort to maintain the information up-to-date and accurate, but does not warrant the accuracy, completeness or reliability of the information contained herein. All content and information are provided on an "as is" basis only, without any representations or warranties, express or implied, of any kind, including representations about the suitability of these products or information for any purpose. Azoteq disclaims all warranties and conditions with regard to these products and information, including but not limited to all implied warranties and conditions of merchantability, fitness for a particular purpose, title and non-infringement of any third party intellectual property rights. Azoteq assumes no liability for any damages or injury arising from any use of the information or the product or caused by, without limitation, failure of performance, error, omission, interruption, defect, delay in operation or transmission, even if Azoteq has been advised of the possibility of such damages. The applications mentioned herein are used solely for the purpose of illustration and Azoteq makes no warranty or representation that such applications will be suitable without further modification, nor recommends the use of its products for application that may present a risk to human life due to malfunction or otherwise. Azoteq products are not authorized for use as critical components in life support devices or systems. No licenses to patents are granted, implicitly, express or implied, by estoppel or otherwise, under any intellectual property rights. In the event that any of the abovementioned limitations or exclusions does not apply, it is agreed that Azoteq's total liability for all losses, damages and causes of action (in contract, tort (including without limitation, negligence) or otherwise) will not exceed the amount already paid by the customer for the products, programs and services at any time or to move or