



MICROCHIP

**BM78 Evaluation Board (EVB)
User's Guide**

Note the following details of the code protection feature on Microchip devices:

- Microchip products meet the specification contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is one of the most secure families of its kind on the market today, when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of these methods, to our knowledge, require using the Microchip products in a manner outside the operating specifications contained in Microchip's Data Sheets. Most likely, the person doing so is engaged in theft of intellectual property.
- Microchip is willing to work with the customer who is concerned about the integrity of their code.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not mean that we are guaranteeing the product as "unbreakable."

Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our products. Attempts to break Microchip's code protection feature may be a violation of the Digital Millennium Copyright Act. If such acts allow unauthorized access to your software or other copyrighted work, you may have a right to sue for relief under that Act.

Information contained in this publication regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION, INCLUDING BUT NOT LIMITED TO ITS CONDITION, QUALITY, PERFORMANCE, MERCHANTABILITY OR FITNESS FOR PURPOSE. Microchip disclaims all liability arising from this information and its use. Use of Microchip devices in life support and/or safety applications is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights unless otherwise stated.

Trademarks

The Microchip name and logo, the Microchip logo, dsPIC, FlashFlex, flexPWR, JukeBlox, KEELOQ, KEELOQ logo, Kleer, LANCheck, MediaLB, MOST, MOST logo, MPLAB, OptoLyzer, PIC, PICSTART, PIC³² logo, RightTouch, SpyNIC, SST, SST Logo, SuperFlash and UNI/O are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

The Embedded Control Solutions Company and mTouch are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Analog-for-the-Digital Age, BodyCom, chipKIT, chipKIT logo, CodeGuard, dsPICDEM, dsPICDEM.net, ECAN, In-Circuit Serial Programming, ICSP, Inter-Chip Connectivity, KleerNet, KleerNet logo, MiWi, MPASM, MPF, MPLAB Certified logo, MPLIB, MPLINK, MultiTRAK, NetDetach, Omniscient Code Generation, PICDEM, PICDEM.net, PICkit, PICtail, RightTouch logo, REAL ICE, SQI, Serial Quad I/O, Total Endurance, TSHARC, USBCheck, VariSense, ViewSpan, WiperLock, Wireless DNA, and ZENA are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

SQTP is a service mark of Microchip Technology Incorporated in the U.S.A.

Silicon Storage Technology is a registered trademark of Microchip Technology Inc. in other countries.

GestIC is a registered trademark of Microchip Technology Germany II GmbH & Co. KG, a subsidiary of Microchip Technology Inc., in other countries.

All other trademarks mentioned herein are property of their respective companies.

© 2016, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.

ISBN: 978-1-5224-0169-8

**QUALITY MANAGEMENT SYSTEM
CERTIFIED BY DNV
= ISO/TS 16949 =**

Microchip received ISO/TS-16949:2009 certification for its worldwide headquarters, design and wafer fabrication facilities in Chandler and Tempe, Arizona; Gresham, Oregon and design centers in California and India. The Company's quality system processes and procedures are for its PIC® MCUs and dsPIC® DSCs, KEELOQ® code hopping devices, Serial EEPROMs, microperipherals, nonvolatile memory and analog products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001:2000 certified.

Table of Contents

Preface	5
Chapter 1. Introduction	
1.1 Kit Contents	12
1.2 BM78 EVB Functionality	12
1.3 BM78 EVB Components	13
1.4 PICtail Plus Interface	15
Chapter 2. Hardware	
2.1 Hardware features	17
Chapter 3. Getting Started	
3.1 Prerequisites	21
3.2 Using BM78 EVB in USB-UART Serial Interface Mode	22
3.3 Using BM78 EVB in PICtail Interface Mode	45
Appendix A. Schematics	
A.1 BM78 EVB Schematics	49
Worldwide Sales and Service	54

NOTES:

Preface

NOTICE TO CUSTOMERS

All documentation becomes dated, and this manual is no exception. Microchip tools and documentation are constantly evolving to meet customer needs, so some actual dialogs and/or tool descriptions may differ from those in this document. Please refer to our web site (www.microchip.com) to obtain the latest documentation available.

Documents are identified with a “DS” number. This number is located on the bottom of each page, in front of the page number. The numbering convention for the DS number is “DSXXXXXXXXA”, where “XXXXXXXX” is the document number and “A” is the revision level of the document.

For the most up-to-date information on development tools, see the MPLAB® X IDE online help. Select the Help menu, and then Topics to open a list of available online help files.

INTRODUCTION

This chapter contains general information that will be useful to know before using the BM78 Evaluation Board (EVB). Items discussed in this chapter include:

- [Document Layout](#)
- [Conventions Used in this Guide](#)
- [Recommended Reading](#)
- [The Microchip Web Site](#)
- [Development Systems Customer Change Notification Service](#)
- [Customer Support](#)
- [Document Revision History](#)

DOCUMENT LAYOUT

This document describes how to use the BM78 EVB (also referred to as “Evaluation kit”) as a development tool to emulate and debug firmware on a target board. This user’s guide is composed of the following chapters:

- **Chapter 1. “Introduction”** provides an overview and features of the BM78 EVB.
- **Chapter 2. “Hardware”** provides hardware details of the BM78 EVB.
- **Chapter 3. “Getting Started With BM78 EVB”** describes how to establish Bluetooth serial data connection using the BM78 EVB.
- **Appendix A. “Reference Schematics”** provides the BM78 EVB reference schematics.

CONVENTIONS USED IN THIS GUIDE

This manual uses the following documentation conventions:

DOCUMENTATION CONVENTIONS

Description	Represents	Examples
Italic characters	Referenced books	<i>MPLAB IDE User's Guide</i>
	Emphasized text	...is the <i>only</i> compiler...
Initial caps	A window	the Output window
	A dialog	the Settings dialog
	A menu selection	select Enable Programmer
Quotes	A field name in a window or dialog	"Save project before build"
Underlined, italic text with right angle bracket	A menu path	<u><i>File > Save</i></u>
Bold characters	A dialog button	Click OK
	A tab	Click the Power tab
Text in angle brackets < >	A key on the keyboard	Press <Enter>, <F1>
Plain Courier New	Sample source code	#define START
	Filenames	autoexec.bat
	File paths	c:\mcc18\h
	Keywords	_asm, _endasm, static
	Command-line options	-Opa+, -Opa-
	Bit values	0, 1
	Constants	0xFF, 'A'
<i>Italic Courier New</i>	A variable argument	<i>file.o</i> , where <i>file</i> can be any valid filename
Square brackets []	Optional arguments	mcc18 [options] <i>file</i> [options]
Curly brackets and pipe character: { }	Choice of mutually exclusive arguments; an OR selection	errorlevel {0 1}
Ellipses...	Replaces repeated text	var_name [, var_name...]
	Represents code supplied by user	void main (void) { ... }
Notes	A Note presents information that we want to re-emphasize, either to help you avoid a common pitfall or to make you aware of operating differences between some device family members. A Note can be in a box, or when used in a table or figure, it is located at the bottom of the table or figure.	Note: This is a standard note box.
		CAUTION This is a caution note. Note 1: This is a note used in a table.

RECOMMENDED READING

This user's guide describes how to use the Evaluation kit. The following Microchip documents are available and recommended as supplemental reference resources.

BM78 Data Sheet (DS60001380)

Refer to this document for detailed information on the BM78 module. Reference information found in this data sheet includes:

- BM78 Module features and pin configurations
- Electrical Specifications
- Reference Circuits

IS1678 Data Sheet (DS60001386)

Refer to this document for detailed information on the IS1678 SoC. Reference information found in this data sheet includes:

- IS1678 SoC features and pin configuration
- Electrical characteristics
- Reference Circuits

THE MICROCHIP WEB SITE

Microchip provides online support via our web site at: <http://www.microchip.com>. This web site makes files and information easily available to customers. Accessible by most Internet browsers, the web site contains the following information:

- **Product Support** – Data sheets and errata, application notes and sample programs, design resources, user's guides and hardware support documents, latest software releases and archived software
- **General Technical Support** – Frequently Asked Questions (FAQs), technical support requests, online discussion groups, Microchip consultant program member listings
- **Business of Microchip** – Product selector and ordering guides, latest Microchip press releases, listings of seminars and events; and listings of Microchip sales offices, distributors and factory representatives

DEVELOPMENT SYSTEMS CUSTOMER CHANGE NOTIFICATION SERVICE

Microchip's customer notification service helps keep customers current on Microchip products. Subscribers will receive e-mail notification whenever there are changes, updates, revisions or errata related to a specified product family or development tool of interest.

To register, access the Microchip web site at www.microchip.com, click on Customer Change Notification and follow the registration instructions.

The Development Systems product group categories are:

- **Compilers** – The latest information on Microchip C compilers and other language tools
- **Emulators** – The latest information on the Microchip in-circuit emulator, MPLAB REAL ICE™
- **In-Circuit Debuggers** – The latest information on the Microchip in-circuit debugger, MPLAB ICD 3
- **MPLAB X IDE** – The latest information on Microchip MPLAB X IDE, the Windows® Integrated Development Environment for development systems tools
- **Programmiers** – The latest information on Microchip programmers including the PICkit™ 3 development programmer

CUSTOMER SUPPORT

Users of Microchip products can receive assistance through several channels:

- Distributor or Representative
- Local Sales Office
- Field Application Engineer (FAE)
- Technical Support

Customers should contact their distributor, representative or Field Application Engineer (FAE) for support. Local sales offices are also available to help customers. A listing of sales offices and locations is included in the back of this document.

Technical support is available through the web site at: <http://support.microchip.com>.

DOCUMENT REVISION HISTORY

Revision A (January 2016)

This is the initial released version of this document.

NOTES:

Chapter 1. Introduction

Thank you for purchasing a BM78 Evaluation Kit. This document describes a detailed information about the Microchip Technology BM78 Evaluation Board (EVB).

The BM78 EVB enables the user to evaluate and demonstrate the functionalities of the Microchip BM78 dual-mode Bluetooth[®] module. The BM78 EVB includes an integrated configuration and programming interface for plug-and-play capability. It also includes on board connection and data status LEDs which enable rapid prototyping and quicker time to market.

Along with the BM78 EVB, software applications are provided to demonstrate the Bluetooth data connections to the on board BM78 module and optionally configuring it.

The demonstration softwares are as follows:

- Android™ Bluetooth Chat (BtChat) Application, Serial Port Profile (SPP)
- iOS Bluetooth Terminal (BLETR)
- Bluetooth Chat Tool

The configuration softwares are as follows:

- BM78 Configuration Library
- BM78 Configuration User Interface (UI) Tool
- BM78 EEPROM Table Utility

The BM78 EVB can be powered using USB host or through the Microchip PICtail™ Plus interface. The BM78 EVB uses a fully certified Bluetooth 4.2 dual-mode wireless BM78 module that supports Bluetooth classic SPP and BLE by providing Bluetooth serial data connections. The BM78 EVB provides a USB-Universal Asynchronous Receiver/Transmitter (UART) converter allowing flexible interface to host PC, a PC terminal utility, and smart phone Applications to drive both classic SPP and BLE data connections.

Additionally, the BM78 EVB also provides the PICtail and PICtail Plus interfaces to be able to interface with the Microchip PIC MCUs using standard Microchip development tools.

This chapter includes the following topics:

1.1 “Kit Contents”

1.2 “BM78 EVB Functionality”

1.3 “BM78 EVB Features”

1.4 “PICtail Plus Interface”

1.1 KIT CONTENTS

The BM78 EVB Evaluation kit contains the following items:

- EVB PCB
- BM78 Module (BM78SPPS5MC2/NC2)

Note: If you are missing any part of the Evaluation kit, contact a Microchip sales office for assistance. A list of Microchip offices for sales and service is provided on the back page of this document.

1.2 BM78 EVB FUNCTIONALITY

The following are key features of the BM78 EVB.

- Transparent serial data connection over Bluetooth classic SPP and BLE transparent serial data service
- Automatic configuration mode for quick setup (default)
- Manual configuration mode where the MCU can access configuration settings
- Configuration settings stored in the internal EEPROM of the BM78 module
- On board dip switch block to set operating modes
- PICTail and PICTail Plus interfaces to fully access the BM78 module using an external PIC MCU
- Embedded USB-to-UART converter to enable application mode and programming interface to update firmware and configuration settings

1.3 BM78 EVB FEATURES


Representations of the layout of the BM78 EVB are shown in [Figure 1-1](#) and [Figure 1-2](#).

The top assembly of the BM78 EVB includes these key features, as indicated in [Figure 1-1](#):

1. FP1 – BM78 module (BM78SPPS5MC2/NC2).
2. On board antenna – Mounted on the BM78 module.
3. CN2 – Header that brings out the BM78 module pins.
4. SW3 – Reset button.
5. SW4 – Mode Switch.
6. JP1 – Ground (GND) test points.
7. J1 – PICtail interface.
8. CN4 – I²C expansion port.
9. SW2 – Wake-up button.
10. SW1 – Button to SW_BTN pin.

For detailed information on these features, refer to **Chapter 2. “Hardware”**.


FIGURE 1-1: BM78 EVB (TOP VIEW)



The bottom assembly of the BM78 EVB includes these key features, as indicated in Figure 1-2:

1. U3 – Microchip MCP2200 chip, USB-to-UART serial converter.
2. J2 – PICTail Plus interface.
3. P1 – Mini-B USB connector.

FIGURE 1-2: BM78 EVB (BOTTOM VIEW)



1.3.1 USB-to-UART Serial Converter

The BM78 EVB consists of a USB-to-UART converter that enables flexible interface to a host computer, a computer terminal utility, and smart phone applications to drive both classic SPP and BLE data connections. The UART port on the BM78 is exposed through a MCP2200 USB-to-UART converter for easy interfacing with a host computer.

On the BM78 EVB, connecting the mini-B USB receptacle (P1) to the USB port of a computer enumerates the BM78 module as a Composite Device Class (CDC) USB device for serial communication. After the MCP2200 enumerates, a dedicated COM port is assigned to the host computer for serial communication with the BM78 module on the BM78 EVB. A computer terminal utility or application can open the assigned COM port and connect to the UART port for serial data transfer or to configure and control the BM78 module. If the MCP2200 does not enumerate, the user must download the MCP2200 drivers and install it from the following location: www.microchip.com/MCP2200.

1.4 PICtail PLUS INTERFACE

Using the PICtail Plus (J2) or PICtail (J1) interface, the BM78 EVB can be plugged into any standard Microchip development board, for example, Explorer 16 Development Board (DM240001) or the PIC18 Explorer Board (DM183032) which supports the PICtail Plus or PICtail interface. This interface provides access to the UART port and control and General Purpose Input/Output (GPIO) pins on the BM78 module.


The PICtail Plus or PICtail interface can be used to configure the BM78 module by updating the Bluetooth parameters residing on the internal EEPROM and the BM78 module firmware on the internal Flash, and put the BM78 module into Application mode. In Application mode, pairing procedure can be performed on the BM78 EVB followed by establishing a Bluetooth connection for SPP or BLE data transfer.

Figure 1-3 and Figure 1-4 show the BM78 EVB is inserted into PICtail and PICtail Plus interfaces.

FIGURE 1-3: BM78 EVB BOARD INSERTED INTO PICtail™ INTERFACE



FIGURE 1-4: BM78 EVB BOARD INSERTED INTO PICtail™ Plus INTERFACE




Note: Ensure that the BM78 module on the BM78 EVB is facing the PIC Plug-In Module (PIM) while inserting the BM78 EVB board into either of the EVB headers.

Chapter 2. Hardware

This chapter describes the hardware features of the BM78 EVB. The BM78 EVB includes a range of peripheral features as shown in [Figure 2-1](#).

FIGURE 2-1: BM78 EVB BLOCK DIAGRAM



2.1 HARDWARE FEATURES

The following key features of the BM78 EVB are provided in the order given in the [Figure 1-1](#).

2.1.1 Power Supply

Users can supply power to the BM78 EVB using any one of the following options:

- USB_5V which can be converted to 3V3 by MCP1700
- PICtail 3V3

2.1.2 USB connectivity

The BM78 EVB provides mini-USB cable connectivity.

2.1.3 Switches

Push-button switches provide the following functionalities:

- SW1 – Push on/off switch button
- SW2 – Wake-up switch to wake up the module from deep-sleep state
- SW3 – Reset button for the BM78 module
- SW4 – Mode switch

[Table 2-1](#) and [Table 2-2](#) provide the details of the SW1 and SW4 switches.

Note: The SW_BTN/SW1 button must be pressed to wake-up the BM78 module.

TABLE 2-1: SWITCH SW1 DETAILS

Part Number	Pin	Signal	Pin Description
SW1	1	GND	Connects 20 Kohm pull-down resistance
	2	SW_BTN	BM78 SW_BTN pin
	3	EXT_3V3	Power source from USB 5V to 3.3V LDO output
	4	NC	NC
	5	NC	NC
	6	NC	NC

TABLE 2-2: SWITCH SW4 DETAILS

Part Number	Pin	Signal	Pin Description
SW4	1	P2_0	P2_0 (pin 18), in the ON state, is connected with 4.7 kohm to GND.
	2	P2_4	P2_4 (pin 19), in the ON state, is connected with 4.7 kohm to GND.
	3	EAN	EAN (pin 20), in the ON state, is connected with 10 ohm to VDD_IO.

Table 2-3 provides the switch positions of the BM78 EVB.

TABLE 2-3: BM78 EVB SWITCH POSITIONS







Switch Position	Switch Number	1	2	3
	Pin Names	P2_0	P2_4	EAN
	ON State	Low	Low	High
	Pin Functions	Test Mode High = Application Mode Low = Test Mode	Flash Write High = Flash Write Enable Low = Flash Write Disable	Boot by Flash or ROM High = Boot from ROM Low = Boot from Flash

Table 2-4 provides the mode and switch positions for the BM78 EVB.

TABLE 2-4: BM78 EVB MODE SWITCH POSITIONS

Mode		Switch Positions	PIN Definition		
			1/P2_0	2/P2_4	3/EAN
Flash	Write Flash		ON	ON	ON
ROM	Test (Write EEPROM)		ON	OFF	ON
	Application (default)		OFF	OFF	ON
Flash	Test (Write EEPROM)		ON	OFF	OFF
	Application (default)		OFF	OFF	OFF

2.1.4 LED

The BM78 EVB contains one LED (D1) which displays the connection status.

2.1.5 Jumpers

Table 2-5 describes the pin, signal, and pin description of the Jumper J1.

TABLE 2-5: GROUND TEST CONNECTOR

Part Number	Pin	Signal	Pin Description
J1	1	GND	Ground Test Pin
	2	GND	Ground Test Pin

2.1.6 Ports

The [Table 2-6](#) provides the CN4-I²C expansion port details.

TABLE 2-6: CN4-I²C EXPANSION PORT DETAILS

Part Number	Pin	Signal	Pin Description
CN4	1	P1_2/SCL	BM78 P1_2 (pin 13) and its SCL function
	2	GND	Ground Pin
	3	P1_3/SDA	BM78 P1_3 (pin 14) and its SCL function
	4	NC	NC
	5	INT_3V3	Connect BM78 VDD_I/O
	6	NC	NC
	7	NC	NC
	8	P3_6	BM78 P3_6 (pin 28) and its Reset function
	9	NC	NC
	10	NC	NC

Chapter 3. Getting Started

This chapter describes how to establish Bluetooth serial data connection using the BM78 EVB over USB-to-UART MCP2200 interface. It also demonstrates the basic data capabilities and interoperability of the BM78 EVB with other Bluetooth devices.

Note: In this demonstrations, the BM78 EVB is a Bluetooth slave waiting for a connection to be initiated by the Bluetooth master device.

This chapter covers the following topics:

Section 3.1 “Prerequisites”

Section 3.2 “Using BM78 EVB in usb-to-Uart Serial Interface Mode”

Section 3.3 “Using BM78 EVB in PICtail Interface Mode”

3.1 PREREQUISITES

The following hardware and software are required for getting started with the BM78 EVB.

3.1.1 Hardware Requirement

- BM78 EVB
 - Users can procure the BM78 EVB from the Microchip web site: www.microchipdirect.com
- Bluetooth-enabled smart phone or tablet:
 - Android™ device running Android 4.3 or later version
 - iOS: iPhone® 4S or later version, iPad® 3 or later version (it must support BLE)
- Windows® host PC with USB port
- USB-mini cable

3.1.2 Software Requirement

The following applications are available for download from the Microchip web site: www.microchip.com/BM78.

- Bluetooth chat application, `BT Chat.exe`
- Android chat application, `BTChat.apk`
- iOS Terminal `BLETR`, available at Apple Store®
- Bluetooth SPP Pro Application
- MCP2200 driver for windows, available for download at www.microchip.com/MCP2200

3.2 USING BM78 EVB IN USB-TO-UART SERIAL INTERFACE MODE

Establishing the connection between Bluetooth classic and BLE data, and transferring data on the BM78 module through the USB-UART serial interface can be performed using a computer terminal utility and a smart phone application.


3.2.1 Bluetooth SPP demonstration using Android Devices

The host computer runs the Bluetooth chat application and transfers serial data over a COM-port (USB virtual COM-port) to the BM78 EVB which is then transmitted over a Bluetooth connection to the remote Bluetooth host. Please note, a smart phone application is used as a Bluetooth host for the SPP demonstration, see [Figure 3-1](#).

Note: For the SPP demonstration, a smart phone or tablet running Android v4.3 or later is required.

A virtual COM port is required when the BM78 EVB is connected to a host computer. If virtual COM port is not available in the Device Manager port list, install the Microchip MCP2200 driver which is available for download from the Microchip web site using the keyword "Microchip MCP2200 Driver".

FIGURE 3-1: BLUETOOTH SPP CONNECTION TO ANDROID SMART PHONE/TABLET




To set up the Bluetooth (SPP) data connection between the Bluetooth Chat application and smart phone application using the BM78 EVB, perform the following actions:

1. Ensure that the BM78 EVB is plugged into the EVB interface of a Microchip development board.
2. Verify the SW4 switch is set to the Application mode (ROM):
 - 1/P2_0: OFF
 - 2/P2_4: OFF
 - 3/EAN: ON
3. Verify that the SW1 button is ON (i.e. pushed down).
4. Using the mini-B USB cable, connect the BM78 EVB mini-B USB receptacle (P1) to the host computer USB port to power-up the EVB.
5. The LED1 (D1) display (blue) indicates the connection states as follows:
 - Stand-by state: the LED1 of the EVB will blink once
 - Pairing, connected state: the LED1 will blink twice

Note: The LED status can be configured by the UI settings.


6. Verify whether the virtual COM port is created.
7. Ensure that the COM port is connected and run `BT Chat Tool.exe` on your computer. The Bluetooth Chat Application window is displayed, see [Figure 3-2](#).

FIGURE 3-2: BLUETOOTH CHAT APPLICATION WINDOW



8. To transmit and receive a text:
 - Select COM Port which is assigned to the BM78 EVB
 - Select BaudRate (the default value is 115200)
9. Click **Connect**.
10. The Bluetooth Chat window will display the transmitted and received text along with the following options, see [Figure 3-3](#).


FIGURE 3-3: BLUETOOTH CHAT SHOWING TRANSMITTED AND RECEIVED TEXT



- a) Disconnect button: The button status is changed from the 'Connect' to the 'Disconnected'.
 - b) Text field: To enter the text to transmit.
 - c) Send button: To transmit the text to the smart phone over the BM78 EVB Bluetooth connection.
 - d) Message sent from the computer application (Bluetooth EVB) to the smart phone.
 - e) Message sent from the smart phone to the computer tool (BM78 EVB).
 - f) Burst send: Select this check box to send a text repeatedly from this application.
 - g) Repeat: Specify the number of times the text needs to be resent.
 - h) Interval: Choose the interval between two resends.
 - i) Clear: Press this button to clears the text from the text box.
11. Install the Bluetooth Chat application on the Android device by copying or downloading the `BtChat.apk` file. The `BtChat.apk` file can be copied to the Android device by using an SD card to transfer the files or by connecting the Android device to the host computer, wherein the Android device mounts as an external USB drive. Please note, Android MTP is required on the host computer.
12. After the `BtChat.apk` file is copied onto the Android device, perform the following actions:


- a) Tap 'Open File' to install "My Files" application from the File Manager. During installation, ensure that the "Unknown Sources" is enabled in the Device Security settings, see [Figure 3-4](#).
- b) After the installation, the BtChat application icon is displayed in the application view.

FIGURE 3-4: FILE MANAGER VIEW AND BtChat APPLICATION ICON




13. To pair the BM78 EVB with the Android device, perform the following actions, see [Figure 3-5](#).
 - a) On the Android device, go to *Settings > Bluetooth* and then turn on the Bluetooth by dragging **ON**.
 - b) Tap **Scan** to initiate the Bluetooth device scan.
 - c) Locate the Dual -SPP device (BM78 EVB) and then tap **Start** to start the pairing.
 - d) Once paired, the Dual-SPP device is listed in the paired devices list.

FIGURE 3-5: BtChat SHOWING PAIRED DEVICE LIST




14. To launch the BtChat application on the Android device, follow these steps:
 - a) From the BtChat main window, use the Android menu to open the BtChat menu, [Figure 3-6](#).
 - b) Tap **Setting** to open the Application Settings.

FIGURE 3-6: BtChat MENU




- c) Enable **Show Rx Text** option to display the received text in the application, see [Figure 3-7](#).
- d) Tap **Back** to return to the main window.

FIGURE 3-7: BtChat APPLICATION SETTINGS




15. To set up the Bluetooth SPP connection to the BM78 EVB, follow these steps, see [Figure 3-9](#).
 - a) From the Bluetooth Chat Application main screen, tap the Android menu to open the Bluetooth Chat menu options and Tap **Connect a device** to open the Paired Devices list.
 - b) Tap **Dual-SPP** to open an SPP connection to the BM78 EVB.

FIGURE 3-8: BtChat SHOWING DUAL SPP



- c) After the connection is established, the status message "Dual SPP has connected" will be displayed on the main window, see [Figure 3-9](#).

FIGURE 3-9: BtChat SHOWING DUAL SPP CONNECTION MESSAGE



16. [Figure 3-10](#) shows the data transfer from the BM78 EVB to the Android device through the Bluetooth SPP connection. To launch the Bluetooth chat application on the host computer and set the correct COM port that corresponds to the BM78 EVB, follow these steps:
 - a) On the BtChat application, enter the text to be sent to the Bluetooth Chat application on the host computer.
 - b) Click **Send** to transmit the text to the BM78 EVB which is connected to the Bluetooth Chat application.
 - c) The received text is displayed on the Bluetooth Chat window.
 - d) In the Bluetooth Chat window, enter the text to be sent to the BM78 EVB.
 - e) Click **Send** to transmit the text.
 - f) The Bluetooth Android application window will display the transmitted messages.

Note: The SPP demo can be performed using the Bluetooth SPP Pro Application on the Android devices. It can also work with iOS devices, but it needs Apple® authentication hardware, which connects the I²C expansion port and iOS application.

FIGURE 3-10: BLUETOOTH CHAT WINDOW



3.2.2 Connecting Bluetooth Low Energy (BLE) Data to iOS Device


This demonstration describes how serial data is transmitted from the BM78 EVB (through PC chat utility) to an iOS device using the BLE connection. This demonstration uses the BLETR application to establish the connection to the BM78 EVB. Please note, BLE do not need authentication hardware to work with iOS devices. The key feature of the BM78 EVB is a transparent serial data connection from the BM78 module's UART to an iOS device over BLE connection.

To connect BLE data to an iOS device, perform the following actions:

1. Using a device running iPhone 4S or later version or a device running iPad3 or later version, download and install the BLETR application, seen [Figure 3-11](#).


Note: Users can purchase the BLETR application from the Apple Store.

FIGURE 3-11: BLETR APPLICATION PAGE




2. [Figure 3-12](#) shows the Bluetooth radio on the iPhone, iPod, or iPad application Settings.
3. Tap *Settings > Bluetooth*.
4. To turn on Bluetooth, drag the slider.

FIGURE 3-12: ENABLING BLUETOOTH FUNCTIONALITY



5. BLETR scans the BLE peripheral devices and lists them, and if the devices are not displayed, tap **Refresh** to restart the BLE peripheral scan, see [Figure 3-13](#).


FIGURE 3-13: SCANNING BLE DEVICES



6. Search for the Dual-SPP BLE peripheral device and tap to establish the connection to the BM78 EVB.

7. On successful connection to the BM78 EVB, BLETR displays “Dual-SPP connected” message, see [Figure 3-14](#).

FIGURE 3-14: BLETR APPLICATION



8. Tap the connected Dual-SPP device to display the top-level view. The window displays the following three views when the Dual-SPP is connected to the BM78 EVB, see [Figure 3-15](#) and [Figure 3-16](#).
 - Transparent – Displays the received data, sent data, and options to enable the features.
 - Proprietary – Displays the BLE connection parameters.
 - Device Info – Displays the BLE device information service settings.

FIGURE 3-15: CONNECTED DUAL-SPP DEVICE SHOWING THREE VIEWS






FIGURE 3-16: TRANSPARENT, PROPRIETARY, AND DEVICE INFO VIEW DETAILS




- Tap **Transparent** to open the Transparent Serial Data view, which displays three modes: Raw, Timer, and Eco. See [Figure 3-17](#). For additional information on these three modes, refer to [Section 3.2.3 “Data Modes”](#).

FIGURE 3-17: DATA MODE



- To send data from the BLETR iOS device to the BM78 EVB, enter data in the text box using the soft keypad, see [Figure 3-18](#).


FIGURE 3-18: BLETR APPLICATION: SOFT KEYBOARD



11. Tap keypad to enter the text and then tap **Send** to transmit the text to the BM78 EVB over BLE connection.

- The text is received through the BM78 UART and is displayed in the Bluetooth Chat text window, see [Figure 3-19](#).

FIGURE 3-19: BLUETOOTH CHAT WINDOW SHOWING RECEIVED TEXT




3.2.3 Data Modes

Figure 3-20 provides detailed description of three modes: Raw, Timer, and Echo.

3.2.3.1 RAW

The Raw mode is the default mode which displays all received and sent data as ASCII value instead of hex value. In the text box, all received data will be displayed in red text.

FIGURE 3-20: RAW MODE




3.2.3.2 TIMER

The Timer mode enables the BLETR to send repeated text patterns to the Bluetooth chat application for throughput and data transfer test. For example, BLETR is configured to transmit 100 text blocks of 20 characters in every 1000 ms. The Bluetooth Chat application receives the text pattern data and displays it in red. The line break indicates the BLE packet break, that is, the transmitted text block is fragmented into multiple BLE packets. Figure 3-21 shows the BLETR window with values.

Users must tap Start button in the BLETR window to initiate the data transfer and the Bluetooth Chat application window will display the received data.

FIGURE 3-21: BLETR APPLICATION WINDOW AND BLUETOOTH CHAT WINDOW WITH RECEIVED DATA




3.2.3.3 TX FILE

The Tx File transfer feature is similar to the Timer feature. [Figure 3-22](#) shows the Tx File functions and the transferred files (which are embedded in the BLETR) to the BM78 EVB.

To transmit a file, perform these actions:

- Tap **Tx File**. The Tx File dialog is displayed.
- The Tx File window displays .txt file sizes to be transmitted. Tap the file size to be transmitted.
- The Bluetooth chat application will display the received files.


FIGURE 3-22: BLETR APPLICATION: TX FILE DIALOG BOX



3.2.3.4 ECHO

The Echo mode is an optional function in the Transparent mode data view. When the Echo feature is enabled, any data received by the BLETR is echoed back to the sender. [Figure 3-23](#) shows texts sent from the Bluetooth Chat tool being echoed to the BLETR when the Echo mode is enabled.


FIGURE 3-23: BLUETOOTH CHAT WINDOW



3.2.4 BLETR Application Device Information

[Figure 3-24](#) shows the device information view that displays the characteristics associated with the device information service. The device information service is available to all Bluetooth Low Energy 4.2 hosts that access the BM78 EVB and it provides the identification information of the BM78 BLE peripheral device.

FIGURE 3-24: BLETR APPLICATION: DEVICE INFORMATION VIEW



3.2.5 Proprietary (Configuration) Feature


In the Proprietary view users can remotely modify the following BLE connection parameters through BLETR. Please note the BLE connection parameters only affect the BLE connections.

- Max Interval – communication time (ms) interval between the BM78 module and BLE central device.
- Connection Timeout – time (ms) between communication events before a connection is considered lost.
- Latency – number of connection events the peripheral device (BM78 module) is allowed to skip.

To modify the BLE connection parameters, perform these actions:

1. Enter values for Max Interval, Connection Timeout, and Latency.
2. Tap **Update**.
3. Enter a new name in the text field and then tap **Change name** to invoke the modifications, see [Figure 3-25](#). This name is used to advertise the peripheral name for scanning central devices.

FIGURE 3-25: BLETR APPLICATION: PROPRIETARY VIEW



3.3 USING BM78 EVB IN PICTAIL INTERFACE MODE

This section provides an overview of tools that can be used to configure the BM78 EVB using a PIC MCU through the PICTail interface. The BM78 Configuration UI Tool is used to change the Bluetooth parameters and generate a EEPROM configuration dump file. The BM78 EEPROM table utility can be used to convert the EEPROM configuration dump file generated by the BM78 UI tool into an EEPROM structure file, for additional information refer to “*EEPROM_Tool User Manual*” available for download from the Microchip web site. The EEPROM structure file can be imported by the BM78 configuration library demo workspace to program the Bluetooth parameters to the BM78 module through the PICTail interface over UART.


3.3.1 Configuring BM78 Module Using User Interface (UI) Tool

Using the BM78 module, users can update and configure various Bluetooth configuration parameters. The BM78 Configuration UI Tool or BM78 UI Tool is a user friendly computer application that enables the user to update various Bluetooth parameters and save in the EEPROM configuration dump file. The Bluetooth parameters, saved in the EEPROM configuration dump file, can be downloaded to the BM78 module using the BM78 Configuration Library.

The BM78 UI tool is available for download from the www.microchip.com/BM78.


1. Download the BM78 Configuration UI tool to a computer (Windows OS) and run the application.
2. From the BM78 UI tool dialog, click **Load** to import the default EEPROM configuration dump file (BM78_eeeprom_configuration_dump_default.txt), provided with the application, see [Figure 3-26](#).

FIGURE 3-26: UI TOOL VIEW




3. Browse to import the dump file, and then click **Open**, see [Figure 3-27](#).

FIGURE 3-27: LOAD UI PARAMETER



4. In the UI Tool dialog, under Version & Device section, Click **Edit**, see [Figure 3-28](#).

FIGURE 3-28: UI TOOL VIEW



5. The BM78 UI tool will display the Bluetooth configuration window with various options (tabs) to configure Bluetooth parameters, see [Figure 3-29](#). Click **Help** to configure each parameters required for the specific application.
6. After updating the Bluetooth parameters, click **Finish**. The Start Menu window is displayed.

FIGURE 3-29: UI PARAMETER SETTING PAGE

The screenshot shows the 'Beacon Setting' configuration window. The tabs at the top are: Beacon Setting, System Setup, System Setup2, LE Mode Setup, LE DIS Setup, LED Setup, Description Setup, and MFi Setup. The 'Beacon Setting' tab is selected.

Device Information

BT Address	<input checked="" type="checkbox"/> Enable	0x	<input type="text"/>	[6 Bytes]	Help
Class of Device		0x	040424	[3 Bytes]	
Device Name			Dual-SPP	[16 characters]	
PIN Code			0000	[4 ~ 16 Number]	
BT3.0 UUID		0x	0000	[2 Bytes]	

SPP Server Setting

RFCOMM Server Channel	0x00 : default	Help
-----------------------	----------------	----------------------

Uart Setting

HCI Baud Rate Index	0x03 : 115200	Help
Parity Check	Disable	
Stop Bits	1 bit	
Parity Mode	ODD	
H/W Flow Control (CTS)	Disable	

Navigation buttons: [Previous](#), [Next](#), [Finish](#)


7. In the Start Menu, click **Save** to save the updated EEPROM configuration dump file. The new EEPROM configuration dump file will be different from the default EEPROM configuration dump file due to the updates made to the Bluetooth parameters using the BM78 UI tool.

FIGURE 3-30: START MENU VIEW



8. In the Save As window, select the file location, and then click **Save**.

FIGURE 3-31: SAVE AS WINDOW



Appendix A. Schematics

A.1 BM78 EVB SCHEMATICS

FIGURE A-1: BM78 EVB SCHEMATICS




FIGURE A-2: BM78 MODULE TEST INTERFACE




FIGURE A-3: BM78 EVB CONFIGURATION




FIGURE A-4: BM78 EVB POWER SWITCH TEST BUTTON




FIGURE A-5: VBAT GROUND TEST CONNECTOR




FIGURE A-6: EXTERNAL I²C INTERFACE




FIGURE A-7: BM78 EVB SCHEMATIC




FIGURE A-8: USB TO UART CONVERTER




FIGURE A-9: PICTAIL PLUS 30-PIN INTERFACE ON BM78 EVB BOARD





FIGURE A-10: PICTAIL 28-PIN INTERFACE ON BM78 EVB BOARD



NOTES:



MICROCHIP

Worldwide Sales and Service

AMERICAS

Corporate Office
2355 West Chandler Blvd.
Chandler, AZ 85224-6199
Tel: 480-792-7200
Fax: 480-792-7277
Technical Support:
<http://www.microchip.com/support>
Web Address:
www.microchip.com

Atlanta
Duluth, GA
Tel: 678-957-9614
Fax: 678-957-1455

Austin, TX
Tel: 512-257-3370

Boston
Westborough, MA
Tel: 774-760-0087
Fax: 774-760-0088

Chicago
Itasca, IL
Tel: 630-285-0071
Fax: 630-285-0075

Cleveland
Independence, OH
Tel: 216-447-0464
Fax: 216-447-0643

Dallas
Addison, TX
Tel: 972-818-7423
Fax: 972-818-2924

Detroit
Novi, MI
Tel: 248-848-4000

Houston, TX
Tel: 281-894-5983

Indianapolis
Noblesville, IN
Tel: 317-773-8323
Fax: 317-773-5453

Los Angeles
Mission Viejo, CA
Tel: 949-462-9523
Fax: 949-462-9608

New York, NY
Tel: 631-435-6000

San Jose, CA
Tel: 408-735-9110

Canada - Toronto
Tel: 905-673-0699
Fax: 905-673-6509

ASIA/PACIFIC

Asia Pacific Office
Suites 3707-14, 37th Floor
Tower 6, The Gateway
Harbour City, Kowloon

Hong Kong
Tel: 852-2943-5100
Fax: 852-2401-3431

Australia - Sydney
Tel: 61-2-9868-6733
Fax: 61-2-9868-6755

China - Beijing
Tel: 86-10-8569-7000
Fax: 86-10-8528-2104

China - Chengdu
Tel: 86-28-8665-5511
Fax: 86-28-8665-7889

China - Chongqing
Tel: 86-23-8980-9588
Fax: 86-23-8980-9500

China - Dongguan
Tel: 86-769-8702-9880

China - Hangzhou
Tel: 86-571-8792-8115
Fax: 86-571-8792-8116

China - Hong Kong SAR
Tel: 852-2943-5100
Fax: 852-2401-3431

China - Nanjing
Tel: 86-25-8473-2460
Fax: 86-25-8473-2470

China - Qingdao
Tel: 86-532-8502-7355
Fax: 86-532-8502-7205

China - Shanghai
Tel: 86-21-5407-5533
Fax: 86-21-5407-5066

China - Shenyang
Tel: 86-24-2334-2829
Fax: 86-24-2334-2393

China - Shenzhen
Tel: 86-755-8864-2200
Fax: 86-755-8203-1760

China - Wuhan
Tel: 86-27-5980-5300
Fax: 86-27-5980-5118

China - Xian
Tel: 86-29-8833-7252
Fax: 86-29-8833-7256

ASIA/PACIFIC

China - Xiamen
Tel: 86-592-2388138
Fax: 86-592-2388130

China - Zhuhai
Tel: 86-756-3210040
Fax: 86-756-3210049

India - Bangalore
Tel: 91-80-3090-4444
Fax: 91-80-3090-4123

India - New Delhi
Tel: 91-11-4160-8631
Fax: 91-11-4160-8632

India - Pune
Tel: 91-20-3019-1500

Japan - Osaka
Tel: 81-6-6152-7160
Fax: 81-6-6152-9310

Japan - Tokyo
Tel: 81-3-6880-3770
Fax: 81-3-6880-3771

Korea - Daegu
Tel: 82-53-744-4301
Fax: 82-53-744-4302

Korea - Seoul
Tel: 82-2-554-7200
Fax: 82-2-558-5932 or
82-2-558-5934

Malaysia - Kuala Lumpur
Tel: 60-3-6201-9857
Fax: 60-3-6201-9859

Malaysia - Penang
Tel: 60-4-227-8870
Fax: 60-4-227-4068

Philippines - Manila
Tel: 63-2-634-9065
Fax: 63-2-634-9069

Singapore
Tel: 65-6334-8870
Fax: 65-6334-8850

Taiwan - Hsin Chu
Tel: 886-3-5778-366
Fax: 886-3-5770-955

Taiwan - Kaohsiung
Tel: 886-7-213-7828

Taiwan - Taipei
Tel: 886-2-2508-8600
Fax: 886-2-2508-0102

Thailand - Bangkok
Tel: 66-2-694-1351
Fax: 66-2-694-1350

EUROPE

Austria - Wels
Tel: 43-7242-2244-39
Fax: 43-7242-2244-393

Denmark - Copenhagen
Tel: 45-4450-2828
Fax: 45-4485-2829

France - Paris
Tel: 33-1-69-53-63-20
Fax: 33-1-69-30-90-79

Germany - Dusseldorf
Tel: 49-2129-3766400

Germany - Karlsruhe
Tel: 49-721-625370

Germany - Munich
Tel: 49-89-627-144-0
Fax: 49-89-627-144-44

Italy - Milan
Tel: 39-0331-742611
Fax: 39-0331-466781

Italy - Venice
Tel: 39-049-7625286

Netherlands - Druen
Tel: 31-416-690399
Fax: 31-416-690340

Poland - Warsaw
Tel: 48-22-3325737

Spain - Madrid
Tel: 34-91-708-08-90
Fax: 34-91-708-08-91

Sweden - Stockholm
Tel: 46-8-5090-4654

UK - Wokingham
Tel: 44-118-921-5800
Fax: 44-118-921-5820

07/14/15