RFM22 Shield Landing Page

Skill Level: 🖈 Beginner

Overview:



The RFM22 shield is an Arduino-compatible shield which provides a means to communicate with the HOPERF RFM22 radio transceiver module. What does THAT mean? It means you can use the RFM22 shield to add wireless communications to your Arduino projects.

This tutorial will give you the information you need to assemble your shield and start using it.

Requirements:

You'll need at least two RFM22 modules to set up communications- the RFM22 is not compatible with other wireless modules on the market, such as XBee, Bluetooth or the RFM12. You'll also need to make sure that your kit is complete- check the list below to see if all the necessary parts came in your package:

- 1 x pre-assembled RFM22 shield PCB. Compare to the picture above to make sure everything is in the right place.
- 2 x long-pin 1x8 female headers
- 2 x long-pin 1x6 female headers
- 1 x 5" wire (22ga solid)



If you find that anything's missing, drop our customer service folks an email and they'll help you out.

Next, you'll need to pull together the various tools that you need for assembly. All you need to provide is a wire stripper, a soldering iron, and some solder. You may find it handy to have a third hand tool or vise to hold the board steady while you solder. Our beginner's tool kit has everything you need in one place.

Assembly:

Assembly of the RFM22 shield is quite easy. The hardest part is getting the headers perpendicular to the board such that the shield plugs easily into Arduino boards, and other shields can be plugged in on top of it.

Start by placing the four header strips in the appropriate locations, by number of pins. The male pins should be sticking out on the side of the board with no components, and the female sockets should be visible when looking down at the component side. NB: at this point, if you have a known-good Arduino shield, you can plug it into the female side of the headers to hold them at a favorable angle and skip straight to soldering all the connections down. Be careful if you do that, though, because a small alignment error in the "good" shield will become a much larger error on the one you're soldering to now!



Flip the board over so the male pin side is up. This is the tricky part- the headers have a tendency to rock left to right, so that the end up soldered at a non-right angle with the board, which makes connecting other boards difficult or impossible. Tack down one and only one pin on each header.



Now pick the board up. See how the headers stay in one place? That's great, because it's time to fit-check the thing. You can plug it into your Arduino board and see if goes in nicely; if not adjust any header that's at an inauspicious angle. To do that, hold the board as shown below and use your iron to melt the solder on the one pin that you tacked down earlier. Applying a little pressure with your forefinger on the female side of the header will cause it to sit flat on the board, most likely nice and perpendicular to the board. Make sure your fingers are not touching the pin you'll be heating!



Once all four headers are nice and square, set the board down again and solder the other pins. It pays to start soldering pins as far from the singles that you tacked down earlier as possible; that way, you won't accidentally melt the first one and cause the header to go all wobbly again before it's secured.



Next, you'll need to attach the piece of wire we've provided to the board. It will function as a 1/4 wavelength whip antenna; the radio module won't work properly without it. Start by stripping about 1/8" - 1/4" (3-6mm) of insulation off the end of the wire and threading the stripped portion up through the antenna hole as pictured below. Solder the wire to the pad as you would any other connection.



Once the wire is soldered in place, measure 8.3cm (3 1/4 inches) of wire from the underside of the board and snip off the excess. This tunes the antenna to 1/4 of the wavelength of the transmit/receive frequency (910MHz), which gives the best performance/size tradeoff.



Now thread the antenna back up through the strain relief hole and out the top of the board. You're done!



Using the RFM22 Shield:

The RFM22 device is a little more complex than other "virtual wire" type wireless solutions. Fortunately, Mike McCauley has written a good library for the Arduino which can be downloaded here. Once you've downloaded the file, extract the archive and install it for Arduino by copying it into the "Libraries" subdirectory in your Sketchbook folder. You may have to create a "Libraries" directory. Find the Sketchbook location by checking in the "Preferences" window in the Arduino IDE; once you've placed the library in the directory, restart the IDE and you should see the "RF22" option under the "Import Library..." sub-menu in the "Sketch" menu.

Brettchbook location: Browse Editor language: System Default Inquires restart of Ardu Editor font size: 10 (requires restart of Arduino) Show verbose output during: compilation upload Image: Verify code after upload Sketchbook location! Image: Verify compate to new extension on save (.pde -> .ino) Image: Image: Automatically associate .ino files with Arduino More preferences.txt (edit only when Arduino is not running) Image: OK Cancel Image: Veri	uino)
C:Dropbox\Arduino Sketchbook Browse Editor language: System Default Fequires restart of Arduino) Editor font size: 10 (requires restart of Arduino) Show verbose output during: compilation upload Image: Sketchbook location! Image: Compilation upload Sketchbook Image: Check for updates on startup Image: Check for updates on startup Image: Update sketch files to new extension on save (.pde -> .ino) Image: Automatically associate .ino files with Arduino More preferences can be edited directly in the file C:\Users\%USERNAME%\AppData\Roaming\Arduino\preferences.txt Cancel Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image:	uino)
Editor language: System Default Editor font size: 10 (requires restart of Arduino) Show verbose output during: compilation upload Sketchbook Use external editor Use external editor Check for updates on startup Update sketch files to new extension on save (.pde -> .ino) Automatically associate .ino files with Arduino More preferences can be edited directly in the file C: Users\%USERNAME%\AppData\Roaming\Arduino\preferences.txt (edit only when Arduino 1.0.1 Cancel Sketch_aug14a Arduino 1.0.1 City / Compile Ctrl+R	uino)
Editor font size: 10 (requires restart of Arduino) Show verbose output during: compilation upload Verify code after upload Use external editor Check for updates on startup Update sketch files to new extension on save (.pde -> .ino) Automatically associate .ino files with Arduino More preferences can be edited directly in the file C:\Users\%USERNAME%\AppData\Roaming\Arduino\preferences.txt (edit only when Arduino 1.0.1 Cancel Sketch_aug14a Arduino 1.0.1 Ctrl+R	
Show verbose output during: compilation upload Verify code after upload Use external editor Check for updates on startup Update sketch files to new extension on save (.pde -> .ino) Automatically associate .ino files with Arduino More preferences can be edited directly in the file C: Users\%USERNAME%\AppData\Roaming\Arduino\preferences.txt (edit only when Arduino 1.0.1 Cancel Sketch_aug14a Arduino 1.0.1 Ctrl+R	
Sketchbook Sketchbook Verify code after upload Sketchbook Use external editor Check for updates on startup Update sketch files to new extension on save (.pde -> .ino) Automatically associate .ino files with Arduino More preferences can be edited directly in the file C:Users\%USERNAME%\AppData\Roaming\Arduino\preferences.txt (edit only when Arduino 1.0.1 Edit Sketch_aug14a Arduino 1.0.1 Verify / Compile Ctrl+R	
Verify code after upload Iocation! Use external editor Vulpe external editor Verify / State extension on save (.pde -> .ino) Vulpe external editor OK Cancel C:\Users\%USERNAME%\AppData\Roaming\Arduino\preferences.txt (edit only when Arduino 1.0.1 Cancel C:\Users\%UserNAME%\Compile Ctrl+R Verify / Compile	
Use external editor Check for updates on startup Update sketch files to new extension on save (.pde -> .ino) Automatically associate .ino files with Arduino More preferences can be edited directly in the file C:Users\%USERNAME%\AppData\Roaming\Arduino\preferences.txt (edit only when Arduino is not running) OK Cancel sketch_aug14a Arduino 1.0.1 Edit Sketch Tools Help Verify / Compile Ctrl+R	
 Check for updates on startup Update sketch files to new extension on save (.pde -> .ino) Automatically associate .ino files with Arduino More preferences can be edited directly in the file C: Users\%USERNAME%\AppData\Roaming\Arduino\preferences.txt (edit only when Arduino is not running) OK Cancel cancel cancel cancel cancel complexecht Tools Help Verify / Compile Ctrl+R 	
✓ Update sketch files to new extension on save (.pde -> .ino) ✓ Automatically associate .ino files with Arduino More preferences can be edited directly in the file C: Users\%USERNAME%\AppData\Roaming\Arduino\preferences.txt (edit only when Arduino is not running) OK Cancel sketch_aug14a Arduino 1.0.1 Edit Sketch Tools Help Verify / Compile Ctrl+R	
V Update sketch files to new extension on save (.pde -> .ino) Automatically associate .ino files with Arduino More preferences can be edited directly in the file C:\Users\%USERNAME%\AppData\Roaming\Arduino\preferences.txt (edit only when Arduino is not running) OK Cancel sketch_aug14a Arduino 1.0.1 Edit Sketch Tools Help Verify / Compile Ctrl+R	
Automatically associate .ino files with Arduino More preferences can be edited directly in the file C: \Users\%USERNAME%\AppData\Roaming\Arduino\preferences.txt (edit only when Arduino is not running) OK Cancel	
More preferences can be edited directly in the file C:\Users\%USERNAME%\AppData\Roaming\Arduino\preferences.txt (edit only when Arduino is not running) OK Cancel Sketch_aug14a Arduino 1.0.1 Edit Sketch Tools Help Verify / Compile Ctrl+R	
(edit only when Arduino is not running) OK Cancel sketch_aug14a Arduino 1.0.1 Edit Sketch Tools Help Verify / Compile Ctrl+R	
OK Cancel sketch_aug14a Arduino 1.0.1 Image: Complement of the second	
sketch_aug14a Arduino 1.0.1	
Edit Sketch Tools Help Verify / Compile	
Edit [Sketch] Tools Help Verify / Compile Ctrl+R	, x
Verify / Compile Ctrl+R	_
	P
ketch Show Sketch Folder Ctrl+K	
Add File	
Import Library EEPROM Ethoremeth	
Firmata	
LiquidCrystal	
SD	
Servo	
SoftwareSerial	
SPI	
Stepper	
Wire	
Contributed	
AlphaNumeric_Driver	
Editedfor101	
EthernetBonjour	
EthernetDHCP	
EthernetDNS	1115
i2cmaster	•
IRremote	•
mbMotor) I
NewSoftSerial	,
	F
Nunchuck Pon	► сом23
Nunchuck ^{P on I}	, сом23
Nunchuck ^{> on} RF22 TinvGPS10	, сом23
Nunchuck ^{> on} RF22 TinyGPS10 TrueRandom	, сом23
Nunchuck ^{> on} RF22 TinyGPS10 TrueRandom Twitter	, сом23

The library comes with a number of good examples; for our purposes here, we'll load the simplest ones: the "rf22_client" and "rf22_server".

File Edit Sketch Tools	Help _		
New	Ctrl+N		
Open	Ctrl+O		
Sketchbook	•	TRANSPORT DE LE CONTRA	
Examples	,	01.Basics	
Close	Ctrl+W	02.Digital	1PGateway
Save	Ctrl+S	03.Analog	rf22_client
Save As	Ctrl+Shift+S	04.Communication +	rf22_datagram_client
Upload	Ctrl+U	05.Control	rf22_datagram_server
Upload Using Progr	ammer Ctrl+Shift+U	06.Sensors	rf22_mesh_client
Page Setup	Ctrl+Shift+P	07.Display	rf22_mesh_server1
Print	Ctrl+P	00.USP/(annuta)	rf22_mesh_server2
Drafarancar	Ctile Comma	(USUSD(Leonardo)	rf22_mesh_server3
ricicia	Curreconnia	ArdunolSP	rf22_reliable_datagram_client
Quit	Ctrl+Q	AlphaNumeric_Driver +	rf22_reliable_datagram_server
		Editedfor101 +	rf22_router_client
	_	EthernetBonjour +	rf22_router_server1
	_	EthernetDHCP +	rf22_router_server2
		EthernetDNS +	rf22_router_server3
		IRremote +	rf22_server
		NewSoftSerial >	rf22_snoop
		Nunchuck +	rf22_specan
		RF22	rf22_test
nu.		TinyGPS10	
Î.		TrueRandom +	сом23
		Twitter +	
		WiFly +	
		EEPROM +	
		Ethernet +	
		Firmata +	
		LiquidCrystal +	
		SD +	
		Servo 🕨	
		SoftwareSerial +	
		SPI >	
		Stepper +	
		Wire +	

Before we go any further, I want to point out that the more complex classes of the RFM22 module- RF22Datagram, RF22ReliableDatagram, RF22Router and RF22Mesh- are known to run poorly or not at all on ATmega328P based Arduino-compatibles (UNO, Pro, ProMicro, Duemilanova, etc) and <u>none</u> of the RF22 library support works on ATmega168 based boards (although those are only the very oldest of boards). At the time of this writing, support for Leonardo and other 32u4 based Arduino-compatibles (e.g., SparkFun's Promicro boards) has not been verified. Support is in place for Arduino Mega boards, however.

Okay, now that I've gotten that warning out of the way, let's go ahead and load up "rf22_client" and see what happens.

🛃 COM31	
	Send
ornaring to tree_states	100
No reply, is rf22_server running?	^
Sending to rf22_server	
No reply, is rf22_server running?	
Sending to rf22_server	
No reply, is rf22_server running?	
Sending to rf22_server	
No reply, is rf22_server running?	
Sending to rf22_server	
No reply, is rf22_server running?	
Sending to rf22 server	
No reply, is rf22_server running?	
Sending to rf22_server	=
No reply, is rf22_server running?	
Sending to rf22_server	-
V Autoscroll	No line ending 🚽 9600 baud 🚽

If there had been a failure of the RFM22 module, we'd see a complaint in the Arduino Serial Monitor (making sure the baud rate is set to 9600). As it is, the "No reply, is rf22_server running?" message lets us know that the sketch is running correctly, the library compiled properly and the module is communicating properly with the Arduino. Unplug this Arduino and plug in another one, with another RFM22 shield attached to it, and load the "rf22_server" sketch onto that board. Launch the Arduino Serial Monitor, and you'll note that there's no traffic at all. That's as should be; the sketch only prints messages received from an "rf22_client" device. Now plug in the other Arduino, the one that you already install "rf22_client" on, and watch what happens in the Serial Monitor window.

1		Send
Sent a reply		
got request: Hello Woo	rld!	
Sent a reply		
got request: Hello Woo	rld!	
Sent a reply		
got request: Hello Wos	rld!	
Sent a reply		
got request: Hello Woo	rld!	1
Sent a reply		
got request: Hello Wor	rld!	

As soon as the new Arduino comes online- not more than a couple of seconds- you'll see a message start scrolling by indicating that the message "Hello world!" was received, and that a reply was sent. If you open the Serial Monitor to the "rf22_client" board, you'll notice a similar message:

		Send
got reply: And hello bac Sending to rf22_server	k to you	*
got reply: And hello bac Sending to rf22_server	k to you	
got reply: And hello bac Sending to rf22_server	k to you	
got reply: And hello bac Sending to rf22_server	k to you	
got reply: And hello bac Sending to rf22_server	k to you	

That message displays the text returned from the board programmed with the "rf22_server" example. Thus, these two examples show how to pass data back and forth between two devices and how to respond when a message has been received. For more information, check out the library webpage.

Important Legal Information:

The RF22 library downloadable from our site configures the RFM22 to operate at 910MHz. This is okay in the US and some other countries, but before you make extensive use of it in projects, <u>please</u> check your local regulations to ensure that it is not interfering with other local radio services. Note that the RF22 library as downloaded from the library webpage at open.com.au configures the device to transmit at 433MHz, which is not a generally acceptable frequency for use in the United States.

Next steps: