How to measure motor parameters

EVAL_100W_DRIVE_CFD2 September 2017



Principal motor parameters – steps and instruments



Fundamental parameters are: R, L, pole pairs, BEMF constant

Measure resistance

Measure inductance


Count pole pairs

Measure BEMF


- Detach your motor > cables
- Connect a
 resistance
 multimeter to two
 phases and leave the third floating
- Detach your motor cables
- Connect a R-L > multimeter to two phases and leave the third floating
- Detach your motor cables
- Connect an oscilloscope voltage probe to two phases and leave the third floating
- Detach your motor cables
- Connect an oscilloscope voltage probe to two phases and leave the third floating




Measure phase-to-phase resistance











- Detach motor cables
- Connect two phases to Ohm-meter
- Leave third phase open
- Write down the phase-to-phase resistance value



Measure phase to phase inductance











- Detach motor cables
- Connect two phases to RCL-meter set to 1 KHz
- Leave third phase open
- Write down the phase-to-phase inductance value





Measure pole pairs number












- Detach motor cables
- Connect two phases to oscilloscope voltage probe
- Leave third phase open
- Move the motor by hand and make one mechanical turn
- Count the peaks of the sinusoid





Measure BEMF constant




- Detach motor cables
- Connect two phases to oscilloscope voltage probe
- Leave third phase open
- Move the motor by hand
- Write down the frequency and the peak-to-peak value of the sinusoid
- Use equation in slide 9













Measure BEMF constant



- Detach motor cables
- Connect two phases to oscilloscope voltage probe
- Leave third phase open
- Move the motor by hand
- Write down the frequency and the peak-to-peak value of the sinusoid
- Use equation in slide 9





Formula to get BEMF at 1kRPM I/n rms

Use this formula to get the BEMF constant

$$Ke_{1kRPM \ln rms} = \frac{V_{pp}}{2 \times \sqrt{2} \times \sqrt{3}} \times \frac{16,67 \times N_{polepairs}}{f_{measured}} = \frac{V_{pp}}{f_{measured}} \times N_{polepairs} \times 3,40$$

Support Online tools and services







Subscribe to Newsletter

Where to Buy

Tools, Finders and Selectors

Support





Part of your life. Part of tomorrow.

