

# LTE-BLE 5.2, 802.15.4 Modules, M.2 Connector

Ver 1.00 Aug. 2021

LN60G840F Series modules integrate a Nordic nRF9160 LTE SIP module with a Fanstel BLE 5.2/Thread/Zigbee module, with an u.FI connector for external LTE antenna, an integrated GPS antenna with amplifier or an u.FL for external GPS antenna, a SIM card connector. It allows faster time to market with reduced development cost.



An M.2 connector, B key is used to connect to the host processor.

## LTE Specifications:

### Microcontroller:

- ARM® Cortex® -M33
- 1 MB flash, 256 kB low leakage RAM
- ARM® Trustzone®
- ARM® Cryptocell 310
- 2x UART (CTS/RTS)
- 11 GPIOs
- SIM card interface for external ESIM.
- On board nano SIM card connector

### LTE modem:

- Transceiver and baseband
- 3GPP LTE release 13 Cat-M1 and Cat-NB1 compliant
  - 3GPP release 13 coverage enhancement
- 3GPP LTE release 14 Cat-NB2 compliant
- GPS receiver
  - GPS L1 C/A supported
  - GPS antenna and amplifier integrated
- RF transceiver for global coverage
  - Up to 23 dBm output power
  - -108 dBm sensitivity (LTE-M) for low band, -107 dBm for mid band
  - An u.FL connector for external LTE antenna
- LTE band support in hardware:
  - Cat-M1: B1, B2, B3, B4, B5, B8, B12, B13, B14, B17, B18, B19, B20, B25, B26, B28, B66
  - Cat-NB1/NB2: B1, B2, B3, B4, B5, B8, B12, B13, B17, B18, B20, B25, B26, B28, B66
- IP v4/v6 stack
- Secure socket (TLS/DTLS) API


- BT840XE, max. TX at +21 dBm, range over 4500 meters in free space at 125 Kbps.
- BT40F with dual core Cortex M33, up to 128 MHz
- USB interface
- UART interface
- 37 GPIOs

### Miscellaneous

- Operation temperature: -40°C to +85°C
- All necessary clock sources integrated
- Size: 30x42mm.
- Package: for M.2 connector, B Key, 67 pins.
- EV board: EV-LN60G

## Hardware for Development

- EV board: EV-LN60G, a base board with an M.2 connector, a flat cable, and an USB cable.
- Programming Kit: PK-BLG840G, an USB to UART bridge board for interfacing and monitoring UART.
- Nordic nRF9160DK
- Nordic nRF5340DK for LN60G40F/E.



## Bluetooth Specifications

- BLE 5.2 modules with nRF52840, nRF5340

## LN Modules Supporting LTE and BLE

Module	LN60G40F	LN60G40X	LN60E840E	LN60G840F	LN60G840XE	LN60G	LN60E
BLE module	BT40F	BT40X	BT840E	BT840F	BT840XE		
BLE antenna	Integrated	u.FL+u.FL	u.FL	Integrated	PA + u.FL		
LTE module	nRF9160 SICA						
LTE antenna	u.FL						
GPS antenna	Integrated	Integrated	u.FL	Integrated	Integrated	Integrated	u.FL
Certifications							
QDID	119517		108621	108621	108621		
Availability	Production		Production	Production	Production	Production	Production

## Table Of Contents

1. Introduction.....	3
LN60G Series, LTE with Optional BLE 5.2 Modules .....	3
Available LN60G Series Modules.....	5
2. Product Descriptions .....	6
nRF9160 Specifications.....	6
BT840F .....	7
BT840XE .....	8
Mechanical Drawings .....	9
M.2 Connector Pin Assignments.....	11
Pin Function.....	13
3. Codes Development Using Nordic Tools.....	16
Over-The-Air DFU .....	16
SoftDevices .....	16
Development Tools .....	16
Control nRF21540 in BT40X .....	17
Control Skyworks Power Amplifier in BT840X.....	17
4. Application Examples .....	18
BLG840F, BLE to LTE Gateway .....	18
LEW840X, BLE-LoRa to LTE, WiFi, PoE Ethernet Gateway.....	19
5. Establishing Cloud Connection and Programming.....	20
PK-BLG840F, the LTE Monitor Board.....	20
EV-LN60G .....	21
EV-LN60G840F .....	22
Download and set up Basic Software tools for LN60E40F.....	22
Establishing an LTE Connection to a Cloud Server .....	22
Relaying Sensor Data to a Cloud Server .....	25
Using Android OS .....	26
Programming the nRF9160.....	27
EV-LN60G EvaluationBoard Schematics .....	31
Packaging and Lot Number .....	33
FCC Label .....	33
Revision History .....	34
Contact Us .....	35


## 1. Introduction

LN60G840F Series modules are powerful, highly flexible, ultra low power wireless modules integrating Nordic nRF9160 SIP module and Fanstel BT40F Series BLE 5.1 or BT840F Series BLE 5 module. With an ARM Cortex™ M33F MCU, 1MB flash, 256KB RAM, embedded LTE-M and NB-IoT transceiver, an u.FL connector for external LTE antenna, integrated GPS antenna and amplifier or an u.FL for external GPS antenna, it allows faster time to market with reduced development cost.

This Series of modules for M.2 connector is referred as the **LN (LTE-M/NB-IoT) Module**.

## LN60G Series, LTE with Optional BLE 5.2 Modules

The following is a block diagram of LN60G840F. Module can be standalone, needing only DC power supply and cross-connect UART on host board. Or, a host processor can control Bluetooth and LTE interfaces through M.2 connector pins.



LN60E and LN60G are without Bluetooth module.

Modules available in the LN60G40F Series.

### LN60E

- nRF9160 SICA SIP module supporting LTE-M and NB-IoT at +23 dBm TX
- An u.FL connector for an external LTE antenna
- An u.FL connector for an external GPS antenna
- Cortex M33 MCU 1MB flash, 256 KB RAM

### LN60G

- nRF9160 SICA SIP module supporting LTE-M and NB-IoT at +23 dBm TX
- An u.FL connector for an external LTE antenna
- GPS receiver with integrated amplifier and antenna
- Cortex M33 MCU 1MB flash, 256 KB RAM

### LN60G40X

- nRF9160 SICA SIP module supporting LTE-M and NB-IoT at +23 dBm TX
- U.FL connector for an external LTE antenna
- GPS receiver with an integrated antenna.
- Cortex M33 MCU 1MB flash, 256 KB RAM
- nRF5340 BLE 5.2 module, BT40X with PA, an integrated PCB trace antenna, an u.FL for external antenna.
- Dual code Cortex M33, application core up to 128 MHz.

### LN60E40F

- nRF9160 SICA SIP module supporting LTE-M and NB-IoT at +23 dBm TX
- U.FL connector for an external LTE antenna
- GPS receiver with an u.FL connector for an external antenna.
- Cortex M33 MCU 1MB flash, 256 KB RAM
- nRF5340 BLE 5.2 module, BT40F with an integrated antenna.
- Dual code Cortex M33, application core up to 128 MHz.

### LN60E840E

- nRF9160 SICA SIP module supporting LTE-M and NB-IoT at +23 dBm TX
- U.FL connector for an external LTE antenna
- GPS receiver with integrated amplifier and antenna
- Cortex M33 MCU 1MB flash, 256 KB RAM
- BT840E with u.FL for an external antenna.
- Bluetooth range with ANT060, 6 dBi antenna, is measured >3400 meters at 125 Kbps.

### LN60G840F

- nRF9160 SICA SIP module supporting LTE-M and NB-IoT at +23 dBm TX
- U.FL connector for an external LTE antenna
- GPS receiver with integrated amplifier and antenna
- Cortex M33 MCU 1MB flash, 256 KB RAM

## LTE-BLE 5.2, 802.15.4 Modules, M.2 Connector

Ver 1.00 Aug. 2021

- BT840F with Integrated PCB trace antenna.
- Bluetooth range is measured 2300 meters

### LN60G840XE

- nRF9160 SICA SIP module supporting LTE-M and NB-IoT at +23 dBm TX
- U.FL connector for an external LTE antenna
- GPS receiver with an integrated antenna
- Cortex M33 MCU 1MB flash, 256 KB RAM
- BT840XE with an u.FL for external antenna.
- Bluetooth range is measured >4500 meters or 2.8 miles at 125 Kbp.

### Available LN60G Series Modules

The following table is a list of available LN Series modules.

LN Module	LTE module	GPS antenna	BLE module	Description
LN60G	nRF9160 SICA	Integrated	None	nRF9160 LTE module with an integrated GPS antenna.
LN60E	nRF9160 SICA	u.FL	None	nRF9160 LTE module with an u.fl for an external GPS antenna.
LN60G840F	nRF9160 SICA	Integrated	BT840F	nRF9160-BT840F, LTE-BLE module, integrated BLE antenna. GPS
LN60G840E	nRF9160 SICA	Integrated	BT840E	nRF9160-BT840E, LTE-BLE module, u.FL for external BLE antenna. GPS
LN60G840X	nRF9160 SICA	Integrated	BT840X	nRF9160-BT840X, LTE-BLE+PA module, integrated BLE antenna. GPS
LN60G840XE	nRF9160 SICA	Integrated	BT840XE	nRF9160-BT840XE, LTE-BLE+PA module, u.FL for ext. BLE antenna. GPS
LN60E840F	nRF9160 SICA	u.FL	BT840F	nRF9160-BT840F, LTE-BLE module, integrated BLE antenna.
LN60E840E	nRF9160 SICA	u.FL	BT840E	nRF9160-BT840E, LTE-BLE module, u.FL for external BLE antenna.
LN60E840X	nRF9160 SICA	u.FL	BT840X	nRF9160-BT840X, LTE-BLE+PA module, integrated BLE antenna.
LN60E840XE	nRF9160 SICA	u.FL	BT840XE	nRF9160-BT840XE, LTE-BLE+PA module, u.FL for external BLE antenna.
LN60G40F	nRF9160 SICA	Integrated	BT40F	nRF9160-BT40F, LTE-BLE module, integrated BLE antenna. GPS
LN60G40E	nRF9160 SICA	Integrated	BT40E	nRF9160-BT40E, LTE-BLE module, u.FL for external BLE antenna. GPS
LN60E40F	nRF9160 SICA	u.FL	BT40F	nRF9160-BT40F, LTE-BLE module, integrated BLE antenna.
LN60E40E	nRF9160 SICA	u.FL	BT40E	nRF9160-BT40E, LTE-BLE module, u.FL for external BLE antenna.
LN60G40X	nRF9160 SICA	Integrated	BT40X	nRF9160-BT40X, LTE-BLE module, BLE + PA +uFL+ PCB antenna. GPS.
LN60E40X	nRF9160 SICA	u.FL	BT40X	nRF9160-BT40X, LTE-BLE module, BLE + PA +uFL+ PCB antenna.


## 2. Product Descriptions

### nRF9160 Specifications

nRF9160 SIP module Product Specifications can be downloaded from.

[https://infocenter.nordicsemi.com/index.jsp?topic=%2Fug\\_nrf91\\_dk%2FUG%2Fnr91\\_DK%2Fintro.html&cp=2\\_0\\_2](https://infocenter.nordicsemi.com/index.jsp?topic=%2Fug_nrf91_dk%2FUG%2Fnr91_DK%2Fintro.html&cp=2_0_2)

Block diagram of nRF9160 is shown below.




## BT840F

BT840F is a long range nRF52840 module. Product Specifications of nRF52840 can be downloaded from.

[https://infocenter.nordicsemi.com/index.jsp?topic=%2Fug\\_nrf91\\_dk%2FUG%2Fnr91\\_DK%2Fintro.html&cp=2\\_0\\_2](https://infocenter.nordicsemi.com/index.jsp?topic=%2Fug_nrf91_dk%2FUG%2Fnr91_DK%2Fintro.html&cp=2_0_2)

The following is a block diagram of Nordic nRF52840 Bluetooth Low Energy (BLE) SoC. Arrows with white heads indicate signals that share physical pins with other signals.




BT840F data sheets can be downloaded from:

<https://www.fanstel.com/download-document>

## BT840XE

A Skyworks power amplifier SKY66112 is integrated with nRF52840 in BT840XE. A block diagram is shown below. nRf52840 codes to control SKY66112 are included in this data sheets. They can be downloaded from Fanstel webpage.

<https://www.fanstel.com/download-document>




Frequency Band from 2402 MHz to 2480 MHz.

# LTE-BLE 5.2, 802.15.4 Modules, M.2 Connector

Ver 1.00 Aug. 2021

## Mechanical Drawings



Size of LN60E840F is 30x42mm.



# LTE-BLE 5.2, 802.15.4 Modules, M.2 Connector

Ver 1.00 Aug. 2021

The following is detailed drawing of the M.2 connector.



unit: mm






# LTE-BLE 5.2, 802.15.4 Modules, M.2 Connector

Ver 1.00 Aug. 2021

Pin assignments with nRF52840 module.



## Pin Function

M.2	9160	BT840F	BT840F/9160	BT40F	BT40F/9160	
pin#	pin#	pin#	Name	pin#	Name	Descriptions
1					5V IN	DC input for 3.3V regulator; 3.2V to 15V. 4.35V minimum if connected to USB-VBUS externally.
2		F4	BLE-VDDH	F4	BLE-VDDH	High voltage input for nRF52840/nRF5340, 2.5V to 5.5V
3					5V IN	DC input for 3.3V regulator; 3.2V to 15V. 4.35V minimum if connected to USB-VBUS externally.
4		9	VDD-3V3	9	VDD-3V3	Regulated 3.3V DC input, 800 mA minimum
5		F6	USB-VBUS	F6	USB-VBUS	USB power supply, 4.35V to 5.5V.
6		9	VDD-3V3	9	VDD-3V3	Regulated 3.3V DC input, 800 mA minimum
7		E4	USB DP	E4	USB DP	USB data pin
8		15	BLE-SWDCLK	15	BLE-SWDCLK	Serial Wire Debug clock input for BLE
9		E5	USB DN	E5	USB DN	USB data pin
10		16	BLE-SWDIO	16	BLE-SWDIO	Serial Wire Debug data for BLE
11		10	GND	10	GND	Ground
12						
13						
14						
15						
16						
17						
18						
19						
20			GND		GND	Ground
21		11	P011	11	P009	BLE GPIO
22			GND		GND	Ground
23		12	P100	12	P011	BLE GPIO
24		13	P013	13	P030	BLE GPIO
25		E6	P012	E6	P010	BLE GPIO
26		D5	P101	D5	P022	BLE_UART RXD
27		E3	P109	E3	P107	BLE GPIO
28		14	P018/RESET	14	RESET	Reset for BT40F, Reset or P018 for BT840F
29		E2	P021	E2	P106	BLE GPIO
30		D4	P014	D4	P029	BLE GPIO
31		D1	P023	D1	P026	BLE GPIO
32		D3	P016	D3	P028	BLE-OTA
33		C1	P024	C1	P031	BLE GPIO

# LTE-BLE 5.2, 802.15.4 Modules, M.2 Connector

Ver 1.00 Aug. 2021

34		D2	P019	D2	P027	BLE GPIO
35		C5	P102	C5	P020	BLE_UART-TXD
36		C4	P015	C4	P023	BLE GPIO
37		C2	P022	C2	P021	BLE GPIO
38		C3	P017	C3	P024	BLE GPIO
39		B5	P008	B5	P012	BLE GPIO
40		E1	P020	E1	P105	BLE GPIO
41		B4	P006	B4	P015	BLE GPIO
42		B3	P031	B3	P014	BLE GPIO
43		A6	P108	A6	P108	BLE GPIO
44		B2	P030	B2	P017	BLE GPIO
45		A5	P007	A5	P100	BLE GPIO
46		B1	P025	B1	P019	BLE GPIO
47		A4	P005	A4	P016	BLE GPIO
48	24		P0.14		P0.14	LTE_UART_APP2-RTS
49		A3	P004	A3	P008	BLE GPIO
50	25		P0.15		P0.15	LTE_UART_APP2-CTS
51		A2	P029	A2	P007	BLE GPIO
52	32		LTE-RESET		LTE-RESET	LTE reset, Active low
53		A1	P028	P006	P006	BLE GPIO
54	33		LTE-SWDCLK		LTE-SWDCLK	LTE-Single Wire Debug clock input
55		1	P026	1	P102	BLE_I2C, SDA
56	34		LTE-SWDIO		LTE-SWDIO	LTE-Single Wire Debug data
57		2	P027	2	P103	BLE_I2C, SCL
58	43		SIM-RESET		SIM-RESET	LTE_SIM reset
59		8	P010	8	P003	BLE_GPIO, NFC2
60	45		SIM-DET		SIM-DET	LTE_SIM detect
61		7	P009	7	P002	BLE_GPIO, NFC1
62	46		SIM-CLK		SIM-CLK	LTE_SIM clock
63		6	P003	6	P005	BLE_GPIO, AIN1
64	48		SIM-IO		SIM-IO	LTE_SIM data
65		5	P002	5	P004	BLE_GPIO, AIN 0
66	47		SIM-1V8		SIM-1V8	LTE_SIM 1.8V power supply
67	95		P0.00		P0.00	LTE_UART_APP2-RXD
68	83		P0.26		P0.26	LTE_UART_APP1-CTS
69	96		P0.01		P0.01	LTE_UART_APP2_TXD
70	84		P0.27		P0.27	LTE_UART_APP1-RTS

## LTE-BLE 5.2, 802.15.4 Modules, M.2 Connector

Ver 1.00 Aug. 2021

71	97		P0.02		P0.02	LTE-GPIO
72	86		P0.28		P0.28	LTE_UART_APP1-RXD
73	99		P0.03		P0.03	LTE-GPIO
74	87		P0.29		P0.29	LTE_UART_APP1-TXD
75	3		P0.06		P0.06	LTE-OTA

### 3. Codes Development Using Nordic Tools

Development tools by Nordic and other third party development tools recommended by Nordic should be used.

Nordic development environment for nRF52840 offers a clean separation between application code development and embedded protocol stacks. This means compile, link and run time dependencies with the embedded stack and associated debugging challenges are removed. The Bluetooth low energy and ANT stack is a pre-compiled binary, leaving application code to be compiled stand-alone. The embedded stack interface uses an asynchronous and event driven model removing the need for RTOS frameworks.

#### Over-The-Air DFU

The nRF52840 is supported by an Over-The-Air Device Firmware Upgrade (OTA DFU) feature. This allows for in the field updates of application software and SoftDevice.

#### SoftDevices

The Nordic protocol stacks are known as SoftDevices and complement the nRF52 Series SoCs. All nRF52 Series are programmable with software stacks from Nordic. This bring maximum flexibility to application development and allows the latest stack version to be programmed into the SoC.

SoftDevices available from Nordic:

**S140:** Bluetooth low energy concurrent central/peripheral/observer/broadcaster stack.

#### Development Tools

Nordic Semiconductor provides a complete range of hardware and software development tools for the nRF52 Series devices. nRF52 DK board is recommended for firmware development.

Nordic software development tools can be downloaded from the following webpage.

[http://infocenter.nordicsemi.com/index.jsp?topic=/com.nordic.infocenter.nrf52/dita/nrf52/development/nrf52\\_dev\\_kit.html&cp=1\\_1](http://infocenter.nordicsemi.com/index.jsp?topic=/com.nordic.infocenter.nrf52/dita/nrf52/development/nrf52_dev_kit.html&cp=1_1)

### Control nRF21540 in BT40X

To be provided.

### Control Skyworks Power Amplifier in BT840X

BT840X in LN60E840X uses SKYWORKS SKY66112-11 power amplifier.

A firmware example to control Skyworks SKY66112 power amplifier is below. This firmware file can be downloaded from <http://www.fanstel.com/download-document/>.

Settings for BT840F and BT840E:

- nRF52840 SoC TX power is set to +8dBm for FCC, ISED, CE, RCM, and TELEC certification testings.
- BT840E passes FCC and ISED certification testings with ANT060, a 6 dBi antenna.
- BT840E passes CE, RCM, and TELEC certification testings with ANT000 antenna.
- VDD is set to 3.3V with DCDC converter enabled.

Settings for BT840X and BT840XE:

- nRF52840 SoC TX is set to +2dBm for FCC and ISED testings.
- nRF52840 SoC TX is set to -4 dBm for CE and RCM testings.
- BT840XE passes FCC, ISED, CE, and RCM certification testings with ANT000, a 0dBi antenna.
- VDD is set to 3.3V.


Please refer to BT840F Product Specifications for firmware to control SKY66112 power amplifier in BT840X and BT840XE.

## 4. Application Examples

### BLG840F, BLE to LTE Gateway

In this basic BLE 5/802.15.4 to LTE-NB-IoT gateway design:

- The bold, gray rectangular box is the boundary of M.2 connector, B Key.
- Most of free GPIOs on M.2 connector are from BLE module.
- nRF9160 is connected to BT840F/BT40F through host board using UART.
- Optional flash memory can be installed for BLE module without SKY66112 power amplifier. QSPI pins are used for PA control inside BT840X/XE.
- Nano SIM connector is on the LN module. eSIM interface is available on M.2 connector to install eSIM on host board.
- The M.2 module in the following block diagram is an LN60G840F.




# LTE-BLE 5.2, 802.15.4 Modules, M.2 Connector

Ver 1.00 Aug. 2021

## LEW840X, BLE-LoRa to LTE, WiFi, PoE Ethernet Gateway

This application example supports multiple network interfaces and multiple protocols.

- PoE Ethernet and 802.11 b/g/n WiFi circuitry is on gateway host board.
- An LN60G, LN module for LTE/NB-IoT network expansion
- An M262X840XE, M2 module to support Bluetooth, Thread, Zigbee, LoRa device interfaces.
- Data from sensors and other devices can be processed in the host board MCU (ESP32) before sending to cloud server.



## 5. Establishing Cloud Connection and Programming

### PK-BLG840F, the LTE Monitor Board

PK-BLG840F can be used:


- to interface with the BLE module or the LTE module on LN60G Series M.2 modules or BLG840F Series gateways.
- To monitor UART data traffic to the LTE module or the BLE module.

It contains:

- an UART to USB bridge board, called **LTE Monitor** board,
- a 10-pin flat cable,
- and an USB cable.

There are three 12-pins square connectors on the **LTE Monitor** board.


- JS5-BLE for connection to the BLE module on LN60G840F module or in BLG840F gateway.
- JS6-LTE for connection to the LTE module on LN60G840F module or in BLG840F gateway.
- JS7-RXD for monitor UART data to the receiver of the BLE or the LTE module. It can be selected by the SW3 switch on the back side.



## EV-LN60G

An evaluation board consists of the followings:

- Micro USB cable
- Evaluation board
- 10-conductor cable for connection to Nordic nRF52840 DK (DK is not included)
- A screw for locking the M.2 module on the EV board.



An EV-LN60G can be used to evaluate any Fanstel M.2 module.

- An M.2 module is **not** included.
- An LN module (for example, an LN60G840F) has a nano SIM card connector. A nano SIM card is **not** included.

The following photo is for an LN60G840F module installed on the EV-LN60G.



## EV-LN60G840F

After installing LN60G840F module into EV-LN60G evaluation board, it is called EV-LN60G840F. The LN60G840F module is pre-loaded Nordic modem mfw\_nrf9160\_1.2.3 and MQTT application.

MQTT tool or MQTT APP<->MQTT broker <-> LN60E40F <->BLE Sensor

The default application is for NB IoT. If you need to run CAT M. Please download the HEX file from Fanstel website.

The LN60G840F preloaded firmware will send the temperature and humidity preset data to Fanstel MQTT server. One can use Fanstel MQTT PC tool or mobile APP to monitor data.

## Download and set up Basic Software tools for LN60E40F.

nRF command line tool 10.2.1 or newer.

<https://www.nordicsemi.com/Software-and-Tools/Development-Tools/nRF-Command-Line-Tools/Download>

nRF Connect desktop 3.2.0 or newer.

<https://www.nordicsemi.com/Software-and-Tools/Development-Tools/nRF-Connect-for-desktop>

Fanstel MQTT PC tool to test default firmware.

[https://www.dropbox.com/s/27xzy1kytb8t918/MQTT\\_PC\\_Tool190916.rar?dl=0](https://www.dropbox.com/s/27xzy1kytb8t918/MQTT_PC_Tool190916.rar?dl=0)

Fanstel LTE PC tool to test default firmware.


[https://www.dropbox.com/s/beyhbh78lowlzal/LTE\\_PC\\_Tool190718.rar?dl=0](https://www.dropbox.com/s/beyhbh78lowlzal/LTE_PC_Tool190718.rar?dl=0)

## Establishing an LTE Connection to a Cloud Server

The following example establishes a connection between nRF9160 on LN60G840F and Fanstel development server. You will enter artificial temperature and humidity data for uploading to the Fanstel MQTT server.

Programming the nRF9160 only HEX code.

- Connect the external antenna.
- Connect the small JS7 board to JS-LTE connector.
- Connect the micro USB port to a PC with an USB cable.



## LTE-BLE 5.2, 802.15.4 Modules, M.2 Connector

Ver 1.00 Aug. 2021

- Open Fanstel LTE monitor and MQTT listener PC tools.
- Select the COM port.
- Reset the BLG840F, the log appears.
- Configure Publish ID and artificial temperature.


The screenshot shows the 'LTE MQTT' application window. At the top left, the title bar reads 'LTE AT tool190611'. The main interface has a blue header with the text 'LTE MQTT' and a green circular arrow icon on the right. Below the header are two blue buttons: 'Disconnect' and 'Clr Log'. The configuration section includes a 'Server' dropdown menu set to 'Fanstel', a 'Publish ID' text box containing '000123', and a note below it: 'Setup 6 Bytes ID then reset the EVB'. To the right, there are two data input fields: 'temperature' set to '23' (with '2 Bytes' below it) and 'humidity' set to '65' (with '2 Bytes' below it). A 'Data updated' label is centered below the configuration. At the bottom, a scrollable log window displays the following text:

```
H-< ***** Booting Zephyr OS v1.14.99-ncs2 *****\r\nH-< The Fanstel MQTT 190904 \r\nH-< UART enabled\r\nH-< Waitting for MQTT ID!\r\nH-< LTE Link Connecting ... \r\n\r\nH-> SetID=000123\r\n\r\nH-> RawData=023,065\r\n
```

When nRF9160 module is connected to the MQTT server, you will see the temperature and humidity data uploaded.

```
H<- IPv4 Address found 59.124.228.194\r\nH<- Got MQTT ID\r\nH<- Got MQTT ID=000123\r\nH<- AT+MQTT=1\r\nH<- Subscribing to: /my/9160_sub len 12\r\nH<- Publishing: Temp:023,Humi:065,ID:001\r\nH<- to topic: esp32_000123/Odemo len: 18\r\nH<- [mqtt_evt_handler:267] SUBACK packet id: 1234\r\nH<- Publishing: Temp:023,Humi:065,ID:002\r\nH<- to topic: esp32_000123/Odemo len: 18\r\n
```


- Open the MQTT PC tool and enter the same Publish ID you just setup.
- Press start icon.
- The data from nRF9160 is displayed.



## Relaying Sensor Data to a Cloud Server

This application example relays temperature and humidity sensor data from Fanstel sensors through a LTE connection to Fanstel loader server.

- Programming mqtt9160NB\_210115.HEX code.
- Remove the small JS7 board.
- Insert the JS7 connector of the **LTE Monitor** board (the USB to UART bridge board included in PK-BLG840F) to JS-LTE connector of EV-LN60G board.
- Use SW3 on the **LTE Monitor** board to select monitoring the UART data to the BLE or to the LTE receiver.
- Check both nRF9160 and nRF52840 UART logs, running normally.



You can use this set up to monitor traffic at the UART interface when developing your own code.

After checking the log, insert the small JS7 board back to JS-LTE.




## Using Android OS


Download and install nRF Connect mobile App.

<https://play.google.com/store/apps/details?id=no.nordicsemi.android.mcp&hl=zh-TW>

Open the nRF Connect mobile App when a Fanstel sensor is powered up nearby. The sensor is advertising the 6 bytes ID.




Enter the sensor ID into Fanstel MQTT tool. The real sensor data are displayed on the tool.



**Programming the nRF9160.**

- Connected PCA10090 debug out to EVLN60G840F JS2-9160




- Open the command line and go to the folder where the HEX file located.
- Execute the programming command  
"nrfjprog --program mqtt9160NB\_190904.hex --chiperase -f nrf91 --reset"

```
C:\Users\Administrator\Desktop\Nordic Firmware\LTE9160_MQTT190904>nrfjprog --pro  
gram mqtt9160NB_190904.hex --chiperase -f nrf91 --reset  
Parsing hex file.  
Erasing user available code and UICR flash areas.  
Applying system reset.  
Checking that the area to write is not protected.  
Programming device.  
Applying system reset.  
Run.
```


# LTE-BLE 5.2, 802.15.4 Modules, M.2 Connector

Ver 1.00 Aug. 2021


Note: The voltage supported by external debugging/programming is the VDD voltage. This voltage can be selected to 1.8 V or 3 V using slide switch SW11. Make sure the voltage level of the external board matches the VDD of the nRF9160 DK. Please select 3V if programming the BLG840F gateway.



Programming the nRF9160 with nRF Connect for desktop.  
Upgrade modem.




## Upgrade application



Programming the BT840F HEX code.


- Connected PCA10090 debug out to EV-LN60G840F JS4-BLE.
- Set SW10 slide switch of the PCA10090 to nRF52.
- Set SW9 slide switch of the PCA10090 to 3V.



# LTE-BLE 5.2, 802.15.4 Modules, M.2 Connector

Ver 1.00 Aug. 2021


Open nRF connect\programmer and load the HEX code.  
Execute Erase & Write.  
The log will show write success.



## EV-LN60G EvaluationBoard Schematics

Evaluation board schematics and Gerber files can be downloaded from

<http://www.fanstel.com/download-document/>




File	<b>FANSTEL Corporation.</b>		
Doc Number	<b>BN60E840 Module EVM</b>		
Rev	Document Number	rRF0160 - BLE	Rev 1.0
Date	Drawn by	Julio.B. 2020	Sheet 1 of 2

# LTE-BLE 5.2, 802.15.4 Modules, M.2 Connector

Ver 1.00 Aug. 2021

Page 2 of EV-LN60G schematics. EV board schematics can be used as a reference design for using modules.



<b>FANSTEL Corporation.</b>			
Title	<b>BN60EB40 Module EVM</b>		
Size	Document Number	CP2102	Rev
B			1.2
Date:	Thursday, July 08, 2020	Sheet:	2 of 2

### Packaging and Lot Number

LN60G840F Series module is individual packed.

### FCC LABEL

The Original Equipment Manufacturer (OEM) must ensure that the OEM modular transmitter must be labeled with its own FCC ID number. This includes a clearly visible label on the outside of the final product enclosure that displays the contents shown below. If the FCC ID is not visible when the equipment is installed inside another device, then the outside of the device into which the equipment is installed must also display a label referring to the enclosed equipment

The end product with this module may subject to perform FCC part 15 unintentional emission test requirement and be properly authorized.

This device is intended for OEM integrator only.

### Revision History

- Aug. 2020, Ver. 0.60: Initial draft release
- Sep. 2020, Ver. 0.61: Draft update
- Jan. 2021, Ver.0.90: Draft revision
- April 2021, Ver. 0.91: Draft revision
- Aug. 2021, Ver. 1.00: Initial release.

## Contact Us

### United States:

Fanstel Corp.

7466 E. Monte Cristo Ave. Scottsdale AZ 85260

Tel. 1 480-948-4928

Fax. 1-480-948-5459

Email: [info@fanstel.com](mailto:info@fanstel.com)

Website: [www.fanstel.com](http://www.fanstel.com)

### Taiwan:

Fanstel Corp.

10F-10, 79 Xintai Wu Road

Xizhu, New Taipei City, Taiwan 22101

泛世公司

臺灣省新北市汐止區新臺五路79號10樓之10, 22101

Tel. 886-2-2698-9328

Fax. 886-2-2698-4813

Email: [info@fanstel.com](mailto:info@fanstel.com)

Website: [www.fanstel.com](http://www.fanstel.com)

### China:

Fanstel Technologies Corp.

11 Jiale Street

Ping-Dih, Long-Gang, Shen Zhen, GD 518117

泛世康科技(深圳)有限公司

廣東省深圳市龍崗區坪地鎮佳樂街11號

Tel. 86-755-8409-0928

Fax. 86-755-8409-0973

QQ. 3076221086

Email: [info@fanstel.com](mailto:info@fanstel.com)

Website: [www.fanstel.com](http://www.fanstel.com)