



EV2696B-Q-00A

Single-Cell Switch-Mode Charger with Power-Path Management Evaluation Board

DESCRIPTION

The EV2696B-Q-00A is an evaluation board designed to demonstrate the capabilities of the MP2696B, a highly integrated, flexible, single-cell switch-mode battery charger system with power path management.

The MP2696B has three operation modes: charge mode, boost mode, and sleep mode.

In charge mode, the MP2696B can achieve up to 3.6A of charge current with a 5V input source.

In boost mode, the MP2696B can achieve up to 6.5A of peak inductor current to deliver a 5V system power output (SYS).

The MP2696B's parameters and controls can be easily configured via the I²C interface.

ELECTRICAL SPECIFICATIONS

| Parameter | Symbol | Value | Units |
|--|------------------------|----------|-------|
| Input voltage | V _{IN} | 4 to 11 | V |
| Input current limit ⁽¹⁾ | I _{IN_LIMIT} | 0.5 | A |
| Charge regulation voltage ⁽¹⁾ | V _{BATT_REG} | 4.2 | V |
| Charge current ⁽¹⁾ | I _{CC} | 1 | A |
| Output voltage ⁽¹⁾ | V _{SYS} | 5.15 | V |
| Output current limit ⁽¹⁾ | I _{OUT_LIMIT} | 3 | A |
| Output power | P _{OUT} | Up to 20 | W |

Note:

1) Configurable via the I²C interface.

FEATURES

- 4V to 11V Operating Input Range
- Up to 16V Sustainable Input Voltage
- 500mA to 3.5A Configurable Input Current Limit
- 500mA to 3.6A Configurable Charge Current
- 3.6V to 4.45V Configurable Charge Regulation Voltage
- Minimum Input Voltage Loop for Maximum Adapter Power Tracking
- Boost Converter with Up to 4A Output Current:
 - Configurable Output Current Limit Loop
 - Configurable Boost Output Voltage
 - USB Output Cable Compensation
 - Configurable Peak Inductor Current
- Comprehensive Safety Features
 - Fully Customizable JEITA Profile
 - Charge Safety Timer
 - Input Over-Voltage Protection (OVP)
 - Thermal Shutdown
 - System Power Output (SYS) Over-Current Protection (OCP) and Short-Circuit Protection (SCP)
- Analog Voltage Output IB Pin for Battery Current Monitoring
- SYS Plug-In Detection
- SYS No-Load Detection
- SYS DP/DM Interface for BC1.2 and Non-Standard Adapters
- Status Monitoring and Fault Monitoring

APPLICATIONS

- Sub-Battery Applications
- Power Bank Applications

All MPS parts are lead-free, halogen-free, and adhere to the RoHS directive. For MPS green status, please visit the MPS website under Quality Assurance. "MPS", the MPS logo, and "Simple, Easy Solutions" are trademarks of Monolithic Power Systems, Inc. or its subsidiaries.

EV2696B-Q-00A EVALUATION BOARD



LxWxH (6.35cmx6.35cmx1.2cm)

| Board Number | MPS IC Number |
|---------------|----------------|
| EV2696B-Q-00A | MP2696BGQ-0000 |

QUICK START GUIDE

1. Install the USB I²C communication interface driver on the computer.
2. Connect the I²C communication interface to the SCL/GND/SDA communication lines on the evaluation board.
3. Connect the battery terminals to:
 - a. Positive (+): TP1/BATT
 - b. Negative (-): TP2/GND
4. If using a battery simulator, preset the battery simulator to 3.8V/5A, then turn the battery simulator off. Then connect the battery simulator terminals to:
 - a. Positive (+): TP1/BATT
 - b. Negative (-): TP2/GND
5. After making the connections to the battery simulator, turn the battery simulator output on.
6. Connect the input terminals to:
 - a. Positive (+): TP3/VIN
 - b. Negative (-): TP4/GND
7. Ensure that the USB I²C communication interface has connected the MP2696B to the computer. There should not be any warnings shown at the bottom of the GUI software screen. ⁽²⁾
8. Configure the charge and boost parameters via the GUI I²C interface. ⁽²⁾

Note:

- 2) The GUI software can be downloaded from the MPS website.

CONNECTIONS

Table 1: Connectors

| Connectors | Description |
|----------------------------|--|
| TP1/BATT | Connect TP1/BATT to the positive battery pack terminal. |
| TP2/GND | Connect TP2/GND to the negative battery pack terminal. |
| TP3/VIN | Connect TP3/VIN to the positive input source terminal. |
| TP4/GND | Connect TP4/GND to the negative input source terminal. |
| TP5/SYS | Power bank positive output terminal. |
| TP6/GND | Power bank negative output terminal. |
| P1/USB Type-A power output | Power bank USB output receptacle. |
| P2/micro-USB power input | Connect P2/micro-USB power input to the input power adapter. |
| SCL/SDA/GND/INT | I ² C connector. |
| NTC | Connect NTC to the external thermistor. |

Table 2: Jumpers and Shunts

| Jumpers | Description | Default |
|---------|---|---------|
| JP1 | Connect the on-board NTC divider. | Install |
| JP2 | Connect the 10kΩ pull-up resistors from SCL/SDA/INT to VCC. | Install |

EVALUATION BOARD SCHEMATIC




Figure 1: Evaluation Board Schematic

EV2696B-Q-00A BILL OF MATERIALS

| Qty | Ref | Value | Description | Package | Manufacturer | Manufacturer PN |
|-----|--------------------------------|---------------|--|------------------|--------------|--------------------|
| 2 | C1, C2 | 10 μ F | Capacitor, 16V, X5R | 0805 | Murata | GRM21BR61C106KE15L |
| 1 | C3 | 10 μ F | Capacitor, 16V, X5R | 1206 | Murata | GRM319R60J106KE19 |
| 3 | C4, C5, C6 | NC | Capacitor, 16V, X5R | 0805 | Murata | GRM21BR61C106KE15L |
| 1 | C7 | 1 μ F | Capacitor, 16V, X5R | 0805 | Murata | GRM21BR71C105KA01 |
| 1 | C8 | 22 μ F | Capacitor, 10V, X7S | 0805 | TDK | C2012X7S1A226M |
| 1 | C9 | 2.2 μ F | Ceramic capacitor, 10V, X5R | 0603 | Murata | GRM188R71A225KE15D |
| 1 | C10 | 470nF | Ceramic capacitor, 25V, X7R | 0603 | TDK | C1608X7R1E474K |
| 1 | C11 | 1 μ F | Ceramic capacitor, 10V, X7R | 0603 | Lion | 0603B105K100T |
| 6 | TP1, TP2, TP3, TP4, TP5, TP6 | 2mm | Connector | DIP | Any | |
| 6 | TP7, TP8 TP9, TP10, TP11, TP12 | | Test point | DIP | Any | |
| 5 | GND, INT, NTC, SCL, SDA | 2.54mm | Connector | DIP | Any | |
| 2 | JP1, JP2 | | Jumper | DIP | Any | |
| 4 | TP13, TP14, TP15, TP16 | | Connector, GND | SMT | Any | |
| 1 | L1 | 1 μ H | Inductor, 1 μ H, 6.8A | SMD | Würth | 744777001 |
| 1 | L2 | 3A | Magnetic bead | 0805 | Würth | 742792063 |
| 1 | P1 | | USB Type-A | DIP | Any | |
| 1 | P2 | | Micro-USB | DIP | Any | |
| 1 | R1 | NC | Film resistor | NC | NC | NC |
| 1 | R2 | 0 | Film resistor, 5% | 0603 | Yageo | RC0603JR-070RL |
| 1 | R3 | 100k Ω | Film resistor 5% | 0603 | Yageo | RC0603JR-07100KL |
| 2 | R4, R5 | 10k Ω | Film resistor 1% | 0603 | Yageo | RC0603FR-0710KL |
| 1 | RS1 | 10m Ω | Film resistor, 1%, 1/4W | 1206 | Yageo | RL1206FR-070R01L |
| 1 | U1 | MP2696B | Single-cell SW charger with power path management and boost output | QFN-21 (3mmx3mm) | MPS | MP2696BGQ-0000 |

PCB LAYOUT




Figure 2: Top Layer




Figure 3: Mid-Layer 1




Figure 4: Mid-Layer 2




Figure 5: Bottom Layer

REVISION HISTORY

| Revision # | Revision Date | Description | Pages Updated |
|------------|---------------|-----------------|---------------|
| 1.0 | 3/29/2021 | Initial Release | - |

Notice: The information in this document is subject to change without notice. Please contact MPS for current specifications. Users should warrant and guarantee that third-party Intellectual Property rights are not infringed upon when integrating MPS products into any application. MPS will not assume any legal responsibility for any said applications.