

Using the UCD3138HSFBEVM-029

User's Guide



Literature Number: SLUUA95A
April 2013–Revised September 2019



WARNING

Always follow TI's set-up and application instructions, including use of all interface components within their recommended electrical rated voltage and power limits. Always use electrical safety precautions to help ensure your personal safety and the safety of those working around you. Contact TI's Product Information Center <http://support.ti.com> for further information.

Save all warnings and instructions for future reference.

Failure to follow warnings and instructions may result in personal injury, property damage, or death due to electrical shock and/or burn hazards.

The term TI HV EVM refers to an electronic device typically provided as an open framed, unenclosed printed circuit board assembly. It is intended strictly for use in development laboratory environments, solely for qualified professional users having training, expertise, and knowledge of electrical safety risks in development and application of high-voltage electrical circuits. Any other use and/or application are strictly prohibited by Texas Instruments. If you are not suitably qualified, you should immediately stop from further use of the HV EVM.

1. Work Area Safety:

1. Keep work area clean and orderly.
2. Qualified observer(s) must be present anytime circuits are energized.
3. Effective barriers and signage must be present in the area where the TI HV EVM and its interface electronics are energized, indicating operation of accessible high voltages may be

present, for the purpose of protecting inadvertent access.

4. All interface circuits, power supplies, evaluation modules, instruments, meters, scopes and other related apparatus used in a development environment exceeding 50 V_{RMS}/75 VDC must be electrically located within a protected Emergency Power Off (EPO) protected power strip.
 5. Use a stable and non-conductive work surface.
 6. Use adequately insulated clamps and wires to attach measurement probes and instruments. No freehand testing whenever possible.
- ### 2. Electrical Safety:
1. De-energize the TI HV EVM and all its inputs, outputs, and electrical loads before performing any electrical or other diagnostic measurements. Revalidate that TI HV EVM power has been safely de-energized.
 2. With the EVM confirmed de-energized, proceed with required electrical circuit configurations, wiring, measurement equipment hook-ups and other application needs, while still assuming the EVM circuit and measuring instruments are electrically live.
 3. Once EVM readiness is complete, energize the EVM as intended.

WARNING: while the EVM is energized, never touch the EVM or its electrical circuits as they could be at high voltages capable of causing electrical shock hazard.

3. Personal Safety:

1. Wear personal protective equipment e.g. latex gloves and/or safety glasses with side shields or protect EVM in an adequate lucent plastic box with interlocks from accidental touch.

4. Limitation for Safe Use:

1. EVMs are not to be used as all or part of a production unit.

Digitally Controlled Hard-Switching Full-Bridge DC-DC Converter

1 Introduction

This EVM, UCD3138HSFBEVM-029 is to help evaluate the UCD3138RHA 40-pin digital control device in a 48-V telecom power conversion application and then to aid in UCD3138 design. The EVM is a standalone symmetrical Hard-Switching Full-Bridge (HSFB) DC-DC power converter.

The UCD3138HSFBEVM-029 can be used as it is delivered without additional work, from either hardware or firmware, to evaluate a hard-switching symmetrical full-bridge DC-DC converter. This EVM allows for some of its design parameters to be re-tuned using a GUI based tool, called [Texas Instruments Fusion Digital Power Designer](#). It is also possible to load custom firmware with user's own definition and development.

This user's guide provides basic evaluation instruction from a viewpoint of system operation in a standalone symmetrical HSFB DC-DC power converter.

WARNING

High voltages are present on this evaluation module during operation and for a while even after power off. This module should only be tested by skilled personnel in a controlled laboratory environment.

High temperature exceeding 60°C may be found during EVM operation and for a while even after power off.

This EVM's purpose is to facilitate the evaluation of digital control in a hard-switching full-bridge DC converter using the UCD3138, and cannot be tested and treated as a final product.

Read and understand this user's guide thoroughly before starting any physical evaluation.

2 Description

The UCD3138HSFBEM-029 demonstrates a symmetrical hard-switching full-bridge DC-DC power converter with digital control using the UCD3138RHA 40-pin device. This EVM includes preloaded firmware providing required control functions for an HSFB converter. For details of the firmware please contact TI. UCD3138HSFBEM-029 accepts a DC input from 36 V_{DC} to 72 V_{DC}, and outputs a nominal 12 V_{DC} with full output load power 360 W, or full output current 30 A.

2.1 Typical Applications

- 48-V Telecom DC-DC Power Conversion
- Servers
- Telecommunication Systems

2.2 Features

- Digitally Controlled and Standalone Hard Switching Full-Bridge DC-DC Power Conversion
- Voltage Mode Control
- Secondary Side Control
- DC Input from 36 V_{DC} to 72 V_{DC}
- 12 V_{DC} Regulated Output from No Load to Full Load
- Full-Load Power 360 W, or Full-Load Current 30 A
- High Efficiency
- Constant Soft-Start Time
- Protection: Over Voltage, Under Voltage, Over Current, and Over Temperature
- Constant Current and Constant Power
- Input Voltage Feed Forward Control
- PMBus Communications
- Test Points to Facilitate Device and Topology Evaluation

3 Performance Specifications

Table 1. UCD3138HSFBEVM-029 Specifications

PARAMETER	TEST CONDITIONS	MIN	TYP	MAX	UNITS
Input Characteristics					
Voltage operation range		36		72	V _{DC}
Input UVLO On			35		
Input UVLO Off			32		
Input current	Input = 36 V _{DC} , full load = 30 A			11	A
Input current	Input = 48 V _{DC} , full load = 30 A			9	
Input current	Input = 72 V _{DC} , full load = 30 A			6	
Output Characteristics					
Output voltage, V _{OUT}	No Load to full load		12		V _{DC}
Output load current, I _{OUT}	36 to 72 V _{DC}			30	A
Output voltage ripple	48 V _{DC} and full load = 30 A		30		mVpp
Systems Characteristics					
Switching frequency			200		kHz
Peak efficiency	48 V _{DC} , load = 20 A		94.5%		
Full load efficiency	48 V _{DC} , full load = 30 A		93.5%		
Operating temperature	Typical 400 LFM forced air flow		25		°C

4 Schematics




Figure 1. UCD3138HSFBEVM-029 Schematics Sheet 1 of 3




Figure 2. UCD3138HSFBEVM-029 Schematics Sheet 2 of 3




Figure 3. UCD3138HSFBEVM-029 Schematics Sheet 3 of 3

5 Test Setup

5.1 Test Equipment

DC Voltage Source: capable of 36 V_{DC} to 72 V_{DC}, adjustable, with minimum power rating of 400 W, or current rating not less than 12 A, with current limit function.

DC Multi-meter: 1 unit capable of 0 V_{DC} to 75 V_{DC} input range, four digits display preferred; and one unit capable of 0 V_{DC} to 15 V_{DC} input range, four digits display preferred.

Output Load: DC load capable of receiving 0 V_{DC} to 15 V_{DC}, 0 A to 30 A, and 0 W to 360 W or greater, with display such as load current and load power.

Current-meter, DC, optional in case the load has no display, one unit, capable of 0 A to 30 A. A low ohmic shunt and a DMM is recommended.

Oscilloscope: capable of 500-MHz full bandwidth, digital or analog, if digital 5Gs/s or better.

Fan: 400 LFM forced air cooling.

Recommended Wire Gauge: capable of 30 A, or better than #14 AWG, with the total length of wire less than 8 feet (4 feet input and 4 feet return).

5.2 Recommended Test Setup




Figure 4. UCD3138FBHSEVM-029 Recommended Test Set Up




Figure 5. UCD3138HSFBEVM-029 Board Outlook

6 List of Test Points

Table 2. UCD3138HSFBEVM-029 List of Test Points

TEST POINTS	NAME	DESCRIPTION
TP1	+VIN	Input Voltage positive
TP2	PWRGND	Input Voltage negative
TP3	+BUS	Input voltage after filter
TP4	Voripple	BNC Vo ripple
TP5	6V UR Bias	Secondary Bias 6V_UR
TP6	PGND	Secondary bias GND
TP7	3.3VD	3.3VD
TP8	AGND	UCD3138 AGND
TP9	VAUXPRI	Primary side bias voltage
TP10	+Vo	+Vout test
TP11	VAUXS	Secondary side bias voltage
TP12	SR_Drive1	Drive to FET Q1, 2 and Q3
TP13	SR_Drive2	Drive to FET Q4, 5 and Q6
TP14	IS-	Secondary side current sense negative
TP15	VINSCALED	VIN monitoring sense on secondary side
TP16	I_Pri	Primary side current sense transformer output on secondary side
TP17	PGND	Secondary bias GND
TP18	DRV_QT2_iso	Q_T2
TP19	DRV_QB1_iso	Q_B1
TP20	PWRGND	Input Voltage negative
TP21	DRV_QT1_iso	Q_T1
TP22	DRV_QB2_iso	Q_B2
TP23	T3-1	Transformer T3 pin 1
TP24		Not Used
TP25	SW1	Switch node of Q_T1 and Q_B2
TP26		Not Used
TP27	ISEC	Secondary side current copper sensing after conditioning
TP28		Not Used
TP29		Not Used
TP30		Not Used
TP31		Not Used
TP32	3.3VEXT	3.3V_EXT
TP33	PGND	Secondary bias GND
TP34		Not Used
TP35-43		Not Used
TP44	-VO	-Vout test
TP45	EAP2	EAP2
TP46	SYNC	UCD3138 SYNC

7 List of Terminals

Table 3. UCD3138HSFBEVM-029 List of Terminals

TERMINAL	NAME	DESCRIPTION
J1	VIN Input	2-pin, input voltage, 36 V _{DC} to 72 V _{DC}
J2	Driver-A	16-pin header, DPWM to driver configuration
J3	+VO	2-pin, output power positive
J4	-Vo	2-pin, output power negative
J5	Driver-B	12-pin header, DPWM to driver configuration
J6	PMBus	10-pin PMBus connection
J7	JTAG	14-pin JTAG connection
J8	UART0	Standard UART connection, RS232, 9-pin female
P1	Bias	External bias terminal for firmware debugging without power stage on
P2	ISHARE	ISHARE and load current sense

8 Test Procedure

8.1 Efficiency Measurement Procedure

WARNING

Danger of electrical shock. High voltage present during the measurement.

Do not leave EVM powered when unattended.

Danger of heat burn from high temperature.

1. Refer to [Figure 4](#) for basic set up to measure power conversion efficiency. The required equipment for this measurement is listed in [Section 5.1](#).
2. Before making electrical connections, visually check the boards to make sure no shipping damage occurred.
3. In this EVM package, two EVMs are included, UCD3138HSFBEVM-029, and USB-TO-GPIO. For this measurement, the UCD3138HSFBEVM-029 board is needed.
4. Connect the DC voltage source to J1-1 (+) and J1-2 (-). Set up the DC output voltage in the range specified in [Table 1](#), between $36 V_{DC}$ and $72 V_{DC}$; set up the DC source current limit 12 A.
5. Connect an electronic load with either constant-current mode or constant-resistance mode. The load range is from 0 A to 30 A.
6. Check and make sure the jumpers are installed correctly on J2 and J5.
 1. J2 should be jumped across to connect its 1-16, 2-15, 7-10, and 8-9.
 2. J5 should be jumped across to connect its 1-12, 2-11, 5-8, and 6-7.

WARNING

Follow the connections correctly to avoid possible damages.

7. It is recommended to use the switch S1 to turn on the board output after the input voltage is applied to the board. Before applying input voltage, make sure the switch, S1, is in the "OFF" position.
8. If the load does not have a current or a power display, a current meter or low ohmic shunt and DMM is needed between the load and the board for current measurements.
9. Connect a volt-meter across the output connector and set the volt-meter scale 0 V to 15 V on its voltage, DC.
10. Turn on the DC voltage source output, flip S1 to "ON" and vary the load. Record output voltage and current measurements.

8.2 Equipment Shutdown

1. Shut down the DC voltage source.
2. Shut down the electronic load.

9 Performance Data and Typical Characteristic Curves

Figure 6 through Figure 14 present typical performance results for UCD3138HSFBEM-029.

9.1 Efficiency




Figure 6. UCD3138HSFBEM-029 Efficiency

9.2 Load Regulation




Figure 7. UCD3138HSFBEM-029 Load Regulation

9.3 Line Regulation




Figure 8. UCD3138HSFBEM-029 Line Regulation

9.4 Constant Power Constant Current (CPCC)




Figure 9. Constant Power Constant Current

9.5 Output Voltage Ripple




Figure 10. Output Voltage Ripple at 48 V_{DC} and Half Load, 27.2 mV

9.6 Output Turn On




Figure 11. Output Turn On 48 V_{DC} with Load Range (Ch 1 = V_O, Ch 3 = DPWM1B, Ch 4 = V_{CT}, Load = 1 A)




Figure 12. Output Turn On 48 V_{DC} with 6-V Prebias

9.7 Bode Plots




Figure 13. Control Loop Bode Plots at 48 V_{DC} and Half Load




Figure 14. Control Loop Bode Plots at 48 V_{DC} and Full Load

10 EVM Assembly Drawing and PCB Layout

The following figures (Figure 15 through Figure 20) show the design of the UCD3138HSFBEVM-029 printed circuit board. PCB dimensions: L x W = 4.5 inch x 4.0 inch, PCB material: FR4 or compatible, four layers and 2-oz copper on each layer.




Figure 15. UCD3138HSFBEVM-029 Top Layer Assembly Drawing (top view)




Figure 16. UCD3138HSFBEVM-029 Bottom Assembly Drawing (bottom view)




Figure 17. UCD3138HSFBEVM-029 Top Copper (top view)




Figure 18. UCD3138HSFBEVM-029 Internal Layer 1 (top view)




Figure 19. UCD3138HSFBEVM-029 Internal Layer 2 (top view)




Figure 20. UCD3138HSFBEVM-029 Bottom Copper (top view)

11 List of Materials

Component list based on schematics of [Figure 1](#) through [Figure 3](#).

Table 4. UCD3138HSFBEVM-029 List of Materials

QTY	RefDes	Description	Part Number	MFR
7	C1, C2, C3, C8, C10, C79, C82	Capacitor, ceramic, 16 V, X5R, 20%, 47 μ F, 1210	STD	STD
2	C11, C52	Capacitor, ceramic, 6.3 V, X7R, 10%, 2.2 μ F, 0603	STD	STD
0	C14, C37, C38, C76	Capacitor, ceramic, 50 V, X7R, 10%, Open, 0603	STD	STD
5	C19, C21, C56, C58, C59	Capacitor, ceramic, 50 V, X7R, 10%, 4700 pF, 0603	STD	STD
12	C20, C23, C26, C29, C30, C31, C32, C33, C42, C44, C47, C48	Capacitor, ceramic, 50 V, X7R, 10%, 0.1 μ F, 0603	STD	STD
5	C22, C25, C60, C61, C64	Capacitor, ceramic, 16 V, X7R, 10%, 1 μ F, 0603	STD	STD
1	C28	Capacitor, ceramic, 50 V, X7R, 10%, 1 nF, 0603	STD	STD
3	C34, C36, C70	Capacitor, ceramic, 50 V, NP0, 10%, 47 pF, 0603	STD	STD
1	C39	Capacitor, ceramic, 50 V, X7R, 10%, 680 pF, 0603	STD	STD
2	C4, C85	Capacitor, ceramic, 10 V, X5R, 10%, 10 μ F, 0805	STD	STD
1	C41	Capacitor, ceramic, 50 V, X7R, 10%, 330 pF, 0603	STD	STD
1	C43	Capacitor, ceramic, 50 V, X7R, 10%, 220 pF, 0603	STD	STD
4	C49, C66, C69, C74	Capacitor, ceramic, 50 V, NP0, 10%, 100 pF, 0603	STD	STD
2	C5, C46	Capacitor, ceramic, 16 V, X7R, 10%, 2.2 μ F, 0805	STD	STD
1	C50	Capacitor, ceramic, 50 V, X7R, 10%, 1000 pF, 0603	STD	STD
2	C53, C54	Capacitor, ceramic, 100 V, X7R, 10%, 1000 pF, 1206	STD	STD
1	C57	Capacitor, ceramic, 200 V, NP0, 10%, 47 pF, 0805	STD	STD
7	C6, C17, C18, C78, C83, C84, C86	Capacitor, ceramic, 16 V, X7R, 10%, 1 μ F, 0805	STD	STD
2	C62, C73	Capacitor, ceramic, 16 V, X7R, 10%, 100 nF, 0603	STD	STD
1	C63	Capacitor, ceramic, 16 V, X7R, 10%, 4.7 μ F, 0805	STD	STD
1	C65	Capacitor, ceramic, 100 V, X7R, 10%, 1 μ F, 1210	STD	STD
2	C67, C68	Capacitor, ceramic, 50 V, NP0, 10%, 10 pF, 0603	STD	STD
9	C7, C13, C15, C16, C35, C45, C71, C72, C77	Capacitor, ceramic, 50 V, X7R, 10%, 10 nF, 0603	STD	STD
1	C75	Capacitor, Electrolytic, 16 V, 20%, 1000 μ F, 12.5 x 20.00 mm	EEU-EB1C102	Panasonic
1	C81	Capacitor, ceramic, 2000 V, X7R, 10%, 4.7 nF, 1812	STD	STD
8	C9, C12, C24, C27, C40, C51, C55, C80	Capacitor, ceramic, 100 V, X7R, 10%, 2.2 μ F, 1210	STD	STD
2	D1, D5	Diode, fast switching, 100 V, SOT23	MMBD914LT1G	Fairchild
4	D11, D15, D16, D18	Diode, Schottky, 40 V, 0.5 A, SOD-123	MBR0540T1G	On Semi
2	D14, D19	LED, 565 NM, green diff, 0603	SML-LX0603GW	LUMEX
1	D17	Diode, small-signal, 85 V, 200 MA, SOT23	BAW56-V-GS08	Vishay-Liteon
2	D2, D13	LED, 660 NM, super red diff, 0603	SML-LX0603SRW	Lite On
2	D3, D8	Diode, Schottky, 2 A, 40 V, SMB	SS24T3G	ON SEMI
2	D4, D10	Diode, TVS Zener dual, 300 W, 5 V, SOT23	SM05T1G	ON SEMI
1	D6	Diode, Zener, 225 MW, 5.6 V, SOT-23	BZX84C5V6-T1G	ON SEMI
3	D7, D9, D12	Diode, dual switch, 100 V, SOT23	MMBD7000LT1G	ON SEMI
1	F1	Fuse, 15 A, 86 V _{DC} fast 6125FA, 15 A 86 V, 2410	TR2/6125FA15A	Cooper
3	J1, J3, J4	Two position 5-mm terminal block, TB 2 x 5 mm, 0.40 x 0.35 inch	ED350/2	OST

Table 4. UCD3138HSFBEM-029 List of Materials (continued)

1	J2	Header 16 position 2 mm, header 2 mm 16 pos	PRPN062PAEN-RC	Sullins
1	J5	Header 12 position 100 mil, header 0.1 12 pos", 0.100 inch x 2 x 6	PEC06DAAN	Sullins
1	J6	Shrouded header 10 pos straight, header 100-2x5 shrouded header 100-2x5 shrouded 0.100 inch x 5 x 2	N2510-6002-RB	Sullins
0	J7	Connector hdr dual 14pos .100 SRT AU, open, 0.100 inch x 2 x 7	PEC07DAAN	Sullins
1	J8	Connector, 9 pin D, right angle, female, 1.213 x 0.510	182-009-213R171	Norcomp
1	L1	Inductor, power, 35 A, 2.2 μ H, 1.100 x 1.100 inch	SER2814H-222KL	Coilcraft
1	L2	Inductor, power, 16 A, 470 nH, 0.255 x 0.270 inch	IHLP2525CZERR47M01	Vishay
2	P1, P2	Conn header 3 position 0.100 vert tin, 3-pin polarized header, 0.100 inch x 3	22-27-2031	Molex
4	Q_B1, Q_B2, Q_T1, Q_T2	MOSFET, N-channel, 100 V, 60 A, 8 m Ω , QFN	FDMS86101	Fairchild
6	Q1, Q2, Q3, Q4, Q5, Q6	MOSFET, N-channel, 100 V, 60 A, 8 m Ω , QFN	FDMS86101	Fairchild
4	Q7, Q8, Q10, Q11	Transistor, NPN, 350 mW, 200 mA, 40 V, SOT23	MMBT3904	FAIRCHILD
1	Q9	MOSFET, N-channel, 200 V, 3 A, S08	FDS2670	Fairchild
16	R1, R5, R6, R8, R18, R19, R24, R28, R40, R62, R63, R64, R68, R96, R103, R104	Resistor, chip, 1/10 W, 1%, 10.0 k Ω , 0603	STD	STD
1	R101	Resistor, chip, 1/10 W, 1%, 1 Ω , 0603	STD	STD
2	R14, R74	Resistor, chip, 1/3 W, 1%, 20 Ω , 1210	STD	STD
2	R15, R16	Resistor, chip, 1/8 W, 1%, 15 Ω , 0805	STD	STD
0	R17	Resistor, chip, 1/8 W, 1%, Open, 0805	STD	STD
5	R2, R30, R52, R95, R106	Resistor, chip, 1/8 W, 1%, 10 Ω , 0805	STD	STD
1	R21	Resistor, chip, 1/10 W, 1%, 6.49 k Ω , 0603	STD	STD
4	R22, R46, R51, R105	Resistor, chip, 1/10 W, 0 Ω , 0603	STD	STD
1	R91	Resistor, chip, 1/10 W, 3 Ω , 0603	STD	STD
4	R25, R32, R76, R82	Resistor, chip, 1/10 W, 1%, 49.9 k Ω , 0603	STD	STD
0	R26	Resistor, current sense, 3 W, 1%, open, 0.394 x 0.205 inch	BVS-M-R001-1.0	Isotek
0	R27, R38, R39, R44, R45, R66, R75, R78, R81, R83, R86, R88, R89, R90, R94	Resistor, chip, 1/10 W, 1%, open, 0603	STD	STD
1	R29	Resistor, chip, 1/10 W, 1%, 2.00 k Ω , 0603	STD	STD
1	R3	Resistor, chip, 1/8 W, 1%, 200 Ω , 0805	STD	STD
1	R31	Resistor, chip, 1/8 W, 1%, 1.00 k Ω , 0805	STD	STD
1	R33	Resistor, chip, 1/10 W, 1%, 1.74 k Ω , 0603	STD	STD
3	R34, R56, R58	Resistor, chip, 1/10 W, 1%, 3.32 k Ω , 0603	STD	STD
2	R35, R85	Resistor, chip, 1/10 W, 1%, 16.2 k Ω , 0603	STD	STD
1	R36	Resistor, chip, 1/10 W, 1%, 1.62 k Ω , 0603	STD	STD
6	R4, R10, R11, R23, R107, R108	Resistor, chip, 1/8 W, 1%, 1 Ω , 0805	STD	STD
1	R42	Resistor, chip, 1/10 W, 1%, 3.09 k Ω , 0603	STD	STD
1	R47	Resistor, chip, 1/10 W, 1%, 15.0 k Ω , 0603	STD	STD
2	R48, R53	Resistor, chip, 1/10 W, 1%, 22.1 k Ω , 0603	STD	STD
1	R49	Resistor, chip, 1/10 W, 1%, 4.99 k Ω , 0603	STD	STD
5	R50, R98, R99, R100, R102	Resistor, chip, 1/10 W, 1%, 33.2 Ω , 0603	STD	STD

Table 4. UCD3138HSFBEM-029 List of Materials (continued)

1	R54	Resistor, chip, 1/10 W, 1%, 1.50 k Ω , 0603	STD	STD
1	R59	Resistor, chip, 1/8 W, 1%, 3.01 Ω , 0805	STD	STD
1	R60	Resistor, chip, 1/8 W, 1%, 750 Ω , 0805	STD	STD
1	R61	Resistor, chip, 1/10 W, 1%, 137 k Ω , 0603	STD	STD
1	R65	Resistor, chip, 1/8 W, 1%, 1.65 k Ω , 0805	STD	STD
1	R67	Resistor, chip, 1/10 W, 1%, 51.1 k Ω , 0603	STD	STD
1	R69	Resistor, chip, 1/8 W, 1%, 90.9 k Ω , 0805	STD	STD
4	R7, R13, R55, R57	Resistor, chip, 1/10 W, 1%, 499 Ω , 0603	STD	STD
1	R72	Resistor, chip, 1/10 W, 1%, 10 Ω , 0603	STD	STD
1	R73	Resistor, chip, 1/8 W, 0 Ω , 0805	STD	STD
1	R77	Resistor, chip, 1/10 W, 1%, 0.47 Ω , 0603	STD	STD
1	R79	Resistor, chip, 1/10 W, 1%, 150 k Ω , 0603	STD	STD
1	R80	Resistor, chip, 1/10 W, 1%, 1.18 k Ω , 0603	STD	STD
1	R84	Resistor, chip, 1/10 W, 1%, 1.82 k Ω , 0603	STD	STD
1	R87	Resistor, Chip, 1/10 W, 1%, 301 Ω , 0603	STD	STD
8	R9, R12, R20, R37, R41, R43, R70, R71	Resistor, chip, 1/10 W, 1%, 1.00 k Ω , 0603	STD	STD
1	R92	Resistor, chip, 1/10 W, 1%, 2.49 k Ω , 0603	STD	STD
1	R93	Resistor, chip, 1/10 W, 1%, 20.0 k Ω , 0603	STD	STD
1	R97	Resistor, chip, 1/10 W, 1%, 220 Ω , 0603	STD	STD
1	S1	Switch, on-on mini toggle, SPDT 28 V 0.4 A, 0.28 x 0.18 inch	G12AP	NKK
1	S2	Switch, SPST, PB momentary, sealed washable, 0.245 X 0.251	KT11P2JM34LFS	C & K
1	T1	SMT 100:1 current sense XFMR, 100:01:00, 0.284 x 0.330 inch	PA1005.100	Pulse
1	T2	Transformer, aux. flyback \pm 10%, 540 μ H, 0.400 x 0.480 inch	031-00019	XFMR Inc
1	T3	Power XFMR 400 W 5:2:2, 26x29.5 mm	755044	Payton
29	TP1, TP2, TP3, TP5, TP6, TP7, TP8, TP9, TP10, TP11, TP12, TP13, TP14, TP15, TP16, TP17, TP18, TP19, TP20, TP21, TP22, TP23, TP25, TP27, TP32, TP33, TP44, TP45, TP46	Test point, white, thru hole, 5012, 0.125 x 0.125 inch	5012	Keystone
1	TP4	Adaptor, 3.5-mm probe clip (or 131-5031-00), 0.200 inch	131-4244-00	Tektronix
1	U1	UCD3138RHA, Digital Power Controllers, QFN	UCD3138RHA	TI
1	U10	OPA344, Mic op amp RRIO, SOT23-5	OPA344NA/250	TI
1	U11	TLV2371, op amp 3 MHz RRIO, SOT23-5	TLV2371IDBVR	TI
2	U2, U9	TPS715A33, LDO reg, QFN-8	TPS715A33DRBT	TI
1	U3	UCC27524, Dual HS MOSFET Driver, 5 A, HTSSOP	UCC27524DGN	TI
1	U4	SN65C3221, Line DRVR/RCVR 1 channel, TSSOP-16	SN65C3221PWR	TI
1	U5	QISO7240CF, UAD channel 25 MBPS digital isolator, SO-16	ISO7240CFDWR	TI
1	U6	LM60C, temp sensor, SOT-23	LM60CIM3X	TI
2	U7, U12	UCC27211, high/low-side driver, 4 A, SO8	UCC27211D	TI
1	U8	UCC3813D-1, low-pwr current-mode PWM, SO8	UCC3813D-1	TI

12 Digital Full-Bridge Converter Description

A.1 Converter Block Diagram

Figure 21 shows the converter block diagram used in the EVM. The signals used for control and for detection are also defined in Figure 21 in connection to the UCD3138 pins which are listed in Section A.2 and Figure 22 as well.




Figure 21. Converter Block Diagram and Pin Definitions

A.2 UCD3138 Pin Definition

The definition of each UCD3138 pin is defined in Figure 21. The definitions shown in Figure 22 are for these pins used in the EVM to make full-bridge converter control. It can be found in Figure 21 how the signals on these pins are used in the converter in this EVM.




Figure 22. UCD3138 Pin Definition in Hard Switching Full-Bridge Control

A.3 EVM Hardware – Introduction

This section describes the EVM hardware functions.

A.3.1 Power Stage

This EVM implements a traditional symmetrical hard-switching full-bridge dc-dc converter topology. The power stage circuit is shown in [Figure 23](#). The complete schematics are shown in [Figure 1](#) through [Figure 3](#). The main power components on the primary side, Q_T1, Q_T2, Q_B1, and Q_B2 form the MOSFET full-bridge converter. These four FETs are controlled by the UCD3138 DPWM module 0 (DPWM0A) and module 1 (DPWM1A). The controller, UCD3138, is located on the secondary side. The driver signals to these four FETs are through digital isolator U5 to transmit from the secondary side to the primary side. The synchronous rectifiers are shown on the same page and are labeled as Q1 to Q3 and Q4 to Q6. They are controlled by DPWM module 0 (DPWM0B) and DPWM module 1 (DPWM1B). Please refer to [Figure 22](#) for DPWM module 0 and 1. The main power transformer is T3. T1 is the current transformer used to sense the primary-side current and feed into the secondary-side UCD3138 controller through AD04.




Figure 23. Full-Bridge Converter Power Stage

A.3.2 Bias Power Supply

The main bias supply is a flyback converter using the UCC3813 controller from Texas Instruments. The bias circuit is shown in Figure 24.

In this circuit, one output (VAUXPRI) is on the primary side and two outputs (VAUXS and 6V_UR) are on the secondary side. The feedback signal is taken from VAUXPRI. The secondary-side controller needs 3.3 V, which is derived from 6V_UR by a regulator (U2) to supply UCD3138 and by a regulator (U9) to supply digital isolator (U5), external temperature sensor (U6) and UART controller (U4). On the primary side a 5V-LDO is to supply the digital isolator to transmit drive signals from the secondary side to the primary side. The three LDO associated bias circuits are shown in Figure 25.




Figure 24. Main Bias Circuit and Input Voltage Optional Monitoring




Figure 25. LDO Bias Circuits

A.3.3 Input Voltage Sensing Using Bias Transformer

As the controller is located on the secondary side, special approaches are required to obtain the input voltage information from the primary side for control needs. One approach is to use the main bias power supply transformer winding.

As shown in [Figure 24](#), a sample-and-hold circuit is on the secondary side to sense the primary voltage. When switch Q9 turns on, D3 turns on by the negative voltage from divider R31 and R76. The voltage on the winding (6, 7) of bias transformer T2 charges capacitor (C71) to a negative voltage equal to V_{IN}/N times the attenuator ratio of R31 and R76, (N is turns ratio of T2). When Q9 is turned off, D3 is turned off, and the voltage on C71 is held until next switching period. The voltage on C71 is proportional to the input voltage. U11 is used to invert the input negative voltage to positive output voltage scaled by R93 and R79. This input voltage monitoring approach is an optional for potential applications while not enabled in the EVM firmware.

A.3.4 Input Voltage Sensing Using Main Transformer

The sensing approach described in [Section A.3.3](#) is good to use in steady-state but not capable of fast transient sensing. This approach presents slow detection and slow response. Its advantage is less noise sensitive.

To improve input voltage sensing speed in real time, the main power transformer can be used. As shown in [Figure 26](#), the approach takes the input voltage signal (VIN_CT) from the center tap of the main transformer secondary side windings, then scaling the signal to feed into UCD3138 EADC02. This EVM uses this sense structure when the converter is in startup, in steady-state, as well as in input voltage feed forward control. Particularly when use this structure for converter startup, the approach is called single-frame input voltage sensing. Single-frame here means one switching cycle. More details on how the main transformer is used to make input voltage sense can be found in [Section A.3.5](#).




Figure 26. Input Voltage Sensing Using Main Transformer

A.3.5 Load Current Sensing by PCB Copper

To utilize the board area, this EVM uses copper trace (R26) to sense the output load current. The copper sensing related circuit is shown in Figure 27. R41 and R43 are installed to feed the sensing signal to the current amplifier U10. With a low pass filter (C7, R54 and R20), the output voltage of the amplifier is of DC voltage in nature. The signal is then fed to AD13 of the controller. The amplifier gain can be set to 137 by choosing $R41 = R43 = 1k$, $R61 = 137k$.

AD13 is used to sense the load current, then the processor utilize the information for many applications, such as reporting the current to the host, calculating output power, implementing current sharing and over current protection.

The accuracy of sensing current with a copper trace is usually poor because the resistance of copper trace depends not only on the base copper thickness and plating, but also on the temperature of the copper. The base copper has a temperature coefficient of about 4000 PPM per degree °C. Fortunately, the resistance can be measured and stored during manufacturing, and the temperature of the copper trace can be measured to compensate for temperature drift. The temperature of the copper trace is measured by a temperature sensor U11 (LM60C) then feed into UCD3138 through AD06. Please refer to Section A.6.7 for temperature sensing.




Figure 27. Load Current Sensing by PCB Copper

A.3.6 Load Current Sharing

UCD3138 supports three major current sharing techniques:

1. Average current sharing, or pwm bus current sharing.
2. Master/slave current sharing.
3. Droop mode current sharing, or analog bus current sharing.

This EVM uses the average current sharing. If interested in the other two sharing techniques, please contact TI for further assistance.

The average current sharing technique uses a share bus to balance and evenly distribute current on each paralleled converter. The share bus is called ISHARE in this EVM design. Hence, when making load current sharing, ISHARE from each board requires connecting together. ISHARE connection is located on P2 terminal pin 3 on the EVM board.

Figure 28 shows the load sharing module inside UCD3138. When enable the average current sharing, SW1 turns on. The ISHARE bus is on AD02 output which generates a voltage corresponding to the load current of that board. As all boards in share connected together by each of their own ISHARE, the voltage on EXT CAP (C19) is an averaged value representing a targeted sharing value for each converter output current. AD13, is used to measure the load current of each board in voltage, then compare to the voltage on ISHARE to adjust one's own output current level to match the targeted ISHARE value by DPWM duty cycle control.




Figure 28. UCD3138 Load Sharing Module

A.3.7 Serial Port Interface

The schematic of the interface for the serial port (UART) is shown in Figure 29. The UART is able to provide real time debug and subsequently reduce code development time. It can also be used as a monitor for fast changing internal variables. The UART is not enabled in delivered EVM boards. Please contact TI to find how to enable this function.




Figure 29. Serial Port Interface in the Converter

A.3.8 LED Indicators

Table 5. LED Status Lights

REF DES	SILK SCREEN TEXT	FUNCTION
D14		This light is on in green when 3.3VD is present on UCD3138.
D13	VIN_OK	This light is on in red when input voltage ok.
D2	FAILURE	This light is on in red when latch-off fault(s) present, currently OVP only.
D19	P_GOOD	This light is on in green when the output voltage is within the thresholds defined by PMBUS_CMD_POWER_GOOD_ON and PMBUS_CMD_POWER_GOOD_OFF

A.4 EVM Firmware – Introduction

The reference firmware provided along with the EVM is only intended to demonstrate basic HSFB converter control functionality as well as basic PMBus communication. The firmware can be used as an initial platform for particular applications. A brief introduction to the firmware is provided in this section.

A.4.1 Firmware Infrastructure Overview

The firmware includes one startup routine and three program threads. The startup routine is to make initialization to set up the controller to the targeted operation functions or status. Please contact TI to obtain the detailed initialization information.

The three program threads are (a) the Fast Interrupt (FIQ); (b) the Standard Interrupt (IRQ); and (c) the Background Loop, as shown in Figure 30.

- **Fast Interrupt (FIQ):** Critical or time sensitive tasks are within the FIQ. Functionally, FIQ events are the highest priority and are addressed as soon as possible. It occurs every four switching cycles, set by DPWM interrupt.
- **Standard Interrupt (IRQ):** The majority of the firmware tasks occur during the IRQ. IRQ events occur synchronously every 100 μ s set by timer.
- **Background Loop:** Non time sensitive tasks are implemented in background loop. Background Loop items are addressed whenever FIQ and IRQ events are not handled.




Figure 30. Firmware Structure Overview

A.4.2 Tasks within FIQ

The FIQ events are with the highest priority and are addressed as soon as possible. Critical or time sensitive tasks are in the FIQ. In the firmware uploaded into the EVM, the function called by the FIQ is constant power and constant current function.

There are two control loops in the EVM. Voltage loop for V_{OUT} regulation; and current loop for constant current protection. Front end 0 and filter 0 are for the voltage loop, front end 1 and filter 1 are for the current loop. In FIQ, the filter output of the two loops is compared. The loop takes control of the power stage is decided base on the larger output of the two filter-outputs.

The FIQ gets called to response every four-switching cycles.




Figure 31. State Machine

A.4.3 Tasks within IRQ State Machine

Almost all firmware tasks occur during the IRQ. The only exceptions are the serial interface and PMBus tasks, which occur in the background loop; and the over current protection (OCP), which is handled by the FIQ. The IRQ is called to response every 100 μ s.

At the heart of the IRQ function is the power supply state machine implemented with “switch” command. The state machine has its structure as shown in [Figure 31](#). At a higher level, this state machine allows the digital controller to optimize the performance of the power supply, based on exactly what it is doing.

A.4.4 Tasks within Background Loop

The background loop handles all PMBus communication as well as process and transmit data through the UART. The data flash is managed with a dual-bank approach. This provides redundancy in the event of a power interruption during the programming of data flash. Once new data flash values have been written, a function called `erase_task()` is initiated in the background loop to erase the old values. The `erase_task()` continues to get called until all of the old DFLASH segments are erased. Erasing the data flash in segments allows the processor in the controller to handle other tasks instead of waiting for the entire data flash to be erased before doing anything else.

A.5 System Normal Operation

The EVM is designed to operate in PWM hard switching mode in normal operation conditions. At very light load condition, if needed, the burst operation can be enabled for EVM operation. Please contact TI to find how to enable this function.

On the other end of the operation, if the load power keeps increasing beyond the rated value, then an over load condition occurs. In such a case, the system enters protection operation, first entering constant power constant current mode, then if load power still keeps increasing, this triggers cycle-by-cycle current limit. Please refer to [Section A.6](#) to learn more about these protection functions.

The converter of this EVM is designed to work in the following manner.

- When V_{IN} reaches above 22 V, the auxiliary power supply turns on. The UCD3138 starts and uses the single-frame approach to check if V_{IN} reaches 36 V if S1 is on. If V_{IN} reaches 36 V or above, operation starts.
- The converter is in normal operation to regulate the output voltage at 12 V nominally. As shown in [Figure 32](#), Ch1 = TP13, Ch2 = TP25, Ch3 = TP23, and Ch4 = TP12, all referenced to the primary-side ground.
- When the load current reaches such a level to have full power as specified in a pre-determined constant power setting, say 360 W, the output voltage to be regulated reduced, the higher the load current, the lower the output voltage regulation point, in this way, the constant power operation is achieved.
- The converter is controlled to keep operating in constant power mode until the load current reaches a pre-determined level, say 36 A, then the operation enters the constant current mode. In this mode, frond end 1 and filter 1 takes control of the power stage and maintains the output current at the setting point 36A. If the controller sees a large current on the primary side, say over 14 A, hardware cycle-by-cycle current limit function becomes active.
- Further increase load current shifts the primary-side current peak value higher. When the peak values reaches a pre-determined level, the operation is in short circuit protection mode.




Figure 32. Normal Operation Switching Waveforms

A.5.1 Start-Up with Single-Frame Input Voltage Sensing

Before start up, the EVM uses a different way to sense the primary side voltage. It is called single-frame V_{IN} sensing. In idle mode, two sets of single DPWM frames with 800 ns width are sent, EADC2 are used to catch the second pulse from secondary and input voltage is determined. The sensing point can be programmed to get the best noise performance. The single-frame V_{IN} sensing scheme is illustrated in Figure 33. Figure 34 shows test waveforms, where the green and the blue are two primary DPWM; the orange is VIN_SNS feed to EADC2. The purple is the transformer CT.




Figure 33. Input Voltage Sensing Using EADC2




Figure 34. Single-Frame Approach Test

In normal operation control, the sensing hardware connection also serves the input voltage feed forward control, refer to Section A.5.2.

A.5.2 Prebias Load and Load Synchronous Startup

When start a converter into pre-biased load condition, or start with two or more converters in parallel, special techniques are required since even a small difference from each output voltage may cause reverse current flow. The special technique, called synchronous startup, is used to enhance the parallel startup performance of UCD3138 controlled converters. This technique uses a GPIO pin as sync-pin which connects each board together to start at the same time then the output voltage difference from different converter is minimized.

A.5.3 Current Sharing Operation

To make two boards in current sharing operation, P2 pin 3 of each board is required to connect together as shown in Figure 35. P2 pin 3 serves as an “ISAHRE” connection, refer to Section A.3.6. Figure 36 provides a test result, the yellow is output voltage, the other two channels are output currents from two paralleled EVM boards. The test was made with total load current change from 3 A to 60 A. The current sharing ratio in steady state at 60-A load is nearly perfect, that is as close to 50%-50%. In the transient, the sharing difference is about 9.8 A with settle down time about 560 μ s. With the 95% load step change, the V_O overshoot and undershoot is about 0.4 V on 12 V, or about 3.5%

The current sharing operation is made possible in the steady-state. To share the load current in soft start time, it is recommended to use Synchronous Startup technique as described in Section A.5.2. With this technique, the load current can still be shared to some degree since CPCC allows completing the soft start without shut down even if one converter in slight over load condition. Please contact TI to find how to set up synchronous startup.




Figure 35. Current Sharing Operation



Figure 36. Current Sharing Test

A.5.4 Input Voltage Feed Forward Control

The input voltage feed forward control employed in the power converter control is to help to maintain output voltage regulation during input voltage high transient time. This technique can adjust the needed final duty cycle right with the input voltage change without go through normal feedback loop which usually has much longer timer delay in order to correct the output voltage error from input voltage transient. By ignoring the various losses, assuming output voltage 12 V and unity transformer turns ratio, and assuming the converter secondary-side in CCM (as SR is in place), the relationship between input and output in a DC-DC forward type of converter, can be described by the duty cycle,

$$d = \frac{V_{OUT}}{V_{IN}} \quad (1)$$

Plot this equation, the relationship between input and output can be shown with the red curve in [Figure 37](#).




Figure 37. Duty Cycle Change in Feed Forward Control

In digital control, the duty cycle shown in the red-curve can be represented by a piecewise-linear approximation overlaid in the blue-curve. UCD3138 implements the blue-curve approximation with a non-linear multiplier as shown [Figure 38](#) which shows the control functions implemented in UCD3138. In normal operation without input voltage transient, CLA2 output is unity. The DPWM is solely controlled by CLA1. When input voltage is in transient, CLA2 generates a multiplier based on input voltage change level which can be pre-programmed.




Figure 38. UCD3138 Digital Feed-Forward Control

On the control used in this EVM, the input voltage sense value is compared with V_{REF2} , their difference, V_{th} , will set up the multiplier from CLA2 to CLA1 as below.

- If $-V_{th1} < V_{th} < V_{th1}$, CLA2 = Gain0, or K_{P0}
- If $-V_{th2} < V_{th} < -V_{th1}$, or, $V_{th1} < V_{th} < V_{th2}$, CLA2 = Gain1, or K_{P1}
- If $-V_{th2} > V_{th}$ or $V_{th2} < V_{th}$, CLA2 = Gain2, or K_{P2}

The above can be expressed as,

$$\text{Gain} = K_C + K_P \times (\text{VDAC} - V_{in_sense}) \quad (2)$$

In steady-state, Gain0 = K_C , where K_C can be described as a unity number although in practice it may be designed differently to match other scaled values.

During the input voltage transient, nonlinear gain is generated to achieve desired duty cycle by feed forward control approximation.

As the control algorithm is of symmetrical characteristics from $\pm V_{th1}$ and $\pm V_{th2}$, an equilibrium point is required to be established. From practice such as in 48-V telecom application, this point may be initially selected at $V_{IN0} = 48$ V. During the operation with different input voltage, a new equilibrium point will be re-established corresponding to that input voltage.

In this EVM design, V_{in_sense} signal is from VIN_CT as shown in [Figure 26](#) and its relationship to VIN is expressed as,

$$V_{in_sense} = (V_{IN/N}) \times R29 / (R25 + R29) = k \times V_{IN}, \text{ where } k = 0.0154, \text{ and } N \text{ is the turns ratio of transformer T3.}$$

A.5.5 Feed Forward Function Test

Load = 1 A, V_{IN} from 40 V to 58 V, V_{IN} slew rate 20 V/us, V_O maximum shift 0.68 V, recovery time 50 μ s. In Figure 39, the purple is V_{OUT} and the yellow is V_{IN} . In Figure 40, the green is primary side DPWM and the yellow is V_{IN} .




Figure 39. V_O Change from Digital Feed Forward Control




Figure 40. Duty Cycle Change from Digital Feed Forward Control

A.5.6 Light Load Operation

At light load, the burst operation can be enabled when the switching duty cycle is small. The significant benefit from this operation is the reduction of the power losses. The associated disadvantage is of higher output voltage ripple in steady-state and of larger output voltage dip in load demanding transient. But the higher ripple and the larger dip can be solved especially with digital control of its convenience and flexibility. For example, non-linear control from digital control can solve the large dip during load transient. The higher ripple can also be reduced by narrowed duty cycle on/off limit for burst operation control.

Figure 41 shows the burst operation timing diagram with UCD3138. When the controller detected light load condition, the operation is enabled into Light Load Enable (LLE) by firmware. When load condition is changed to heavy, CLA can generate a large gain to adapt the load change and minimize the output voltage drop although the operation is still in LLE mode. If the load keeps heavy for certain time, light load will be terminated by the firmware.

The burst operation mode is disabled in the EVM. Please contact TI to know how to enable this feature.




Figure 41. Burst Operation Timing Diagram

A.6 System Operation in Protection

A.6.1 Faults and Warnings

The system comes equipped with a variety of programmable fault and warning options. In section 12.3.8, Table 5 lists the LEDs used to indicate a fault. Table 6 below shows the basic faults and warnings available in the EVM along with the corresponding action taken by these events. Each of these parameters can be modified through the GUI.

Table 6. Faults and Warnings

SIGNAL	TYPE	WARNING	FAULT RESPONSE
VOUT	Over	Report	Report & Latch off
	Under	Report	Report
VIN	Over	Report	Report & Latch off
	Under	Report	Report & Latch off
IOUT	Over	Report	Report & Latch off
IIN	Over	Report	Cycle by cycle limiting
Temperature	Over	Report	Report and Latch off

The GUI reporting includes appropriate setting of the PMBus alert line, status byte and status word. Faults and warnings can be reset by toggling the unit off and then on. Alternatively, as long as the system does not latch off, the “Clear Faults” button can also be used to clear any faults or warnings. Refer to Figure 42 which is from the Designer GUI Monitor tab. More details can be found in Section A.8.




Figure 42. Faults and Warnings

A.6.2 Constant Power Constant Current Operation

Both hardware and firmware in this EVM supports Constant Power Constant Current, or CPCC operation. Figure 43 illustrates the behavior of the output voltage and output current (V_{OUT} vs. I_{OUT}). However, the EVM comes pre-programmed with a constant power threshold of 360 W and a constant current threshold of 36 A. Some of the limits are adjustable through the GUI and new setting can be saved to data flash. The maximum hardware capability is to limit the current within 36 A. Figure 44 shows the GUI interface to these controls with the default values. The CPCC can be enabled or disabled through GUI. Details can be found in Section A.4.2.

After the output power reaches the set point, V_{OUT} starts to drop while the power keeps the same which means the current may increase. The power stage stays on and it will not enter latch mode. When the current loop filter output (Front End 1 and Filter 1) is larger than the voltage loop filter output (Front End 0 and Filter 0), the current loop takes control of the power stage and output voltage starts in hiccup operation state. In hiccup state, the power stage stays on for 1s, and then goes to idle state and try to turn on again. If the load is reduced, the power stage will go to regulated state. If the load current is still high, the output voltage goes to hiccup state again. Only OVP will take the power stage to latch-off state. OTP, OCP, and constant current will take the power state to hiccup state. In hiccup state, the power state turns on automatically. In latch state, toggle off the PSON switch is needed or recycle the input power.




Figure 43. Constant Power Constant Current Operation




Figure 44. CPCC Default Values and Adjustable through GUI

A.6.3 Cycle-By-Cycle Current Limit

Cycle-by-cycle current limit is made to the primary-side input current. The current is sensed by current transformer T1. The sensing circuit is shown in Figure 45; also refer to full schematics of Figure 1 and power stage Figure 23. The current signal is fed into AD04 and compared to a programmable threshold on a cycle-by-cycle basis. Whenever this current exceeds the threshold the active DPWM waveforms are truncated. The cycle-by-cycle current limit is mainly used to the primary current to limit its peak within pre-determined value, default as 16 A.

As AD04 is a simple voltage comparator, external current slope compensation circuit may be needed in order to minimize the sub-harmonics normally existing in peak current mode control including cycle-by-cycle current limit. An example circuit is shown in Figure 46. More detail on this circuit can be found in "Modeling, Analysis and Compensation of the Current-Mode Converter", (TI Literature Number SLUA101).

In case the peak current mode control is employed in an application, the peak current mode control should be made through Front End 2 (EADC2) instead of using AD04. Front End 2 has build-in current slope compensation (RAMP) as shown in Figure 47 which does not require external slope compensation.

UCD3138 can balance two pulses in a switching cycle with the same width. In UCD3138RHA, this feature exists in the DPWM module on its two outputs, for example between DPWM0A and 0B, but not available on the interconnection matrix. Then this EVM is not able to balance the pulse width in a switching cycle. If this feature is preferred, please contact TI for technical assistance.




Figure 45. Cycle-by-Cycle Current Limit Sensing Circuit




Figure 46. An Example of External Slope Compensation




Figure 47. Peak Current Mode Control with Front End 2

A.6.4 Short Circuit Protection

Load short circuit protection is mainly based on the secondary-side current sensing when the load current is beyond a 36 A by default. In short circuit protection the output voltage is in hiccup state.

Figure 48 shows a test results with the conditions: short circuit test at 30-A load, V_{OUT} (Ch1), I_{PRI} (Ch 2), and V_{IN} (Ch 3).




Figure 48. Short Circuit Protection Test

A.6.5 Output Over Voltage

Output over voltage detection and protection is through AD03, refer to Figure 1 and Figure 23. When output over voltage is detected, the switching pulses will be disabled and the board will be in latch-off until recycle the input power or toggle the switch S1.

A.6.6 Input Over Voltage

The input over voltage is detected based on the main power transformer winding as described in Section A.3.4. Currently in the EVM delivered, input voltage is detected and the firmware provides warning to the Designer GUI. Please contact TI if need OVP protection.

A.6.7 Over Temperature

Over temperature includes UCD3138 internal temperature sensing and external added temperature sensing. The external over temperature condition is determined by a temperature sensing element on U13, LM60C. The temperature signal is fed into the controller through AD06. U13 is located on board top side next to the current sensing copper. Then it is sensing the temperature of secondary-side board temperature. In addition to the over temperature protection, this temperature information is used to compensate the copper current sensing.




Figure 49. Temperature Detection Circuit

A.7 Loop Compensation Using PID Control

PID control is usually used in the feedback loop compensation in digitally controlled power converters. We will describe several aspects how to use PID control.

A.7.1 Digital PID Coefficients Transformation to Poles and Zeros in s-Domain

PID control in UCD3138 CLA for control loop is formed in the following equation in z-domain:

$$G_c(z) = K_P + K_I \frac{1+z^{-1}}{1-z^{-1}} + K_D \frac{1-z^{-1}}{1-\alpha \times z^{-1}} \quad (3)$$

If Equation 3 is converted to the s-domain equivalent using the bilinear transform, the result has two forms. One is with two real zeros and one real pole:

$$G_{cz}(s) = K_0 \frac{\left(\frac{s}{\omega_{z1}} + 1\right)\left(\frac{s}{\omega_{z2}} + 1\right)}{s\left(\frac{s}{\omega_{p1}} + 1\right)} \quad (4)$$

K_0 is the gain of the frequency domain pole at origin, and K_0 is also represented as the angular frequency when the integrator Bode plot gain crosses over with 0-dB. By the way, K_0 can be used as a method for initially designing the feedback loop compensation, refer to for more details.

The second way is when the two zeros are possibly presented with complex conjugates and in such a case,

$$G_{cz}(s) = K_0 \frac{\left(\frac{s^2}{\omega_r^2} + \frac{s}{Q \times \omega_r} + 1\right)}{s\left(\frac{s}{\omega_{p1}} + 1\right)} \quad (5)$$

Two complex conjugate zeros are expressed as,

$$\omega_{z1, z2} = \frac{\omega_r}{2 \times Q} \left(1 \pm j\sqrt{4 \times Q^2 - 1}\right) \quad \text{and} \quad j = \sqrt{-1} \quad (6)$$

$$\omega_r = \sqrt{\omega_{z1} \times \omega_{z2}} \quad (7)$$

$$Q = \frac{\sqrt{\omega_{z1} \times \omega_{z2}}}{\omega_{z1} + \omega_{z2}} \quad (8)$$

The factor of Q is in the range of 0 to infinite. The two complex conjugate zeros become the two real zeros when Q is not greater than 0.5.

$$Q \leq 0.5 \quad (9)$$

Hence, Equation 4 is actually a special form of Equation 5. In this sense, Equation 5 can be used in either case across the range of Q.

A low pass filter usually exists in a control loop of its feedback path. The low pass filter adds a pole to the loop,

$$H_{CS}(s) = K_{CS} \frac{1}{\frac{s}{\omega_{PCS}} + 1} \quad (10)$$

The close loop transfer function is then shown as below:

$$G_{CS}(s) = \frac{G_M(s) \times G_{PID}(s)}{1 + G_M(s) \times G_{PID}(s) \times H_{CS}(s)} \quad (11)$$

where GM(s) is the control plant transfer function. For example, GM(s) can be the transfer function associated to the modulator in an HSFB converter.

The parameters can be calculated with the assumption of sensor sampling cycle T_s much smaller than the corresponding time constant of the voltage loop bandwidth, T_C . A rule of thumb is to choose the sampling frequency to meet

$$T_s \leq 0.05 \times T_C \quad (12)$$

When the above assumption is true, the delay effect from the sampling (usually with zero order hold or ZOH) can be ignored and the parameters can be determined after we know where the poles and zeros should be positioned. Table 7 summarizes the poles and zeros in a form to relate z-domain to s-domain.

$$K_P = \frac{K_0 \times (\omega_{p1} \times \omega_{z1} + \omega_{p1} \times \omega_{z2} - \omega_{z1} \times \omega_{z2})}{\omega_{p1} \times \omega_{z1} \times \omega_{z2}} \quad (13)$$

$$K_I = \frac{K_0 \times T_s}{2} \quad (14)$$

$$K_D = \frac{2 \times K_0 \times (\omega_{p1} - \omega_{z1}) \times (\omega_{p1} - \omega_{z2})}{\omega_{p1} \times \omega_{z1} \times \omega_{z2} (T_s \times \omega_{p1} + 2)} \quad (15)$$

$$\alpha = \frac{2 - T_s \times \omega_{p1}}{2 + T_s \times \omega_{p1}} \quad (16)$$

Table 7. Poles and Zeros from PID Coefficients

System Name	Transfer Functions
Complex Zeros (K_0, f_z, Q_z, f_p)	$\frac{s^2}{(2 \times \pi \times f_z)^2} + \frac{s}{2 \times \pi \times f_z \times Q_z} + 1$ $\frac{s}{2 \times \pi \times K_0} \times \left(\frac{s}{2 \times \pi \times f_p} + 1 \right)$
Real Zeros (K_0, f_{z1}, f_{z2}, f_p)	$\left(\frac{s}{2 \times \pi \times f_{z1}} + 1 \right) \times \left(\frac{s}{2 \times \pi \times f_{z2}} + 1 \right)$ $\frac{s}{2 \times \pi \times K_0} \times \left(\frac{s}{2 \times \pi \times f_p} + 1 \right)$
Device PID (K_p, K_i, K_d, α)	$1000 \times \left(K_p + K_i \times \frac{1+z^{-1}}{1-z^{-1}} + K_d \times \frac{1-z^{-1}}{1-\alpha \times 2^{-8} \times z^{-1}} \right) \times 2^{-SC} \times K_{COMP} \times 2^{-19} \times \frac{1}{2^4 \times (PRD+1)}$

A.7.2 Tuning PID Coefficients for Loop Compensation

When making fine-tune adjustments to the feedback control loop, one would like to know each parameter in PID how to affect the control loop characteristics without going through complicated description of the above equations. Table 8 below helps this and visually shown in Figure 50.

Table 8. Tuning PID Coefficients

CONTROL PARAMETERS	IMPACT ON BODE PLOT
K_p	Increasing K_p
	Pushes up the minimum gain between the two zeros.
	Moves the two zeros apart.
K_i	Increasing K_i
	Pushes up integration curve at low frequencies.
	Gives a higher low-frequency gain.
K_d	Increasing K_d
	Shifts the second zero left.
	Doesn't impact the second pole.
α	Increasing α
	Shifts the second pole to the right.
	Shifts the second zero to the right.
$T_s = 1 / f_s$	Increasing the sampling frequency f_s :
	Causes the whole Bode plot to shift to right.




Figure 50. Tuning PID Parameters

A.7.3 Measuring the Control Loop

The control loop measurement can be made by injecting frequency sweep signal across R16. The connections can take advantage of P2 pin 1 and TP10.

A.8 Evaluating the EVM with GUI

Collectively, the GUI is called Texas Instruments Fusion Digital Power Designer. The GUI serves the interface for several families of TI digital control IC's including the family of UCD31xx, that is the UCD3138 as its one member. The GUI can be divided into two main categories, Designer GUI and Device GUI. In the family of UCD31xx, each EVM is related to a particular Designer GUI to allow users to re-tune/re-configure a particular EVM in that regarding with existing hardware and firmware. Device GUI is related to a particular device to access its internal registers and memory cells.

UCD3138HSFBEM-029 is a standalone board where UCD3138RGH 40-pin device is placed. The firmware to control this converter is downloaded into this board through Device GUI. How to install the GUI is described in the user's guide "Using the UCD3138CC64EVM-030 (TI Lit#, SLUU886)". The designer GUI is installed at the same time when installing the Device GUI.

A.8.1 Graphical User Interface (GUI)

As mentioned above, there are two types of graphical user interfaces (GUI), one is Device GUI, and the other is Designer GUI. The Device GUI is sometimes called low level GUI. From the Device GUI, device's registers are accessed if the device is in the ROM mode and the PMBus communication is established. This GUI should be used to download the code when the device is blank at the first programming. Also, at the flash mode, a customer can send PMBus commands to read or write the data. The Designer GUI is an interface between a host and a user's board. It supports some of PMBus commands for configuration, monitoring and design such as loop compensator built in the UCD3138 digital controller.

A.8.1.1 Hardware Setup

The board hardware connection is overall the same as shown in Section 5.2 and Figure 4 while shown in Figure 51 again. The addition to the setup is to connect USB-to-GPIO to the board. The ribbon cable connects to J6 and the USB cabled connects to a host PC computer. The remaining connections are described again in the below.




Figure 51. Test Setup

- Refer to [Figure 51](#) for basic hardware connections. The required equipment is listed in [Section 5.1](#).
- Before making electrical connections, visually check the boards to make sure no shipping damage occurred.
- Connect the DC voltage source to J1-1 (+) and J1-2 (-). Set up the DC output voltage in the range specified in [Table 1](#), between 36 V_{DC} and 72 V_{DC}; set up the DC source current limit 12 A.
- Connect an electronic load with either constant current mode or constant resistance mode. The load range is from zero to 30 A.
- Connect USB-to-GPIO ribbon cable to J6 and connect USB-to-GPIO USB cable to a host PC computer.
- Check and make sure the jumpers are installed correctly on J2 and J5.
 - J2 should be jumped across to connect its 1-16, 2-15, 7-10, and 8-9.
 - J5 should be jumped across to connect its 1-12, 2-11, 5-8, and 6-7.

WARNING

Follow the connections correctly to avoid possible damages

- It is recommended to use the switch S1 to turn on the board output after the input voltage is applied to the board. Before applying input voltage, make sure the switch, S1, is in the “OFF” position.
- If the load does not have a current or a power display, a current meter or low ohmic shunt and DMM will be needed between the load and the board for current measurements.
- Connect a volt-meter across the output connector and set the volt-meter scale 0 V to 15 V on its voltage, DC.

A.8.1.2 GUI Installation

GUI software can be downloaded from the TI website, www.ti.com. The software should be installed in the host PC before it is executed. More details about the TI GUI, which is called TI Fusion Digital Power Designer (DFPD), can be found in its user’s guide/manual. Please contact TI to get this user’s guide/manual. After the GUI installation, the Guide can be found in the Designer GUI of its real time “Help”.

“Help” > “Documentation & Help Center” > “UCD3138”

Copy the TI Fusion Digital Power Designer zip file and unzip the file TI-Fusion-Digital-Power-Designer-xx.zip to get installer TI-Fusion-Digital-Power-Designer-xxx.exe. The xxx in the file name refers to the GUI release version.

Double click the installer TI-Fusion-Digital-Power-Designer-xxx.exe and follow the straight forward instructions to finish the installation. Normally, you need accept all the installation defaults. In order to get all GUI functions, all boxes under Select Additional Tasks should be checked, shown in [Figure 52](#).




Figure 52. GUI Installation

After the installation, a quick launch button is created next to the start menu which contains shortcuts to commonly used applications. [Figure 53](#) shows the icon of TI DFPD after the installation. Some other icons such as UCD3K Device GUI are also displayed on the desktop. For more information on the GUI installation, one can refer to UCD3138CC64EVM-030 user’s guide.




Figure 53. GUI Shortcut Location

A.8.1.3 USB-to-GPIO Adaptor Connection

CAUTION

Shut off DC power source before connection to avoid electrical shock!

Connect one end of the ribbon cable to the module, and connect the other end to the USB-to-GPIO (HPA172) interface adapter. Connect the Mini connector of the USB cable to the USB interface adapter, and connect the other end to the USB port of the host computer.

A.8.1.4 Launch the Designer GUI

Click the Quick Launch Shortcut icon located next to the start menu. The GUI starts to look for the attached device attached to the PMBus. If the device is found and the communication is established successfully, one should see a screen that looks similar to [Figure 54](#). In the following we will describe how to use the GUI to evaluate the module.



Figure 54. Designer GUI Overview

A.8.1.5 Designer GUI Overview

The Designer GUI has four tabs, as shown in Figure 54, namely, Configure, Design, Monitor, and Status. After launch the GUI, its default tab is Monitor. To go to the other three tabs, simply click the tab you would like to go.

In the GUI used with this EVM, Configure is used to configure the EVM settings through PMBus commands. Design is mainly used to make tuning control loop parameters and to set up the Feed-Forward control non-linear gains. Monitor is used to monitor the board operation. Status is mainly used to show fault and/or warnings.

A.8.2 Operation Monitoring

After the designer GUI launched, the Monitor tab is presented by default as shown in Figure 54. This tab provides a quick overview of operation status with some settings changeable as well. This tab also provides oscilloscope type of plot view in real time operation. The number of scope windows can be adjusted by check or un-check upper left square boxes to show or to hide these scope plot windows.




Figure 55. Designer GUI Status

A.8.3 Operation Status

After click the Status tab as shown in [Figure 54](#), the EVM operation status is shown as in [Figure 55](#). All grayed entries are candidates that can be implemented. Those in black are showing current operation status which helps to indicate potential operation issues with warning or fault indications. If a fault occurred, the corresponding entry is highlighted in red. Warnings are not a fault while may remind the user that those might need attention.

A.8.4 Configuring EVM

Configure tab can help to adjust the EVM feature setup conveniently without directly accessing the firmware code. Also, it helps to navigate through the various features of the converter through the GUI.

Command	Code	Value/Edit	Hex/Edit
Configuration			
CPCC [MFR 36]	0xF4	Click...	0x01...
DEADBAND_CONFIG [MFR 26]	0xEA	Click...	0x01...
FREQUENCY_SWITCH	0x33	200.0 kHz	0x00C8
IDEAL DIODE EMUL CONFIG	0xFE	Enabled	0x01
LIGHT_LOAD_CONFIG [MFR 02]	0xD2	Click...	0x00...
VFF_CONFIG [MFR 42]	0xFA	Enabled	0x01
VOUT_COMMAND	0x21	12.000 V	0x1800
VOUT_MODE	0x20	EXP	0x17
VOUT_TRANSITION_RATE	0x27	1.000 mV/μs	0x0001
Limits			
IIN_OC_FAULT_LIMIT	0x5B	16.00 A	0x0010
IOUT_OC_FAULT_LIMIT	0x46	38.00 A	0x0026
OT_FAULT_LIMIT	0x4F	50 °C	0x0032
VIN_OFF	0x36	35.000 V	0x0023
VIN_ON	0x35	37.000 V	0x0025
VIN_OV_FAULT_LIMIT	0x55	75.000 V	0x0048
VIN_UV_FAULT_LIMIT	0x59	33.000 V	0x0021
VOUT_OV_FAULT_LIMIT	0x40	14.000 V	0x1C00
VOUT_UV_FAULT_LIMIT	0x44	3.000 V	0x0600
Manufacturer Info			
CMDS_DCDC_NONPAGED [MFR 21]	0xE5	Click...	0x10...
CMDS_DCDC_PAGED [MFR 20]	0xE4	Click...	0x00...
DEVICE_ID [MFR 45]	0xFD	UCD3100ISO1	0x55...
IC_DEVICE_ID	0xAD	UCD3138RHA	0x55...
IC_DEVICE_REV	0xAE	0	0x3000
MFR_DATE	0x9D	121115	0x31...
MFR_ID	0x99	TI	0x54...
MFR_LOCATION	0x9C	Dallas, TX	0x44...
MFR_MODEL	0x9A	UCD3138HS...	0x55...
MFR_REVISION	0x9B	A	0x4100
MFR_SERIAL	0x9E	121115	0x31...
PMBUS_REVISION	0x98	1.2,1.2 - Part 1.1.2 - Rev 1.1	0x42
SETUP_ID [MFR 23]	0xE7	VERSIO...	0x56...
On/Off Configuration			
POWER_GOOD_OFF	0x5F	11.000 V	0x1600
POWER_GOOD_ON	0x5E	11.500 V	0x1700
TON_RISE	0x61	20.0 ms	0x0014
Status			
READ_DEBUG_BUFFER1 [MFR 32]	0xF0	Click...	0x01...
READ_FREQUENCY	0x95	0.0 kHz	0x0000
READ_IOUT	0x8C	0.00 A	0x5800
READ_TEMP_EXTERNAL	0x8E	-353 °C	0xFD3E
READ_TEMP_INTERNAL	0x8D	22 °C	0xDAB6
READ_VIN	0x88	28.750 V	0xDB98
READ_VOUT	0x8B	0.000 V	0x0000
STATUS_BYTE	0x78	00000000	0x00
STATUS_WORD	0x79	Click...	0x0000

Figure 56. GUI Supported PMBus Commands

A.8.4.1 GUI Supported PMBus Commands

Figure 56 displays the various GUI based PMBus commands supported by the current version of the firmware. Adding additional standard commands is easy to do with the built in “Isolated Bit Mask” generator. This tool creates a coded index that the GUI reads from the device to determine what PMBus commands are supported. To add a standard command simply modify the bit mask and the GUI will automatically display the new command. Please contact Texas Instruments for details on the use of this tool.

A.8.4.2 Configuring EVM with GUI

In the Configure tab, change configuration is made simple. For example, to configure CPCC, the CPCC control can be accessed by clicking the drop down arrow next to the Value/Edit box on the CPCC[MFR 36] line as shown in Figure 57. As we mentioned before, maximum current 36A and maximum power 360 W. Please consult Texas Instruments if there is any uncertainty to be resolved.

Command	Code	Value/Edit	Hex/Edit
Configuration			
CPCC [MFR 36]	0xF4	Click...	0x01...
DEADBAND_CONFIG [MFR 26]	0xEA	Click...	0x01...
FREQUENCY_SWITCH	0x33	200.0 kHz	0x00C8
IDEAL DIODE EMUL CONFIG	0xFE	Enabled	0x01
LIGHT_LOAD_CONFIG [MFR 02]	0xD2	Click...	0x00...
VFF_CONFIG [MFR 42]	0xFA	Enabled	0x01
VOUT_COMMAND	0x21	12.000 V	0x1800
VOUT_MODE	0x20	EXP	0x01
VOUT_TRANSITION_RATE	0x27	1.000 mV/μs	0x0001
Limits			
IIN_OC_FAULT_LIMIT	0x5B	16.00 A	0x0010
IOUT_OC_FAULT_LIMIT	0x46	38.00 A	0x0026
OT_FAULT_LIMIT	0x4F	50 °C	0x0032
VIN_OFF	0x36	35.000 V	0x0023
VIN_ON	0x35	37.000 V	0x0025
VIN_OV_FAULT_LIMIT	0x55	75.000 V	0x004B
VIN_UV_FAULT_LIMIT	0x59	33.000 V	0x0021
VOUT_OV_FAULT_LIMIT	0x40	14.000 V	0x1C00
VOUT_UV_FAULT_LIMIT	0x44	3.000 V	0x0600
Manufacturer Info			
CMD5_DCDC_NONPAGED [MFR 21]	0xE5	Click...	0x10...
CMD5_DCDC_PAGED [MFR 20]	0xE4	Click...	0x00...
DEVICE_ID [MFR 45]	0xFD	UCD31001S01	0x55...
IC_DEVICE_ID	0xAD	UCD3138RHA	0x55...
IC_DEVICE_REV	0xAE	0	0x3000
MFR_DATE	0x9D	121115	0x31...
MFR_ID	0x99	TI	0x54...
MFR_LOCATION	0x9C	Dallas, TX	0x44...
MFR_MODEL	0x9A	UCD3138H5...	0x55...
MFR_REVISION	0x9B	A	0x4100
MFR_SERIAL	0x9E	121115	0x31...
PMBUS_REVISION	0x98	1.2,1.2 - Part 1.1.1 - Rev. 1.1	0x42
SETUP_ID [MFR 23]	0xE7	VERSIO...	0x56...
On/Off Configuration			
POWER_GOOD_OFF	0x5F	11.000 V	0x1600
POWER_GOOD_ON	0x5E	11.500 V	0x1700
TON_RISE	0x61	20.0 ms	0x0014
Status			
READ_DEBUG_BUFFER1 [MFR 32]	0xF0	Click...	0x01...
READ_FREQUENCY	0x95	0.0 kHz	0x0000
READ_IOUT	0x8C	0.00 A	0x5800
READ_TEMP_EXTERNAL	0x8E	-353 °C	0xF03E
READ_TEMP_INTERNAL	0x8D	22 °C	0xDAB6
READ_VIN	0x88	28.750 V	0xDB98
READ_VOUT	0x8B	0.000 V	0x0000
STATUS_BYTE	0x78	00000000	0x00
STATUS_WORD	0x79	Click...	0x0000

Figure 57. Configure CPCC

As one more example, in the following, we will describe how to configure the dead time. Configuring other functions is made in the similar way. Again, please consult Texas Instruments if there is any uncertainty to be resolved before making your configuration.

A.8.4.3 Configuring Dead Time

Click the drop down arrow next to the Value/Edit box on the DEADBAND_CONFIG [MFR 26] line, a dialogue box of [Figure 58](#) is present to allow configuring the dead time.




Figure 58. Configuring Dead Time

A.8.5 Tuning Control Loop Using GUI Design

A.8.5.1 Options to Program Digital Control Loop

The GUI comes equipped with 3 different ways to program the UCD3138 digital control loop compensator. [Table 9](#) lists the three options, (a) using K_0 , f_z , Q_z , and f_p ; (b) using K_0 , f_{z1} , f_{z2} , and f_p ; (c) using K_p , K_i , K_d , and α .

In option (c), the compensator is described by Device PID. In this context, K_p , K_i , K_d and α are the raw register values used to configure the positions of the poles and zeros of the compensator. SC is a gain scaling term. Although it is normally set to zero it provides additional gain for situations where the power stage gain may be low. PRD is used to configure the minimum operating period and KCOMP is used to configure the maximum operating period. In the context of the compensator they are simply gain terms that modify the overall transfer function by a fixed value. It is important to be aware that the proper way to configure PRD and KCOMP varies based on the control topology implemented.

Table 9. Programming Digital Control Loop

SYSTEM NAME	TRANSFER FUNCTIONS
Complex Zeros (K_0 , f_z , Q_z , f_p)	$\frac{s^2}{(2 \times \pi \times f_z)^2} + \frac{s}{2 \times \pi \times f_z \times Q_z} + 1$ $\frac{s}{2 \times \pi \times K_0} \times \left(\frac{s}{2 \times \pi \times f_p} + 1 \right)$
Real Zeros (K_0 , f_{z1} , f_{z2} , f_p)	$\frac{s^2}{(2 \times \pi \times f_z)^2} + \frac{s}{2 \times \pi \times f_z \times Q_z} + 1$ $\frac{s}{2 \times \pi \times K_0} \times \left(\frac{s}{2 \times \pi \times f_p} + 1 \right)$
Device PID (K_p , K_i , K_d , α)	$1000 \times \left(K_p + K_i \times \frac{1+z^{-1}}{1-z^{-1}} + K_d \times \frac{1-z^{-1}}{1-\alpha \times 2^{-8} \times z^{-1}} \right) \times 2^{-SC} \times KCOMP \times 2^{-19} \times \frac{1}{2^4 \times (PRD + 1)}$

The compensator of this EVM is configured to acquire one sample per switching cycle, T_s , as defined by [Equation 17](#) where $T_{DPWM} = 250$ ps,

$$T_s = 16 \times (PRD + 1) \times T_{DPWM} \quad (17)$$

When the converter operates in PWM mode $KCOMP = PRD$ and the “Device PID” option in [Table 9](#) is expressed in [Equation 16](#) which correctly describes the behavior of the compensator. For clarity [Equation 18](#) displays the exact transfer function used in PWM mode operation.

$$1000 \times \left(K_p + K_i \times \frac{1+z^{-1}}{1-z^{-1}} + K_d \times \frac{1-z^{-1}}{1-\alpha \times 2^{-8} \times z^{-1}} \right) \times \frac{2^{-SC} \times PRD \times 2^{-19}}{2^4 \times (PRD + 1)} \quad (18)$$

[Equation 18](#) is based on a fixed sample rate. This means [Equation 18](#) is assumed with one switching frequency. The value of that frequency is inside the variable z ;

$$z = e^{sT_s} \quad (19)$$

where T_s is the switching period, that is the reciprocal of the switching frequency. In PWM mode, the switching frequency is fixed at 200 kHz such that T_s is fixed and the only value. [Figure 59](#) shows an example of Bode plot outputs from the GUI. [Figure 60](#) shows the PID coefficients used. [Figure 61](#) shows the schematics used to obtain the Bode Plots in [Figure 59](#) with the PID coefficients shown in [Figure 60](#).




Figure 59. Bode Plots from GUI

```

CLA Gains Review - DC-DC HSFB @ Address 88d
C Code
//This is the C code for the loop currently selected.
//It also reflects the values currently set in the GUI and
//may not reflect what was last written to the device.
//Write coefficients for the code to reflect the device.
//Time: 12/6/2012 5:03 PM

Filter0Regs.FILTERCTRL.bit.NL_MODE = 1; //Symmetric

// Coefficient set A(0)
Filter0Regs.FILTERKPCOEFO.bit.KP_COEF_0 = 1500;
Filter0Regs.FILTERKICOEFO.bit.KI_COEF_0 = 150;
Filter0Regs.FILTERKDCOEFO.bit.KD_COEF_0 = 20000;

// Coefficient set B(1)
Filter0Regs.FILTERKPCOEFO.bit.KP_COEF_1 = 3000;
Filter0Regs.FILTERKICOEFO.bit.KI_COEF_1 = 250;
Filter0Regs.FILTERKDCOEFO.bit.KD_COEF_1 = 10000;

// Coefficient set C(2)
Filter0Regs.FILTERKPCOEFO.bit.KP_COEF_2 = 10000;
Filter0Regs.FILTERKICOEFO.bit.KI_COEF_2 = 500;
Filter0Regs.FILTERKDCOEFO.bit.KD_COEF_2 = 5500;

// Coefficient set D(3)
Filter0Regs.FILTERKICOEFO.bit.KI_COEF_3 = 500;

// Alpha coefficient banks
Filter0Regs.FILTERKDALPHA.bit.KD_ALPHA_0 = 150;
Filter0Regs.FILTERKDALPHA.bit.KD_ALPHA_1 = 25;
    
```

Copy to Clipboard

Figure 60. PID Coefficients Used in Voltage Loop




Figure 61. Bode Plots Calculation

NOTE: The above Figure 61 schematic was used in the bode plots calculation.

A.9 Firmware Development for HSF B Power Converter

Please contact TI for additional information regarding UCD3138 digital HSF B firmware development.

A.10 References

1. UCD3138 Datasheet, *Highly Integrated Digital Controller for Isolated Power*, ([Texas Instruments, Literature Number SLUSAP2](#)), 2012
2. UCD3138CC64EVM-030 Evaluation Module and User's Guide, *Programmable Digital Power Controller Control Card Evaluation Module*, ([Texas Instruments Literature Number SLUU886](#)), 2012
3. TI Application Manual, *UCD3138 Digital Power Peripherals Programmer's Manual*, (Texas Instruments Literature Number SLUU995)
4. TI Application Manual, *UCD3138 Monitoring and Communications Programmer's Manual*, (Texas Instruments Literature Number SLUU996)
5. TI Application Manual, *UCD3138 ARM and Digital System Programmer's Manual*, (Texas Instruments Literature Number SLUU994)
6. User Guide, *UCD3138 Isolated Power Fusion GUI*, ([please contact TI](#)). Note this User Guide is also available in the GUI after installation.

Revision History

NOTE: Page numbers for previous revisions may differ from page numbers in the current version.

Changes from Original (April 2013) to A Revision	Page
• changed R91 from 0 Ohm to 3 Ohm (schematic).....	8
• changed R91 from 0 Ohm to 3 Ohm (list of materials)	22

STANDARD TERMS FOR EVALUATION MODULES

1. *Delivery:* TI delivers TI evaluation boards, kits, or modules, including any accompanying demonstration software, components, and/or documentation which may be provided together or separately (collectively, an "EVM" or "EVMs") to the User ("User") in accordance with the terms set forth herein. User's acceptance of the EVM is expressly subject to the following terms.
 - 1.1 EVMs are intended solely for product or software developers for use in a research and development setting to facilitate feasibility evaluation, experimentation, or scientific analysis of TI semiconductor products. EVMs have no direct function and are not finished products. EVMs shall not be directly or indirectly assembled as a part or subassembly in any finished product. For clarification, any software or software tools provided with the EVM ("Software") shall not be subject to the terms and conditions set forth herein but rather shall be subject to the applicable terms that accompany such Software
 - 1.2 EVMs are not intended for consumer or household use. EVMs may not be sold, sublicensed, leased, rented, loaned, assigned, or otherwise distributed for commercial purposes by Users, in whole or in part, or used in any finished product or production system.
2. *Limited Warranty and Related Remedies/Disclaimers:*
 - 2.1 These terms do not apply to Software. The warranty, if any, for Software is covered in the applicable Software License Agreement.
 - 2.2 TI warrants that the TI EVM will conform to TI's published specifications for ninety (90) days after the date TI delivers such EVM to User. Notwithstanding the foregoing, TI shall not be liable for a nonconforming EVM if (a) the nonconformity was caused by neglect, misuse or mistreatment by an entity other than TI, including improper installation or testing, or for any EVMs that have been altered or modified in any way by an entity other than TI, (b) the nonconformity resulted from User's design, specifications or instructions for such EVMs or improper system design, or (c) User has not paid on time. Testing and other quality control techniques are used to the extent TI deems necessary. TI does not test all parameters of each EVM. User's claims against TI under this Section 2 are void if User fails to notify TI of any apparent defects in the EVMs within ten (10) business days after delivery, or of any hidden defects with ten (10) business days after the defect has been detected.
 - 2.3 TI's sole liability shall be at its option to repair or replace EVMs that fail to conform to the warranty set forth above, or credit User's account for such EVM. TI's liability under this warranty shall be limited to EVMs that are returned during the warranty period to the address designated by TI and that are determined by TI not to conform to such warranty. If TI elects to repair or replace such EVM, TI shall have a reasonable time to repair such EVM or provide replacements. Repaired EVMs shall be warranted for the remainder of the original warranty period. Replaced EVMs shall be warranted for a new full ninety (90) day warranty period.

WARNING

Evaluation Kits are intended solely for use by technically qualified, professional electronics experts who are familiar with the dangers and application risks associated with handling electrical mechanical components, systems, and subsystems.

User shall operate the Evaluation Kit within TI's recommended guidelines and any applicable legal or environmental requirements as well as reasonable and customary safeguards. Failure to set up and/or operate the Evaluation Kit within TI's recommended guidelines may result in personal injury or death or property damage. Proper set up entails following TI's instructions for electrical ratings of interface circuits such as input, output and electrical loads.

NOTE:

EXPOSURE TO ELECTROSTATIC DISCHARGE (ESD) MAY CAUSE DEGRADATION OR FAILURE OF THE EVALUATION KIT; TI RECOMMENDS STORAGE OF THE EVALUATION KIT IN A PROTECTIVE ESD BAG.

3 Regulatory Notices:

3.1 United States

3.1.1 Notice applicable to EVMs not FCC-Approved:

FCC NOTICE: This kit is designed to allow product developers to evaluate electronic components, circuitry, or software associated with the kit to determine whether to incorporate such items in a finished product and software developers to write software applications for use with the end product. This kit is not a finished product and when assembled may not be resold or otherwise marketed unless all required FCC equipment authorizations are first obtained. Operation is subject to the condition that this product not cause harmful interference to licensed radio stations and that this product accept harmful interference. Unless the assembled kit is designed to operate under part 15, part 18 or part 95 of this chapter, the operator of the kit must operate under the authority of an FCC license holder or must secure an experimental authorization under part 5 of this chapter.

3.1.2 For EVMs annotated as FCC – FEDERAL COMMUNICATIONS COMMISSION Part 15 Compliant:

CAUTION

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Interference Statement for Class A EVM devices

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

FCC Interference Statement for Class B EVM devices

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

3.2 Canada

3.2.1 For EVMs issued with an Industry Canada Certificate of Conformance to RSS-210 or RSS-247

Concerning EVMs Including Radio Transmitters:

This device complies with Industry Canada license-exempt RSSs. Operation is subject to the following two conditions:

(1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Concernant les EVMs avec appareils radio:

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Concerning EVMs Including Detachable Antennas:

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication. This radio transmitter has been approved by Industry Canada to operate with the antenna types listed in the user guide with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Concernant les EVMs avec antennes détachables

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante. Le présent émetteur radio a été approuvé par Industrie Canada pour fonctionner avec les types d'antenne énumérés dans le manuel d'usage et ayant un gain admissible maximal et l'impédance requise pour chaque type d'antenne. Les types d'antenne non inclus dans cette liste, ou dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur.

3.3 Japan

3.3.1 *Notice for EVMs delivered in Japan:* Please see http://www.tij.co.jp/lstds/ti_ja/general/eStore/notice_01.page 日本国内に輸入される評価用キット、ボードについては、次のところをご覧ください。
http://www.tij.co.jp/lstds/ti_ja/general/eStore/notice_01.page

3.3.2 *Notice for Users of EVMs Considered "Radio Frequency Products" in Japan:* EVMs entering Japan may not be certified by TI as conforming to Technical Regulations of Radio Law of Japan.

If User uses EVMs in Japan, not certified to Technical Regulations of Radio Law of Japan, User is required to follow the instructions set forth by Radio Law of Japan, which includes, but is not limited to, the instructions below with respect to EVMs (which for the avoidance of doubt are stated strictly for convenience and should be verified by User):

1. Use EVMs in a shielded room or any other test facility as defined in the notification #173 issued by Ministry of Internal Affairs and Communications on March 28, 2006, based on Sub-section 1.1 of Article 6 of the Ministry's Rule for Enforcement of Radio Law of Japan,
2. Use EVMs only after User obtains the license of Test Radio Station as provided in Radio Law of Japan with respect to EVMs, or
3. Use of EVMs only after User obtains the Technical Regulations Conformity Certification as provided in Radio Law of Japan with respect to EVMs. Also, do not transfer EVMs, unless User gives the same notice above to the transferee. Please note that if User does not follow the instructions above, User will be subject to penalties of Radio Law of Japan.

【無線電波を送信する製品の開発キットをお使いになる際の注意事項】 開発キットの中には技術基準適合証明を受けていないものがあります。技術適合証明を受けていないものご使用に際しては、電波法遵守のため、以下のいずれかの措置を取っていただく必要がありますのでご注意ください。

1. 電波法施行規則第6条第1項第1号に基づく平成18年3月28日総務省告示第173号で定められた電波暗室等の試験設備でご使用いただく。
2. 実験局の免許を取得後ご使用いただく。
3. 技術基準適合証明を取得後ご使用いただく。

なお、本製品は、上記の「ご使用にあたっての注意」を譲渡先、移転先に通知しない限り、譲渡、移転できないものとします。

上記を遵守頂けない場合は、電波法の罰則が適用される可能性があることをご留意ください。日本テキサス・インスツルメンツ株式会社

東京都新宿区西新宿 6 丁目 2 4 番 1 号
西新宿三井ビル

3.3.3 *Notice for EVMs for Power Line Communication:* Please see http://www.tij.co.jp/lstds/ti_ja/general/eStore/notice_02.page 電力線搬送波通信についての開発キットをお使いになる際の注意事項については、次のところをご覧ください。http://www.tij.co.jp/lstds/ti_ja/general/eStore/notice_02.page

3.4 European Union

3.4.1 *For EVMs subject to EU Directive 2014/30/EU (Electromagnetic Compatibility Directive):*

This is a class A product intended for use in environments other than domestic environments that are connected to a low-voltage power-supply network that supplies buildings used for domestic purposes. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

- 4 *EVM Use Restrictions and Warnings:*
 - 4.1 EVMS ARE NOT FOR USE IN FUNCTIONAL SAFETY AND/OR SAFETY CRITICAL EVALUATIONS, INCLUDING BUT NOT LIMITED TO EVALUATIONS OF LIFE SUPPORT APPLICATIONS.
 - 4.2 User must read and apply the user guide and other available documentation provided by TI regarding the EVM prior to handling or using the EVM, including without limitation any warning or restriction notices. The notices contain important safety information related to, for example, temperatures and voltages.
 - 4.3 *Safety-Related Warnings and Restrictions:*
 - 4.3.1 User shall operate the EVM within TI's recommended specifications and environmental considerations stated in the user guide, other available documentation provided by TI, and any other applicable requirements and employ reasonable and customary safeguards. Exceeding the specified performance ratings and specifications (including but not limited to input and output voltage, current, power, and environmental ranges) for the EVM may cause personal injury or death, or property damage. If there are questions concerning performance ratings and specifications, User should contact a TI field representative prior to connecting interface electronics including input power and intended loads. Any loads applied outside of the specified output range may also result in unintended and/or inaccurate operation and/or possible permanent damage to the EVM and/or interface electronics. Please consult the EVM user guide prior to connecting any load to the EVM output. If there is uncertainty as to the load specification, please contact a TI field representative. During normal operation, even with the inputs and outputs kept within the specified allowable ranges, some circuit components may have elevated case temperatures. These components include but are not limited to linear regulators, switching transistors, pass transistors, current sense resistors, and heat sinks, which can be identified using the information in the associated documentation. When working with the EVM, please be aware that the EVM may become very warm.
 - 4.3.2 EVMs are intended solely for use by technically qualified, professional electronics experts who are familiar with the dangers and application risks associated with handling electrical mechanical components, systems, and subsystems. User assumes all responsibility and liability for proper and safe handling and use of the EVM by User or its employees, affiliates, contractors or designees. User assumes all responsibility and liability to ensure that any interfaces (electronic and/or mechanical) between the EVM and any human body are designed with suitable isolation and means to safely limit accessible leakage currents to minimize the risk of electrical shock hazard. User assumes all responsibility and liability for any improper or unsafe handling or use of the EVM by User or its employees, affiliates, contractors or designees.
 - 4.4 User assumes all responsibility and liability to determine whether the EVM is subject to any applicable international, federal, state, or local laws and regulations related to User's handling and use of the EVM and, if applicable, User assumes all responsibility and liability for compliance in all respects with such laws and regulations. User assumes all responsibility and liability for proper disposal and recycling of the EVM consistent with all applicable international, federal, state, and local requirements.
5. *Accuracy of Information:* To the extent TI provides information on the availability and function of EVMs, TI attempts to be as accurate as possible. However, TI does not warrant the accuracy of EVM descriptions, EVM availability or other information on its websites as accurate, complete, reliable, current, or error-free.
6. *Disclaimers:*
 - 6.1 EXCEPT AS SET FORTH ABOVE, EVMS AND ANY MATERIALS PROVIDED WITH THE EVM (INCLUDING, BUT NOT LIMITED TO, REFERENCE DESIGNS AND THE DESIGN OF THE EVM ITSELF) ARE PROVIDED "AS IS" AND "WITH ALL FAULTS." TI DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, REGARDING SUCH ITEMS, INCLUDING BUT NOT LIMITED TO ANY EPIDEMIC FAILURE WARRANTY OR IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF ANY THIRD PARTY PATENTS, COPYRIGHTS, TRADE SECRETS OR OTHER INTELLECTUAL PROPERTY RIGHTS.
 - 6.2 EXCEPT FOR THE LIMITED RIGHT TO USE THE EVM SET FORTH HEREIN, NOTHING IN THESE TERMS SHALL BE CONSTRUED AS GRANTING OR CONFERRING ANY RIGHTS BY LICENSE, PATENT, OR ANY OTHER INDUSTRIAL OR INTELLECTUAL PROPERTY RIGHT OF TI, ITS SUPPLIERS/LICENSORS OR ANY OTHER THIRD PARTY, TO USE THE EVM IN ANY FINISHED END-USER OR READY-TO-USE FINAL PRODUCT, OR FOR ANY INVENTION, DISCOVERY OR IMPROVEMENT, REGARDLESS OF WHEN MADE, CONCEIVED OR ACQUIRED.
7. *USER'S INDEMNITY OBLIGATIONS AND REPRESENTATIONS.* USER WILL DEFEND, INDEMNIFY AND HOLD TI, ITS LICENSORS AND THEIR REPRESENTATIVES HARMLESS FROM AND AGAINST ANY AND ALL CLAIMS, DAMAGES, LOSSES, EXPENSES, COSTS AND LIABILITIES (COLLECTIVELY, "CLAIMS") ARISING OUT OF OR IN CONNECTION WITH ANY HANDLING OR USE OF THE EVM THAT IS NOT IN ACCORDANCE WITH THESE TERMS. THIS OBLIGATION SHALL APPLY WHETHER CLAIMS ARISE UNDER STATUTE, REGULATION, OR THE LAW OF TORT, CONTRACT OR ANY OTHER LEGAL THEORY, AND EVEN IF THE EVM FAILS TO PERFORM AS DESCRIBED OR EXPECTED.

8. *Limitations on Damages and Liability:*

8.1 *General Limitations.* IN NO EVENT SHALL TI BE LIABLE FOR ANY SPECIAL, COLLATERAL, INDIRECT, PUNITIVE, INCIDENTAL, CONSEQUENTIAL, OR EXEMPLARY DAMAGES IN CONNECTION WITH OR ARISING OUT OF THESE TERMS OR THE USE OF THE EVMS , REGARDLESS OF WHETHER TI HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. EXCLUDED DAMAGES INCLUDE, BUT ARE NOT LIMITED TO, COST OF REMOVAL OR REINSTALLATION, ANCILLARY COSTS TO THE PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES, RETESTING, OUTSIDE COMPUTER TIME, LABOR COSTS, LOSS OF GOODWILL, LOSS OF PROFITS, LOSS OF SAVINGS, LOSS OF USE, LOSS OF DATA, OR BUSINESS INTERRUPTION. NO CLAIM, SUIT OR ACTION SHALL BE BROUGHT AGAINST TI MORE THAN TWELVE (12) MONTHS AFTER THE EVENT THAT GAVE RISE TO THE CAUSE OF ACTION HAS OCCURRED.

8.2 *Specific Limitations.* IN NO EVENT SHALL TI'S AGGREGATE LIABILITY FROM ANY USE OF AN EVM PROVIDED HEREUNDER, INCLUDING FROM ANY WARRANTY, INDEMNITY OR OTHER OBLIGATION ARISING OUT OF OR IN CONNECTION WITH THESE TERMS, , EXCEED THE TOTAL AMOUNT PAID TO TI BY USER FOR THE PARTICULAR EVM(S) AT ISSUE DURING THE PRIOR TWELVE (12) MONTHS WITH RESPECT TO WHICH LOSSES OR DAMAGES ARE CLAIMED. THE EXISTENCE OF MORE THAN ONE CLAIM SHALL NOT ENLARGE OR EXTEND THIS LIMIT.

9. *Return Policy.* Except as otherwise provided, TI does not offer any refunds, returns, or exchanges. Furthermore, no return of EVM(s) will be accepted if the package has been opened and no return of the EVM(s) will be accepted if they are damaged or otherwise not in a resalable condition. If User feels it has been incorrectly charged for the EVM(s) it ordered or that delivery violates the applicable order, User should contact TI. All refunds will be made in full within thirty (30) working days from the return of the components(s), excluding any postage or packaging costs.

10. *Governing Law:* These terms and conditions shall be governed by and interpreted in accordance with the laws of the State of Texas, without reference to conflict-of-laws principles. User agrees that non-exclusive jurisdiction for any dispute arising out of or relating to these terms and conditions lies within courts located in the State of Texas and consents to venue in Dallas County, Texas. Notwithstanding the foregoing, any judgment may be enforced in any United States or foreign court, and TI may seek injunctive relief in any United States or foreign court.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265
Copyright © 2019, Texas Instruments Incorporated

IMPORTANT NOTICE AND DISCLAIMER

TI PROVIDES TECHNICAL AND RELIABILITY DATA (INCLUDING DATASHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS AND IMPLIED, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for skilled developers designing with TI products. You are solely responsible for (1) selecting the appropriate TI products for your application, (2) designing, validating and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, or other requirements. These resources are subject to change without notice. TI grants you permission to use these resources only for development of an application that uses the TI products described in the resource. Other reproduction and display of these resources is prohibited. No license is granted to any other TI intellectual property right or to any third party intellectual property right. TI disclaims responsibility for, and you will fully indemnify TI and its representatives against, any claims, damages, costs, losses, and liabilities arising out of your use of these resources.

TI's products are provided subject to TI's Terms of Sale (www.ti.com/legal/termsofsale.html) or other applicable terms available either on ti.com or provided in conjunction with such TI products. TI's provision of these resources does not expand or otherwise alter TI's applicable warranties or warranty disclaimers for TI products.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265
Copyright © 2019, Texas Instruments Incorporated