

Test Procedure for the NCP458RFCT2GEVB Evaluation Board

- 1. Connect strap between IN and Vbias
- 2. Connect 3.2 V between IN and GND
- 3. Check Vout = 0
- 4. Set EN = 2V
- 5. Check Vout = Vin
- 6. Set EN = 0V
- 7. Check Vout decreases down to GND
- 8. Disconnect Vin

10/6/2014 1 www.onsemi.com