



TRANSFORMING TECHNOLOGIES

OUTSTANDING ALTERNATIVES IN STATIC CONTROL

Ohm Metrics™

Continuous Workstation Monitors - Periodic Verification Unit
Model CM420PV

TEST PROCEDURE:

1. Unplug the power supply to the CM420 unit.
2. Plug the Periodic Verification Unit (PVU) **BENCH** lead (Male Banana Plug) to the common ground at the workstation.
3. Connect the PVU **GROUND** lead (Male Phono Plug) to the CM420 **BENCH** plug-in.
4. Plug the PVU **OPERATOR LEFT** lead (Banana Male Plug) to the CM420 **LEFT OPERATOR** remote jack.
5. Plug the PVU **OPERATOR RIGHT** lead (Banana Male Plug) to the CM420 **RIGHT OPERATOR** remote jack.
6. Connect the power supply to the CM420 power plug-in.
7. Press the **BENCH** push button on the PVU and the **BENCH** led on the CM420 should change to red, with constant beeps.
8. Press the **OPERATOR LEFT** push button on the PVU and the **LEFT OPERATOR** led on the CM420 should change from a blinking red to green.
9. Press the **OPERATOR RIGHT** push button on the PVU and the **RIGHT OPERATOR** led on the CM420 should change from a blinking red to green.
10. If the monitor did not pass as per the test procedure call Transforming Technologies at (419) 841-9552



CM420PV Labeled Leads

TEST PROCEDURE: