

MOUNTING LOCATION:

Right side of radio

TOOLS REQUIRED:

10mm nut driver
Hook tool

HARDWARE INCLUDED:

None

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

PART#: 75103-599

MFG: BMW

MODELS & YEARS:

323i	Sedan&Wagon	99-2000
323Ci	Coupe&Conv	2000
325i	Sedan&Wagon	2001-05
325Ci Coupe	01-05 & Conv 01-06	
325xi	Sedan	2003-05
328i	Sedan	99-2000
328Ci	Coupe	2000-04
330Ci, xi Coupe	01-05 & Conv 01-06	
330i	Sedan	2001-05
M3	Coupe&Conv	2001-06

**** ADVISEMENT ****

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1 Remove the trim strip located between the air bag and glove compartment by inserting the hook tool under the trim strip on the right side of the passenger side; pull to release. Keep working toward the left side, remove completely and set aside. Remove the trim strip above the radio that extends to the right of the steering column by inserting the hook tool under the left side of the trim next to the steering column and pull. Set trim strip aside.

STEP #2 With the 10mm nut driver, remove a 10mm Hex nut located to the right side of the radio. Take the InDash, and place the slotted hole on the stud; install the 10mm Hex nut. Install the trim strip above the radio, then install the trim strip above the glove box.

STEP #3 Attach phone holder to InDash Mount.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW PANAVISE INDASH MOUNT.



Finished Install Picture



04-24-06