

INDASH by PANAVISE®

I-751052008

Page 1 of 12

MOUNTING LOCATION:

Right side of radio cavity K R
(2) Locations, Lower R and Upper R

TOOLS REQUIRED:

Hook tool, Dash Tool, 7mm
Phillips screwdriver, T-20 Torx

PARTS INCLUDED:

(1)S7-1981,S7-1932(75001)

(Radio, MyGig/Nav Mount)

INSTALLATION INSTRUCTIONS

:PART#:751052008 **

MFG: CHRYSLER/DODGE/JEEP/VW

MODELS & YEARS:

JEEP-Wrnlr/Ultd.(8-10)pg.1Wrangler(11-17),JK(2018)pg.2
Liberty(8-12),CHRY-200(11-14)pg.3DODGE:Dakota(8-11)CHRY-
Sebrng&conv(7-10)pg.4
DODGE-Avenger(8-10),Avenger(11-14)pg.5
JEEP-GrCherokee(8-10)Cmnder(8-10)pg.6
DODGE-GR.Caravan(8-10)(11-17),CHRY-T&C(8-10)(11-16)pg.7
JEEP-Patriot(09-15)Compass(09-11)pg.8
CHRY-300C(8-10),Magnm(08),Charger(8-10)pg.9
DODGE-Durango(8-09)Aspen(8-09)pg.10
DODGE-Challenger(9-14)pg.11Nitro(8-11)pg.11
Caliber(9-10)(11-12)pg.11Journey.ex.RT(09-10)pg.12
DODGE-RAM 1500(9-12)2500-5500cons.shft.pg.12
2500-5500cons.shft.(10-12)pg.12
DODGE-RAM 1500(9-11)2500-5500cons.shft.pg.12
RAM 1500(9-11)colmn.shft.pg.12
RAM 2500-5500(10-11)cons.shft.pg.12VW-Routan13-15,pg.12

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

Start here for Jeep Wrangler 2008-2010 (See new instructions for 11-17)pg.2:

STEP #1: With Hook/Dash Tool remove the lower cover plate by inserting Hook Tool into the upper right then left corner, pulling to release (1) clip on each side. Tilt it out and pull up to remove. Set cover aside.

STEP #2: To remove the top cover above the radio. With the Hook Tool, lift up on the front of the top cover to release (1) clip on each side. Tilt up the front of the cover and pull it towards you to release. Set it aside.

STEP #3: With 9/32" socket driver remove the (4) screws, (2) top and (2) bottom. With your hands starting at the top of the radio, release the bezel that goes from the top of the radio down to below the switches and power outlet. There are (6) total clips only as far as needed to get at the right side radio screws.

STEP#4: Remove the (2) screws with 7mm socket driver. Install bottom piece of InDash by PanaVise Mount over screw holes and reinstall the (2) screws. Replace the bezel starting at the bottom, tilting it into place.

STEP#5: Install the top part of InDash by PanaVise Mount with the (2) Acorn nuts.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



Lower Cover Plate



Top cover Plate



InDash Mount in place showing location



12-13-17

MOUNTING LOCATION:

Right side of radio cavity K R
(2) Locations, Lower R and Upper R

TOOLS REQUIRED:

Hook tool, Dash Tool, 7mm
socket

Phillips screwdriver, T-20 Torx

HARDWARE INCLUDED:

75001 Top W/ (2) O - 8-32 Acorn Nuts
(Radio, MiGig/Nav, Mount)

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

:PART#:751052008 **

MFG: CHRYSLER/DODGE/JEEP/VW

MODELS & YEARS:

- JEEP-Wrnglr/Ultd.(8-10)pg.1Wrangler(11-17),JK(2018)pg.2
- Liberty(8-12),CHRY-200(11-14)pg.3DODGE:Dakota(8-11)CHRY-
Sebrng&conv(7-10)pg.4
- DODGE-Avenger(8-10),Avenger(11-14)pg.5
- JEEP-GrCherokee(8-10)Cmnder(8-10)pg.6
- DODGE-GR.Caravan(8-10)(11-17),CHRY-T&C(8-10)(11-16)pg.7
- JEEP-Patriot(09-15)Compass(09-11)pg.8
- CHRY-300C(8-10),Magnum(08),Charger(8-10)pg.9
- DODGE-Durango(8-09)Aspen(8-09)pg.10
- DODGE-Challenger(9-14)pg.11Nitro(8-11)pg.11
- Caliber(9-10)(11-12)pg.11Journey.ex.R/T(09-10)pg.12
- DODGE-RAM 1500(9-12)2500-5500cons.shft.pg.12
- 2500-5500cons.shft.(10-12)pg.12
- DODGE-RAM 1500(9-11)2500-5500cons.shft.pg.12
- RAM 1500(9-11)colmn.shft.pg.12
- RAM 2500-5500(10-11)cons.shft.pg.12VW-Routan13-15,pg.12

Start here for: JEEP-Wrangler 2011-17

STEP#1: Lift out top of dash tray, with 9/32(7mm) socket, remove the (1) screw in the tray.

STEP#2: Release the clips that hold the drivers knee panel in place. (2) at the R & L of steering column. Pull to release (2) more clips at the top sides as well.Tilt down the panel to release L- prongs from the bottom and set aside.

With 9/32(7mm) socket remove the (2) exposed screws to the R & L of steering column. Tilt the steering wheel down all the way.

STEP#3: Start to remove the large bezel that goes from the drivers door, around the IP, and includes the top tray, surrounds the radio, includes the air vents, and window switches. NOTE: Prying out the climate control from the side will help release the bezel under the air vents. Clips are located (2) to the L of the drivers door air vents, (3) over IP, (2) behind dash top tray, (2) to R & L of radio, (2) in the center of air vents R&L, (4) below center air vents.

STEP#4: Remove the (2) right side radio mounting screws and place the InDash by PanaVise bottom piece over the screw holes and replace the screws.

STEP#5:Replace the bezels in reverse order. Install the top piece 75001 of the mount with the (2) 8-32 Acorn Nuts.

INSTALLATION IS NOW COMPLETE, ENJOY YOUR NEW INDASH BY PANAVISE MOUNT!

**** ADVISEMENT ****

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.



Screw Under Top Dash Tray



Knee Panel Removal



Screws Under Knee Panel



Jeep Liberty 2011 Final Install



Liberty Bottom Part Install

12-13-17



MOUNTING LOCATION:

Right side of radio cavity K R
(2) Locations, Lower R and Upper R

TOOLS REQUIRED:

Hook tool, Dash Tool, 7mm socket

Phillips screwdriver, T-20 Torx

HARDWARE INCLUDED:

75001 Top W/ (2) O - 8-32 Acorn Nuts

(Radio, MiGig/Nav, Mount)

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

:PART#:751052008 **

MFG: CHRYSLER/DODGE/JEEP/VW

MODELS & YEARS:

JEEP-Wrangler/Ultd.(8-10)pg.1Wrangler(11-17),JK(2018)pg.2
Liberty(8-12),CHRY-200(11-14)pg.3DODGE:Dakota(8-11)CHRY-
Sebring&conv(7-10)pg.4
DODGE-Avenger(8-10),Avenger(11-14)pg.5
JEEP-GrCherokee(8-10)Cmnder(8-10)pg.6
DODGE-GR.Caravan(8-10)(11-17),CHRY-T&C(8-10)(11-16)pg.7
JEEP-Patriot(09-15)Compass(09-11)pg.8
CHRY-300C(8-10),Magnum(08),Charger(8-10)pg.9
DODGE-Durango(8-09)Aspen(8-09)pg.10
DODGE-Challenger(9-14)pg.11Nitro(8-11)pg.11
Caliber(9-10)(11-12)pg.11Journey.ex.R/T(09-10)pg.12
DODGE-RAM 1500(9-12)2500-5500cons.shft.pg.12
2500-5500cons.shft.(10-12)pg.12
DODGE-RAM 1500(9-11)2500-5500cons.shft.pg.12
RAM 1500(9-11)colmn.shft.pg.12
RAM 2500-5500(10-11)cons.shft.pg.12VW-Routan13-15,pg.12

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

Start here for: JEEP-Liberty 08-12

STEP#1: Apply Brake, shift into Neutral. Lift up on back of the console bezel, pulling to release (2) clips. Continue lifting to release (2) more front clips. Lift off bezel and disconnect plug(s) and set aside.



Removal of Bezel

STEP#2: Pull off bezel that surrounds the radio/nav and includes the air vents, climate control, and switches. Start at the top of the air vents. Pry with dash tool at top to release (1) clip on each side. Note: side strips will come off with the bezel. Continue to release (2) more clips to the R & L of radio/nav. Tilt out and release last (2) clips at bottom below switches. Pull out enough to get at right side radio/nav screws.



Jeep Liberty 2011 Install

STEP#3: Remove the (2) screws with Phillips screwdriver. Install bottom piece of InDash by PanaVise Mount over screw holes and reinstall the (2) screws. Replace the bezel starting at the bottom, tilting it into place.

STEP#4: Install the top part of InDash by PanaVise Mount with the (2) Acorn nuts.

INSTALLATION IS NOW COMPLETE, ENJOY YOUR NEW INDASH BY PANAVISE MOUNT!

Start here for: Chrysler 200 2011-14

STEP#1: With Dash tool pry off bezel that surrounds the radio and includes the air vents, and switches. Start at the lower right side of the bezel. Continue to pry off bezel releasing (7) clips total. Disconnect any plugs and set bezel aside.

STEP#2: Remove the (2) screws with Phillips screwdriver. Install bottom piece of InDash by PanaVise Mount over screw holes and reinstall the (2) screws. Replace the bezel starting at the bottom, tilting it into place.

STEP#3: Install the top part of InDash by PanaVise Mount with the (2) Acorn nuts.

INSTALLATION IS NOW COMPLETE, ENJOY YOUR NEW INDASH BY PANAVISE MOUNT!



Chrysler 200 bottom in place



Chrysler 200 installed



12-13-17

MOUNTING LOCATION:

Right side of radio cavity K R
(2) Locations, Lower R and Upper R

TOOLS REQUIRED:

Hook tool, Dash Tool, 7mm socket

Phillips screwdriver, T-20 Torx

HARDWARE INCLUDED:

75001 Top W/ (2) O - 8-32 Acorn Nuts
(Radio, MiGig/Nav, Mount)

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

:PART#:751052008 **

MFG: CHRYSLER/DODGE/JEEP/VW

MODELS & YEARS:

JEEP-Wrangler/Utd.(8-10)pg.1Wrangler(11-17),JK(2018)pg.2
Liberty(8-12),CHRY-200(11-14)pg.3DODGE:Dakota(8-11)CHRY-
Sebring&conv(7-10)pg.4
DODGE-Avenger(8-10),Avenger(11-14)pg.5
JEEP-GrCherokee(8-10)Cmnder(8-10)pg.6
DODGE-GR.Caravan(8-10)(11-17),CHRY-T&C(8-10)(11-16)pg.7
JEEP-Patriot(09-15)Compass(09-11)pg.8
CHRY-300C(8-10),Magnum(08),Charger(8-10)pg.9
DODGE-Durango(8-09)Aspen(8-09)pg.10
DODGE-Challenger(9-14)pg.11Nitro(8-11)pg.11
Caliber(9-10)(11-12)pg.11Journey.ex.R/T(09-10)pg.12
DODGE-RAM 1500(9-12)2500-5500cons.shft,pg.12
2500-5500cons.shft,(10-12)pg.12
DODGE-RAM 1500(9-11)2500-5500cons.shft,pg.12
RAM 1500(9-11)colmn.shft,pg.12
RAM 2500-5500(10-11)cons.shft,pg.12VW-Routan13-15,pg.12

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

Start here for DODGE-Dakota 08-11

STEP#1: With dash tool, insert it into the lower left of radio/climate control bezel, pry and pull to release (1) clip. Repeat on right side. Pry at top of bezel to release (1) clip each side, (4) clips total. Set bezel aside

STEP#2: Remove the (2) screws with Phillips screwdriver. Install bottom piece of InDash by PanaVise Mount over screw holes and reinstall the (2) screws. Replace the bezel.

STEP#3: Install the top part of InDash by PanaVise Mount with the (2) Acorn nuts.

INSTALLATION IS NOW COMPLETE, ENJOY YOUR NEW INDASH BY PANAVISE MOUNT!

Start here for Chrysler Sebring & Conv. 07-10

STEP #1: With hook tool, remove the air vent bezel that surrounds the radio by inserting the hook tool into the bottom corner Left or Right below the emergency flasher. Pull to release (1) clip on each side. Continue up the bezel releasing (2) more clips. Pull the bezel out releasing top lugs. Disconnect clock plug. Lay bezel onto towel on console.

STEP #2: With T-20 Torx driver, remove (2) right radio screws. Install bottom piece of InDash by PanaVise Mount over screw holes and reinstall the (2) screws. Replace the bezel.

STEP#3: Install the top part of InDash by PanaVise Mount with the (2) Acorn nuts. Replace the bezels in reverse order.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



Final Install Picture, Dakota



Final Install Picture, Sebring



12-13-17

MOUNTING LOCATION:

Right side of radio cavity K R
(2) Locations, Lower R and Upper R

TOOLS REQUIRED:

Hook tool, Dash Tool, 7mm socket

Phillips screwdriver, T-20 Torx

HARDWARE INCLUDED:

75001 Top W/ (2) O - 8-32 Acorn Nuts
(Radio, MiGig/Nav, Mount)

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

:PART#:751052008 **

MFG: CHRYSLER/DODGE/JEEP/VW

MODELS & YEARS:

JEEP-Wrangler/Utd.(8-10)pg.1Wrangler(11-17),JK(2018)pg.2
Liberty(8-12),CHRY-200(11-14)pg.3DODGE:Dakota(8-11)CHRY-
Sebring&conv(7-10)pg.4
DODGE-Avenger(8-10),Avenger(11-14)pg.5
JEEP-GrCherokee(8-10)Cmnder(8-10)pg.6
DODGE-GR.Caravan(8-10)(11-17),CHRY-T&C(8-10)(11-16)pg.7
JEEP-Patriot(09-15)Compass(09-11)pg.8
CHRY-300C(8-10),Magnum(08),Charger(8-10)pg.9
DODGE-Durango(8-09)Aspen(8-09)pg.10
DODGE-Challenger(9-14)pg.11Nitro(8-11)pg.11
Caliber(9-10)(11-12)pg.11Journey.ex.RT(09-10)pg.12
DODGE-RAM 1500(9-12)2500-5500cons.shft.pg.12
2500-5500cons.shft.(10-12)pg.12
DODGE-RAM 1500(9-11)2500-5500cons.shft.pg.12
RAM 1500(9-11)colmn.shft.pg.12
RAM 2500-5500(10-11)cons.shft.pg.12VW-Routan13-15,pg.12

Start here for DODGE-Avenger 08-10

STEP#1: Apply brake, Shift into D. With dash tool, remove shifter bezel that goes up the sides of the climate control. Insert it into the top left or right of climate control and pull to release (1) clip each side. Continue by sliding bezel back and up around shifter bezel area to release (4) L-shaped clips. The cubby is included, and shifter bezel ring.

STEP#2: Insert dash tool into winged clips. Push and pry up to release (1) clip on each side. With hands pull out the bezel below the power outlet releasing (2) plastic clips. Continue up the bezel that includes the climate control and air vents with a total of (10) clips. Pull out the bezel and set it down

STEP #3: Remove the (2) T-20 torx screws on the right side of the radio. Install bottom piece of InDash by PanaVise Mount over screw holes and reinstall the (2) screws. Replace the bezels in reverse order. Install top on to bottom piece. Shifter bezel needs to be reinstalled, shifted back, and slid forward to lock the (2) clips by the climate control in place. Install the top part of InDash by PanaVise Mount with the (2) Acorn nuts.

INSTALLATION IS NOW COMPLETE, ENJOY YOUR NEW INDASH BY PANAVISE MOUNT!

Start here for DODGE-Avenger 11-14

STEP#1: Insert the dash tool into the crack between the top dash bezel beside the air vents and twist to separate the top. Repeat on the other side. Continue to remove the top bezel by lifting up and pull towards you releasing (7) clips.

STEP#2: With your hands, pull on the top of the airvent, radio, switch bezel, releasing (6) clips. you may need to use dash tool to the R & L side of the radio.

STEP#3: With T25 Torx Driver, remove the (2) right side radio screws. Place the bottom piece of the InDash by PanaVise Mount over the screw holes and replace the screws.

STEP#4: Reinstall the radio-airvent bezel, and dash top bezel. Install the top part of InDash by PanaVise Mount with the (2) Acorn nuts using 5/16" wrench.

INSTALLATION IS NOW COMPLETE, ENJOY YOUR NEW INDASH BY PANAVISE MOUNT!

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.



Finished Install of
08-10 Avenger



Finished Install of
11-12 Avenger

12-13-17



INDASH by PANAVISE®

I-751052008

Page 6 of 12

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

:PART#:751052008 **

MFG: CHRYSLER/DODGE/JEEP/VW

MODELS & YEARS:

JEEP-Wrnglr/Utd.(8-10)pg.1Wrangler(11-17),JK(2018)pg.2
Liberty(8-12),CHRY-200(11-14)pg.3DODGE:Dakota(8-11)CHRY-
Sebrng&conv(7-10)pg.4
DODGE-Avenger(8-10),Avenger(11-14)pg.5
JEEP-GrCherokee(8-10)Cmnder(8-10)pg.6
DODGE-GR.Caravan(8-10)(11-17),CHRY-T&C(8-10)(11-16)pg.7
JEEP-Patriot(09-15)Compass(09-11)pg.8
CHRY-300C(8-10),Magnm(08),Charger(8-10)pg.9
DODGE-Durango(8-09)Aspen(8-09)pg.10
DODGE-Challenger(9-14)pg.11Nitro(8-11)pg.11
Caliber(9-10)(11-12)pg.11,Journey.ex.R/T(09-10)pg.12
DODGE-RAM 1500(9-12)2500-5500cons.shft.pg.12
2500-5500cons.shft.(10-12)pg.12
DODGE-RAM 1500(9-11)2500-5500cons.shft.pg.12
RAM 1500(9-11)colmn.shft.pg.12
RAM 2500-5500(10-11)cons.shft.pg.12VW-Routan13-15,pg.12

MOUNTING LOCATION:

Right side of radio cavity K R
(2) Locations, Lower R and Upper R

TOOLS REQUIRED:

Hook tool, Dash Tool, 7mm
socket

Phillips screwdriver, T-20 Torx

HARDWARE INCLUDED:

75001 Top W/ (2) O - 8-32 Acorn Nuts

(Radio, MiGig/Nav, Mount)

Start here for: JEEP-Grand Cherokee 08-10

STEP#1: With dash tool, lift up on the shifter bezel trim ring, releasing (4) ratcheting clips. Pry up the shifter bezel releasing (4) clips and set aside.

STEP#2: With hook toll release the bezel that surrounds the radio includes the climate control and lower switches, and the air vents as well. Begin by inserting the hook tool in the lower left corner of the bezel using the holes at the bottom of the bezel. Work your way up to the top of the bezel and to the outside of the center air vents to release (10) total clips.

STEP#3: Remove the (2) screws on the right side of the radio. Install bottom piece of InDash by PanaVise Mount over screw holes and reinstall the (2) screws. Replace the bezels in reverse order.

STEP#4: Install the top part of InDash by PanaVise Mount with the (2) Acorn nuts.

INSTALLATION IS NOW COMPLETE, ENJOY YOUR NEW INDASH BY PANAVISE MOUNT!

Start here for: JEEP-Commander 08-10

STEP#1: With dash tool, lift up on the shifter bezel trim ring, releasing (4) ratcheting clips. Pry up the shifter bezel releasing (4) clips and set aside.

STEP#2: With hook toll release the bezel that surrounds the radio includes the climate control and lower switches. Begin by inserting the hook tool in the lower left corner of the bezel using the holes at the bottom of the bezel. Work your way up to the top of the bezel (7) total clips.

STEP#3: Remove the (2) screws on the right side of the radio. Install bottom piece of InDash by PanaVise Mount over screw holes and reinstall the (2) screws. Replace the bezels in reverse order.

STEP#4: Install the top part of InDash by PanaVise Mount with the (2) Acorn nuts.

INSTALLATION IS NOW COMPLETE, ENJOY YOUR NEW INDASH BY PANAVISE MOUNT!

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.



Final Install Picture
Jeep Grand Cherokee



Final Install Picture,
Jeep Commander



12-13-17

MOUNTING LOCATION:

Right side of radio cavity K R
(2) Locations, Lower R and Upper R

TOOLS REQUIRED:

Hook tool, Dash Tool, 7mm socket

Phillips screwdriver, T-20 Torx

HARDWARE INCLUDED:

75001 Top W/ (2) O - 8-32 Acorn Nuts

(Radio, MiGig/Nav Mount)

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

:PART#:751052008 **

MFG: CHRYSLER/DODGE/JEEP/VW

MODELS & YEARS:

JEEP-Wrangler/Utd.(8-10)pg.1Wrangler(11-17),JK(2018)pg.2
Liberty(8-12),CHRY-200(11-14)pg.3DODGE:Dakota(8-11)CHRY-
Sebrng&conv(7-10)pg.4
DODGE-Avenger(8-10),Avenger(11-14)pg.5
JEEP-GrCherokee(8-10)Cmnder(8-10)pg.6
DODGE-GR.Caravan(8-10)(11-17),CHRY-T&C(8-10)(11-16)pg.7
JEEP-Patriot(09-15)Compass(09-11)pg.8
CHRY-300C(8-10),Magnum(08),Charger(8-10)pg.9
DODGE-Durango(8-09)Aspen(8-09)pg.10
DODGE-Challenger(9-14)pg.11Nitro(8-11)pg.11
Caliber(9-10)(11-12)pg.11Journey.ex.R/T(09-10)pg.12
DODGE-RAM 1500(9-12)2500-5500cons.shft,pg.12
2500-5500cons.shft,(10-12)pg.12
DODGE-RAM 1500(9-11)2500-5500cons.shft,pg.12
RAM 1500(9-11)colmn.shft,pg.12
RAM 2500-5500(10-11)cons.shft,pg.12VW-Routan13-15,pg.12

Start Here for Dodge-Grand Caravan & Chrysler T&C (2008-2010):

STEP#1: With hook Tool open (2) small covers under the overhang of the radio. (Use the inside cracks to pry out).

STEP#2: With Phillips screwdriver remove the (2) screws under covers. Lift up on the long cover that goes from the top of the radio to the defroster bezel. There are (2) clips, (1) on each side of cover. Do not take cover off all the way. Prop it up with something.

STEP#3: Remove the (2) Phillips screws above the radio and set aside. Pull on the top of the radio / climate control / cubby bezel enough to get at the (2) Phillips screws on the right side of the radio. Remove the (2) screws with Phillips screwdriver. Install bottom piece of InDash by PanaVise Mount over screw holes and reinstall the (2) screws. Replace the bezel.

STEP#3: Install the top part of InDash by PanaVise Mount with the (2) Acorn nuts. Replace the bezels in reverse order.

INSTALLATION IS NOW COMPLETE, ENJOY YOUR NEW INDASH BY PANAVISE MOUNT!

Start Here for Dodge-Grand Caravan & Chrysler T&C (2011-17/14)&VW Routan 2010-2011:

STEP#1: With Dash Tool pry the top of the bezel surrounding the radio out slightly. With Hook Tool pull out the bezel. (2) clips at the sides of the radio.

STEP#2: With 9/32 socket, remove the (2) screws on the right side of the radio. Place the InDash by PanaVise Mount over the holes and replace the screws.

STEP#3: Replace the radio bezel, and install the top part (75001) of the mount with the 5/16" socket.

INSTALLATION IS NOW COMPLETE, ENJOY YOUR NEW INDASH BY PANAVISE MOUNT!

**** ADVISEMENT ****
Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.



Cover Removal and screws under cover



Mount installed on 08-10



Mount installed on 2011

12-13-17



MOUNTING LOCATION:

Right side of radio cavity K R
(2) Locations, Lower R and Upper R

TOOLS REQUIRED:

Hook tool, Dash Tool, 7mm socket

Phillips screwdriver, T-20 Torx

HARDWARE INCLUDED:

75001 Top W/ (2) O - 8-32 Acorn Nuts
(Radio, MiGig/Nav Mount)

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

:PART#:751052008 **

MFG: CHRYSLER/DODGE/JEEP/VW

MODELS & YEARS:

JEEP-Wrangler/Utd.(8-10)pg.1Wrangler(11-17),JK(2018)pg.2
Liberty(8-12),CHRY-200(11-14)pg.3DODGE:Dakota(8-11)CHRY-Sebrng&conv(7-10)pg.4
DODGE-Avenger(8-10),Avenger(11-14)pg.5
JEEP-GrCherokee(8-10)Cmder(8-10)pg.6
DODGE-GR.Caravan(8-10)(11-17),CHRY-T&C(8-10)(11-16)pg.7
JEEP-Patriot(09-15)Compass(09-11)pg.8
CHRY-300C(8-10),Magna(08),Charger(8-10)pg.9
DODGE-Durango(8-09)Aspen(8-09)pg.10
DODGE-Challenger(9-14)pg.11Nitro(8-11)pg.11
Caliber(9-10)(11-12)pg.11Journey.ex.R/T(09-10)pg.12
DODGE-RAM1500(9-12)2500-5500cons.shft.pg.12
2500-5500cons.shft.(10-12)pg.12
DODGE-RAM1500(9-11)2500-5500cons.shft.pg.12
RAM1500(9-11)colmn.shft.pg.12
RAM2500-5500(10-11)cons.shft.pg.12VW-Routan13-15,pg.12

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

Start Here for Jeep- Patriot 09-15 & Compass: 09-11

STEP#1: With Dash tool, begin to remove the bezel that surrounds the radio and includes the climate control and air vents. Start at the bottom corners releasing 1 clip each side. Continue up the bezel releasing (1) clip on each side of the radio, (1) clip on each side of the air vents, and (3) plastic clips above the air vents

STEP#2: Remove the (2) Phillips screws on the right side of the radio and install the bottom part of the InDash by PanaVise Mount, tighten the (2) screws making sure the mount is pressed flush up against the radio.

STEP#3: Install the Radio, air vent , climate control bezel.

NOTE: If the bezel does not fit into the side by the InDash Mount. Pull off the bezel and take the clip to the right of where the mount is and cut away part of the inside of the tab that hits the InDash Mount so the bezel can fit back in place.



Install Picture of bottom part of mount on radio

INSTALLATION IS NOW COMPLETE, ENJOY YOUR NEW INDASH BY PANAVISE MOUNT!



Install Picture of InDash in place in new Jeep Patriot and Compass



12-13-17

INDASH by PANAVISE®

I-751052008

Page 9 of 12

MOUNTING LOCATION:

Right side of radio cavity K R
(2) Locations, Lower R and Upper R

TOOLS REQUIRED:

Hook tool, Dash tool
Phillips screwdriver

HARDWARE INCLUDED:

75001 Top W/ (2) O - 8-32 Acorn Nuts
(Radio, MiGig/Nav Mount)

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

:PART#:751052008 **

MFG: CHRYSLER/DODGE/JEEP/VW

MODELS & YEARS:

JEEP-Wrnlgr/Utd.(8-10)pg.1Wrangler(11-17),JK(2018)pg.2
Liberty(8-12),CHRY-200(11-14)pg.3DODGE:Dakota(8-11)CHRY-Sebrng&conv(7-10)pg.4
DODGE-Avenger(8-10),Avenger(11-14)pg.5
JEEP-GrCherokee(8-10)Cmnder(8-10)pg.6
DODGE-GR.Caravan(8-10)(11-17),CHRY-T&C(8-10)(11-16)pg.7
JEEP-Patriot(09-15)Compass(09-11)pg.8
CHRY-300C(8-10),Magnum(08),Charger(8-10)pg.9
DODGE-Durango(8-09)Aspen(8-09)pg.10
DODGE-Challenger(9-14)pg.11Nitro(8-11)pg.11
Caliber(9-10)(11-12)pg.11Journey.ex.R/T(09-10)pg.12
DODGE-RAM 1500(9-12)2500-5500cons.shft.pg.12
2500-5500cons.shft.(10-12)pg.12
DODGE-RAM 1500(9-11)2500-5500cons.shft.pg.12
RAM 1500(9-11)colmn.shft.pg.12
RAM2500-5500(10-11)cons.shft.pg.12VW-Routan13-15,pg.12

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

Start Here for Chrysler 300C 08-10,Dodge Magnum 2008 & Charger 08-10

STEP#1: With hook tool remove the center bezel that surrounds the radio/nav, and includes the climate control and air vents. Begin to release the clips up at the top corner by the air vents. Pull to release (1) clip and then (2) more clips at the top of the radio bezel. There are (2) more clips located about half way down the side of the bezel, and (2) more clips at the bottom sides of the climate control. Pull out the bezel and set it off to the left enough to get at the Radio/Nav screws. You may have to release (2) clips at the top of the ash tray bezel while pulling off the Radio/Nav bezel.

STEP#2: Remove the (2) Phillips screws on the right side of the radio and set aside. Pull on the top of the radio / climate control / cubby bezel enough to get at the (2) Phillips screws on the right side of the radio. Remove the (2) screws with Phillips screwdriver. Install bottom piece of InDash by PanaVise Mount over screw holes and reinstall the (2) screws. Replace the bezel.

STEP#3: Install the top part of InDash by PanaVise Mount with the (2) Acorn nuts. Replace the bezels in reverse order.



Bezel removed picture

INSTALLATION IS NOW COMPLETE, ENJOY YOUR NEW INDASH BY PANAVISE MOUNT!



Install Picture of InDash in place
On 300c and Magnum



12-13-17

There may be recent updates to this Instruction Sheet, please visit our website or contact PanaVise Products, Inc. for the latest revision as well as for the most complete up-to-date PanaVise InDash Applications List: 7540 Colbert Dr., Reno, NV, Phone: 800.759.7535, 775.850.2900, Fax: 800.395.8002, www.panavise.com. © 2016 PanaVise Products, Inc.

INDASH by PANAVISE®

I-751052008

Page 10 of 12

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

:PART#:751052008 **

MFG: CHRYSLER/DODGE/JEEP/VW

MODELS & YEARS:

JEEP-Wrangler/Ultid.(8-10)pg.1Wrangler(11-17),JK(2018)pg.2
Liberty(8-12),CHRY-200(11-14)pg.3DODGE:Dakota(8-11)CHRY-
Sebrng&conv(7-10)pg.4
DODGE-Avenger(8-10),Avenger(11-14)pg.5
JEEP-GrCherokee(8-10)Cmnder(8-10)pg.6
DODGE-GR.Caravan(8-10)(11-17),CHRY-T&C(8-10)(11-16)pg.7
JEEP-Patriot(09-15)Compass(09-11)pg.8
CHRY-300C(8-10),Magnm(08),Charger(8-10)pg.9
DODGE-Durango(8-09)Aspen(8-09)pg.10
DODGE-Challenger(9-14)pg.11Nitro(8-11)pg.11
Caliber(9-10)(11-12)pg.11Journey.ex.R/T(09-10)pg.12
DODGE-RAM 1500(9-12)2500-5500cons.shft,pg.12
2500-5500cons.shft,(10-12)pg.12
DODGE-RAM 1500(9-11)2500-5500cons.shft,pg.12
RAM 1500(9-11)colmn.shft,pg.12
RAM 2500-5500(10-11)cons.shft,pg.12VW-Routan13-15,pg.12

MOUNTING LOCATION:

Right side of climate control C R

TOOLS REQUIRED:

Hook tool, Dash tool

9/32" Socket and ratchet/ Driver

Phillips head screwdriver

HARDWARE INCLUDED:

(1) A - #8X9/16 Needle Point Screw

75001 Top W/ (2) O - 8-32 Acorn Nuts

(Radio, MiGig/Nav Mount)

Start here for Durango 08-09 & Aspen 08-09

STEP #1: With hook tool remove the cover below the seat heaters and power outlet. With 9/32"(7mm) socket and ratchet remove the (2) screws located below the power outlet, seat heater , small cubby box. With your hands start to pull out the bezel that surrounds the radio, and includes the climate control, air vents, and power outlets. Tilt it up from the bottom releasing a total of (6) clips. These clips are located (2) to the L & R of the climate control, (2) to the L & R of the Radio, and (2) to the L & R of the air vents. Tilt the bezel out and down to release the lip at the top of the bezel.

STEP #2: Move the radio / climate control / cubby bezel aside enough to get at the (2) Phillips screws on the right side of the radio. Remove the (2) screws with Phillips screwdriver. Install bottom piece of InDash by PanaVise Mount over screw holes and reinstall the (2) screws. Replace the bezel.

STEP#3: Install the top part of InDash by PanaVise Mount with the (2) Acorn nuts. Replace the bezels in reverse order.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.



Screws below bezel



Bottom part in place without Nav



InDash installed showing location with MyGig /Nav on Aspen



12-13-17

IN DASH by PANAVISE®

751052008

Page 11 of 12

MOUNTING LOCATION:

Right Side of Radio Cavity K R

TOOLS REQUIRED:

Dash Tool, Hook Tool

Phillips Screwdriver, T-20 Torx

HARDWARE INCLUDED:

75001 Top W/ (2) O - 8-32 Acorn Nuts

(Radio, MiGig/Nav Mount)

INSTALLATION INSTRUCTIONS CELL PHONE & MEDIA MOUNT :PART#:751052008 **

MFG: CHRYSLER/DODGE/JEEP/VW

MODELS & YEARS:

JEEP-Wrnlr/Ultd.(8-10)pg.1Wrangler(11-17),JK(2018)pg.2
Liberty(8-12),CHRY-200(11-14)pg.3DODGE:Dakota(8-11)CHRY-
Sebrng&conv(7-10)pg.4

DODGE-Avenger(8-10),Avenger(11-14)pg.5

JEEP-GrCherokee(8-10)Cmnder(8-10)pg.6

DODGE-GR.Caravan(8-10)(11-17),CHRY-T&C(8-10)(11-16)pg.7

JEEP-Patriot(09-15)Compass(09-11)pg.8

CHRY-300C(8-10),Magnum(08),Charger(8-10)pg.9

DODGE-Durango(8-09)Aspen(8-09)pg.10

DODGE-Challenger(9-14)pg.11Nitro(8-11)pg.11

Caliber(9-10)(11-12)pg.11Journey.ex.R/T(09-10)pg.12

DODGE-RAM 1500(9-12)2500-5500cons.shft.pg.12

2500-5500cons.shft.(10-12)pg.12

DODGE-RAM 1500(9-11)2500-5500cons.shft.pg.12

RAM 1500(9-11)colmn.shft.pg.12

RAM 1500(9-11)colmn.shft.pg.12VW-Routan13-15,pg.12

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.



Install Picture of InDash on Challenger



Install Picture of InDash on Dodge Nitro



Install Picture of InDash on 09 Dodge Caliber

12-13-17

Start here for DODGE Challenger (R-L) 09-13:

STEP #1: With dash tool remove the bezel that surrounds the radio, and includes the climate control and switches. Releasing clips. Disconnect plugs if necessary and set aside.

STEP #2: Remove the (2) screws to the right side of the radio. Install bottom piece of InDash by PanaVise Mount over screw holes and reinstall the (2) screws. Replace the bezel.

STEP#3: Install the top part of InDash by PanaVise Mount with the (2) Acorn nuts. Replace the bezels in reverse order. Install the top part of InDash by PanaVise Mount with the (2) Acorn nuts.

Start here for DODGE Caliber Only (R) 09-10:

STEP #1: Shift vehicle into DorL. With Dash Tool remove the bezel that surrounds the shifter releasing (4) clips. With Dash Tool remove the bezel that surrounds the Radio/Climate Control & Air Vents. Start at the bottom to release all the clips.

STEP #2: With Phillips screwdriver remove (2) right side radio screws. Place the InDash by PanaVise Mount over the screw holes and replace the screw. Replace the bezels in reverse order. Install the top part of InDash by PanaVise Mount with the (2) Acorn nuts.

Start here for DODGE Caliber Only 11-12:

STEP #1: Shift vehicle into DorL. With Dash Tool remove the bezel that surrounds the shifter releasing (4) clips. With Hook Tool remove the switch bezel and disconnect plugs. with Phillips screwdriver remove the (2) screws below climate control. Open the top of dash storage bin and remove the (1) screw. Pull from the bottom to release the bezel that surrounds the Radio/Climate Control & Air Vents. Start at the bottom to release all clips.

STEP #2: With Phillips screwdriver remove (2) right side radio screws. Place the InDash by PanaVise Mount over the screw holes and replace the screw. Replace the bezels in reverse order. Install the top part of InDash by PanaVise Mount with the (2) Acorn nuts.



INDASH by PANAVISE®

751052008

Page 12 of 12

MOUNTING LOCATION:

Right Side of Radio Cavity K R

TOOLS REQUIRED:

Dash Tool, Hook Tool

Phillips Screwdriver, T-20 Torx

HARDWARE INCLUDED:

75001 Top W/ (2) O - 8-32 Acorn Nuts

(Radio, MiGig/Nav Mount)

INSTALLATION INSTRUCTIONS

:PART#:751052008 **

MFG: CHRYSLER/DODGE/JEEP/VW

MODELS & YEARS:

JEEP-Wrnlr/Ultd.(8-10)pg.1Wrangler(11-17),JK(2018)pg.2
Liberty(8-12),CHRY-200(11-14)pg.3DODGE:Dakota(8-11)CHRY-
Sebrng&conv(7-10)pg.4
DODGE-Avenger(8-10),Avenger(11-14)pg.5
JEEP-GrCherokee(8-10)Cmnder(8-10)pg.6
DODGE-GR.Caravan(8-10)(11-17),CHRY-T&C(8-10)(11-16)pg.7
JEEP-Patriot(09-15)Compass(09-11)pg.8
CHRY-300C(8-10),Magnum(08),Charger(8-10)pg.9
DODGE-Durango(8-09)Aspen(8-09)pg.10
DODGE-Challenger(9-14)pg.11Nitro(8-11)pg.11
Caliber(9-10)(11-12)pg.11Journey.ex.R/T(09-10)pg.12
DODGE-RAM 1500(9-12)2500-5500cons.shft.pg.12
2500-5500cons.shft.(10-12)pg.12
DODGE-RAM 1500(9-11)2500-5500cons.shft.pg.12
RAM 1500(9-11)colmn.shft.pg.12
RAM 2500-5500(10-11)cons.shft.pg.12VW-Routan13-15,pg.12

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

Start here for DODGE Journey 09-10 (Except R/T Model TBD):

STEP #1: With Dash Tool remove the bezel that surrounds the Radio/Climate Control & Air Vents. Start at the bottom to release all the clips.

STEP #2: With T-15 Torx driver remove (2) right side radio screws. Place the InDash by PanaVise Mount over the screw holes and replace the screw. Replace the bezels in reverse order. Install the top part of InDash by PanaVise Mount with the (2) Acorn nuts.

Start here for DODGE RAM 1500 09-11 & (2500-5500) with CONSOLE Shift Only:

STEP# 1: Remove upper&lower center bezel tray liners. Remove (2) T-20 screws under each.

STEP# 2. Using a dash tool, release the clips that secure the power outlet trim bezel to the center bezel.

STEP# 3. Release the five center bezel clips. (2) on top of bezel, (1) by the power outlet, (2) at the bottom of the bezel.

STEP# 4. Using a dash tool, release the clips that secure the trim ring to the console.

STEP# 5. Using a dash tool, release the clips that secure the shifter bezel to the floor console. If needed open small cover door to the drivers side under consle and use dash tool to push up to release console top.

STEP# 6. Using a dash tool, release the clips that secure the instrument panel center bezel to the instrument panel. There are (12) total clips holding bezel assembly in place.

STEP# 7. Disconnect connector plugs if necessary(4), remove center bezel from the vehicle.

STEP #8: With T-20 Torx driver remove (2) right side radio screws. Place the InDash by PanaVise Mount over the screw holes and replace the screw. Replace the bezels.

Start here for DODGE RAM 1500 09-11 with COLUMN Shift Only:

STEP# 1: Remove upper center tray liners. Remove (2) T-20 Torx screws under liner.

STEP# 2: Using a dash tool, release the clips that secure the instrument panel center bezel to the instrument panel. There are (12) total clips holding bezel assembly in place.

STEP# 3: Disconnect connector plugs if necessary (4) and remove the center bezel.

STEP# 4: With T-20 Torx driver remove (2) right side radio screws. Place the InDash by PanaVise Mount over the screw holes and replace the screw.

STEP# 5: Replace the bezels in reverse order.

Start here DODGE RAM 2500-5500 10-11(For Console Model, see 1500 Console Inst.)

STEP# 1: Remove upper center tray liners. Remove (2) T-20 Torx screws under liner.

STEP# 2: With hook tool remove the cover surrounding the 115V power outlet. Remove torx screw and set aside.

STEP# 2: Using a dash tool, release the clips that secure the instrument panel. There are (14) total clips holding bezel assembly in place.

STEP# 3: Disconnect connector plugs if necessary (4) and remove the center bezel.

STEP# 4: With T-20 Torx driver remove (2) right side radio screws. Place the InDash by PanaVise Mount over the screw holes and replace the screw.

STEP# 5: Install top piece of Mount with 5/16 socket. Replace the bezels in reverse order.



Install Picture of InDash on Dodge Journey



Install Picture of InDash of Dodge Ram 1500

12-13-17

