

# ASSEMBLING THE CLAW

Assemble the claw as shown in the diagram below.  
The screws should self-tap into the acrylic.

Take care when screwing in the servo screws as you can damage the wires!

**Note:** Ensure the servo is almost at its maximum travel, counter clockwise, when attaching the claws.

