

#### Note the following details of the code protection feature on Microchip devices:

- Microchip products meet the specification contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is one of the most secure families of its kind on the market today, when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of these methods, to our knowledge, require using the Microchip products in a manner outside the operating specifications contained in Microchip's Data Sheets. Most likely, the person doing so is engaged in theft of intellectual property.
- Microchip is willing to work with the customer who is concerned about the integrity of their code.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not mean that we are guaranteeing the product as "unbreakable."

Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our products. Attempts to break Microchip's code protection feature may be a violation of the Digital Millennium Copyright Act. If such acts allow unauthorized access to your software or other copyrighted work, you may have a right to sue for relief under that Act.

Information contained in this publication regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION, INCLUDING BUT NOT LIMITED TO ITS CONDITION. QUALITY, PERFORMANCE, MERCHANTABILITY OR FITNESS FOR PURPOSE. Microchip disclaims all liability arising from this information and its use. Use of Microchip devices in life support and/or safety applications is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights.

# QUALITY MANAGEMENT SYSTEM CERTIFIED BY DNV ISO/TS 16949:2002

#### Trademarks

The Microchip name and logo, the Microchip logo, dsPIC, KEELOQ, KEELOQ logo, MPLAB, PIC, PICmicro, PICSTART, PIC<sup>32</sup> logo, rfPIC and UNI/O are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

FilterLab, Hampshire, HI-TECH C, Linear Active Thermistor, MXDEV, MXLAB, SEEVAL and The Embedded Control Solutions Company are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Analog-for-the-Digital Age, Application Maestro, CodeGuard, dsPICDEM, dsPICDEM.net, dsPICworks, dsSPEAK, ECAN, ECONOMONITOR, FanSense, HI-TIDE, In-Circuit Serial Programming, ICSP, Mindi, MiWi, MPASM, MPLAB Certified logo, MPLIB, MPLINK, mTouch, Octopus, Omniscient Code Generation, PICC, PICC-18, PICDEM, PICDEM.net, PICkit, PICtail, REAL ICE, rfLAB, Select Mode, Total Endurance, TSHARC, UniWinDriver, WiperLock and ZENA are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

 $\ensuremath{\mathsf{SQTP}}$  is a service mark of Microchip Technology Incorporated in the U.S.A.

All other trademarks mentioned herein are property of their respective companies.

© 2010, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.



#### ISBN: 978-1-60932-069-0

Microchip received ISO/TS-16949:2002 certification for its worldwide headquarters, design and water fabrication facilities in Chandler and Tempe, Arizona; Gresham, Oregon and design centers in California and India. The Company's quality system processes and procedures are for its PIC® MCUs and dsPIC® DSCs, KEELOQ® code hopping devices, Serial EEPROMs, microperipherals, nonvolatile memory and analog products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001:2000 certified.



#### INTRODUCTION

Transition sockets are products that allow header boards (for next generation in-circuit emulators or in-circuit debuggers) or device adapters (for the MPLAB ICE 2000 in-circuit emulator) to interface to sockets on target applications.

Typically, header boards or device adapters have connectors that match development cycle device formats, such as DIP or PLCC. However, target sockets will match compact production device formats, such as SOIC, SSOP, QFP, or QFN. The solution is transition sockets. A transition socket is specifically designed to provide compatibility between two differing types of IC package formats.

Transition sockets are typically composed of two parts: the adapter socket and the adapter header. The adapter socket is designed to plug into the header board or device adapter on one side, and the adapter header on the other. The adapter header is then soldered down to the target application.

#### WHY SHOULD I USE TRANSITION SOCKETS IN MY PRODUCT DESIGN?

There are two very significant advantages to using transition sockets:

- 1. Shorter product development cycle
- 2. Reduced expense in the design, layout and prototype testing

A typical product design cycle has two important phases: the prototype design phase and the production design phase. Traditionally, these phases were different simply because the prototype used a microcontroller with a different package type. However, with the availability of the transition sockets, the prototype design can be identical to the production design because a transition socket can be used to bridge microcontroller package differences.

# WHAT TRANSITION SOCKETS ARE CURRENTLY AVAILABLE?

Microchip Technology currently offers the transition sockets listed in the "Table of Contents" following this introductory section.

Use the on-line Development Tools Selector (DTS) to find the transition sockets available for each header board or for each device adapter. For more on header boards or device adapters, see:

- Header Board Specification (DS51292)
- MPLAB<sup>®</sup> ICE 2000 Processor Module and Device Adapter Specification (DS51140)
- MPLAB<sup>®</sup> ICE 4000 Processor Module and Device Adapter Specification (DS51298)

Please see the Microchip web site (www.microchip.com) for the DTS and most current version of all documents.

#### HOW CAN I OBTAIN MAXIMUM BENEFIT FROM THE USE OF TRANSITION SOCKETS?

Attention to component placement should be considered to provide adequate clearance for the transition socket interface to the PCB footprint. This is especially true for any tall components such as connector headers, radial components or voltage regulators. Refer to the transition socket mechanical drawings for dimensions.

#### TRANSITION SOCKET APPLICATIONS – COMMENTS AND SUGGESTIONS

Attention to component placement should be considered in mating the adapter sockets to the SOIC/SSOP headers.

The placement of vias around the Surface Mount Technology (SMT) layout area should be examined. Vias immediately adjacent to the end of a SMT pad may inadvertently come into contact with the header leads. Vias should be placed along the center line of the SMT pad to lessen the chance of pin-to-pin shorts while soldering.

Care should be taken when soldering some transition sockets to target boards. See the releated section for specific instructions.

For information on packaging dimensions, please refer to the *Packaging Specification* (DS00049).

## GLOSSARY

Terms used in this document: **DFN** – Dual Flat No lead **DIP** – Dual In-line Package **MQFP** – Metric Quad Flat Pack **PDIP** – Plastic Dual In-line Package **PLCC** – Plastic Leaded Chip Carrier **QFN** – Quad Flat No lead **QFP** – Quad Flat Pack **SOIC** – Small Outline IC

**SOT** – Small Outline Transistor

SSOP - Shrink Small Outline Package

TQFP - Thin Quad Flat Pack



# **Table of Contents**

## **Current Sockets**

SOIC Transition Socket	
XLT08SO-1	
8-lead DIP to 8-lead SOIC	9
XLT08SN-1	
8-lead DIP to 8-lead SOIC (Narrow)	
XLT14SO-1	
14-lead DIP to 14-lead SOIC	
XLT18SO-1	
18-lead DIP to 18-lead SOIC	
XLT20SO1-1	
20-lead DIP to 20-lead SOIC	
XLT28SO-1	10
28-lead DIP to 28-lead SOIC	
SSOP Transition Socket	
XLT14SS-1	
14-lead DIP to 14-lead SSOP	
XLT20SS-1	
18-lead DIP to 20-lead SSOP	14
XLT20SS1-1	
20-lead DIP to 20-lead SSOP	14
XLT28SS-1	
28-lead DIP to 28-lead SSOP	15
XLT28SS2-1	
28-lead DIP to 28-lead SSOP (PIC16X55/57)	15
PLCC Transition Socket	
XLT44L2	

# 44-lead PLCC (0.050") 16 QFP Transition Socket 18 XLT44PT3 18 44-lead QFP (0.8 mm) 18 XLT64PT5, XLT80PT3 18 64/80-lead QFP (0.5 mm) 18 XLT80PT2 19 SOT/DFN/QFN Transition Sockets 19 XLT06SOT 14-lead DIP to 6-lead SOT-23 22 XLT08DFN2 22 14-lead DIP to 8-lead DFN 22

XLT16QFN1, XLT28QFN3, XLT28QFN4, XLT44QFN2, XLT44QFN3, XLT44QFN4, XLT44QFN5	
Multi-lead DIP to Multi-lead QFN, Top View	23
Multi-lead DIP to Multi-lead QFN, Side View	23
Multi-lead DIP to Multi-lead QFN Cables	23
XLT20QFN-1	
20-lead DIP Adapter Socket	24
20-lead QFN Header (Surface Foot)	24
XLT20QFN-1 Soldering Suggestions	25

## **Discontinued Sockets**

PDIP Transition Socket	
<b>XLT28XP (Discontinued)</b> 28-lead DIP 0.300-inch Male to 0.600-inch Female	
SOIC Transition Socket	_
XLT08SO (Discontinued – see XLT08SO-1 or XLT08SN-1)	
8-lead DIP to 0.050-inch Adapter Socket	
8-lead SOIC Header	
XLT14SO (Discontinued – see XLT14SO-1) 14-lead DIP to 0.050-inch Adapter Socket	20
14-lead SOIC Header	
XLT18SO (Discontinued – see XLT18SO-1)	20
18-lead DIP to 0.050-inch Adapter Socket	
18-lead SOIC Header	
XLT20SO1 (Discontinued – see XLT20SO1-1)	
20-lead DIP to 0.050-inch Adapter Socket	
XLT28SO (Discontinued – see XLT28SO-1)	
28-lead DIP to 0.050-inch Adapter Socket	
28-lead SOIC Header	
SSOP Transition Socket	
XLT14SS (Discontinued – see XLT14SS-1)	
14-lead DIP to 0.8 mm Adapter Socket	
14-lead SSOP Header	
XLT20SS (Discontinued – see XLT20SS-1)	
18-lead DIP to 0.8 mm Adapter Socket	
20-lead SSOP Header	
20-lead DIP to 0.8 mm Adapter Socket	31
20-lead SSOP Header	
XLT28SS (Discontinued – see XLT28SS-1)	
XLT28SS2 (Discontinued – see XLT28SS2-1)	
28-lead DIP to 0.8 mm Adapter Socket	
28-lead SSOP Header	
PLCC Transition Socket	
XLT68L1, XLT84L1 (Discontinued)	0.4
68/84-lead Adapter Socket	
XLT44PT (Discontinued – see XLT44PT3) 44-lead QFP to 0.8 mm Adapter Socket	35
XLT64PT1 (Discontinued)	
XLT64PT2 (Discontinued – see XLT64PT5)	
XLT80PT (Discontinued – see XLT80PT3)	
64/80-lead QFP to 0.5 mm Adapter Socket	
XLT64PT3 (Discontinued – see XLT64PT5)	
64-lead QFP to 0.8mm Adapter Socket	
XLT64PT4 (Discontinued – see XLT64PT5) 64-lead QFP (0.8 mm)	22
04-16au QI F (V.0 11111)	

#### SOT/DFN/QFN Transition Sockets

XLT08DFN (Discontinued – see XLT08DFN2)	
8-lead DIP to 0.025-inch Adapter Socket	
XLT28QFN (Discontinued – see XLT28QFN4)	
28-lead DIP to 0.025-inch Adapter Socket	
XLT28QFN2 (Discontinued – see XLT28QFN3)	
18-lead DIP to 0.025-inch Adapter Socket	40
XLT44QFN (Discontinued – see XLT44QFN2)	
40-lead DIP to 0.025-inch Adapter Socket	
44-lead QFN Header	40


# **CURRENT SOCKETS**

The transition sockets in this section are currently available from Microchip.

## SOIC TRANSITION SOCKET

An SOIC transition socket and associated hardware is shown in Figure 1.

#### FIGURE 1: SOIC TRANSITION SOCKET



There are two components of the SOIC transition socket::

- 1. Adapter socket that connects to the DIP device adapter
- 2. SOIC header that is to be soldered down to the target application


Microchip offers the following SOIC transition sockets:

- XLT08SO-1: One 8-lead DIP adapter socket and one 8-lead SOIC header (5.28mm body size)
- XLT08SN-1: One 8-lead DIP adapter socket and one 8-lead SOIC header (3.9mm body size)
- XLT14SO-1: One 14-lead DIP adapter socket and one 14-lead SOIC header
- XLT18SO-1: One 18-lead DIP adapter socket and one 18-lead SOIC header
- XLT20SO1-1: One 20-lead DIP adapter socket and one 20-lead SOIC header
- XLT28SO-1: One 28-lead DIP adapter socket and one 28-lead SOIC header


See the drawings in this section for layout dimensions.

#### XLT08SO-1

8-lead DIP to 8-lead SOIC




#### XLT08SN-1




#### XLT14SO-1

#### 14-lead DIP to 14-lead SOIC




#### XLT18SO-1

#### 18-lead DIP to 18-lead SOIC



#### XLT20SO1-1


20-lead DIP to 20-lead SOIC



stated otherwise.

#### XLT28SO-1


28-lead DIP to 28-lead SOIC



## SSOP TRANSITION SOCKET

An SSOP transition socket and associated hardware is shown in Figure 2.

#### FIGURE 2: SSOP TRANSITION SOCKET



The SSOP transition sockets are similar to the SOIC transition sockets. There are two parts to the SSOP transition socket:

- 1. Adapter socket that connects to the DIP device adapter.
- 2. SSOP header that gets soldered down to the target application.


Microchip offers the following SSOP transition sockets:

- XLT14SS-1: One 14-lead DIP adapter socket and one 14-lead SSOP header
- XLT20SS-1: One 18-lead DIP adapter socket and one 20-lead SSOP header
- XLT20SS1-1: One 20-lead DIP adapter socket and one 20-lead SSOP header
- XLT28SS-1: One 28-lead DIP adapter socket and one 28-lead SSOP header
- XLT28SS2-1: One 28-lead DIP adapter socket and one 28-lead SSOP header (PIC16X55/57)

See the drawings in this section for layout dimensions and clearances for tall components.


## XLT14SS-1

14-lead DIP to 14-lead SSOP




#### XLT20SS-1

#### 18-lead DIP to 20-lead SSOP



XLT20SS1-1

#### 20-lead DIP to 20-lead SSOP




stated otherwise.

all other tolerances ±0.13 mm [±0.005"] unless

stated otherwise.

#### XLT28SS-1


#### 28-lead DIP to 28-lead SSOP



pitches (from true position)  $\pm 0.08$  mm [ $\pm 0.003$ "], all other tolerances  $\pm 0.13$  mm [ $\pm 0.005$ "] unless stated otherwise.

#### XLT28SS2-1


28-lead DIP to 28-lead SSOP (PIC16X55/57)



## PLCC TRANSITION SOCKET

A PLCC transition socket and associated hardware is shown in Figure 3.

#### FIGURE 3: PLCC TRANSITION SOCKET



The PLCC transition socket is required for use along with the PLCC device adapters. The DAF18-1 device adapter is equipped with eight socket strips that interface with one of two transition sockets. The DAF18-3 device adapter is equipped with four socket strips that interface with one transition socket.

The PLCC transition sockets are designed with a threaded insert in the center of the footprint so that a 4/40 screw can securely fasten the transition socket to the device adapter.


The PLCC transition sockets are designed to be soldered to the target PCB PLCC surface mount pattern or inserted into a PLCC socket on the target PCB.

**Note:** To avoid solder bridging, do not place vias within 0.025-inch of the PLCC footprint. Also, any vias near the PLCC should be directly on the centerline of the pad.

Microchip offers the following PLCC transition sockets:


· XLT44L2: One 44-lead PLCC transition socket

## **RECOMMENDED PCB LAYOUT**





#### XLT44L2

#### 44-lead PLCC (0.050")



TOP VIEW






## **QFP TRANSITION SOCKET**

QFP (MQFP, TQFP, PQFP) transition sockets and associated hardware are shown below.

#### FIGURE 4: QFP TRANSITION SOCKET



The QFP transition socket is required for use along with the QFP device adapter. The device adapter is equipped with four socket strips that interface with the transition socket.

Note: To avoid solder bridging, do not place vias within 0.025-inch of the QFP footprint. Also, any vias near the QFP should be directly on the centerline of the pad.

There are two parts to the QFP transition socket:

- 1. Adapter socket that connects to the QFP device adapter
- 2. QFP header that gets soldered down to the target application

Microchip offers the following QFP transition sockets:


- XLT44PT3: One 44-lead QFP adapter socket and one 44-lead QFP header (0.8 mm)
- XLT64PT5: One 64-lead QFP adapter socket and one 64-lead QFP header (0.5 mm)
- XLT80PT2: One 80-lead QFP adapter socket and one 80-lead QFP header (0.65 mm)
- XLT80PT3: One 80-lead QFP adapter socket and one 80-lead QFP header (0.5 mm)

See the drawings in this section for layout dimensions and clearances for tall components.

## QFP TRANSITION SOCKET SOLDERING TIPS


- Use controlled soldering iron tip temperatures between 300°C and 325°C (570°F to 615°F)
- If possible, use a PACE mini wave soldering iron tip or an equivalent tip design.
- Plan to solder one (1 of 4) side first, then the opposite side, then the remaining two sides.
- Soldering iron tip movement should be in the direction of the leads (backward and forward), not across the leads; dragging the tip across the leads may cause lead damage.
- Use generous amounts of soldering flux to aid in the solder flow action.

#### XLT44PT3




## XLT64PT5, XLT80PT3

#### 64/80-lead QFP (0.5 mm)



#### XLT80PT2

#### 80-lead QFP (0.65 mm)




#### TABLE 1: DVA/DAF INTERFACE SPECIFICATION FOR QFP PACKAGES

Socket	Package Style*	DVA/DAF Interface Specification**
XLT44PT3	44PT TQFP 44PQ MQFP 44KW PQFP	DVA-44PL
XLT64PT5	64PT	DVA-68PL
XLT80PT2	80PF	DVA-84PL
XLT80PT3		
<ul> <li>Refer to the "Package Specification" for PCB footprint dimensions (DS00049).</li> <li>Refer to the processor module and device adapter specification for interface and dimensions to DVA/DAF (ICE 2000: "MPLAB<sup>®</sup> ICE 2000 Processor Module and Device Adapter Specification" (DS51140); ICE 4000: "MPLAB<sup>®</sup> ICE 4000 Processor Module and Device Adapter Specification" (DS51298)).</li> </ul>		


# SOT/DFN/QFN TRANSITION SOCKETS

SOT/DFN/QFN transition sockets and associated hardware are shown below.


#### FIGURE 5: SOT TRANSITION SOCKET WITH CABLE




#### FIGURE 6: DFN TRANSITION SOCKET WITH CABLE



#### FIGURE 7: QFN TRANSITION SOCKET WITH CABLE



#### FIGURE 8: QFN TWO-PART TRANSITION SOCKET



Two-part transition sockets consist of:

- 1. Adapter socket that connects to the DIP device adapter
- 2. QFN header that is to be soldered down to the target application

Microchip offers the following SOT/DFN/QFN transition sockets:

- XLT06SOT: One 14-lead DIP to 6-lead SOT-23 transition socket with cable
- XLT08DFN2: One 14-lead DIP to 8-lead DFN transition socket with cable
- XLT16QFN1: One 14-lead DIP to 16-lead QFN transition socket with cable
- XLT20QFN-1: One 20-lead DIP adapter socket and one 20-lead QFN header
- XLT28QFN3: One 18-lead DIP to 28-lead QFN transition socket with cable
- XLT28QFN4: One 28-lead DIP to 28-lead QFN transition socket with cable
- XLT44QFN2: One 40-lead DIP to 44-lead QFN transition socket with cable
- XLT44QFN3: One 28-lead DIP to 44-lead QFN transition socket with cable
- XLT44QFN4: One 28-lead DIP to 44-lead QFN transition socket with cable
- XLT44QFN5: One 18-lead DIP to 44-lead QFN transition socket with cable

See the drawings in this section for layout dimensions.

#### RECOMMENDED INSTALLATION OF TRANSITION SOCKETS WITH CABLES


For transition sockets that use a cable, follow these instructions for installing your transition socket on the target board.

#### PCB Layout Considerations:

Make sure you leave enough room on the PCB to accommodate the cable, i.e., space your target pads for each device far enough apart so that the cable from one pad group will not interfere with another pad group.


#### 6-Pin SOT Solder Instructions:

- 1. Remove protective cable covering from end of cable.
- 2. Position cables on target board (see below). Tape down to prevent movement.
- 3. Solder each lead to target pad.
- 4. Remove tape and clean.



#### 8-Pin DFN Solder Instructions:

- 1. Prepare leads by trimming narrowest portion to 0.10-inch maximum in length (see below).
- 2. Position cables on target board (see below). Tape down to prevent movement.
- 3. Solder each lead to target pad.
- 4. Remove tape and clean.




#### 8-Pin DFN Assembly Instructions:

- 1. Start with cable associated with pin 1.
- 2. Fold cable up and over, forming a radius.
- 3. Mate with the header on the side of the transition socket assembly, making sure pin 1 mates with the pin labeled "DFN Pin 1".
- 4. Fold over and mate the other cable.

#### 16-Pin QFN Solder Instructions:

- 1. Remove protective cable jacket from stripped end of cable.
- 2. Lay out the four cables in a "+" pattern (see below).

- 3. Center each cable on the footprint (see below). Tape down each cable to prevent movement.
- 4. Solder each lead to target pad.
- 5. Remove tape and clean




#### 16-Pin QFN Assembly Instructions:

- 1. Start with cable associated with pin 1.
- 2. Fold cable up and over, forming a radius. Header pins will now be facing upwards.
- Mate with the socket on the underside of the transition socket assembly, making sure pin 1 mates with the pin labeled "QFN Pin 1".
- 4. Fold over and mate the other cables.

#### 28/44-Pin QFN Solder Instructions:

- 1. Remove protective cable jacket from stripped end of cable.
- Lay out with long cables opposing each other and short cables opposing each other (see below).
- 3. Place center lead (6th lead for 44-pin, 4th lead for 28-pin) on center target pad to center each cable on the footprint (see below). Tape down each cable to prevent movement.
- 4. Solder each lead to target pad.
- 5. Remove tape and clean




#### 28/44-Pin QFN Assembly Instructions:

- 1. Start with cable associated with pin 1.
- 2. Fold cable up and over, forming a radius. Header pins will now be facing upwards.
- Mate with the socket on the underside of the transition socket assembly, making sure pin 1 mates with the pin labeled "QFN Pin 1".
- 4. Fold over and mate the other cables.


## **RECOMMENDED PCB LAYOUT**

The recommended target board footprint layout for different pin-counts is shown here.


#### FIGURE 9: 6-PIN SOT, 8-PIN DFN




#### FIGURE 10: 16-PIN QFN




#### FIGURE 11: 20-PIN QFN



#### FIGURE 12: 28-PIN QFN




#### FIGURE 13: 44-PIN QFN




## XLT06SOT

14-lead DIP to 6-lead SOT-23




#### XLT08DFN2

#### 14-lead DIP to 8-lead DFN




#### XLT16QFN1, XLT28QFN3, XLT28QFN4, XLT44QFN2, XLT44QFN3, XLT44QFN4, XLT44QFN5

#### Multi-lead DIP to Multi-lead QFN, Top View




#### Multi-lead DIP to Multi-lead QFN, Side View




UNLESS OTHERWISE SPECIFIED, DIMENSIONS ARE IN INCHES.


#### Multi-lead DIP to Multi-lead QFN Cables



#### XLT20QFN-1



#### 20-lead QFN Header (Surface Foot)



stated otherwise.

#### XLT20QFN-1 Soldering Suggestions

This socket is difficult to solder since the device pins are not exposed, but embedded, into the socket's Surface Foot (SF).

- 1. To start, add tack flux to the target land pattern.
- 2. Visually align the QFN SF with the target land pattern. Then solder two opposite SF pins to the target lands so that the SF does not move around.
- 3. Finish soldering the rest of the SF pins.
- 4. If the SF has a middle ground pin, feed solder through the bottom side of hte target board via holes. This will connect the center QFN SF pin to the target board.
- 5. Check each solder connection on the QFN SF pins.

You are now ready to attach the QFN header to the SF.


# **DISCONTINUED SOCKETS**

The transition sockets in this section are discontinued and may no longer be ordered from Microchip. They are kept in this document as a reference for customers who still have these sockets.

## PDIP TRANSITION SOCKET

A PDIP transition socket and associated hardware is shown in Figure 1.

## FIGURE 1: PDIP TRANSITION SOCKET



The PDIP transition socket is a 0.300-inch Male to 0.600-inch Female adapter socket.


Microchip offers the following PDIP transition socket:

 XLT28XP: One 28-lead DIP transition socket and two 28-lead gold standoffs

See the drawings in this section for layout dimensions.

## XLT28XP (Discontinued)


28-lead DIP 0.300-inch Male to 0.600-inch Female



## SOIC TRANSITION SOCKET

An SOIC transition socket and associated hardware is shown in Figure 2.

#### FIGURE 2: SOIC TRANSITION SOCKET



There are two components of the SOIC transition socket:

- 1. Adapter socket that connects to the PDIP device adapter
- 2. SOIC header that is to be soldered down to the target application

The following SOIC transition sockets have been discontinued:


- XLT08SO: One adapter socket and three 8-lead SOIC headers
- XLT14SO: One adapter socket and three 14-lead SOIC headers
- XLT18SO: One adapter socket and three 18-lead SOIC headers
- XLT20SO1: One adapter socket and three 20-lead SOIC headers
- XLT28SO: One adapter socket and three 28-lead SOIC headers

See the drawings in this section for layout dimensions.


**Note:** The SOIC header is designed for SOIC body width of 0.300-inch. The adapter leads should be cut to fit the 0.150-inch and 0.208-inch SOIC body widths.

# XLT08SO (Discontinued – see XLT08SO-1 or XLT08SN-1)

#### 8-lead DIP to 0.050-inch Adapter Socket




#### 8-lead SOIC Header




#### XLT14SO (Discontinued – see XLT14SO-1)

14-lead DIP to 0.050-inch Adapter Socket




#### 14-lead SOIC Header




#### XLT18SO (Discontinued – see XLT18SO-1)

18-lead DIP to 0.050-inch Adapter Socket




#### 18-lead SOIC Header




#### XLT20SO1 (Discontinued – see XLT20SO1-1)

20-lead DIP to 0.050-inch Adapter Socket




#### 20-lead SOIC Header




#### XLT28SO (Discontinued – see XLT28SO-1)

28-lead DIP to 0.050-inch Adapter Socket




#### 28-lead SOIC Header



## SSOP TRANSITION SOCKET

An SSOP transition socket and associated hardware is shown in Figure 3.

#### FIGURE 3: SSOP TRANSITION SOCKET



The SSOP transition sockets are similar to the SOIC transition sockets. There are two parts to the SSOP transition socket:

- 1. Adapter socket that connects to the PDIP device adapter.
- 2. SSOP header that gets soldered down to the target application.
  - **Note:** To keep the leads straight during assembly and shipping, the SSOP headers are shipped with break-away tabs attached to the leads. Please remove the break-away tabs before applying power to the target system. Be careful not to bend the leads prior to soldering to the target application.


The following SSOP transition sockets have been discontinued:

- XLT14SS: One adapter socket and three 14-lead SSOP headers
- XLT20SS: One adapter socket and three 20-lead SSOP headers
- XLT20SS1: One adapter socket and three 20-lead SSOP headers
- XLT28SS: One adapter socket and three 28-lead SSOP headers
- XLT28SS2: One adapter socket and three 28-lead SSOP headers for PIC16C55/57


See the drawings in this section for layout dimensions and clearances for tall components.

#### XLT14SS (Discontinued - see XLT14SS-1)

14-lead DIP to 0.8 mm Adapter Socket




#### 14-lead SSOP Header




#### XLT20SS (Discontinued – see XLT20SS-1)

18-lead DIP to 0.8 mm Adapter Socket




#### 20-lead SSOP Header




## XLT20SS1 (Discontinued – see XLT20SS1-1)

20-lead DIP to 0.8 mm Adapter Socket




#### 20-lead SSOP Header




XLT28SS (Discontinued – see XLT28SS-1) XLT28SS2 (Discontinued – see XLT28SS2-1)

28-lead DIP to 0.8 mm Adapter Socket




#### 28-lead SSOP Header



## PLCC TRANSITION SOCKET

A PLCC transition socket and associated hardware is shown in Figure 4.


#### FIGURE 4: PLCC TRANSITION SOCKET



The PLCC transition socket is required for use along with the PLCC device adapters. The DAF18-1 device adapter is equipped with eight socket strips that interface with one of two transition sockets. The DAF18-3 device adapter is equipped with four socket strips that interface with one transition socket.

The PLCC transition sockets are designed with a threaded insert in the center of the footprint so that a 4/40 screw can securely fasten the transition socket to the device adapter.


The PLCC transition sockets are designed to be soldered to the target PCB PLCC surface mount pattern or inserted into a PLCC socket on the target PCB.



The following PLCC transition sockets have been discontinued:


- XLT68L1: One 68-lead PLCC transition socket
- XLT84L1: One 84-lead PLCC transition socket

## **RECOMMENDED PCB LAYOUT**



#### XLT68L1, XLT84L1 (Discontinued)

68/84-lead Adapter Socket



0.050 - 0.018

FRONT/ SIDE VIEW

UNLESS OTHERWISE SPECIFIED, DIMENSIONS ARE


IN INCHES.

Drawing shown is for 68-lead.

## **QFP TRANSITION SOCKET**

QFP (MQFP, TQFP, PQFP) transition sockets and associated hardware are shown below.

#### FIGURE 5: QFP TRANSITION SOCKET




The QFP transition socket is required for use along with the QFP device adapter. The device adapter is equipped with four socket strips that interface with the transition socket.

Note:	To avoid solder bridging, do not place vias within 0.025-inch of the QFP footprint. Also, any vias near the QFP should be
	directly on the centerline of the pad.

The following QFP transition sockets have been discontinued:

- XLT44PT: One 44-lead QFP transition socket, 0.80 mm
- XLT64PT1: One 64-lead QFP transition socket, 0.5 mm (PIC16C92X)



- XLT64PT2: One 64-lead QFP transition socket, 0.5 mm (PIC17CXXX)
- XLT64PT3: One 64-lead QFP transition socket, 0.8 mm (dsPIC30F)
- XLT64PT4: One 64-lead QFP adapter socket and one 64-lead QFP header (0.8 mm)
- XLT80PT: One 80-lead QFP transition socket, 0.5 mm

## QFP TRANSITION SOCKET SOLDERING TIPS


- Before soldering, consider keeping the break-away tabs in place during soldering.
- Use controlled soldering iron tip temperatures between 300°C and 325°C (570°F to 615°F)
- If possible, use a PACE mini wave soldering iron tip or an equivalent tip design.
- Plan to solder one (1 of 4) side first, then the opposite side, then the remaining two sides.
- Soldering iron tip movement should be in the direction of the leads (backward and forward), not across the leads; dragging the tip across the leads may cause lead damage.
- Use generous amounts of soldering flux to aid in the solder flow action.
- If the break-away tabs are removed after soldering (using a dental pick or equivalent), any solder bridging between leads can be repaired by simply gently touching the soldering tip to the lead tip.

#### CAUTION

The 64 and 80-pin QFP headers are very delicate and can be easily damaged!


#### XLT44PT (Discontinued – see XLT44PT3)

#### 44-lead QFP to 0.8 mm Adapter Socket




XLT64PT1 (Discontinued) XLT64PT2 (Discontinued – see XLT64PT5) XLT80PT (Discontinued – see XLT80PT3)

64/80-lead QFP to 0.5 mm Adapter Socket




#### XLT64PT3 (Discontinued – see XLT64PT5)

64-lead QFP to 0.8mm Adapter Socket



#### XLT64PT4 (Discontinued – see XLT64PT5)

64-lead QFP (0.8 mm)




#### TABLE 1: DVA/DAF INTERFACE SPECIFICATION FOR QFP PACKAGES

Socket	Package Style*	DVA/DAF Interface Specification**
XLT44PT	44PT TQFP 44PQ MQFP 44KW PQFP	DVA-44PL
XLT64PT1	64PT special – PIC16C923/4, PIC16C925/6 only	DVA-68PL2
XLT64PT2	64PT	DVA-68PL
XLT64PT3		
XLT64PT4		
XLT80PT	80PT	DVA-84PL
<ul> <li>* Refer to the "Package Specification" for PCB footprint dimensions (DS00049).</li> <li>** Refer to the processor module and device adapter specification for interface and dimensions to DVA/DAF (ICE 2000: "MPLAB<sup>®</sup> ICE 2000 Processor Module and Device Adapter Specification" (DS51140); ICE 4000: "MPLAB<sup>®</sup> ICE 4000 Processor Module and Device Adapter Specification" (DS51298)).</li> </ul>		


# SOT/DFN/QFN TRANSITION SOCKETS

SOT/DFN/QFN transition sockets and associated hardware are shown below.

#### FIGURE 6: DFN/QFN TWO-PART TRANSITION SOCKET



#### FIGURE 7: QFN TRANSITION SOCKET



The following SOT/DFN/QFN transition sockets have been discontinued:


- XLT08DFN: One 8-lead DFN transition socket. (Replaced by XLT08DFN2.)
- XLT28QFN: One 28-lead QFN transition socket. (Replaced by XLT28QFN4.)
- XLT28QFN2: One 28-lead QFN transition socket. (Replaced by XLT28QFN3.)
- XLT44QFN: One 44-lead QFN two-part transition socket. (Replaced by XLT44QFN2.)

See the drawings in this section for layout dimensions.


## **RECOMMENDED PCB LAYOUT**

The recommended target board footprint layout for different pin-counts is shown here.


#### FIGURE 8: 8-PIN DFN



#### FIGURE 9: 28-PIN QFN




#### FIGURE 10: 44-PIN QFN




#### XLT08DFN (Discontinued – see XLT08DFN2)

8-lead DIP to 0.025-inch Adapter Socket




#### XLT28QFN (Discontinued – see XLT28QFN4)

28-lead DIP to 0.025-inch Adapter Socket




#### XLT28QFN2 (Discontinued – see XLT28QFN3)

18-lead DIP to 0.025-inch Adapter Socket



#### XLT44QFN (Discontinued – see XLT44QFN2)

40-lead DIP to 0.025-inch Adapter Socket



UNLESS OTHERWISE SPECIFIED, DIMENSIONS ARE IN INCHES.

## APPENDIX A: REVISION HISTORY

#### A.1 <u>Revision N (February 2006)</u>

The following is a list of modifications:

- 1. Added Appendix A: Revision History.
- 2. Removed "Preliminary" from the document's footer.
- 3. Added notes referring user to the "*Packaging Specification*" (DS00049) for PCB footprint dimensions in the "Two-Part QFP Sockets" section.

#### A.2 Revision P (September 2006)

The following is a list of modifications:

- 1. Removed "MPLAB ICE 2000/4000" from the name of the document. This document now applies to multiple tools, and the document title was renamed to reflect this.
- 2. Updated document to reflect support of 4 tools.
- 3. Updated document to include break-away tab information for XLT64PT1, XLT64PT2 and XLT80PT.

#### A.3 <u>Revision Q (July 2008)</u>

The following is a list of modifications:

1. Update for new SOIC, SSOP and QFN sockets.

#### A.4 Revision R (July 2009)

The following is a list of modifications:

1. Updated the first paragraph in the "Introduction" section.

#### A.5 Revision S (March 2010)

The following is a list of modifications:

- 1. Obsoleted XLT28XP and XLT64PT4
- 2. Added XLT44QFN4 and XLT44QFN5.



# WORLDWIDE SALES AND SERVICE

#### AMERICAS

Corporate Office 2355 West Chandler Blvd. Chandler, AZ 85224-6199 Tel: 480-792-7200 Fax: 480-792-7277 Technical Support: http://support.microchip.com Web Address: www.microchip.com

Atlanta Duluth, GA Tel: 678-957-9614 Fax: 678-957-1455

Boston Westborough, MA Tel: 774-760-0087 Fax: 774-760-0088

Chicago Itasca, IL Tel: 630-285-0071 Fax: 630-285-0075

**Cleveland** Independence, OH Tel: 216-447-0464 Fax: 216-447-0643

**Dallas** Addison, TX Tel: 972-818-7423 Fax: 972-818-2924

Detroit Farmington Hills, MI Tel: 248-538-2250 Fax: 248-538-2260

Kokomo Kokomo, IN Tel: 765-864-8360 Fax: 765-864-8387

Los Angeles Mission Viejo, CA Tel: 949-462-9523 Fax: 949-462-9608

Santa Clara Santa Clara, CA Tel: 408-961-6444 Fax: 408-961-6445

Toronto Mississauga, Ontario, Canada Tel: 905-673-0699 Fax: 905-673-6509

#### ASIA/PACIFIC

Asia Pacific Office Suites 3707-14, 37th Floor Tower 6, The Gateway Harbour City, Kowloon Hong Kong Tel: 852-2401-1200 Fax: 852-2401-3431

Australia - Sydney Tel: 61-2-9868-6733 Fax: 61-2-9868-6755

**China - Beijing** Tel: 86-10-8528-2100 Fax: 86-10-8528-2104

**China - Chengdu** Tel: 86-28-8665-5511 Fax: 86-28-8665-7889

**China - Chongqing** Tel: 86-23-8980-9588 Fax: 86-23-8980-9500

**China - Hong Kong SAR** Tel: 852-2401-1200 Fax: 852-2401-3431

**China - Nanjing** Tel: 86-25-8473-2460 Fax: 86-25-8473-2470

**China - Qingdao** Tel: 86-532-8502-7355 Fax: 86-532-8502-7205

**China - Shanghai** Tel: 86-21-5407-5533 Fax: 86-21-5407-5066

**China - Shenyang** Tel: 86-24-2334-2829 Fax: 86-24-2334-2393

**China - Shenzhen** Tel: 86-755-8203-2660 Fax: 86-755-8203-1760

**China - Wuhan** Tel: 86-27-5980-5300 Fax: 86-27-5980-5118

**China - Xian** Tel: 86-29-8833-7252 Fax: 86-29-8833-7256

**China - Xiamen** Tel: 86-592-2388138 Fax: 86-592-2388130

**China - Zhuhai** Tel: 86-756-3210040 Fax: 86-756-3210049

#### ASIA/PACIFIC

India - Bangalore Tel: 91-80-3090-4444 Fax: 91-80-3090-4123

**India - New Delhi** Tel: 91-11-4160-8631 Fax: 91-11-4160-8632

India - Pune Tel: 91-20-2566-1512 Fax: 91-20-2566-1513

**Japan - Yokohama** Tel: 81-45-471- 6166 Fax: 81-45-471-6122

**Korea - Daegu** Tel: 82-53-744-4301 Fax: 82-53-744-4302

Korea - Seoul Tel: 82-2-554-7200 Fax: 82-2-558-5932 or 82-2-558-5934

Malaysia - Kuala Lumpur Tel: 60-3-6201-9857 Fax: 60-3-6201-9859

**Malaysia - Penang** Tel: 60-4-227-8870 Fax: 60-4-227-4068

Philippines - Manila Tel: 63-2-634-9065 Fax: 63-2-634-9069

**Singapore** Tel: 65-6334-8870 Fax: 65-6334-8850

**Taiwan - Hsin Chu** Tel: 886-3-6578-300 Fax: 886-3-6578-370

**Taiwan - Kaohsiung** Tel: 886-7-536-4818 Fax: 886-7-536-4803

**Taiwan - Taipei** Tel: 886-2-2500-6610 Fax: 886-2-2508-0102

**Thailand - Bangkok** Tel: 66-2-694-1351 Fax: 66-2-694-1350

#### EUROPE

Austria - Wels Tel: 43-7242-2244-39 Fax: 43-7242-2244-393 Denmark - Copenhagen Tel: 45-4450-2828 Fax: 45-4485-2829

France - Paris Tel: 33-1-69-53-63-20 Fax: 33-1-69-30-90-79

**Germany - Munich** Tel: 49-89-627-144-0 Fax: 49-89-627-144-44

**Italy - Milan** Tel: 39-0331-742611 Fax: 39-0331-466781

**Netherlands - Drunen** Tel: 31-416-690399 Fax: 31-416-690340

**Spain - Madrid** Tel: 34-91-708-08-90 Fax: 34-91-708-08-91

**UK - Wokingham** Tel: 44-118-921-5869 Fax: 44-118-921-5820

01/05/10