

ASSEMBLY INSTRUCTIONS:

A) Using the footrest (item 1) as a template, mark and drill 3/8 (9.5mm) hole in plinth (item 2) to suit.

Note: Leave the removable front panels on plinth as shown

B) Using the 5/16 screw and KEP nut (item 3 & 4) secure the footrest to plinth.

PARTS LIST

ITEM No.	DESCRIPTION	QTY
1	FOOTREST	1
2	PLINTH (NOT INCLUDED)	1
3	5/16-18 HEX SCREW	8
4	5/16-18 KEP NUT	8


TOOL BOX



Centre
Punch



Electric Drill .136" (3.5 mm)
Dia. bit



Hammer



1/2 Socket
Wrench



1/2 Open
Wrench

