

LMH9235 Evaluation Module

This document outlines the basic steps and functions that are required to ensure the proper operation and quick setup of the LMH9235RRL-EVM. This document also includes a schematic diagram, a bill of materials (BOM), printed-circuit board (PCB) layouts, and test block diagrams. Throughout this document, the abbreviations *EVM, LMH9235 EVM* and the term *evaluation module* are synonymous with the LMH9235RRL-EVM, unless otherwise noted.

Contents

List of Figures

List of Tables

Trademarks

Isola is a registered trademark of Isola USA Corporation. All other trademarks are the property of their respective owners.

1 Description

The LMH9235 evaluation module (EVM) is used to evaluate the LMH9235 device, which is a single-ended input to differential output RF gain block amplifier available in a 2 \times 2-mm², 12-pin RRL package. The device is well-suited to support requirements for the next generation 5G m-MIMO active antenna system while interfacing with the input of transceiver. The EVM is designed to quickly demonstrate the functionality and performance of the LMH9235 device in the 3.3-GHz to 3.8-GHz receive frequency band with 700 MHz of 1-dB bandwidth.

By default, the board is set up for 50-Ω single-ended input matching and 100-Ω differential output matching for easy interface with 50-Ω test equipment. The EVM is ready to connect to a +3.3-V power supply, signal source, and test instruments through the use of onboard connectors.

1.1 Features

- Operates on a single +3.3-V supply.
- Designed for a single-ended 50-Ω input matching and 100-Ω differential output matching interface.
- Simple interface to the inputs and output through onboard SMA connectors.
- Power down option available onboard using a jumper connector.

Figure 1. Single Tone Setup for Gain and Output P1dB

1.2 General Usage Information

This section provides general usage information for the LMH9235 EVM. See [Figure 1](#page-1-3) for a general single tone setup diagram as a reference point for the following instructions. Some components such as supply bypass capacitors and power down reference voltage generation circuits are omitted in [Figure 1](#page-1-3) for clarity.

- 1. Recommended power up sequence:
	- a. Before connecting the power-supply cables to the EVM, set the DC output power supply to +3.3 V.
	- b. Set the current limit of the DC output power supply at 150 mA.
	- c. Making sure the supply is turned off, connect the power supply cables to the J1 connector of the EVM.
	- d. Now turn on the DC power supply of VCC = +3.3 V. The supply current (I_0) drawn from the power supply should be approximately 80 mA.
	- e. If the supply current is low, ensure that the device is not disabled by shorting the jumper connection for J5 between 2 and 3 header pins.
- 2. Power-down option:

www.ti.com *Description*

- a. Short terminals 1 and 2 on J5 to put the LMH9235 device in its power down state. The supply current (I_o) drawn should be < 15 mA.
- 3. Single tone measurement setup recommendation:
	- a. Connect an RF signal generator to input J3 SMA connector.
	- b. The RF signal generator used must support 3.3-GHz to 3.8-GHz signal frequency for testing out the LMH9235 EVM.
	- c. When measuring the EVM for single tone distortion products, TI recommends using an RF band pass filter (not shown in [Figure 1\)](#page-1-3) between the signal source and J3 SMA input.
	- d. The LMH9235 device input is tuned to 50-Ω matching impedance in the 3.3-GHz to 3.8-GHz frequency band of operation. To minimize signal reflections due to impedance mismatch, TI recommends using an attenuator pad of approximately 3-dB to 6-dB between the source and J3 SMA input.
	- e. The EVM outputs are fully differential (or 180° out-of-phase) at J2 and J4 SMA connectors. Although the LMH9235 device output is internally matched to 50- Ω differential impedance, the onboard discrete L and C components transform the differential output impedance to 100- Ω in the 3.3-GHz to 3.8-GHz frequency band. See [Table 1](#page-6-1) for the discrete L and C component values used on the LMH9235 EVM.
	- f. When connecting to a spectrum analyzer single-ended input, the differential signal out of the EVM should be converted to a single-ended signal using a passive balun as shown in [Figure 1.](#page-1-3)
	- g. It is recommended to use a balun which operates in the same frequency band as the LMH9235 device to avoid any setup issues. Also, using an attenuator pad of approximately 3-dB to 6-dB is recommended at the three terminals of the passive balun for 50- Ω matching between the EVM output and spectrum analyzer input.
	- h. Lastly, it is recommended to properly characterize and account for the insertion loss of RF coaxial (coax) cables, attenuator pads, and passive baluns to measure accurate gain and power levels for the device.
- 4. Matching or tuning options:
	- a. Solder mask has been removed along the RF signal paths and VCC path allowing an easy method to slide surface mount components along these traces for optimal tuning.
	- b. The device differential output is tuned for 100-Ω differential impedance in the 3.3-GHz to 3.8-GHz frequency band using discrete L and C components. The trace impedance is calculated by the stack-up configuration as given in [Section 2.4](#page-7-0). See [Table 1](#page-6-1) for the L and C component values used on the LMH9235 EVM.

2 EVM Overview

This section includes the schematic diagram, a bill of materials (BOM), PCB layer prints, and EVM stackup information.

2.1 Schematic

[Figure 2](#page-3-2) shows the LMH9235 EVM schematic.

Figure 2. LMH9235 EVM Schematic

2.2 PCB Layers

[Figure 3](#page-4-1) through [Figure 6](#page-5-1) illustrate the PCB layers for this EVM.

Figure 3. Top Layer

Figure 4. Layer 2

Figure 5. Layer 3

Figure 6. Bottom Layer

www.ti.com *EVM Overview*

2.3 LMH9235 EVM Bill of Material

Table 1. LMH9235 EVM BOM

EVM Overview www.ti.com

2.4 Stack-Up and Material

The LMH9235 EVM is a 56-mil, 4-layer board whose material type is Isola® 370HR. The top layer routes the power, ground, and signals to and from the device. The signal impedance is targeted at 49.9 Ω . The bottom 3 layers are ground layers.

Layer	Stack up	Type	Supplier	Supplier Description	Description	Base Thickness	Impedance ID	Mask Thickness	Processed Thickness	Er
		Copper			Copper Foil	0.579	1, 2, 3		1.760	
$\overline{2}$ 3		FR4	isola	370HR	PrePreg 2116	4.331			4.308	4.100
		FR4	isola	370HR	PrePreg 2116	4.331			4.308	4.100
	$-10.00%$	FR4	isola	370HR	PrePreg 1080	2.559			2.546	3.930
	\sim +10.00%	FR4	isola	370HR	Core	1.181 27.953 1.181			1.181 27.953 1.181	4.360
		FR4	isola	370HR	PrePreg 1080	2.559			2.546	3.930
	62.99	FR4	isola	370HR	PrePreg 2116	4.331			4.308	4.100
		FR4	isola	370HR	PrePreg 2116	4.331			4.308	4.100
4		Copper			Copper Foil	0.579	4, 5, 6		1.760	

Figure 7. LMH9235 EVM Stack-Up (Units in Mils)

3 Test Setup Diagrams

This section includes general recommendations for S-parameter, noise figure, and two-tone OIP3 setup while measuring the LMH9235 EVM.

3.1 S-Parameter Test Setup

Figure 8. S-Parameter Test Setup

Use the following guidelines for S-parameter measurement:

- 1. S-parameter measurement is typically done using a Vector Network Analyzer (VNA), as [Figure 8](#page-7-4) shows. For measuring the LMH9235 EVM, a 4-port VNA is recommended which can generate and receive truly differential signals at the input and output ports.
- 2. Before connecting the RF coax cables to the LMH9235 EVM, you must calibrate the VNA along with the cables using a calibration kit. This accounts for any cable losses in the S-parameter calculation at the VNA and helps set reference impedance at the cable ends.
- 3. Make sure the frequency sweep and output power level from the VNA is set within the linear operating range of the LMH9235 devices. The resolution bandwidth (RBW) and dynamic range of the VNA can be adjusted to give optimum sweep time for the measurement.
- 4. It is important to account for onboard trace losses at the input and output pins of the device. Deembedding of the input and output traces is recommended to improve the S-parameter measurement

that is representative of the device performance. [Figure 9](#page-8-1) and [Figure 10](#page-8-2) give typical input and output trace losses measured on the LMH9235 EVM, respectively.

3.2 Noise Figure Test Setup

Figure 11. Noise Figure Test Setup

Use the following guidelines for Noise Figure (NF) measurement:

- 1. The traditional Y-factor method can be used for the NF measurement using a Noise Diode and a spectrum analyzer (or a Noise Figure Analyzer), as [Figure 11](#page-8-3) shows.
- 2. While doing the measurement, take into account any RF cable losses to the EVM board. Any external input attenuator added for matching will result in proportional NF degradation and must be calibrated out in the measurement.
- 3. Also, onboard losses of the input traces at the device input pin must be factored into the NF measurement.
- 4. If the device output loss is significant, it is important to factor the output loss into the NF measurement.
- 5. Using the *Friis* equation is helpful when calculating combined NF of the measurement setup, and then back calculating the individual device noise figure.

Test Setup Diagrams www.ti.com

3.3 Two-Tone OIP3 Test Setup

Figure 12. OIP3 Test Setup

Use the following guidelines for two-tone OIP3 measurement:

- 1. As [Figure 12](#page-9-1) shows, combine two signal generator outputs using an in-phase power splitter and combiner. A 6-dB attenuator is recommended at the signal generator outputs to prevent the generators from talking to each other and resulting in signal generator IMD3 spurs.
- 2. Set both the signal generator outputs to a power level and frequency spacing such that it would yield the desired output power (P_{OUT}) at the device.
- 3. TI recommends that the output power level is within the linear operation range of the LMH9235 device. For example, if the total desired output power at the device is 8 dBm, then set the signal generators such that each of the fundamental output power results in 2 dBm per tone. However, if each output tone is at 8 dBm instead, the amplifier linearity will degrade as a result of higher total composite output power of 14 dBm at the device outputs. As a general rule, it is recommended to keep the total output power level approximately 6 to 8 dB lower than the 1-dB compression point. Also, see the device data sheet for the recommended output power levels supported by the device.
- 4. For the OIP3 test, the two tones can be spaced ±10 MHz with respect to the desired center frequency.
- 5. TI recommends setting the spectrum analyzer attenuation setting from 20 to 26 dB based on sweet spot of the incoming input power level.
- 6. Keep spectrum analyzer RBW and VBW settings identical for main tone and IM3 products.
- 7. For output IP3 calculation, take into account combined losses at the desired frequency band between the LMH9235 device output to the spectrum analyzer input. The combined power losses include loss due to PCB output trace, RF coax cable, 0/180◦passive balun and any attenuator pad used for external matching purposes. The calculated OIP3 is given in the following equation:

Output IP3 = $(P_{IN_SA} - IMD3) / 2 + P_{IN_SA} + P_{LOSS}$

where,

- $P_{IN,SA}$ = Input power per tone into the spectrum analyzer
- P_{loss} = Power loss from the device output to the spectrum analyzer input
- IMD3 = Higher power of the two inter-modulation distortion products recorded at either 2f1 f2 or 2f2 f1
- 8. The thing to note in is the P_{IN SA} + P_{LOSS} = P_{OUT} which is the amplifier output power per tone.

IMPORTANT NOTICE AND DISCLAIMER

TI PROVIDES TECHNICAL AND RELIABILITY DATA (INCLUDING DATA SHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS AND IMPLIED, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for skilled developers designing with TI products. You are solely responsible for (1) selecting the appropriate TI products for your application, (2) designing, validating and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, regulatory or other requirements.

These resources are subject to change without notice. TI grants you permission to use these resources only for development of an application that uses the TI products described in the resource. Other reproduction and display of these resources is prohibited. No license is granted to any other TI intellectual property right or to any third party intellectual property right. TI disclaims responsibility for, and you will fully indemnify TI and its representatives against, any claims, damages, costs, losses, and liabilities arising out of your use of these resources.

TI's products are provided subject to [TI's Terms of Sale](https://www.ti.com/legal/termsofsale.html) or other applicable terms available either on [ti.com](https://www.ti.com) or provided in conjunction with such TI products. TI's provision of these resources does not expand or otherwise alter TI's applicable warranties or warranty disclaimers for TI products.

TI objects to and rejects any additional or different terms you may have proposed.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265 Copyright © 2022, Texas Instruments Incorporated