




MSP-6-P

Ruland MSP-6-P, 6mm Two-Piece Shaft Collar, Plastic, Clamp Style, 16mm OD, 9mm Width





Description

Ruland MSP-6-P is a two-piece shaft collar with a 6mm bore, 16mm OD, and 9mm width. The clamp style design does not mar the shaft, is easy to remove, and is indefinitely adjustable. It is commonly used for guiding, spacing, stopping, mounting, and component alignment. Equipment manufacturers benefit from the tightly controlled face to bore perpendicularity of Ruland shaft collars, TIR of ? 05mm. Perpendicularity is critical for alignment when the shaft collar is used as a load bearing face, mechanical stop, or for mounting components such as gears or bearings. Proprietary processes have been developed by Ruland to maintain superior fit, finish, and holding power. MSP-6-P is stamped with the Ruland name and bore size for ease of identification. Halves are mated throughout the manufacturing process for proper fit and alignment. Forged screws test beyond DIN 912 12.9 standards to ensure maximum holding power. MSP-6-P is manufactured from solid bar stock sourced from select North American mills and machined to a fine burr free finish. Ruland uses engineered acetal plastic for a consistent finish. MSP-6-P is RoHS3 and REACH compliant and manufactured in our Marlborough, MA factory under strict controls using proprietary processes.

Product Specifications

Bore (B)	6 mm	Bore Tolerance	+0.050 mm / +0.012 mm	
Outer Diameter (OD)	16 mm	Clearance Diameter (C) MAX	20.8 mm	
Width (W)	9 mm	Width Tolerance	+0.076 mm / -0.254 mm	
Recommended Gap	1.20 mm	Recommended Shaft Tolerance	+0.000 mm / -0.013 mm	
Forged Clamp Screw	M3 x 8	Screw Material	18-8 300 Series Stainless Steel	
Hex Wrench Size	2.5 mm	Screw Finish	Bright	
Seating Torque	0.2 Nm	Screw Location (R)	5.51 mm	
Number of Screws	2 ea	Material Specification	Acetal Bar	
Finish Specification	Plain	Manufacturer	Ruland Manufacturing	
Country of Origin	USA	Temperature	-10°F to 185°F (-23°C to 85°C)	
Weight (lbs)	0.007200	UPC	634529077825	
Tariff Code	8483.60.8000	UNSPC	31162811	
Note 1	Performance ratings are	Performance ratings are for guidance only. The user must determine suitability for a particular application.		
Prop 65	▲WARNING This product can expose you to chemicals including Nickel (metallic) and Formaldehyde, known to the State of California to cause cancer. For more information go to www.P65Warnings.ca.gov .			

Installation Instructions

- 1. Use the MSP-6-P two-piece shaft collar as it is received.
- 2. Wipe the bore clean.
- 3. Apply a thin coat of light oil to the shaft.
- 4. Place the collar onto the desired shaft location with the groove side as the work surface. Tighten the collar using a 2.5 mm hex wrench until a slight resistance is felt.
- 5. Be sure to maintain the gap of 1.20 mm between the two halves of the collar during installation.
- 6. Wring collar into its final position and tighten the screw to the full recommended seating torque of 0.2 Nm using a 2.5 mm torque wrench.