

EVM3820-QV-00A

6V Input, 1.2 MHz, 2A Module Synchronous Step-Down Converter with Integrated Inductor Evaluation Board

The Future of Analog IC Technology

DESCRIPTION

EVM3820-QV-00A The is used for demonstrating the performance of MPS's MPM3820 a low voltage high switching frequency step-down switcher with built-in power MOSFETs and power inductor. MPM3820 provides up to 2A continuous highly efficient output with constant-on-time control for fast loop response.

High power efficiency over a wide load range is achieved by scaling down the switching frequency at light load to reduce the switching related loss by constant on time control. Short circuit and thermal shutdown provides reliable, fault-tolerant operation.

MPM3820 is available in QFN 3.0x5.0x1.6mm package.

ELECTRICAL SPECIFICATION

Parameter	Symbol	Value	Units
Input Voltage	V _{IN}	2.7– 6	V
Output Voltage	V _{OUT}	1.2	V
Output Current	I _{OUT}	2	Α

FEATURES


- Wide 2.7V to 6V Operating Input Range
- Fixed and Adjustable Output from 0.6V
- 3.0mm x 5.0mm x 1.6mm QFN Package •
- Total Solution Size 8.5mm x 4.5 mm •
- Up to 2A Continuous Output Current •
- 100% Duty Cycle in Dropout •
- Ultra Low IQ: 40µA •
- EN and Power Good for Power Sequencing •
- Cycle-by-Cycle Over-Current Protection
- Short Circuit Protection with Hiccup Mode •
- Adjustable Output Only Needs 4 External • Components - 2 Ceramic Capacitors and **FB** Divider Resistors
- Fixed Output Only Needs Input and Output Capacitors


APPLICATIONS

- Low Voltage I/O System Power •
- LDO Replacement
- Power for Portable Products
- Storage (SSD/HDD)
- Space-limited Applications

All MPS parts are lead-free and adhere to the RoHS directive. For MPS green status, please visit MPS website under Quality Assurance. "MPS" and "The Future of Analog IC Technology", are Registered Trademarks of Monolithic Power Systems, Inc.

EVM3820-QV-00A EVALUATION BOARD






www.MonolithicPower.com MPS Proprietary Information. Patent Protected. Unauthorized Photocopy and Duplication Prohibited. © 2014 MPS. All Rights Reserved.



EVALUATION BOARD SCHEMATIC




EVM3820-QV-00A BILL OF MATERIALS

Qty	RefDes	Value	Description	Package	Manufacturer	Manufacturer P/N
3	C1, C2,C2A	22µF	Ceramic Cap., 10V, X5R	SM0805	TDK	C2012X5R1A226K
0	C1A	NS				
1	R1	100k	Film Res., 1%	SM0603	Any	
1	R2	100k	Film Res.,1%	SM0603	Any	
1	R3	100k	Film Res., 5%	SM0603	Yageo	RC0603FR-07100KL
1	U1		COT Buck	QFN 3.0*5.0	MPS	MPM3820GQV


EVB TEST RESULTS

Performance waveforms are tested on the evaluation board. V_{IN} =5V, V_{OUT} =1.2V, T_A = 25°C, unless otherwise noted.



EVB TEST RESULTS (continued)

Performance waveforms are tested on the evaluation board. V_{IN} =5V, V_{OUT} =1.2V, T_A = 25°C, unless otherwise noted.





EVM3820-QV-00A Rev. 1.0 3/20/2014 MPS Propriet www.MonolithicPower.com


MPS Proprietary Information. Patent Protected. Unauthorized Photocopy and Duplication Prohibited. © 2014 MPS. All Rights Reserved.

EVB TEST RESULTS (continued)

Performance waveforms are tested on the evaluation board. V_{IN} =5V, V_{OUT} =1.2V, T_A = 25°C, unless otherwise noted.







EVM3820-QV-00A Rev. 1.0 3/20/2014 MPS Proprietary www.MonolithicPower.com tent Protected. Unauthorized Ph

MPS Proprietary Information. Patent Protected. Unauthorized Photocopy and Duplication Prohibited. © 2014 MPS. All Rights Reserved.

PRINTED CIRCUIT BOARD LAYER




Figure 1: Top Silk Layer




Figure 3: Bottom Silk Layer




Figure 2: Top Layer




Figure 4: Bottom Layer

QUICK START GUIDE (ADJUSTABLE OUTPUT)

The output voltage of this board is set externally which can be regulated as low as 0.6V by operating from +2.7V to +6V input as the figure 5. The default output voltage of this board is set to 1.2V.

- 1. Connect the positive and negative terminals of the load to the VOUT and GND pins, respectively.
- 2. Preset the power supply output between 2.7V and 6V, and then turn off the power supply.
- 3. Connect the positive and negative terminals of the power supply output to the VIN and GND pins, respectively.
- 4. Turn the power supply on. The board will automatically start up.
- 5. The Output Voltage V_{OUT} can be changed by varying R2. Choose R1 to be around $50k\Omega$ to $200k\Omega$. R2 is then given by:

$$R2 = \frac{R1}{\frac{V_{out}}{0.6} - 1}$$

Example: For Vout= 1V, R1=100k Ω , R2=150k Ω .




Figure 5—Adjustable Version

LAYOUT RECOMMENDATION OF MPM3820

Proper layout of the switching power supplies is very important, and sometimes critical to make it work properly. Especially, for the high switching converter, if the layout is not carefully done, the regulator could show poor line or load regulation, stability issues.

NOTICE: The information in this document is subject to change without notice. Please contact MPS for current specifications. Users should warrant and guarantee that third party Intellectual Property rights are not infringed upon when integrating MPS products into any application. MPS will not assume any legal responsibility for any said applications.