## **Etherlite, RJ-45 to DB-9 Console Adapter**

For use with Etherlite 2, 80, 160, 162, 32 – All Models

Digi Cable Adapters allow you to connect your serial devices using commercially available CAT 5 cable of any length. Simply plug standard CAT 5 cable into your Digi Product, connect a Cable Adapter to the other end and plug the adapter into your device.

From RJ-45	Signal	Direction	Signal	To DB-9	Pin 1 Pin 1
1	RTS	$\rightarrow$	CTS	8	
3	DCD	$\leftarrow$	DTR	4	
4	RxD	<b>←</b>	TxD	3	Female RJ-45 Female DB-9 8-pin
5	TxD	$\rightarrow$	RxD	2	
6	SG	$\leftrightarrow$	SG	5	
7	DTR	_	DCD	1	
		<b>-</b>	DSR	6	
8	CTS	<b>←</b>	RTS	7	
					Cable Adapter not to scale

\* Arrows indicate which direction the signal is flowing

## **Notes:**

- All RJ45 cable adapters are 8-pin.
- This cable utilizes the RTS signal of the serial device for hardware flow control (RTS / CTS).

Digi Part Number 76000461 Etherlite DB9F Console Adapter (single-pack)