

ILLUMRA ZBT-S1E and ZBT-S2E European Style Switches are for use with the Philips EVO200, EvoKit, Spacewise DT, SNS120, SNH200, SNS200, SNS210 MC.

ILLUMRA™ ZigBee Euro Switches offer a familiar and convenient interface for controlling Signify EasySense and SpaceWise products. The switches do not require wires or batteries, they contain a microgenerator powered ZigBee transmitter to send a wireless signal. The signal transmits through walls or around corners.

Philips EasySense configuration software is used to configure the behavior and allows the rocker to be configured for On/Off function and also works as press and hold dim to adjust brightness up and down. If using a Dual Rocker switch, the left rocker would perform the on/off and dim functions, and the right side can be configured for Scene Recall - the top and bottom buttons each dim to a level that is adjustable in the configuration software.

115 S State St, Suite B Lindon, UT 84042

T: (801) 349-1200 F: (801) 614-7100 Sales@ILLUMRA.com

# Philips EasySense / SpaceWise Compatible Wireless Switch

### **Self Powered** - No Batteries! No Wires!



## Compatible Philips EasySense and SpaceWise European Style Switches

### **Simple Wireless Control**

- Mount switches anywhere
- Create 3-way and 4-way switches
- Control lights, motors, or other electrical loads
- Reconfigure or relocate as needed
- Unique (theft) tamper-resistant design

#### **Control it Your Way**

- Use with any line-voltage or low voltage ILLUMRA receivers
- Control an unlimited number of ILLUMRA receivers within range
- Experience wireless dimming or ON/OFF control
- Maintenance-free operation for 20+ years

ILLUMRA ZBT-S1E(wh / bk) and ZBT-S2E(wh / bk) switches are for use with the Philips EVO200, EvoKit, Spacewise DT, SNS120, SNH200, SNS200, SNS210 MC. **Available in Black and White** 

| Part Number    | ZBT-S1E(x)                            | ZBT-S2E(x)                           |
|----------------|---------------------------------------|--------------------------------------|
| Range          | 30ft (10m)                            |                                      |
| Frequency      | ZigBee Channels 11-26 (2.4Ghz)        |                                      |
| Power          | Self-generated when switch is pressed |                                      |
| Buttons        | 2 Buttons                             | 4 Buttons                            |
| Dimensions     | 3.16(W) x 3.16(H) x 0.40(D) inches    |                                      |
| Ordering Codes | ZBT-S1EWH (White<br>ZBT-S1EBK (Black  | ZBT-S2EWH (White<br>ZBT-S2EBK (Black |