

Note: The “Out” jack on the Spectacle Audio Board is not for audio signals. Plugging an audio device into one of the Spectacle jacks could cause damage to the audio device. The audio jack on the Audio Board produces output suitable for amplification only. It is not suited to headphones or unpowered speakers.

Kit Includes:

- 1x Spectacle Director Board
- 1x Spectacle Audio Board
- 1x Spectacle Button Board
- 1x Hamburger Mini Speaker
- 1x microSD Card with Adapter — 16GB
- 1x microSD USB Reader
- 1x White Concave Button
- 2x Female Spade Connector Wire — 3ft
- 3x Audio Cable TRRS — 3ft
- 1x USB micro-B Cable — 6ft
- 1x USB Wall Charger — 5V, 1A
- 1x USB Lithium Ion Battery Pack — 2.2Ah