

APPLICATOR PARTS LIST

TYPE  
**SIDWISE**      **TERMI - FOIL**  
**CONTACT**

AMP INCORPORATED  
 HARRISBURG, PENNA.

NO.	DESCRIPTION	REQ.	PART NO.
1	WIRE CRIMPER	1	453946-2
2	INS. CRIMPER		
3	ANVIL	1	458906-2
4	ANVIL SPACER		
5	SHEAR <del>FL</del> FLOATING	1	689931-3
6	REAR SHEAR PLATE	1	811239-1
7	SHEAR BLADE SPACER		
8	FRONT SHEAR PLATE		
9	REAR ANVIL SPACER PLT.		
10	FRONT ANVIL SPACER PLT.		
11	TOOL SPACER	2	378246
12	CRIMP SPACER		
13	FRONT STRIP GUIDE	1	692949-5
14	REAR STRIP GUIDE	1	458908-1
15	RAM	1	473699
16	TOOL HOLDER		
17	ADJ. CRIMP MOUNT		
18	ADJ. BLOCK		
19	APPLICATOR MOUNT ASSY.		
20	BASE PLATE	1	465100-2
21	BASE BLOCK	1	692793-2
22	STRIP GUIDE PLATE	1	458910-1
23	ANVIL HOLDER	1	458909-1
24	AUX. ANVIL HOLDER	1	458907-1
25	STRIPPER	1	386361-1
26	STRIPPER MOUNT	1	386362
27	RETAINER PLATE	1	389078
28	STRIPPER MOUNT BRACKET	1	387715-1
29	STRIPPER BUSHING	1	389049-1
30	STOCK DRAG	1	387650-4
31	STOCK DRAG HANDLE		
32	STOCK DRAG STUD	1	374900
33	STOCK DRAG SPRING	1	370572
34	STOCK DRAG ADJ. <del>W/</del> NUT	1	21022-3
35	FEED FINGER HOLDER	1	386942
36	FEED FINGER	1	473739-1
37	FEED FINGER TIP	1	387251
38	FEED FINGER SPACER		
39	BASE CASTING	1	570238
40	GUARD 457665-8	1	<del>811303-1</del>
41	GUARD BRACKET	1	<del>811304-1</del>

NO.	DESCRIPTION	REQ.	PART NO.
42	<del>GUARD MT.</del>	<del>1</del>	<del>811306-1</del>
43			
44	SPRING - SHEAR	1	387083
45			
46			
47			
48			
49			
50			
51			
52			
53			
54			
55			
56			
57			
58			
59			
60			
61			
62			
63	BRACKET, AIR FEED SUP.	1	692036-1
64	1" AIR FEED $\Delta$	1	690021-1
65	TENSION ADJ. PL.	1	374999
	MISCELLANEOUS		
66	LUBRICATOR ASSY.	1	464519-2
67	TERMINAL LUBRICANT	1	22014-1
68	<del>SPREADER ASSY.</del>	<del>1</del>	<del>453596-1</del>
69	BRACKET, STOCK GUIDE	1	694927-4
70	EXTENSION, REEL BRKT	2	455807-2
71			
72	BENDING FIXTURE ASSY	1	68196-1

REV.	REVISION RECORD	DATE	BY	ECN
A	REV. PER ECN	2-25-76	JG	R1555
A1	INACTIVE	2-24-77	CE	R1983
B	REACTIVATE W/CHANGES	8-17-81	CE	R4128
C	REV PER ECN	2-82	CE	4333
D	ECR-08-018679	7-08	TM	

CRIMPING DATA		TERMINALS
TO APPLY TERMINAL		
WIRE SIZE	CRIMP HEIGHT	
12	.111	53644
10	.124	
CRIMP	SIZE	TYPE
WIRE	.210	F
INSUL.		
SLEEVED		.970
INSULATION RANGE	WIRE RANGE	
<del>W</del>	12-10	
EXPLODED VIEW		
A-6089		
REMARKS		
$\Delta$ REVERSE BRACKET 471799 (180°)		
§ REMOVE AIR PLUG FROM AIR CYL (LEFT REAR)		
MUST LAY WIRE IN BARREL		
$\Delta$ PRINT OF ASSY ITEM (72) MUST ACCOMPANY LOG SHEET		
■ DENOTES WEARING PARTS (NO MINI) RECOMMEND PURCHASE REPLACEMENT		
THIS APPLICATOR IS TO BE USED ON		
AMP-O-LECTRIC 1-471273-2		DIST. 4
SERIAL NO.	DATE SHIPPED	DESIGNED
		RUSS 7-23-73
CUSTOMER NAME AND ADDRESS		CHK'D
		1/25-73
APPLICATOR NUMBER		APP'R
REV D	566138-1	7-25-73
SHEET		1 OF 1

FOR HARDWARE  
 SEE 687524-2

THIS IS A CONTROLLED DOCUMENT  
 ALL RIGHTS RESERVED  
 AMP INCORPORATED  
 HARRISBURG, PENNSYLVANIA  
 17104  
 1981