

#### UM9941/3 December 2015


#### Features

- Demonstration of SDR wireless data modem supporting multiple bit rates and modulation schemes.
- Direct Conversion Receiver (CMX994E) and Linear Cartesian Loop Transmitter (CMX998).
- 1W Transmitter Operation
- Designed to meet EN 302 561

# DE9941 SDR Demonstrator User Manual

Provisional Issue

- Provides a demonstration platform for the CMX7164 Multi-mode Modem
- On-board PLL and VCO for 452MHz to 467MHz Operation
- Interfaces directly to the PE0003
- Small size 83mm x 55mm



### **1** Brief Description

The DE9941 is a small demonstration platform for the CMX994E Direct Conversion Receiver, the CMX998 Cartesian Loop Transmitter and the CMX7164 Multi-mode Wireless Data Modem. The small form factor of the evaluation platform is due to the compact nature of the CML IC solutions. The DE9941 can be used to demonstrate Tx and Rx performance with QAM modulation, FSK and GMSK type modulation. Together with the PE0003 host controller, a full transceiver can be demonstrated using a Function Image<sup>TM</sup> and control scripts.

The DE9941 provides a Fractional-N PLL and VCO plus associated circuits to provide local oscillator signals for the CMX994E and CMX998. The PE0003, together with the control scripts, gives the user the ability to program the RF synthesiser to the correct operating frequencies. The design also includes a 1W power amplifier, harmonic filter and Tx/Rx switch. The RF performance is designed to be compliant with EN 302 561 and all the circuits are provided with power-down capability to allow standby functionality.

The design is aimed to be low cost, with a minimum number of component types/values.

© 2015 CML Microsystems Plc COMPANY CONFIDENTIAL

### CONTENTS

<u>Se</u>	<u>etion</u>	age
1	Brief Description	.1
2	Block Diagram	. 5
3	Preliminary Information	.6 .6 .6 .6 .6 .6 .7 .8 .8 .9
	4.3.2       Rx Configuration         4.4       Operate         1       4.5         Signal Lists       1	.9 10 11
5	Circuit Schematics and Board Layouts1	14
6	Detailed Description       1         6.1       Hardware Description       1         6.1.1       Harmonic Filter       1         6.1.2       Tx/Rx Switch       1         6.1.3       Coupler       1         6.1.4       Power Amplifier       1         6.1.5       Transmitter       1         6.1.6       Receiver       1         6.1.7       Local Oscillator       1         6.1.8       Reference Oscillator       1         6.1.9       Power Supply       1         6.1.10       Inductors       1         6.2       Adjustments and Controls       1         6.2.1       External/Internal LO       1         6.3       Software Description       1         6.4       Application Information       1         6.4.1       Scripts       1         6.4.2       Typical Receiver Results with CMX7164 FI-4       2         6.4.3       Typical Transmit Performance with CMX7164 FI-4       2         6.5.1       Receiver Operation       2         6.5.1       Receiver Operation       2         6.5.2       Transmitter Operation       2	17 177 177 177 177 18 18 19 19 19 19 19 19 228 535 335
7	Performance Specification       3         7.1       Electrical Performance       3         7.1.1       Absolute Maximum Ratings       3         7.1.2       Operating Limits       3         7.1.3       Operating Characteristics       3	36 36 36

	age
able 1 Signal List1	1
able 2 PE0003 Interface1	
able 3 Test Points1	2
able 4 Adjustments1	
able 5 Changes to DE99411	4
able 6 Modification State ('Mod State') Definitions1	
able 7 DE9941 Channel Table2	20
able 8 Sensitivity levels (mean power) for different gross (on-air) bit rates in a 25kHz channel 2	24
able 9 4-QAM Rx Adjacent Channel Rejection with a TETRA interferer at +/-25kHz offset2	25
able 10 16-QAM Rx Adjacent Channel Rejection with a TETRA interferer at +/-25kHz offset2	26
able 11 64-QAM Rx Adjacent Channel Rejection with a TETRA interferer at +/-25kHz offset2	26
able 12 Co-channel Performance for different gross (on-air) bit rates2	26
able 13 Rx Intermodulation Performance for 4-QAM in normal mode	
able 14 4-QAM Rx Blocking Performance2	28
able 15 Tx Performance at 459.25MHz with different QAM and Channel Filter Types2	
able 16 Summary of 16-QAM Tx Output Power and ACP Performance	29
able 17 Receiver – Possible Errors	35
able 18 Transmitter – Possible Errors	35

Figure 1Block Diagram5Figure 2Typical Evaluation Connections for DE99418Figure 3PCB Layout: top15Figure 4PCB Layout: bottom16Figure 5Tx Setup 121Figure 6Tx Setup 222Figure 7Rx Sensitivity with 4-QAM, 16-QAM and 64-QAM24Figure 8Rx Sensitivity at different frequencies with 4-QAM25Figure 94-QAM, 16-QAM and 64-QAM Co-Channel Performance27Figure 1016-QAM ACP Performance at 459.75MHz29Figure 1116-QAM ACP Performance at 452.25MHz30Figure 1216-QAM ACP Performance at 467.25MHz30Figure 1316-QAM Constellation at 459.75MHz31Figure 1416QAM Eye Diagram at 459.75MHz31Figure 1516-QAM EVM, symbol/error table at 459.75MHz32Figure 16Wideband plots of Tx at 452.25MHz32Figure 17Wideband plots of Tx at 459.75MHz33Figure 18Wideband plots of Tx at 467.25MHz33	<u>Figure</u>		<u>Page</u>
Figure 3 PCB Layout: top       15         Figure 4 PCB Layout: bottom       16         Figure 5 Tx Setup 1       21         Figure 6 Tx Setup 2       22         Figure 7 Rx Sensitivity with 4-QAM, 16-QAM and 64-QAM       24         Figure 8 Rx Sensitivity at different frequencies with 4-QAM       25         Figure 9 4-QAM, 16-QAM and 64-QAM Co-Channel Performance       27         Figure 10 16-QAM ACP Performance at 459.75MHz       29         Figure 11 16-QAM ACP Performance at 452.25MHz       30         Figure 12 16-QAM ACP Performance at 467.25MHz       30         Figure 13 16-QAM Constellation at 459.75MHz       31         Figure 14 16QAM Eve Diagram at 459.75MHz       31         Figure 15 16-QAM EVM, symbol/error table at 459.75MHz       32         Figure 16 Wideband plots of Tx at 452.25MHz       32         Figure 17 Wideband plots of Tx at 459.75MHz       33	Figure 1	Block Diagram	5
Figure 4PCB Layout: bottom16Figure 5Tx Setup 121Figure 6Tx Setup 222Figure 7Rx Sensitivity with 4-QAM, 16-QAM and 64-QAM24Figure 8Rx Sensitivity at different frequencies with 4-QAM25Figure 94-QAM, 16-QAM and 64-QAM Co-Channel Performance27Figure 1016-QAM ACP Performance at 459.75MHz29Figure 1116-QAM ACP Performance at 452.25MHz30Figure 1216-QAM ACP Performance at 467.25MHz30Figure 1316-QAM Constellation at 459.75MHz31Figure 1416QAM Eye Diagram at 459.75MHz31Figure 1516-QAM EVM, symbol/error table at 459.75MHz32Figure 16Wideband plots of Tx at 452.25MHz32Figure 17Wideband plots of Tx at 459.75MHz33	Figure 2	Typical Evaluation Connections for DE9941	8
Figure 5 Tx Setup 121Figure 6 Tx Setup 222Figure 7 Rx Sensitivity with 4-QAM, 16-QAM and 64-QAM24Figure 8 Rx Sensitivity at different frequencies with 4-QAM25Figure 9 4-QAM, 16-QAM and 64-QAM Co-Channel Performance27Figure 10 16-QAM ACP Performance at 459.75MHz29Figure 11 16-QAM ACP Performance at 452.25MHz30Figure 12 16-QAM ACP Performance at 467.25MHz30Figure 13 16-QAM Constellation at 459.75MHz31Figure 14 16QAM Eye Diagram at 459.75MHz31Figure 15 16-QAM EVM, symbol/error table at 459.75MHz32Figure 16 Wideband plots of Tx at 452.25MHz32Figure 17 Wideband plots of Tx at 459.75MHz33	Figure 3	PCB Layout: top	15
Figure 6 Tx Setup 222Figure 7 Rx Sensitivity with 4-QAM, 16-QAM and 64-QAM24Figure 8 Rx Sensitivity at different frequencies with 4-QAM25Figure 9 4-QAM, 16-QAM and 64-QAM Co-Channel Performance27Figure 10 16-QAM ACP Performance at 459.75MHz29Figure 11 16-QAM ACP Performance at 452.25MHz30Figure 12 16-QAM ACP Performance at 467.25MHz30Figure 13 16-QAM Constellation at 459.75MHz31Figure 14 16QAM Eye Diagram at 459.75MHz31Figure 15 16-QAM EVM, symbol/error table at 459.75MHz32Figure 16 Wideband plots of Tx at 452.25MHz32Figure 17 Wideband plots of Tx at 459.75MHz33	Figure 4	PCB Layout: bottom	16
Figure 7Rx Sensitivity with 4-QAM, 16-QAM and 64-QAM24Figure 8Rx Sensitivity at different frequencies with 4-QAM25Figure 94-QAM, 16-QAM and 64-QAM Co-Channel Performance27Figure 1016-QAM ACP Performance at 459.75MHz29Figure 1116-QAM ACP Performance at 452.25MHz30Figure 1216-QAM ACP Performance at 467.25MHz30Figure 1316-QAM Constellation at 459.75MHz31Figure 1416QAM Eye Diagram at 459.75MHz31Figure 1516-QAM EVM, symbol/error table at 459.75MHz32Figure 16Wideband plots of Tx at 452.25MHz32Figure 17Wideband plots of Tx at 459.75MHz33	Figure 5	Tx Setup 1	21
Figure 8Rx Sensitivity at different frequencies with 4-QAM25Figure 94-QAM, 16-QAM and 64-QAM Co-Channel Performance27Figure 1016-QAM ACP Performance at 459.75MHz29Figure 1116-QAM ACP Performance at 452.25MHz30Figure 1216-QAM ACP Performance at 467.25MHz30Figure 1316-QAM Constellation at 459.75MHz31Figure 1416QAM Eye Diagram at 459.75MHz31Figure 1516-QAM EVM, symbol/error table at 459.75MHz32Figure 16Wideband plots of Tx at 452.25MHz32Figure 17Wideband plots of Tx at 459.75MHz33	Figure 6	Tx Setup 2	22
Figure 94-QAM, 16-QAM and 64-QAM Co-Channel Performance27Figure 1016-QAM ACP Performance at 459.75MHz29Figure 1116-QAM ACP Performance at 452.25MHz30Figure 1216-QAM ACP Performance at 467.25MHz30Figure 1316-QAM Constellation at 459.75MHz31Figure 1416QAM Eye Diagram at 459.75MHz31Figure 1516-QAM EVM, symbol/error table at 459.75MHz32Figure 16Wideband plots of Tx at 452.25MHz32Figure 17Wideband plots of Tx at 459.75MHz33	Figure 7	Rx Sensitivity with 4-QAM, 16-QAM and 64-QAM	24
Figure 10       16-QAM ACP Performance at 459.75MHz       .29         Figure 11       16-QAM ACP Performance at 452.25MHz       .30         Figure 12       16-QAM ACP Performance at 467.25MHz       .30         Figure 13       16-QAM Constellation at 459.75MHz       .31         Figure 14       16QAM Eye Diagram at 459.75MHz       .31         Figure 15       16-QAM EVM, symbol/error table at 459.75MHz       .32         Figure 16       Wideband plots of Tx at 452.25MHz       .32         Figure 17       Wideband plots of Tx at 459.75MHz       .33	Figure 8	Rx Sensitivity at different frequencies with 4-QAM	25
Figure 1116-QAM ACP Performance at 452.25MHz	Figure 9	4-QAM, 16-QAM and 64-QAM Co-Channel Performance	27
Figure 1216-QAM ACP Performance at 467.25MHz	Figure 10	16-QAM ACP Performance at 459.75MHz	29
Figure 1316-QAM Constellation at 459.75MHz.31Figure 1416QAM Eye Diagram at 459.75MHz.31Figure 1516-QAM EVM, symbol/error table at 459.75MHz.32Figure 16Wideband plots of Tx at 452.25MHz.32Figure 17Wideband plots of Tx at 459.75MHz.33	Figure 11	16-QAM ACP Performance at 452.25MHz	30
Figure 1416QAM Eye Diagram at 459.75MHz.31Figure 1516-QAM EVM, symbol/error table at 459.75MHz.32Figure 16Wideband plots of Tx at 452.25MHz.32Figure 17Wideband plots of Tx at 459.75MHz.33	Figure 12	16-QAM ACP Performance at 467.25MHz	30
Figure 1516-QAM EVM, symbol/error table at 459.75MHz	Figure 13	16-QAM Constellation at 459.75MHz	31
Figure 16 Wideband plots of Tx at 452.25MHz	Figure 14	16QAM Eye Diagram at 459.75MHz	31
Figure 17 Wideband plots of Tx at 459.75MHz	Figure 15	16-QAM EVM, symbol/error table at 459.75MHz	32
	Figure 16	Wideband plots of Tx at 452.25MHz	32
Figure 18 Wideband plots of Tx at 467.25MHz	Figure 17	Wideband plots of Tx at 459.75MHz	33
	Figure 18	Wideband plots of Tx at 467.25MHz	33
Figure 19 Ramp-up and Ramp-down Profile (QAM)	Figure 19	Ramp-up and Ramp-down Profile (QAM)	33
Figure 20 Tx Ramp Profile (QAM)	Figure 20	Tx Ramp Profile (QAM)	34

It is always recommended that you check for the latest product datasheet version from the Products page of the CML website: [www.cmlmicro.com].

#### DE9941

### <u>History</u>

Version	Changes	Date
3	Updated to include CMX994E and other relevant changes for mod state 5.	02/12/15
2	Details of modification states 3 and 4 added in section 5.	5/7/13
1	First Issue	19/09/12

# 2 Block Diagram




Figure 1 Block Diagram

### 3 **Preliminary Information**

The DE9941 provides a RF platform for evaluation of the CMX7164 Multi-mode Wireless Data Modem, with the use of the CMX994E Direct Conversion Receiver and the CMX998 Cartesian Loop Transmitter. A 1W power amplifier has been included plus PLL and VCO for stand-alone operation.

The DE9941 is designed to be used with the PE0003 Evaluation Kit interface Card (see <u>www.cmlmicro.com</u> for more information) which provides controller functionality from a PC interface. PC software is available for use with the PE0003. This software allows scripts to be used to control the CMX7164. All RF circuits are controlled via the CMX7164 C-BUS interface. Various scripts are available for use with the DE9941 and a PE0003 (see section 6.4.1). Alternatively the user may connect their own host controller solution to the control interface (J3).

### 3.1 Laboratory Equipment

The following laboratory equipment is needed to use this evaluation kit:

- Power Supply
- Spectrum Analyser
- RF Signal Generator
- Oscilloscope
- Personal Computer + PE0003 or other C-BUS microcontroller

For more detailed design or investigation work, additional RF test equipment may be required.

### 3.1.1 Power Supply

The supply input voltage to the PCB is nominally 3.6V (3.5V to 4.0V acceptable). On-board regulators are provided to generate all voltage rails used on the PCB (3.3V). The 3.6V supply should be rated at 2A.

**NOTE:** Care should be exercised with the supplies as they are not protected for reverse polarity. The 3.6V supply directly feeds the power amplifier and it should not exceed 4.8V for nominal operating limits.

### 3.2 Handling Precautions

Like most evaluation kits, this product is designed for use in office and laboratory environments. The following practices will help ensure its proper operation.

### 3.2.1 Static Protection

This product uses low-power CMOS circuits that can be damaged by electrostatic discharge. Partially damaged circuits can function erroneously, leading to misleading results. Observe ESD precautions at all times when handling this product.

### 3.2.2 Contents - Unpacking

Please ensure that you have received all of the items on the separate information sheet (EK9941) and notify CML within seven working days if the delivery is incomplete.

### 3.3 Approvals

This product is not approved to any EMC or other regulatory standard. Users are advised to observe local statutory requirements, which may apply to this product and the radio frequency signals that may emanate from it.

### 4 Quick Start

This section provides instructions for users who wish to experiment immediately with this Evaluation Kit at 459.25MHz. A more complete description of the kit and its uses appears later in this document. The user should read the appropriate CMX7164, CMX994E and CMX998 Datasheets plus the PE0003 User Manuals before using the DE9941 board.

This Quick Start configuration assumes that the user has a CML PE0003 Evaluation Kit Interface Card and that the PE0003 provides the interface between DE9941 and a controlling PC.

### 4.1 Setting-Up

The following procedure is recommended:

- 1. Connect the boards as shown in Figure 2. J1 should be connected to either an RF signal generator or Spectrum analyser via a suitable  $50\Omega$  attenuator. If testing the transmitter, the RF output J1 should be connected to a suitable  $50\Omega$  load. THE USE OF AN EXTERNAL 50  $\Omega$  LOAD IS ESSENTIAL TO PREVENT POSSIBLE
- 2. Connect the PE0003 to the DE9941 C-BUS interface connector J3.

DAMAGE TO THE RF POWER AMPLIFIER STAGE.

- 3. Apply power to PE0003 and the DE9941.
- 4. Install the PE0003 software when prompted. see PE0003 User Manual.
- 5. The CMX7164 fitted to the DE9941 must be loaded with the required Function Image<sup>™</sup>.This can be done using the PE0003 GUI. Programming of the RF PLL IC (SKY72300), the CMX994E and the CMX998 is via the PE0003 using a suitable script, for which examples are available (see section 6.4.1).

The board is now ready for operation.




Figure 2 Typical Evaluation Connections for DE9941

### 4.1.1 PE0003 Software and Driver Installation

See the PE0003 User Manual for information on installing and using the PE0003.

### 4.2 Adjustments

VC1 is a trimmer capacitor used to centre the tuning voltage of the main VCO. The tuning voltage can be monitored at TP13. VC1 has been adjusted in production test and should not require user adjustment.

 $\ensuremath{\textcircled{}^{\odot}}$  2015 CML Microsystems Plc

The CMX7164 Multi-mode Modem must be loaded with a Function Image (FI) to initialise the device and determine the modulation type; FI-1.x supports GMSK/GFSK, FI-2.x supports 2/4FSK or FI-4.x supports 4/16/64-QAM. This User Manual focuses on FI-4.x because this fully utilities the Tx functionality due to QAM being a non-constant envelope modulation.

The following procedures allow the user to quickly setup the DE9941 for Rx or Tx operation.

### 4.3.1 Tx Configuration

The following steps will configure the DE9941 to transmit at 459.25MHz with a continuous 4-QAM PRBS modulated output. Set the applied signals and run the scripts (see section 6.4.1 for details on the scripts) in the order shown in the following table. Note: Ensure J1 is connected to a Spectrum analyser via a suitable  $50\Omega$  attenuator for Tx testing.

**Note:** Setting the CML device registers requires the use of the PE0003 host connected as above. The CML datasheets give details of the registers and commands.

Script/Command	Setting	Note
Setup_Tx_Rx_SDR	Script allows selection of;	Select mod size = 4, FI = 4, mode Tx, Baud rate
	<ul> <li>Mod size</li> </ul>	18ks/s, Channel No = 8 (Operating Frequency is
	• FI	459.25MHz).
	<ul> <li>Baud Rate</li> </ul>	
	Tx or Rx	
	<ul> <li>Frequency</li> </ul>	
Tx_only_test_SDR	Performs a DC Calibration	After this script has run the Tx output level should
_DCcal	on the Tx Cartesian loop	be <-25dBm, the output should be nulled
		unmodulated carrier. Leave PA Enabled.
Write \$32 to	Apply Tx PRBS	The Tx output will now be at full output power
modem control		(circa +25dBm mean) continuously. Note: due to
register (\$6B)		limited heatsinking in the compact design it is
		advised to avoid leaving the Tx in this state for
		long periods of time.

### 4.3.2 Rx Configuration

The following steps will configure the DE9941 to receive at 459.25MHz with a 2kHz tone IQ output. Set the applied signals and run the scripts (see section 6.4.1 for details on the scripts) as shown in the following table. Note; Ensure J1 is connected to a RF signal generator via a suitable  $50\Omega$  attenuator for Rx testing.

**Note:** Setting the CML device registers requires the use of the PE0003 host connected as above. The CML datasheets give details of the registers and commands.

Signal/Script	Setting	Note
ANTENNA (J1)	459.252MHz	The input level here may be user defined: for an input signal of -60dBm at J1, the typical single- ended output level would be ~420mVp-p at U6 pin 28. The output should be a 2kHz sine and cosine wave on I and Q when the configuration in this table is completed.

Signal/Script	Setting	Note
Setup_Tx_Rx_SDR	Script allows selection of;	Select mod size = 4, FI = 4, mode Rx, Baud rate
	Mod Size	18ks/s, Channel No = 8 (Operating Frequency is
	• FI	459.25MHz).
	Tx or Rx	
	<ul> <li>Baud Rate</li> </ul>	
	Frequency	
RXIQ	Rx IQ output.	The differential I and Q signals can be measured
(U6)		at U6 pins 28, 29, 31 or 32.

### 4.4 Operate

Following the configuration procedures given in sections 4.1, 4.2 and 4.3, the DE9941 should be operating as a transmitter or receiver at 459.25MHz. Various evaluation tests can now be performed.

# 4.5 Signal Lists

CONNECTOR PINOUT							
Connector Ref.	Connector Pin No.	Signal Name	Signal Type	Description			
J1	N/A	ANTENNA	RF	Tx Output or Rx Input			
J2	2	+V	DC	3.6V Power supply input			
J2	1	GNDA	DC	Power supply ground			

CONN	ECTOR PINOUT f		
Connector Pin No.	Signal Name	Signal Type	Description
1	RESETN	I/P	General RESET (RESET active low)
2	CSN	I/P	C-BUS Enable
3	~	~	Spare pin. Leave unconnected
4	CDATA	I/P	C-BUS Data Input
5	~	~	Spare pin. Leave unconnected
6	SCLK	I/P	C-BUS Clock
7	~	~	Spare pin. Leave unconnected
8	RDATA	O/P	C-BUS Data Output
9	~	~	Spare pin. Leave unconnected
10	IRQN	I/P	Interrupt Request
11	GNDD	Power	Connection to Digital Ground
12	GNDD	Power	Connection to Digital Ground
13	~	~	Spare pin. Leave unconnected
14	~	~	Spare pin. Leave unconnected
15	~	~	Spare pin. Leave unconnected
16	~	~	Spare pin. Leave unconnected
17	~	~	Spare pin. Leave unconnected
18	~	~	Spare pin. Leave unconnected
19	~	~	Spare pin. Leave unconnected
20	~	~	Spare pin. Leave unconnected

Table 2 PE0003 Interface

TEST	POINTS			
Test Point Ref.	Default Measurement	Description		
TP1	-	AUXADC1 – Tx Instability Detector Output		
TP2	1.6V DC	CMX998 BVRef (Buffered Vref)		
TP3	-	AUXADC3 – CMX998 Q Feedback Path Output		
TP4	-	AUXADC4 – CMX998 I Feedback Path Output		
TP5	-	AUXADC2 – CMX998 DC Meas – used for DC Calibration		
TP6	-	RF5110G Power Amplifier Control Voltage		
TP7	-	TXEN+V – Tx/Rx PIN switch supply		
TP8	3.3V DC	CMX994E Vddio Power Supply Voltage		
TP10	-	VCO Control Voltage when using CMX994E PLL		
TP11	-	SKY72300 Frac N Synth Mux Output		
TP12	-	SKY72300 Frac N Synth Lock Detect Output		
TP13	-	VCO Control Voltage when using SKY72300 Skyworks Frac N PLL		
TP14	-	CMX7164 – SYSCLK1		
TP15	-	CMX7164 – SYSCLK2		
TP16	-	CMX7164 – Not connected pin		
TP17	-	CMX7164 – Not connected pin		
TP18	-	CMX7164 – Not connected pin		
TP19	-	CMX7164 – Not connected pin		
TP20	-	CMX7164 – Not connected pin		
TP21	-	CMX7164 – Not connected pin		
TP22	-	CMX7164 – Not connected pin		
TP23	-	CMX7164 – Not connected pin		
TP24	-	CMX7164 – Not connected pin		
TP25	-	CMX7164 – MOSI – SPI Data Out		
TP26	-	CMX7164 – SSOUT1 – SPI Chip Select 1		
TP27	-	CMX7164 – SSOUT2 – SPI Chip Select 2		
TP28	-	CMX7164 – CLK – SPI Clock		
TP29	-	AUXDAC2 – VCTCXO Control Voltage		
TP30	3.3V DC	CMX7164 Digital Power Supply		
TP31	3.3V DC	CMX7164 Analogue Power Supply		
TP32	3.3V DC	Tx and Rx Analogue Power Supply		
TP33	3.3V DC	VCO and PLL Power Supply		

Table 3 Test Points

ADJUSTMENTS					
Adjustment Ref.	Adjustment	Adjustment Range	Description		
VC1	VCO Tuning	1 - 3V DC	Adjustment used to centre the tuning volts of the main VCO		

### Table 4 Adjustments

Notes:	I/P	=	Input
	O/P	=	Output
	TP	=	Test Point

The DE9941 circuit schematic is available as separate high-resolution files, which can be downloaded from the CML website. A 0R link has been added between the analogue and digital ground planes. This has been placed near C87 and C96 on the top layer. The circuit reference on the schematic is R121. Screening is provided over the connector J1, primarily to improve receiver performance.

The layout on each side of the pcb is shown in Figure 3 and Figure 4.

The DE9941 kit was originally released as a Mod State 2 board (dwg9941B02.pdf schematics). Some improvements have been made to the kit and it is currently at Mod State 4 (dwg9941B04.pdf). A list of these modifications appears below, for customers who may wish to update their earlier Mod State boards.

No.	Circuit Area & Component Reference	Comment	Change
12	C131 VCO Resonator C	Capacitor tolerance has affected the VCO nominal tuning range, to bring VCO into correct range series C to variable cap has been adjusted.	Change C131 to 3.3pF +/- 0.1pF to match C128
13	L2 RF5110G Vcc1 Supply Inductor	Following investigation into transient performance it was found necessary to dampen the PA gain response, most importantly as a function of sharp gain transition over frequency at certain regions of the PA control curve. Adding a 18R at Vcc1 supply choke created this effect (note this is a change indicated in later versions of the RF5110G datasheet application circuit).	Change L2 to 18R 0603 resistor
14	PA Input Pad R58, R60 and R61	Due to the PA gain reducing because of mod #13 it was necessary to reduce the PA input pad to 6dB.	Change R58 to 39R (0402) Change R60 and R61 to 150R (0402)
15	C47 PA Control Circuit	See mod #13 relating to transient performance; it was found that in certain regions of the RF5110G control range there were signs of instability, adding a $1\mu$ F capacitor at C47 stopped this. Also C47 shapes the PA control curve.	Change C47 to 1µF (0402)

### Table 5 Changes to DE9941

Mod State	Changes	Hi-Res Schematic Drawings	Date
1	No modifications	(B01)	27/4/12
2	Modifications 1-11 (first release)	dwg9941B02.pdf	2/8/12
3	As mod state 2 plus modification 12	dwg9941B03.pdf	23/11/12
4	As mod state 3 plus modifications 13 to 15	dwg9941B04.pdf	20/6/13
5	As mod state 4 but with CMX994E fitted instead of CMX994	dwg9941B05.pdf	2/12/15

### Table 6 Modification State ('Mod State') Definitions

**Note:** The 'mod state' of a particular PCB can be determined from the 'Board Mod' box on the PCB. The number of figures with black dots is the 'mod state' thus 'mod state' 3 is shown thus:

B	oard	Mod	
•	•	•	4
5	6	7	8

Note Mod state 5 boards include the CMX994E instead of the CMX994 and mod state 4 modifications as listed.




Figure 3 PCB Layout: top




Figure 4 PCB Layout: bottom

## 6 Detailed Description

The DE9941 functionality includes:

- Nominal +3.6V Supply
- Direct Conversion Receiver
- Cartesian Loop Transmitter
- 1W Power Amplifier
- VCO and Fractional-N PLL
- 19.2MHz VCTCXO
- Operation from 452MHz to 467MHz
- The C-BUS Interface that allows the card to be connected to a host µController. A PC Interface board is separately available (PE0003) and allows control of all device functions, to support initial test and customer evaluation.
- Capability to demonstrate the performance of the CMX7164 Multi-mode Modem, for example 4/16/64-QAM, 2/4FSK and GMSK.

In summary, the DE9941 allows the user to create experiments to investigate all aspects of the CMX7164 device using an RF platform based around the CMX994E Direct Conversion Receiver and the CMX998 Cartesian Loop Transmitter. The DE9941 is designed to allow user modification, to support the detailed investigation of the user's specific and different applications. The evaluation platform also includes additional circuits that allow the user to use the DE9941 standalone, for example a fractional-N PLL (U5) and a high-frequency VCO (TR6/TR7).

### 6.1 Hardware Description

### 6.1.1 Harmonic Filter

L5, L6 and associated components form a low-loss low pass filter with taps centred at the  $2^{nd}$  and  $3^{rd}$  Tx harmonics. This filter is common to the transmitter and receiver paths and is connected between the Tx/Rx switch and the antenna connector J1.

### 6.1.2 Tx/Rx Switch

The Tx/Rx switch is a classic series-shunt switch using PIN diodes (D2 and D3) after a lumped quarter wave section. The diodes are activated in transmit via the GPIOC/TXD signal from the CMX7164. An additional diode is provided (at D3), in anti-parallel, to protect the LNA from extremely strong signals (e.g. a nearby transceiver). This branch of the switch then goes to the receiver input.

### 6.1.3 Coupler

The coupler is a lumped coupler formed around one of the low pass sections of the harmonic filter (L5). The signal is coupled from this low pass section to another low pass section (L1) via very low value capacitors (C60 & C61). The coupling factor is  $\sim$  28dB and the output of the coupler forms part of the feedback path to the CMX998 to create the Tx Cartesian Loop.

### 6.1.4 Power Amplifier

The DE9941 includes a 1W Power Amplifier U2 (RF5110G) configured for 450MHz to 470MHz operation and is capable of producing ~+25dBm (mean) output power with 16-QAM modulation.

The CMX7164 RAMDAC (AUXDAC1) output is connected to the PA control line via a diode and transistor (D1 and TR2) to provide sufficient current to the PA control pins.

### 6.1.5 Transmitter

The transmitter is based on the CMX998 Cartesian Feedback Loop (CFBL) IC plus the PA and coupler which complete the loop. The up-converter and down-converter are matched with broadband baluns. The LO input is configured for single-ended operation with matching applied for the default DE9941 operating

frequencies. The LO has been configured single ended as the LO is at four times the final operating frequency (~1.8GHz). The CMX998 IQ differential inputs are provided straight from the CMX7164 main DAC's. The error amplifier is configured with a loop filter optimised for operation with the on-board power amplifier and for modulation bandwidths up to 25kHz.

The DCMEAS pin is connected to an AUXADC on the CMX7164 to allow automatic DC calibration and the ability to control the PA from the CMX7164.

The CMX998 is controlled via the CMX7164 SPI-Thru port using chip select 1 (SSOUT1).

#### 6.1.6 Receiver

The receiver uses the CMX994E Direct Conversion Receiver IC, capable of supporting a range of digital radio systems of both constant envelope and linear modulation types. The CMX994E integrated LNA has been utilised with the output of the LNA matched directly to the IQ down conversion mixer. The mixer convert the received signal to IQ baseband format, where C87 and C90 combine with on-chip components to remove off-channel signals. The signal is then amplified before further filtering to remove adjacent channel signals (C88 and C89). The nominal maximum bandwidth of the adjacent channel filters is 8kHz and this is scaled by a factor of 2 or 4 in the other filter bandwidth states. A final amplifier stage completes the receiver line-up, providing differential IQ outputs directly to the CMX7164 Main ADC's.

The overall receiver gain and noise figure for the default configuration is ~62.5dB and 7dB respectively. The Rx input third-order intercept point is ~ -2 to -3dBm in normal mode and ~+1 to +2 dBm in enhanced mode.

The LO input is at four times the final operating frequency.

The CMX994E is controlled via the CMX7164 SPI-Thru port using chip select 1 (SSOUT1).

#### 6.1.7 Local Oscillator

The LO (Local Oscillator) for the Tx and the Rx is at four times the final operating frequency. This is achieved with a VCO at 603MHz to 623MHz and then applying a tripler which gives a LO frequency range of 1809MHz to 1869MHz. After the tripler is a SAW filter (FL1 – Golledge MA05897) which reduces all the spurious frequencies from the tripler and ensures that there is enough LO level for the CMX994E and CMX998. There is a buffer stage at the output of the SAW filter.

The VCO consists of TR6 and TR7 which are connected in DC cascode and share the same input biasing network. At RF frequencies TR6 works as a common emitter amplifier with the emitter grounded through C126. The oscillator stage is fed to the buffer amplifier through the coupling capacitor C127. To ensure that the frequency range of the VCO can be achieved with good noise performance, a variable capacitor (VC1) has been included to centre the VCO tuning range.

The tripler is based around TR5.The final LO buffer is a general purpose silicon bipolar RFIC gain block amplifier (U4 – ADA-4743). At the output of the LO buffer is a  $50\Omega$  splitter that feeds the CMX994E and CMX998. The output level from the splitter is ~ -10dBm.

The VCO is locked with a Skyworks Fractional N PLL (U5 - SKY72300) controlled via the CMX7164 SPI Thru port and uses chip select 2 (SSOUT2). Circuitry is also included on the board which will allow the user to use the integer-N PLL on the CMX994E if this is desirable over the Frac-N PLL.

If required an external LO source can be used instead of the on-board VCO.

### 6.1.8 Reference Oscillator

A 1.5ppm 19.2MHz VCTCXO (Golledge MP05955 is used as the reference for the Frac-N PLL and the CMX7164.

<sup>© 2015</sup> CML Microsystems Plc

#### 6.1.9 Power Supply

The input to the PCB is nominally 3.6V (3.5V to 4V is acceptable). On-board regulators are provided to generate voltage rails used on the DE9941.

### 6.1.10 Inductors

All inductors used in the RF sections of the design are manufactured by Coilcraft (<u>www.coilcraft.com</u>). Performance of the circuits with inductors from other manufacturers may vary.

### 6.2 Adjustments and Controls

The user has the ability to configure the DE9941 for a number of different operational scenarios.

### 6.2.1 External/Internal LO

The DE9941 has two options for the LO, the default is the on-board VCO plus tripler, SAW filter and buffer. Alternatively, an external LO may be applied at J4 but L15 and R79 should be removed and R82 moved to position R120.

### 6.3 Software Description

Please refer to the PE0003 User Manual for detailed description of the software (see <u>www.cmlmicro.com</u> for more information). The Serial Memory Programming Tab is not applicable with the DE9941.

Section 6.4.1 gives detailed information about scripts developed for the DE9941 Evaluation kit. These can be executed through the PE0003 Script Handler.

### 6.4 Application Information

See section 4.1 for board setup details and section 4.3 for operating the DE9941 as a transmitter or receiver.

### 6.4.1 Scripts

The following scripts are available to support the DE9941:

- Setup\_Tx\_Rx\_SDR Must be run first on the Tx and Rx device
- Tx\_only\_test\_SDR\_DCcal Only used with the Tx device if a DE9941 is used
- SDR\_test\_ber\_tx\_rx BER Script to be run first on the Rx device and then on the Tx device

The scripts assume that the user has two PE0003's, one for Tx and one for Rx. Below is a brief description of what the scripts do:

#### Setup\_Tx\_Rx\_SDR

This script includes a channel table which allows the PLL to be programmed over the entire operating range of 452.25MHz to 467.25MHz in 1MHz steps. The channel table is shown in Table 7.

Frequency (MHz)	Channel No
452.25	1
453.25	2
454.25	3
455.25	4
456.25	5
457.25	6
458.25	7
459.25	8
460.25	9
461.25	10
462.25	11
463.25	12
464.25	13
465.25	14
466.25	15
467.25	16

Table 7 DE9941 Channel Table

The script configures the CMX994E or CMX998 depending on whether it is a transmitter or receiver. The script assumes there are two possible setups for the Tx source: Setup 1 (see Figure 5) and Setup 2 (see Figure 6).

### Setup 1. The Tx is a DE9941.





Figure 5 Tx Setup 1



Setup 2. The Tx is a PE0601 providing an IQ source to an IQ vector signal generator.

Figure 6 Tx Setup 2

The External Buffer Board shown in Figure 6 provides signal conditioning to ensure that the DC conditions of the IQ input are accurate, so that the carrier suppression of the signal generator output is >40dBc. This setup was used to do the detailed Rx Performance Measurements (see section 6.4.2).

This script also sets up the baud rate and channel filters for Tx and Rx. The default channel filter selection in the case of FI-4 is RRC alpha = 0.2. Note: different Tx gain settings (CMX7164 registers B4 and B5) need to be used with the different QAM types and filter types (the script has the nominal gain settings for the alpha = 0.2 case and there are values noted in the script comments for alpha = 0.35).

### Tx\_only\_test\_SDR\_DCcal

This script only needs to be used with the transmitter when a DE9941 is being used – Setup 1. It performs the CMX998 DC calibration over a requested number of bursts and blocks. For the first blocks sent, a full DC calibration is done and then subsequent calibrations are done in high-gain mode only. The PA is also ramped up and down in this script according to the DC calibration timings.

At the end of the DC calibration script, the user has the option to keep the PA enabled. At this point the user can then enable a Tx PRBS transmission by writing \$32 to the modem control register (\$6B) of the CMX7164 using the PE0003 C-BUS Control Tab. The modulated Tx output will now be at full output power (circa +25dBm mean) continuously. Note: due to limited heat sinking in the compact design it is advised to avoid leaving the Tx in this state for long periods of time.

### SDR\_test\_ber\_tx\_rx

As with the setup script this script assumes that there are two PE0003 boards, one for Tx and one for Rx. The script trains the Receiver Response Equaliser for QAM modulation types and then runs a BER test. The equaliser must be trained with 4-QAM and with an Rx Input signal level of ~ -65 to -60dBm. The default values in the script for the equaliser gain and duration can be used. Further information on the Receiver Response Equaliser can be found in the CMX7164 datasheet. When the equaliser has been trained the user can select the QAM Type but the script assumes that the FI being used is FI-4. The Rx will display the total number of errors at the end of the test with more detailed information being written to a text file. The number of bursts sent is displayed by the transmitter so that the user can confirm the number being received.

### 6.4.2 Typical Receiver Results with CMX7164 FI-4

The Receiver Response Equaliser within the CMX7164 has been used in single mode to create a channel filter that has compensation for the ADC's and also the channel filtering within the Rx chain. The AAF (Anti-Alias filter in the CMX7164) is at its default setting of 50kHz, 3 dB bandwidth. The ACR (Adjacent Channel Rejection) filters on the CMX994E are in the maximum bandwidth state (typically 8kHz -3dB bandwidth).

In all of the following results the data rate is 18ksymbols/s and, in the following table, the raw over-air bit rate for the three different modulation types have been highlighted. Also, the RRC channel filter used in all cases has an alpha of 0.2. Parametric measurements and graphs shown are typical only, not guaranteed performance limits.

QAM Modulation Type	Bits per Symbol	Base Over-air Bit Rate (18,000 symbols/s)	Raw Mode Over-air Bit Rate (18,000 symbols/s)
4-QAM	2	36,000 bps	32,000 bps
16-QAM	4	72,000 bps	64,000 bps
64-QAM	6	108,000bps	96,000 bps

The difference between the base over-air rate and the raw mode rate (which is the actual user data rate in raw mode at 18ksymbols/second) is due to some symbols being used internally by the modem to perform channel equalisation. All measurements reference ETSI EN 302 561 (v1.2.1 – Dec 2009) specification.

All of the detailed receiver performance results were taken with a CML PE0601-7164 and an IQ Vector Signal Generator as the wanted signal.

### Sensitivity

Table 8 shows the EN 302 561 sensitivity specification limits; these limits are to be met at a BER of 10<sup>-2</sup>:

Channel BW	Data Rate	Sensitivity
	38,4 kbit/s or less	-111 dBm
25 kHz	38,5 kbits to 76,8 kbit/s	-104 dBm
	Greater than 76,8 kbit/s	-99 dBm

Table 8 Sensitivity levels (mean power) for different gross (on-air) bit rates in a 25kHz channel

Sensitivity results for the DE9941 for 4-QAM, 16-QAM and 64-QAM are shown in Figure 7; the results were taken at 459.25MHz. It can be seen that there is significant margin on the EN 302 561 limits above.




Figure 7 Rx Sensitivity with 4-QAM, 16-QAM and 64-QAM

The plot in Figure 8 shows the 4-QAM sensitivity performance at the top, middle and bottom of the frequency range; channel 16, 8 and 1 respectively.




Figure 8 Rx Sensitivity at different frequencies with 4-QAM

### Adjacent Channel Rejection

The adjacent channel rejection was measured with the wanted signal 3 dB above the limit specified in Table 8 and the unwanted signal TETRA modulated at  $\pm$ -25kHz offset. EN 302 561 states that a BER of less than 10<sup>-2</sup> should be achieved with an interferer level of -63dBm. The results in Table 9 show that this limit can be met with 4-QAM modulation, with ~8 dB margin.

	+25 kHz Offset	-25 kHz Offset
Interferer Level (dBm)	BER	BER
/		
-60	4.75E-05	3.42E-05
-59	1.67E-04	
-58	5.85E-04	4.77E-04
-57	1.54E-03	
-56	2.92E-03	2.62E-03
-55	6.96E-03	
-54	1.39E-02	1.24E-02

Table 9 4-QAM Rx Adjacent Channel Rejection with a TETRA interferer at +/-25kHz offset

	+25 kHz Offset	-25 kHz Offset
Interferer Level (dBm)	BER	BER
-63	3.33E-06	
-62	1.25E-05	7.50E-06
-61	2.42E-05	
-60	5.25E-05	
-58	6.33E-04	6.03E-04
-56	2.72E-03	
-54	1.15E-02	9.93E-03

The results in Table 10 show that this limit can be met with 16-QAM modulation, with ~7dB margin.

Table 10 16-QAM Rx Adjacent Channel Rejection with a TETRA interferer at +/-25kHz offset

The results in Table 11 show that this limit can be met with 64-QAM modulation, with ~7dB margin.

	+25 kHz Offset	-25 kHz Offset
Interferer Level (dBm)	BER	BER
-62	1.53E-04	1.27E-04
-60	5.81E-04	4.68E-04
-56	6.63E-03	5.54E-03
-55	1.12E-02	9.45E-03

Table 11 64-QAM Rx Adjacent Channel Rejection with a TETRA interferer at +/-25kHz offset

### **Co-Channel Rejection**

The co-channel rejection was measured with the wanted signal 3dB above the limit specified in Table 8 and the unwanted signal TETRA modulated on frequency.

EN 302 561 co-channel specification limits are as follows and these limits are to be met at a BER of 10<sup>-2</sup>:

Channel BW	Data Rate	Co-channel
	38,4 kbit/s or less	-12 dB
25 kHz	38,5 kbits to 76,8 kbit/s	-19 dB
	Greater than 76,8 kbit/s	-24 dB

### Table 12 Co-channel Performance for different gross (on-air) bit rates

The results for 4-QAM, 16-QAM and 64-QAM co-channel performance are shown in Figure 9. It can be seen that the EN 302 561 can be met in all cases with more than 3 dB margin.

<sup>© 2015</sup> CML Microsystems Plc




Figure 9 4-QAM, 16-QAM and 64-QAM Co-Channel Performance

### Intermodulation

Intermodulation was measured against EN 302 561, which specifies that the wanted tone is 3 dB above the limit specified in Table 8 and the spacing between the unwanted tones is 200kHz for a channel bandwidth of 25 kHz. The first unwanted tone was at 459.45MHz and was un-modulated. The second unwanted tone was at 459.65MHz and was TETRA modulated. The EN 302 561 limit is at an unwanted tone level of -47dBm at a BER of less than 10<sup>-2</sup>. The results for 4-QAM are given in Table 13: they show the EN 302 561 can be met comfortably.

Interferer Level (dBm)	BER	Separation (dB)
-42	3.21E-04	66
-41	2.27E-03	67
-40.5	5.67E-03	67.5
-40	1.27E-02	68

 Table 13 Rx Intermodulation Performance for 4-QAM in normal mode

### Blocking

The wanted 4-QAM signal level was -108dBm and an interferer was generated by the HP8642A Low Noise Signal Generator, which was unmodulated. The EN 302 561 interferer level limit is -27dBm with the wanted signal 3 dB up from the sensitivity level in Table 8. The results show that in the 4-QAM mode, the EN 302 561 limit is met comfortably.

	Offset	+1MHz	-1MHz	+2MHz	-2MHz	+5MHz	-5MHz	+10MHz	-10MHz
Interferer Level (dBm)	Blocker (dBc)	BER							
-20	88	6.50E-05	6.08E-05	1.68E-05					
-18	90	8.03E-04	1.56E-03						
-17	91		3.86E-03						
-16	92	5.05E-03	9.66E-03	2.09E-03	2.00E-03	5.92E-04	7.17E-04	2.12E-04	4.72E-04

### Table 14 4-QAM Rx Blocking Performance

### **Rx Conducted Spurious**

All spurious are below -80dBm up to 1GHz.

### High Input Level Performance

With AGC ON in the CMX7164, the receiver can be seen to work up to 0dBm with 4-QAM modulation.

#### 6.4.3 Typical Transmit Performance with CMX7164 FI-4

The signal spectrum is identical in bandwidth when using 4-, 16- or 64-QAM. However, the peak-to-mean of each modulation type does vary.

4-QAM has a peak to mean of
16-QAM has a peak to mean of
64-QAM has a peak to mean of

5.3dB ( $\alpha$ =0.2) or 3.8dB ( $\alpha$ =0.35) 7.8dB ( $\alpha$ =0.2) or 6.4dB ( $\alpha$ =0.35) 9dB ( $\alpha$ =0.2) or 7.5dB ( $\alpha$ =0.35)

Table 15 shows some typical measurements at 459.25MHz, with the different QAM and channel filter types. Parametric measurements and graphs shown are typical only, not guaranteed performance limits.

	DAC Atten Value B4 & B5 (hex)	Mean O/P Power (dBm)	1 <sup>st</sup> ACP (dBc)
RRC alpha = 0.2			
4-QAM	12	26	65
16-QAM	F	24.4	65.5
64-QAM	E	23.8	66
RRC alpha = 0.35			
4-QAM	С	27.5	65/66
16-QAM	A	25.7	66
64-QAM	9	25	66/67

### Table 15 Tx Performance at 459.25MHz with different QAM and Channel Filter Types

Some further detailed results have been taken with 16-QAM modulation at 18ksymbols/s, with a RRC alpha = 0.2. These results are shown in the following sections.

#### 16-QAM ACP

The plot in Figure 10 was taken at 459.75MHz, Figure 11 is at 452.25MHz and Figure 12 is at 467.25MHz. In all cases the mean output power is >+25 dBm. Note that this includes ~1.2 dB loss through the Tx/Rx switch, harmonic filter/coupler. The peak to mean of 16-QAM is ~7.8 dB, based on a RRC alpha = 0.2 channel filter. A summary of results is shown in Table 16.

	452.25MHz	459.75MHz	467.25MHz
Mean output power	+25.89dBm	+25.57dBm	+25.58dBm
1 <sup>st</sup> ACP	65dBc	65dBc	65dBc
2 <sup>nd</sup> ACP	76dBc	75.5dBc	75dBc




Table 16 Summary of 16-QAM Tx Output Power and ACP Performance

Figure 10 16-QAM ACP Performance at 459.75MHz





Figure 12 16-QAM ACP Performance at 467.25MHz

### 16-QAM Constellation, Eye Diagram and EVM

In Figure 13 to Figure 15 there are plots of the DE9941 Tx output at 459.75MHz, showing the resultant constellation, eye diagram and EVM.








Figure 14 16QAM Eye Diagram at 459.75MHz

lef Lv.				SR		1	8 k	Symbol	L/Erro:
33 dBı								Demod	1
31 dB (	Offs:		Symbol	Table					
0	01010110	10100111	00110110	00011001	010000	00			
40	01100011	00111101	10000001	00000001	001010	10			
80	01110000	10101100	11010001	01111110	000011	11			
120	00001100	01111011	01001011	10110110	001100	10			
160	00011010	10110001	11111100	10101100	000011	10			
200	01011000	00000111	10011100	00101100	111110	10			
240	00100100	11010000	00000000	00000110	111001	00			
280	11000100	01000101	00101010	01001100	011110	00			
320	10000110	11110000	11110011	01001010	110011	10			
360	11011010	10100101	10111111	01100000	110100	00			
400	00111111	11111010	00110000	10010011	110010	00			
440	01101100	11111001	11101001	10010101	011100	11			
480	11001110	00110000	10101111	00011100	001110	11			
520	01110100	10101111	00100000	11100000	001111	11			
560	00100011	00100010	01100110	01011010	101100	10			
			Error Su	ımmary			BURS	T NOT	FOUND
Error V	ector Mag	1.09	% rms	3.01	% Pk	at	sym	208	
Magnitu	de Error	0.72	% rms	1.94	% Pk	at	sym	95	
Phase E	rror	0.66	deg rms	2.10	deg Pk	at	sym	208	
Freq Er	ror	6.33	Hz	6.33	Hz Pk				
Amplitu	de Droop	9.82	dB/sym	Rho Fa	ctor		Ο.	.9998	
IO Offs			8	IQ Imb	-		~	79 %	

Figure 15 16-QAM EVM, symbol/error table at 459.75MHz

#### Transmit Harmonics and Spurious

The following pairs of plots show the DE9941 Tx output at the low (452.25MHz), mid (459.75MHz) and upper (467.25MHz) points of the operating frequency. At each frequency, the plots are taken with a 1MHz span and with a 1GHz span. In all cases the main spurious are those at ~300MHz and 150MHz.





Figure 16 Wideband plots of Tx at 452.25MHz

#### DE9941








Figure 18 Wideband plots of Tx at 467.25MHz

### Power and Modulation Ramping

Plots in Figure 19 and Figure 20 show the ramp-up and ramp-down profiles using QAM.




Figure 19 Ramp-up and Ramp-down Profile (QAM)




Figure 20 Tx Ramp Profile (QAM)

### 6.5 Troubleshooting

The DE9941 is a complex RF and Baseband system. If incorrectly programmed or modified, results will be at variance from datasheet performance. Please study the CMX7164, CMX998 and CMX994E datasheets, along with the manuals and the associated schematics and layout drawings for these and the DE9941 PCB carefully when troubleshooting. This section provides suggestions to help users resolve application issues they might encounter.

### 6.5.1 Receiver Operation

Error Observed	Possible Cause	Remedy
Received data is not provided by the receiver	Incorrect set-up	Ensure that suitable values are written to the CMX7164 registers concerning receiver gains and polarity. Also check the dc offsets and signal levels into the CMX7164 IQ Inputs (pins 28, 29, 31 and 32).
	Incorrect set-up	CMX994E has not been programmed correctly. Check signals as above.
	FI not loaded	Reset by cycling power. Check checksums.
Synthesiser not locked	Incorrect configuration components	Check the SKY72300 synthesiser programming data is correct.
Poor Receiver Performance	Receiver Response Equaliser configuration	Ensure single mode equaliser is being used and that training is done with a signal level of ~-65dBm.

### Table 17 Receiver – Possible Errors

### 6.5.2 Transmitter Operation

Error Observed	Possible Cause	Remedy
Synthesiser not locked	Incorrect configuration components	Check that the SKY72300 synthesiser programming data is correct.
Poor Tx modulation spectrum	Modulation levels incorrect	Check CMX7164 main DAC attenuator values (B4 and B5) are correct for the QAM and Channel Filter type (see Table 15 for details).
	Poor DC Calibration	Check nulled carrier condition, i.e. no modulation case. The nulled carrier should typically be <-25dBm.
Poor Wideband Spectrum	Incorrect CMX998 Loop Phase Setting	Check values sent to the CMX998 Phase control register.
Low power	PIN diode or PA not enabled	Check that the TXEN+V (TP7) power supply is enabled. Also check that the RAMDAC output is being enabled. Check PA control volts at TP6 are ~2.6/2.7Vdc.

### Table 18 Transmitter – Possible Errors

<sup>© 2015</sup> CML Microsystems Plc

-

-

# 7 Performance Specification

### 7.1 Electrical Performance

### 7.1.1 Absolute Maximum Ratings

Exceeding these maximum ratings can result in damage to the Evaluation Kit.

	Min.	Max.	Units
Supply (V <sub>IN</sub> - V <sub>SS</sub> )	0	4.5	V
Current into or out of $V_{IN}$ and $V_{SS}$ pins	0	+1.5	А
Current into or out of any other connector pin	-20	+20	mA
Receiver Maximum Input Level		+10	dBm

### 7.1.2 Operating Limits

Correct operation of the Evaluation Kit outside these limits is not implied.

	Notes	Min.	Max.	Units
Supply (V <sub>IN</sub> - V <sub>SS</sub> )		3.5	4.0	V

### 7.1.3 Operating Characteristics

For the following conditions unless otherwise specified:

Xtal Frequency = 19.2MHz, Bit Rate = 18ksymbols/s, Noise Bandwidth = 16kHz,  $V_{IN}$  = 3.6V,  $T_{AMB}$  = +25°C.

	Notes	Min.	Тур.	Max.	Units
DC Parameters					
IIN (on power-up)	1	-	64	68	mA
IIN (FI Loaded only)	1	_	55	58	mA
IIN (Rx enabled and SFS)		_	167	_	mA
IIN (Rx enabled and Rx Data)		_	153	_	mA
IIN (Tx and PA enabled, nulled carrier)		_	360	_	mA
IIN (Tx and PA enabled, modulated carrier)		_	1000	1500	mA
AC Parameters					
Frequency Range		452.25	-	467.25	MHz
Тх					
Mean Output Power	2,3	-	25	_	dBm
Tx Output Impedance		-	50	-	Ω
Adjacent Channel Power					
16-QAM 1 <sup>st</sup> ACP	2,3	_	66	-	dBc
16-QAM 2 <sup>nd</sup> ACP	2,3	_	75	_	dBc
Tx EVM	2	-	1	_	%
Unwanted emission	4	_	-36	_	dBm
Frequency Error		_	1.5	_	ppm
Rx					
Rx Input Impedance		_	50	-	Ω
Rx Sensitivity	4,5				
4-QAM		_	-116	-	dBm
16-QAM		_	-110	-	dBm
64-QAM		_	-104	-	dBm
Adjacent Channel Rejection (4-QAM)	4	_	-55	-	dBm
Co-Channel Rejection (4-QAM)	4	-	8	-	dB
Intermodulation (4-QAM)	4	-	-40.5	_	dBm
Rx Conducted Spurious	4	-	< -80	_	dBm
Maximum Input Level		-	0	-	dBm

#### **Microcontroller Interface**

For timings see CMX7164 Datasheet

#### Notes:

- 1. PCB current consumption, not current consumption of the CML devices.
- 2. Modulation 16-QAM and RRC alpha = 0.2.
- 3. 25kHz Channel Spacing and 16kHz Measurement Bandwidth
- 4. Tested as specified in EN 302 561. BER (Bit Error Rate) is 1 x 10<sup>-2</sup> in all cases in normal mode.
- 5. Tx/Rx Channel Filter RRC alpha = 0.2. Receiver Response Equaliser used in single mode.

© 2015 CML Microsystems Plc

CML does not assume any responsibility for the use of any circuitry described. No IPR or circuit patent licences are implied. CML reserves the right at any time without notice to change the said circuitry and any part of this product specification. Evaluation kits and demonstration boards are supplied for the sole purpose of demonstrating the operation of CML products and are supplied without warranty. They are intended for use in a laboratory environment only and are not for re-sale, end-use or incorporation into other equipments. Operation of these kits and boards outside a laboratory environment is not permitted within the European Community. All software/firmware is supplied "as is" and is without warranty. It forms part of the products supplied and is licensed for use only with this product, for the purpose of demonstrating the operation of CML products. Whilst all reasonable efforts are made to ensure that software/firmware contained in this product is virus free, CML accepts no responsibility whatsoever for any contamination which results from using this product and the onus for checking that the software/firmware is virus free is placed on the purchaser of this evaluation kit or development board.

CML Microcircuits (UK)Ltd COMMUNICATION SEMICONDUCTORS	CML Microcircuits (USA) Inc. COMMUNICATION SEMICONDUCTORS	CML Microcircuits (Singapore) Pte Ltd
Tel:	Tel:	Tel:
+44 (0)1621 875500	+1 336 744 5050	+65 62 888129
Fax:	800 638 5577	Fax:
+44 (0)1621 875600	Fax:	+65 62 888230
Sales:	+1 336 744 5054	Sales:
sales@cmlmicro.com	Sales: us.sales@cmlmicro.com	sg.sales@cmlmicro.com
Tech Support:	Tech Support:	Tech Support:
techsupport@cmlmicro.com	us.techsupport@cmlmicro.com	sg.techsupport@cmlmicro.com
	- www.cmlmicro.com -	