

AMP 1281 (7/82) APPLICATOR PARTS LIST				TYPE LENGTHWISE			.250 SERIES AMPLIVAR FASTON RECEPT.			AMP INCORPORATED HARRISBURG, PENNA.			
NO.	DESCRIPTION	REQ.	PART NO.	NO.	DESCRIPTION	REQ.	PART NO.	CRIMPING DATA			TERMINALS		
1	WIRE CRIMPER	1	1-456406-6	37	FEED FINGER TIP			TO APPLY TERMINAL			63623-1		
2	INS. CRIMPER	1	378147	38	FEED FINGER SPACER			WIRE SIZE	CRIMP HEIGHT				
3	ANVIL	1	1-465284-1	39	BASE CASTING	1	570238	19	.043±.002				
4	ANVIL SPACER			40	GUARD	1	457664-2	20	.041±.002				
5	SHEAR BLADE	1	373071	41				21	.040±.002				
6	REAR SHEAR PLATE	1	385013-4	42				22,23,OR 24	.038±.002				
7	SHEAR BLADE SPACER	2	373072	43				CRIMP	SIZE	TYPE	FEED		
8	FRONT SHEAR PLATE	1	810347-9	44	HOLD DOWN	1	375826	WIRE	.090	F	.760		
9	REAR ANVIL SPACER PL			45	SPACER - TUBING STOP	2	377628	INSUL.	.110	F			
10	FRONT ANVIL SPACER PL			46	TUBING STOP	1	811923-2	SLEEVED					
11	TOOL SPACER	1	1-854652-1	47				INSULATION RANGE	WIRE RANGE				
12	CRIMP SPACER	1	854652-6	48	HOLD DOWN ASSEMBLY	1	811849-1	.050-.080	24-19				
13	FRONT STRIP GUIDE	2	370976	49	HOLDER	REF	811850-1	EXPLODED VIEW A-6000 A-6000-4					
14	REAR STRIP GUIDE			50	BLADE	REF	811852-1	THIS APPLICATOR IS TO BE USED ON AMP-O-ELECTRIC 1-471273-3					
15	RAM	1	471911	51	SPRING	REF	6-22279-6	ALIGNMENT GAGE: 679597-1					
16	TOOL HOLDER			52	COVER	REF	811851-1						
17	ADJ. CRIMP MOUNT ASSY	1	465392-1	53	SCREW, FLAT HEAD	REF	1-21003-8						
18	ADJ. BLOCK			54									
19	APPLICATOR MOUNT	1	570656	55									
20	BASE PLATE			56									
21	BASE BLOCK			57	BASE MOUNT WASHER	3	371178						
22	STRIP GUIDE PLATE			58									
23	ANVIL HOLDER	1	452819-1	59									
24	AUX. ANVIL HOLDER	1	377515	60									
25	STRIPPER	1	452631-1	61									
26	STRIPPER MOUNT	2	379613	62									
27	RETAINER PLATE	2	372251	63									
28	STRIPPER MOUNT BRACKET			64									
29	STRIPPER BUSHING			65	TENSION ADJ PLATE	1	374999						
30	STOCK DRAG	1	375381	MISCELLANEOUS									
31	STOCK DRAG HANDLE			66	AIR BLAST ASSY	1	455350-1						
32	STOCK DRAG STUD	2	354045-1	67	AIR FEED ASSY	1	690021-1						
33	STOCK DRAG SPRING	2	1-23847-1	68	AIR BLAST TUBE	1	689446-2						
34	STOCK DRAG ADJ. SCREW	2	372997	69	ELBOW, METAL TUBING, MALE	1	22317-3						
35	FEED FINGER HOLDER			70									
36	FEED FINGER	1	375093	71									
				72									

1. RECOMMENDED SPARE PARTS.
2. TOP TOOL MOUNTING SEQUENCE FROM RAM OUTWARD: ITEMS 5, 48, 11, 1, 12 & 17. SPECIAL INSULATION TUBING STOP.

LOC	DWG SIZE	PART NO	DESCRIPTION	ITEM NO
A				
DIST	← REVISION OF EACH ASSY NO (WHEN BLANK, USE DWG REVISION)			
4	QTY REQD PER ASSY		PARTS LIST	
	MATL	HT TR	FIN	
	DR 6-10-92 J. HERRINGTON	APP 6-14-92 B. WOLFE	AMP AMP Incorporated Harrisburg, PA 17105-3608	
	CHK 6-12-92 C. ERISMAN	REL 3/15/94 B. MORGAN	NAME SIDE FEED HDM APPLICATOR MACHINE REF MINI-APPL	
	SCALE 1:1	DWG NO B 566374-1	SHEET 1 OF 1	REV D

THIS DRAWING IS A CONTROLLED DOCUMENT FOR AMP INCORPORATED. IT IS SUBJECT TO CHANGE AND THE CONTROLLING ENGINEERING ORGANIZATION SHOULD BE CONTACTED FOR THE LATEST REVISION.

THIS INFORMATION IS CONFIDENTIAL AND IS DISCLOSED TO YOU ON CONDITION THAT NO FURTHER DISCLOSURE IS MADE BY YOU TO OTHER THAN AMP PERSONNEL WITHOUT WRITTEN AUTHORIZATION FROM AMP INCORPORATED, HARRISBURG, PA.