

# QSG123: CP2102N Evaluation Kit Quick-Start Guide

The CP2102N-EK kit is designed to showcase the various features of the CP2102N USBXpress® devices.

These highly-integrated USB-to-UART bridge controllers provide a simple solution for updating RS-232 designs to USB using a minimum of components and PCB space. By eliminating the need for complex firmware and driver development, the CP2102N devices enable quick USB connectivity with minimal development effort.

#### KIT CONTENTS

- CP2102N USB-to-UART Bridge Evaluation Board
- 1 x micro USB cable
- 1 x serial cable
- · Getting Started card



# 1. Getting Started

1. Download and Install the Latest Virtual COM Port (VCP) Drivers.

The Virtual COM Port (VCP) drivers enable the CP2102N to appear as a standard COM port. Download the latest version of drivers from the Silicon Labs website:

http://www.silabs.com/vcpdrivers


In most cases, select the default option without serial enumeration.

- 2. Set Up Your Kit.
  - a. Provide power to the board by connecting the USB connector to the PC using the provided USB cable. When a connection has been established successfully, the LED (marked in the picture) lights up.
  - b. Connect the serial cable to an external device or use the J1 header to jumper UART signals to the external device.



#### 3. Detect Your Device.

The CP2102N device will appear as a COM port in Device Manager in Windows. As a virtual COM port, the CP210x functions identically to a real COM port from the reference point of both the host application and the serial device, and it can support serial device control requests defined in the Microsoft Win32® Communications API.



4. Set up a Loop-Back Test.

Rotate the jumpers on the CP210x 7 RX and TX pins to tie RX and TX together and perform a loop back test.



#### 5. Send and Receive Some Data

- a. In Windows, open a serial terminal program (downloaded separately, RealTerm pictured) to verify the CP2102N UART functionality.
- b. Set the baud rate and select the COM port from Device Manager.
- c. Type in the transmit area. The characters should echo back after looping through the CP2102N TXD and RXD pins.

	•		
Display Pot Capture Prins Send Echo Pot 12C 12		7	n <u>Clear</u> Freeze
Parity Data Bits Stop Bits Stop Bits Ret	Spy Control er Flow Control erive Xon Char. 17 nsmit Xoff Char. 19 Winsock is: Raw relet		Disconnect       RVD (2)       TXD (3)       CTS (8)       DDD (1)       DSR (6)       Rvag (9)       BREAK       Error


#### 6. Utilize the Available Resources

The next section includes additional resources available for the device, including documentation and application notes.

# 2. Resources

### **Xpress Configurator**

The various GPIO and other features of the CP2102N can be configured using the [**Xpress Configurator**] tool within Simplicity Studio (http://www.silabs.com/simplicity-studio). Documentation for Xpress Configurator can be found in *AN721: CP210x Device Customiza-tion Guide*, which can be found on the Silicon Labs website (www.silabs.com/interface-appnotes) or within Simplicity Studio using the [**Getting Started**]>[**Application Notes**] area of the launcher.




#### Kit Documentation and User's Guide

Kit documentation like the schematic and detailed board description can be found using the [**Documentation**] area of the launcher. The User's Guide will be a valuable document to reference while using the device.

🚰 Laurichier - Simplicity Studio =					
e Edit Navigala Search Project Run Window Help					
prin * 🔆 🕭	50409	JE Yook		E In Leane	
Constructions	EFM8BB1 Busy Bee Starter Kit Betrevel VID(1911) VIII will 2: Talk new in dunge the preferred VIX. Debug Mode: MCU charge Acoustic Himmele Vectorio 044/p22433 Noticeal seaster Himmele available: Cite 2011 to connit				
	Getting Started Docu FF:681: Bay Bay Bay Bay Bay BRD5200A A01 assy draw 5 FFM8BBL_datasheet 3	EFM9881-SLSTK2020A-Quick:	BRD52004 EFM8BB1-SLST	latic 5 020A-UserGi 2	
BRD5200A	_A01_schemat	tic 📋			
		2		SILICIN	

#### CP2102 to CP2102N Migration Guide


Migrating a product from the CP2102 to the CP2102N? View AN976: Migrating from a CP2102 to a CP2102N for more information on differences and similarities between these products. This document can be found on the Silicon Labs website (www.silabs.com/inter-face-appnotes) or within Simplicity Studio using the [Getting Started]>[Application Notes] area of the launcher.



#### **Other Application Notes**

Application Notes can be accessed on the Silicon Labs website (www.silabs.com/interface-appnotes) or within Simplicity Studio using the [Getting Started]>[Application Notes] area of the launcher. Some application notes that are available are as follows:


- AN721: CP210x Device Customization Guide—This application note guides developers through the configuration process of USBXpress devices using Simplicity Studio [Xpress Configurator].
- AN220: USB Driver Customization—This document and accompanying software enable the customization of the CP210x Virtual COM Port (VCP) and USBXpress drivers.
- AN197: Serial Communications Guide for CP210x—This document describes recommendations for communicating with USBXpress CP210x devices using the Virtual COM Port (VCP) driver.



## **Community and Support**

Have a question? Visit the community by clicking the [Resources]>[Silicon Labs Community] area of the launcher.

100 00	2100
Autors with a series of the se	Z



#### Disclaimer

Silicon Laboratories intends to provide customers with the latest, accurate, and in-depth documentation of all peripherals and modules available for system and software implementers using or intending to use the Silicon Laboratories products. Characterization data, available modules and peripherals, memory sizes and memory addresses refer to each specific device, and "Typical" parameters provided can and do vary in different applications. Application examples described herein are for illustrative purposes only. Silicon Laboratories reserves the right to make changes without further notice and limitation to product information, specifications, and descriptions herein, and does not give warranties as to the accuracy or completeness of the included information. Silicon Laboratories shall have no liability for the consequences of use of the information supplied herein. This document does not imply or express copyright licenses granted hereunder to design or fabricate any integrated circuits. The products are not designed or authorized to be used within any Life Support System without the specific written consent of Silicon Laboratories. A "Life Support System" is any product or system intended to support or sustain life and/or health, which, if it fails, can be reasonably expected to result in significant personal injury or death. Silicon Laboratories products are not designed or authorized for military applications. Silicon Laboratories shall under no circumstances be used in weapons of mass destruction including (but not limited to) nuclear, biological or chemical weapons, or missiles capable of delivering such weapons.

#### **Trademark Information**

Silicon Laboratories Inc.®, Silicon Laboratories®, Silicon Labs®, SiLabs® and the Silicon Labs logo®, Bluegiga®, Bluegiga Logo®, Clockbuilder®, CMEMS®, DSPLL®, EFM®, EFM32®, EFR, Ember®, Energy Micro, Energy Micro logo and combinations thereof, "the world's most energy friendly microcontrollers", Ember®, EZLink®, EZRadio®, EZRadio®, Gecko®, ISOmodem®, Precision32®, ProSLIC®, Simplicity Studio®, SiPHY®, Telegesis, the Telegesis Logo®, USBXpress® and others are trademarks or registered trademarks of Silicon Laboratories Inc. ARM, CORTEX, Cortex-M3 and THUMB are trademarks or registered trademarks of ARM Holdings. Keil is a registered trademark of ARM Limited. All other products or brand names mentioned herein are trademarks of their respective holders.



Silicon Laboratories Inc. 400 West Cesar Chavez Austin, TX 78701 USA

# http://www.silabs.com