



Windows

Each machine comes with a set of four polycarbonate windows, but some people like to purchase more. Choose between the left, right, or the front/back window, and don't forget to remove the plastic film from both sides!

Front/back window



Right window





Left window