

APPLICATOR PARTS LIST				TYPE			AMP INCORPORATED HARRISBURG, PENNA.							
				SIDEWISE										
NO.	DESCRIPTION	REQ.	PART NO.	NO.	DESCRIPTION	REQ.	PART NO.	CRIMPING DATA		TERMINALS				
1	WIRE CRIMPER 453933-7	1	453933-7	42	Shear Plate - Left	1	811855-1	TO APPLY TERMINAL		66113-				
2	INS. CRIMPER	1	465603-2	43	Shear Block - Right	1	386372							
3	ANVIL	1	465998-1	44	Floating Shear	1	465406	WIRE SIZE	CRIMP HEIGHT					
4	ANVIL SPACER	1	810070-1	45	Retaining Plate - Front	1	811714-3	26						
5	SHEAR BLADE			46	Retaining Plate - Rear	1	810822-1		237					
6	REAR SHEAR PLATE			47	Spring - Shear Return	1	374322	22						
7	REAR ANVIL SPACER PLT.	1	811959-1	48	Shear Depressor 453302-1	1	382265-1							
8	FRONT SHEAR PLATE			49	Key - Shear Retainer	1	386358	CRIMP	SIZE	TYPE				
9	REAR ANVIL SPACER PLT.			50	Guard Mount	1	811986-1	WIRE	.062	"5"				
10	FRONT ANVIL SPACER PLT. Hold	1	810799-2	51	Punch Holder	1	810498-3	INSUL.	.070	"0"				
11	TOOL SPACER	1	370695	52	Punch ASSY.	1	810738-1			.300				
12	CRIMP SPACER	1	375548	53				SLEEVED						
13	FRONT STRIP GUIDE	1	810971-2	54				INSULATION RANGE	WIRE RANGE					
14	REAR STRIP GUIDE	1	465413-1	55				.053 Max.	26 - 22					
15	RAM	1	471912	56				EXPLODED VIEW						
16	TOOL HOLDER			57				A-6002-4 A-6002-6						
17	ADJ. CRIMP MOUNT ASSY.	1	465392-9	58				REMARKS:						
18	ADJ. BLOCK			59				Max. Ins. Crimp Height .060						
19	APPLICATOR MOUNT ASSY.			60				△ Mounts on top of item #13						
20	BASE PLATE	1	465100	61										
21	BASE BLOCK	1	465101	62										
22	STRIP GUIDE PLATE	1	465414-1	63										
23	ANVIL HOLDER			64	Paper Separator	1	694927-1							
24	WIRE STOP	1	811787-1	65	TENSION ADJ. PLATE	1	374999							
25	STRIPPER - Wire Stop	1	386361	66	2 Ft. Dia. Reel Spind Assy.	1	453596-1							
26	STRIPPER MOUNT	1	386362	67	Air Feed Assy.	1	690021-							
27	RETAINER PLATE	1	389078	68	Lubricator Assy.	1	465181-2							
28	STRIPPER MOUNT BRACKET	1	387115-1	69	SYNTHETIC OIL	1	22014-1							
29	STRIPPER BUSHING	1	386368	70										
30	STOCK DRAG	1	386955	71										
31	STOCK DRAG HANDLE			72										
32	STOCK DRAG STUD	1	374900	REV. REVISION RECORD		DATE	BY	ECN						
33	STOCK DRAG SPRING	1	370572	B	Change Item 42 44 45	11-11-65								
34	STOCK DRAG ADJ. NUT	1	21022-3	C	ITEM 32 WAS -2	1/2/66								
35	FEED FINGER HOLDER	1	386912	D	ADD ITEM 38	12-20-66		L-4323						
36	FEED FINGER	1	386911	E	ITEM 7 WAS -2	5-8-69		L-6617						
37	FEED FINGER TIP	1	387251	F	ADDED ITEM 65 374999	5-27-69		L-6673						
38	FEED FINGER GUIDE	1	689915-2	G	REV. PER ECN	9-9-69		L-6952						
39	BASE CASTING	1	570238	H	REV PER ECN	6-4-71		L-8332						
40	GUARD 460881-2	1	460881-2	I	REV PER ECN	4/21/71		L-8362						
41	BRACKET	1	811304-1								APPLICATOR NUMBER	REV. M	670892-3	SHEET 1 OF 31

**— IMAGINE —
FOR REPLACEMENT KEY**

■ DENOTES WEARING PARTS
RECOMMEND PURCHASE REPLACEMENT

THIS APPLICATOR IS TO BE USED ON
AMP-O-ELECTRIC 1-471273-2
~~AMP-O-ELECTRIC~~ AIR FEED

SERIAL NO. _____ DATE SHIPPED _____ DESIGNED _____

CUSTOMER NAME AND ADDRESS _____ CHK'D _____

APPLICATOR NUMBER _____ REV. M 670892-3 SHEET 1 OF 31

M REV ITEM 40 11-10-78
 K 48 WAS 378265-7
 L REV PER ECN 4.5-73 TK - L-9645
 FOR HARDWARE SEE 1-687511-5