# INSTALLATION INSTRUCTIONS FOR THE MAGNETICALLY ACTUATED SAFETY INTERLOCK SWITCHES FFS SERIES



### **AWARNING** IMPROPER INSTALLATION

- Consult with local safety agencies and their requirements when designing a machine-control link, interface, and all control elements that affect safety.
- Strictly adhere to all installation instructions.

Failure to comply with these instructions could result in death or serious injury

### **GENERAL INFORMATION**

When installed on a machine guard, and the switch and actuator are within the specified operating range, the safety contacts will be closed and the auxiliary contacts will be open. (See table for switching distances).


When the actuator moves out of the operating range, the safety contacts will open. The auxiliary contacts will close for indication.

The FF series safety switches and actuators are designed to approach each other from most angles. When the switch is closed, the targets on the printed face of the switch must align.


### **MOUNTING INFORMATION**

The FF safety switches can approach each other from most angles. When the switch is closed, targets on the printed face must align. See Figure 1.


#### Figure 1. Switch Alignment (FFS and FF6)



#### Figure 2. Switch Alignment (FF2 and FF3)









Mount the switch on the machine frame and the actuator on the opening edge of the door. Always try to mount the switch on non-ferrous material. **Ferrous material may reduce the switching distance.** Be sure to use tamper-proof screws. Do not use the safety switch as a door stop. Leave a minimum of 50 mm [1.97 in] between any adjacent switches. See Figures 4 and 5.

# Honeywell

Figure 4. Do Not Use the Safety Switch as a Door Stop



#### Figure 5. Minimum Distance Between Switches



Minimum: 50 mm [1.97in]

When fixing the safety switch to a sliding door (A), ensure that when the door is opened (B) it is not easily accessible, helping prevent the system being overridden. See Figure 6.

### Figure 6. Placement for Sliding Doors




TABLE 1. SP	TABLE 1. SPECIFICATIONS						
Туре	FF2-10-AC FF2-11-AC	FF2-10-DC FF2-11-DC	FF3-20-AC FF3-21-AC	FF3-20-DC FF3-21-DC	FF5	FF5-SS	
Contact arrangement	1NC (FF2-10-AC) 1NC/1NO (FF2- 11-AC)	1NC (FF2-10-DC); 1NC/1NO (FF2- 11-DC)	2NC (FF3-20-AC) 2NC/1NO (FF3- 21-AC)	2NC (FF3-20-DC); 2NC/1NO (FF3- 21-DC)	Max: 2NC safety and 1NO auxiliary	Max: 2NC safety and 1NO auxiliary	
Safety contact rating	230 Vac/2 A	30 Vdc/1 A induc- tive/resistive	230 Vac/2 A	30 Vdc/1 A induc- tive/resistive	24 Vdc/0.3 A in- ductive/resistive	24 Vdc/0.3 A in- ductive/resistive	
Safety contact operating distance	10 mm [0.4 in] ON; 30 mm [ 1.18 in] OFF	10 mm [0.4 in] ON; 30 mm [ 1.18 in] OFF	10 mm [0.4 in] ON; 30 mm [ 1.18 in] OFF	10 mm [0.4 in] ON; 30 mm [ 1.18 in] OFF	6 mm [0.24 in] ON; 17 mm [ 0.67 in] OFF	6 mm [0.24 in] ON; 17 mm [ 0.67 in] OFF	
Safety contact close/drop/ bounce	3 ms/2.1 ms/ 0.7 ms						
Auxiliary con- tact rating	15 W/10 VA	15 W/10 VA	15 W/10 VA	15 W/10 VA	24 Vdc/0.3 A in- ductive/resistive	24 Vdc/0.3 A in- ductive/resistive	
Auxiliary con- tact operating distance	7 mm [0.28 in] OFF; 14 mm [0.55 in] ON	7 mm [0.28 in] OFF; 14 mm [0.55 in] ON	7 mm [0.28 in] OFF; 14 mm [0.55 in] ON	7 mm [0.28 in] OFF; 14 mm [0.55 in] ON	6 mm [0.24 in] OFF; 17 mm [0.67 in] ON	6 mm [0.24 in] OFF; 17 mm [0.67 in] ON	
Auxiliary contact close/ drop/bounce	0.5 ms/0.3 ms/ 0.7 ms						
Internal fuse	ac: 2 A fast acting	dc: 1 A fast acting	ac: 2 A fast acting	dc: 1 A fast acting	not applicable	not applicable	
External fuse (cust. sup- plied)	ac: 1.6 A fast act- ing	dc: 0.8 A fast act- ing	ac: 1.6 A fast act- ing	dc: 0.8 A fast act- ing	dc: 0.2 A fast act- ing	dc: 0.2 A fast act- ing	
IP rating	IP67	IP67	IP67	IP67	IP67	IP67	
Vibration/ shock	50 Hz to 100 Hz/ 10 g						
Operating temperature	-10°C to 55°C [14°F to 131°F]						
Mounting and fixture	Target to target						
Construction	Red ABS resin filled	316 stainless steel, resin filled					

### lssue 2 **50026830**

TABLE 2. SPECIFICATIONS						
Туре	FF6 ac	FF6 dc	FF6-SS ac	FF6-SS dc		
Contact arrangement	Max: 2NC safety and 1NO auxiliary	Max: 2NC safety and 1NO auxiliary	1NC safety	Max: 2NC safety and 1NO auxiliary		
Safety contact rating	230 Vac/2 A	30 Vdc/1 A inductive/resis- tive	230 Vac/2 A	30 Vdc/1 A inductive/resis- tive		
Safety contact operating dis- tance	10 mm [0.4 in] ON; 30 mm [ 1.18 in] OFF	10 mm [0.4 in] ON; 30 mm [ 1.18 in] OFF	10 mm [0.4 in] ON; 30 mm [ 1.18 in] OFF	10 mm [0.4 in] ON; 30 mm [ 1.18 in] OFF		
Safety contact close/drop/ bounce	3 ms/2.1 ms/0.7 ms					
Auxiliary con- tact rating	15 W/10 VA	15 W/10 VA		15 W/10 VA		
Auxiliary con- tact operating distance	7 mm [0.28 in] OFF; 20 mm [0.79 in] ON	7 mm [0.28 in] OFF; 20 mm [0.79 in] ON		7 mm [0.28 in] OFF; 20 mm [0.79 in] ON		
Auxiliary con- tact close/drop/ bounce	0.5 ms/0.3 ms/0.7 ms	0.5 ms/0.3 ms/0.7 ms		0.5 ms/0.3 ms/0.7 ms		
Internal fuse	ac: 2 A fast acting	dc: 1 A fast acting	ac: 2 A fast acting	dc: 1 A fast acting		
External fuse (cust. supplied)	ac: 1.6 A fast acting	dc: 0.8 A fast acting	ac: 1.6 A fast acting	dc: 0.8 A fast acting		
IP rating	IP67	IP67	IP67	IP67		
Vibration/shock	50 Hz to 100 Hz/ 10 g					
Operating tem- perature	-10°C to 55°C [14°F to 131°F]					
Mounting and fixture	Target to target	Target to target	Target to target	Target to target		
Construction	Red ABS resin filled	Red ABS resin filled	316 stainless steel, resin filled	316 stainless steel, resin filled		

TABLE 3. SPECIFICATIONS						
Туре	FFS-11-03	FFS-20-03	FFS-11-QD	FFS-20-QD		
Contact arrangement	Max: 1NC safety and 1NO auxiliary	Max: 2NC safety	Max: 1NC safety and 1NO auxiliary	Max: 2NC safety		
Safety contact rating	230 Vac/2 A 30 Vdc/2 A					
Safety contact operating dis- tance	7 mm [0.28 in] ON; 12 mm [ 0.47 in] OFF	7 mm [0.28 in] ON; 12 mm [ 0.47 in] OFF	7 mm [0.28 in] ON; 12 mm [ 0.47 in] OFF	7 mm [0.28 in] ON; 12 mm [ 0.47 in] OFF		
Safety contact close/drop/ bounce	3 ms/2.1 ms/0.7 ms					
Auxiliary con- tact rating	15 W/10 VA	-	15 W/10 VA	-		
Auxiliary con- tact operating distance	7 mm [0.28 in] OFF; 12 mm [0.47 in] ON	-	7 mm [0.28 in] OFF; 12 mm [0.47 in] ON	-		
Auxiliary con- tact close/drop/ bounce	0.5 ms/0.3 ms/0.7 ms	-	0.5 ms/0.3 ms/0.7 ms	-		
Internal fuse	Not applicable	Not applicable	Not applicable	Not applicable		
External fuse (cust. supplied)	3 A/230 Vac, 1 A/30 Vdc					
IP rating	IP67	IP67	IP67	IP67		
Supply voltage	24 Vdc	24 Vdc	24 Vdc	24 Vdc		
Vibration/shock	50 Hz to 100 Hz/ 10 g					
Operating tem- perature	-10°C to 55°C [14°F to 131°F]					
Mounting and fixture	Target to target	Target to target	Target to target	Target to target		
Construction	Blue ABS resin filled					

19.0

[0.75]

Issue 2 **50026830** 

### DIMENSIONS mm [in]

Figure 7. FF2 Series






Figure 8. FF3 Series




SWITCH

ACTUATOR

#### Figure 9. FF6 Stainless Steel, Pre-Wired



#### Figure 10. FF5 Series



Issue 2 50026830





Figure 12. FF6 Series Quick Connect



SWITCH

ACTUATOR

Figure 13. FFS Pre-Wired






Figure 14. FFS Quick Connect




Issue 2 **50026830** 

### CONTACTS AND CONNECTIONS


#### Figure 15. FF2-10





#### Figure 19. FF5

The safety contact must be fused externally. dc switch - external fuse = 0.2 A fast acting



NOTE: Contact configurations show under closed condition for guard device.

#### CONTACTS AND CONNECTIONS FF6-21-ABS (ac & dc) FF6-20 ABS (ac & dc) FF6-11 ABS (ac & dc) FF6-10 ABS (ac & dc) FF6-21-SS (dc only) FF6-20 SS (dc only) FF6-11 (dc only) FF6-10 SS (ac & dc) Blue Blue Red • Brown • Blue Red -Blue Brown -White Black · Black • White Yellow Green -Yellow Green • FF6-10-03-SS Blue Brown • Green/Yellow

NOTE: Contact configurations show under closed condition for guard device.

#### QUICK DISCONNECT CONNECTIONS


FF6-21-AC-QD05 FF6-21-DC-QD05


4

3


FF6-20-AC-QD05 FF6-20-DC-QD05

FF6-11-AC-QD05 FF6-11-DC-QD05





#### FF6-10-AC-SS-QD05



Red

#### WARRANTY/REMEDY

Honeywell warrants goods of its manufacture as being free of defective materials and faulty workmanship. Honeywell's standard product warranty applies unless agreed to otherwise by Honeywell in writing; please refer to your order acknowledgement or consult your local sales office for specific warranty details. If warranted goods are returned to Honeywell during the period of coverage, Honeywell will repair or replace, at its option, without charge those items it finds defective. The foregoing is buyer's sole remedy and is in lieu of all other warranties, expressed or implied, including those of merchantability and fitness for a particular purpose. In no event shall Honeywell be liable for consequential, special, or indirect damages.

While we provide application assistance personally, through our literature and the Honeywell web site, it is up to the customer to determine the suitability of the product in the application.

Specifications may change without notice. The information we supply is believed to be accurate and reliable as of this printing. However, we assume no responsibility for its use.

#### For more information

Honeywell Sensing and Safety Technologies services its customers through a worldwide network of sales offices and distributors. For application assistance, current specifications, pricing or the nearest Authorized Distributor, visit <u>our website</u> or call:

USA/Canada +1 302 613 4491 Latin America +1 305 805 8188 Europe +44 1344 238258 Japan +81 (0) 3-6730-7152 Singapore +65 6355 2828 Greater China +86 4006396841

#### Honeywell Sensing and Safety Technologies 830 East Arapaho Road

830 East Arapaho Road Richardson, TX 75081 sps.honeywell.com/ast

