


CONSTRUCTION

CONNECTOR PARTS	MATERIALS	FINISH
BODY	ALUMINIUM ALLOY	-
OUTER CONTACT	-	-
CENTER CONTACT	-	-
INSULATOR	-	-
CENTRE PIN	STAINLESS STEEL	-
-	-	-
-	-	-
-	-	-
-	-	-

ISSUE	REVISION No	DESCRIPTION	BY	DATE
-	-	-	-	-
-	-	-	-	-
-	-	-	-	-
-	-	-	-	-


Initiated on	02/10/95	The information given here is subject to change without notice. Design changes may be in order to improve the product.	
Approval by	-		

HOUSING



1

Place the extraction tool in front of the connector to remove (upper coaxial line only)
Slide the extraction tool till it stops on the housing
Push gently on the knob , this will push the connector out from the rear of the housing



2

Remove the connectors from the housing

