
# **Order Number** 63808-4310



**Application Tooling Specification** 



## **FEATURES**

- Applicator designed to industry-standard mounting and 135.80mm (5.346") shut height
- Quick setup time; plus, the crimp height, track and feed adjustments can be set without removing the applicator from the press
- Fine adjustment allows users to achieve target with little effort by adjusting in increments of .015mm (.0006") for conductor crimp height and .025mm (.001") for insulation height
- Fine adjustment of the bend is achieved using the bend adjust dial
- Independent adjustment rings allow users to quickly adjust the conductor or insulation crimp height without affecting each other
- Directly adapts to most automatic wire processing machines
- This applicator is configured with a pneumatic feed, which requires a 4-way pneumatic valve for operation

### SCOPE


**Products:** CTX50 New Small Grip, 0.13 mm<sup>2</sup> wire.

<b>Terminal Series</b>	Terminal Order	Wire		Insulation Diameter		Strip Length (Ref)	
No.	No.	Wire Type	Size	mm	In.	mm	In.
560023	560023-0444	FLCUSN03RY	0.13 mm <sup>2</sup>	0.75-1.05	.030041	3.60	.142

**CAUTION:** This applicator was designed for use in a wire processor only.

**CAUTION:** To operate the pneumatic feed, a 4-way pneumatic valve is required.

# **DEFINITION OF TERMS**



### **CRIMP SPECIFICATIONS**

The following crimp specifications are based on document AS-560023-001 Rev. J:

Feature	Requirement						
1. Bend Up	1° Max						
2. Bend Down	1° Max						
3. Twist	2° Max						
4. Roll	N/A° Max						
5. Bell Mouth Rear	0.12-0.32mm (.005013")						
6. Bell Mouth Front	0-0mm (.000000″)						
7. Cut-Off Tab	0.30mm (.012″) Max						
8. Conductor Brush	0.55mm (.022″)						
Conductor Grimm	Wire Type	Wire Size	9. Crim	p Height	10. Crim	o Width	
Conductor Crimp	FLCUSN03RY	0.13 mm²	0.50-0.56mm	.020022 in.	0.80-0.86mm	.031034 in.	
Insulation Crimp	Wire Type	Wire Size	11. Crim	np Height	12. Crim	o Width	
	FLCUSN03RY	0.13 mm²	1.15-1.25mm	.045049 in.	1.05-1.15mm	.041045 in.	
	Wire Type	Wire Size	Minimum Force				
Pull Force	FLCUSN03RY	0.13 mm²	50 N	11.3 lb.	To be measured with no influence from the insulation crimp.		
13. Conductor Anvil Flash	0.10mm (.004") Max						
14. Insulation Grip Step	-0.05-0.05mm (002002")						
	15a. 1.07mm (.042") Max within crimp/transition area						
Crimp Bulge	<b>15b.</b> 0.10mm (.004")						
	<b>15c.</b> -0.05-0.15mm (002006")						
	Wire Type	Wire Size		Conductor Crimp Angle Conductor Crimp Horizontal Length		rimp Angle	
Misc.	FLCUSN03RY	0.13 mm²	1-2mm	.039079 in.	5-10°		
	Wire Type	Wire Size	16. Wing D	issymmetry	17. Wing Tips to Crimp Botto		
	FLCUSN03RY	0.13 mm <sup>2</sup>	0-0.2mm	.000008 in.	0.1-1mm	.004039 in.	

FA2 Pneumatic Feed Crimp Applicator for CTX50 New Small Grip 0.13mm<sup>2</sup>

# **NOTES**

### **Applicator Notes**

- This applicator is for automatic wire processor use only.
- This applicator does not include a cutting insert. .
- Installing a cutting insert will cause jamming in this applicator.

#### **Specification Notes**


This applicator should only be run in a properly set up wire processor to consistently achieve the brush length.

#### **General Notes**

- 1. Molex recommends that an extra perishable tooling kit be maintained at your facility.
- 2. Verify tooling alignment by hand cycling the press and applicator before crimping under power. Check that all screws are tight.
- 3. Slugs, terminals, dirt and oil should be kept clear of the work area.
- 4. Wear safety glasses at all times.
- 5. For recommended maintenance, refer to the FA2 manual (TM-638080200).
- 6. Molex recommends crimping standard copper wire only.

#### **Terminal Notes**

- This terminal may have anvil impressions along the bottom of the insulation crimp and beyond the bottom of the conductor crimp into the transition area when successfully crimped.
- This is an expected condition. See Figure 1.



### WARNINGS

**CAUTION:** This applicator must be installed in a press with a standard shut height of 135.80mm (5.346"). Tooling damage could result at a lower setting.


**CAUTION:** To prevent injury, never operate this applicator without the guards supplied with the press or wire-processing machine in place. Reference the press or wire processing manufacturer's instruction manual.

CAUTION: Molex tooling crimp specifications are valid only when used with Molex terminals and tooling manufactured by Molex and sold by Molex or authorized distributors ("Molex Tooling"). When using tooling other than Molex Tooling with Molex-specific connector systems listed in our ATS documents, the Molex Tooling qualification does not apply, and the responsibility for full qualification of the connector system is that of the customer. Molex accepts no liability for connector performance or tooling support where tooling other than Molex Tooling is used or where Molex Tooling is modified.

#### Doc. No: 638084310 Revision: A1

Release Date: 09-27-18 UNCONTROLLED COPY Revision Date: 10-30-18






# PARTS LIST

	Applicator 63808-4310						
Item	Order No.	Engineering No. Description		Quantity			
Perishable Tooling							
	63808-4370	63808-4370	Tool Kit (All "Y" Items)	Ref			
1	63454-0164	63454-0164	Insulation Punch	1 Y			
2	63457-0806	63457-0806	Conductor Punch	1 Y			
3	63455-0142	63455-0142	Combination Anvil	1 Y			
4	63443-0145	63443-0145	Front Plunger	1 Y			
		Non-Perishab	le Components	-			
5	63443-0118	63443-0118	Front Plunger Retainer	1			
6	01124-1067	4996-4	Cut-Off Plunger Spring	1			
7	63443-0117	63443-0117	Front Scrap Chute	1			
8	63443-7510	63443-7510	Anvil Mount	1			
9	63443-0090	63443-0090	Wire Stop Assembly	1			
10	63443-2805	63443-2805	Front Plunger Striker	1			
11	63443-2919	63443-2919	Wire Hold Down Plunger	1			
12	63600-0021	63600-0021	Wire Hold Down Spring	1			
13	63600-5776	63600-5776	Nose Hold Down	1			
14	63600-5775	63600-5775	Nose Hold Down Shank	1			
15	63443-4701	63443-4701	Terminal Guide	1			
16	63443-7403	63443-7403	Hold Down Block	1			
17	63808-0229	63808-0229	Bend Adjust Dial	1			
			ame	-			
18	63808-0200	63808-0200	Applicator Core	1			
19	63808-0191	63808-0191	Track Assembly	1			
20	63808-0196	63808-0196	Pneumatic Feed Assembly	1			
21	63808-0249	63808-0249	Feed Pawl	1			
		Hare	dware	-			
22	—	_	M2.5 x 3 SHCS	1*			
23	—	_	M3 x 6 BHCS	2*			
24	_	_	M3 x 12 SHCS	4*			
25	_	_	M4 x 4 SSS	1*			
26	_	—	M4 x 6 SHCS	1*			
27	_	_	M4 x 50 SHCS	2*			
28	_	_	M5 x 12 SHCS	1*			
29	—	—	#10-32UNF x .25" BHCS	1*			
30	—	—	M3 Flat Washer Hard	1*			
31	_	_	M3 Inner Tooth Lock Washer	1*			
32	—	—	M3 Hex Nut	1*			
*Fa	istener parts ca		ιgh most industrial suppliers by ι the table above.	ising the			

# **ASSEMBLY DRAWING**




# FACTORY SETTINGS

#### Feed Pawl Assembly


The FA2 applicator number 63808-4310 ships with the following factory settings. See Figure 3:

- The feed pawl shaft and M3 screw that holds the feed pawl spring are in position 3.
- The pin is in position B.
   FEED PAWL



**Note:** Each applicator is configured and tested by Molex prior to shipping, and the above settings were used to produce the included sample crimps.


#### Third Dial/Ram Assembly



**Note:** The above dimensions were measured during setup and are included as a reference only. Additional adjustments may be required before crimping for production.

### Mounting Datum Location

This applicator was assembled and tested by Molex with the mounting datum in the location shown in Figure 5. Do not remove the mounting datum.




# **PNEUMATIC CONNECTION (AIR FEED)**

- The pneumatic feed applicator uses a double-acting air cylinder that must be actuated by a 4-way
  pneumatic valve.
- The air cylinder is equipped with push-in fittings for 6mm diameter vinyl or Nylon tube. Adapters are included for ¼" diameter and 4mm diameter vinyl or Nylon tube.

**Note:** The TM-3000 and TM-4000 presses have pneumatic valves with  $\frac{1}{4}$ " diameter tube fittings. Be sure to install the  $\frac{1}{4}$ " diameter adapters in the air cylinder fittings and use  $\frac{1}{4}$ " diameter vinyl or Nylon tube.

- Pneumatic tubes must be connected as shown in Figure 6. Tubes are typically connected so the terminal feed is forward when the applicator ram is up.
- When using the TM-3000 or TM-4000 presses, connect the tubes to the press pneumatic valve as shown in Figure 7.



FA2 Pneumatic Feed Crimp Applicator for CTX50 New Small Grip 0.13mm<sup>2</sup>

#### **Application Tooling Support**

**Phone:** (402) 458-TOOL (8665) **E-Mail:** applicationtooling@molex.com **Website:** www.molex.com/applicationtooling

Molex is a registered trademark of Molex, LLC in the United States of America and may be registered in other countries; all other trademarks listed herein belong to their respective owners.

Release Date: 09-27-18 U Revision Date: 10-30-18

**UNCONTROLLED COPY**