



Foot Pedal Switch

COM-11192



Description: Put the pedal to the metal with this metal foot switch. This is the same kind of foot pedal you might find switching the power supply for a tattoo machine or as a sustain pedal on an electric piano. The non-slip pad on top and rubber bumpers on the bottom keep the pedal from slipping out of place during use. If you open it up, it's a simple momentary switch and a big spring and that's about it. This pedal has, however, been described as "luxuriant, elegant and generous" and I guess we'd have to agree. The 59 inch cable is terminated with a 1/4" mono jack making it easy to incorporate into your next build, sounds "elegant" to us.

Dimensions: 10.5 x 7 x 3 cm