



Quick Reference

FRDM-STBC-AGM04

Sensor Toolbox Development Platform for
MMA8652FC 3-axis digital accelerometer,
FXAS21002C 3-axis digital angular rate gyroscope, and
MAG3110 3-axis digital magnetometer

SENSOR TOOLBOX SHIELD DEVELOPMENT BOARD



HOW TO GET STARTED

1. Connect the FRDM-STBC-AGM04 development board to an NXP Freedom development board, such as the FRDM-K64F (or any Arduino R3 compatible board). Refer to the NXP Freedom development board Quick Start Guide for driver information. The latest drivers for the FRDM boards can be found at:

www.nxp.com/openSDA

2. Plug one end of a USB cable into the SDA port on the assembly. Plug the other end of the cable into the USB port on the computer.

3. Download and install the latest Sensor Toolbox software at:

www.nxp.com/sensortoolbox



Figure 2: Connect board to computer

www.nxp.com

NXP and the NXP logo are trademarks of NXP B.V. All other product or service names are the property of their respective owners. © 2016 NXP B.V.

Document Number: FRDM-STBC-AGM04 REV 0
Agile Number: 920-29415 REV A

