# NPI-19-I<sup>2</sup>C evaluation Kit (V1.0) User Guide

## Description

NPI-19-I<sup>2</sup>C Nova Sensor evaluation kit was designed to allow quick evaluation of the performance of I2C pressure sensor for customer applications. Graphic user interface is available to collect sensor data either by selecting OLED display or USB streaming serial data. Full details about sensor output characteristics and specifications are described in NPI-19 Series datasheet which is available from Amphenol Advanced Sensor, Inc, and should be consulted in conjunction with this user guide when using this evaluation kit.

#### Features

- I2C calibrated pressure and temperature data display on OLED screen.
- Overvoltage and reverse protection up to +28V and -28V.
- Overvoltage and undervoltage trip at 5.8V and 2.85V.
- UART interfaced serial data logging.

## Application

- Wide supply voltage test capability ranging from 2.9V to 5.5V (Typ. 3.3V) through external power supply.
- Plug and play NPI-19 I<sup>2</sup>C sensor evaluation and proof of concept testing.
- Quick and easy NPI-19 I<sup>2</sup>C sensor demonstration.
- Sensor design verification testing.

#### **PCB Schematic**



## **Step by Step Operating Instructions**

- 1. Connect the NPI-19-I<sup>2</sup>C unit as per pin outline below.

 Connect Nova Sensor Evaluation board GND and VDD terminals to DC power supply and set power switch to ON position (~3-10mV voltage drop @Vin=3.3V expected).



3. USB to serial converter driver compatible with user's window OS in PC will be automatically installed when USB cable is connected to PC.

Device Manager

File	2	Actio	n Vie	w ł	lelp	(17)								
(a	eþ			?		2	2	×	٠					
~ 1	8.	AAS-	3QJVTT	2										
	>	A	udio inj	outs a	nd o	utputs								
	2	🔗 В	atteries											
	>	B	luetoot	h										
	> (	9 c	ameras											
	- I	_ c	ompute	r										
	> [	2 c	ontrolV	ault D	evice									
	۰,	<b>_</b> D	isk driv	es										
		🖬 D	isplay a	dapte	ers									
	> [	F F	irmware											
	> 1	H H	uman li	nterfa	ce De	vices								
	> 1	_ к	eyboard	ds										
	> [	I N	lemory	techn	olog	y devi	ces							
	>	() N	lice and	othe	r poir	nting	device	es.						
	> [	_ N	Ionitors											
	> [	N	letwork	adap	ters									
	~	🖗 P	orts (CO	M &	LPT)									
		9	ECPP	rinter	Port	(LPT1)								
		Ű,	USB S	Serial	Port (	COM4	)							
		1	USB-	SERIA	L CH3	40 (CC	OM5)							
	> 5	-I P	rint que	ues										
	>	P	rocesso	rs										
	> ]	S 🎙	ecurity of	device	25									
	> [	<u>s</u>	ensors											
	>	S S	mart car	rd rea	ders									
	2	S	oftware	comp	oner	ts								
	3	S	oftware	devid	es									
	> 1	S	ound, vi	ideo a	and g	ame o	ontro	llers						
	> 1	S 🙀	torage o	contro	llers									
	-	s s	ystem d	evice	s									
	>	ΨU	niversal	Seria	I Bus	contre	ollers							

- 4. Download "NPI19\_EVT\_Installer.exe" to target folder to install MATLAB Run time and NPI19\_EVT executable GUI software.
- 5. A list of all serial ports on a system will be identified on the NPA19\_EVT GUI and once USB-serial converter port number is selected, USB connection will be established.



6. By default, OLED will display active I2C device's slave address followed by pressure and temperature readings after screen is initialized by applied power (Vin=3.3V).



- 7. OLED screen input on the evaluation board can be toggled ON/OFF by clicking OLED control button on the GUI.
- 8. The desired sampling rate can be entered to acquire I2C output at fixed data acquisition rate (>100ms recommended) and there is no requirement to configure baud rate, data, and parity bits.



9. In order to initiate serial I2C data collection through USB cable rather than live I2C data monitoring on OLED screen, START button should be clicked on the GUI and I2C pressure and temperature data will be plotted at pre-determined sampling rate on the GUI.



- The serial data execution will automatically stop I2C data display on OLED screen and I2C data file can be logged onto the same directory as GUI in Comma Separated File (CSV) format.
- 11. The data file name will be saved with unique current date/time string and status Bit (in DEC), calibrated pressure (in % ADC) and temperature (in C), and sampling rate (ms) will be recorded in Comma Separated File (CSV) format.

F	□										
F	ile Home	FMEA Analysis	Insert Page Layout	Formulas Dat	a Re	eview	View	Add-ins	LOAD T	EST Foxit Pl	DF JMP Powe
	Cut	Calibri	• 11 • A A	≡≡∎ ≫•	📴 Wr	ap Text		General	8	•	Norm
Pas	te	inter BIU -	- <u>A</u> - <u>A</u> -		😫 Me	rge & Ce	enter *	\$ - %	• €.0 .0 • 00 →.	Conditiona	Format as Neutr
	Clipboard		Font 5	Alian	nent		5	Nur	iber	Formatting	* lable *
M1	.6 *		r								
- 4	Α	В	C	D	E	F		G	н	1 ]	К
1	Status(in DEC)	Pressure(%ADC)	Temperature(C)	Sampling Rate(m	5)						
2	0	11.91	43.65	100.004	14						
3	0	11.91	43.65	100.003	4						
4	0	11.91	43.65	100.002	21						
5	0	11.91	43.65	100.002	22						
6	0	11.91	43.65	100.003	.2						
7	0	11.91	43.65	100.003	.2						
8	0	11.91	43.65	100.002	21						
9	0	11.9	43.65	100.003	.3						
10	0	11.9	43.65	100.003	13						
11	0	11.91	43.65	100.003	12						
12	0	11.9	43.65	100.003	31						
13	0	11.91	43.65	100.003	.9						
14	0	11.91	43.65	100.003	.3						
15	0	11.91	43.65	100.003	.9						
16	0	11.91	43.65	100.001	.5						
17	0	11.91	43.65	100.003	2						
18	0	11.91	43.65	100.003	L <mark>6</mark>						
19	0	11.91	43.65	100.003	.5						
20	0	11.91	43.65	100.003	15						
21	0	11.91	43.65	100.003	13						
22	0	11.91	43.65	100.003	1						
23	0	11.91	43.65	100.003	L <mark>6</mark>						
24	0	11.91	43.65	100.003	2						
25	0	11.91	43.65	100.00	02						
26	0	11.91	43.65	100.003	12						
27	0	11.91	43.65	100.00	01						
28	0	11.91	43.65	100.012	27						
29	0	11.91	43.65	100.003	.4						
30	0	11.9	43.65	100.00	)2	_					
4	→ I2C_	20211201T15194	3_Data (+)								