

## APPLICATOR PARTS LIST

TYPE

SIDEWISE  
AMP-LOKAMP INCORPORATED  
HARRISBURG, PENNA.

NO.	DESCRIPTION	REQ.	PART NO.	NO.	DESCRIPTION	REQ.	PART NO.	CRIMPING DATA			TERMINALS
1	WIRE CRIMPER 1-453936-3	1	<del>453936-3</del>	42	Shear Plate Left	1	811855-1	TO APPLY TERMINAL			4264-
2	INS. CRIMPER & Stab. (.160)	1	465604-3	43	Right Shear Guide Block	1	387219				.0126 Stk.
3	ANVIL	1	810765-1	44	Floating Shear	1	465406	WIRE SIZE	CRIMP HEIGHT	WIRE RANGE	350 Feed
4	ANVIL SPACER	1	810017-0	45	Retaining Plate-Front	1	811714-3	22	.426	60016	
5	SHEAR BLADE			46	Retaining Plate- Rear	1	810822-1	20	.043	.051	20
6	REAR SHEAR PLATE			47	Spring-Shear Return	1	374322	18	.045	.055	18
7	SHEAR BLADE SPACER			48	Shear Depressor 453302	1	<del>387255</del>	16	.049	.062	16
8	FRONT SHEAR PLATE			49	Key - Shear Retainer	1	386358	16	.057	.073	14
9	REAR ANVIL SPACER PLT.			50	Adj. Strip Guide Plate	1	692035-1	CRIMP SIZE	TYPE	FEED	
10	FRONT ANVIL SPACER PLT.			51	Rear Adj. Block	1	387252	WIRE			
11	TOOL SPACER			52	Wire Stop Holder Spacer	1	387280	INSUL.	.090	"P"	.250
12	CRIMP SPACER	1	372177	53	Rear Hold Down Holder	1	810771-1	SLEEVED	.130	"O"	.550
13	STRIP GUIDE Plate-Feed	1	387248	54	Rear Hold Down	1	694947-1	INSULATION RANGE	WIRE RANGE	60016	60016
14	REAR STRIP GUIDE	1	387250	55	Hold Down Pin	1	810768-1	REC. MIN. 22-14	MAX. 20-14	22-14	20-14
15	RAM	1	471912	56	Plunger Tip	1	810767-1	EXPLODED VIEW	AI-8012		
16	TOOL HOLDER			57	Spring - Hold Down	1	810773-1	A-6002-1	A-6002-7		
17	ADJ. CRIMP MOUNT ASSY.	1	465392-6	58	Anvil Back-Up Block	1	810769-1	REMARKS:	REC		
18	ADJ. BLOCK			59	Front Strip Hold	1	810799-1				
19	APPLICATOR MOUNT ASSY.			60	<del>Strip Mount</del>	1	<del>811906-1</del>				
20	BASE PLATE	1	473471	61							
21	BASE BLOCK	1	465002-3	62							
22	STRIP GUIDE PLATE 692034-1	1	<del>473471</del>	63	Wire Stop Guide	1	811787-1				
23	ANVIL HOLDER			64	Tension Adj. Plate	1	374999				
24	AUX. ANVIL HOLDER			65							
25	STRIPPER			66	Punch Holder	1	810498-1				
26	STRIPPER MOUNT 386362	1	<del>386362</del>	67	Button Hd. CapScr. 10-32x3/8	1	2-21002-				
27	Wire Stop	1	386361-1	68	Hex Nut 10-32	1	21018-7				
28	STRIPPER MOUNT BRACKET	1	386375	69	<del>2-Pl. 21018-7 Supply Classy</del>	1	<del>21018-7</del>				
29	STRIPPER BUSHING	1	389049-1	70							
30	STOCK DRAG	1	387230	71							
31	STOCK DRAG HANDLE			72	<del>MECH FEED ASSY</del>	1	<del>692140-2</del>				
32	STOCK DRAG STUD			REV. REVISION RECORD				DATE	BY	ECN	
33	STOCK DRAG SPRING	1	373469	K							
34	STOCK DRAG ADJ. Knob	1	21022-3	L	REV FROM 54	11-24-77		IM	L-7135		
35	FEED FINGER HOLDER	1	386912	D	ITEM 22 WAS 50 WAS 473470	3-9-70	RS	IM	L-74-29		
36	FEED FINGER	1	810111	D	OBS TYPED 60204	3-23-70	RS	IM	L-74-29		
37	FEED FINGER TIP	1	387251	E	REV 72 & C.H	3-3-71			L-8138		
38	FEED FINGER SPACER			F	REV PER ECN	7-26-71			L-8409		
39	BASE CASTING	1	570238	G	ITEM 4E WAS 387265-1, 67472	1-71	RS	IM	L-8582		
40	GUARD 457665-2	1	<del>457665-2</del>	H	REV PER ECN	3-29-73	RS	IM	L-9610		
41	<del>Bracket</del>	1	<del>811906-1</del>	HI	INACTIVE ENG	2-17-77	RS	IM	L-9170		

**— INACTIVE —**  
**FOR REPLACEMENT ONLY**

■ DENOTES WEARING PARTS  
RECOMMEND PURCHASE REPLACEMENT

THIS APPLICATOR IS TO BE USED ON  
AMP-O-LECTRIC 1-471273-3

AMP-O-MATHG-1 MECH FEED  
Alignment Gage R-678498

SERIAL NO. DATE SHIPPED DESIGNED

CUSTOMER NAME AND ADDRESS CHK'D.

APPLICATOR NUMBER RE #/ 1-672454-2 SHEET 1 OF 1

DIST. 4

APPR'D. 2-7-74

APPR'D. 12-22-74

OK