

Support & 22 **[Community](http://www.ti.com/product/TPS23525?dcmp=dsproject&hqs=support&#community)**

[TPS23525](http://www.ti.com/product/tps23525?qgpn=tps23525)

SLVSDX0B –OCTOBER 2017–REVISED NOVEMBER 2017

TPS23525: –48-V Hot Swap and Dual OR-ing Controller

1 Features

- -10-V to -80-V DC Operation, -200-V Absolute Maximum
- Soft Start Cap Disconnect
- 400-µA Gate Sourcing Current
- Dual Current Limit (based on V_{DS})
	- $-$ 25 mV ±4% When Low V_{DS}
	- $-$ 3 mV \pm 25% When High V_{DS}
- Programmable $UV(\pm 1.5\%)$ and OV $(\pm 2\%)$
	- Programmable Hysteresis (±11%)
- Integrated Dual OR-ing Controller
	- Regulation: 25 mV ±15 mV
	- Fast Turn off: –6 mV ±4 mV
- Retries After Time Out
- 16-Pin TSSOP

2 Applications

- Remote Radio Units
- **Baseband Units**
- Routers and Switchers
- Small Cells
- –48-V Telecommunications Infrastructure

3 Description

The TPS23525 is an integrated hot swap and dual OR-ing controller that enables high power telecom systems to comply with stringent transient requirements. The 200-V absolute maximum rating makes it easier to survive lightning surge tests (IEC61000-4-5). The soft start cap disconnect allows for the use of smaller hot swap FETs by limiting the inrush current, without hurting the transient response. The 400-µA sourcing current allows fast recovery, which helps to avoid system resets during lightning surge tests. The dual current limit makes it easier to pass brown outs and input steps such as required by the ATIS 0600315.2013. Finally, it offers accurate undervoltage and overvoltage protection with programmable thresholds and hysteresis.

The TPS23525 integrates a dual OR-ing controller, making it ideal for –48-V systems fed by two redundant supplies.

Device Information(1)

(1) For all available packages, see the orderable addendum at the end of the data sheet.

Simplified Schematic

An IMPORTANT NOTICE at the end of this data sheet addresses availability, warranty, changes, use in safety-critical applications, **44** intellectual property matters and other important disclaimers. PRODUCTION DATA.

Table of Contents

8.3 Feature Description... [12](#page-11-0)

4 Revision History

 $\overline{2}$

EXAS STRUMENTS

5 Pin Configuration and Functions

Pin Functions

6 Specifications

6.1 Absolute Maximum Ratings

over operating free-air temperature range (unless otherwise noted)⁽¹⁾

(1) Stresses beyond those listed under *Absolute Maximum Ratings* may cause permanent damage to the device. These are stress ratings only, which do not imply functional operation of the device at these or any other conditions beyond those indicated under *Recommended Operating Conditions*. Exposure to absolute-maximum-rated conditions for extended periods may affect device reliability.

6.2 ESD Ratings

(1) JEDEC document JEP155 states that 500-V HBM allows safe manufacturing with a standard ESD control process.

(2) JEDEC document JEP157 states that 250-V CDM allows safe manufacturing with a standard ESD control process.

6.3 Recommended Operating Conditions

over operating free-air temperature range (unless otherwise noted)

6.4 Thermal Information

(1) For more information about traditional and new thermal metrics, see the *[Semiconductor and IC Package Thermal Metrics](http://www.ti.com/lit/pdf/spra953)* application report.

Thermal Information (continued)

6.5 Electrical Characteristics

 $-$ 40°C ≤ T $_{\rm J}$ ≤125°C, 1.1 mA < I $_{\rm VC}$ < 10 mA, V $_{\rm (UVEN)}$ = 2 V, V $_{\rm (OV)}$ = V $_{\rm (SNS)}$ = V, V $_{\rm (NS)}$ = GATEx = Hi-Z , V $_{\rm (TMR)}$ = 0 V, -1 V < $\rm V$ _{NEG48Vx} < 150 V, ; All pin voltages are relative to VEE (unless otherwise noted)

SLVSDX0B –OCTOBER 2017–REVISED NOVEMBER 2017 **www.ti.com**

Electrical Characteristics (continued)

–40°C ≤ Tյ ≤125°C, 1.1 mA < I_{VCC} < 10 mA, V_(UVEN) = 2 V, V_(OV) = V_(SNS) = V_(D) = 0 V, V_(SS) = GATEx = Hi-Z , V_(TMR) = 0 V, –1 V < $\rm V$ _{NEG48Vx} < 150 V, ; All pin voltages are relative to VEE (unless otherwise noted)

Electrical Characteristics (continued)

–40°C ≤ Tյ ≤125°C, 1.1 mA < I_{VCC} < 10 mA, V_(UVEN) = 2 V, V_(OV) = V_(SNS) = V_(D) = 0 V, V_(SS) = GATEx = Hi-Z , V_(TMR) = 0 V, –1 V < $\rm V$ _{NEG48Vx} < 150 V, ; All pin voltages are relative to VEE (unless otherwise noted)

SLVSDX0B –OCTOBER 2017–REVISED NOVEMBER 2017 **www.ti.com**

6.6 Switching Characteristics

over operating free-air temperature range (unless otherwise noted)

6.7 Typical Characteristics

Unless otherwise noted: –40°C ≤ T_J ≤125°C, 1.1 mA < I_{VCC} < 10 mA, $V_{(UVEN)} = 2$ V, $V_{(OV)} = V_{(SNS)} = V_{(D)} = 0$ V, $V_{(SS)} = GATEX$ $=$ Hi-Z, $V_{(TMR)} = 0 V, -1 V < V_{NEG48Vx} < 150 V$, ;

7 Parameter Measurement Information

7.1 Relationship between Sense Voltage, Gate Current, and Timer

Current

 $I_{GATE, TMR}$

The diagram below illustrates the relationship between the $\rm{V_{SNS}}$ (voltage across $\rm{R_{SNS}}$), Gate current, and the timer operation. The diagram is intended to help explain the various parameters in the electrical characteristic table and is not drawn to scale.

Note that I_{GATE} reduces as the sense voltage approaches the current limit threshold and it equals zero at the current limit regulation point. To ensure that the timer always runs when the IC is in regulation the timer starts at a slightly positive I_{GATE} .

 I_{GATE}

 $\rm V_{\rm SNS, TMR}$

ľ $V_{\text{SNS},C}$ $I_{\rm TMR}$

 V_{SNS}

8 Detailed Description

8.1 Overview

The TPS23525 is an integrated hot swap and Dual OR-ing controller that enables high power telecom systems to comply with stringent transient requirements. The soft start cap disconnect allows soft start at start-up and disconnects the soft start cap during normal operation. This allows for the use of smaller hot swap FETs without hurting the transient response. The 400 µA sourcing current allows fast recovery, which helps to avoid system resets during lightning surge tests. The dual current limit makes it easier to pass brown outs and input steps such as required by the ATIS 0600315.2013. Finally, the TPS23525 offers accurate under voltage and over voltage protection with programmable thresholds and hysteresis.

The TPS23525 integrates a dual OR-ing controller, making it ideal for –48 V systems fed by two redundant supplies.The OR-ing controller will turn off if any reverse current is detected.

8.2 Functional Block Diagram

STRUMENTS

8.3 Feature Description

8.3.1 Current Limit

The TPS23525 utilizes two current limit thresholds:

- I_{CL1} also referred to as high current limit threshold, which is used when the V_{DS} of the hot swap FET is low.
- I_{CL2} lower current limit threshold, which is used when the V_{DS} of the hot swap FET is high.

This dual level protection scheme ensures that the part has a higher chance of riding out voltage steps and other transients due to the higher current limit at low V_{DS} , while protecting the MOSFET during start into short and hotshort events, by setting a lower current limit threshold for conditions with high V_{DS} . The transition threshold is programmed with a resistor that is connected from the drain of the hot swap FET to the D pin of the TPS23525. The figure below illustrates an example with a I_{CL1} set to 25 A and I_{CL2} set to 3 A. Note that compared to a traditional SOA protection scheme this approach allows better utilization of the SOA in the 10 V < V_{DS} < 40-V range, which is critical in riding through transients and voltage steps.

Note that in both cases the TPS23525 regulated the gate voltage to enforce the current limit. However, this regulation is not very fast and doesn't offer the best protection against hot-shorts on the output. To protect in this scenario a fast comparator is used, which quickly pulls down the gate in case of severe over current events (2x bigger than V_{CL1}).

8.3.1.1 Programming the CL Switch-Over Threshold

The V_{DS} threshold when the TPS23525 switches over from I_{CL1} to I_{CL2} (V_{D,SW}) can be computed using [Equation 1](#page-11-1). For example, if a 15-V switch over is desired, R_D should be set to 270 k Ω .

$$
V_{DS,SW} = \frac{1.5 V \times (30 k\Omega + R_D)}{30 k\Omega}
$$
 (1)

8.3.1.2 Programming CL1

The current limit at low V_{DS} (I_{C11}) of the TPS23525 can be computed using [Equation 2](#page-11-2) below.

$$
I_{CL1} = \frac{V_{SNS,CL1}}{R_{SNS}}
$$

Feature Description (continued)

To compute I_{CL1} for a 1-m Ω sense resistor use [Equation 3](#page-12-0) below.

$$
I_{CL1} = \frac{V_{SNS,CL1}}{R_{SNS}} = \frac{25 \text{ mV}}{1 \text{ m}\Omega} = 25 \text{ A}
$$
 (3)

8.3.1.3 Programming CL2

The current limit at high V_{DS} (I_{C12}) of the TPS23525 can be computed using [Equation 4](#page-12-1) below.

$$
I_{CL2} = \frac{V_{SNS, CL2}}{R_{SNS}}
$$
 (4)

To compute I_{CL2} for a 1-m Ω sense resistor use [Equation 5](#page-12-2) below.

$$
I_{CL2} = \frac{V_{\text{SNS,CL2}}}{R_{\text{SNS}}} = \frac{3 \text{ mV}}{1 \text{ m}\Omega} = 3 \text{ A}
$$
\n
$$
(5)
$$

8.3.1.4 Computing the Fast Trip Threshold

The fast trip threshold is set to 2x the I_{CL1} when operating at low V_{DS} and its set to 3x the I_{CL2} when operating at high V_{DS} .

8.3.2 Soft Start Disconnect

The inrush current into the output capacitor (C_{OUT}) can be limited by placing a capacitor between the SS (Soft Start) pin and the drain of the hot swap MOSFET. In that case the inrush current can be computed using equation below.

$$
I_{INR} = \frac{C_{OUT} \times I_{GATE, SRS, STATE}}{C_{SS}} = \frac{660 \, \mu \cdot 20 \, \mu \cdot A}{33 \, \text{nF}} = 0.4 \, \text{A}
$$
\n
$$
\tag{6}
$$

Note that with most hot swap the C_{SS} pin is tied simply to the gate pin, but this can interfere with performance during normal operation if transients or short circuits are encountered. In addition the C_{SS} capacitor tends to pull up the gate during hot plug and cause shoot through current if it is always tied to the gate. For that reason the TPS23525 has a disconnect switch between the gate pin and the SS pin as well as a discharge resistor. During the initial hot plug and during the insertion delay the switch between SS and GATE is open and SS is being discharged to GND through a resistor. Then during start-up SS and GATE are connected to limit the slew rate. Once in normal operation the SS pin is not tied to GATE and it is not shorted to GND, which prevents it from interfering with the operation during transients.

Figure 9. Implementation of SS Disconnect

Feature Description (continued)

8.3.3 Timer

Timer is a critical feature in the hot swap, which manages the stress level in the MOSFET. The timer will source and sink current into the timer capacitor as follows:

- Not in current limit: sink 2 uA
- If the part is in current limit and $V_{GATE} < V_{GATE,TH}$, the timer sources current as follows:
	- $-$ V_D < V_{D,CL} sw: source 10 μ A
	- $-V_D > V_{D,CI-SW}$: source 50 µA

The TPS23525 times out and shuts down the hot swap as follows.

- If $V_D < V_{D, TMR_SW}$ then the hot swap times out when V_{TMR} reaches 1.5 V.
- If $V_D > V_{D,TMR-SW}$ then the hot swap times out when V_{TMR} reaches 0.75 V.

The above behavior maximizes the ability of the hot swap to ride out voltage steps, while ensuring that the FET remains safe even if the part can not ride out a voltage step.

A cool down period follows after the part times out. During this time the timer performs the following:

- Discharge C_{TMR} with a 2-µA current source until 0.5 V
- Charge C_{TMR} with a 10-µA current source until it is back to 1.5 V.
- Repeat the above 64 times
- Discharge timer to 0 V.

The part attempts to restart after finishing the above. If the UVEN signal is toggled while the 64 cycles are in progress the part restarts immediately after the 64 cycles are completed.

The timer operates as follows when recovering from POR:

- If V_{TMR} < 0.5 V:
	- Proceed to regular startup
	- $-$ Do not discharge V_{TMR}
- If $V_{TMR} > 0.5 V$:
	- Go through 64 charge/discharge cycles
	- $-$ Discharge V_{TMR}
	- Proceed to startup

The Time Out (T_{TO}) can be computed using the equations below. Note that the time out depends on the V_{DS} of the MOSFET.

$$
T_{TO} = \frac{C_{TMR} \times V_{TMR}}{I_{TMR, SRS}}
$$
 (7)

$$
T_{TO}(V_D < 0.75 V) = \frac{C_{TMR} \times 1.5 V}{10 \mu A}
$$

$$
\sim \mu \tag{8}
$$

$$
T_{TO}(0.75 V < V_D < 1.5 V) = \frac{C_{TMR} \times 0.75 V}{10 \mu A}
$$
 (9)

$$
T_{TO}(V_D > 1.5 V) = \frac{C_{TMR} \times 0.75 V}{50 \mu A}
$$
 (10)

Feature Description (continued)

8.3.4 OR-ing

The TPS23525 features integrated OR-ing that controls the external MOSFET in a way to emulate an ideal diode. The TPS23525 will regulate the forward drop across the OR-ing FET to 25 mV. This is accomplished by controlling the V_{GS} of the MOSFET. As the current decreases the V_{GS} is also decreased, which effectively increases the $\mathsf{R}_{\mathsf{DSON}}$ of the MOSFET. This process is regulated with a low gain amplifier that is gate (OR-ing FET) pole compensated. The lower gain helps ensure stability over various operating conditions. The regulating amplifier ensures that there is no DC reverse current.

However, the amplifier is not very fast and thus it is paired with a fast comparator. This comparator quickly turns off the FET if there is significant reverse current detected.

Figure 10. Simplified Diagram of OR-ing Block

8.4 Device Functional Modes

Device Functional Modes (continued)

The Figure above shows a simplified state machine of the hot swap controller. It has 4 distinct operating states and the controller switches between these states based on the following signals:

- Ving rc: This means that both the input voltage is in the right range and the IC has power with Vcc. A 4-us delay is added for deglitching. If the input voltage is above the OV threshold, input voltage is below the UV threshold, or VCC is below its internal UVLO, Ving_rc will be low.
- TimeOut: This signal comes from the timer block and will be asserted Hi if the IC has timed out due to an over-current condition. This signal is also Hi while the timer is going through the restart cycles. Once the cycles are completed this signal will go Low.
- ins_over: This signal states that the insertion delay has been completed and the hot swap is ready to start-up.
- FT: this is the fast trip signal coming from the fast trip comparator. It goes Hi if an extreme over current event is detected.
- PG: Internal Power good signal. This is high when the hot swap is fully on and the load can draw full power. For PG to be Hi, the GATE has to be Hi and the drain pin needs to be below 0.75 V.
- PG_degl: This is a deglitched version of the PG and is the signal used to move between states and controls the external PGb pin.

8.4.1 OFF State

In this state the hot swap FET is turned off and the controller is waiting to start-up. The controller can be in this state due to any of these scenarios:

- Input voltage is not in the valid range.
- The hot swap is in the cool down state and the timer is going through the retry cycle after a fault condition such as output hot short or over current.
- VCC is below its UVLO threshold and the IC doesn't have enough power to operate properly.

8.4.2 Insertion Delay State

In this state the hot swap FET is turned off and the controller is waiting for the insertion delay to finish. This allows the input supply to settle after a Hot Plug. If any of the following occur, the controller will be kicked back to the OFF state:

- Input voltage is not in the valid range.
- VCC is below its UVLO threshold and the IC doesn't have enough power to operate properly.
- Once the insertion delay is finished, the controller will move to the Start-up state.

8.4.3 Start-up State

In this state the controller is turning on and charging the output cap. The operation is set as follows:

- The SS pin is internally connected to the GATE pin to allow for output dv/dt control.
- Lower gate sourcing current is applied to the GATE pin to allow for smaller SS caps.
- The lower current limit setting of $V_{\text{SNS,CI2}}$ and a lower fast trip setting of $V_{\text{SNS,EST2}}$ is used to minimize the MOSFET stress in case of a fault condition.

If any of the following occur, the controller will be kicked back to the OFF state:

- Input voltage is not in the valid range.
- The timer times out due to over-current.
- VCC is below its UVLO threshold and the IC doesn't have enough power to operate properly.
- Fast trip is triggered.

Once the PG degl signal goes Hi, the controller will move to the Normal Operation state.

8.4.4 Normal Operation State

In this state the hot swap is fully on and the operation is set as follows:

- The SS pin is disconnected from the GATE pin to improve transient response.
- The full gate sourcing current is used to improve transient response.
- The current limit and fast trip threshold are a function of the D pin to optimize the transient response while protecting the MOSFET.

Device Functional Modes (continued)

If any of the following occur, the controller will be kicked back to the OFF state:

- • PG degl goes low.
- The timer times out due to over-current.

• VCC is below its UVLO threshold and the IC doesn't have enough power to operate properly.

Note that if the input voltage is outside the valid range or the fast trip is triggered, the hot swap FET will turn off, but the controller will not exit the Normal Operation state. In this case the PG signal would go low immediately. If this condition persists, the PG_degl will go low as well and the controller would move to the OFF state. This operation prevents the controller from re-starting the system during quick transients.

Texas **NSTRUMENTS**

9 Application and Implementation

NOTE

Information in the following applications sections is not part of the TI component specification, and TI does not warrant its accuracy or completeness. TI's customers are responsible for determining suitability of components for their purposes. Customers should validate and test their design implementation to confirm system functionality.

9.1 Application Information

The TPS23525 is a hot swap controller for –48-V applications and is used to manage inrush current and protect downstream circuitry and the upstream bus in case of fault conditions. The following key scenarios should be considered when designing a –48-V hot swap circuit:

- Start Up.
- Output of a hot swap is shorted to ground while the hot swap is on. This is often referred to as a Hot Short.
- Powering up a board when the output and ground are shorted. This is usually called a start-into-short.
- Input lightning surge. Here it is usually desired to avoid damage to downstream circuitry and to avoid system restarts.

These scenarios place a lot of stress on the hot swap MOSFET and the board designer should take special care to ensure that the MOSFET stays within it's Safe Operating Area (SOA) under all of these conditions. A detailed design example is provided below and the key equations are written out. Note that solving all of these equations by hand is cumbersome and can result in errors. Instead, TI recommends using the TPS2352X Design Calculator provided on the product page.

9.2 Typical Application

Figure 12. Application Diagram for Design Example

Typical Application (continued)

9.2.1 Design Requirements

The table below summarizes the design parameters that must be known before designing a hot swap circuit. When charging the output capacitor through the hot swap MOSFET, the FET's total energy dissipation equals the total energy stored in the output capacitor (1/2CV²). Thus both the input voltage and output capacitance will determine the stress experienced by the MOSFET. The maximum load power will drive the current limit and sense resistor selection. In addition, the maximum load current, maximum ambient temperature, and the thermal properties of the PCB ($R_{\theta CA}$) will drive the selection of the MOSFET's R_{DSON} and the number of MOSFETs used. $R_{\theta CA}$ is a strong function of the layout and the amount of copper that is connected to the drain of the MOSFET. Air cooling will also reduce $R_{\theta CA}$ substantially. Finally, it's important to know what transients the circuit has to pass in order to size up the input protection accordingly.

Table 1. Design Requirements for a –38 V to –60 V, 400-W Protection Circuit

9.2.2 Detailed Design Procedure

9.2.2.1 Selecting R_{SNS}

Before selecting R_{SNS} , first compute the maximum load current. For this example the worst case load current happens at the minimum input voltage of 38 V. Thus the maximum current is 400 W/38 V = 10.5 A. To provide some margin, set the target current limit to 12 A and compute R_{SNS} using equation below:

$$
R_{\text{SNS,CLC}} = \frac{V_{\text{SNS,CL1}}}{I_{\text{CL1}}} = \frac{25 \text{ mV}}{12 \text{ A}} = 2.08 \text{ m}\Omega
$$
\n(11)

Use next available R_{SNS} of 2 m Ω .

9.2.2.2 Selecting Soft Start Setting: C_{SS} and C_{SS, VEE}

First, compute the minimum inrush current where the timer will trip using equation below.

$$
I_{\text{INR,TMR}} = \frac{V_{\text{SNS,TMR2}}}{R_{\text{SNS}}} = \frac{1.5 \text{ mV}}{2 \text{ m}\Omega} = 0.75 \text{ A}
$$
\n(12)

To avoid running the timer the inrush current needs to be sufficiently low. Target 0.4 A of inrush current to allow margin, and compute the target C_{SS} using equation below.

$$
c_{SS} = \frac{c_{OUT,MAX} \times I_{GATE, SRS, STATE}}{I_{INR, TGT}} = \frac{792 \, \mu F \times 20 \, \mu A}{0.4 \, A} = 39.6 \, nF
$$
\n(13)

Next choose, the next available C_{SS} greater than 39.6 nF. For this example 43 nF was used, which assumes a 33 nF and 10 nF cap in parallel. This results in an inrush current of 0.37 A at max C_{OUT} (792 μ F) and inrush current of 0.31 A at typical C_{OUT} (660 µF). Also it is recommended to add a capacitor between the soft start pin and VEE ($C_{SS,VEE}$) to improve immunity to input voltage noise during soft start. It's recommended to chose a capacitor that's 3x larger than C_{SS} . In this case a 150 nF capacitor was chosen.

Finally the start-up time at maximum input voltage can be computed using the equation below:

$$
T_{\text{START}}(V_{\text{IN,MAX}}) = \frac{c_{SS} \times V_{\text{IN,MAX}}}{I_{\text{GATE, SRS, START}}}
$$
 =
$$
\frac{43nF \times 60 \text{ V}}{20 \text{ }\mu\text{A}}
$$
 = 129 ms (14)

9.2.2.3 Selecting V_{DS} Switch Over Threshold

 $\left(V_{IN,MAX}\right) = \frac{C_{SS} \times V_{IN,MAX}}{I_{GATE, SRS, START}}$

shold where the current limit sold improves ability to ride the

can also expose the MOSFE

shold improves ability to ride the

can also expose the MOSFE

sholding in the target R The V_{DS} threshold where the current limit switches from CL1 to CL2 can be programmed using R_D . In general a higher threshold improves ability to ride through voltage steps, brown outs, and other transients. However, a larger setting can also expose the MOSFET to more stress, because the larger current limit is now allowed at higher V_{DS} voltages. If there are no specific voltage step requirements, 20 V is a good starting point. Use the equation below to compute the target R_D .

$$
R_D = 30 \text{ k}\Omega \times \left(\frac{V_{DS,SW}}{1.5 \text{ V}} - 1\right) = 370 \text{ k}\Omega
$$
\n(15)

9.2.2.4 Timer Selection

The timer determines how long the hot swap can be in current limit before timing out and can be programmed using C_{TMR} . In general a longer time out (T_{TO}) improves ability to ride through voltage steps, brown outs, and other transients. However, a larger setting can also expose the MOSFET to more stress, because it takes longer for the FET to shut down during fault conditions. If there are no specific voltage step or transient requirements, 2 ms is a good starting point. Use the equation below to compute the target C_{TMR} . Choose the next available capacitor value of 15 nF, which results in a 2.25 ms time out.

$$
C_{TMR} = \frac{T_{TO} \times I_{TMR, SRS}}{V_{TMR}} = \frac{2 \text{ ms} \times 10 \text{ }\mu\text{A}}{1.5 \text{ V}} = 13.3 \text{ nF}
$$
\n(16)

9.2.2.5 MOSFET Selection and SOA Checks

When selecting MOSFETs for the -48 V application the three key parameters are: V_{DS} rating, R_{DSON} , and safe operating area (SOA). For this application the CSD19535KTT was selected to provide a 100 V V_{DS} rating, low R_{DSON}, and sufficient SOA. After selecting the MOSFET, it is important to double check that it has sufficient SOA to handle the key stress scenarios: start-up, output Hot Short, and Start into Short. MOSFET's SOA is usually specified at a case temperature of 25°C and should be derated based on the maximum case temperature expected in the application. Compute the maximum case temperature using the equation below. Note that the R_{DSON} will vary with temperature and solving the equation below could be a repetitive process. The CSD19535KTT, has a maximum 3.4 mΩ R_{DSON} at room temperature and is ~1.5x higher at 100°C. N stands for the number of MOSFETs used in parallel.

$$
T_{C,MAX} = T_{A,MAX} + R_{\theta CA} \times \left(\frac{I_{LOAD,MAX}}{N}\right)^{2} \times R_{DSON}(T_{J})
$$
\n(17)

$$
T_{C,MAX} = 85 \,^{\circ}\text{C} + 20 \,^{\circ}\frac{\text{C}}{\text{W}} \times (10.5 \, \text{A})^2 \times (3.4 \times 1.5 \, \text{m}\Omega) = 96.3 \,^{\circ}\text{C}
$$
\n⁽¹⁸⁾

Next the stress the MOSFET will experience during operation should be compared to the FETs capability. First, consider the power up. The inrush current with max C_{OUT} will be 0.37 A and the inrush will last for 129 ms. Note that the power dissipation of the FET will start at $V_{IN,MAX} \times I_{INR}$ and reduce to zero as the V_{DS} of the MOSFET is reduced. The SOA curve of a typical MOSFET assume the same power dissipation for a given time. A conservative approach is to assume an equivalent power profile where P_{FET} = $V_{IN,MAX}$ × I_{INR} for t = Tstart-up /2. In this instance, the SOA can be checked by looking at a 60 V, 0.4 A, 64.5 ms pulse. Based on the SOA of the CSD19535KTT, it can handle 60 V, 1.8 A for 10 ms and it can handle 60 V, 1 A for 100 ms. The SOA at T_c = 25°C for 64.5 ms can be extrapolated by approximating SOA vs time as a power function as shown in equations below:

$$
I_{\text{SOA}}(t) = a \times t^m \tag{19}
$$

$$
m = \frac{\ln (I_{\text{SOA}}(t_1)/I_{\text{SOA}}(t_2))}{\ln(t_1/t_2)} = \frac{\ln \left(\frac{1.8 \text{ A}}{1 \text{ A}}\right)}{\ln \left(\frac{10 \text{ ms}}{100 \text{ ms}}\right)} = -0.25
$$
\n(20)

$$
a = \frac{I_{\text{SOA}}(t_2)}{t_2^m} = \frac{1 \text{ A}}{(100 \text{ ms})^{-0.25}} = 3.16 \text{ A} \times (\text{ms})^{0.25}
$$
 (21)

$$
I_{\text{SOA}}\left(64.5 \text{ ms}, 25 \text{ °C}\right) = 3.16 \text{ A} \times \left(\text{ms}\right)^{0.52} \times \left(64.5 \text{ ms}\right)^{-0.25} = 1.12 \text{ A}
$$
\n(22)

Finally, the FET SOA needs to be derated based on the maximum case temperature as shown below. Note that the FET can handle 0.59 A, while it will have 0.37 A during start-up. Thus there is a lot of margin during this test condition.

$$
I_{\text{SOA}}\left(64.5 \text{ ms}, \text{T}_{\text{C},\text{MAX}}\right) = 1.12 \text{ A} \times \frac{175 \text{ °C} - 96.3 \text{ °C}}{175 \text{ °C} - 25 \text{ °C}} = 0.59 \text{ A}
$$
\n(23)

A similar approach should be taken to compute the FETs SOA capability during a Hot Short and start into short. As shown in the following figure, during a start into short the gate is coming up very slowly due to a large capacitance tied to the gate through the SS pin. Thus it is more stressful than a Hot Short and should be used for worst case SOA calculations. To compare the FET stress during start-up into short to the SOA curves the stress needs to be approximated as a square pulse as showing in the figure below. In this example, the stress is approximated with a 1.1 ms (Teq), 1.5 A, 60 V pulse. The FET can handle 6 A, 60 V for 1 ms and 1.8 A, 60 V for 10 ms. Using approximation and temp derating as shown earlier, the FET's capability can be computed as 3 A, 60 V, for 1.1 ms at 96°C. 3 A is significantly larger than 1.5 A implying good margin.

INSTRUMENTS

Texas

Figure 13. Teq During a Start Into a Short

The final operating point to check is the operation with high current and V_{DS} just below the $V_{DS,SW}$ threshold. In this example, the time out would be 1.1ms (one half of the time out at $Vd = 0 V$), the current will be 12.5 A, and the voltage would be 20 V. Looking up the SOA curve, the FET can handle 30 A, 20 V for 1 ms and 10 A, 20 V for 10 ms. Repeating previously shown approximations and temp derating, the FET's capability is computed to be 16 A, 20 V, for 1.1 ms at 96°C. Again this is below the worst case operating point of 12.5 A and 20 V suggesting good margin.

9.2.2.6 Input Cap, Input TVS, and OR-ing FET selection

This design example is sized for an application that needs to pass a 2 kV, 2Ω lightning strike per IEC61000-4-5. This equates to almost 1000 A of input current that needs to be clamped. In addition, the design needs to pass reverse hook up and thus the TVS needs to be bi directional. A ceramic transient voltage suppressor (2x B72540T6500S162) CT2220K50E2G was used to clamp this huge surge of current. According to it's datasheet it can clamp 500 A of current to 150 V. Note that the lightning strike can be positive or negative. The worst case voltage is dropped across the OR-ing FETs when the strike is positive (–48 V line goes above RTN). If the output of the OR-ing is –48 V and the input goes to +150 V that is a 200 V drop. Thus BSC320N20NS3 was chosen for the OR-ing FETs. This is a 200 V FET with a 32 m Ω R_{DSON} at room temperature. 2 of these were used in parallel to minimize power loss and manage thermal. Finally a 0.1μ F input bypass cap is recommended.

9.2.2.7 EMI Filter Consideration

In this example it is assumed that the EMI filter is right after the hot swap and the bulk cap is after the EMI filter. The EMI filter adds significant inductance and needs to be accounted for. During a Hot Short, the inductor builds up significant current that needs to go somewhere after the FET opens. For that a free wheeling diode should be used along with a snubber. For this example a 150 V, SMA diode was used: STPS1150A. The snubber consisted of a 10-Ω resistor in series with a 1-µF ceramic capacitor. In addition a 0.1-µF ceramic cap was tied directly on the output.

(27)

9.2.2.8 Under Voltage and Over Voltage Settings

Both the threshold and hysteresis can be programmed for under voltage and over voltage protection. In general the rising UV threshold should be set sufficiently below the minimum input voltage and the falling OV threshold should be set sufficiently above the maximum input voltage to account for tolerances. For this example a rising UV threshold of 37 V and a falling UV threshold of 35 V was chosen as the target. First, choose R_{UV1} based on the 2 V UV hysteresis as shown below.

flUV,hyst,tgt UV1 UV,hyst ^V 2 V R 200 k i 10 µA fl (24)

Once R_{UV1} is known R_{UV2} can be computed based on the target rising UV threshold as shown below.

$$
R_{UV2} = \frac{R_{UV1}}{V_{UV, TGT, Rising} - 1 \text{ V}} = \frac{200 \text{ k}\Omega}{37 \text{ V} - 1 \text{ V}} = 5.56 \text{ k}\Omega
$$
\n(25)

The OV setting can be programmed in a similar fashion as shown in equations below.

$$
R_{OVI} = \frac{V_{OV, hyst, tgt}}{i_{OV, hyst}} = \frac{3 V}{10 \mu A} = 300 k\Omega
$$
\n(26)\n
$$
R_{OVI} = \frac{R_{OVI}}{i} = \frac{300 k\Omega}{1000 k} = 4.68 k\Omega
$$

$$
R_{OV2} = \frac{R_{OV1}}{V_{OV, TGT, Rising} - 1 \text{ V}} = \frac{300 \text{ k}\Omega}{65 \text{ V} - 1 \text{ V}} = 4.68 \text{ k}\Omega
$$
\n(28)

Optional filtering capacitors can be added to the UV and OV to improve immunity to noise and transients on the input bus. These should be tuned based on system requirements and input inductance. In this example place holders were added to the PCB, but the components were not populated.

9.2.2.9 Choosing R_{VCC} and C_{VCC}

The VCC is used as internal supply rail and is a shunt regulator. To ensure stability of internal loop a minimum of 0.1 μ F is required for C_{VCC}. To ensure reasonable power on time it is recommended to keep C_{VCC} below 1 μ F. R_{VCC} should be sized in such a way to ensure that sufficient current is supplied to the IC at minimum operating voltage corresponding to the falling UV threshold. To allow for some margin it is recommended that the current through R_{VCC} is at least 1.2x of I_{Q,MAX} when RTN = Falling UV threshold and VCC = 10 V (minimum recommended operating voltage on VCC). For this example R_{VCC} of 16.2 k Ω was used.

9.2.2.10 Power Good Interface to Downstream DC/DC

It's critical to keep the downstream DC/DC off while the hot swap is charging the bulk capacitor. This can be accomplished through the PGb pin. Note that the VEE of the hot swap and the DC/DC are different and the Power Good can not be directly tied to the EN or UV of the DC/DC. The application circuit below provides a simple way to control the downstream converter with the PGb pin of the hot swap.

Figure 14. Interface to DC/DC

SLVSDX0B –OCTOBER 2017–REVISED NOVEMBER 2017 **www.ti.com**

9.2.3 Application Curves

SLVSDX0B –OCTOBER 2017–REVISED NOVEMBER 2017 **www.ti.com**

www.ti.com SLVSDX0B –OCTOBER 2017–REVISED NOVEMBER 2017

SLVSDX0B –OCTOBER 2017–REVISED NOVEMBER 2017 **www.ti.com**

www.ti.com SLVSDX0B –OCTOBER 2017–REVISED NOVEMBER 2017

SLVSDX0B –OCTOBER 2017–REVISED NOVEMBER 2017 **www.ti.com**

10 Power Supply Recommendations

In general, the TPS23525 is designed to have robust operation from a non-ideal –48 V bus with various transients such as the lightning surge. The IC is powered through RVCC making it more immune to supply drop outs and high voltage spikes. Regardless, TI recommends following several key precautions:

- Always test the solution with the various transients that can be encountered in the systems. This especially applies to transients that were not tested with TI's EVM.
- If large input ripple is expected during start-up, increase the ratio of $C_{SS, VEE}$ to C_{SS} to reduce input current ripple at start-up.
- Operating from large input inductance $(>40 \mu H)$ can cause instability to the current limit loop or oscillations during start-up. Add a capacitor from Gate to VEE to help stabilize the current limit loop. Add an input snubber if oscillations are observed at start-up.

EXAS ISTRUMENTS

11 Layout

11.1 Layout Guidelines

There are several things to keep in mind during layout of the TPS23525 circuit:

- The VEE and SNS pin need to have a Kelvin Sense connection to the sense resistor.
- The VEE trace carries current and needs to be thick and short in order to minimize IR drop and to avoid introducing current sensing error.

• It is recommended to use a net-tie to separate the power plane coming into the R_{SNS} and the Kelvin connection to VEE.

● Connect the Neg48Vx filtering caps, UVEN resistor divider, OV resistor divider, and TMR cap to the "VEE" to insure maximum accuracy.

● The filtering caps on Neg48VB, Neg48VA, and SNS should be placed as close to the IC as possible.

11.2 Layout Example

Figure 57. Layout Example

12 Device and Documentation Support

12.1 Device Support

12.1.1 Third-Party Products Disclaimer

TI'S PUBLICATION OF INFORMATION REGARDING THIRD-PARTY PRODUCTS OR SERVICES DOES NOT CONSTITUTE AN ENDORSEMENT REGARDING THE SUITABILITY OF SUCH PRODUCTS OR SERVICES OR A WARRANTY, REPRESENTATION OR ENDORSEMENT OF SUCH PRODUCTS OR SERVICES, EITHER ALONE OR IN COMBINATION WITH ANY TI PRODUCT OR SERVICE.

12.2 Documentation Support

12.2.1 Related Documentation

For related documentation see the following:

• TPS23525EVM-815 Evaluation Module User's Guide [\(SLVUB36](http://www.ti.com/lit/pdf/SLVUB36))

12.3 Receiving Notification of Documentation Updates

To receive notification of documentation updates, navigate to the device product folder on ti.com. In the upper right corner, click on *Alert me* to register and receive a weekly digest of any product information that has changed. For change details, review the revision history included in any revised document.

12.4 Community Resources

The following links connect to TI community resources. Linked contents are provided "AS IS" by the respective contributors. They do not constitute TI specifications and do not necessarily reflect TI's views; see TI's [Terms of](http://www.ti.com/corp/docs/legal/termsofuse.shtml) [Use.](http://www.ti.com/corp/docs/legal/termsofuse.shtml)

[TI E2E™ Online Community](http://e2e.ti.com) *TI's Engineer-to-Engineer (E2E) Community.* Created to foster collaboration among engineers. At e2e.ti.com, you can ask questions, share knowledge, explore ideas and help solve problems with fellow engineers.

[Design Support](http://support.ti.com/) *TI's Design Support* Quickly find helpful E2E forums along with design support tools and contact information for technical support.

12.5 Trademarks

E2E is a trademark of Texas Instruments.

All other trademarks are the property of their respective owners.

12.6 Electrostatic Discharge Caution

This integrated circuit can be damaged by ESD. Texas Instruments recommends that all integrated circuits be handled with appropriate precautions. Failure to observe proper handling and installation procedures can cause damage.

ESD damage can range from subtle performance degradation to complete device failure. Precision integrated circuits may be more susceptible to damage because very small parametric changes could cause the device not to meet its published specifications.

12.7 Glossary

[SLYZ022](http://www.ti.com/lit/pdf/SLYZ022) — *TI Glossary*.

This glossary lists and explains terms, acronyms, and definitions.

13 Mechanical, Packaging, and Orderable Information

The following pages include mechanical, packaging, and orderable information. This information is the most current data available for the designated devices. This data is subject to change without notice and revision of this document. For browser-based versions of this data sheet, refer to the left-hand navigation.

```
Copyright © 2017, Texas Instruments Incorporated Submit Documentation Feedback
```


www.ti.com 10-Dec-2020

PACKAGING INFORMATION

(1) The marketing status values are defined as follows:

ACTIVE: Product device recommended for new designs.

LIFEBUY: TI has announced that the device will be discontinued, and a lifetime-buy period is in effect.

NRND: Not recommended for new designs. Device is in production to support existing customers, but TI does not recommend using this part in a new design.

PREVIEW: Device has been announced but is not in production. Samples may or may not be available.

OBSOLETE: TI has discontinued the production of the device.

⁽²⁾ RoHS: TI defines "RoHS" to mean semiconductor products that are compliant with the current EU RoHS requirements for all 10 RoHS substances, including the requirement that RoHS substance do not exceed 0.1% by weight in homogeneous materials. Where designed to be soldered at high temperatures. "RoHS" products are suitable for use in specified lead-free processes. TI may reference these types of products as "Pb-Free".

RoHS Exempt: TI defines "RoHS Exempt" to mean products that contain lead but are compliant with EU RoHS pursuant to a specific EU RoHS exemption.

Green: TI defines "Green" to mean the content of Chlorine (CI) and Bromine (Br) based flame retardants meet JS709B low halogen requirements of <=1000ppm threshold. Antimony trioxide based flame retardants must also meet the <=1000ppm threshold requirement.

(3) MSL, Peak Temp. - The Moisture Sensitivity Level rating according to the JEDEC industry standard classifications, and peak solder temperature.

(4) There may be additional marking, which relates to the logo, the lot trace code information, or the environmental category on the device.

(5) Multiple Device Markings will be inside parentheses. Only one Device Marking contained in parentheses and separated by a "~" will appear on a device. If a line is indented then it is a continuation of the previous line and the two combined represent the entire Device Marking for that device.

(6) Lead finish/Ball material - Orderable Devices may have multiple material finish options. Finish options are separated by a vertical ruled line. Lead finish/Ball material values may wrap to two lines if the finish value exceeds the maximum column width.

Important Information and Disclaimer:The information provided on this page represents TI's knowledge and belief as of the date that it is provided. TI bases its knowledge and belief on information provided by third parties, and makes no representation or warranty as to the accuracy of such information. Efforts are underway to better integrate information from third parties. TI has taken and continues to take reasonable steps to provide representative and accurate information but may not have conducted destructive testing or chemical analysis on incoming materials and chemicals. TI and TI suppliers consider certain information to be proprietary, and thus CAS numbers and other limited information may not be available for release.

In no event shall TI's liability arising out of such information exceed the total purchase price of the TI part(s) at issue in this document sold by TI to Customer on an annual basis.

PACKAGE OPTION ADDENDUM

TEXAS

TAPE AND REEL INFORMATION

ISTRUMENTS

QUADRANT ASSIGNMENTS FOR PIN 1 ORIENTATION IN TAPE

Pack Materials-Page 1

www.ti.com www.ti.com 3-Jun-2022

PACKAGE MATERIALS INFORMATION

*All dimensions are nominal

PACKAGE OUTLINE

PW0016A TSSOP - 1.2 mm max height

SMALL OUTLINE PACKAGE

NOTES:

- 1. All linear dimensions are in millimeters. Any dimensions in parenthesis are for reference only. Dimensioning and tolerancing per ASME Y14.5M.
- 2. This drawing is subject to change without notice.
- 3. This dimension does not include mold flash, protrusions, or gate burrs. Mold flash, protrusions, or gate burrs shall not exceed 0.15 mm per side.
- 4. This dimension does not include interlead flash. Interlead flash shall not exceed 0.25 mm per side.
- 5. Reference JEDEC registration MO-153.

EXAMPLE BOARD LAYOUT

PW0016A TSSOP - 1.2 mm max height

SMALL OUTLINE PACKAGE

NOTES: (continued)

6. Publication IPC-7351 may have alternate designs.

7. Solder mask tolerances between and around signal pads can vary based on board fabrication site.

EXAMPLE STENCIL DESIGN

PW0016A TSSOP - 1.2 mm max height

SMALL OUTLINE PACKAGE

8. Laser cutting apertures with trapezoidal walls and rounded corners may offer better paste release. IPC-7525 may have alternate design recommendations.

9. Board assembly site may have different recommendations for stencil design.

IMPORTANT NOTICE AND DISCLAIMER

TI PROVIDES TECHNICAL AND RELIABILITY DATA (INCLUDING DATA SHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS AND IMPLIED, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for skilled developers designing with TI products. You are solely responsible for (1) selecting the appropriate TI products for your application, (2) designing, validating and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, regulatory or other requirements.

These resources are subject to change without notice. TI grants you permission to use these resources only for development of an application that uses the TI products described in the resource. Other reproduction and display of these resources is prohibited. No license is granted to any other TI intellectual property right or to any third party intellectual property right. TI disclaims responsibility for, and you will fully indemnify TI and its representatives against, any claims, damages, costs, losses, and liabilities arising out of your use of these resources.

TI's products are provided subject to [TI's Terms of Sale](https://www.ti.com/legal/termsofsale.html) or other applicable terms available either on [ti.com](https://www.ti.com) or provided in conjunction with such TI products. TI's provision of these resources does not expand or otherwise alter TI's applicable warranties or warranty disclaimers for TI products.

TI objects to and rejects any additional or different terms you may have proposed.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265 Copyright © 2022, Texas Instruments Incorporated