

SWITCH08 - DIN RAIL MOUNTED 8 PORT ETHERNET SWITCH



- UNMANAGED SWITCH REQUIRES NO CONFIGURATION
- SUPPORTS 10/100 MDPS NETWORK
- AUTO HALF/FULL DUPLEX NEGOTIATION
- AUTO-CROSSING DETECTION SUPPORTS STANDARD AND CROSSOVER ETHERNET CABLES






UL Recognized Component, File # E244362

DESCRIPTION

The SWITCH08 is an eight-port Ethernet switch designed to simplify network expansion, while improving the network's efficiency. Eight 10/100 Base-T ports, with auto negotiation of half or full duplex connections requires no setup, reducing installation time. The SWITCH08 also offers an auto-crossing feature, which allows connections to be made with any combination of standard or crossover Ethernet cables.

The SWITCH08 may be powered with two DC sources, allowing for redundancy in critical applications. A relay output provides a warning signal if the backup supply fails, ensuring continued operation when needed.



SAFETY SUMMARY

All safety related regulations, local codes and instructions that appear in the literature or on equipment must be observed to ensure personal safety and to prevent damage to either the instrument or equipment connected to it. If equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.



CAUTION: Read complete instructions prior to installation and operation of the unit.

ORDERING INFORMATION

MODEL NO.	DESCRIPTION	PART NUMBER
SWITCH	8-Port Ethernet Switch	SWITCH08

SPECIFICATIONS

1. POWER: 24 VDC ±20 %, 4.8 W

2. RELAY OUTPUT: Single N.C. 24 VDC @ 100 mA max.

3. LEDs:

V1+ and V2+ - On when proper voltage is present at respective terminal Link/Act - On indicates link established; blinking indicates network activity on the port.

100 - On indicates 100 Mbps connection established; off indicates 10 Mbps connection.

4. ENVIRONMENTAL CONDITIONS:

Operating Temperature Range: 0 to +55°C **Storage Temperature Range**: -20 to +70°C

Operating and Storage Humidity: 30-95%, non-condensing

Altitude: Up to 1500 meters

5. CONSTRUCTION: Brushed aluminum housing.

6. CONNECTIONS:

POWER: Removable wire clamp screw terminal block.

Wire Gage Capacity: 24 AWG to 12 AWG Torque: 4.45 to 5.34 in/lb (0.5 to 0.6 N-m) ETHERNET: 8-position RJ-45 female connector

 MOUNTING: Snaps onto standard DIN style top hat (T) profile mounting rails according to EN50022 -35 x 7.5 and -35 x 15.

8. CERTIFICATIONS AND COMPLIANCES:

Immunity to Industrial Locations:

EN 61000-4-2	Criterion B
EN 61000-4-3	Criterion A
EN 61000-4-4	Criterion A
EN 61000-4-5	Criterion B
EN 61000-4-6	Criterion A
EN 61000-4-8	Criterion A
EN 55022	Class A
	EN 61000-4-3 EN 61000-4-4 EN 61000-4-5 EN 61000-4-6 EN 61000-4-8

Mechanical:

Shock IEC 60068-2-27

Operation: 25g, 11 msec period, half-sine shock pulse Storage: 50g, 11 msec period, half-sine shock pulse

Vibration IEC 60068-2-6

Operation/Storage: 5g, 150 Hz Criterion 3

Fall IEC 60068-2-32 3.281 ft (1 m)


9. WEIGHT: 0.61 lbs. (0.27 Kg)

POWER

The SWITCH08 can be powered in various configurations with either one or two +24 VDC SELV power supplies. How it is wired depends on whether or not a backup power supply is desired for failsafe operation. (For example, if the relay isn't used, a single power supply may be connected to +V1 only.)



NOTE: MUST USE SELV POWER SUPPLIES



RELAY OUTPUT

The N.C. relay output remains closed as long as the proper voltage is present at both +V1 and +V2 terminals. In the event of a voltage failure at one of the terminals, the contact is opened. This may be used to signal other systems that one of the power supplies has failed.

MOUNTING

Mount the SWITCH08 to a grounded standard DIN rail. The switch will be grounded once it is snapped onto the rail. Additionally the noise immunity can be improved in environments with high electromagnetic smog by a low-impedance connection to the functional earth through terminal 7.



NOTE: The SWITCH08 module was designed for use with SELV in accordance with IEC 950 / EN 60950 / VDE 0805

TROUBLESHOOTING

For further technical assistance, contact technical support at the appropriate company numbers listed.