## **General Description**

The MAX16816 is a current-mode, high-brightness LED (HB LED) driver designed to control two external n-channel MOSFETs for single-string LED current regulation. The MAX16816 integrates all the building blocks necessary to implement fixed-frequency HB LED drivers with wide-range dimming control and EEPROM-programmable LED current binning with a factor of up to 1.6. This device is configurable to operate as a step-down (buck), step-up (boost), or step-up/ step-down (buck-boost) current regulator.

Current-mode control with adjustable leading-edge blanking simplifies control-loop design. Adjustable slope compensation stabilizes the current loop when operating at duty cycles above 50%. The MAX16816 operates over a wide input voltage range and is capable of withstanding load-dump events. Multiple MAX16816 devices can be synchronized to each other or to an external clock. The MAX16816 includes a floating dimming driver for brightness control with an external n-channel MOSFET in series with the LED string.

HB LEDs using the MAX16816 can achieve efficiencies of over 90%. The MAX16816 also includes a 1.4A source and 2A sink gate driver for driving switching MOSFETs in highpower LED driver applications, such as front light assemblies. Dimming control allows for wide PWM dimming range at frequencies up to 5kHz. Higher dimming ratios (up to 1000:1) are achievable at lower dimming frequencies.

The MAX16816 provides user-programmable features through on-chip nonvolatile EEPROM registers. Adjustable features include a programmable soft-start, LED current (binning), external MOSFET gate driver supply voltage, slope compensation, leading-edge blanking time, and disabling/enabling of the RT oscillator.

The MAX16816 is available in a 32-pin TQFN package with exposed pad and operates over the -40°C to +125°C automotive temperature range.

## **Applications**

- **General Illumination**
- Navigation and Marine Indicators
- Neon Replacement, Emergency Lighting
- Signage and Beacons

### **Features**

- EEPROM-Programmable LED Current Binning
- Wide Input Range: 5.9V to 76V with Cold-Start Operation to 5.4V
- Integrated Floating Differential LED Current-Sense Amplifier
- Floating Dimming Driver Capable of Driving an n-Channel MOSFET
- 5% or Better LED Current Accuracy
- Multiple Topologies: Buck, Boost, Buck-Boost, SEPIC
- Resistor-Programmable Switching Frequency (125kHz to 500kHz) and Synchronization Capability
- 200Hz On-Board Ramp Allows Analog-Controlled PWM Dimming and External PWM Dimming
- Output Overvoltage, Overcurrent, and LED Short Protection
- Enable/Shutdown Input with Shutdown Current Below 45μA

## **Ordering Information**



*+Denotes a lead(Pb)-free/RoHS-compliant package. \*\*EP = Exposed pad.*

## **Typical Operating Circuits**





## **Absolute Maximum Ratings**





*\*As per JEDEC 51 standard, Multilayer Board (PCB).*

Stresses beyond those listed under "Absolute Maximum Ratings" may cause permanent damage to the device. These are stress ratings only, and functional operation of the device at these<br>or any other conditions beyond those in *device reliability.*

## **Package Thermal Characteristics (Note 1)**

 Junction-to-Ambient Thermal Resistance (θJA) ............29°C/W Junction-to-Case Thermal Resistance (θJC) ................1.7°C/W

**Note 1:** Package thermal resistances were obtained using the method described in JEDEC specification JESD51-7, using a four-layer board. For detailed information on package thermal considerations, refer to **www.maximintegrated.com/thermal-tutorial**.

## **Electrical Characteristics**



# **Electrical Characteristics (continued)**



# **Electrical Characteristics (continued)**



## **Electrical Characteristics (continued)**



# **Electrical Characteristics (continued)**



## **Electrical Characteristics (continued)**



# **Electrical Characteristics (continued)**



# **Electrical Characteristics (continued)**

(V<sub>CC</sub> = V<sub>UVEN</sub> = 14V, C<sub>REG1</sub> = 1μF, C<sub>REG2</sub> = 1μF, C<sub>CLMP</sub> = 0.1μF, R<sub>T</sub> = 25kΩ, T<sub>A</sub> = T<sub>J</sub> = -40°C to +125°C, unless otherwise noted. Typical specifications are at  $T_A$  = +25°C.)



# **Electrical Characteristics – 1-Wire® System**

(C<sub>REG1</sub> = 1μF, C<sub>REG2</sub> = 1μF, T<sub>A</sub> = T<sub>J</sub> = -40°C to +125°C, unless otherwise noted. Typical specifications are at T<sub>A</sub> = +25°C.)



*1-Wire is a registered trademark of Maxim Integrated Products, Inc.*

## **Electrical Characteristics (continued)**

- **Note 2:** Dropout voltage is defined as the input to output differential voltage at which the output voltage drops 100mV below its nominal value measured at output.
- **Note 3:** V<sub>CLMP</sub><sub>TH</sub> determines the voltage necessary to operate the current-sense amplifier. The DIM driver requires 2.5V for (V<sub>CLMP</sub>) -  $V_{LO}$ ) to drive a FET. V<sub>HI</sub> is typically one diode drop above V<sub>CLMP</sub>. A large capacitor connected to V<sub>CLMP</sub> slows the response of the LED current-sense circuitry, resulting in current overshoot. To ensure proper operation, connect a 0.1μF capacitor from CLMP to LO.
- **Note 4:** Minimum pulse width required to guarantee proper dimming operation.
- **Note 5:** FAULT multiplexes a programming interface and fault-indication functionality. At power-up initialization, an internal timer enables FAULT and two programming passcodes must be entered within the programming slot to enter programming mode. If the programming passcodes are not received correctly within the programming slot, FAULT goes back towards fault indication. Cycling power to the device is required to re-attempt entry into programming mode.
- **Note 6:** Not production tested. Guaranteed by design.
- **Note 7:** Recovery time is the time required for FAULT to be pulled high by the internal 10kΩ resistor.

## **Typical Operating Characteristics**

(V<sub>CC</sub> = V<sub>UVEN</sub> = 14V, C<sub>REG1</sub> = 1μF, C<sub>REG2</sub> = 10μF, C<sub>CLMP</sub> = 0.1μF, R<sub>CS</sub> = 0.1Ω, Binning adjustment register is '0000', T<sub>A</sub> = +25°C, unless otherwise noted.)



## **Typical Operating Characteristics (continued)**

(V<sub>CC</sub> = V<sub>UVEN</sub> = 14V, C<sub>REG1</sub> = 1μF, C<sub>REG2</sub> = 10μF, C<sub>CLMP</sub> = 0.1μF, R<sub>CS</sub> = 0.1Ω, Binning adjustment register is '0000', T<sub>A</sub> = +25°C, unless otherwise noted.)



## **Typical Operating Characteristics (continued)**

(V<sub>CC</sub> = V<sub>UVEN</sub> = 14V, C<sub>REG1</sub> = 1μF, C<sub>REG2</sub> = 10μF, C<sub>CLMP</sub> = 0.1μF, R<sub>CS</sub> = 0.1Ω, Binning adjustment register is '0000', T<sub>A</sub> = +25°C, unless otherwise noted.)



# **Pin Description**



# **Pin Description (continued)**



# **Functional Diagram**



## **Detailed Description**

The MAX16816 is a current-mode PWM LED driver for use in driving HB LEDs. An output current accuracy of 5% is achievable using two current-regulation loops: one current-regulation loop controls the external switching MOSFET peak current through a sense resistor  $(R_{\text{SENSE}})$ from SNS+ to SNS- while the other current-regulation loop controls the average LED string current through the sense resistor,  $R_{CS}$ , in series with the LEDs.

The MAX16816 provides LED binning through one programmable on-chip nonvolatile EEPROM. The LED current can be scaled up to a factor of 1.6. This feature is used to offset factory LED luminance variations and allows the system to achieve overall luminance accuracy.

A programmable undervoltage lockout (UVEN) ensures predictable operation during brownout conditions. The UVEN input circuitry monitors the supply voltage  $(V_{CC})$ and turns the driver off when  $V_{CC}$  drops below the UVLO threshold. Connect UVEN to  $V_{CC}$  to use the 5.7V (typ) default UVLO threshold. The MAX16816 includes a cycleby-cycle current limit that turns off the gate drive to the external switching MOSFET  $(Q<sub>S</sub>)$  during an overcurrent condition and a programmable oscillator that simplifies and optimizes the design of external magnetics.

The MAX16816 is capable of synchronizing to an external clock or operating in a stand-alone mode. A single resistor  $(R<sub>T</sub>)$  can be used to adjust the switching frequency from 125kHz to 500kHz for stand-alone operation. To synchronize the device with an external clock, apply a clock signal directly to the RTSYNC input. A buffered clock output, CLKOUT, is available to configure the MAX16816 for multichannel applications.

The external RT oscillator can be disabled by setting EEPROM register RTOF to '1'. The MAX16816 provides wide contrast pulsed dimming (up to 1000:1) utilizing a separate dimming input. Apply either a DC level voltage or low-frequency PWM signal to the dimming input. DC level input results in a 200Hz fixed dimming frequency.

The MAX16816 provides configurable on-chip nonvolatile EEPROM features including a programmable soft-start, load current, external MOSFET gate-driver supply voltage, blanking time, and slope compensation.

Protection features include peak current limiting, HICCUP mode current limiting, output overvoltage protection, shortcircuit protection, and thermal shutdown. The HICCUP current-limit circuitry reduces the power delivered to the load during severe fault conditions. A nonlatching overvoltage protection limits the voltage on the external switching MOSFET  $(Q<sub>S</sub>)$  under open-circuit conditions in the LED

# MAX16816 **Programmable Switch-Mode LED Driver** with Analog-Controlled PWM Dimming

string. During continuous operation at high input voltages, the power dissipation of the MAX16816 could exceed the maximum rating and the internal thermal shutdown circuitry safely turns off the MAX16816 when the device junction temperature exceeds +165°C. When the junction temperature drops below the hysteresis temperature, the MAX16816 automatically reinitiates startup.

## **Undervoltage Lockout/Enable (UVEN)**

The MAX16816 features a dual-purpose adjustable undervoltage lockout input and enable function (UVEN). Connect UVEN to  $V_{CC}$  through a resistive voltage-divider to set the undervoltage-lockout (UVLO) threshold. The device is enabled when the voltage at UVEN exceeds the 1.244V (typ) threshold. Drive UVEN to ground to disable the output.

### **Setting the UVLO Threshold**

Connect UVEN directly to  $V_{CC}$  to select the default 5.7V (typ) UVLO threshold. Connect UVEN to  $V_{CC}$  through a resistive voltage-divider to select a UVLO threshold (Figure 1). Select the desired UVLO threshold voltage,  $V_{\text{UVLO}}$ , and calculate resistor values using the following equation:

$$
R_{UV1} = R_{UV2} \times \left(\frac{V_{UVEN}}{V_{UVLO} - V_{UVEN}}\right)
$$

where  $R_{UV1}$  +  $R_{UV2}$  ≤ 270k $\Omega$ . V<sub>UVEN</sub> is the 1.244V (typ) UVEN threshold voltage.

The capacitor  $C_{\text{UVEN}}$  is required to prevent chattering at the UVLO threshold due to line impedance drops during power-up and dimming. If the undervoltage setting is very close to the required minimum operating voltage, there can



*Figure 1. Setting the UVLO Threshold*

be large jumps in the voltage at  $V_{CC}$  during dimming, which may cause the MAX16816 to turn on and off when the dimming signal transitions from low to high. The capacitor  $C_{\text{UVFN}}$  should be large enough to limit the ripple on UVEN to less than the 100mV (min) UVEN hysteresis so that the device does not turn off under these circumstances.

## **Soft-Start**

The MAX16816 features a digitally programmable soft-start delay that allows the load current to ramp up in a controlled manner, minimizing output overshoot. Soft-start begins once the device is enabled and  $V_{CC}$  exceeds the UVLO threshold. Soft-start circuitry slowly increases the internal soft-start voltage  $(V_{SS})$ , resulting in a controlled rise of the load current. Signals applied to DIM are ignored until the soft-start duration is complete and a successive delay of 200μs has elapsed. Use the Digital Soft-Start Duration register in the EEPROM to select a soft-start duration from 0 (no delay) to 4.096ms. See the *EEPROM and Programming* section for more information on using the Digital Soft-Start Duration register.

## **Regulators (REG1, REG2, CLAMP)**

The MAX16816 includes a fixed 5V voltage regulator, REG1; an EEPROM-adjustable regulator, REG2; and an internal 8V regulator, CLAMP. REG1 and REG2 power up when V<sub>CC</sub> exceeds the UVLO threshold. REG1 supplies power to internal circuitry and remains on during PWM dimming. REG1 is capable of driving external loads up to 2mA.

Use the REG2 Control Register in the EEPROM to select an output voltage from 5V to 15V for REG2. Connect REG2 to DRI to generate the supply voltage for the primary switching MOSFET driver, DRV. REG2 is capable of delivering up to 20mA of current. See the *EEPROM and Programming* section for more information on configuring the REG2 output voltage.

CLAMP is powered by HI and supplies power to the current-sense amplifier (CSA). CSA is enabled when V<sub>CLMP</sub> goes 2.5V above  $V_{LO}$  and is disabled when ( $V_{CLMP}$  -  $V_{LO}$ ) falls below 2.28V. The CLAMP regulator also provides power to the dimming MOSFET control circuitry. CLMP is the output of the CLAMP regulator. Do not use CLMP to power external circuitry. Bypass CLMP to LO with a 0.1μF ceramic capacitor. A larger capacitor will result in overshoot of the load current.

## **Reference Voltage Output (REF)**

The MAX16816 includes a 5% accurate, 3V (typ) buffered reference output, REF. REF is a push-pull output capable of sourcing/sinking up to 200μA of current and can drive a maximum load capacitance of 100pF. Connect REF

# MAX16816 **Programmable Switch-Mode LED Driver** with Analog-Controlled PWM Dimming

to DIM through a resistive voltage-divider to supply an analog signal for dimming. See the *Dimming Input (DIM)*  section for more information.

## **Dimming MOSFET Driver (DDR)**

The MAX16816 requires an external n-channel MOSFET for PWM dimming. Connect the MOSFET to the output of the DDR dimming driver (DGT) for normal operation.  $V_{\text{DGT}}$ swings between  $V_{LO}$  and  $V_{CLMP}$ . The DDR dimming driver is capable of sinking or sourcing up to 20mA of current. The average current required to drive the dimming MOSFET (IDRIVE\_DIM) depends on the MOSFET's total gate charge  $(Q_G_D|_M)$  and the dimming frequency of the converter,  $f_{\text{DIM}}$ . Use the following equation to calculate the supply current for the n-channel dimming FET driver.

### $I_{DRIVE_DIM} = Q_G_{DIM} x$  f<sub>DIM</sub>

## **n-Channel MOSFET Switch Driver (DRV)**

The MAX16816 drives an external n-channel MOSFET for switching. Use an external supply or connect REG2 to DRI to power the MOSFET driver. The driver output,  $V_{DRV}$ , swings between ground and  $V_{DRI}$ . Ensure that VDRI remains below the absolute maximum  $V_{GS}$  rating of the external MOSFET. DRV is capable of sinking 2A or sourcing 1.4A of peak current, allowing the MAX16816 to switch MOSFETs in high-power applications. The average current sourced to drive the external MOSFET depends on the total gate charge  $(Q_G)$  and operating frequency of the converter  $(f_{SW})$ . The power dissipation in the MAX16816 is a function of the average output drive current ( $I_{DRIVF}$ ). Use the following equations to calculate the power dissipation in the gate-driver section of the  $MAX16816$  due to  $I_{DRIVE}$ :

$$
I_{DRIVE} = Q_G \times f_{SW}
$$

$$
P_D = I_{DRIVE} \times V_{DRI}
$$

where  $V_{\text{DRI}}$  is the supply voltage to the gate driver.

## **Dimming Input (DIM)**

The dimming input, DIM, functions with either analog or PWM control signals. Once the internal pulse detector detects three successive edges of a PWM signal with a frequency between 80Hz and 2kHz, the MAX16816 synchronizes to the external signal and pulse-width modulates the LED current at the external DIM input frequency with the same duty cycle as the DIM input. If an analog control signal is applied to DIM, the MAX16816 compares the DC input to an internally generated 200Hz ramp to pulse-width modulate the LED current ( $f_{\text{DIM}}$  = 200Hz). The output current duty cycle is linearly adjustable from 0 to 100% (0.2V <  $V_{\text{DIM}}$  < 2.8V).

Use the following formula to calculate voltage  $(V_{\text{DIM}})$ necessary for a given output current duty cycle (D):

$$
V_{\text{DIM}} = (D \times 2.6) + 0.2V
$$

where  $V_{\text{DIM}}$  is the voltage applied to DIM in volts.

Connect DIM to REF through a resistive voltage-divider to apply a DC DIM control signal (Figure 2). Use the required dimming input voltage  $(V_{\text{DIM}})$  calculated above and select appropriate resistor values using the following equation:

$$
R4 = R3 \times V_{\text{DIM}}/(V_{\text{REF}} - V_{\text{DIM}})
$$

where V<sub>REF</sub> is the 3V reference output voltage and 15kΩ  $≤$  R<sub>3</sub> + R<sub>4</sub> ≤ 150kΩ.

A minimum 20μs pulse width is necessary for proper operation during dimming.

### **Oscillator, Clock, and Synchronization**

The MAX16816 is capable of stand-alone operation, of synchronizing to an external clock, and of driving external devices in SYNC mode. For stand-alone operation, set the EEPROM Oscillator Enable/Disable (RTOF) bit to '1' to use the fixed internal 125kHz oscillator or set RTOF to '0' and program the switching frequency by connecting a single external resistor  $(R_T)$  between RTSYNC and ground. Select a switching frequency ( $f_{SW}$ ) between 125kHz and 500kHz and calculate  $R<sub>T</sub>$  using the following formula:

$$
R_T = \frac{500kHz}{f_{SW}} \times 25k\Omega
$$

where the switching frequency is in kHz and  $R<sub>T</sub>$  is in kΩ.

To synchronize the MAX16816 with an external clock signal ranging from 125kHz to 500kHz, set the RTOF bit to '0' and connect the clock signal to the RTSYNC input. The MAX16816 synchronizes to the clock signal after the detection of 5 successive clock edges at RTSYNC.



*Figure 2. Creating DIM Input Signal from REF*

# MAX16816 **Programmable Switch-Mode LED Driver** with Analog-Controlled PWM Dimming

A buffered clock output, CLKOUT, can drive the RTSYNC input of an external PWM controller for multichannel applications. CLKOUT can drive capacitive loads up to 500pF.

If the PWM switching frequency is set to 125kHz, the RTSYNC oscillator can be temporarily disabled by setting the EEPROM RTOF bit to '1'. In this case, the internal 125kHz frequency-fixed oscillator drives the PWM. See the *EEPROM and Programming* section for more information on setting the Oscillator Enable/Disable bit in the EEPROM.

## **Multichannel Configuration**

The MAX16816 is capable of multichannel operation and is configurable as a master or slave in a Master-Slave configuration, or in a Peer-to-Peer configuration. Connect CLKOUT to the SYNC input of an external device to use the MAX16816 as a master clock signal. Connect an external clock signal to RTSYNC to configure the MAX16816 as a slave. To setup two MAX16816 devices in a daisy-chain configuration, drive the RTSYNC input of one MAX16816 with the CLKOUT buffer of another (Figure 3).

## **ILIM and HICCUP Comparator**

R<sub>SENSE</sub> sets the peak current through the inductor for switching. The differential voltage across RSENSE is compared to the 200mV voltage-trip limit of the currentlimit comparator, ILIM. Set the current limit 20% higher than the peak switch current at the rated output power and minimum voltage. Use the following equation to calculate R<sub>SENSE</sub>:

$$
R_{\text{SENSE}} = V_{\text{SENSE}}/(1.2 \times I_{\text{PEAK}})
$$

where  $V_{\text{SENSE}}$  is the 200mV maximum differential voltage between  $SNS+$  and  $SNS-$  and  $I_{PFAK}$  is the peak inductor current at full load and minimum input voltage.

When the voltage drop across RSENSE exceeds the ILIM threshold, the MOSFET driver (DRV) terminates the



*Figure 3. Master-Slave/Peer-Peer Clock Configuration*

on-cycle and turns the switch off, reducing the current through the inductor. The FET is turned back on at the beginning of the next switching cycle.

When the voltage across RSENSE exceeds the 300mV (typ) HICCUP threshold, the HIC comparator terminates the on-cycle of the device, turning the switching MOSFET off. Following a startup delay of 8ms (typ), the MAX16816 reinitiates soft-start. The device will continue to operate in HICCUP mode until the overcurrent condition is removed.

A programmable built-in leading-edge blanking circuit of the current-sense signal prevents these comparators from prematurely terminating the on-cycle of the external switching MOSFET  $(Q<sub>S</sub>)$ . Select a blanking time from 75ns to 150ns by configuring the Blanking Time register in the EEPROM. In some cases, the maximum blanking time may not be adequate and an additional RC filter may be required to prevent spurious turn-off.

## **Load Current Sense**

The load current-sense resistor  $(R_{CS})$  monitors the current through the LEDs. The internal floating currentsense amplifier (CSA) measures the differential voltage across  $R_{CS}$ , and generates a voltage proportional to the load current through  $R_{CS}$  at CS. This voltage on CS is referred to AGND. The closed loop regulates the load current to a value  $(I_{LED})$  given by the following equation:

## $I_{LED} = V_{SS}/R_{CS}$

where  $V_{SS}$  is the binning adjustment voltage. Set the value of V<sub>SS</sub> in the Binning Adjustment register in the EEPROM between 100mV and 166mV. See the *EEPROM and Programming* section for more information on adjusting the binning voltage.

### **Slope Compensation**

The amount of slope compensation required is largely dependent on the down-slope of the inductor current when the switching MOSFET  $(Q_S)$  is off. The inductor down-slope depends on the input-to-output voltage differential of the converter, the inductor value, and the switching frequency. For stability, the compensation slope should be equal to or greater than half of the inductor current down-slope multiplied by the current-sense resistance (RSENSE).

See the *EEPROM and Programming* section for more information on the ESLP register.

## **Internal Voltage-Error Amplifier (EAMP)**

The MAX16816 includes a built-in voltage amplifier, with three-state output, which can be used to close the feedback loop. The buffered output current-sense signal appears at CS, which is connected to the inverting input (FB) of the

error amplifier through resistor  $R_1$ . The noninverting input is connected to an internally trimmed current reference.

The output of the error amplifier is controlled by the signal applied to DIM. When DIM is high, the output of the amplifier is connected to COMP. The amplifier output is open when DIM is low. This enables the integrating capacitor to hold the charge when the DIM signal has turned off the gate drive. When DIM is high again, the voltage on the compensation capacitors  $(C_1$  and  $C_2$ ) forces the converter into steady state almost instantaneously.

### **PWM Dimming**

PWM dimming is achieved by driving DIM with either a PWM signal or a DC signal. The PWM signal is connected internally to the error amplifier, the dimming MOSFET gate driver, and the switching MOSFET gate driver. When the DIM signal is high, the dimming MOSFET and the switching MOSFET drivers are enabled and the output of the voltage-error amplifier is connected to the external compensation network. Also, the buffered current-sense signal is connected to CS. Preventing discharge of the compensation capacitor when the DIM signal is low allows the control loop to return the LED current to its original value almost instantaneously.

When the DIM signal goes low, the output of the error amplifier is disconnected from the compensation network and the compensation capacitors  $(C_1$  and  $C_2$ ) voltage is preserved. Choose low-leakage capacitors for  $C_1$  and  $C_2$ . The drivers for the external dimming and switching MOSFETs are disabled, and the converter stops switching. The inductor energy is now transferred to the output capacitors.

When the DIM signal goes high and the gate drivers are enabled, the additional voltage on the output capacitor may cause a current spike on the LED string. A larger output capacitor will result in a smaller current spike. If the overcurrent spike exceeds 30% of the programmed LED current, the dimming is turned off and the MAX16816 reinitiates soft-start.

## **FAULT 1-Wire Interface**

The MAX16816 features a FAULT output multiplexed with a 1-Wire programming interface. Once the voltage at UVEN exceeds the UVLO threshold, the device is enabled and FAULT will pulse low once, indicating the beginning of the programming window. Two programming mode entry codes must be entered within 8ms after the pulse to enter programming mode (see Table 1). The MAX16816 will register the second entry code only after the first code has been received. Once the MAX16816 successfully enters programming mode, the data and clock for the 1-Wire interface are supplied through FAULT.

Once the programming window has passed, the EEPROM is no longer accessible without cycling power to the device. Under these conditions, FAULT will go low only when a fault (overvoltage, overcurrent, or HICCUP mode) occurs or when the supply voltage drops below the UVLO threshold.

### **EEPROM and Programming**

Nonvolatile EEPROM is available to configure the MAX16816 through a 1-Wire serial interface. Registers are located in a linear address space as shown in Table 2. All other EEPROM locations are reserved.

## **Table 1. Programming Mode Entry Codes**

Configure the six control registers to adjust parameters including the REG2 voltage, soft-start durations, blanking time, LED load current (binning), slope compensation, and to enable/disable the RTOF oscillator. See the *1-Wire Interface* section for more information about 1-Wire programming.

### **Binning-Adjustment Register (BIN)**

The MAX16816 uses a feedback loop to control the load current. The differential voltage across the current-sense resistor  $(R_{CS})$  is compared with an internal adjustable reference to regulate the LED current. The voltage across



## **Table 2. EEPROM Memory Map**



the sense resistor is measured differentially to achieve high immunity to common-mode noise. The MAX16816 includes a factory-set regulation voltage of 133mV ±3% across  $R_{CS}$ . Adjust the differential regulation voltage by programming the binning adjustment register (see Table 3). The reference voltage level may not necessarily be equal to the regulation voltage. There are offsets involved that are trimmed at the factory. Read the default register code and step up the code by one to increase the regulation voltage by 6.66mV. Step down the code by one to reduce the regulation voltage by 6.66mV.

### **REG2 Control Register (DRPS)**

REG2 is EEPROM configurable to supply a voltage ranging from 5V to 15V and is capable of sourcing up to 20mA. Connect REG2 to the primary switching MOSFET gate-driver supply input, DRI, for normal operation.

Adjust REG2 by programming the REG2 Control Register. See Table 4.



## **Table 3. Binning Adjustment Register**

\**Not recommended.*

# MAX16816 **Programmable Switch-Mode LED Driver** with Analog-Controlled PWM Dimming

### **Blanking Time-Adjustment Register (BLNK)**

The MAX16816 features a programmable blanking time to mask out the current-sense signal for a short duration to avoid the ILIM and HICCUP comparators from prematurely terminating the on-cycle of the switching MOSFET. This blanking time allows for higher input current during startup without triggering a fault condition. The blanking time is adjustable in the range of 150ns to 75ns by configuring the EEPROM. See Table 5.

## **Table 4. REG2 Control Register**



\**Factory default.*

## **Table 5. Blanking Time**



\**Factory default*

### **Digital Soft-Start Duration Register (SS)**

The MAX16816 programmable soft-start feature allows the load current to ramp up in a controlled manner, eliminating output overshoot during startup. Soft-start begins once the device is enabled and  $V_{CC}$  has exceeded the 5.5V (min) rising threshold voltage. Adjust the soft-start duration by configuring the EEPROM. Enter '111' to disable the softstart feature. See Table 6.

### **Oscillator Enable/Disable Register (RTOF)**

The MAX16816 features a programmable accurate RTSYNC oscillator and resistor synchronized to an external clock. Set the EEPROM bit RTOF to '1' to disable the external sync mode, and the RTSYNC oscillator, and to use the fixed internal frequency of 125kHz as the switching frequency. Set RTOF to '0' to synchronize with an external oscillator or to program the external oscillator frequency with an external resistor,  $R_T$ . See Table 7.

### **Slope Compensation Register (ESLP)**

The MAX16816 uses an internally generated ramp to stabilize the current loop when operating at duty cycles above 50%. Set the compensating slope by adjusting the peak ramp voltage through the on-chip EEPROM. See Tables 8 and 9.

## **Table 6. Digital Soft-Start Duration**



\**Factory default*

## **Table 7. Oscillator Enable/Disable**



\**Factory default*

# MAX16816 **Programmable Switch-Mode LED Driver** with Analog-Controlled PWM Dimming

## **Table 8. Slope Compensation with Clock Generated by RT Oscillator**



\**Factory default.*

## **Table 9. Slope Compensation with External Clock Applied to RTSYNC or RT Oscillator Off**



\**Factory default*

## **Fault Protection**

The MAX16816 features built-in overvoltage protection, overcurrent protection, HICCUP mode current-limit protection, and thermal shutdown. Overvoltage protection is achieved by connecting OV to HI through a resistive voltage-divider. HICCUP mode limits the power dissipation in the external MOSFETs during severe fault conditions. Internal thermal shutdown protection safely turns off the converter when the IC junction temperature exceeds +165°C.

### **Overvoltage Protection**

The overvoltage-protection (OVP) comparator compares the voltage at OV with a 1.235V (typ) internal reference. When the voltage at OV exceeds the internal reference, the OVP comparator terminates PWM switching and no further energy is transferred to the load. The MAX16816 reinitiates soft-start once the overvoltage condition is removed. Connect OV to HI through a resistive voltagedivider to set the overvoltage threshold at the output.

### **Setting the Overvoltage Threshold**

Connect OV to HI or to the high-side of the LEDs through a resistive voltage-divider to set the overvoltage threshold at the output (Figure 4). The overvoltage protection (OVP) comparator compares the voltage at OV with a 1.235V (typ) internal reference. Use the following equation to calculate resistor values:

$$
R_{OVI} = R_{OV2} \times \left(\frac{V_{OV\_LIM} - V_{OV}}{V_{OV}}\right)
$$

where  $V_{\text{OV}}$  is the 1.235V OV threshold. Choose  $R_{\text{OV1}}$ and  $R<sub>OV2</sub>$  to be reasonably high-value resistors to prevent discharge of filter capacitors. This will prevent unnecessary undervoltage and overvoltage conditions during dimming.

### **Load-Dump Protection**

The MAX16816 features load-dump protection up to 76V. LED drivers using the MAX16816 can sustain single fault load dump events. Repeated load dump events within very short time intervals can cause damage to the dimming MOSFET due to excess power dissipation.

### **Thermal Shutdown**

The MAX16816 contains an internal temperature sensor that turns off all outputs when the die temperature exceeds +165°C. Outputs are enabled again when the die temperature drops below +145°C.

## **Applications Information**

### **Inductor Selection**

The minimum required inductance is a function of operating frequency, input-to-output voltage differential, and the peak-to-peak inductor current  $(\Delta I)$ . Higher  $\Delta I_1$  allows for a lower inductor value while a lower  $\Delta I_1$ requires a higher inductor value. A lower inductor value minimizes size and cost, improves large-signal transient response, but reduces efficiency due to higher peak currents and higher peak-to-peak output ripple voltage for the same output capacitor. On the other hand, higher inductance increases efficiency by reducing the ripple current, Δl<sub>l</sub>. However, resistive losses due to extra turns can exceed the benefit gained from lower ripple current levels, especially when the inductance is increased without also allowing for larger inductor dimensions. A good compromise is to choose  $\Delta I_1$  equal to 30% of the full load current. The inductor saturating current is also important to avoid runaway current during the output overload and continuous short circuit. Select the  $I_{\text{SAT}}$  to be higher than the maximum peak current limit.

Buck configuration: In a buck configuration the average inductor current does not vary with the input. The worstcase peak current occurs at high input voltage. In this case the inductance (L) for continuous-conduction mode is given by:

$$
L = \frac{V_{OUT} \times (V_{INMAX} - V_{OUT})}{V_{INMAX} \times f_{SW} \times \Delta I_L}
$$

where  $V_{INMAX}$  is the maximum input voltage,  $f_{SW}$  is the switching frequency, and  $V_{\text{OUT}}$  is the output voltage.



*Figure 4. Setting the Overvoltage Threshold*

Boost configuration: In the boost converter, the average inductor current varies with line and the maximum average current occurs at low line. For the boost converter,

the average inductor current is equal to the input current. In this case the inductance  $(L)$  is calculated as:

$$
L = \frac{V_{INMIN} \times (V_{OUT} - V_{INMIN})}{V_{OUT} \times f_{SW} \times \Delta I_L}
$$

where  $V_{INMIN}$  is the minimum input voltage,  $V_{OUT}$  is the output voltage, and  $f_{SW}$  is the switching frequency. Buck-boost configuration: In a buck-boost converter the average inductor current is equal to the sum of the input current and the load current. In this case the inductance, L, is:

$$
L = \frac{V_{OUT} \times V_{INMIN}}{(V_{OUT} + V_{INMIN}) \times f_{SW} \times \Delta I_L}
$$

where  $V_{INMIN}$  is the minimum input voltage,  $V_{OUT}$  is the output voltage, and  $f_{SW}$  is the switching frequency.

### **Output Capacitor**

The function of the output capacitor is to reduce the output ripple to acceptable levels. The ESR, ESL, and the bulk capacitance of the output capacitor contribute to the output ripple. In most of the applications, the output ESR and ESL effects can be dramatically reduced by using low-ESR ceramic capacitors. To reduce the ESL effects, connect multiple ceramic capacitors in parallel to achieve the required bulk capacitance.

In a buck configuration, the output capacitance  $(C_F)$  is calculated using the following equation:

$$
C_F \geq \frac{(V_{INMAX} - V_{OUT}) \times V_{OUT}}{\Delta V_R \times 2 \times L \times V_{INMAX} \times f_{SW}^2}
$$

where  $\Delta V_R$  is the maximum allowable output ripple.

In a boost configuration, the output capacitance  $(C_F)$  is calculated as:

$$
C_F \geq \frac{(V_{OUT} - V_{INMIN}) \times 2 \times I_{OUT}}{\Delta V_R \times V_{OUT} \times f_{SW}}
$$

where  $I_{\text{OUT}}$  is the output current.

In a buck-boost configuration, the output capacitance  $(C_F)$ is calculated as:

$$
C_F \geq \frac{2 \times V_{OUT} \times I_{OUT}}{\Delta V_R \times (V_{OUT} + V_{INMIN}) \times f_{SW}}
$$

# MAX16816 **Programmable Switch-Mode LED Driver** with Analog-Controlled PWM Dimming

where  $V_{\text{OUT}}$  is the voltage across the load and  $I_{\text{OUT}}$  is the output current.

### **Input Capacitor**

An input capacitor connected between  $V_{CC}$  and ground must be used when configuring the MAX16816 as a buck converter. Use a low-ESR input capacitor that can handle the maximum input RMS ripple current. Calculate the maximum allowable RMS ripple using the following equation:

$$
I_{IN(RMS)} = \frac{I_{OUT} \times \sqrt{V_{OUT} \times (V_{INMIN} - V_{OUT})}}{V_{INMIN}}
$$

In most of the cases, an additional electrolytic capacitor should be added to prevent input oscillations due to line impedances.

When using the MAX16816 in a boost or buck-boost configuration, the input RMS current is low and the input capacitance can be small (see the *Typical Operating Circuits*).

### **Operating the MAX16816 Without the Dimming Switch**

The MAX16816 can also be used in the absence of the dimming MOSFET. In this case, the PWM dimming performance is compromised but in applications that do not require dimming the MAX16816 can still be used. A short circuit across the load will cause the MAX16816 to disable the gate drivers and they will remain off until the input power is recycled.

### **Switching Power MOSFET Losses**

When selecting MOSFETs for switching, consider the total gate charge, power dissipation, the maximum drain-tosource voltage, and package thermal impedance. The product of the MOSFET gate charge and  $R_{DS(ON)}$  is a figure of merit, with a lower number signifying better performance. Select MOSFETs optimized for high-frequency switching applications.

### **Layout Recommendations**

Typically, there are two sources of noise emission in a switching power supply: high di/dt loops and high dv/dt surfaces. For example, traces that carry the drain current often form high di/dt loops. Similarly, the heatsink of the MOSFET connected to the device drain presents a high dv/dt source; therefore, minimize the surface area of the heatsink as much as possible. Keep all PCB traces carrying switching currents as short as possible to minimize current loops. Use ground planes for best results.

Careful PCB layout is critical to achieve low switching losses and clean, stable operation. Use a multilayer board whenever possible for better noise performance and power dissipation. Follow these guidelines for good PCB layout:

- Use a large copper plane under the MAX16816 package. Ensure that all heat-dissipating components have adequate cooling. Connect the exposed pad of the device to the ground plane.
- Isolate the power components and high current paths from sensitive analog circuitry.
- Keep the high-current paths short, especially at the ground terminals. This practice is essential for stable, jitter-free operation. Keep switching loops short.
- Connect AGND, SGND, and QGND to a ground plane. Ensure a low-impedance connection between all ground points.
- Keep the power traces and load connections short. This practice is essential for high efficiency. Use thick copper PCBs (2oz vs. 1oz) to enhance full-load efficiency.
- Ensure that the feedback connection to FB is short and direct.
- Route high-speed switching nodes away from the sensitive analog areas.
- $\bullet$  To prevent discharge of the compensation capacitors (C<sub>1</sub>) and C2) during the off-time of the dimming cycle, ensure that the PCB area close to these components has extremely low leakage. Discharge of these capacitors due to leakage may result in degraded dimming performance.

## **1-Wire Interface**

EEPROM implementation uses a 1-Wire communication method. A 1-Wire net-based system consists of three main elements: a bus master with controlling software, the wiring and associated connectors, and 1-Wire devices. Data on

the 1-Wire net is transferred with respect to time slots. For example, the master pulls the bus low and holds it for 15μs or less to write a logic '1', and holds the bus low for at least 60μs to write a logic '0'. During EEPROM programming the MAX16816 is a 1-Wire slave device only. Data and clock signals are supplied through FAULT.

### **MAX16816 1-Wire Function Commands**

Table 10 shows the list of 1-Wire function commands for the MAX16816. Use these commands to start the programming mode, write to the on-chip EEPROM, and read EEPROM through the 1-Wire interface.

**PASS\_CODE\_ONE:** The PASS\_CODE\_ONE sequence is the first code that the MAX16816 must receive from the master. PASS\_CODE\_ONE must be received within the initial 8ms programming window after startup.

**PASS CODE TWO:** The PASS CODE TWO sequence is the second code that the MAX16816 must receive during the 8ms programming window. The MAX16816 will start searching for PASS\_CODE\_TWO only after PASS\_CODE\_ONE has been received.

**EXT\_EEM\_MODE:** The EXT\_EEM\_MODE command clears the PASS\_CODE\_ONE and PASS\_CODE\_TWO verification register. Use this command to exit programming mode.

**SET\_WRITE\_EE:** The SET\_WRITE\_EE command is the write all command for the MAX16816. When the device detects the SET\_WRITE\_EE command the write sequence begins. All EEPROM bits are copied to the EEPROM from the scratchpad with a single SET\_WRITE\_ EE command. This command also sets an internal BUSY flag to mask all other incoming signals.

**SET\_WRITE\_SCH:** The SET\_WRITE\_SCH command transfers data to the scratchpad. The 4 MSBs contain the register address and the 4 LSBs contain the data to be written. The internal BUSY flag is not set by this command. Table



## **Table 10. MAX16816 1-Wire Function Commands**

11 shows the MAX16816 EEPROM memory organization. Use the SET\_WRITE\_EE command to transfer data from the scratchpad to the EEPROM.

**SET READ SCH:** The SET READ SCH command is the command to read data in the scratch pad buffer. Once the MAX16816 receives the SET READ SCH command, data on the scratchpad register is shifted out. After 60 clock cycles, the MAX16816 completes the SET\_READ\_SCH sequence. The BUSY signal is not set by this command.

### **Programming**

To program the MAX16816 on-chip EEPROM with a pulldown device, directly connect FAULT to the DATA IN input of a microcontroller (μC). Also, connect FAULT to the DATA OUT output of a μC using an external switch (Figure 5). Connect the EN of the μC directly to UVEN to control the internal timer of the MAX16816 for programming purposes. Ensure that  $V_{CC}$  is greater than the UVLO threshold because both UVEN and FAULT are pulled up to 5V. See the *Electrical Characteristic* tables for details.

### **Programming Sequences**

The μC (master) starts the communication with the MAX16816 by pulling UVEN high. The MAX16816 then does the handshaking with the μC by pulling FAULT low. Once the μC receives the handshaking signal, it begins the initialization sequences to reset the 1-Wire interface. The sequence consists of a reset pulse from the μC followed by a presence pulse from the MAX16816. At this point the μC must send PASS\_CODE\_ONE and PASS\_

## **Table 11. MAX16816 Memory Map (Scratchpad)**



# MAX16816 **Programmable Switch-Mode LED Driver** with Analog-Controlled PWM Dimming

CODE TWO. These pass codes must be received by the MAX16816 within the 8ms programming slot to allow the MAX16816 to enter the EE programming mode.

### **1-Wire Signaling**

The MAX16816 requires strict protocols to ensure data integrity. The protocol consists of four types of signaling on one line: reset sequence with Reset Pulse and Presence Pulse, Write-Zero, Write-One, and Read-Data.



*Figure 5. Programming Through a FAULT Pin*

Except for the Presence Pulse, the bus master initiates all falling edges.

Externally pull  $\overline{FAULT}$  below  $V_{\vert L}$  to indicate a logic-input low. Release the pulldown device to indicate a logic-input high. The MAX16816 will pull  $\overline{FAULT}$  low below  $V_{\text{O}}$  to indicate a logic-output low. FAULT is pulled high with an internal 10kΩ resistor above V<sub>OH</sub> to indicate a logicoutput high.

### **Initialization Procedure (Reset and Presence Pulses)**

All 1-Wire communication with the MAX16816 begins with an initialization sequence that consists of a Reset Pulse from the master followed by a Presence Pulse from the MAX16816 (Figure 6). When the MAX16816 sends the Presence Pulse in response to the Reset Pulse, it is indicating to the master that it is ready to receive and transmit data.

During the initialization sequence, the bus master transmits the reset pulse by pulling the 1-Wire bus low for a minimum of 480μs. The bus master then releases the bus and goes into receive mode. When the bus is released, the pullup resistor pulls the 1-Wire bus high. When the MAX16816 detects this rising edge, it waits 15μs to 60μs and then transmits a Presence Pulse by pulling the 1-Wire bus low for 60μs to 240μs.

### **Read and Write Time Slots**

The bus master writes data to the MAX16816 during write time slots and reads data from the MAX16816 during read time slots. One bit of data is transmitted over the 1-Wire bus per time slot.



*Figure 6. 1-Wire Initialization Timing*

### **Write Time Slots**

There are two types of write time slots: Write-1 time slots and Write-0 time slots. The bus master uses a Write-1 time slot to write a logic '1' to the MAX16816 and a Write-0 time slot to write a logic '0'. All write time slots must be a minimum of 60μs in duration, with a minimum of a 1μs recovery time between individual Write slots. Both types of write time slots are initiated by the master pulling the 1-Wire bus low (Figures 7 and 8).

To generate a Write-1 time slot, the bus master must release the 1-Wire bus within 15μs after pulling the bus low. When the bus is released, the pullup resistor will pull the bus high. To generate a Write-0 time slot, the bus master must continue to hold the bus low for the duration of the time slot (at least 60μs) after pulling the 1-Wire bus low. The MAX16816 samples the 1-Wire bus during a window that lasts from 15μs to 60μs after the master initiates the Write time slot. If the bus is high during the samples window, a '1' is written to the MAX16816. If the line is low, a '0' is written to the MAX16816.



*Figure 7. 1-Wire Write-1 Time Slot*



*Figure 8. 1-Wire Write-0 Time Slot*

### **Read Time Slots**

The MAX16816 can only transmit data to the master when the master issues read time slots.

All read time slots must be a minimum of 60μs in duration with a minimum of a 1μs recovery time between slots. A read time slot is initiated by the master device pulling the 1-Wire bus low for a minimum of 1μs and then releasing it (Figure 9). After the master initiates the read time slot, the MAX16816 will transmit a '1' or a '0' on the bus. The

MAX16816 transmits a '1' by leaving the bus high and transmits a '0' by pulling the bus low. When transmitting a '0', the MAX16816 will release the bus before the end of the time slot, and the bus will be pulled back to its high idle state by the pullup resistor. Output data from the MAX16816 is valid for 15μs after the falling edge that initiated the read time slot. Therefore, the master must release the bus and then sample the bus state within 15μs from the start of the slot.



*Figure 9. 1-Wire Read Time Slot*



# **Typical Operating Circuits (continued)**



# **Typical Operating Circuits (continued)**



# **Pin Configuration**

## **Chip Information**

PROCESS: BiCMOS

## **Package Information**

For the latest package outline information and land patterns (footprints), go to **www.maximintegrated.com/packages**. Note that a "+", "#", or "-" in the package code indicates RoHS status only. Package drawings may show a different suffix character, but the drawing pertains to the package regardless of RoHS status.



# **Revision History**



For pricing, delivery, and ordering information, please contact Maxim Direct at 1-888-629-4642, or visit Maxim Integrated's website at www.maximintegrated.com.

*Maxim Integrated cannot assume responsibility for use of any circuitry other than circuitry entirely embodied in a Maxim Integrated product. No circuit patent licenses*  are implied. Maxim Integrated reserves the right to change the circuitry and specifications without notice at any time. The parametric values (min and max limits) *shown in the Electrical Characteristics table are guaranteed. Other parametric values quoted in this data sheet are provided for guidance.*