

**Hardware Documentation** 

# Data Sheet

# **HAC 830**

Robust Multi-Purpose Programmable Linear Hall-Effect Sensor with Integrated Capacitors

### **Copyright, Warranty, and Limitation of Liability**

The information and data contained in this document are believed to be accurate and reliable. The software and proprietary information contained therein may be protected by copyright, patent, trademark and/or other intellectual property rights of TDK-Micronas. All rights not expressly granted remain reserved by TDK-Micronas.

TDK-Micronas assumes no liability for errors and gives no warranty representation or guarantee regarding the suitability of its products for any particular purpose due to these specifications.

By this publication, TDK-Micronas does not assume responsibility for patent infringements or other rights of third parties which may result from its use. Commercial conditions, product availability and delivery are exclusively subject to the respective order confirmation.

Any information and data which may be provided in the document can and do vary in different applications, and actual performance may vary over time.

All operating parameters must be validated for each customer application by customers' technical experts. Any new issue of this document invalidates previous issues. TDK-Micronas reserves the right to review this document and to make changes to the document's content at any time without obligation to notify any person or entity of such revision or changes. For further advice please contact us directly.

Do not use our products in life-supporting systems, military, aviation, or aerospace applications! Unless explicitly agreed to otherwise in writing between the parties, TDK-Micronas' products are not designed, intended or authorized for use as components in systems intended for surgical implants into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the product could create a situation where personal injury or death could occur.

No part of this publication may be reproduced, photocopied, stored on a retrieval system or transmitted without the express written consent of TDK-Micronas.

### **TDK-Micronas Patents**

EP0 953 848, EP 1 039 357, EP 1 575 013

#### **Third-Party Trademarks**

All other brand and product names or company names may be trademarks of their respective companies.

#### **Contents**



# **[Robust Multi-Purpose Programmable Linear Hall-Effect Sensor with Integrated](#page--1-1) [Capacitors](#page--1-1)**

**Release Note: Revision bars indicate significant changes to the previous edition.**

# <span id="page-3-0"></span>**1. Introduction**

The HAC 830 is a programmable linear Hall sensor from TDK-Micronas. It offers optimal Electromagnetic Compatibility (EMC) protection as it integrates the HAL 830 robust multipurpose device as well as decoupling capacitors within a single 3-pin package.

With its integrated capacitors, the HAC 830 meets the stringent ESD and EMC requirements and eliminates the need for a PCB, thus reducing the total system size and cost.

The HAC 830 is a magnetic field sensor based on the Hall effect featuring a linear output. The integrated circuit (IC) can be used for angle or distance measurements when combined with a rotating or moving magnet. There is no need either to add a load capacitor between ground and the analog output or any blocking capacitor to suppress noise on the supply line of the device.

The major characteristics like magnetic field range, sensitivity, output quiescent voltage (output voltage at  $B = 0$  mT), and output voltage range are programmable in a non-volatile memory. The sensors have a ratiometric output characteristic, which means that the output voltage is proportional to the magnetic flux and the supply voltage.

The HAC 830 features a temperature-compensated Hall plate with spinning-current offset compensation, an A/D converter, digital signal processing, a D/A converter with output driver, an EEPROM memory with redundancy and lock function for the calibration data, an EEPROM for customer serial number, a serial interface for programming the EEPROM, protection devices at all pins and decoupling capacitors.

The HAC 830 is programmable by modulating the supply voltage. No additional programming pin is needed. The easy programmability allows a 2-point calibration by adjusting the output voltage directly to the input signal (like mechanical angle, distance, or current). Individual adjustment of each sensor during the customer's manufacturing process is possible. With this calibration procedure, the tolerances of the sensor, the magnet, and the mechanical positioning can be compensated in the final assembly. It is possible to program several devices connected to the same supply and ground line.

In addition, the temperature compensation of the Hall IC can be fit to common magnetic materials by programming first- and second-order temperature coefficients of the Hall sensor sensitivity. This enables operation over the full temperature range with high accuracy.

The calculation of the individual sensor characteristics and the programming of the EEPROM memory can easily be done with a PC and the application kit from TDK-Micronas.

The sensor is designed for hostile industrial and automotive applications and is AECQ100 qualified. It operates with typically 5 V supply voltage in the ambient temperature range from  $-40$  °C up to 150 °C. It is available in the very small 3-pin package TO92UP-2.

# <span id="page-4-0"></span>**1.1. General Features**

- High-precision linear Hall-effect sensor with 12 bit ratiometric analog output and digital signal processing
- Multiple programmable magnetic characteristics in a non-volatile memory (EEPROM) with redundancy and lock function
- Integrated capacitors for improved Electromagnetic Compatibility (EMC) and PCB-less applications
- Operates from  $-40$  °C up to 150 °C ambient temperature
- Operates from 4.5 V up to 5.5 V supply voltage in specification and functions up to 8.5 V
- Operates with static magnetic fields and dynamic magnetic fields up to 2 kHz
- Programmable magnetic field range from  $\pm 30$  mT up to  $\pm 150$  mT
- Open-circuit (ground and supply line break detection) with 5 k $\Omega$  pull-up and pull-down resistor, overvoltage and undervoltage detection
- For programming an individual sensor within several sensors in parallel to the same supply voltage, a selection can be done via the output pin
- Temperature characteristics are programmable for matching common magnetic materials
- Programmable clamping function
- Programming via modulation of the supply voltage
- Overvoltage- and reverse-voltage protection at all pins
- Magnetic characteristics extremely robust against mechanical stress
- Short-circuit protected push-pull output
- EMC and ESD optimized design

# <span id="page-4-1"></span>**1.2. Applications**

Due to the sensor's versatile programming characteristics and low temperature drift, the HAC 830 is the optimal system solution for PCB-less applications such as:

- Pedal, turbo-charger, throttle and EGR systems
- Distance measurements

# <span id="page-5-0"></span>**2. Ordering Information**

A Micronas device is available in a variety of delivery forms. They are distinguished by a specific ordering code:



#### <span id="page-5-2"></span>**Fig. 2–1:** Ordering Code Principle

For a detailed information, please refer to the brochure: "Micronas Sensors and Controllers: Ordering Codes, Packaging, Handling".

# <span id="page-5-1"></span>**2.1. Device-Specific Ordering Codes**

The HAC 830 is available in the following package, capacitor, and temperature variants.

#### **Table 2–1:** Available packages



Values of the capacitors from VSUP to GND and OUT to GND are uniquely identified by a letter added within the Hall sensor package code, according to the description in [Fig. 2–1](#page-5-2).

#### <span id="page-5-3"></span>**Table 2–2:** Available capacitor configurations



#### **Table 2–3:** Available temperature ranges



The relationship between ambient temperature  $(\mathsf{T}_\mathsf{A})$  and junction temperature  $(\mathsf{T}_\mathsf{J})$  is explained in [Section 5.4. on page 37.](#page-36-2)

For available variants for Configuration (C), Packaging (P), Quantity (Q), and Special Procedure (SP) please contact TDK-Micronas.

**Table 2–4:** Available ordering codes and corresponding package marking



# <span id="page-7-0"></span>**3. Functional Description**

# <span id="page-7-1"></span>**3.1. General Function**

The HAC 830 programmable linear Hall-effect sensor provides an output signal proportional to the magnetic flux through the Hall plate and proportional to the supply voltage (ratiometric behavior) as long as the analog output mode is selected.

The external magnetic field component perpendicular to the branded side of the package generates a Hall voltage. The Hall ICs are sensitive to magnetic north and south polarity. The Hall voltage is converted to a digital value, processed in the Digital Signal Processing Unit (DSP) according to the settings of the EEPROM registers, converted to an output signal. The function and parameters for the DSP are explained in [Section 3.2.](#page-10-0) [on page 11](#page-10-0).

The setting of the LOCK register disables the programming of the EEPROM memory for all time. It also disables the reading of the memory. This register cannot be reset.

As long as the LOCK register is not set, the output characteristic can be adjusted by programming the EEPROM registers. The IC is addressed by modulating the supply voltage [\(see Fig. 3–1\)](#page-8-0). In the supply voltage range from 4.5 V up to 5.5 V, the sensor generates a normal output signal. After detecting a command, the sensor reads or writes the memory and answers with a digital signal on the output pin (see also application note "HAL 8xy, HAL 100x Programmer Board"). The output switches from analog to digital during the communication. Several sensors in parallel to the same supply and ground line can be programmed individually. The selection of each sensor is done via its output pin.

The open-circuit detection function provides a defined output voltage for the analog output if the VSUP or GND lines are broken. Internal temperature compensation circuitry and spinning-current offset compensation enable operation over the full temperature range with minimal changes in accuracy and high offset stability. The circuitry also reduces offset shifts due to mechanical stress from the package. The non-volatile memory consists of redundant and non-redundant EEPROM cells. The non-redundant EEPROM cells are only used to store production information for tracking inside the sensor. In addition, the sensor IC is equipped with devices for overvoltage and reverse-voltage protection at all pins.

To improve EMC performance HAC 830 devices integrate two capacitors within the package, between VSUP and GND and OUT and GND respectively.



<span id="page-8-0"></span>Fig. 3-1: Programming with V<sub>SUP</sub> modulation



**Fig. 3–2:** HAC 830 block diagram



<span id="page-9-0"></span>**Fig. 3–3:** Details of EEPROM registers and digital signal processing

# <span id="page-10-1"></span><span id="page-10-0"></span>**3.2. A/D Converter**

The ADC used in HAC 830 sensor has a "Sigma-Delta" architecture. It delivers an oversampled multi-bit stream with high-frequency shaped quantization noise. Low-pass filtering performs an averaging of the signal by accumulation. With longer accumulation the resolution of the data converter increases.

The accumulation takes place in the decimating filter, the low-pass filter, and the external RC-filter.



### **Fig. 3–4:** Signal path

Example of a Sigma-Delta-ADC (simplified illustration)



#### **Fig. 3–5:** Sigma-Delta-ADC

- A: Input Signal
- B: Integrated value
- C: High frequency data stream (modulated)

After filtering (D), the signal is reconstructed: the lower the cutoff frequency of this filter the higher is the resolution.

The A/D readout of the sensor is a snapshot of the explained data stream.

# <span id="page-11-0"></span>**3.3. Digital Signal Processing and EEPROM**

The DSP performs signal conditioning and allows adaption of the sensor to the customer application. The parameters for the DSP are stored in the EEPROM registers. The details are shown in [Fig. 3–3.](#page-9-0)

### **Terminology:**

SENSITIVITY: name of the register or register value

Sensitivity: name of the parameter

The EEPROM registers consist of four groups:

Group 1 contains the registers for the adaptation of the sensor to the magnetic system: MODE for selecting the magnetic field range and filter frequency, TC, TCSQ and TC-Range for the temperature characteristics of the magnetic sensitivity.

Group 2 contains the registers for defining the output characteristics: SENSITIVITY, VOQ, CLAMP-LOW (MIN-OUT), CLAMP-HIGH (MAX-OUT) and OUTPUT MODE. The output characteristic of the sensor is defined by these parameters.

- The parameter  $V_{OO}$  (Output Quiescent Voltage) corresponds to the output signal at  $B = 0$  mT
- The parameter Sensitivity defines the magnetic sensitivity:

$$
Sensitivity = \frac{\Delta V_{OUT}}{\Delta B}
$$

– The output voltage can be calculated as:

$$
V_{OUT} \sim Sensitivity \times B + V_{OO}
$$

The output voltage range can be clamped by setting the registers CLAMP-LOW and CLAMP-HIGH in order to enable failure detection (such as short-circuits to VSUP or GND and open connections).

Group 3 contains the general purpose register GP. The GP Register can be used to store customer information, like a serial number after manufacturing. TDK-Micronas will use this GP REGISTER to store informations like, lot number, wafer number, x and y position of the die on the wafer, etc. This information can be read by the customer and stored in its own data base or it can stay in the sensor as is.

Group 4 contains the MICRONAS registers and LOCK for the locking of all registers. The MICRONAS registers are programmed and locked during production. These registers are used for oscillator frequency trimming, A/D converter offset compensation, and several other special settings.

An external magnetic field generates a Hall voltage on the Hall plate. The ADC converts the amplified positive or negative Hall voltage (operates with magnetic north and south poles at the branded side of the package) to a digital value. This value can be read by the A/D-READOUT register to ensure that the suitable converter modulation is achieved. The digital signal is filtered in the internal low-pass filter and manipulated according to the settings stored in the EEPROM. The digital value after signal processing is readable in the D/A-READOUT register. The operating range of the A/D converter is from  $\pm 30$  mT up to  $\pm 150$  mT.

During further processing, the digital signal is multiplied with the sensitivity factor, added to the quiescent output voltage level and limited according to the clamping voltage levels. The result is converted to an analog signal and stabilized by a push-pull output stage transistor stage.

The D/A-READOUT at any given magnetic field depends on the programmed magnetic **field range, the low-pass filter, Sensitivity, VOQ, TC, Clamp-Low, and Clamp-High values.** The D/A-READOUT range is min. 0 and max. 16383.

**Note** During application design, it should be taken into consideration that the maximum and minimum D/A-READOUT should not violate the error band of the operational range.

### **MODE register**

The MODE register contains all bits used to configure the A/D converter and the different output modes.

#### **Table 3–1:** MODE register of HAC 830



#### **Magnetic Range**

The RANGE bits define the magnetic field range of the A/D converter.

#### <span id="page-13-0"></span>**Table 3–2:** Magnetic Range HAC 830



#### **Filter**

The FILTER bits define the  $-3$  dB frequency of the digital low pass filter.

#### Table 3-3: FILTER bits defining the -3 dB frequency



# **Output Format**

The OUTPUTMODE bits define the different output modes of HAC 830.

#### **Table 3–4:** OUTPUTMODE for HAC 830



In **Analog Output** mode the sensor provides a ratiometric 12 bit analog output voltage between 0 V and 5 V.

### **TC Register**

The temperature dependence of the magnetic sensitivity can be adapted to different magnetic materials in order to compensate for the change of the magnetic strength with temperature. The adaptation is done by programming the TC (Temperature Coefficient) and the TCSQ registers (Quadratic Temperature Coefficient). Thereby, the slope and the curvature of the temperature dependence of the magnetic sensitivity can be matched to the magnet and the sensor assembly. As a result, the output voltage characteristic can be constant over the full temperature range. The sensor can compensate for linear temperature coefficients ranging from about -3100 ppm/K up to 1000 ppm/K and quadratic coefficients from about -7 ppm/K² to 2 ppm/K².

The full TC range is separated in the following four TC range groups (see [Table 3–5](#page-14-0) and [Table 5–1 on page 35\)](#page-34-1).



#### <span id="page-14-0"></span>**Table 3–5:** TC-Range Groups

TC (5 bit) and TCSQ (3 bit) have to be selected individually within each of the four ranges. For example 0 ppm/k requires  $TC$ -Range = 1,  $TC$  = 15 and  $TCSQ$  = 1. Please refer to [Section 5.3.](#page-34-2) for more details.

# **Sensitivity**

The SENSITIVITY register contains the parameter for the multiplier in the DSP. The Sensitivity is programmable between -4 and 4. For  $V_{SUP} = 5 V$ , the register can be changed in steps of 0.00049.

For all calculations, the digital value from the magnetic field of the D/A converter is used. This digital information is readable from the D/A-READOUT register.

SENSITIVITY =  $\frac{\Delta V_{\text{OUT}} \times 16383}{(4 \Delta V_{\text{A}} \text{PE} \text{ADOLIT})}$  $=\frac{\Delta V_{\text{OUT}} \times 10363}{(\Delta D/A-READOUT \times V_{DD})} \times \text{Sens}_{\text{INITIAL}}$ 

# **VOQ**

The VOQ register contains the parameter for the adder in the DSP.  $V_{\Omega}$  is the output signal without external magnetic field ( $B = 0$  mT) and programmable from  $-V_{SUP}$  (-100% duty-cycle) up to  $V_{SIIP}$  (100% duty-cycle). For  $V_{SUP} = 5 V$ , the register can be changed in steps of 4.9 mV (0.05% duty-cycle).

**Note:** If  $V_{\text{OO}}$  is programmed to a negative value, the maximum output signal is limited to:

 $V_{\text{OUTmax}} = V_{\text{OO}} + V_{\text{SUP}}$ 

### **Clamping Levels**

The output signal range can be clamped in order to detect failures like shorts to  $V_{SUP}$  or GND or an open circuit.

The CLAMP-LOW register contains the parameter for the lower limit. The lower clamping limit is programmable between 0 V (min. duty-cycle) and  $V_{\text{SUP}}/2$  (50% duty-cycle). For  $V_{\text{SUP}} = 5$  V, the register can be changed in steps of 9.77 mV (0.195% duty-cycle).

The CLAMP-HIGH register contains the parameter for the upper limit. The upper clamping voltage is programmable between 0 V (min. duty-cycle) and  $V_{\text{SUP}}$  (max. duty-cycle). For  $V_{\text{SUP}} = 5$  V, in steps of 9.77 mV (0.195% duty-cycle).

### **GP Register**

The registers GP0 to GP3 can be used to store some information, like production date or customer serial number. TDK-Micronas will store production lot number, wafer number and x,y coordinates in registers GP1 to GP3. The total register contains of four blocks with a length of 13 bit each. The customer can read out this information and store it in his production data base for reference or he can store own production information instead.

**Note** This register is not a guarantee for traceability.

To read/write this register it is mandatory to read/write all GP register one after the other starting with GP0. In case of writing the registers it is necessary to first write all registers followed by one store sequence at the end. Even if only GP0 should be changed all other GP registers must first be read and the read out data must be written again to these registers.

# **LOCK**

By setting the 1-bit register all registers will be locked, and the sensor will no longer respond to any supply voltage modulation. This bit is active after the first power-off and power-on sequence after setting the LOCK bit. EMC properties of the HAC 830 are only guaranteed for locked devices.

### **Warning This register cannot be reset!**

### **D/A-READOUT**

This 14-bit register delivers the actual digital value of the applied magnetic field after the signal processing. This register can be read out and is the basis for the calibration procedure of the sensor in the system environment.

**Note** The MSB and LSB are reversed compared to all the other registers. Please reverse this register after readout.

# <span id="page-17-0"></span>**3.4. Calibration Procedure**

### <span id="page-17-2"></span><span id="page-17-1"></span>**3.4.1. General Procedure**

For calibration in the system environment, the application kit from TDK-Micronas is recommended. It contains the hardware for generation of the serial telegram for programming (Programmer Board Version 5.1) and the corresponding software (PC83x) for the input of the register values.

For the individual calibration of each sensor in the customer application, a two point adjustment is recommended. The calibration shall be done as follows:

### **Step 1: Input of the registers which are not required to be adjusted individually**

The magnetic circuit, the magnetic material with its temperature characteristics, the filter frequency, the output mode and the GP Register value are given for this application. Therefore, the values of the following registers should be identical for all sensors of the customer application.

– FILTER

(according to the maximum signal frequency)

- RANGE (according to the maximum magnetic field at the sensor position)
- OUTPUTMODE
- TC, TCSQ and TC-RANGE

(depends on the material of the magnet and the other temperature dependencies of the application)

– GP

(if the customer wants to store own production information. It is not necessary to change this register)

As the clamping levels are given. They have an influence on the D/A-Readout value and have to be set therefore after the adjustment process.

Write the appropriate settings into the HAC 830 registers.

# **Step 2: Initialize DSP**

As the D/A-READOUT register value depends on the settings of SENSITIVITY, VOQ and CLAMP-LOW/HIGH, these registers have to be initialized with defined values, first:

- $-VOO<sub>INITIAL</sub> = 2.5 V$
- $-$  Clamp-Low = 0 V
- $-$  Clamp-High = 4.999 V
- $-$  Sens<sub>INITIAI</sub> [\(see Table 3–6\)](#page-18-0)

#### <span id="page-18-1"></span><span id="page-18-0"></span>**Table 3-6: SensINITIAL**



### **Step 3: Define Calibration Points**

The calibration points 1 and 2 can be set inside the specified range. The corresponding values for  $V_{\text{OUT1}}$  and  $V_{\text{OUT2}}$  result from the application requirements.

```
Lowclampingvoltage \leq V_{OUT12} \leq Highclampingvoltage
```
For highest accuracy of the sensor, calibration points near the minimum and maximum input signal are recommended. The difference of the output voltage between calibration point 1 and calibration point 2 should be more than 3.5 V.

# **Step 4: Calculation of V<sub>OQ</sub> and Sensitivity**

Set the system to calibration point 1 and read the register D/A-READOUT. The result is the value D/A-READOUT1.

Now, set the system to calibration point 2, read the register D/A-READOUT again, and get the value D/A-READOUT2.

With these values and the target values  $V_{\text{OUT1}}$  and  $V_{\text{OUT2}}$ , for the calibration points 1 and 2, respectively, the values for Sensitivity and  $V_{\Omega\Omega}$  are calculated as:

Sensitivity = Sens<sub>INITIAL</sub>  $(Vout2 - Vout1)$  $\frac{\text{(Vout2 - Vout1)}}{\text{(D/A-Readout2 - D/A-Readout1)}} \times \frac{16383}{5}$ 5  $=$  Sens<sub>INITIAL</sub>  $\times$   $\frac{(V\text{out2}-V\text{out1})}{(V\text{out2}-V\text{out1})} \times \frac{16383}{5}$ 

$$
Voq = Vout2 - \left[ \left( \frac{5 \times D/A - Readout2}{16383} - VoqINITIAL \right) \times \frac{Sensitivity}{SensitivityINITIAL} \right]
$$

This calculation has to be done individually for each sensor.

Next, write the calculated values for Sensitivity and  $V_{OO}$  into the IC for adjusting the sensor. At that time it is also possible to store the application specific values for Clamp-Low and Clamp-High into the sensor's EEPROM. The sensor is now calibrated for the customer application. However, the programming can be changed again and again if necessary.

**Note** For a recalibration, the calibration procedure has to be started at the beginning (step 1). A new initialization is necessary, as the initial values from step 1 are overwritten in step 4.

### **Step 5: Locking the Sensor**

The last step is activating the LOCK function by programming the LOCK bit. Please note that the LOCK function becomes effective after power-down and power-up of the Hall IC. The sensor is now locked and does not respond to any programming or reading commands.

**Note** It is mandatory to lock the sensor.

#### **Warning This register can not be reset!**

# <span id="page-20-1"></span><span id="page-20-0"></span>**4. Specifications 4.1. Outline Dimensions**



c Copyright 2016 Micronas GmbH, all rights reserved

#### <span id="page-20-2"></span>**Fig. 4–1: TO92UP-2**: Plastic Transistor Standard UP package, 4 leads Weight approximately 0.212 g



#### **Fig. 4–2: TO92UP-2**: Dimensions ammopack inline, not spread

# <span id="page-22-0"></span>**4.2. Soldering, Welding and Assembly**

**Note** TDK-Micronas recommends to weld the HAC 830 using resistance or laser beam welding. Reflow soldering is not permitted. Contact your TDK-Micronas sales representative for more information.

Further information related to solderability, welding, assembly, and second-level packaging is included in the document "Guidelines for the Assembly of Micronas Packages". It is available on the TDK-Micronas website [\(http://www.micronas.com/en/service-cen](http://www.micronas.com/en/service-center/downloads)[ter/download](http://www.micronas.com/en/service-center/downloads)s) or on the service portal ([http://service.micronas.com\)](http://service.micronas.com).

# <span id="page-22-1"></span>**4.3. Pin Connections and Short Descriptions**



#### **Table 4–1:** Pin Connection



**Fig. 4–1:** Pin configuration

# <span id="page-22-2"></span>**4.4. Dimension of Sensitive Area**



See [Fig. 4–1 on page 21](#page-20-2) for more information on the Hall plate position.

# <span id="page-23-0"></span>**4.5. Absolute Maximum Ratings**

Stresses beyond those listed in the "Absolute Maximum Ratings" may cause permanent damage to the device. This is a stress rating only. Functional operation of the device at these conditions is not implied. Exposure to absolute maximum rating conditions for extended periods will affect device reliability.

This device contains circuitry to protect the inputs and outputs against damage due to high static voltages or electric fields; however, it is advised that normal precautions be taken to avoid application of any voltage higher than absolute maximum-rated voltages to this circuit.

<span id="page-23-1"></span>All voltages listed are referenced to ground (GND).



#### **Table 4–2:** Absolute Maximum Ratings

 $^{2)}$  For 96 h - Please contact TDK-Micronas for other temperature requirements

3) No cumulated stress

 $^{4)}$  As long as  ${\sf T}_{\sf J}$  is not exceeded

# <span id="page-24-0"></span>**4.6. Storage and Shelf Life**

Information related to storage conditions of TDK-Micronas sensors is included in the document "Guidelines for the Assembly of Micronas Packages". It gives recommendations linked to moisture sensitivity level and long-term storage.

It is available on the TDK-Micronas website [\(http://www.micronas.com/en/service-center/](http://www.micronas.com/en/service-center/downloads) [download](http://www.micronas.com/en/service-center/downloads)s) or on the service portal [\(http://service.micronas.com\)](http://service.micronas.com).

# <span id="page-24-1"></span>**4.7. Recommended Operating Conditions**

Functional operation of the device beyond those indicated in the "Recommended Operating Conditions/Characteristics" is not implied and may result in unpredictable behavior, reduce reliability and lifetime of the device.

All voltages listed are referenced to ground (GND).



#### **Table 4–3:** Recommended Operating Conditions

# <span id="page-25-0"></span>**4.8. Characteristics**

at  $T_J = -40$  °C to 170 °C,  $V_{SUP} = 4.5$  V to 5.5 V, GND = 0 V after programming and locking, at Recommended Operation Conditions if not otherwise specified in the column "Conditions". Typical Characteristics for T<sub>J</sub> = 25 °C and V<sub>SUP</sub> = 5 V.

#### <span id="page-25-1"></span>**Table 4–4:** Characteristics



#### **Table 4–4:** Characteristics, continued



2) Characterized on small sample size, not tested.

3) Output DAC full scale = 5 V ratiometric, Output DAC offset = 0 V, Output DAC LSB =  $V_{\text{SUP}}/4096$ 

<sup>4)</sup> Only tested at 25 °C. The specified values are test limits only. Overmolding and packaging might influence this parameter  $5)$  T<sub>ambient</sub> = 150 °C

# <span id="page-26-1"></span><span id="page-26-0"></span>**4.8.1. Additional Information**

#### **Table 4–5:** Additional Information



<sup>1)</sup> Guaranteed by design

 $\blacksquare$ 

Ī

<sup>2)</sup> Signal Band Area with full accuracy is located between  $V_{\text{OUTL}}$  and  $V_{\text{OUTH}}$ . The sensor accuracy is reduced below  $V_{\text{OUTL}}$  and above  $V_{\text{OUTH}}$ 

 $3)$  The energy of the impulse injected into the analog output when the code in the D/A-Converter register changes state. This energy is normally specified as the area of the glitch in nVs

4) Characterized on small sample size, not tested.

# <span id="page-27-0"></span>**4.8.2. TO92UP Packages**

#### **Table 4–6:** TO92UP Packages



# <span id="page-27-1"></span>**4.8.3. Definition of Sensitivity Error ES**

ES is the maximum of the absolute value of the quotient of the normalized measured value<sup>1</sup> over the normalized ideal linear<sup>2</sup> value minus 1:

 $ES = max(abs(\frac{meas}{ideal} - 1))$ {, } *Tmin Tmax* =

In the example below, the maximum error occurs at  $-10$  °C:

 $ES = \frac{1.001}{0.993} - 1 = 0.8\%$ 

<sup>1.</sup> Normalized to achieve a least-squares method straight line that has a value of 1 at 25 °C.

<sup>2.</sup> Normalized to achieve a value of 1 at 25 °C.



**Fig. 4–1:** ES definition example

# <span id="page-29-0"></span>**4.8.4. Power-On Operation**

at  $T_J = -40$  °C to 170 °C, after programming and locking. Typical Characteristics for T $_{\textrm{J}}$  = 25 °C.

#### **Table 4–7:** Power-On Operation







# <span id="page-30-0"></span>**4.9. Diagnostics and Safety Features**

### <span id="page-30-1"></span>**4.9.1. Overvoltage and Undervoltage Detection**

at T $_{\textrm{J}}$  = –40 °C to 170 °C, Typical Characteristics for T $_{\textrm{J}}$  = 25 °C, after programming and locking

#### **Table 4–8:** Over-/Undervoltage Detection



# **Note The over- and undervoltage detection is activated only after locking the sensor!**

### <span id="page-30-2"></span>**4.9.2. Open-Circuit Detection**

at T $_{\textrm{J}}$  = –40 °C to 170 °C, Typical Characteristics for T $_{\textrm{J}}$  = 25 °C, after locking the sensor

#### **Table 4–9:** Open-Circuit Detection



### <span id="page-31-0"></span>**4.9.3. Over temperature and Short-Circuit Protection**

If over temperature at  $T$ <sub>J</sub>>180 °C, e.g. due to a short circuit, the output will be switched off and goes in high impedance condition.

#### <span id="page-31-1"></span>**4.9.4. EEPROM Redundancy**

The non-volatile memory except the GP registers uses the Micronas Fail Safe Redundant Cell technology well proven in automotive applications.

### <span id="page-31-2"></span>**4.9.5. ADC Diagnostic**

The A/D-READOUT register can be used to avoid under/overrange effects in the A/D converter.

# <span id="page-32-0"></span>**5. Application Notes**

# <span id="page-32-1"></span>**5.1. Application Circuit**

Thanks to the integrated capacitors, it is not necessary to connect additional capacitors between ground and the supply voltage or the output voltage pin.

Built-in capacitors are monolithic ceramic capacitors with X8R characteristics. They are specifically suited for high temperature applications with stable capacitance value  $(\pm 10\%)$  up to 150 °C, and therefore suitable for harsh automotive operating conditions. The maximum rated capacitor voltage is  $\geq$ 25 V.



**Fig. 5–1:** Recommended application circuit (analog output signal), no additional capacitors needed

# <span id="page-33-0"></span>**5.2. Use of two HAC 830 in Parallel**

Two different HAC 830 sensors which are operated in parallel to the same supply and ground line can be programmed individually. In order to select the IC which should be programmed, both Hall ICs are inactivated by the "Deactivate" command on the common supply line. Then, the appropriate IC is activated by an "Activate" pulse on its output. Only the activated sensor will react to all following read, write, and program commands. If the second IC has to be programmed, the "Deactivate" command is sent again, and the second IC can be selected.

**Note** The multi-programming of two sensors requires a 10 k $\Omega$  pull-down resistor on the sensors' output pins.



**Fig. 5–2:** Recommended application circuit (parallel operation of two HAC 830), no additional capacitors needed

# <span id="page-34-2"></span><span id="page-34-0"></span>**5.3. Temperature Compensation**

The relationship between the temperature coefficient of the magnet and the corresponding TC, TCSQ and TC-Range codes for linear compensation is given in the following table. In addition to the linear change of the magnetic field with temperature, the curvature can be adjusted as well. For this purpose, other TC, TCSQ and TC-Range combinations are required which are not shown in the table. Please contact TDK-Micronas for more detailed information on this higher order temperature compensation.

#### <span id="page-34-3"></span><span id="page-34-1"></span>**Table 5–1:** Temperature compensation codes



#### **Table 5–1:** Temperature compensation codes, continued



**Note** [Table 5–1](#page-34-3) shows only some approximate values. TDK-Micronas recommends to use the TC-Calc software to find optimal settings for temperature coefficients. Please contact TDK-Micronas for more detailed information.

# <span id="page-36-2"></span><span id="page-36-0"></span>**5.4. Ambient Temperature**

Due to the internal power dissipation, the temperature on the silicon chip (junction temperature T $_{\textrm{\scriptsize{J}}}$ ) is higher than the temperature outside the package (ambient temperature  $T_A$ ).

 $T_J = T_A + \Delta T$ 

At static conditions and continuous operation, the following equation applies:

 $\Delta T = I_{\text{SUP}} * V_{\text{SUP}} * R_{\text{thiX}}$ 

The X represents junction-to-air or junction-to-case.

In order to estimate the temperature difference  $\Delta T$  between the junction and the respective reference (e.g. air, case, or solder point) use the max. parameters for  $I_{SUP}$ ,  $R_{thX}$ , and the max. value for  $V_{\text{SUP}}$  from the application.

The following example shows the result for junction-to -air conditions.  $V_{\text{SUP}} = 5.5 V$ ,  $R<sub>thia</sub> = 250$  K/W and  $I<sub>SUP</sub> = 10$  mA the temperature difference  $\Delta T = 13.75$  K.

The junction temperature  ${\sf T}_{\sf J}$  is specified. The maximum ambient temperature  ${\sf T}_{\sf Amax}$  can be estimated as:

 $T_{\text{Amax}} = T_{\text{Imax}} - \Delta T$ 

# <span id="page-36-1"></span>**5.5. EMC and ESD**

Please contact TDK-Micronas for the detailed investigation reports with the EMC and ESD results.

**Note** EMC results are valid for locked devices only.

# <span id="page-37-0"></span>**6. Programming**

# <span id="page-37-1"></span>**6.1. Definition of Programming Pulses**

The sensor is addressed by modulating a serial telegram on the supply voltage. The sensor answers with a serial telegram on the output pin.

The bits in the serial telegram have a different bit time for the VSUP-line and the output. The bit time for the VSUP-line is defined through the length of the Sync Bit at the beginning of each telegram. The bit time for the output is defined through the Acknowledge Bit.

A logical "0" is coded as no voltage change within the bit time. A logical "1" is coded as a voltage change between 50% and 80% of the bit time. After each bit, a voltage change occurs.

# <span id="page-37-2"></span>**6.2. Definition of the Telegram**

Each telegram starts with the Sync Bit (logical 0), 3 bits for the Command (COM), the Command Parity Bit (CP), 4 bits for the Address (ADR), and the Address Parity Bit (AP).

There are 4 kinds of telegrams:

– Write a register [\(see Fig. \)](#page-38-0)

After the AP Bit, follow 14 Data Bits (DAT) and the Data Parity Bit (DP). If the telegram is valid and the command has been processed, the sensor answers with an Acknowledge Bit (logical 0) on the output.

- Read a register [\(see Fig. 6–3\)](#page-39-0) After evaluating this command, the sensor answers with the Acknowledge Bit, 14 Data Bits, and the Data Parity Bit on the output.
- Programming the EEPROM cells [\(see Fig. 6–4\)](#page-39-1) After evaluating this command, the sensor answers with the Acknowledge Bit. After the delay time  $t_{w}$ , the supply voltage rises up to the programming voltage.
- Activate a sensor [\(see Fig. 6–4\)](#page-39-1) If more than one sensor is connected to the supply line, selection can be done by first deactivating all sensors. The output of all sensors have to be pulled to ground. With an Activate pulse on the appropriate output pin, an individual sensor can be selected. All following commands will only be accepted from the activated sensor.



## <span id="page-38-1"></span><span id="page-38-0"></span>**Fig. 6–1:** Definition of logical 0 and 1 bit

# **Table 6–1:** Telegram parameters







#### **READ**



#### <span id="page-39-0"></span>**Fig. 6–3:** Telegram for coding a Read command



#### <span id="page-39-1"></span>**Fig. 6–4:** Telegram for coding the EEPROM programming





# <span id="page-40-0"></span>**6.3. Telegram Codes**

### **Sync Bit**

Each telegram starts with the Sync Bit. This logical "0" pulse defines the exact timing for  $t_{p0}$ .

### **Command Bits (COM)**

The Command code contains 3 bits and is a binary number. [Table 6–2](#page-41-1) shows the available commands and the corresponding codes for the HAC 830.

### **Command Parity Bit (CP)**

This parity bit is "1" if the number of zeros within the 3 Command Bits is uneven. The parity bit is "0", if the number of zeros is even.

### **Address Bits (ADR)**

The Address code contains 4 bits and is a binary number. [Table 6–3](#page-44-0) shows the available addresses for the HAC 830 registers.

### **Address Parity Bit (AP)**

This parity bit is "1" if the number of zeros within the 4 Address bits is uneven. The parity bit is "0" if the number of zeros is even.

### **Data Bits (DAT)**

The 14 Data Bits contain the register information.

The registers use different number formats for the Data Bits. These formats are explained in [Section 6.4.](#page-41-0)

In the Write command, the last bits are valid. If, for example, the TC register (10 bits) is written, only the last 10 bits are valid.

In the Read command, the first bits are valid. If, for example, the TC register (10 bits) is read, only the first 10 bits are valid.

### **Data Parity Bit (DP)**

This parity bit is "1" if the number of zeros within the binary number is even. The parity bit is "0" if the number of zeros is uneven.

# **Acknowledge**

After each telegram, the output answers with the Acknowledge signal. This logical "0" pulse defines the exact timing for  $t_{pOUT}$ .

#### <span id="page-41-1"></span>**Table 6–2:** Available commands



# <span id="page-41-0"></span>**6.4. Number Formats**

#### **Binary number:**

The most significant bit is given as first, the least significant bit as last digit.

Example: 101001 represents 41 decimal.

### **Signed binary number:**

The first digit represents the sign of the following binary number (1 for negative, 0 for positive sign).

Example: 0101001 represents +41 decimal 1101001 represents 41 decimal

#### **Two's-complement number:**

The first digit of positive numbers is "0", the rest of the number is a binary number. Negative numbers start with "1". In order to calculate the absolute value of the number, calculate the complement of the remaining digits and add "1".

Example: 0101001 represents +41 decimal 1010111 represents 41 decimal

# <span id="page-42-0"></span>**6.5. Register Information**

### **CLAMP-LOW**

- The register range is from 0 up to 255.
- The register value is calculated by:

$$
CLAMP-LOW = \frac{LowClampingVoltage \times 2}{V_{SUP}} \times 255
$$

# **CLAMP-HIGH**

- The register range is from 0 up to 511.
- The register value is calculated by:

$$
CLAMP-HIGH = \frac{HighClampingVoltage}{V_{SUP}} \times 511
$$

# **VOQ**

- $-$  The register range is from  $-1024$  up to 1023.
- The register value is calculated by:

$$
VOQ = \frac{V_{OO}}{V_{SUP}} \times 1024
$$

# **SENSITIVITY**

- $-$  The register range is from  $-8192$  up to 8191.
- The register value is calculated by:

 $SENSITIVITY = Sensitivity \times 2048$ 

# **TC**

- The TC register range is from 0 up to 1023.
- The register value is calculated by:

$$
TC = GROUP \times 256 + TCValue \times 8 + TCSQValue
$$

### **MODE**

– The register range is from 0 up to 1023 and contains the settings for FILTER, RANGE, OUTPUTMODE:

 $MODE = RANGE (Mode [9]) \times 512$ *OUTPUTMODE* +  $\frac{1}{2}$   $\frac{1}{32}$  +  $FILTER \times 8 + RANGE (Mode [2:1]) \times 2$ =

# **D/A-READOUT**

- This register is read only.
- The register range is from 0 up to 16383.

# **DEACTIVATE**

- This register can only be written.
- The register has to be written with 2063 decimal (80F hexadecimal) for the deactivation.
- The sensor can be reset with an activate pulse on the output pin or by switching off and on the supply voltage.



#### <span id="page-44-0"></span>**Table 6–3:** Available register addresses

 $1)$  To read/write this register it is mandatory to read/write all GP register one after the other starting with GP0. In case of a writing the registers it is necessary to first write all registers followed by one store sequence at the end. Even if only GP0 should be changed all other GP registers must first be read and the read out data must be written again to these registers.

I

# <span id="page-45-0"></span>**Table 6–4:** Data formats



# <span id="page-46-0"></span>**6.6. Programming Information**

If the content of any register (except the lock registers) is to be changed, the desired value must first be written into the corresponding RAM register. Before reading out the RAM register again, the register value must be permanently stored in the EEPROM.

Permanently storing a value in the EEPROM is done by first sending an ERASE command followed by sending a PROM command. **The address within the ERASE and PROM commands must be zero.** ERASE and PROM act on all registers in parallel.

If all HAC 830 registers are to be changed, all writing commands can be sent one after the other, followed by sending one ERASE and PROM command at the end.

During all communication sequences, the customer has to check if the communication with the sensor was successful. This means that the acknowledge and the parity bits sent by the sensor have to be checked by the customer. If the Micronas programmer board is used, the customer has to check the error flags sent from the programmer board.

**Note** For production and qualification tests, it is mandatory to set the LOCK bit after final adjustment and programming of HAC 830. The LOCK function is active after the next power-up of the sensor. The success of the lock process must be checked by reading at least one sensor register after locking and/or by an analog check of the sensor's output signal. Electrostatic discharges (ESD) may disturb the programming pulses. Please take precautions against ESD.

# <span id="page-47-0"></span>**7. Document History**

- 1. Data Sheet: "[HAC 830](#page--1-0) [Robust Multi-Purpose Programmable Linear Hall-Effect Sensor with Inte](#page--1-1)[grated Capacitors](#page--1-1)", Feb. 24, 2016, DSH000178\_001EN. First release of the data sheet.
- 2. Data Sheet: "[HAC 830](#page--1-0) [Robust Multi-Purpose Programmable Linear Hall-Effect Sensor with Inte](#page--1-1)[grated Capacitors](#page--1-1)", Dec. 19, 2018, DSH000178\_002EN. Second release of the data sheet.

Major Changes:

- Package drawing updated
- – [Section 3.2.](#page-10-1) "[A/D Converter](#page-10-1)" added
- 40 mT magnetic range in [Table 3–2](#page-13-0) removed
- Initial values for Sens $_{\text{INITIAL}}$  in [Table 3–6](#page-18-1) changed
- Sensitivity equation in [Section 3.4.1.](#page-17-2) updated
- $-V<sub>OO</sub>$  equation in [Section 3.4.1.](#page-17-2) changed
- $-$  t<sub>NVMLife</sub> and T<sub>storage</sub> in [Table](#page-23-1) added
- Characteristics [\(Table](#page-25-1) ) updated:
	- $\cdot$  R<sub>OUT</sub> conditions
	- $\bullet$  f<sub>OSC</sub> added
	- V<sub>OQ</sub> value
	- $V_{\text{OUTn}}$  value
	- $R_{\text{thia}}$  conditions
	- $R_{\text{thic}}$  conditions
- Maximum values for  $t_{r(0)}$  (Step Response Time of Output) added in [Section](#page-26-1)
- Parameter A/D-Readout in [Table 6–4](#page-45-0) added
- Application circuit updated