



All dimensions are in mm; tolerances according to ISO 2768 m-H

**Interface**

According to IEC 61169-54

**Documents**

Application note AN001 "Calibration Services"

**Material and plating**

**Connector parts**

- Center conductor
- Outer conductor
- Body
- Coupling nut
- Dielectric

**Material**

- Brass
- Stainless steel
- Stainless steel
- Stainless steel
- PTFE

**Plating**

- Gold, min. 1.27 µm, over nickel
- Passivated
- Passivated
- Passivated

Dieses Dokument ist urheberrechtlich geschützt • This document is protected by copyright • Rosenberger Hochfrequenztechnik GmbH & Co. KG

RF\_35/09;14/6.2

**Electrical data**

|                 |   |
|-----------------|---|
| Frequency range | DC to 12 GHz  |
| Return loss     | ≥ 35 dB, DC to 4 GHz<br>≥ 32 dB, 4 GHz to 6 GHz<br>≥ 25 dB, 6 GHz to 12 GHz |

**Mechanical data**

|                    |                    |
|--------------------|--------------------|
| Mating cycles      | ≥ 100              |
| Maximum torque     | 5 Nm               |
| Recommended torque | 2 Nm               |
| Gauge              | 2.80 mm to 2.90 mm |

**General standard definitions**

For proper operation the vector network analyzer (VNA) needs a model describing the electrical behaviour of this calibration standard. The different models, units, and terms used will depend on the VNA type and they will have to be entered into the VNA. All values are based on typical geometry and plating.

|                                     |                                 |
|-------------------------------------|---------------------------------|
| Offset $Z_o$ / Impedance / $Z_o$    | 50 $\Omega$                     |
| Offset Delay                        | 189.466 ps                      |
| Length (electrical) / Offset Length | 56.80 mm                        |
| Offset Loss                         | 2.50 G $\Omega$ /s              |
| Loss                                | 0.0411 dB / $\sqrt{\text{GHz}}$ |

**Environmental data**

|   |                   |
|---|-------------------|
| Operating temperature range <sup>1</sup>    | +20 °C to +26 °C  |
| Rated temperature range of use <sup>2</sup> | 0 °C to +50 °C    |
| Storage temperature range                   | - 40 °C to +85 °C |

RoHS compliant

<sup>1</sup> Temperature range over which these specification are valid.

<sup>2</sup> This range is underneath and above the operating temperature range, within the calibration adaptor is fully functional and could be used without damage.

**Declaration of calibration options**

**Factory Calibration**

Standard delivery for this calibration standard includes a Factory Calibration. The Calibration Certificate issued reports individual calibration results, traceable to national / international standards. Model based standard definitions are reported in an Agilent/Keysight, Rohde & Schwarz and Anritsu compatible VNA format.

**Accredited Calibration**

Not available.

*For further, more detailed information see application note AN001 on the Rosenberger homepage.*

**Calibration interval**

Recommendation 12 months

**Packing**

Standard 1 pce in box  
Weight 117 g/pce

While the information has been carefully compiled to the best of our knowledge, nothing is intended as representation or warranty on our part and no statement herein shall be construed as recommendation to infringe existing patents. In the effort to improve our products, we reserve the right to make changes judged to be necessary.

| Draft          | Date     | Approved      | Date     | Rev. | Engineering change number | Name             | Date     |
|----------------|----------|---------------|----------|------|---------------------------|------------------|----------|
| Marcel Panicke | 11.02.16 | Markus Müller | 18.05.17 | d00  | 17-0836                   | Marion Striegler | 18.05.17 |

|  |  |               |
|--|--|---------------|
| Rosenberger Hochfrequenztechnik GmbH & Co. KG<br>P.O.Box 1260 D-84526 Tittmoning Germany<br><a href="http://www.rosenberger.de">www.rosenberger.de</a> | Tel. : +49 8684 18-0<br>Email : <a href="mailto:info@rosenberger.de">info@rosenberger.de</a> | Page<br>3 / 3 |
|--|--|---------------|