

EFM[®]32

... the world's most energy friendly microcontrollers

Quick Start Guide

EFM32-G8XX-STK

0 1 2 3 4

Congratulations with your new EFM32 Gecko Starter Kit. Your package should include

- EFM32 Starter Kit Board
- USB cable
- CD with IAR Embedded Workbench for ARM, Kickstart edition
- Quick Start Guide (this document)

Please follow these simple steps to start using your new Starter Kit.

1. Download and install the "EFM32 Gecko Installer" Software Package. Run the "Update STK" script to install firmware.

<http://www.energymicro.com/downloads/software>

2. Install your choice of development environment (one of the below)

IAR - Embedded Workbench for ARM

<http://www.iar.com> or enclosed CD

Rowley Associates - Crossworks for ARM

<http://www.rowley.co.uk>

CodeSourcery - Sourcery G++

<http://www.codesourcery.com>

Keil - MDK-ARM

<http://www.keil.com>

3. Review the enclosed documentation for your selected development environment, and the EFM32-G8XX-STK user guide found in your "Energy Micro" software installation folder

4. This product includes J-Link Technology. Download and install the latest SEGGER J-Link ARM software

<http://www.segger.com/cms/jlink-software.html>

5. Attach the enclosed USB cable to your PC and kit

6. Your kit is ready to use. Source examples are typically installed under

`C:\Program Files\Energy Micro\EFM32 Gecko DK\board\EFM32_G8XX_STK\examples`

For detailed information, please refer to the EFM32 Gecko Starter Kit User Manual.

This product is compliant with

Electromagnetic Compatibility (EMC)
2004/108/EC

FCC CFR 47 Part 15 (2008)

RoHS compliant





Declaration of Conformity



Energy Micro AS, Sandakervien 118, P.O Box 4633 Nydalen, Oslo, Norway, declares that the following product(s):

- **EFM32 Starter Kit, EFM32-G8XX-STK**

has (have) been tested and conform(s) with the essential requirements and other relevant provision of the following harmonized standard(s) and directive(s):

- **EN 55022 (2006)**

and therefore comply with the essential requirements and provisions of the following Directives of the European Parliament and European Council:

- **Electromagnetic Compatibility (EMC) 2004/108/EC**

The technical test has been executed following the Norwegian accreditation scheme by *Nemko, P.O. Box 73 Blindern, N-0314 Oslo, Norway*:


- **Test Report No. E10077.00**

Oslo, Norway, 23 March 2010

A handwritten signature in blue ink, appearing to read "Geir Førre".

Geir Førre

President and CEO



ENERGY[®]
micro

*Energy Micro AS
Sandakerveien 118
P.O. Box 4633 Nydalen
N-0405 Oslo
Norway*

www.energymicro.com