

# Getting Started Guide

 **Development Kit**  
nRF24LE1

nRF24LE1-F16Q24-DK

nRF24LE1-F16Q32-DK


nRF24LE1-F16Q48-DK

## 1. Register at [www.nordicsemi.com](http://www.nordicsemi.com) and download all kit software and documentation

1. Go to [www.nordicsemi.com](http://www.nordicsemi.com).
  2. Log in to your **MyPage** account (or create an account first if you don't already have one).
  3. Select **My Products** from the left menu.
  4. From the **Add Product** list, select **nRF24LE1 Development Kit**.
  5. Click **Add**.
  6. Click the **Downloads** link in the **Overview, My Products table**. Available documentation and software are listed on the **Downloads** tab.
  7. Below **Software** click **nRFgo Studio** and run the install file.
  8. The software will be available from your Windows **Start** menu.
- 


## 2. Connect an nRF24LE1 module to an nRFgo Motherboard

1. Plug one of the nRF24LE1 radio modules into the nRF module socket on an nRFgo Motherboard (sold separately with the Starter Kit).
2. Connect the nRFgo Motherboard to an available USB port on your computer using one of the USB cables (included in the nRFgo Starter Kit).



### 3. Power on

1. Turn the **S8** switch on the nRFGo Motherboard to **VBUS**.
2. Turn the **S9** switch on the nRFGo Motherboard to **On**.
3. The VTG and VCC LEDs will light up green.



### 4. Start nRFGo Studio

1. From the Windows **Start** menu on your computer go to **All Programs - Nordic Semiconductor - nRFGo Studio**.
2. You can view the connected nRFGo module in the nRFGo Studio Device Manager pane.

