User's Guide

UCC3976/7 Dual Evaluation Module

User's Guide

EVM IMPORTANT NOTICE

Texas Instruments (TI) provides the enclosed product(s) under the following conditions:

This evaluation kit being sold by TI is intended for use for **ENGINEERING DEVELOPMENT OR EVALUATION PURPOSES ONLY** and is not considered by TI to be fit for commercial use. As such, the goods being provided may not be complete in terms of required design-, marketing-, and/or manufacturing-related protective considerations, including product safety measures typically found in the end product incorporating the goods. As a prototype, this product does not fall within the scope of the European Union directive on electromagnetic compatibility and therefore may not meet the technical requirements of the directive.

Should this evaluation kit not meet the specifications indicated in the EVM User's Guide, the kit may be returned within 30 days from the date of delivery for a full refund. THE FOREGOING WARRANTY IS THE EXCLUSIVE WARRANTY MADE BY SELLER TO BUYER AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED, IMPLIED, OR STATUTORY, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE.

The user assumes all responsibility and liability for proper and safe handling of the goods. Further, the user indemnifies TI from all claims arising from the handling or use of the goods. Please be aware that the products received may not be regulatory compliant or agency certified (FCC, UL, CE, etc.). Due to the open construction of the product, it is the user's responsibility to take any and all appropriate precautions with regard to electrostatic discharge.

EXCEPT TO THE EXTENT OF THE INDEMNITY SET FORTH ABOVE, NEITHER PARTY SHALL BE LIABLE TO THE OTHER FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.

TI currently deals with a variety of customers for products, and therefore our arrangement with the user **is not exclusive**.

TI assumes **no liability for applications assistance, customer product design, software performance, or infringement of patents or services described herein**.

Please read the EVM User's Guide and, specifically, the EVM Warnings and Restrictions notice in the EVM User's Guide prior to handling the product. This notice contains important safety information about temperatures and voltages. For further safety concerns, please contact the TI application engineer.

Persons handling the product must have electronics training and observe good laboratory practice standards.

No license is granted under any patent right or other intellectual property right of TI covering or relating to any machine, process, or combination in which such TI products or services might be or are used.

Mailing Address:

Texas Instruments Post Office Box 655303 Dallas, Texas 75265

Copyright 2001, Texas Instruments Incorporated

DYNAMIC WARNINGS AND RESTRICTIONS

It is important to operate this EVM within the input voltage range of 3.0 V to 13.5 Vdc and the output voltage of 400 – 600 Vac.

Exceeding the specified input range may cause unexpected operation and/or irreversible damage to the EVM. If there are questions concerning the input range, please contact a TI field representative prior to connecting the input power.

Applying loads outside of the specified output range may result in unintended operation and/or possible permanent damage to the EVM. Please consult the EVM User's Guide prior to connecting any load to the EVM output. If there is uncertainty as to the load specification, please contact a TI field representative.

During normal operation, some circuit components may have case temperatures greater than 50°C. The EVM is designed to operate properly with certain components above 50°C as long as the input and output ranges are maintained. These components include but are not limited to linear regulators, switching transistors, pass transistors, and current sense resistors. These types of devices can be identified using the EVM schematic located in the EVM User's Guide. When placing measurement probes near these devices during operation, please be aware that these devices may be very warm to the touch.

Mailing Address:

Texas Instruments Post Office Box 655303 Dallas, Texas 75265

Copyright 2001, Texas Instruments Incorporated

UCC3976/7 Dual Evaluation Module

Power Supply Control Products

1 Introduction

1.1 UCC3976/7 Dual Evaluation Module Design Note

The UCC3976/7 dual evaluation modules are dc/ac inverter modules used to drive a cold cathode fluorescent lamp (CCFL) with a piezoelectric transformer (PZT). This evaluation module (EVM) consists of two separate circuits. One is a half-bridge circuit using the UCC3976 controller. The other is a push-pull circuit using the UCC3977 controller.

The principle of operation for the inverter is explained in the application section of the UCC3975/6/7 data sheet. This design note explains the design procedures for the two circuits. Section 2 describes the half-bridge design, while Section 3 describes the push-pull design.

2 Half-Bridge Design With the UCC3976 Controller

A schematic for the UCC3976 EVM is given in Figure 1. Recommended parts lists are provided in Table 1. The evaluation board components can be modified depending on the application require ments.

This EVM is designed for a 400-V cold-cathode fluorescent lamp (CCFL) with a 12-V input voltage. The input voltage range changes for lamps that have different voltage requirements.

Figure 1. Evaluation Module Schematic for UCC3976

2.1 Half-Bridge Inductor Selection

The inductor and the capacitor from the primary side of a PZT form a low-pass filter, which should pass the resonant frequency required by the PZT and attenuate higher harmonic components. The resonant frequency formed by the LC filter can be calculated by equation 1.

V Texas **NSTRUMENTS**

$$
f = \frac{1}{2\pi\sqrt{L \times C_{IN}}} \tag{1}
$$

where C_{IN} is the primary capacitance of the PZT.

In the EVM, the inductance value is 39 μ H while the input capacitance of the PZT is 105 nF. The resulting LC resonant frequency is around 78 kHz. The resonant frequency of the PZT, which is also the operating frequency, is around 55 kHz. Therefore the LC circuit passes the 55 kHz fundamental, yet attenuates higher harmonics.

If the external inductance is too low, a non-sinusoidal primary waveform results, since higher order harmonics are allowed through the filter. A low value inductor also increases circulating currents and results in lower efficiency. If the inductance is too large, it causes attenuation of the input voltage to the PZT and increases its gain requirements.

2.2 Frequency Range Setting

The VCO frequency range is programmed with external components R1, R2, and C3. The frequency is determined by the voltage decay from 1.7 V to 0.7 V at the OSC pin. When the voltage reaches 0.7 V, an internal current source charges OSC back to 1.7 V. The decay time is determined by the value of C3 and the discharge currents generated in R1 and R2. An accurate NPO capacitor is recommended for C3 and 1% resistors are recommended for R1 and R2. The output frequency range can be calculated by equation 2:

$$
f(V_{COMP}) = \frac{\left[\frac{R1 + R2}{R1 \times R2 \times C3}\right]}{2 \times 10\left[\frac{1.7 V \times (R1 + R2) - V_{COMP} \times R1}{(0.7 V - V_{COMP}) \times R1 + 0.7 V \times R2}\right]}
$$
(2)

With C3 set at 560 pF, R1 at 16 kΩ, and R2 at 121 kΩ, the frequency range is 51 kHz to 71 kHz, which gives sufficient operation range.

2.3 Analog Dimming of the Lamp

For analog dimming, enable the open-lamp detection by connecting pin 1 to pin 2 of jumper J1 and ground BD1. Lamp intensity is controlled with the signal VCNT1.

Referring to Figure1, the RMS lamp current becomes:

$$
I_{LAMP} = \frac{\left[1.5 \text{ V} \times (\text{R3} + \text{R5}) - \text{V}_{CNT} \times \text{R5}\right]\pi}{\sqrt{2} \times \text{R3} \times \text{R6}}
$$
(3)

(4)

Zero volts on VCNT1 commands full current while 3 V commands minimum current. For the initially configured EVM, maximum current is 6 mA and minimum current is 2 mA. R6 is selected to be 845 Ω using equation 3 and setting VCNT1 to 1.5 V and lamp current to 4 mA. With R3 set to 100 kΩ, R5 is calculated to be 50 kΩ using equation 3 and setting VCNT1 to 0 V and lamp current to 6 mA. The control-voltage to lamp-current equation for the EVM is:

$$
I_{\text{LAMP}}(mA) = 6.0 - 1.33 \times V_{\text{CNT}}
$$

Figure 2 shows the normal operation waveforms. The waveforms were take at $V_{\text{IN}} = 12$ V and $I_{\text{LAMP}} = 5$ mA.

Figure 2. Half-Bridge Operation Waveform CH1: Lamp Voltage; CH2: Primary Voltage; CH3: Primary Current; CH4: OUTN

2.4 Open-Lamp Voltage Programming

It is necessary to suspend power-stage operation if an open lamp occurs, because the piezoelectric transformer has high gain. The open-lamp detection circuit is composed of voltage divider R10, R12 through R18, R4, R9, D3, and C5. Resistors R10 and R12 through R18 are multiple series 1-MΩ resistors to stand off high voltage. A 1.5-V comparator at the OPEN pin shuts down the inverter if an open lamp is triggered. The RMS secondary voltage at which an open lamp shutdown occurs can be calculated by equation 5.

$$
V_{\text{OPEN}} = \frac{(1.5 \text{ V} + \text{V}_{\text{DIODE}}) \times \left(R10 + \frac{\frac{18}{2}}{1 = 12}R_1 + R9 + R4\right)}{\sqrt{2} \times (R9 + R4)}
$$
(5)

With R10 and R12 through R18 at 1 M each, R12 at 2 k Ω , and R9 at 8.2 k Ω , the RMS value of open lamp threshold voltage at the secondary is 1220 VRMS.

The value of capacitor C5 should be large enough to filter the sinusoid waveform into dc. For this board, 2.2 nF was chosen. If C5 is too large, it will take extra time for the OPEN/SD to climb to 1.5 V when the output voltage hits the open-lamp threshold, which results in a higher output voltage than the set value.

The open-lamp level should be set high enough to avoid tripping during normal operation. Open-lamp detection is disabled for burst-dimming mode by connecting pin 3 to pin 2 of J1. Connect pin 1 to pin 2 of J1 to enable open lamp and shutdown for analog dimming application.

Figure 3. COMP Pin and SD/OPEN Pin During Open Lamp Start-Up CH1: COMP; CH2: OPEN/SD; CH 3&4: OUTP/OUTN

2.5 Shutdown

The OPEN/SD pin is used for both open-lamp detection and commanded shutdown. When a voltage higher than 2.5 V is applied to OPEN/SD through D1, the part enters the shutdown or sleep mode where the oscillator is inactive and both outputs are high. In this mode, the part draws little current at the VDD pin and the OPEN/SD pin.

2.6 No-Lock

If the part fails to achieve regulation before reaching minimum frequency (Comp >2.2 V), it causes an internal retry counter to increment and then attempt another start-up. If the application does not operate normally after 7 attempts, the controller enters an error-induced shutdown state removing power to the load. Figure 4 shows the waveforms at no lock. Under low input-voltage conditions, the PZT is unable to ignite the lamp at full current. The waveforms in Figure 4 were taken at 4-V input voltage and 0-V VCNT1.

2.7 System Efficiency and Frequency Range

Efficiencies and operating frequencies using analog dimming techniques are shown in Figure 5 and Figure 6 using a 400-V lamp. The maximum efficiency can be as high as 89%.

2.8 Burst Dimming

The UCC3976 is primarily intended for analog dimming applications. Burst dimming can be implemented at the OPEN/SD pin at the cost of open-lamp detection.

Connect pin 2 to pin 3 of J1 to disable the open-lamp detection circuit during burst dimming mode.

To implement burst dimming on the EVM, VCNT1 should be grounded to set maximum lamp brightness. A low-frequency 0-V to 5-V square wave applied to BD1 modulates the lamp current between zero and full intensity at the desired frequency. A low-frequency repetition rate of greater than 120 Hz is recommended to avoid visible flicker. Applying 5 V at BD1 forces the lamp current to zero, where 0 V at BD1 forces maximum lamp current. The duty cycle of the square wave determines the lamp brightness as a percent of rated lamp current.

CH1: OUTP; CH2: OPEN/SD; CH3: COMP

2.9 Clamp Circuit (Optional)

There is also a clamp circuit to limit the maximum secondary voltage. This circuit is typically not needed since the CCFL strikes or the open lamp circuit triggers before destructive levels are reached.

If R11 and Q2 are added to the board, the peak clamp voltage for the EVM is given by equation 6:

$$
V_{CLAMP} = \frac{(1.5 V + V_{BE}) \times \left[R10 + \frac{\frac{18}{2}}{t = 12}R_1 + R9 + R4 \right]}{R9}
$$
 (6)

The peak clamped voltage for the evaluation board is 2200 V.

Figure 8 shows the waveforms when clamp circuit is active.

3 Push-Pull Design With the UCC3977 Controller

A complete schematic for the UCC3977 EVM is given in Figure 9. Recommended part lists are provided in Table 2. The evaluation board components can be modified depending on the application requirements.

The frequency-range, open-lamp voltage programming, no-lock, shutdown, analog-dimming setting, and the clamp circuit are all designed with the same values as the UCC3976 half-bridge circuit.

A supply between 4 VDC and 8 VDC is required for this board to operate a 520-V cold-cathode fluorescent lamp (CCFL) from 2 mA to 6 mA.

Figure 9. Evaluation Module Schematic for UCC3977

3.1 Push-Pull Inductor Selection

The push-pull topology requires a different approach for calculating the external inductor values. Referring to Figure 1, Q4A and Q4B are driven out of phase at 50% duty cycle. When Q4A is on, current is ramped up in L2 as shown in Figure 10. During the next switch cycle Q4B is turned on, Q4A is turned off, and the energy stored in L2 is transferred through the piezoelectric transformer (returning to ground through L3). L2 resonates with the piezoelectric primary capacitance forming a half sinusoid at Q4A's drain and across the transformer. In order to achieve zero-voltage switching, the drain voltage must return to ground before the next switching cycle. This dictates that the LC resonant frequency must be greater than the switching frequency.

$$
L < \frac{1}{4 \times \pi^2 \times f^2 \times C_P}
$$
 (7)

In the EVM with a 55-kHz switching frequency and 105-nF piezoelectric transformer, L2 and L3 must be less than 80 µH for zero-voltage switching, so 47-µH inductors are used.

Figure 10 shows the normal operation waveforms, which were taken at $V_{IN} = 4$ V and $I_{LAMP} = 5$ mA.

Figure 10. Push-Pull Operation Waveform CH1: Lamp Voltage; M1: Primary Voltage; CH2: Voltage of P to GND; CH3: Current Through L1

3.2 System Efficiency

Efficiencies and operating frequencies using analog-dimming techniques are shown in Figure 11 and Figure 12 using a 520-V lamp. The maximum efficiency can be as high as 88%.

3.3 Evaluation Module Component Placement

Figure 13 shows the component placement for the EVM. Pin numbers and component polarities are also shown. The top part is for a half-bridge circuit with UCC3976 and the bottom one is for a push-pull circuit with UCC3977. Table 1 lists the parts values of the UCC3976/7 EVM as initially configured. These values can be modified to meet the application requirements.

Figure 13. Parts Placement for the UCC3976/7 Dual Evaluation Module

4 Appendix

4.1 Layout Consideration to Avoid Oscillations Due to Output Capacitance

There is a very small capacitance in a PZT output, (about 15 pF for a Panasonic PZT). For a CCFL system, there are many parasitic capacitances from the lamp to ground along the length of the lamp. These parasitic capacitances influence resonant operation and contribute to the output voltage. If the wires to the lamp are long and these parasitic capacitances are not constant, output voltage can jitter and an output voltage envelope appears, as shown in Figure 14 trace 1. Due to the nonlinear characteristics of CCFL, small lamp voltage changes result in large current changes, as shown in Figure 14 trace 2.

If these types of oscillations occur, the high voltage wire to the lamp should be shortened and the parasitic capacitance should be kept constant. Putting a shield around the lamp and letting the ground return wire run along the shield also helps.

Figure 14. Envelope CH1: Lamp Voltaage, CH2: Drive Signal, CH3: Lamp Current

IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by government requirements, testing of all parameters of each product is not necessarily performed.

TI assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using TI components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any TI patent right, copyright, mask work right, or other TI intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information published by TI regarding third–party products or services does not constitute a license from TI to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. Reproduction of this information with alteration is an unfair and deceptive business practice. TI is not responsible or liable for such altered documentation.

Resale of TI products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

Mailing Address:

Texas Instruments Post Office Box 655303 Dallas, Texas 75265

Copyright 2002, Texas Instruments Incorporated