

EFM8 Busy Bee Family QSG129: EFM8BB2-SLSTK2021A Quick Start Guide




The EFM8BB2-SLSTK2021A is an excellent starting point to get familiar with the EFM8 Busy Bee microcontrollers.

The kit contains sensors and peripherals demonstrating some of the MCU's many capabilities. The kit can also serve as a starting point for application development.

KIT CONTENTS

- EFM8BB2 Busy Bee Starter Kit Board
 1 x mini USB cable
- 1 x CR2032 coin cell battery
- Getting Started card



1. Getting Started

Install Simplicity Studio


Simplicity Studio is a free software suite needed to start developing your application. Download the latest version of Simplicity Studio from the Silicon Labs website:

http://www.silabs.com/simplicity-studio


📲 Launcher - Simplicity Studio =			_ — — ×
file Epit Navigate Search Project Run Window Help			
Senin - 🔆 🚊	Scarch	JF Tools	😰 🛛 👘 Leuncher
Devices 2 Solutions Constructions Constructions Constructions Constructions Construction Construction Construction Construction Construction Construction Construction	Debug Mode: MCU Acapter Firmware Version: 0x44p1b4		Self to counti
	Getting Started Doo New Project Recent Pro Demos	ojacts - Software Examples	Tools Resources Application Notes Yane 44
	EFM88B1 CPT0078 Demo	EFM8881 ADC ExternalInput	AN111 Using CB051Fxxx in 5 \ 📑
	EFM8881 CPT1125 Demo	EFM8881 ADC Lib Accumulate K This example demonstrates using the CFM8 ADC perpherel driver lot emple.	AN119 Calculating Settling Ti
	EFM8BB1 Oscilloscope () This demo samples the ADC input at 200	EFM3881 ADC LIb Interrupt 55	AN124 Pin Sharing Technique 🕌
	lisps and displays the measured.	EFM8881 ADC Lib Interrupt Lo 🐂	AN136 Production Programm 🖺
	EFM8BB1 Rainbow Blinky () This execute demonstrate the 3CA LCD	This example demonstrates using the FFMI ADC peripheral driver lower to sample.	AN203 C8051Fxxx Printed Circ 皆

Note: The board comes pre-loaded with a default application, Space Invaders, to play with while the software downloads.

- Set Up Your Kit
 - 1. Provide power to the board by connecting the DBG USB connector to the PC using the provided USB cable.



- Detect Your Device
 - 1. Wait for the J-Link debug adapter to appear in the [Devices] area. The board may take some time to appear due to driver installations for the debug adapter.
 - 2. Click the J-Link debug adapter or the board information corresponding to the board. This will verify that the installation was successful, identify the MCU on the kit hardware, and automatically configure the software tools for use with your device.



Run Blinky


Click the [Demos] tile to load the available demos. Select [Rainbow Blinky] and click [Start] to download and run the demo. Follow the instructions on the kit LCD screen to run the demo.

A Launcher - Simplicity Studio T		ورجعر	a 🔤 🗙 🔤	
The Edit Navigate Search Project Run Window Help				
Sente = 🔆 🚊	Scandh	🗲 Toob 😰 🦷	Leuncher	
Devices: 2 Solutions Control (1997) Devices: 2 Solutions Control (1997) Devices: 2 Solutions Control (1997) Control (1997) Control (1997) Device (1997) Device (1997) Device (1997)	EFM8BB1 Busy Bee Start Peterwei VIII: WIII VIII: VIII: Club feet in drunge the p Petrog Mode: MCU data Club feet in drunge the p Acapter Firmare Version 0x44p1b420 Holeal acapter Getting Started Documentation Have Projects -	ter Kit		
	Demos Software Exc EM8881 mm (c) to except prime and software Studies to except prime and software Studies to except prime and software Studies EM88881 CPT S Dame (c) Be concept prime or the Studies(c) Be concept prime or the Studies(c) B	Eternalingut tala ut a ser Demos	View	<u>v All</u>
	EFM8881 Ovcil scope The drow compares The drow	EFM8BB1 CPT This example proje	007B Demo	δ

2. Resources

Demos

Demos are a quick and easy way to evaluate a device without compiling or debugging code. Demos can be accessed using the [Get-ting Started]>[Demos] area in the launcher.



Software Examples

Software examples can be imported, compiled, and downloaded using the [Getting Started]>[Software Examples] area in the launcher.

	Constant of the provided	Herried SDE Compatible Cice p Compatible T Input % Input % In	
And Killer Kills Valler skaller för and ode: MCU art Finneare Version: 04.4423 mg Started D. Rescard Rescard D. Rescard D. Rescard Rescard D. Rescard D. Rescard Rescard D. Rescard D. Rescard Rescard D. Rescard D. Rescard D. Rescard Rescard D. Rescard D. Resc	Constant of the provided	Herried SDE Compatible Cice p Compatible T Input % Input % In	cols Resources Application Notes AN111 Using C0051Face In 1 AN114 Hand Soldering Text
Project Recent 1 S Yourd S Yourd S Yourd S Yourd S Yourd S	Contract Co	Input K Input	Application Notes AN111 Using C8051Fxxx In 1 AN114 Hand Soldering Tute
S Vere 4 ISI CPT007B Denno (*) wysie project uwe the 21MB LCD intrars the ed. ISI CPT12S Damo (*) wysie project uwe the BMB LCD omage by the 41 CP ISI Oscilloscope (*) ro sample the 40 cy reset at 900	Software Examination FM9881 A This wands cool of the wands cool of the wands cool of the wands cool of the wands down a ADC perpined drive FM9881 ADC L	Input 🛼	AN111 Using C8051Fxxx in ! AN114 Hand Soldering Tute
write project user the SFME LCD entrane the use of	This example code to enalog measurement EFM88891 ADC L This example denote ADC pergineral drive EFM88891 ADC L	Lib Accumulate SHE to from input. PL7 comp	AN114 Hand Soldering Tuto
In the project uses the SFM&LCD constraines the Lase of	EFM8881 ADC L	names using the CFM3 r Nonzy to semple	_
no samples the ADC input at 500			
	This example demon	states using the CFM2	AN124 Pin Sharing Techniq
	This example demon	Lib Interrupt Lo 🐂	ANISS Production Program
oles	View A		
ernalInpu and average	es 2048		
	and averag	ernalInput and averages 2048 m input P1.7	and averages 2048

Software Documentation

Software documentation provides more information on the firmware libraries available for the selected device. Access these documents using the [**Documentation**] area in the launcher.

🚰 Gundher - Simplicity Studio T				
File Edit Navigale Search Project Run Window Help				
Sente * 🕀 🕭	50401	Jush	28 M Learcher	
Povice: 2 ♀ Solutions □ > ↓ ↓ ↓ □ > ↓ ↓ ↓ ↓ □ > ↓	EFM8BB1 Busy B Perference SUDCINITY SUIT SALAR CHICK CO Debug Mode: MCU Acceptor Firmmare Version OxAlepted 20		3	
	Getting Started Docu EFV6881 Birk Birk Birk Birk Birk Birk Birk Birk	BRD5200A A01, bom	EFM8 4.0.0 Documen	tation
	EFM8861_datasheet	EFM8BB1-SLSTK2020A-QuickS	EFM8BB1-SLSTK2020A-UserGt 🖸	hà
				-


Kit Documentation and User's Guide

Kit documentation like the schematic and detailed board user guide can be found using the [Documentation] area of the launcher.

Cusinoher - Simplicity Studio =				
he Ecit Navigate Search Project Run Window Help				
entr ≠⊕ ≜	30401	First		E In Lound
Devices: 2 P Solutions				
	EFM8BB1 Busy B Preferred SDG (RIN) SING Se DID. Clinic Se Debug Mode: MCU Acaptor Firmware Version: 96449;26430		Prese to count:	J.
	FFVSREI Rusy Ree Dance ()r	mentation Compatible	1	urces
	BRD5200A A01 assy draw 💍	BRD5200A A01 bom 5	BRD5200/	atic 🗧
	EFM8BB1 datasheet	EFM8BB1-SLSTK2020A-Quicks	EFM8BB1-SLST	020A-UserGi
BRD5200A	_A01_schema	tic 🚦		
		h		SILICON

Application Notes


Application Notes on peripherals and other various topics can be accessed using the [Getting Started]>[Software Examples] area of the launcher.



Community and Support

Have a question? Visit the community by clicking the [Resources]>[Silicon Labs Community] area of the launcher.

100 00	E
Autors Constant Const	Ì



Disclaimer

Silicon Laboratories intends to provide customers with the latest, accurate, and in-depth documentation of all peripherals and modules available for system and software implementers using or intending to use the Silicon Laboratories products. Characterization data, available modules and peripherals, memory sizes and memory addresses refer to each specific device, and "Typical" parameters provided can and do vary in different applications. Application examples described herein are for illustrative purposes only. Silicon Laboratories reserves the right to make changes without further notice and limitation to product information, specifications, and descriptions herein, and does not give warranties as to the accuracy or completeness of the included information. Silicon Laboratories shall have no liability for the consequences of use of the information supplied herein. This document does not imply or express copyright licenses granted hereunder to design or fabricate any integrated circuits. The products are not designed or authorized to be used within any Life Support System without the specific written consent of Silicon Laboratories. A "Life Support System" is any product or system intended to support or sustain life and/or health, which, if it fails, can be reasonably expected to result in significant personal injury or death. Silicon Laboratories products are not designed or authorized for military applications. Silicon Laboratories shall under no circumstances be used in weapons of mass destruction including (but not limited to) nuclear, biological or chemical weapons, or missiles capable of delivering such weapons.

Trademark Information

Silicon Laboratories Inc.®, Silicon Laboratories®, Silicon Labs®, SiLabs® and the Silicon Labs logo®, Bluegiga®, Bluegiga Logo®, Clockbuilder®, CMEMS®, DSPLL®, EFM®, EFM32®, EFR, Ember®, Energy Micro, Energy Micro logo and combinations thereof, "the world's most energy friendly microcontrollers", Ember®, EZLink®, EZRadio®, EZRadio®, Gecko®, ISOmodem®, Precision32®, ProSLIC®, Simplicity Studio®, SiPHY®, Telegesis, the Telegesis Logo®, USBXpress® and others are trademarks or registered trademarks of Silicon Laboratories Inc. ARM, CORTEX, Cortex-M3 and THUMB are trademarks or registered trademarks of ARM Holdings. Keil is a registered trademark of ARM Limited. All other products or brand names mentioned herein are trademarks of their respective holders.



Silicon Laboratories Inc. 400 West Cesar Chavez Austin, TX 78701 USA

http://www.silabs.com