

### TLV320AIC1103/1109/1110 EVMs

# User's Guide

March 2003

**Data Acquisition Products** 

SLAU092

#### **IMPORTANT NOTICE**

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by government requirements, testing of all parameters of each product is not necessarily performed.

TI assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using TI components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any TI patent right, copyright, mask work right, or other TI intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information published by TI regarding third-party products or services does not constitute a license from TI to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. Reproduction of this information with alteration is an unfair and deceptive business practice. TI is not responsible or liable for such altered documentation.

Resale of TI products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

Mailing Address:

Texas Instruments Post Office Box 655303 Dallas, Texas 75265

Copyright © 2003, Texas Instruments Incorporated

#### **EVM IMPORTANT NOTICE**

Texas Instruments (TI) provides the enclosed product(s) under the following conditions:

This evaluation kit being sold by TI is intended for use for **ENGINEERING DEVELOPMENT OR EVALUATION PURPOSES ONLY** and is not considered by TI to be fit for commercial use. As such, the goods being provided may not be complete in terms of required design-, marketing-, and/or manufacturing-related protective considerations, including product safety measures typically found in the end product incorporating the goods. As a prototype, this product does not fall within the scope of the European Union directive on electromagnetic compatibility and therefore may not meet the technical requirements of the directive.

Should this evaluation kit not meet the specifications indicated in the EVM User's Guide, the kit may be returned within 30 days from the date of delivery for a full refund. THE FOREGOING WARRANTY IS THE EXCLUSIVE WARRANTY MADE BY SELLER TO BUYER AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED, IMPLIED, OR STATUTORY, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE.

The user assumes all responsibility and liability for proper and safe handling of the goods. Further, the user indemnifies TI from all claims arising from the handling or use of the goods. Please be aware that the products received may not be regulatory compliant or agency certified (FCC, UL, CE, etc.). Due to the open construction of the product, it is the user's responsibility to take any and all appropriate precautions with regard to electrostatic discharge.

EXCEPT TO THE EXTENT OF THE INDEMNITY SET FORTH ABOVE, NEITHER PARTY SHALL BE LIABLE TO THE OTHER FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.

TI currently deals with a variety of customers for products, and therefore our arrangement with the user **is not exclusive**.

TI assumes no liability for applications assistance, customer product design, software performance, or infringement of patents or services described herein.

Please read the EVM User's Guide and, specifically, the EVM Warnings and Restrictions notice in the EVM User's Guide prior to handling the product. This notice contains important safety information about temperatures and voltages. For further safety concerns, please contact the TI application engineer.

Persons handling the product must have electronics training and observe good laboratory practice standards.

No license is granted under any patent right or other intellectual property right of TI covering or relating to any machine, process, or combination in which such TI products or services might be or are used.

Mailing Address:

Texas Instruments Post Office Box 655303 Dallas, Texas 75265

Copyright © 2003, Texas Instruments Incorporated

#### **EVM WARNINGS AND RESTRICTIONS**

It is important to operate this EVM within the input voltage range of 3.3 V described in the EVM User's Guide.

Exceeding the specified input range may cause unexpected operation and/or irreversible damage to the EVM. If there are questions concerning the input range, please contact a TI field representative prior to connecting the input power.

Applying loads outside of the specified output range may result in unintended operation and/or possible permanent damage to the EVM. Please consult the EVM User's Guide prior to connecting any load to the EVM output. If there is uncertainty as to the load specification, please contact a TI field representative.

During normal operation, some circuit components may have case temperatures greater than 60°C. The EVM is designed to operate properly with certain components above 60°C as long as the input and output ranges are maintained. These components include but are not limited to linear regulators, switching transistors, pass transistors, and current sense resistors. These types of devices can be identified using the EVM schematic located in the EVM User's Guide. When placing measurement probes near these devices during operation, please be aware that these devices may be very warm to the touch.

Mailing Address:

Texas Instruments Post Office Box 655303 Dallas, Texas 75265

Copyright © 2003, Texas Instruments Incorporated

### Preface

### **Read This First**

#### About This Manual

This user's guide describes the operation and use of the evaluation module (EVM) for the TLV320AIC1103 /1109 /1110 codec family. A complete circuit description as well as schematic diagram and bill of materials are also included.

### How to Use This Manual

This document contains the following chapters:

Chapter 1 – EVM Overview Chapter 2 – Digital and Analog Interface Chapter 3 – EVM Bill of Materials and Schematic

### **Related Documentation From Texas Instruments**

To obtain a copy of any of the following documents, call the Texas Instruments literature response center at (800) 477-8924 or the product information center (PIC) at (972) 644-5580. When ordering, please identify this booklet by its title and literature number. Updated documents can also be obtained through the TI website at www.ti.com.

Literature Number:
SLAS356
SLAS358
SLAS359

### FCC Warning

This equipment is intended for use in a laboratory test environment only. It generates, uses, and can radiate radio frequency energy and has not been tested for compliance with the limits of computing devices pursuant to subpart J of part 15 of FCC rules, which are designed to provide reasonable protection against radio frequency interference. Operation of this equipment in other environments may cause interference with radio communications, in which case the user at his own expense will be required to take whatever measures may be required to correct this interference.

### Contents

1		Overview	
2	Digita	al and Analog Interface	2-1
	2.1	Description	2-2
	2.2	Codec-to-Development Platform Interface	2-2
	2.3	Jumper Options	2-4
		2.3.1 Default Mode	2-4
		2.3.2 PCM Interface	2-4
	2.4	Analog Interface	2-4
3		Bill of Materials and Schematic	
		EVM Bill of Materials	
	3.2	TLV320AIC1103/ 1109/ 1110 EVM Schematic	3-2

## Figures

2-1	Development Platform Mechanical Interface	2-2

### **Tables**

2-1	EVM J3 Connector Pinout	2-3
2-2	Jumper Options	2-4
2-3	Default Mode—W1 Jumper Options	2-4
	PCM Interface—P1 Jumper Options	

### Chapter 1

### **EVM Overview**

This chapter provides an overview of the TLV320AIC1103 / 1109 / 1110 EVM.

Topio	C	Pag	je
1.1	Introduction	1-	2

### 1.1 Introduction

This EVM and user's guide supports the following devices:

TLV320AIC1103 TLV320AIC1109 TLV320AIC1110

These devices are voice-band audio processors, designed to perform transmit-encoding analog-to-digital (A/D) conversion, receive-decoding digital-to-analog (D/A) conversion, and transmit and receive filtering for voice-band communications systems.

The EVM can operate with a DSP development platform to provide the necessary power requirements and a convenient way to interface with TI's range of starter kits via the 80-pin expansion connector located on the DSK. Alternatively, the EVM can operate without a DSP development platform. In this case the user is responsible for providing a suitable interface to the host system.

System-level features for the chip are managed via 2 jumpers. Register programming is achieved via an I<sup>2</sup>C interface.

Interfacing with the analog I/O is accomplished via 3 screw terminals.

### Chapter 2

### **Digital and Analog Interface**

This chapter describes the digital and analog interface for the TLV320AIC1103 / 1109 /1110  ${\rm EVM}.$ 

Торі	c Page
2.1	Description2-2
2.2	Codec-to-Development Platform Interface
2.3	Jumper Options2-4
2.4	Analog Interface2-4

### 2.1 Description

The digital signals required to operate this codec originate from the 40-pin connector—J1. There are two methods to drive the digital interface:

Create a custom interface between the codec EVM and the host system.


Alternatively, if a TI DSP starter kit (DSK) is the host system, a development platform is available from TI. This platform provides the additional functions that the codec requires in a convenient form factor.

### 2.2 Codec-to-Development Platform Interface

The EVM mates with TI's DSP starter kit systems (DSKs) via the development platform.

The development platform mates with the DSK, through which all the necessary power is provided. RESET can be manually furnished to the EVM via a switch on the development platform, or by the RESET signal on the DSK via the development platform.

#### Figure 2 - 1. Development Platform Mechanical Interface



Electrical interface to the development platform is via a 40-pin connector on the TLV320AIC1103/1109/1110 EVM. The connector mates with the development platform connector (Samtec part number, TSM-120-01-T-DV-P). Consult Samtec at <u>www.samtec.com</u> or 1-800-SAMTEC-9 for more information.

The pinout for the 40-pin connector is given in Table 2-1.

Pin Number	Signal	Description
J1.1	MCLK	Master system clock
J1.2	DGND	Digital ground
J1.3	SCLK	Serial data clock
J1.4	DGND	Digital ground
J1.5	DIN	Data in
J1.6	DGND	Digital ground
J1.7	DOUT	Data out
J1.8	N/A	Reserved
J1.9	FS	Frame sync
J1.10	N/A	Reserved
J1.11	SCL	I <sup>2</sup> C Serial bus clock
J1.12	N/A	Reserved
J1.13	SDA	I <sup>2</sup> C Serial bus address / data
J1.14	N/A	Reserved
J1.15	N/A	Reserved
J1.16	N/A	Reserved
J1.17	RESET	Reset
J1.18	N/A	Reserved
J1.19	N/A	Reserved
J1.20	N/A	Reserved
J1.21	N/A	Reserved
J1.22	N/A	Reserved
J1.23	N/A	Reserved
J1.24	N/A	Reserved
J1.25	3.3V_D	Digital 3.3 V
J1.26	N/A	Reserved
J1.27	3.3V_D	Digital 3.3 V
J1.28	DGND	Digital ground
J1.29	N/A	Reserved
J1.30	DGND	Digital ground
J1.31	N/A	Reserved
J1.32	DGND	Digital ground
J1.33	N/A	Reserved
J1.34	AGND	Analog ground
J1.35	N/A	Reserved
J1.36	AGND	Analog ground
J1.37	3.3V_A	Analog 3.3 V
J1.38	AGND	Analog ground
J1.39	3.3V_A	Analog 3.3 V
J1.40	AGND	Analog ground

### Table 2 - 1. EVM J1 Connector Pinout

The development platform supports a number of functions required by the codecs:

Manual reset generation

Power options

Convenient mechanical interface to TI's DSK

Refer to SLAU090 for details regarding the development platform.

#### 2.3 Jumper Options

There are two jumpers on the EVM board that can be configured in various ways, depending upon the user's requirements. Their functions are briefly presented in the following tables.

#### Table 2-2. Jumper Options

Jumper	Jumper Function	
W1	Default mode selected	
P1.1 - P1.3	MCLK = PCMCLK (SCLK)	

#### 2.3.1 Default Mode

Default mode permits the codec to operate from power up without programming any registers via l<sup>2</sup>C.

#### Table 2 - 3. Default Mode—W1 Jumper Options

	W1	
Description	1-2	2-3
Default mode is selected	Inserted	Not inserted
Power-down mode	Not inserted	Inserted

See the appropriate data sheet for information regarding the default settings.

### 2.3.2 PCM Interface

The PCM interface transmits and receives data at the PCMO (DOUT) and PCMI (DIN) terminals respectively. The data is transmitted or received at the PCMCLK (SCLK) speed once every PCMSYN cycle (FS). The PCMCLK can be tied directly to a master 2.048 MHz clock (MCLK).

Table 2 - 4. PCM Interface—P1 Jumper Options

	P1	
Description	P1.1 - P1.3	
MCLK = SCLK	Inserted	

#### 2.4 Analog Interface

To make it as easy as possible to connect to a wide range of input and output devices, the analog interface features simple screw terminals—J2 and J3 for microphone inputs, and J4 for earphone output.

### Chapter 3

### **EVM Bill of Materials and Schematic**

This chapter provides a bill of materials and schematic for the TLV3201103/ 1109 / 1110 EVM.

Topio	c Page
3.1	EVM Bill of Materials3-2
3.2	EVM Schematic

### 3.1 EVM Bill of Materials

The following table contains a complete bill of materials for the TLV320AIC1103 /1109 /1110 EVM. The schematic diagram is also provided for reference. For further information contact the product information center (PIC) or E-mail questions regarding this EVM to <u>dataconvapps@list.ti.com</u>.

Quantity	Reference	Description
4	C1, C2, C3, C4	Capacitor, 0.22 $\mu F$ 16 V ceramic X7R 1206
2	C5, C6	Capacitor, 10 $\mu F$ 16 V tantalum TE series
2	C7, C8	Capacitor, 0.1 $\mu F$ 16 V ceramic X7R 1206
2	R1, R2	Resistor, 10 k $\Omega$ 1/8 W 5% 1206 SMD
3	R3, R4, R5	Resistor, 2 k $\Omega$ 1/8W 5% 1206 SMD
1	R6	Resistor, 100 k $\Omega$ 1/8W 5% 1206 SMD
2	R7	Resistor, 4.7 k $\Omega$ 1/8W 5% 1206 SMD
1	R8	Resistor, 0 $\Omega$ 1/8W 5% 1206 SMD
1	U1	TLV320AIC1110 IC, PCM codec, Prog. MIC AMP 32TQFP
	Alternate	TLV320AIC1109 IC, PCM codec, Prog. MIC AMP 32TQFP
	Alternate	TLV320AIC1103 IC, PCM codec, Prog. MIC AMP 32TQFP
1		TLV320AIC1110 PWB
1	J1	40-Pin SMT socket
1	P1	40-Pin SMT plug
3	J2, J3, J4	2 Terminal screw connector
1	W1	2 Position jumper
5	BUZZCON1	0.025 Inch test point
	EAR1	
	MUXIN1	
	MUXOUT1	
	MUXOUT2	
2	See assembly drawing	1.000/4-40, nylon, hex thread, SP
2	See assembly drawing	4-40  imes 1/4 inch, machine screw, panhead SS

### 3.2 EVM Schematic

The schematic is on the following page.

