

V850E2/Fx4-G

User's Manual: Hardware

32

32-bit Microcontroller

V850E2/FF4-G

μPD70F4177

μPD70F4178

V850E2/FG4-G

μPD70F4179

μPD70F4180

All information contained in these materials, including products and product specifications, represents information on the product at the time of publication and is subject to change by Renesas Electronics Corp. without notice. Please review the latest information published by Renesas Electronics Corp. through various means, including the Renesas Electronics Corp. website (<http://www.renesas.com>).

Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: "Standard", "High Quality", and "Specific". The recommended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as "Specific" without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as "Specific" or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics.

The quality grade of each Renesas Electronics product is “Standard” unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.

- “Standard”:
- Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
- “High Quality”:
- Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
- “Specific”:
- Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.

8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) “Renesas Electronics” as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) “Renesas Electronics product(s)” means any product developed or manufactured by or for Renesas Electronics.

General Precautions in the Handling of MPU/MCU Products

The following usage notes are applicable to all MPU/MCU products from Renesas. For detailed usage notes on the products covered by this manual, refer to the relevant sections of the manual. If the descriptions under General Precautions in the Handling of MPU/MCU Products and in the body of the manual differ from each other, the description in the body of the manual takes precedence.

1. Handling of unused Pins

Handle unused pins in accord with the directions given under Handling of Unused Pins in the manual.

- The input pins of CMOS products are generally in the high-impedance state. In operation with an unused pin in the open-circuit state, extra electromagnetic noise is induced in the vicinity of LSI, an associated shoot-through current flows internally, and malfunctions occur due to the false recognition of the pin state as an input signal become possible. Unused pins should be handled as described under Handling of Unused Pins in the manual.

2. Processing at power-on

The state of the product is undefined at the moment when power is supplied.

- The states of internal circuits in the LSI are indeterminate and the states of register settings and pins are undefined at the moment when power is supplied.

In a finished product where the reset signal is applied to the external reset pin, the states of pins are not guaranteed from the moment when power is supplied until the reset process is completed.

In a similar way, the states of pins in a product that is reset by an on-chip power-on reset function are not guaranteed from the moment when power is supplied until the power reaches the level at which resetting has been specified.

3. Prohibition of access to reserved addresses

Access to reserved addresses is prohibited.

- The reserved addresses are provided for the possible future expansion of functions. Do not access these addresses; the correct operation of LSI is not guaranteed if they are accessed.

4. Clock signals

After applying a reset, only release the reset line after the operating clock signal has become stable. When switching the clock signal during program execution, wait until the target clock signal has stabilized.

- When the clock signal is generated with an external resonator (or from an external oscillator) during a reset, ensure that the reset line is only released after full stabilization of the clock signal. Moreover, when switching to a clock signal produced with an external resonator (or by an external oscillator) while program execution is in progress, wait until the target clock signal is stable.

5. Differences between products

Before changing from one product to another, i.e. to one with a different part number, confirm that the change will not lead to problems.

- The characteristics of MPU/MCU in the same group but having different part numbers may differ because of the differences in internal memory capacity and layout pattern. When changing to products of different part numbers, implement a system-evaluation test for each of the products.

Table of Contents

Notice	2
General Precautions in the Handling of MPU/MCU Products	4
Table of Contents	5
How to use this manual	19
Purpose and target readers	19
Special notations	19
Electrical specifications	19
Additional documents	19
Content of this manual	20
Notation of numbers and symbols	21
Diagrams	22
Trademarks	22
Functional modules descriptions	23
Functional modules abbreviation convention	23
Product specific features	23
Further information	28
Chapter 1 Introduction	29
1.1 V850E2/Fx4-G Product Line Overview	29
1.2 Related Documents	34
1.3 Ordering Information	35
Chapter 2 Port Functions	36
2.1 V850E2/Fx4-G Port Features	36
2.2 Overview	37
2.2.1 Terms	38
2.2.2 Pin function configuration	39
2.2.3 Pin data input/output	41
2.2.4 Port control logic diagram	43
2.3 Port Group Configuration Registers	44
2.3.1 Writing to protected registers	44
2.3.2 Port control registers overview	44
2.3.3 Port function configuration registers	46
2.3.4 Data input/output registers	54
2.3.5 Configuration of electrical characteristics registers	59
2.4 V850E2/Fx4-G Port Groups Configuration	64
2.4.1 Port register protection clusters	64
2.4.2 Common port functions	65
2.4.3 V850E2/FF4-G port functions	68
2.4.4 V850E2/FG4-G port functions	75
2.4.5 Non-port input/output signals	81

2.4.6	Alphabetic pin function list	82
2.4.7	Port and pin functions in stand-by modes	86
2.4.8	Port and pin functions during and after reset	86
2.4.9	Recommended connection of unused pins	87
2.5	Port Filters	89
2.5.1	Port filters assignment	89
2.5.2	Port filters clock supply	93
2.5.3	Port filters reset	94
2.6	Port Filters Functional Description	95
2.6.1	Analog filters	95
2.6.2	Digital filters	98
2.6.3	Filter control registers	102
Chapter 3	CPU System Functions	106
3.1	Overview	106
3.2	Memory Protection Unit (MPU)	107
3.3	CPU Access Bus Structures and Latencies	108
3.3.1	CPU Subsystem modules access	108
3.3.2	PBUS modules access	109
3.3.3	PBUS Synchronizer	112
3.4	CPU Subsystem	115
3.4.1	Power and clock domain	115
3.4.2	CPU Subsystem busses overview	116
3.4.3	CPU Subsystem	117
3.4.4	V850E2 system manual	119
3.5	Data flash wait cycle control	120
3.6	Operation modes	121
3.6.1	Normal operation mode	121
3.6.2	Flash programming mode	121
3.7	Mode pins and JP0 connections	122
3.7.1	Normal operation mode	123
3.7.2	Debug mode	124
3.7.3	Flash programming mode	126
3.8	Address Space	127
3.8.1	CPU data address and physical program address space	127
3.8.2	Program and data space	127
3.9	V850E2/Fx4-G CPU Address Map	129
3.9.1	DMA address map	129
3.9.2	Memory map	130
3.10	Back-up RAM (BURAM)	132
3.10.1	Back-up RAM protection	133
3.11	Write protected Registers	135
3.11.1	Register protection clusters	135
3.11.2	Register protection unlock sequence	136
3.11.3	Register protection and interrupt/emulation break	137
3.11.4	V850E2/Fx4-G write protected registers	137
3.11.5	V850E2/Fx4-G Protection registers overview	139
3.11.6	Control protection clusters registers details	141

3.11.7	Clock monitors protection cluster registers details	143
3.11.8	Port protection clusters registers details	144
3.11.9	Self-programming protection cluster registers details	145
3.11.10	OCD control protection cluster registers details	146
Chapter 4	Interrupt Functions	147
4.1	Exceptions and Interrupts	147
4.2	V850E2/Fx4-G Exceptions	149
4.2.1	Memory error exceptions MEP	149
4.2.2	System error exceptions SYSERR	150
4.2.3	Code flash error correction	154
4.3	V850E2/Fx4-G Interrupt Requests	158
4.3.1	V850E2/Fx4-G interrupt sources	158
4.3.2	FE level non-maskable interrupt sharing	167
4.4	External Interrupts	169
4.4.1	Edge Detection Configuration	169
4.4.2	External interrupts as trigger and wake-up signals	170
4.5	Interrupt Controller Control Registers	171
4.6	Interrupt Acknowledgment and Restoring	181
4.6.1	FE level non-maskable interrupt FENMI	181
4.6.2	FE level maskable interrupt FEINT	183
4.6.3	EI level maskable interrupt INTn	185
4.7	Interrupt Operation	188
4.7.1	Mask function of EI level maskable interrupt INTn	188
4.7.2	Interrupt priority level judgment	188
4.7.3	Priority mask function	194
4.7.4	Pending interrupt report function	194
4.7.5	In-service priority clear function	195
4.8	Exception Handler Address Switching Function	195
Chapter 5	DMA Controller (DMAC)	196
5.1	V850E2/Fx4-G DMA Features	196
5.2	Definition of Terms	198
5.3	General	198
5.3.1	DMA Controller (DMAC) function	198
5.3.2	DMA trigger factor register (DTFR) function	199
5.3.3	DMA access memory map	199
5.3.4	Prioritization of channels	199
5.3.5	Stand-by function	200
5.4	DMAC Function	200
5.4.1	Features	200
5.4.2	DMAC setting registers	202
5.4.3	Enabling or disabling writing control registers	204
5.5	DMA Control Registers	204
5.5.1	DTRC – DMA transfer request control register	204
5.5.2	DSAnL – DMA source address register L	205
5.5.3	DSAnH – DMA source address register H	207
5.5.4	DDAnL – DMA destination address register L	208

5.5.5	DDAnH – DMA destination address register H	210
5.5.6	DTCn – DMA transfer count register	211
5.5.7	DTCTn – DMA transfer control register	212
5.5.8	DTSn – DMA transfer status register	214
5.6	DMAC Function Details	216
5.6.1	DMAC transfer setting flow	216
5.6.2	DMAC transfer modes	217
5.6.3	DMAC channel priority control	219
5.6.4	Valid DMA transfer request conditions	220
5.6.5	Aborting/resuming DMA transfer	221
5.6.6	Error response support	222
5.6.7	Stand-by support	222
5.7	DTFR Function	223
5.7.1	Features	223
5.8	DTFR Control Registers	224
5.8.1	DTFRn – DMA trigger factor register	224
5.8.2	DRQCLR – DMA request clear register	225
5.8.3	DRQSTR – DMA request check register	226
Chapter 6	Flash Memory	227
6.1	Code Flash Memory Overview	227
6.1.1	Code flash memory features	227
6.1.2	Code flash memory map	227
6.1.3	Data flash memory map	229
6.2	Code Flash Memory functional Outline	230
6.2.1	Code flash memory erasure and rewrite	232
6.3	Data Flash Memory	233
6.3.1	Data flash memory features	233
6.3.2	Data flash reading and writing	233
6.4	Flash Programming with Flash Programmer	234
6.4.1	Programming environment	234
6.4.2	Communication modes	235
6.4.3	Pin connection with flash programmer PG-FP5	236
6.4.4	Flash memory programming control	237
6.5	Code Flash Self-Programming	244
6.5.1	Self-Programming enable	245
6.5.2	Self-Programming library functions	246
6.5.3	Self-Programming internal RAM occupancy	246
6.5.4	Secure Self-Programming (boot cluster swapping)	247
6.5.5	Interrupt handling during flash Self-Programming	251
6.6	Flash configuration options	252
6.6.1	OPBT0 - Flash configuration option register 0	253
Chapter 7	Clock Controller	254
7.1	Clock Controller Overview	254
7.2	General Description of Clock Generation and Control	257
7.2.1	Clock generators	260
7.2.2	Clock selectors	261

7.3	Clock Generators	263
7.3.1	Main Oscillator (MainOsc) clock generator	263
7.3.2	Low Speed Internal Oscillator (Low Speed IntOsc) clock generator	266
7.3.3	High Speed Internal Oscillator (High Speed IntOsc) clock generator	267
7.3.4	Phase-Locked Loop (PLL) clock generators	270
7.4	Clock Selection	273
7.4.1	Clock domains of Always-On-Area	276
7.4.2	Clock domains of Isolated-Area-0	278
7.5	Clock Domain Figures	284
7.6	Clock Monitor A (CLMA)	289
7.6.1	V850E2/Fx4-G CLMA features	289
7.6.2	CLMA enable and start-up options	292
7.6.3	Functional Overview	294
7.6.4	Functional Description	295
7.6.5	Clock Monitor registers	299
7.7	Clock Controller Registers	305
7.7.1	Writing to protected registers	305
7.7.2	Clock Controller registers overview	305
7.7.3	Clock generators registers	307
7.7.4	Clock selector control register	319
Chapter 8	Stand-by Controller (STBC)	322
8.1	V850E2/Fx4-G Stand-by Controller Features	322
8.2	Stand-by Controller functions	325
8.2.1	Stand-by Controller signal connections	326
8.2.2	Stand-by modes control	327
8.2.3	Stand-by modes overview	328
8.2.4	Clock generators in stand-by	329
8.2.5	Wake-up	330
8.2.6	I/O buffer control	335
8.2.7	Mode transitions	336
8.3	Stand-by modes entry and exit example flows	337
8.3.1	STOP mode	338
8.3.2	DEEPSTOP mode	341
8.3.3	Application hint: Handling of wake-up events during stand-by mode preparation	344
8.4	Stand-by Controller Registers	347
8.4.1	Writing to protected registers	347
8.4.2	Stand-by Controller registers overview	347
8.4.3	Stand-by Controller control registers details	348
8.4.4	Wake-up factor controller registers details	351
8.4.5	Oscillator wake-up registers details	354
Chapter 9	Wake-up Sequencer (SEQ)	355
9.1	V850E2/Fx4-G SEQ Features	355
9.2	I/O signals port configuration	358
9.3	Functional Overview	359
9.4	Functional description	360

9.4.1	Mode selection	360
9.4.2	Starting and stopping the sequencer	360
9.4.3	Digital input signals selection	360
9.4.4	Event flag	361
9.4.5	CPU processing acceleration	361
9.4.6	Operation clocks	362
9.4.7	Wake-up Sequencer setup	363
9.4.8	Digital input mode	365
9.4.9	Mixed input mode	369
9.5	Wake-up Sequencer registers	376
9.5.1	Wake-up Sequencer registers overview	376
9.5.2	Wake-up Sequencer registers details	377
9.6	Wake-up Sequencer specific operation of TAUJ0	381
9.6.1	TAUJ0 operation overview	381
9.6.2	TAUJ0 register settings	385
Chapter 10	Code Protection and Security	391
10.1	Overview	391
10.2	Flash Programmer and Self-Programming Protection	392
10.3	On-Chip Debug Interface Protection	393
10.3.1	On-Chip Debug enable flag	393
10.3.2	On-Chip Debug ID code	394
10.3.3	On-Chip Debug protection levels summary	394
10.3.4	On-Chip Debug control registers	395
Chapter 11	Reset Controller	398
11.1	Functional Overview	398
11.2	Functional Description	402
11.2.1	Reset flags	402
11.2.2	Power-On Clear (POC)	403
11.2.3	Low-Voltage Indicator (LVI)	404
11.2.4	Very-Low-Voltage Indicator (VLVI)	406
11.2.5	External RESET	408
11.2.6	Watchdog Timers reset (WDTAnRES)	410
11.2.7	Software reset (SWRES)	410
11.2.8	Clock Monitors reset (CLMAnRES)	410
11.2.9	Debugger reset (DBRES)	410
11.3	Reset Controller Registers	411
11.3.1	Writing to protected registers	411
11.3.2	Reset Controller registers overview	411
11.3.3	Reset Controller general control registers details	412
11.3.4	Software reset control registers details	415
11.3.5	Low-Voltage Indicator reset control registers	416
11.3.6	Very Low-Voltage flag control registers	417
Chapter 12	OS Timer (OSTM)	418
12.1	V850E2/Fx4-G OSTM Features	418
12.2	Functional Overview	419

12.3	Functional Description	420
12.3.1	Count clock	421
12.3.2	Interrupt request generation	421
12.3.3	Starting and stopping the timer	422
12.3.4	Interval timer mode	422
12.3.5	Free-run compare mode	426
12.4	OS Timer Registers	428
12.4.1	OS Timer registers overview	428
12.4.2	OS Timer registers details	429
Chapter 13 Window Watchdog Timer A (WDTA)		434
13.1	V850E2/Fx4-G WDTA Features	434
13.2	WDTA Start-up Options	437
13.2.1	V850E2/Fx4-G WDTAn start modes	438
13.3	Functional Overview	439
13.4	Functional Description	440
13.4.1	WDTA after reset release	441
13.4.2	WDTA trigger	444
13.4.3	Error detection	445
13.4.4	75% interrupt output	447
13.4.5	Window function	448
13.5	Application hint: Evaluation of the Watchdog status	449
13.6	WDTA registers	450
13.6.1	WDTA registers overview	450
13.6.2	WDTA registers details	451
Chapter 14 Timer Array Unit B (TAUB)		457
14.1	V850E2/Fx4-G TAUB Features	457
14.2	TAUB0 Input Selections	461
14.3	Functional Overview	469
14.3.1	Terms	471
14.4	Functional Description	472
14.5	General Operating Procedure	474
14.6	Operation Modes	475
14.7	Concepts of Synchronous Channel Operation	476
14.7.1	Rules	476
14.7.2	Simultaneous start and stop of synchronous channel counters	478
14.8	Simultaneous Rewrite	479
14.8.1	Introduction	479
14.8.2	How to control simultaneous rewrite	481
14.8.3	Other general rules of simultaneous rewrite	482
14.8.4	Types of simultaneous rewrite	483
14.9	Channel Output Modes	489
14.9.1	General procedure for specifying a channel output mode	491
14.9.2	Channel output modes controlled independently by TAUBn signals	492
14.9.3	Channel output modes controlled synchronously by TAUBn signals	493

14.10	Start Timing of Operating Modes	496
14.10.1	Interval Timer Mode, Judge Mode, Capture Mode, Up Down Count Mode	496
14.10.2	Event Mode	497
14.10.3	All other operating modes	497
14.11	TAUBnTTOUTm toggle and INTTAUBnIm Generation when Counter start is triggered (MD0-bit)	498
14.12	TAUBnTTINm Edge Detection	500
14.13	Independent Channel Operation Functions	501
14.14	Independent Channel Interrupt Functions	501
14.14.1	Interval Timer Function	502
14.14.2	TAUBnTTINm Input Interval Timer Function	510
14.14.3	One-Pulse Output Function	516
14.15	Independent Channel Signal Measurement Functions	521
14.15.1	TAUBnTTINm Input Pulse Interval Measurement Function	522
14.15.2	TAUBnTTINm Input Signal Width Measurement Function	530
14.15.3	Overflow Interrupt Output Function (During TAUBnTTINm Width Measurement)	538
14.15.4	TAUBnTTINm Input Period Count Detection Function	543
14.15.5	Overflow Interrupt Output Function (During TAUBnTTINm Input Period Count Detection)	549
14.15.6	TAUBnTTINm Input Pulse Interval Judgment Function	554
14.15.7	TAUBnTTINm Input Signal Width Judgment Function	559
14.16	Independent Channel Simultaneous Rewrite Functions	564
14.16.1	Simultaneous Rewrite Trigger Generation Function Type 1	565
14.17	Other Independent Channel Functions	571
14.17.1	External Event Count Function	572
14.17.2	Clock Divide Function	579
14.17.3	TAUBnTTINm Input Position Detection Function	586
14.18	Synchronous Channel Operation Functions	592
14.19	Synchronous PWM Signal Functions Triggered at Regular Intervals	592
14.19.1	PWM Output Function	593
14.19.2	Delay Pulse Output Function	604
14.19.3	AD Conversion Trigger Output Function Type 1	620
14.20	Synchronous PWM Signal Functions Triggered by an External Signal	622
14.20.1	One-Shot Pulse Output Function	623
14.21	Synchronous Triangle PWM Functions	635
14.21.1	Triangle PWM Output Function	636
14.21.2	Triangle PWM Output Function with Dead Time	647
14.21.3	AD Conversion Trigger Output Function Type 2	670
14.22	Registers	672
14.22.1	TAUBn registers overview	672
14.22.2	TAUBn prescaler registers details	673
14.22.3	TAUBn control registers details	675
14.22.4	TAUBn output registers details	685
14.22.5	TAUBn channel output level registers details	688
14.22.6	TAUBn simultaneous rewrite register details	689

14.22.7	TAUBn emulation register	692
Chapter 15	Timer Array Unit J (TAUJ)	693
15.1	V850E2/Fx4-G TAUJ Features	693
15.2	Functional Overview	696
15.2.1	Terms	698
15.3	Functional Description	699
15.4	General Operating Procedure	701
15.5	Operation Modes	702
15.6	Concepts of Synchronous Channel Operation	703
15.6.1	Rules	703
15.6.2	Simultaneous start and stop of synchronous channel counters	705
15.7	Simultaneous Rewrite	706
15.7.1	Introduction	706
15.7.2	How to control simultaneous rewrite	707
15.7.3	Other general rules of simultaneous rewrite	708
15.7.4	Simultaneous rewrite procedure	709
15.8	Channel Output Modes	711
15.8.1	General procedure for specifying a channel output mode	713
15.8.2	Channel output modes controlled independently by TAUJn signals	714
15.8.3	Channel output modes controlled synchronously by TAUJn signals	715
15.9	Start Timing of Operating Modes	716
15.9.1	Interval Timer Mode, Capture Mode	716
15.9.2	Other operating modes	717
15.10	TAUJnTTOUTm Output and INTTAUJnIm Generation when Counter Starts or Restarts	718
15.11	Interrupt Generation upon Overflow	719
15.11.1	Capture Mode	720
15.11.2	Capture and One Count Mode	721
15.11.3	Count Capture Mode	722
15.11.4	Capture and Gate Count Mode	723
15.12	TAUJnTTINm Edge Detection	724
15.13	Independent Channel Operation Functions	725
15.14	Independent Channel Interrupt Functions	725
15.14.1	Interval Timer Function	726
15.14.2	TAUJnTTINm Input Interval Timer Function	733
15.15	Independent Channel Signal Measurement Functions	739
15.15.1	TAUJnTTINm Input Pulse Interval Measurement Function	740
15.15.2	TAUJnTTINm Input Signal Width Measurement Function	747
15.15.3	Overflow Interrupt Output Function (During TAUJnTTINm Width Measurement)	754
15.15.4	TAUJnTTINm Input Period Count Detection Function	759
15.15.5	Overflow Interrupt Output Function (During TAUJnTTINm Input Period Count Detection)	765
15.16	Other Independent Channel Functions	770
15.16.1	TAUJnTTINm Input Position Detection Function	771

15.17 Synchronous PWM Signal Functions Triggered at Regular Intervals	777
15.17.1 PWM Output Function	778
15.18 Registers	789
15.18.1 TAUJn registers overview	789
15.18.2 TAUJn prescaler registers details	790
15.18.3 TAUJn control registers details	793
15.18.4 TAUJn output registers details	803
15.18.5 TAUJn simultaneous rewrite register details	806
15.18.6 TAUJn emulation register	808
Chapter 16 Asynchronous Serial Interface E (URTE)	809
16.1 V850E2/Fx4-G URTEn Features	809
16.2 Functional Overview	812
16.3 Configuration	813
16.4 URTE Registers	814
16.5 Interrupt Request Signals	830
16.5.1 Transmission interrupt request INTUAE _n TIT	830
16.5.2 Reception interrupt request INTUAE _n TIR	831
16.5.3 Status interrupt request INTUAE _n TIS	832
16.6 Operation	832
16.6.1 Data formats	832
16.6.2 BF transmission/reception format	834
16.6.3 BF transmission	836
16.6.4 BF reception	837
16.6.5 Transmission data consistency check	839
16.6.6 URTE _n transmission	840
16.6.7 Continuous transmission procedure	841
16.6.8 URTE _n reception	843
16.6.9 Reception errors	845
16.6.10 Parity types and operations	846
16.6.11 Digital receive data noise filter	847
16.7 Baud Rate Generator	848
Chapter 17 LIN Master Controller (LMA)	849
17.1 V850E2/Fx4-G LMA_n Features	849
17.2 LIN Master Scheduler Counters (CNTA)	853
17.2.1 CNTA _m registers	853
17.3 Functional Overview	855
17.4 Functional Description	857
17.4.1 UART through mode	857
17.4.2 UART buffer mode	858
17.4.3 LIN master modes	864
17.4.4 Automatic checksum function	876
17.4.5 Scheduler	877
17.5 LMA_n Registers	882
17.5.1 LMA _n registers overview	882

17.5.2	LMA n registers details	884
Chapter 18	CAN Controller (FCN)	899
18.1	V850E2/Fx4-G FCN Features	899
18.2	FCN0 and FCN1 connection	905
18.3	CAN baudrate and time quanta	907
18.4	Features	908
18.4.1	Overview of functions	908
18.4.2	Configuration	910
18.5	Internal Registers of CAN Controller	911
18.5.1	CAN Controller configuration	911
18.5.2	CAN Controller Registers Overview	913
18.5.3	Register bit configuration	915
18.6	Bit Set/Clear Function	920
18.7	Control Registers	922
18.7.1	CAN Controller global registers	922
18.7.2	CAN channel registers	931
18.7.3	Message buffer registers	953
18.8	CAN Controller Initialization	962
18.8.1	Initialization of CAN Controller	962
18.8.2	Initialization of message buffer	962
18.8.3	Redefinition of message buffer	962
18.8.4	Transition from initialization mode to operation mode	964
18.9	Message Reception	965
18.9.1	Message reception	965
18.9.2	Receive data read	966
18.9.3	Receive history list function	967
18.9.4	Mask function	969
18.9.5	Multi buffer receive block function	971
18.9.6	Remote frame reception	972
18.10	Message Transmission	974
18.10.1	Message transmission	974
18.10.2	Transmit history list function	976
18.10.3	Automatic block transmission (ABT)	978
18.10.4	Transmission abort process	980
18.10.5	Remote frame transmission	981
18.11	Power Saving Modes	982
18.11.1	CAN Controller sleep mode	982
18.11.2	CAN Controller stop mode	985
18.11.3	Example of using power saving modes	986
18.12	Interrupt Function	987
18.13	Diagnosis Functions and Special Operational Modes	988
18.13.1	Receive-only mode	988
18.13.2	Single-shot mode	989
18.13.3	Self-test mode	990
18.13.4	Receive/transmit operation in each operation mode	991
18.14	Time Stamp Function	992
18.14.1	Time stamp function	992

18.15	Baudrate Settings	993
18.15.1	Baudrate setting conditions	993
18.15.2	Clock prescaler and baudrate generator settings	997
18.16	Operation of the CAN Controller	999
18.16.1	Initialization	999
18.16.2	Message transmission	1005
18.16.3	Message reception	1019
18.16.4	Power save modes	1024
Chapter 19	Clocked Serial Interface G (CSIG)	1031
19.1	V850E2/Fx4-G CSIG Features	1031
19.1.1	Data consistency check	1035
19.2	Functional Overview	1036
19.3	Functional Description	1038
19.3.1	Master/slave mode	1038
19.3.2	Master/slave connections	1039
19.3.3	Transmission clock selection	1041
19.3.4	Data transfer modes	1042
19.3.5	Data length selection	1043
19.3.6	Serial data direction select function	1045
19.3.7	Communication in slave mode	1046
19.3.8	CSIG interrupts	1047
19.3.9	Handshake function	1049
19.3.10	Loop-back mode	1052
19.3.11	Error detection	1053
19.4	CSIG Control Registers	1056
19.5	Operating Procedure Example	1068
Chapter 20	I²C Interface (IICB)	1070
20.1	V850E2/Fx4-G IICB Features	1070
20.2	I²C Interface Port Settings	1072
20.3	Functional Overview	1073
20.4	I²C Bus Mode Functions	1075
20.4.1	Pin configuration	1075
20.5	I²C Bus Definition	1076
20.5.1	Start Condition	1077
20.5.2	Addresses	1077
20.5.3	Extension code	1078
20.5.4	Transfer direction specification	1078
20.5.5	Acknowledge (ACK)	1079
20.5.6	Data	1080
20.5.7	Stop condition	1080
20.5.8	Wait state	1081
20.5.9	Arbitration	1083
20.6	Registers	1084
20.7	Operation	1105
20.7.1	Single transfer mode	1105

20.7.2	Arbitration	1110
20.7.3	Entering and exiting wait state	1111
20.7.4	Extension code	1115
20.8	Interrupt Request Signals	1116
20.8.1	Single transfer mode	1117
20.9	Interrupt Outputs and Statuses	1120
20.9.1	Single transfer mode (master device operation)	1121
20.9.2	Single transfer mode (slave device operation: during slave address reception (IICBnSTR0.IICBnSSC0 bit = 1))	1124
20.9.3	Single transfer mode (slave device operation: during extension code reception (IICBnSTR0.IICBnSSEX bit = 1))	1125
20.9.4	Single transfer mode (non-participation in communications)	1126
20.9.5	Single transfer mode (arbitration loss operation (IICBnSTR0.IICBnALDF bit = 1): operation as slave after arbitration loss)	1127
20.9.6	Single transfer mode (arbitration loss operation (IICBnSTR0.IICBnALDF bit = 1): non-participation in communications after arbitration loss)	1129
20.9.7	Single transfer mode (arbitration loss operation (IICBnSTR0.IICBnALDF bit = 1): non-participation in communications after arbitration loss (during extension code transfer))	1135
20.10	Setting Sequence	1136
20.10.1	Single master environment	1136
Chapter 21	Key Return Function (KR)	1138
21.1	V850E2/Fx4-G KR Features	1138
21.2	Functional Overview	1140
21.3	Functional Description	1141
21.3.1	Interrupt request KRnTIKR	1141
21.4	Registers	1142
21.4.1	Key Return Function registers overview	1142
21.4.2	Key Return Function registers details	1142
Chapter 22	A/D Converter (ADAA)	1143
22.1	V850E2/Fx4-G ADAA Features	1143
22.2	H/W Trigger Expansion	1146
22.2.1	ADAA _n H/W trigger selection	1146
22.2.2	ADAA _n H/W trigger edge selection	1147
22.2.3	ADAA _n H/W trigger tables	1148
22.3	Functional Overview	1150
22.4	Cautions	1152
22.5	Functional Description	1152
22.5.1	Basic Operation	1154
22.5.2	Clock usage	1155
22.5.3	Channels and channel groups	1155
22.5.4	A/D conversion modes	1157
22.5.5	Starting A/D conversion (start trigger modes)	1160
22.5.6	Stopping A/D conversion	1162

22.5.7	Stand-by mode	1164
22.5.8	Pausing and resuming A/D conversion (ADCHALT mode)	1164
22.5.9	Resolution, sampling and conversion times	1165
22.5.10	Interrupt generation	1166
22.5.11	Storage of A/D conversion result	1167
22.5.12	Result check functions	1169
22.5.13	Self-diagnosis function	1171
22.5.14	Discharge function	1173
22.5.15	Stabilization control	1173
22.6	Registers	1174
22.6.1	ADAA registers overview	1174
22.6.2	Control registers details	1176
22.6.3	Conversion status registers	1186
22.6.4	S/W trigger registers details	1190
22.6.5	ADAA conversion result registers details	1192
22.6.6	A/D conversion result upper/lower limit comparison registers details	1199
22.6.7	Diagnose functions registers	1203
22.6.8	Emulation register	1204
Chapter 23	On-chip Debug Unit (OCD)	1205
23.1	V850E2/Fx4-G On-chip Debug Features	1205
23.1.1	Modules behaviour during emulation break	1205
23.1.2	Signal masking	1206
23.2	Functional Overview	1207
23.3	Emulation Break Control	1209
23.4	Connection with On-Chip Debug Emulator	1210
23.5	Cautions on using On-Chip Debugging	1210
Chapter 24	Power Supply	1211
24.1	Power supply pins naming	1211
24.2	Power supply schemes	1212
24.2.1	V850E2/FF4-G power supply scheme	1213
24.2.2	V850E2/FG4-G power supply scheme	1214
24.3	Power supply control	1215
	Revision History	1217
	Index	1218

How to use this manual

Purpose and target readers

This manual is designed to provide the user with an understanding of the hardware functions of the microcontroller. It is intended for users designing application systems incorporating the microcontroller. A basic knowledge of electric circuits, logical circuits, and microcontrollers is necessary in order to use this manual.

Special notations

Following special notations are used throughout this document:

Note Additional remark or tip

Caution Item deserving extra attention

Electrical specifications

This manual does not present any electrical specifications. Refer to the Data Sheet for detailed definitions of all electrical properties. For information about the Data Sheet document, refer to the section “*Related Documents*” in the chapter “*Introduction*”.

Additional documents

Following types of documents are available for the V850E2/Fx4-G microcontrollers. Make sure to refer to the latest versions of these documents. The newest versions of the documents listed may be obtained from the Renesas Electronics Web site.

Document Type	Description	Document
Data sheet	Hardware overview and electrical characteristics	Refer to the section “ <i>Related Documents</i> ” in the chapter “ <i>Introduction</i> ”
User manual: Hardware	Hardware specifications (pin assignments, memory maps, functional modules specifications and operation description) Note: Refer to the application notes for details on using functional modules.	
User manual: 32-bit Microprocessor Core Architecture	Description of CPU, its instruction set and processor protection functions	
Application note	Information on using peripheral functions and application examples, sample programs and information on writing programs in assembly language and C	Available from Renesas Electronics Web site
Renesas technical update	Product specifications, updates on documents, etc.	

Content of this manual

In the following brief hints are given where to find certain information about the V850E2/Fx4-G microcontrollers.

- Product overview** Refer to the chapter “Introduction” for an overview of the features of all target microcontrollers and their block diagrams. Order codes for all devices and a list of related documents is given here as well.
- CPU core functions** The functions of the CPU core (e.g. instruction set, processor protection functions, etc.) are not subject to this manual. Refer to the separate CPU core manual, shown in the section “Related Documents” in the chapter “Introduction”.
- CPU Subsystem functions** The functions of the CPU Subsystem (including address map, operation modes, etc.) are described in the chapter “CPU System Function”. The section “Write protected Registers” in this chapter describes how to deal with registers, that feature special write protection facilities. If the microcontroller has separate bus systems beside the CPU Subsystem to connect certain functional modules, refer to the chapter “Bus Architecture”.
- Port functions** The chapter “Port Functions” describes all input/output port related functions, such as port sharing, I/O buffer control, port filters. The features and electrical properties of the I/O buffers are not subject to this manual, but are described in the Data Sheet.
- Interrupt functions** Refer to the chapter “Interrupt Controller”. Note that the function of each interrupt source is not described here, but in the related chapter of the module, that generates the interrupt.
- DMA/DTS functions** Refer to the chapter “DMA/DTS Controller” or “DMA Controller”, if the target microcontroller does not feature DTS functions. Note that the function of each DMA/DTS trigger source is not described here, but in the related chapter of the module, that generates the trigger signal.
- Flash memory** For microcontrollers with on-chip flash memory refer to the chapter “Flash Memory” for information about the flash memories structure and features, programming facilities, etc.
- Stand-by functions** How to set the microcontroller in stand-by modes and wake it up again is described in the chapter “Stand-by Controller (STBC)”.
- Code protection and security** Facilities to protect program code in on-chip flash memory (if available) from illegal read-out via external flash programming equipment or debuggers is described in the chapter “Code Protection and Security”.

Clock supply	The chapter “Clock Controller” describes the generation and operation of all clocks, provide to the entire microcontroller.
Resets	The sources that can generate reset signals to all or dedicated internal modules and how to control them is described in the chapter “Reset Controller”.
Functional modules	The description of most functional modules, like timers, serial interfaces, etc. is provided in separate chapters. These chapters have a certain structure of information presentation. Refer to the section “ <i>Functional modules descriptions</i> ”.
Debugging	The main features on the On-Chip Debug Unit of the microcontroller is described in the chapter “On-chip Debug Unit (OCD)”. Note that the description of the external debugger tool is not subject to this manual.
Power supply	The chapter “Power Supply” provides information which modules of the microcontrollers are supplied by which external power supply pins. Note that the specification of the external power supply is not subject to this manual. Refer to the Data Sheet for detailed definitions of the power supply.
Boundary scan	If the target microcontroller supports boundary scan testing, refer to the chapter “Boundary Scan” for information about available Boundary Scan features.

Notation of numbers and symbols

Symbols	Symbols and notation are used as follows: <ul style="list-style-type: none"> • Weight in data notation: Left is high order column, right is low order column • Active low notation: $\overline{\text{xxx}}$ (pin or signal name is over-scored) or /xxx (slash before signal name) • Memory map address: High order at high stage and low order at low stage
Numeric notation	<ul style="list-style-type: none"> • Binary: xxxx or xxx_B • Decimal: xxxx • Hexadecimal: xxxx_H or 0x xxxx

Numeric prefixes represent different factors, depending on the measure:

Prefix	Powers of 2	Powers of 10
k (kilo)	–	$10^3 = 1000$
K (Kilo)	$2^{10} = 1024$	–
M (Mega)	$2^{20} = 1024^2 = 1,048,576$	$10^6 = 1000^2 = 1,000,000$
G (Giga)	$2^{30} = 1024^3 = 1,073,741,824$	$10^9 = 1000^3 = 1,000,000,000$
m (milli)	–	$10^{-3} = 0.001$
μ (micro)	–	$10^{-6} = 0.001^2 = 0.000,001$
p (piko)	–	$10^{-9} = 0.001^3 = 0.000,000,001$
	For example used for <ul style="list-style-type: none"> • address and memory spaces in bytes: KB, MB, GB 	For example used for <ul style="list-style-type: none"> • frequencies: kHz, MHz, GHz • times: ms, μs • resistance: kΩ, MΩ • capacitance: μF, pF

Register contents X, x = don't care

Diagrams

Block diagrams do not necessarily show the exact wiring in hardware but the functional structure.

Timing diagrams are for functional explanation purposes only, without any relevance to the real hardware implementation.

Trademarks

All trademarks are the property of their respective owners.

Functional modules descriptions

Most of the chapters provide a technical description of a certain functional module.

These chapters are split into two parts:

- The first section describes all properties of the functional module specific to the target product of the user manual, such as instances, register base addresses, input/output signal names, etc.
- The subsequent sections describe the features of the functional module as a generic description. The generic description is common to all user manuals of products, that feature this module.

Functional modules abbreviation convention

Each functional module has a unique abbreviation, for instance

TAUA for the Timer Array Unit A

This shortcut is used in names for various purposes:

- The module registers and their bits names are preceded by this shortcut, for instance

TAUAnTS for the TAUAn channel start trigger register

The index “n” denotes the instance number of the module, refer to the next section and the key words *“Instances”* and *“Instances index n”*.

- The base address of the module registers include the by this shortcut, for instance

<TAUAn_base> for the base address of the TAUAn registers

- The input/output signals of the module are preceded by this shortcut, for instance

TAUAnTTIN0 for the TAUAn channel 0 input signal

- The names of the module interrupts includes the module shortcut, for instance

INTTAUAnI0 for the TAUAn channel 0 interrupt

Product specific features

The product specific section is always structured by a set of identical key words.

For the naming of signals product specific section serves also as some kind of interface between the generic module description and all other parts of the document.

This means that the names of signals, used in the generic module description, may be translated to other names, that are used in the other document chapters.

This name translation is given in form of tables, as the following as an example:

Module signals	Function	Connected to
Module shortcut:		
Name used in generic module description	Brief functional description	Name used in remaining document

The following lists the key words for product specific definitions. As examples, definitions of different modules are used.

- Cautions**
1. The following product specific definitions are only used as examples and do not define any properties of the target product of this document.
 2. Consequently the functional modules, used for examples purposes, may not be available with the target product of this document.

Instances The devices of the target product may contain different numbers of the functional module, so called instances. The "Instances" paragraph specifies the number of instances for all devices of the target product.

Table 0-1 Example: Instances of TAUAn

Timer Array Unit A	Device_1	Device_2	Device_3
Instance	2	4	2
Name	TAUA0 to TAUA1	TAUA0 to TAUA3	TAUA0 to TAUA1

Instances index n Throughout the following generic module description, an instance of a module is identified by the index "n", for instance

TAUAnTS for the TAUAn channel start trigger register

"n" counts from 0 to the number of instances minus one.

Other indices In case other indices, except "n" for instances, are used throughout the generic module description, they are specified here.

Channel index m Timer Array Unit A has 16 channels. Throughout this chapter, the individual channels are identified by the index "m" (m = 0 to 15), thus a certain channel is denoted as CHm.
The even numbered channels (m = 0, 2, 4, 6, 8, 10, 12, 14) are denoted as CHm_even.
The odd numbered channels (m = 1, 3, 5, 7, 9, 11, 13, 15) are denoted as CHm_odd.

Register addresses All module register addresses in the generic description are given as address offsets to a base address, that is individual to a certain module instance n. For each module instance n the individual base address is given here.

Table 0-2 Example: Register base addresses <TAUAn_base>

TAUAn instance	<TAUAn_base> address
TAUA0	FF80 8000 _H
TAUA1	FF80 9000 _H
TAUA2	FF80 A000 _H
TAUA3	FF80 B000 _H
TAUA4	FF80 C000 _H

Clock supply The clock signals of each instance n of the module and their connection to other functional modules of the device are given here. A figure shows the modules clock supply options.

Table 0-3 Example: TAUAn clock supply

TAUAn instance	TAUAn clock	Connected to
TAUA0	PCLK	Clock Generator CKSCLK_006
TAUA1	PCLK	Clock Generator CKSCLK_104
TAUA2	PCLK	Clock Generator CKSCLK_111
TAUA3	PCLK	Clock Generator CKSCLK_106
TAUA4	PCLK	Clock Generator CKSCLK_105

Interrupts and DMA/DTS The interrupt signals of each instance n of the module and their connections to other functional modules of the device are given here.

Table 0-4 Example: TAUAn interrupt and DMA/DTS requests

TAUAn signals	Function	Connected to
TAUA0:		
INTTAUA010 to INTTAUA017	Channel 0 to 7 interrupt	Interrupt Controller INTTAUA010 to INTTAUA017
INTTAUA018	Channel 8 interrupt	Interrupt Controller INTTAUA018 DMA Controller trigger 15 DTS Controller trigger 9
INTTAUA019 to 15	Channels 9 to 14 interrupt	not connected
TAUA1:		
...

Internal signals Signals of some modules are connected to other device's modules. Such connections are defined here.

Table 0-5 Example: VIn internal signals

VIn signal	Function	Connected to
VIOEN	VIO0 enable	VIO I/F control
ES_VSYNC	VSYNC signal output	MVO0 EVSYNC
ES_HSYNC	HSYNC signal output	MVO0 EHSYNC

H/W reset The signals, that reset each instance n of the module, are listed here.

Table 0-6 Example: TAUAn reset signals

TAUAn	Reset signal
TAUA0	<ul style="list-style-type: none"> Reset Controller SYSRES Reset upon Isolated-Area-0 wake-up from DEEPSTOP mode
TAUA1 to TAUA4	<ul style="list-style-type: none"> Reset Controller SYSRES Reset upon Isolated-Area-1 wake-up from DEEPSTOP mode

I/O signals The input/output signals of each instance n of the module and their connections to ports and other functional modules of the device are given here.

Table 0-7 Example: TAUAn I/O signals

TAUA signal	Function	Connected to
TAUA0:		
TAUA0TTIN0	Channel 0 input	Port TAU000 ^a or FCN0 TSOUT or port URTE0RX ^b
TAUA0TTIN1	Channel 1 input	Port TAU001 ^a or FCN1 TSOUT or port URTE1RX ^b
TAUA0TTIN2 to TAU00TTIN15	Channel 2 to 15 input	Port TAU002 ^a to TAU00115 ^a
TAUA0TTOUT0 to TAU00TTOUT15	Channel 0 to 15 output	Port TAU0000 to TAU00015
TAUA1:		
...

- a) These input signals are passed through a noise filter, refer to the section "Port Filters" in the chapter "Port Functions".
- b) Refer to 15.2 "TAUA Input Selection" on page 662 for details.

Special definitions If the functional module needs any particular definitions for its operation, which are product dependent, these are defined here.

Further information

For further information see <http://www.renesas.com>.

Chapter 1 Introduction

1.1 V850E2/Fx4-G Product Line Overview

(1) V850E2/FF4-G product line overview

Table 1-1 V850E2/FF4-G product series overview (1/2)

Series name:		FF4-G-256K	FF4-G-512K	
Part number:		μPD70F4177	μPD70F4178	
Internal memory	Instruction flash	256 KB	512 KB	
	Data flash	32 KB		
	CPU RAM	32 KB	64 KB	
	Back-up RAM	4 KB		
CPU	CPU core	V850E2		
	CPU frequency	64 MHz max. ^a		
	System Protection Functions (SPF)	MPU	provided	
		SRP	provided	
DMA		8 channels		
Operating clock	Main Oscillator (MainOsc)	4, 5, 6, 10, 12, 16, 20 MHz		
	Low Speed Internal Oscillator (LS IntOsc)	240 kHz typ.		
	High Speed Internal Oscillator (HS IntOsc)	8 MHz typ.		
	PLL0	64 MHz max.		
I/O ports		59		
A/D converter (ADAA0)		1 × 10 channels, 10 bit		
Timers	Timer Array Unit B (TAUB), 16 bit	1 unit × 16 channels		
	Timer Array Unit J (TAUJ), 32 bit	1 unit × 4 channels		
	Window Watchdog (WDTA)	2 channels		
	Operating System Timer (OSTM)	1 channel		
Serial interfaces	CAN I/F (FCN)	3 channel (32 messages buffer)	6 channel (32 messages buffer)	
	UART I/F (URTE) with LIN Master Controller (LM)	2 channels		
	Synchronous I/F (CSIG)	2 channels		
	I ² C I/F (IICB)	1 channel		
External interrupts	Maskable (INTPn)	External	9	
		Internal	61	70
	Non-maskable (NMI)	External	1	
		Internal	2	
Other functions	Power-On-Clear (POC)	provided		
	Clock Monitors (CLMA)	provided for MainOsc, HS IntOsc, PLL0 supervision		
	Key Return (KR)	8 channels		
	On-Chip debug (OCD)	provided		

Table 1-1 V850E2/FF4-G product series overview (2/2)

Series name:		FF4-G-256K	FF4-G-512K
Part number:		μ PD70F4177	μ PD70F4178
Voltage supply	Internal supply	V_{POC} to 5.5 V ^a	
	I/O supply	V_{POC} to 5.5 V ^a	
Operating Temperature		-40° C to +125° C ^a	
Package		80-pin LQFP	

a) Refer to the Data Sheet.




Figure 1-1 V850E2/FF4-G block diagram

(2) V850E2/FG4-G product line overview

Table 1-2 V850E2/FG4-G product series overview

Series name:		FG4-G-256K	FG4-G-512K	
Part number:		μPD70F4179	μPD70F4180	
Internal memory	Instruction flash	256 KB	512 KB	
	Data flash	32 KB		
	CPU RAM	32 KB	64 KB	
	Back-up RAM	4 KB		
CPU	CPU core	V850E2		
	CPU frequency	64 MHz max. ^a		
	System Protection Functions (SPF)	MPU	provided	
SRP		provided		
DMA		8 channels		
Operating clock	Main Oscillator (MainOsc)	4, 5, 6, 10, 12, 16, 20 MHz		
	Low Speed Internal Oscillator (LS IntOsc)	240 kHz typ.		
	High Speed Internal Oscillator (HS IntOsc)	8 MHz typ.		
	PLL0	64 MHz max.		
I/O ports		77		
A/D converter (ADAA0)		1 × 16 channels, 10 bit		
Timers	Timer Array Unit B (TAUB), 16 bit	1 unit × 16 channels		
	Timer Array Unit J (TAUJ), 32 bit	1 unit × 4 channels		
	Window Watchdog (WDTA)	2 channels		
	Operating System Timer (OSTM)	1 channel		
Serial interfaces	CAN I/F (FCN)	3 channel (32 messages buffer)	6 channel (32 messages buffer)	
	UART I/F (URTE) with LIN Master Controller (LM)	3 channels		
	Synchronous I/F (CSIG)	3 channels		
	I ² C I/F (IICB)	1 channel		
External interrupts	Maskable (INTPn)	External	13	
		Internal	67	76
	Non-maskable (NMI)	External	1	
		Internal	2	
Other functions	Power-On-Clear (POC)	provided		
	Clock Monitors (CLMA)	provided for MainOsc, HS IntOsc, PLL0 supervision		
	Key Return (KR)	8 channels		
	On-Chip debug (OCD)	provided		
Voltage supply	Internal supply	V _{POC} to 5.5 V ^a		
	I/O supply	V _{POC} to 5.5 V ^a		
Operating Temperature		-40° C to +125° C ^a		
Package		100-pin LQFP		

a) Refer to the Data Sheet.




Figure 1-2 V850E2/FG4-G block diagram

1.2 Related Documents

Table 1-3 Related documents

Document number ^a	Title
R01US0037EJxxxx	User's Manual: V850E2 32-bit Microcontroller Core Architecture
R01DS0167EJxxxx	FF4-G Data Sheet
R01DS0166EJxxxx	FG4-G Data Sheet
R20UT0008EJxxxx	User's Manual: PG-FP5 Flash Memory Programmer
U17638EJxVxUM00	User's Manual: QB-V850MINI, QB-V850MINIL On-Chip Debug Emulator
R01US0046EDxxxx	User's Manual: Flash Self-Programming Library FSL - T06
<td>	User's Manual: Data Flash Access Library FDL - T06

a) "x" denotes the current document revision numbers.

1.3 Ordering Information

Table 1-4 V850E2/Fx4-G ordering information

Series name	Device name	Renesas order code	Remarks
FF4-G-256K	μPD70F4177	uPD70F4177GK(Ax)-GAK-AX	
FF4-G-512K	μPD70F4178	uPD70F4178GK(Ax)-GAK-AX	
FG4-G-256K	μPD70F4179	uPD70F4179GC(Ax)-UEU-AX	
FG4-G-512K	μPD70F4180	uPD70F4180GC(Ax)-UEU-AX	

Chapter 2 Port Functions

This chapter contains a generic description of the Port control functions.

The first section describes all properties specific to the V850E2/Fx4-G, such as port groups, register base addresses, etc.

The second section describes the features of the port control functions that apply to all ports.

The third section summarizes the individual functions of all pins of V850E2/Fx4-G microcontrollers.

Finally the function of analog and digital filters, which are implemented at some pins, are described.

2.1 V850E2/Fx4-G Port Features

Port groups The V850E2/Fx4-G microcontrollers have following number of port groups:

Table 2-1 Port groups of V850E2/Fx4-G

Port groups	V850E2/FF4-G	V850E2/FG4-G
Number	6	7
Names	P0, P1, P3, P4, P10, JP0	P0, P1, P3, P4, P10, P27, JP0

Port groups index n Throughout this chapter, the individual port groups are identified by the index “n”, for example, PMCn for the port mode control register of Pn.

Register addresses All port and JTAG port control register addresses are given as address offsets from the individual base addresses <PORTn_base> and <JPORT0_base>. The base addresses <PORTn_base> and <JPORT0_base> are specified in the following table:

Table 2-2 Port base addresses <PORTn_base> and <JPORT0_base>

<PORTn_base> address	<JPORT0_base> address
FF40 0000 _H	FF44 0000 _H

2.2 Overview

The microcontroller has various pins for input/output functions, known as ports. The ports are organized in port groups.

The microcontroller also has several control registers to allocate other than general purpose input/output functions to the pins.

For a description of the terms pin, port, or port group, see the following section "*Terms*".

- Features summary**
- Configuration possible for individual pins.
 - The following features can be selected for most of the pins:
 - One out of four input buffer characteristics
 - Output current limit
 - Open drain emulation
 - Pull-up or pull-down resistor connection
 - The following registers are offered for most of the ports:
 - Direct register for reading the pin values
 - Port register
 - Port set/reset register
 - Register for output inversion

2.2.1 Terms

In this chapter, the following terms are used:

- **Pin**

Denotes the physical pin. Every pin is denoted by a unique pin number. The pin numbers depend on the package and are given in the Data Sheet. Most of the pins can be used in several modes. Thus the pin name depends on the selected mode.

- **Port group**

Denotes a group of ports. The ports of a port group have a common set of port mode control registers.

- **Port mode / Port**

A pin in port mode works as a general purpose input/output pin. It is then called "port".

The corresponding name is P_n_m. For example, P0_7 denotes port 7 of port group 0. It is referenced as "port P0_7".

- **Alternative mode**

In alternative mode, a pin can be used for various non-general purpose input/output functions, for example as the input/output pin of on-chip peripherals.

The corresponding pin name depends on the selected function. For example, pin INTP0 denotes the pin for one of the external interrupt inputs.

Note that two different names can refer to the same physical pin, for example P0_0 and INTP0. The different names indicate the function in which the pin is being operated.

JTAG ports The JTAG port group JP0 is used for connecting the debugger for on-chip debugging purposes. Therefore it presents a special port group, as the ports of JP0 are not available for application purposes during a debug session. During normal operation, i.e. without debugger, the JP0 ports can be used in the same way as all others.

The JTAG port group JP0 control registers and their control bits have the same names as the other port groups, registers and bits, but are identified by a "J" prefix.

Note Throughout this chapter the description of all ports and their registers apply also to the JTAG ports, unless otherwise noted.

2.2.2 Pin function configuration

The pins can operate in three different general modes:

- Port mode (PMn.PMn_m = 0)
In port mode the pin operates as a general purpose I/O port. PMn.PMn_m selects input or output.
- S/W I/O control alternative mode (PMn.PMn_m = 1, PIPn.PIPn_m = 0)
In S/W I/O control alternative mode the pin is operated by an alternative function. The selection between input or output is done by S/W via the PMn.PMn_m control bits.
- Direct I/O control alternative mode (PMn.PMn_m = 1, PIPn.PIPn_m = 1)
In direct I/O control alternative mode the pin is operated by an alternative function. In contrast to the S/W I/O control alternative mode the input/output control is also handled by the alternative function, thus the S/W doesn't have to care about.

An overview of the register settings is given in the tables below.

Table 2-3 Pin function configuration (overview)

Mode	Control bits			I/O
	PMn_m	PMn_m	PIPn_m	
Port	0	0	X	O
		1 ^a		I
S/W I/O control alternative	1	0	0	O
		1	0	I
Direct I/O control alternative		X	1	controlled by alternative function

^{a)} The input buffer must be enabled (PIBn.PIBn_m = 1)

If a pin is operated in an alternative mode (PMn.PMn_m = 1), one out of up to four different alternative functions can be selected by the PFCn and PFCEn registers.

Selection of one of the alternative input and output functions:

- S/W I/O control alternative functions (PIPn.PIPn_m = 0):
 - outputs (PMn_m = 0): ALT-OUT1 to ALT-OUT4
 - inputs (PMn_m = 1): ALT-IN1 to ALT-IN4
- Direct I/O control alternative functions (PIPn.PIPn_m = 1):
 - input/out of ALT-OUT1 to ALT-OUT4 and ALT-IN1 to ALT-IN4 is directly controlled by the alternative function

Table 2-4 Alternative mode selection overview (PMn.PMCn_m = 1)

Function	Registers				I/O
	PIPC ^a	PM ^a	PFCE	PFC	
Alternative output mode 1 (ALT-OUT1)	0	0	0	0	O
Alternative input mode 1 (ALT-IN1)		1			I
Alternative output mode 2 (ALT-OUT2)		0	0	1	O
Alternative input mode 2 (ALT-IN2)		1			I
Alternative output mode 3 (ALT-OUT3)		0	1	0	O
Alternative input mode 3 (ALT-IN3)		1			I
Alternative output mode 4 (ALT-OUT4)		0	1	1	O
Alternative input mode 4 (ALT-IN4)		1			I

a) If PIPn.PIPn_m = 1, the I/O direction is directly controlled by the alternative function and PM is ignored.

Caution In case a certain alternative input function is available via multiple ports, only one port must be configured to use this alternative input function. All other ports must be configured to use other signals.

PMn/PMcN register write

The port mode register PMn and port mode control register PMcN can be manipulated in two different ways:

- Direct PMn/PMcN write
New value can be written directly to the PMn/PMcN register.
- Indirect PMn/PMcN bit set/reset
An indirect way to set or reset a PMn/PMcN bit is possible by using following registers:
 - Port mode set reset register PMSRn
If the bit PMSRn.PMSRn(m+16) = 1, the value of bit PMSRn.PMSRn_m determines the value of PMn.PMn_m.
Thus PMn_m can be set/reset without a direct write to PMn.
 - Port mode control set reset register PMCSRn
If the bit PMCSRn.PMCSRn(m+16) = 1, the value of bit PMCSRn.PMCSRn_m determines the value of PMcN.PMn_m.
Thus PMn_m can be set/reset without a direct write to PMcN.

The indirect PMn/PMcN set/reset operation provides access to single bits of the PMn/PMcN register, while leaving all other register bits untouched.

Both ways to manipulate a PMn/PMcN bit can be used concurrently.

Note It is recommended to use the indirect PMn/PMcN bit set/reset method for changing a single bit or concurrently several bits of the PMn/PMcN register, since all other bits are not modified and can be independently treated by other S/W modules, for instance in interrupt service routines.

2.2.3 Pin data input/output

In the following the registers are described, used for data input and output.

Depending on the pin mode, the source of the data to be output and the data read via the PPRn register differs.

Output data In *port mode* (PMcn.PMCn_m = 0) the data of Pn.Pn_m is output to pin Pn_m. In *alternative mode* (PMcn.PMCn_m = 1) the pin Pn_m output is determined by the alternative function.

Input data A read operation of the PPRn register returns either the value of the Pn_m pin, the associated bit of the port register Pn.Pn_m or the data output by an alternative function.

The source of the data read via PPRn depends on the pin mode and the setting of several control bits.

The table below summarizes the different PPRn read modes.

Note PBDCn_m is not included in the table, as it can be set to 1 for reading the Pn_m pin level in all modes.

Table 2-5 PPRn_m read values

PMc n_m	PM n_m	PIBC n_m	PIPC n_m	PODC n_m	Mode	PPRn_m read value	
0	1	0	X	X	Port input, input buffer disabled	Pn.Pn_m register	
		1		X	Port input, input buffer enabled	Pn_m pin	
	0	X		0	Port push-pull output	Pn.Pn_m register ^a	
				1	Port open-drain output		
1	1	X	0	X	S/W I/O control alternative input	Pn_m pin	
				0	S/W I/O control alternative push-pull output	Alternative function output ^a	
				1	S/W I/O control alternative open-drain output		
	X			1	0	Direct I/O control alternative input/ push-pull output	If alternative functions sets port in • input: PPRn_m = Pn_m pin • output: PPRn_m = alternative function output ^a
					1	Direct I/O control alternative input/ open-drain output	

a) If PBDCn_m = 1, Pn_m pin level is read via PPRn_m.

The control registers in the table above have following effects:

- PBDCn.PBDCn_m (see table footnote)
This bit forces to read the Pn_m pin level via PPRn_m, thus enabling a bi-directional mode, where the level of pin Pn_m can also be read back if the port is operated in an output mode.
- PMcn.PMCn_m
This bit selects port mode (PMcn_m = 0) or alternative mode (PMcn_m = 1).

- **PMn.PMn_m**
This bit selects input (PMn_m = 1) or output (PMn_m = 0) in port mode (PMnCn_m = 0) and S/W I/O control alternative function mode (PMnCn_m = 1, PIPCn_m = 0).
- **PIBCn.PIBCn_m**
This bit disables (PIBCn_m = 0) or enables (PIBCn_m = 1) the input buffer in input port mode (PMnCn_m = 0 and PMn_m = 1). If the input buffer is disabled, PPRn_m reads the Pn.Pn_m bit, otherwise the Pn_m pin level is returned.
- **PIPCn.PIPCn_m**
This bit selects between the S/W and direct I/O control alternative mode.
- **PODCn.PODCn_m**
This bit selects between push-pull (PODCn_m = 0) and open-drain (PODCn_m = 1) output.

Pn register write The data to be output via port Pn_m in port mode (PMnCn.PMCn_m = 0) is held in the port register Pn. The Pn data can be manipulated in two different ways:

- **Direct Pn write**
New data can be written directly to the Pn register.
- **Indirect Pn bit set/reset/not**
An indirect way to set (Pn_m = 1), reset (Pn_m = 0), or invert ($\overline{Pn_m} \rightarrow Pn_m$) a Pn bit is possible using two registers:
 - **Port set reset register PSRn**
If the bit PSRn.PSRn(m+16) = 1, the value of bit PSRn.PSRn_m determines the value of Pn.Pn_m.
Thus Pn_m can be set/reset without a direct write to Pn.
 - **Port NOT register PNOTn**
Setting PNOTn.PNOTn_m = 1 inverts the bit Pn.Pn_m without a direct write to Pn_m.

The indirect Pn set/reset/not operation provides access to single bits of the Pn register, while leaving all other Pn bits untouched.

Both ways to manipulate a Pn bit can be used concurrently.

Note It is recommended to use the indirect Pn bit set/reset/not method for changing a single bit or concurrently several bits of the Pn register, since all other bits are not modified and can independently be treated by other S/W modules, for instance in interrupt service routines.

Caution If a port Pn_m

- provides an alternative output ALT_OUTx and input function ALT_INx
- and is used in alternative output mode ALT_OUTx (PMnCn.PMCn_m = 1, PMn.PMn_m = 0)
- and the bi-directional mode is enabled (PBDCn.PBDCn_m = 1) for reading the Pn_m level via PPRn.PPRn_m,

the Pn_m output, i.e. of ALT_OUTx, is internally fed back to the alternative input function ALT_INx.

2.2.4 Port control logic diagram

The following diagram shows the logical circuitry of the port control functions.

Note The diagram is only a logical reference and does not show the real circuitry.




Figure 2-1 Port control logic diagram

The signals to the I/O buffer in the diagram above have the following general function:

Buffer control signal	General function
IS, ISE	input buffer selection
PUON/PDON	pull-up/-down register control
ENO/ENI	output/input buffer enable
DIN/DOUT	port data in/out

2.3 Port Group Configuration Registers

This section starts with an overview of all configuration registers and then presents all registers in detail. The configuration registers are grouped as follows:

- “Pin function configuration registers”
- “Pin data input/output”
- “Configuration of electrical characteristics registers”

2.3.1 Writing to protected registers

Write protected registers are protected from inadvertent write access due to erroneous program execution, etc.

Following port registers feature this special write protection:

- Port open drain control registers PODCn, JPODC0

Refer to the section “Write protected Registers” in the chapter “CPU System Functions” for a detailed description how to write to write protected registers.

2.3.2 Port control registers overview

The following registers are used for the configuration of the individual pins of the port groups:

Note Some of the registers, listed in the table below, are not available for all port groups n. Refer to the section “V850E2/Fx4-G port functions” below for information which registers are available for the individual port groups.

Table 2-6 Registers for port group configuration (1/2)

Register name	Shortcut	Address
Port function configuration:		
Port mode control register	PMcN	<PORTn_base> + 0400 _H + n x 4
	JPMC0	<JPORT0_base> + 0040 _H
Port mode control set reset register	PMCSRn	<PORTn_base> + 0900 _H + n x 4
	JPMCSR0	<JPORT0_base> + 0090 _H
Port IP control register	PIPCn	<PORTn_base> + 4200 _H + n x 4
Port mode register	PMn	<PORTn_base> + 0300 _H + n x 4
	JPM0	<JPORT0_base> + 0030 _H
Port mode set reset register	PMSRn	<PORTn_base> + 0800 _H + n x 4
	JPMSR0	<JPORT0_base> + 0080 _H
Port input buffer control register	PIBCn	<PORTn_base> + 4000 _H + n x 4
	JPIBC0	<JPORT0_base> + 0400 _H
Port function control register	PFCn	<PORTn_base> + 0500 _H + n x 4
	JPFC0	<JPORT0_base> + 0050 _H
Port function control expansion register	PFCEn	<PORTn_base> + 0600 _H + n x 4

Table 2-6 Registers for port group configuration (2/2)

Register name	Shortcut	Address
Data input/output:		
Port bi-direction control register	PBDCn	<PORTn_base> + 4100 _H + n x 4
	JPBDC0	<JPORT0_base> + 0410 _H
Port pin read register	PPRn	<PORTn_base> + 0200 _H + n x 4
	JPPR0	<JPORT0_base> + 0020 _H
Port register	Pn	<PORTn_base> + 0000 _H + n x 4
	JP0	<JPORT0_base> + 0000 _H
Port NOT register	PNOT0	<PORTn_base> + 0700 _H + n x 4
	JPNOT0	<JPORT0_base> + 0070 _H
Port set reset register	PSRn	<PORTn_base> + 0100 _H + n x 4
	JPSR0	<JPORT0_base> + 0010 _H
Configuration of electrical characteristics:		
Pull-up option register	PU _n	<PORTn_base> + 4300 _H + n x 4
	JPU0	<JPORT0_base> + 0430 _H
Pull-down option register	PD _n	<PORTn_base> + 4400 _H + n x 4
	JPD0	<JPORT0_base> + 0440 _H
Port open drain control register	PODC _n	<PORTn_base> + 4500 _H + n x 4
	JPODC0	<JPORT0_base> + 0450 _H
Port input buffer selection register	PIS _n	<PORTn_base> + 4700 _H + n x 4
	JPIS0	<JPORT0_base> + 0470 _H
Port input buffer selection expansion register	PISE _n	<PORTn_base> + 4800 _H + n x 4
	JPISE0	<JPORT0_base> + 0480 _H

<PORTn_base> The base address <PORTn_base> of the port control registers is defined in the first section of this chapter under the key word “Register addresses”.

JTAG port registers The following register descriptions do not explicitly reference the JTAG port registers. However all description apply also to the respective JTAG port registers, but the base address of the JTAG port registers is different:

<JPORT0_base> The base addresses <JPORT0_base> of the JTAG port control registers is defined in the first section of this chapter under the key word “Register addresses”.

Initial register values The initial values after reset release depend on the port, and are not described in the following register descriptions, but are given in the section “V850E2/Fx4-G Port Groups Configuration”.

2.3.3 Port function configuration registers

(1) PMCN/JPMC0 - Port mode control register

This register specifies whether the individual pins of port group n are in port mode or in alternative mode.

Access PMCN: This register can be read/written in 16-bit units.
JPMC0: This register can be read/written in 8-bit units.

Address PMCN: $\langle \text{PORTn_base} \rangle + 0400_{\text{H}} + n \times 4$
JPMC0: $\langle \text{JPORT0_base} \rangle + 0040_{\text{H}}$

Initial Value Refer to the section “V850E2/Fx4-G Port Groups Configuration”.

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
PMC n_15	PMC n_14	PMC n_13	PMC n_12	PMC n_11	PMC n_10	PMC n_9	PMC n_8	PMC n_7	PMC n_6	PMC n_5	PMC n_4	PMC n_3	PMC n_2	PMC n_1	PMC n_0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Note The control bits of the JTAG port register JPMC0 are named JPMC0_[7:0].

Table 2-7 PMCN/JPMC0 register contents

Bit position	Bit name	Function
15 to 0	PMC n_[15:0]	Specifies the operation mode of the corresponding pin: 0: Port mode 1: Alternative mode

- Cautions**
- Setting PMCN.PMCn_m = 1 to use a port in alternative mode does not hand over I/O control to the alternative function. If the alternative function requires direct I/O control, PIPCN.PIPCn_m must also be set to 1.
 - Setting PMCN.PMCn_m = 1 to use a port in alternative mode may also require to configure a port filter, if this port is used as a signal input. The input signal may be passed through a noise filter, that may need to be configured. Refer to the section “Port Filters” in this chapter.

(2) PMCSRn/JPMCSR0 - Port mode control set reset register

This register provides an alternative method to write data to the PMCn register.

The register's upper 16 bit PMCSRn_[31:16] specify which PMCn.PMCn_m bit will be modified by the corresponding bit of the lower 16 bit PMCSRn_[15:0].

Access These registers can be read/written in 32-bit units.

Bits 31 to 16 are always read as 0000_H.

Reading bits 15 to 0 returns the value of register PMCn/JPMC0.

Address PMCSRn: <PORTn_base> + 0900_H + n x 4

JPMCSR0: <JPORT0_base> + 0090_H

Initial Value Refer to the section "V850E2/Fx4-G Port Groups Configuration".

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
PMCSR n_31	PMCSR n_30	PMCSR n_29	PMCSR n_28	PMCSR n_27	PMCSR n_26	PMCSR n_25	PMCSR n_24	PMCSR n_23	PMCSR n_22	PMCSR n_21	PMCSR n_20	PMCSR n_19	PMCSR n_18	PMCSR n_17	PMCSR n_16
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
PMCSR n_15	PMCSR n_14	PMCSR n_13	PMCSR n_12	PMCSR n_11	PMCSR n_10	PMCSR n_9	PMCSR n_8	PMCSR n_7	PMCSR n_6	PMCSR n_5	PMCSR n_4	PMCSR n_3	PMCSR n_2	PMCSR n_1	PMCSR n_0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Note The control bits of the JTAG port register JPMCSR0 are named JPMCSR0_[31:0].

Table 2-8 PMCSRn/JPMCSR0 register contents

Bit position	Bit name	Function
31 to 16	PMCSR n_[31:16]	PMCSRn_m specifies whether the value of the corresponding lower bit PMCSRn_m value is written to PMCn_m: 0: PMCn_m is independent of PMCSRn_m 1: PMCn_m is PMCSRn_m Example: If PMCSRn.PMCSRn_31 = 1, the value of bit PMCSRn.PMCSRn_15 is written to bit PMCn.PMCn_15 and output.
15 to 0	PMCSR n_[15:0]	Specifies the PMCn_m value if the corresponding upper bit PMCSRn_(m+16) is 1: 0: PMCn_m = 0 1: PMCn_m = 1

(3) PIPCN - Port IP control register

This register specifies whether the I/O direction of pin Pn_m is controlled by the port mode register PMn.PMn_m or by an alternative function.

If pin Pn_m is operated in alternative mode (PMcn.PMCn_m = 1) and the alternative function requires to directly control the I/O direction of Pn_m, PIPcn.PIPCn_m must be set to 1 as well. This hands over I/O control to the alternative function and overrules the PMn.PMn_m setting.

Access PIPCN: This register can be read/written in 16-bit units.

Address PIPCN: <PORTn_base> + 4200_H + n x 4

Initial Value Refer to the section "V850E2/Fx4-G Port Groups Configuration".

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
PIPC n_15	PIPC n_14	PIPC n_13	PIPC n_12	PIPC n_11	PIPC n_10	PIPC n_9	PIPC n_8	PIPC n_7	PIPC n_6	PIPC n_5	PIPC n_4	PIPC n_3	PIPC n_2	PIPC n_1	PIPC n_0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 2-9 PIPCN register contents

Bit position	Bit name	Function
15 to 0	PIPC n_[15:0]	Specifies the I/O control mode: 0: I/O mode is selected by PMn.PMn_m (S/W I/O control) 1: I/O mode is selected by peripheral function (direct I/O control)

(4) PMn/JPM0 - Port mode register

The PMn register specifies whether the individual pins of the port group n are in input mode or in output mode.

Access PMn: This register can be read/written in 16-bit units.
JPM0: This register can be read/written in 8-bit units.

Address PMn: <PORTn_base> + 0300_H + n x 4
JPM0: <JPORT0_base> + 0030_H

Initial Value Refer to the section “V850E2/Fx4-G Port Groups Configuration”.

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
PM n_15	PM n_14	PM n_13	PM n_12	PM n_11	PM n_10	PM n_9	PM n_8	PM n_7	PM n_6	PM n_5	PM n_4	PM n_3	PM n_2	PM n_1	PM n_0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Note The control bits of the JTAG port register JPM0 are named JPM0_[7:0].

Table 2-10 PMn/JPM0 register contents

Bit position	Bit name	Function
15 to 0	PM n_[15:0]	Specifies input/output mode of the corresponding pin: 0: Output mode (output enabled) 1: Input mode (output disabled)

- Notes**
- To use a port in input port mode (PMn.PMn_m = 0 and PMn.PMn_m = 1), the input buffer must be enabled (PIBCn.PIBCn_m = 1).
 - By default, PMn_m specifies the I/O direction in port mode (PMn.PMn_m = 0) and alternative mode (PMn.PMn_m=1), since PIPCn.PIPCn_m = 0 after reset.

(5) PMSRn/JPMSR0 - Port mode set reset register

This register provides an alternative method to write data to the PMn register.

The register's upper 16 bit PMSRn_[31:16] specify which PMn.PMn_m bit will be modified by the corresponding bit of the lower 16 bit PMSRn_[15:0].

Access These registers can be read/written in 32-bit units.

Bits 31 to 16 are always read as 0000_H.

Reading bits 15 to 0 returns the value of register PMn/JPM0.

Address PMSRn: <PORTn_base> + 0800_H + n x 4

JPMSR0: <JPORT0_base> + 0080_H

Initial Value Refer to the section "V850E2/Fx4-G Port Groups Configuration".

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
PMSR n_31	PMSR n_30	PMSR n_29	PMSR n_28	PMSR n_27	PMSR n_26	PMSR n_25	PMSR n_24	PMSR n_23	PMSR n_22	PMSR n_21	PMSR n_20	PMSR n_19	PMSR n_18	PMSR n_17	PMSR n_16
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
PMSR n_15	PMSR n_14	PMSR n_13	PMSR n_12	PMSR n_11	PMSR n_10	PMSR n_9	PMSR n_8	PMSR n_7	PMSR n_6	PMSR n_5	PMSR n_4	PMSR n_3	PMSR n_2	PMSR n_1	PMSR n_0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Note The control bits of the JTAG port register JPMSR0 are named JPMSR0_[31:0].

Table 2-11 PMSRn/JPMSR0 register contents

Bit position	Bit name	Function
31 to 16	PMSR n_[31:16]	PMSRn_m specifies whether the value of the corresponding lower bit PMSRn_m value is written to PMn_m: 0: PMn_m is independent of PMSRn_m 1: PMn_m is PMSRn_m Example: If PMSRn.PMSRn_31 = 1, the value of bit PMSRn.PMSRn_15 is written to bit PMn.PMn_15 and output.
15 to 0	PMSR n_[15:0]	Specifies the PMn_m value if the corresponding upper bit PMSRn_(m+16) is 1: 0: PMn_m = 0 1: PMn_m = 1

(6) PIBCn/JPIBC0 - Port input buffer control register

In input port mode (PMnC.PMCn_m = 0 and PMn.PMn_m = 1) this register enables/disables the port pin's input buffer.

Access PIBCn: This register can be read/written in 16-bit units.
JPIBC0: This register can be read/written in 8-bit units.

Address PIBCn: <PORTn_base> + 4000_H + n x 4
JPIBC0: <JPORT0_base> + 0400_H

Initial Value Refer to the section "V850E2/Fx4-G Port Groups Configuration".

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
PIBC n_15	PIBC n_14	PIBC n_13	PIBC n_12	PIBC n_11	PIBC n_10	PIBC n_9	PIBC n_8	PIBC n_7	PIBC n_6	PIBC n_5	PIBC n_4	PIBC n_3	PIBC n_2	PIBC n_1	PIBC n_0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Note The control bits of the JTAG port register JPIBC0 are named JPIBC0_[7:0].

Table 2-12 PIBCn/JPIBC0 register contents

Bit position	Bit name	Function
15 to 0	PIBC n_[15:0]	Enables/disables the input buffer: 0: Input buffer disabled 1: Input buffer enabled

Note When the input buffer is disabled, it does not consume current even when the pin level is Hi-Z state. Thus the pin does not need to be fixed to a high or low level externally.

(7) PFCn/JPFC0 - Port function control register

This register, together with register PFCEn, specifies an alternative function of the pins.

Some alternative functions require direct I/O control of pin Pn_m. For such alternative functions PIPCN.PIPCn_m must be set to 1 as well.

For other alternative functions, input/output must be specified by PMn.PMn_m.

Access PFCn: This register can be read/written in 16-bit units.
JPFC0: This register can be read/written in 8-bit units.

Address PFCn: <PORTn_base> + 0500_H + n x 4
JPFC0: <JPORT0_base> + 0050_H

Initial Value Refer to the section "V850E2/Fx4-G Port Groups Configuration".

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
PFC n_15	PFC n_14	PFC n_13	PFC n_12	PFC n_11	PFC n_10	PFC n_9	PFC n_8	PFC n_7	PFC n_6	PFC n_5	PFC n_4	PFC n_3	PFC n_2	PFC n_1	PFC n_0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Note The control bits of the JTAG port register JPFC0 are named JPFC0_[7:0].

Table 2-13 PFCn/JPFC0 register contents

Bit position	Bit name	Function
15 to 0	PFC n_[15:0]	Specifies the alternative function of a pin. See Table 2-4 "Alternative mode selection overview (PMcn.PMCn_m = 1)" on page 40 for details.

(8) PFCEn - Port function control expansion register

This register, together with register PFCn, specifies an alternative function of the pins.

Some alternative functions require direct I/O control of pin Pn_m. For such alternative functions PIPCN.PIPCN_m must be set to 1 as well.

For other alternative functions, input/output must be specified by PMn.PMn_m.

Access PFCEn: This register can be read/written in 16-bit units.

Address PFCEn: <PORTn_base> + 0600_H + n x 4

Initial Value Refer to the section "V850E2/Fx4-G Port Groups Configuration".

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
PFCE n_15	PFCE n_14	PFCE n_13	PFCE n_12	PFCE n_11	PFCE n_10	PFCE n_9	PFCE n_8	PFCE n_7	PFCE n_6	PFCE n_5	PFCE n_4	PFCE n_3	PFCE n_2	PFCE n_1	PFCE n_0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 2-14 PFCEn register contents

Bit position	Bit name	Function
15 to 0	PFCE n_[15:0]	Specifies the alternative function of a pin. See Table 2-4 "Alternative mode selection overview (PMCN.PMCn_m = 1)" on page 40 for details.

2.3.4 Data input/output registers

(1) PBDCn/JPBDC0 - Port bi-direction control register

This register enables the input buffer of Pn_m, if its output buffer is enabled as well.

Thus the concerned port Pn_m is operated in bi-directional mode and the Pn_m pin level is read via PPRn.PPRn_m.

Note If Pn_m is not configured as output, the input buffer can not be activated via the PBDCn/JPBDCn register.

Access PBDCn: This register can be read/written in 16-bit units.
JPBDC0: This register can be read/written in 8-bit units.

Address PBDCn: <PORTn_base> + 4100_H + n x 4
JPBDC0: <JPORT0_base> + 0410_H

Initial Value Refer to the section “V850E2/Fx4-G Port Groups Configuration”.

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
PBDC n_15	PBDC n_14	PBDC n_13	PBDC n_12	PBDC n_11	PBDC n_10	PBDC n_9	PBDC n_8	PBDC n_7	PBDC n_6	PBDC n_5	PBDC n_4	PBDC n_3	PBDC n_2	PBDC n_1	PBDC n_0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Note The control bits of the JTAG port register JPBDC0 are named JPBDC0_[7:0].

Table 2-15 PBDCn/JPBDC0 register contents

Bit position	Bit name	Function
15 to 0	PBDC n_[15:0]	Enables/disables bi-directional mode of the corresponding pin: 0: Bi-directional mode disabled 1: Bi-directional mode enabled

(2) PPRn/JPPR0 - Port pin read register

This register reflects the actual level of pin Pn_m, the value of the Pn.Pn_m bit or the level of an alternative output function. The value which is read depends on various control settings as described in *Table 2-5 “PPRn_m read values” on page 41*.

Access PPRn: This register can be read/written in 16-bit units.
JPPR0: This register can be read/written in 8-bit units.

Address PPRn: <PORTn_base> + 0200_H + n x 4
JPPR0: <JPORT0_base> + 0020_H

Initial Value Refer to the section “V850E2/Fx4-G Port Groups Configuration”.

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
PPR n_15	PPR n_14	PPR n_13	PPR n_12	PPR n_11	PPR n_10	PPR n_9	PPR n_8	PPR n_7	PPR n_6	PPR n_5	PPR n_4	PPR n_3	PPR n_2	PPR n_1	PPR n_0
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Note The control bits of the JTAG port register JPPR0 are named JPPR0_[7:0].

Table 2-16 PPRn/JPPR0 register contents

Bit position	Bit name	Function
15 to 0	PPR n_[15:0]	Pin Pn_m, Pn.Pn_m value or alternative function output.

(3) Pn/JP0 - Port register

This register holds the data Pn.Pn_m to be output via the related port Pn_m in output port mode (PMcn.PMCn_m = 0 and PMn.PMn_m = 0).

Access Pn: This register can be read/written in 16-bit units.
JP0: This register can be read/written in 8-bit units.

Address Pn: <PORTn_base> + 0000_H + n x 4
JP0: <JP0T0_base> + 0000_H

Initial Value Refer to the section "V850E2/Fx4-G Port Groups Configuration".

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
P n_15	P n_14	P n_13	P n_12	P n_11	P n_10	P n_9	P n_8	P n_7	P n_6	P n_5	P n_4	P n_3	P n_2	P n_1	P n_0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Note The control bits of the JTAG port register JP0 are named JP0_[7:0].

Table 2-17 Pn/JP0 register contents

Bit position	Bit name	Function
15 to 0	P n_[15:0]	Sets the output level of pin m (m = 0 to 15): 0: Outputs low level 1: Outputs high level

Note The bits of this register can be manipulated by different means, refer to 2.2.3 "Pin data input/output" on page 41 under the keyword "Pn register write".

(4) PNOTn/JPNOT0 - Port NOT register

This register allows to invert a bit Pn_m of the port register Pn without directly writing to Pn.

Access PNOTn: This register can be read/written in 16-bit units.
JPNOT0: This register can be read/written in 8-bit units.
These registers are always read as 0000_H.

Address PNOTn: <PORTn_base> + 0700_H + n x 4
JPNOT0: <JPORT0_base> + 0070_H

Initial Value Refer to the section “V850E2/Fx4-G Port Groups Configuration”.

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
PNOT n_15	PNOT n_14	PNOT n_13	PNOT n_12	PNOT n_11	PNOT n_10	PNOT n_9	PNOT n_8	PNOT n_7	PNOT n_6	PNOT n_5	PNOT n_4	PNOT n_3	PNOT n_2	PNOT n_1	PNOT n_0
W	W	W	W	W	W	W	W	W	W	W	W	W	W	W	W

Note The control bits of the JTAG port register JPNOT0 are named JPNOT0_[7:0].

Table 2-18 PNOTn/JPNOT0 register contents

Bit position	Bit name	Function
15 to 0	PNOT n_[15:0]	Specifies if Pn.Pn_m is inverted: 0: Pn.Pn_m is not inverted (Pn_m → Pn_m) 1: Pn.Pn_m is inverted (Pn_m → Pn_m)

(5) PSRn/JPSR0 - Port set reset register

This register provides an alternative method to write data to the Pn register.

The register's upper 16 bit PSRn_[31:16] specify which Pn.Mn_m bit will be modified by the corresponding bit of the lower 16 bit PSRn_[15:0].

Access These registers can be read/written in 32-bit units.

Bits 31 to 16 are always read as 0000_H.

Reading bits 15 to 0 returns the value of register Pn/JP0.

Address PSRn: <PORTn_base> + 0100_H + n x 4

JPSR0: <JPORT0_base> + 0010_H

Initial Value Refer to the section "V850E2/Fx4-G Port Groups Configuration".

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
PSR n_31	PSR n_30	PSR n_29	PSR n_28	PSR n_27	PSR n_26	PSR n_25	PSR n_24	PSR n_23	PSR n_22	PSR n_21	PSR n_20	PSR n_19	PSR n_18	PSR n_17	PSR n_16
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
PSR n_15	PSR n_14	PSR n_13	PSR n_12	PSR n_11	PSR n_10	PSR n_9	PSR n_8	PSR n_7	PSR n_6	PSR n_5	PSR n_4	PSR n_3	PSR n_2	PSR n_1	PSR n_0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Note The control bits of the JTAG port register JPSR0 are named JPSR0_[31:0].

Table 2-19 PSRn/JPSR0 register contents

Bit position	Bit name	Function
31 to 16	PSR n_[31:16]	PSRn_m specifies whether the value of the corresponding lower bit PSRn_m value is written to Pn_m: 0: Pn_m is independent of PSRn_m 1: Pn_m is PSRn_m Example: If PSRn.PSRn31 = 1, the value of bit PSRn.PSRn_15 is written to bit Pn.Pn_15 and output. Reading of PSRn_[31:0] returns always 0000 _H .
15 to 0	PSR n_[15:0]	Specifies the Pn_m value if the corresponding upper bit PSRn_(m+16) is 1: 0: Pn_m = 0 1: Pn_m = 1 Reading of PSRn_[15:0] returns the value of the Pn register.

2.3.5 Configuration of electrical characteristics registers

(1) PUn/JPU0 - Pull-up option register

This register specifies whether a pull-up resistor is connected to an input pin.

Access PUn: This register can be read/written in 16-bit units.
JPU0: This register can be read/written in 8-bit units.

Address PUn: <PORTn_base> + 4300_H + n x 4
JPU0: <JPORT0_base> + 0430_H

Initial Value Refer to the section “V850E2/Fx4-G Port Groups Configuration”.

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
PU n_15	PU n_14	PU n_13	PU n_12	PU n_11	PU n_10	PU n_9	PU n_8	PU n_7	PU n_6	PU n_5	PU n_4	PU n_3	PU n_2	PU n_1	PU n_0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Note The control bits of the JTAG port register JPU0 are named JPU0_[7:0].

Table 2-20 PUn/JPU0 register contents

Bit position	Bit name	Function
15 to 0	PU n_[15:0]	Specifies whether a pull-up resistor is connected to the corresponding pin: 0: No pull-up resistor connected 1: Pull-up resistor connected

- Notes**
1. If a pin is configured that both a pull-up resistor (PUn.PUn_m = 1) and a pull-down resistor (PDn.PDn_m = 1) are connected, the pull-down resistor is automatically selected and the pull-up resistor is not connected.
 2. The pull-up resistor has no effect when the pin is operated in output mode.

(2) PDn/JPD0 - Pull-down option register

This register specifies whether a pull-down resistor is connected to an input pin.

Access PDn: This register can be read/written in 16-bit units.
JPD0: This register can be read/written in 8-bit units.

Address PDn: <PORTn_base> + 4400_H + n x 4
JPD0: <JPORT0_base> + 0440_H

Initial Value Refer to the section "V850E2/Fx4-G Port Groups Configuration".

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
PD n_15	PD n_14	PD n_13	PD n_12	PD n_11	PD n_10	PD n_9	PD n_8	PD n_7	PD n_6	PD n_5	PD n_4	PD n_3	PD n_2	PD n_1	PD n_0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Note The control bits of the JTAG port register JPD0 are named JPD0_[7:0].

Table 2-21 PDn/JPD0 register contents

Bit position	Bit name	Function
15 to 0	PD n_[15:0]	Specifies whether a pull-down resistor is connected to the corresponding pin: 0: No pull-down resistor connected 1: Pull-down resistor connected

- Notes**
1. If a pin is configured that both a pull-up resistor (PUn.PUn_m = 1) and a pull-down resistor (PDn.PDn_m = 1) are connected, the pull-down resistor is automatically selected and the pull-up resistor is not connected.
 2. The pull-down resistor has no effect when the pin is operated in output mode.

(3) PODCn/JPODC0 - Port open drain control register

This register selects push-pull or open-drain as output buffer function.

Protection Writing to this register is protected by a special sequence of instructions. Refer to the section “*Write protected Registers*” in the chapter “*CPU System Functions*” for a detailed description how to write to write protected registers.

Access These registers can be read/written in 32-bit units. The bits 31 to 16 must always be written with “0” and “0” is returned when read.

Address PODCn: <PORTn_base> + 4500_H + n x 4
JPODC0: <JPORT0_base> + 0450_H

Initial Value Refer to the section “*V850E2/Fx4-G Port Groups Configuration*”.

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
PODC n_15	PODC n_14	PODC n_13	PODC n_12	PODC n_11	PODC n_10	PODC n_9	PODC n_8	PODC n_7	PODC n_6	PODC n_5	PODC n_4	PODC n_3	PODC n_2	PODC n_1	PODC n_0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Note The control bits of the JTAG port register JPODC0 are named JPODC0_[31:0].

Table 2-22 PODCn/JPODC0 register contents

Bit position	Bit name	Function
15 to 0	PODC n_[15:0]	Specifies the output buffer function: 0: Push-pull 1: Open-drain

(4) PISn/JPIS0 - Port input buffer selection register

This register specifies the input buffer characteristics.

A port can have up to four different input buffer characteristics.

The type of input characteristic is selected by the

- port input buffer selection register PISn
- port input buffer selection expansion register PISEn

Table 2-23 Port input buffer characteristic selection

PISEn_m	PISn_m	Input buffer characteristic
0	0	Setting prohibited
	1	Schmitt2 (type 2)
1	0	Schmitt1 (type 3)
	1	Schmitt4 (type 4)

Refer to the Data Sheet for electrical characteristics of the different types and which types are available for each port.

Access PISn: This register can be read/written in 16-bit units.
JPIS0: This register can be read/written in 8-bit units.

Address PISn: <PORTn_base> + 4700_H + n x 4
JPIS0: <JPORT0_base> + 0470_H

Initial Value Refer to the section “V850E2/Fx4-G Port Groups Configuration”.

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
PIS n_15	PIS n_14	PIS n_13	PIS n_12	PIS n_11	PIS n_10	PIS n_9	PIS n_8	PIS n_7	PIS n_6	PIS n_5	PIS n_4	PIS n_3	PIS n_2	PIS n_1	PIS n_0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Note The control bits of the JTAG port register JPIS0 are named JPIS0_[7:0].

Table 2-24 PISn/JPIS0 register contents

Bit position	Bit name	Function
15 to 0	PIS n_[15:0]	Specifies the input buffer characteristic of port m (m = 0 to 15) together with the bits PISEn[15:0].

(5) PISEn/JPISn - Port input buffer selection expansion register

This register specifies the input buffer characteristics together with the port input selection register PISn.

If a port has up to five input buffer characteristics, the port input selection advanced register PISAn is also valid.

Access PISEn: This register can be read/written in 16-bit units.
JPISn: This register can be read/written in 8-bit units.

Address PISEn: <PORTn_base> + 4800_H + n x 4
JPISn: <JPORT0_base> + 0480_H

Initial Value Refer to the section "V850E2/Fx4-G Port Groups Configuration".

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
PISE n_15	PISE n_14	PISE n_13	PISE n_12	PISE n_11	PISE n_10	PISE n_9	PISE n_8	PISE n_7	PISE n_6	PISE n_5	PISE n_4	PISE n_3	PISE n_2	PISE n_1	PISE n_0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Note The control bits of the JTAG port register JPISn are named JPISn_[7:0].

Table 2-25 PISEn/JPISn register contents

Bit position	Bit name	Function
15 to 0	PISE n_[15:0]	Specifies the input buffer characteristic of port m (m = 0 to 15) together with the bits PISn[15:0]. Refer to the PISn register description for how to select the input buffer characteristic.

2.4 V850E2/Fx4-G Port Groups Configuration

This section provides

- an overview of the port register protection clusters, refer to the section “*Port registers protection clusters*”
- general information for all ports , refer to the section “*Common port functions*”
- details of all port groups and their associated control registers for each device, refer to the sections
 - “*V850E2/FF4-G port functions*”
 - “*V850E2/FG4-G port functions*”
- a list of input/output signals with port functionality, refer to the section “*Non-port input/output signals*”
- an alphabetic pin functions list and the ports, the functions can be assigned to, refer to the section “*Alphabetic pin function list*”
- a description of the port status during and after reset and in stand-by modes, refer to the section “*Port functions during/after reset and in stand-by modes*”
- recommendations concerning unused pins, refer to the section “*Recommended connection of unused pins*”.

2.4.1 Port register protection clusters

Several registers of certain port groups n are bundled in port protection clusters:

Table 2-26 Port protection clusters

Port protection cluster	Port groups
1	JP0
2	P0
3	P1, P3, P4, P10, P27

For further information concerning port register protection refer to the section “*Write protected Registers*” in the chapter “*CPU System Functions*” for a detailed description how to write to write protected registers.

2.4.2 Common port functions

This section provides information about special port functions, common to all devices.

(1) Initialization of port control registers

The port control registers are initialized by the following reset signals:

Table 2-27 Port control registers reset signals

Port group	Power domain	Reset signal
JP0, P0	Always-On-Area	• Reset Controller SYSRES
P1, P3, P4, P10, P27	Isolated-Area-0	• Reset Controller SYSRES • Stand-by Controller DPSTPWU (wake-up from DEEPSTOP mode)

(2) JP_0 to JP_5: Debug interface

If the debug reset $\overline{\text{DCUTRST}}$ is at high level at reset release, the port of the JP0 port group are used for the debugger interface:

- JP0_0: DCUTDI input
- JP0_1: DCUTDO output
- JP0_2: DCUTCK input
- JP0_3: DCUTMS
- JP0_4: $\overline{\text{DCUTRST}}$
- JP0_5: $\overline{\text{DCUTRDY}}$

Consequently all port and alternative modes on these pins can not be used while the debugger is connected.

Refer to the chapter “*On-chip Debug Unit (OCD)*” and the section “*Operation Modes*” of chapter “*CPU System Functions*” for details.

Note In order to connect the debugger via the JP0 pins the flash mask option OPBT0.OPBT0[31] has to be set to 1.

(3) JP0_0, JP0_1, JP0_2: Flash programmer

These ports are used for connecting a flash programmer.

Refer to the chapter “*Flash Memory*” and the section “*Operation Modes*” of chapter “*CPU System Functions*” for details.

(4) Mode pins

Following ports are used as mode setting signals in combination with the FLMD0 pin:

- P0_1: FLMD1

Refer to the section “*Operation Modes*” of chapter “*CPU System Functions*” for details.

(5) Permanent inputs

Permanent input means, that the input to a port is unconditionally connected to another module. Thus settings of the port control registers do not impact this connection.

Following ports are permanently connected to dedicated function modules:

Table 2-28 Permanent input functions

Port	Permanent input to	Port	Permanent input to
P10_0	ADAA010	P10_8	ADAA018
P10_1	ADAA011	P10_9	ADAA019
P10_2	ADAA012	P10_10	ADAA0110
P10_3	ADAA013	P10_11	ADAA0111
P10_4	ADAA014	P10_12	ADAA0112
P10_5	ADAA015	P10_13	ADAA0113
P10_6	ADAA016	P10_14	ADAA0114
P10_7	ADAA017	P10_15	ADAA0115

Note If the ports of the port group P10 shall be used in input port mode, set ADAA0CTL1.ADAA0GPS = 1.

(6) Direct I/O control (PIPC)

Some modules take over the input and output control of the used ports automatically.

These ports have to be set in alternative mode by setting `PMn.PMn_m`, `PFCn.PFCn_m` and `PFCEn.PFCEn_m` accordingly and I/O control has to be handed over to the module by setting

`PIPCn.PIPCn_m = 1`.

The setting of `PMn.PMn_m` has no more effect for these ports.

The following table lists all alternative modes, where `PIPCn.PIPCn_m` has to be set to 1.

Note that not all functions in the table below are available for all devices.

Table 2-29 Alternative modes with `PIPCn.PIPCn_m = 1`

Port	Function	Alternative mode
Clocking Serial Interfaces G (CSIG):		
P0_14	CSIG0SO	ALT_OUT4
P0_15	CSIG0SC	ALT_IN4/ALT_OUT4
P3_5	CSIG0SC	ALT_IN4/ALT_OUT4
P3_6	CSIG0SO	ALT_OUT4
P4_4	CSIG0SO	ALT_OUT2
P4_5	CSIG0SC	ALT_IN2/ALT_OUT2
P0_1	CSIG4SO	ALT_OUT2
P0_3	CSIG4SC	ALT_IN2/ALT_OUT2
P4_7	CSIG4SO	ALT_OUT2
P4_8	CSIG4SC	ALT_IN2/ALT_OUT2
P1_3	CSIG7SO	ALT_OUT4
P1_4	CSIG7SC	ALT_IN4/ALT_OUT4

2.4.3 V850E2/FF4-G port functions

This section summarizes all port functions of the V850E2/FF4-G devices and its port control registers.

(1) V850E2/FF4-G general I/O functions

The table below shows all alternative functions, that can be applied to the V850E2/FF4-G ports.

It also gives the settings of the control bits $PMCn_m$, $PFCn_m$, $PFCEn_m$ and PMn_m to the respective port into the different modes.

Table 2-30 V850E2/FF4-G general I/O functions (1/3)

Port mode	Alternative mode							
$PMCn_m = 0$	$PMCn_m = 1$							
	$PFCEn_m = 0, PFCn_m = 0$		$PFCEn_m = 0, PFCn_m = 1$		$PFCEn_m = 1, PFCn_m = 0$		$PFCEn_m = 1, PFCn_m = 1$	
	$PMn_m = 1$	$PMn_m = 0$	$PMn_m = 1$	$PMn_m = 0$	$PMn_m = 1$	$PMn_m = 0$	$PMn_m = 1$	$PMn_m = 0$
	ALT_IN1	ALT_OUT1	ALT_IN2	ALT_OUT2	ALT_IN3	ALT_OUT3	ALT_IN4	ALT_OUT4
Port group 0 (Always-On-Area, E0VDD/E0VSS power supply):								
P0_0	DPIN0		CSIG4SSI		ADCA0 TRG0		INTP0	
P0_1	DPIN1		CSIG4 DCS ^c	CSIG4SO			INTP1	TAUB001
P0_2	DPIN2		CSIG4SI		ADCA0 TRG2		INTP2	TAUB002
P0_3	DPIN3		CSIG4SC ^a		ADCA0 TRG1		INTP3	
P0_4	DPIN4	FCN0TX					INTP11	
P0_5	FCN0RX/ DPIN5						INTP12	
P0_6	FCN1RX/ DPIN6	URTE11TX	KR0I1		NMI			
P0_7	URTE11RX/ DPIN7	FCN1TX	KR0I2		INTP4			
P0_8	DPIN8	URTE10TX	KR0I3	FCN3TX ^b		TAUB005	IICB0SDA ^a	
P0_9	URTE10RX/ DPIN9	FCN2TX	KR0I4		INTP6	TAUB006	IICB0SCL ^a	
P0_10	DPIN10	URTE11TX	FCN3RX ^b					
P0_11	DPIN11		FCN2RX					
P0_12	TAUJ0I0/ DPIN12	TAUJ0O0	KR0I0		INTP8	FCN4TX ^b	CSIG0SSI	
P0_13	TAUJ0I1/ DPIN13	TAUJ0O1	KR0I5			FCN5TX ^b	CSIG0SI	
P0_14	TAUJ0I2	TAUJ0O2/ DPO	KR0I6		FCN5RX ^b		CSIG0DCS ^c	CSIG0SO
P0_15	TAUJ0I3	TAUJ0O3/APO	KR0I7		FCN4RX ^b		CSIG0SC ^a	

Table 2-30 V850E2/FF4-G general I/O functions (2/3)

Port mode	Alternative mode							
PMC _n m = 0	PMC _n m = 1							
	PFCE _n m = 0, PFC _n m = 0		PFCE _n m = 0, PFC _n m = 1		PFCE _n m = 1, PFC _n m = 0		PFCE _n m = 1, PFC _n m = 1	
	PM _n m = 1	PM _n m = 0	PM _n m = 1	PM _n m = 0	PM _n m = 1	PM _n m = 0	PM _n m = 1	PM _n m = 0
	ALT_IN1	ALT_OUT1	ALT_IN2	ALT_OUT2	ALT_IN3	ALT_OUT3	ALT_IN4	ALT_OUT4
Port group 1 (Isolated-Area-0, E1VDD/E1VSS power supply):								
P1_1	TAUB011	TAUB001					FCN1RX	FCN0TX
P1_2	TAUB012	TAUB002						FCN1TX
P1_3	TAUB013	TAUB003	FCN3RX ^b					
P1_4	TAUB014	TAUB004		FCN3TX ^b				
P1_5	TAUB015	TAUB005	FCN4RX ^b					
P1_6	TAUB016	TAUB006		FCN4TX ^b				
P1_7	TAUB017	TAUB007					FCN0RX	
P1_8	TAUB018	TAUB008					FCN2RX	
P1_9	TAUB019	TAUB009	INTP3					FCN2TX
P1_10	TAUB0110	TAUB0010	FCN5RX ^b				INTP4	
P1_11	TAUB0111	TAUB0011		FCN5TX ^b				
Port group 3 (Isolated-Area-0, E1VDD/E1VSS power supply):								
P3_4			TAUB014	TAUB004	KR015		CSIG0RYI	CSIG0RYO
P3_5			TAUB015	TAUB005	KR014		CSIG0SC ^a	
P3_6			TAUB016	TAUB006			CSIG0DCS ^c	CSIG0SO
P3_7			TAUB017	TAUB007			CSIG0SI	
Port group 4 (Isolated-Area-0, E1VDD/E1VSS power supply):								
P4_0			TAUB0113	TAUB0013			FCN0RX	
P4_1			TAUB0114	TAUB0014				FCN0TX
P4_2			TAUB0115	TAUB0015			FCN1RX	
P4_3			CSIG0SI	URTE10TX				FCN1TX
P4_4	INTP2		URTE10RX	CSIG0SO			FCN2RX	
P4_5			CSIG0SC ^a		KR013			FCN2TX
P4_6			CSIG4SI	URTE11TX	KR012		FCN3RX ^b	
P4_7	INTP4		URTE11RX	CSIG4SO	KR011			FCN3TX ^b
P4_8			CSIG4SC ^a		KR010		FCN4RX ^b	
P4_9				CSIG0RYO				FCN4TX ^b
P4_10			CSIG4RYI				FCN5RX ^b	
P4_11								FCN5TX ^b

Table 2-30 V850E2/FF4-G general I/O functions (3/3)

Port mode	Alternative mode							
PMCn_m = 0	PMCn_m = 1							
	PFCEn_m = 0, PFCn_m = 0		PFCEn_m = 0, PFCn_m = 1		PFCEn_m = 1, PFCn_m = 0		PFCEn_m = 1, PFCn_m = 1	
	PMn_m = 1	PMn_m = 0	PMn_m = 1	PMn_m = 0	PMn_m = 1	PMn_m = 0	PMn_m = 1	PMn_m = 0
	ALT_IN1	ALT_OUT1	ALT_IN2	ALT_OUT2	ALT_IN3	ALT_OUT3	ALT_IN4	ALT_OUT4
Port group 10 (Isolated-Area-0, A0VDD/A0VSS power supply):								
P10_3								
P10_4								
P10_5								
P10_6								
P10_7								
P10_8								
P10_9	ADCA0 TRG0							
P10_10	ADCA0 TRG1							
P10_11	ADCA0 TRG2							
P10_12								
Port group JP0 (Always-On-Area, E0VDD/E0VSS power supply):								
JP0_0	INTP0		TAUJ0I0	TAUJ0O0				
JP0_1	INTP1		TAUJ0I1	TAUJ0O1				
JP0_2	INTP2		TAUJ0I2	TAUJ0O2				
JP0_3	INTP3		TAUJ0I3	TAUJ0O3				
JP0_4								
JP0_5	NMI							

- To use this alternative function, set the PIPCn.PIPCnm bit to 1. Input or output is not affected by the PMn.PMnm bit setting.
- This alternative function is not available in μ PD70F4177.
- To use this alternative function, set the CSIGNCTL1.CSIGNDCS bit to 1 (Data Consistency Check enable) and also set the PIPCn.PIPCnm or PBDCn.PBDCnm bit to 1. Data consistency check is not affected by the PMn.PMnm bit setting.

(2) V850E2/FF4-G port control registers

The following table summarizes all V850E2/FF4-G port control registers, their addresses and initial values.

Tables legend

- A: Register address
- I: Initial value
- B: Available bits
 - 1: available, x: not available
 - right: bit 0, left: bit 15

Table 2-31 V850E2/FF4-G port (groups 0, 1, 3, 4) control registers (1/2)

Register	Port group n =				
		0	1	3	4
Pn	A:	FF40 0000 _H	FF40 0004 _H	FF40 000C _H	FF40 0010 _H
	I:	0000 _H	0000 _H	0000 _H	0000 _H
	B:	1111 1111 1111 1111	xxxx 1111 1111 111x	xxxx xxxx 1111 xxxx	xxxx 1111 1111 1111
PSRn	A:	FF40 0100 _H	FF40 0104 _H	FF40 010C _H	FF40 0110 _H
	I:	0000 0000 _H	0000 0000 _H	0000 0000 _H	0000 0000 _H
	B:	1111 1111 1111 1111	xxxx 1111 1111 111x	xxxx xxxx 1111 xxxx	xxxx 1111 1111 1111
PNOTn	A:	FF40 0700 _H	FF40 0704 _H	FF40 070C _H	FF40 0710 _H
	I:	0000 _H	0000 _H	0000 _H	0000 _H
	B:	1111 1111 1111 1111	xxxx 1111 1111 111x	xxxx xxxx 1111 xxxx	xxxx 1111 1111 1111
PPRn	A:	FF40 0200 _H	FF40 0204 _H	FF40 020C _H	FF40 0210 _H
	I:	0000 _H	0000 _H	0000 _H	0000 _H
	B:	1111 1111 1111 1111	xxxx 1111 1111 111x	xxxx xxxx 1111 xxxx	xxxx 1111 1111 1111
PMn	A:	FF40 0300 _H	FF40 0304 _H	FF40 030C _H	FF40 0310 _H
	I:	FFFF _H	FFFF _H	FFFF _H	FFFF _H
	B:	1111 1111 1111 1111	xxxx 1111 1111 111x	xxxx xxxx 1111 xxxx	xxxx 1111 1111 1111
PMCn	A:	FF40 0400 _H	FF40 0404 _H	FF40 040C _H	FF40 0410 _H
	I:	0000 _H	0000 _H	0000 _H	0000 _H
	B:	1111 1111 1111 1111	xxxx 1111 1111 111x	xxxx xxxx 1111 xxxx	xxxx 1111 1111 1111
PFCn	A:	FF40 0500 _H	FF40 0504 _H	FF40 050C _H	FF40 0510 _H
	I:	0000 _H	0000 _H	0000 _H	0000 _H
	B:	1111 1111 1111 1111 1111 1x11 1111 1111	xxxx 1111 1111 111x xxxx x111 1xxx x11x	xxxx xxxx 1111 xxxx	xxxx 1111 1111 1111 xxxx x111 1111 1111
PFCEn	A:	FF40 0600 _H	FF40 0604 _H	FF40 060C _H	FF40 0610 _H
	I:	0000 _H	0000 _H	0000 _H	0000 _H
	B:	1111 1x11 1111 1111	xxxx 1111 1xxx x11x	xxxx xxxx 1111 xxxx	xxxx 1111 1111 1111 xxxx xxx1 1111 1111
PMSRn	A:	FF40 0800 _H	FF40 0804 _H	FF40 080C _H	FF40 0810 _H
	I:	0000 FFFF _H	0000 FFFF _H	0000 FFFF _H	0000 FFFF _H
	B:	1111 1x11 1111 1111	xxxx 1111 1111 111x	xxxx xxxx 1111 xxxx	xxxx 1111 1111 1111
PMCSRn	A:	FF40 0900 _H	FF40 0904 _H	FF40 090C _H	FF40 0910 _H
	I:	0000 0000 _H	0000 0000 _H	0000 0000 _H	0000 0000 _H
	B:	1111 1111 1111 1111	xxxx 1111 1111 111x	xxxx xxxx 1111 xxxx	xxxx 1111 1111 1111

Table 2-31 V850E2/FF4-G port (groups 0, 1, 3, 4) control registers (2/2)

Register		Port group n =			
		0	1	3	4
PBCn	A:	FF40 4000 _H	FF40 4004 _H	FF40 400C _H	FF40 4010 _H
	I:	0000 _H	0000 _H	0000 _H	0000 _H
	B:	1111 1111 1111 1111	xxxx 1111 1111 111x	xxxx xxxx 1111 xxxx	xxxx 1111 1111 1111
PBDCn	A:	FF40 4100 _H	FF40 4104 _H	FF40 410C _H	FF40 4110 _H
	I:	0000 _H	0000 _H	0000 _H	0000 _H
	B:	1111 1111 1111 1111	xxxx 1111 1111 111x	xxxx xxxx 1111 xxxx	xxxx 1111 1111 1111
PIPCn	A:	FF40 4200 _H	FF40 4204 _H	FF40 420C _H	FF40 4210 _H
	I:	0000 _H	0000 _H	0000 _H	0000 _H
	B:	1111 1111 1111 1111	xxxx 1111 1111 111x	xxxx xxxx 1111 xxxx	xxxx 1111 1111 1111
PUn	A:	FF40 4300 _H	FF40 4304 _H	FF40 430C _H	FF40 4310 _H
	I:	0000 _H	0000 _H	0000 _H	0000 _H
	B:	1111 1111 1111 1111	xxxx 1111 1111 111x	xxxx xxxx 1111 xxxx	xxxx 1111 1111 1111
PDn	A:	FF40 4400 _H	FF40 4404 _H	FF40 440C _H	FF40 4410 _H
	I:	0000 _H	0000 _H	0000 _H	0000 _H
	B:	1111 1111 1111 1111	xxxx 1111 1111 111x	xxxx xxxx 1111 xxxx	xxxx 1111 1111 1111
PODCn	A:	FF40 4500 _H	FF40 4504 _H	FF40 450C _H	FF40 4510 _H
	I:	0000 0000 _H	0000 0000 _H	0000 _H	0000 _H
	B:	1111 1111 1111 1111	xxxx 1111 1111 111x	xxxx xxxx 1111 xxxx	xxxx 1111 1111 1111
PISn	A:	FF40 4700 _H	FF40 4704 _H	FF40 470C _H	FF40 4710 _H
	I:	FFFF _H	FFFF _H	FFFF _H	FFFF _H
	B:	1111 1111 1111 1111	xxxx 1111 1111 111x	xxxx xxxx 1111 xxxx	xxxx 1111 1111 1111
PISEn	A:	FF40 4800 _H	FF40 4804 _H	FF40 480C _H	FF40 4810 _H
	I:	FFFF _H	FFFF _H	FFFF _H	FFFF _H
	B:	1111 1111 1111 1111	xxxx 1111 1111 111x	xxxx xxxx 1111 xxxx	xxxx 1111 1111 1111
PPCMDn	A:	FF40 4C00 _H	FF40 4C04 _H	FF40 4C0C _H	FF40 4C10 _H
	I:	00 _H	00 _H	00 _H	00 _H
	B:	1111 1111	1111 1111	1111 1111	1111 1111
PPRO T _{Sn}	A:	FF40 4B00 _H	FF40 4B04 _H	FF40 4B0C _H	FF40 4B10 _H
	I:	00 _H	00 _H	00 _H	00 _H
	B:	xxxx xxx1	xxxx xxx1	xxxx xxx1	xxxx xxx1

Table 2-32 V850E2/FF4-G port (groups 10, JP0) control registers (1/2)

Register		Port group n =			
		10	JP0 ^a		
Pn	A:	FF40 0028 _H	FF44 0000 _H		
	I:	0000 _H	00 _H		
	B:	xxx1 1111 1111 1xxx	xx11 1111		
PSRn	A:	FF40 0128 _H	FF44 0010 _H		
	I:	0000 0000 _H	0000 0000 _H		
	B:	xxx1 1111 1111 1xxx	xxxx xxxx xx11 1111		
PNOTn	A:	FF40 0728 _H	FF44 0070 _H		
	I:	0000 _H	00 _H		
	B:	xxx1 1111 1111 1xxx	xx11 1111		
PPRn	A:	FF40 0228 _H	FF44 0020 _H		
	I:	FFFF _H	00 _H		
	B:	xxx1 1111 1111 1xxx	xx11 1111		
PMn	A:	FF40 0328 _H	FF44 0030 _H		
	I:	FFFF _H	FF _H		
	B:	xxx1 1111 1111 1xxx	xx11 1111		
PMCn	A:	FF40 0428 _H	FF44 0040 _H		
	I:	0000 _H	00 _H		
	B:	xxxx 111x xxxx xxxx	xx1x 1111		
PFCn	A:	–	FF44 0050 _H		
	I:		00 _H		
	B:		xxxx 1111		
PFCEn	A:	–	–		
	I:				
	B:				
PMSRn	A:	FF40 0828 _H	FF44 0080 _H		
	I:	0000 FFFF _H	0000 00FF _H		
	B:	xxx1 1111 1111 1xxx	xxxx xxxx xx11 1111		
PMCSRn	A:	FF40 0928 _H	FF44 0090 _H		
	I:	0000 0000 _H	0000 0000 _H		
	B:	xxxx 111x xxxx xxxx	xxxx xxxx xx1x 1111		
PIBCn	A:	FF40 4028 _H	FF44 0400 _H		
	I:	0000 _H	00 _H		
	B:	xxx1 1111 1111 1xxx	xx11 1111		
PBDCn	A:	FF40 4128 _H	FF44 0410 _H		
	I:	0000 _H	00 _H		
	B:	xxx1 1111 1111 1xxx	xx11 1111		
PIPCn	A:	–	–		
	I:				
	B:				
PUn	A:	–	FF44 0430 _H		
	I:		00 _H		
	B:		xx11 1111		

Table 2-32 V850E2/FF4-G port (groups 10, JP0) control registers (2/2)

Register		Port group n =			
		10	JP0 ^a		
PDn	A:	–	FF44 0440 _H		
	I:		00 _H		
	B:		xx11 1111		
PODCn	A:	FF40 4528 _H	FF44 0450 _H		
	I:	0000 0000 _H	0000 0000 _H		
	B:	xxx1 1111 1111 1xxx	xxxx xxxx xx11 1111		
PISn	A:	–	FF44 0470 _H		
	I:		FF _H		
	B:		xx11 1111		
PISEn	A:	–	FF44 0480 _H		
	I:		FF _H		
	B:		xx11 1111		
PPCMDn	A:	FF40 4C28 _H	FF44 04C0 _H		
	I:	00 _H	00 _H		
	B:	1111 1111	1111 1111		
PPRO TSn	A:	FF40 4B28 _H	FF44 04B0 _H		
	I:	00 _H	00 _H		
	B:	xxxx xxx1	xxxx xxx1		

a) The JTAG port group registers are identified by a “J” prefix, with n = 0. For example, JP0 stands for the register name of Pn.

2.4.4 V850E2/FG4-G port functions

This section summarizes all port functions of the V850E2/FG4-G devices and its port control registers.

(1) V850E2/FG4-G general I/O functions

The table below shows all alternative functions, that can be applied to the V850E2/FG4-G ports.

It also gives the settings of the control bits $PMCn_m$, $PFCn_m$, $PFCEn_m$ and PMn_m to the respective port into the different modes.

Table 2-33 V850E2/FG4-G general I/O functions (1/3)

Port mode	Alternative mode							
$PMCn_m = 0$	$PMCn_m = 1$							
	$PFCEn_m = 0, PFCn_m = 0$		$PFCEn_m = 0, PFCn_m = 1$		$PFCEn_m = 1, PFCn_m = 0$		$PFCEn_m = 1, PFCn_m = 1$	
	$PMn_m = 1$	$PMn_m = 0$	$PMn_m = 1$	$PMn_m = 0$	$PMn_m = 1$	$PMn_m = 0$	$PMn_m = 1$	$PMn_m = 0$
	ALT_IN1	ALT_OUT1	ALT_IN2	ALT_OUT2	ALT_IN3	ALT_OUT3	ALT_IN4	ALT_OUT4
Port group 0 (Always-On-Area, E0VDD/E0VSS power supply):								
P0_0	DPIN0		CSIG4SSI		ADCA0 TRG0		INTP0	
P0_1	DPIN1		CSIG4DCS ^c	CSIG4SO	URTE2RX		INTP1	TAUB001
P0_2	DPIN2		CSIG4SI		ADCA0 TRG2	URTE2TX	INTP2	TAUB002
P0_3	DPIN3		CSIG4SC ^a		ADCA0 TRG1		INTP3	
P0_4	DPIN4	FCN0TX					INTP11	
P0_5	FCN0RX/ DPIN5						INTP12	
P0_6	FCN1RX/ DPIN6	URTE11TX	KR011		NMI			
P0_7	URTE11RX/ DPIN7	FCN1TX	KR012		INTP4			
P0_8	DPIN8	URTE10TX	KR013	FCN3TX ^b	INTP5	TAUB005	IICB0SDA ^a	
P0_9	URTE10RX/ DPIN9	FCN2TX	KR014		INTP6	TAUB006	IICB0SCL ^a	
P0_10	DPIN10	URTE11TX	FCN3RX ^b		INTP9			
P0_11	URTE11RX/ DPIN11		FCN2RX		INTP10			
P0_12	TAUJ010/ DPIN12	TAUJ000	KR010		INTP8	FCN4TX ^b	CSIG0SSI	
P0_13	TAUJ011/ DPIN13	TAUJ001	KR015		INTP7	FCN5TX ^b	CSIG0SI	
P0_14	TAUJ012	TAUJ002/ DPO	KR016		FCN5RX ^b		CSIG0DCS ^c	CSIG0SO
P0_15	TAUJ013	TAUJ003/APO	KR017		FCN4RX ^b		CSIG0SC ^a	

Table 2-33 V850E2/FG4-G general I/O functions (2/3)

Port mode	Alternative mode							
PMCn_m = 0	PMCn_m = 1							
	PFCEn_m = 0, PFCn_m = 0		PFCEn_m = 0, PFCn_m = 1		PFCEn_m = 1, PFCn_m = 0		PFCEn_m = 1, PFCn_m = 1	
	PMn_m = 1	PMn_m = 0	PMn_m = 1	PMn_m = 0	PMn_m = 1	PMn_m = 0	PMn_m = 1	PMn_m = 0
	ALT_IN1	ALT_OUT1	ALT_IN2	ALT_OUT2	ALT_IN3	ALT_OUT3	ALT_IN4	ALT_OUT4
Port group 1 (Isolated-Area-0, E1VDD/E1VSS power supply):								
P1_1	TAUB011	TAUB001					FCN1RX	FCN0TX
P1_2	TAUB012	TAUB002					CSIG7SI	FCN1TX
P1_3	TAUB013	TAUB003	FCN3RX ^b				CSIG7DCS ^c	CSIG7SO
P1_4	TAUB014	TAUB004		FCN3TX ^b			CSIG7SC ^a	
P1_5	TAUB015	TAUB005	FCN4RX ^b				CSIG7RYI	CSIG7RYO
P1_6	TAUB016	TAUB006		FCN4TX ^b			CSIG7SSI	
P1_7	TAUB017	TAUB007					FCN0RX	
P1_8	TAUB018	TAUB008					FCN2RX	
P1_9	TAUB019	TAUB009	INTP3					FCN2TX
P1_10	TAUB0110	TAUB0010	FCN5RX ^b				INTP4	
P1_11	TAUB0111	TAUB0011		FCN5TX ^b			INTP5	
P1_12	TAUB0112	TAUB0012					INTP6	
P1_13	TAUB0113	TAUB0013					INTP7	
P1_14	TAUB0114	TAUB0014					INTP8	
P1_15	TAUB0115	TAUB0015					INTP9	
Port group 3 (Isolated-Area-0, E1VDD/E1VSS power supply):								
P3_2			TAUB012	TAUB002	KR017			
P3_3			TAUB013	TAUB003	KR016			
P3_4			TAUB014	TAUB004	KR015		CSIG0RYI	CSIG0RYO
P3_5			TAUB015	TAUB005	KR014		CSIG0SC ^a	
P3_6			TAUB016	TAUB006			CSIG0DCS ^c	CSIG0SO
P3_7			TAUB017	TAUB007			CSIG0SI	
Port group 4 (Isolated-Area-0, E1VDD/E1VSS power supply):								
P4_0			TAUB0113	TAUB0013			FCN0RX	
P4_1			TAUB0114	TAUB0014			URTE2RX	FCN0TX
P4_2			TAUB0115	TAUB0015			FCN1RX	URTE2TX
P4_3			CSIG0SI	URTE10TX				FCN1TX
P4_4	INTP2		URTE10RX	CSIG0SO			FCN2RX	
P4_5			CSIG0SC ^a		KR013			FCN2TX
P4_6			CSIG4SI	URTE11TX	KR012		FCN3RX ^b	
P4_7	INTP4		URTE11RX	CSIG4SO	KR011			FCN3TX ^b
P4_8			CSIG4SC ^a		KR010		FCN4RX ^b	
P4_9				CSIG0RYO				FCN4TX ^b
P4_10			CSIG4RYI				FCN5RX ^b	
P4_11								FCN5TX ^b
Port group 10 (Isolated-Area-0, A0VDD/A0VSS power supply):								
P10_0								
P10_1								
P10_2								
P10_3								
P10_4								

Table 2-33 V850E2/FG4-G general I/O functions (3/3)

Port mode	Alternative mode							
	PMcN_m = 1							
PMcN_m = 0	PFCEn_m = 0, PFCn_m = 0		PFCEn_m = 0, PFCn_m = 1		PFCEn_m = 1, PFCn_m = 0		PFCEn_m = 1, PFCn_m = 1	
	PMn_m = 1	PMn_m = 0	PMn_m = 1	PMn_m = 0	PMn_m = 1	PMn_m = 0	PMn_m = 1	PMn_m = 0
	ALT_IN1	ALT_OUT1	ALT_IN2	ALT_OUT2	ALT_IN3	ALT_OUT3	ALT_IN4	ALT_OUT4
P10_5								
P10_6								
P10_7								
P10_8								
P10_9	ADCA0 TRG0							
P10_10	ADCA0 TRG1							
P10_11	ADCA0 TRG2							
P10_12								
P10_13								
P10_14								
P10_15								
Port group 27(Isolated-Area-0, E1VDD/ E1VSS power supply):								
P27_0	INTP0							
P27_1	INTP1							
P27_2	INTP2							
P27_3	INTP3							
P27_4	INTP4							
P27_5	INTP5							
Port group JP0 (Always-On-Area, E0VDD/E0VSS power supply):								
JP0_0	INTP0		TAUJ0I0	TAUJ0O0				
JP0_1	INTP1		TAUJ0I1	TAUJ0O1				
JP0_2	INTP2		TAUJ0I2	TAUJ0O2				
JP0_3	INTP3		TAUJ0I3	TAUJ0O3				
JP0_4								
JP0_5	NMI							

- To use this alternative function, set the PIPcN.PIPCnm bit to 1. Input or output is not affected by the PMn.PMnm bit setting.
- This alternative function is not available in μ PD70F4179.
- To use this alternative function, set the CSIGNcTL1.CSIGNDCS bit to 1 (Data Consistency Check enable) and also set the PIPcN.PIPCnm or PBDCn.PBDCnm bit to 1. Data consistency check is not affected by the PMn.PMnm bit setting.

(2) V850E2/FG4-G port control registers

The following table summarizes all V850E2/FG4-G port control registers, their addresses and initial values.

Tables legend

- A: Register address
- I: Initial value
- B: Available bits
 - 1: available, x: not available
 - right: bit 0, left: bit 15

Table 2-34 V850E2/FG4-G port (groups 0, 1, 3, 4) control registers (1/2)

Register		Port group n =			
		0	1	3	4
Pn	A:	FF40 0000 _H	FF40 0004 _H	FF40 000C _H	FF40 0010 _H
	I:	0000 _H	0000 _H	0000 _H	0000 _H
	B:	1111 1111 1111 1111	1111 1111 1111 111x	xxxx xxxx 1111 11xx	xxxx 1111 1111 1111
PSRn	A:	FF40 0100 _H	FF40 0104 _H	FF40 010C _H	FF40 0110 _H
	I:	0000 0000 _H	0000 0000 _H	0000 0000 _H	0000 0000 _H
	B:	1111 1111 1111 1111	1111 1111 1111 111x	xxxx xxxx 1111 11xx	xxxx 1111 1111 1111
PNOTn	A:	FF40 0700 _H	FF40 0704 _H	FF40 070C _H	FF40 0710 _H
	I:	0000 _H	0000 _H	0000 _H	0000 _H
	B:	1111 1111 1111 1111	1111 1111 1111 111x	xxxx xxxx 1111 11xx	xxxx 1111 1111 1111
PPRn	A:	FF40 0200 _H	FF40 0204 _H	FF40 020C _H	FF40 0210 _H
	I:	0000 _H	0000 _H	0000 _H	0000 _H
	B:	1111 1111 1111 1111	1111 1111 1111 111x	xxxx xxxx 1111 11xx	xxxx 1111 1111 1111
PMn	A:	FF40 0300 _H	FF40 0304 _H	FF40 030C _H	FF40 0310 _H
	I:	FFFF _H	FFFF _H	FFFF _H	FFFF _H
	B:	1111 1111 1111 1111	1111 1111 1111 111x	xxxx xxxx 1111 11xx	xxxx 1111 1111 1111
PMCn	A:	FF40 0400 _H	FF40 0404 _H	FF40 040C _H	FF40 0410 _H
	I:	0000 _H	0000 _H	0000 _H	0000 _H
	B:	1111 1111 1111 1111	1111 1111 1111 111x	xxxx xxxx 1111 11xx	xxxx 1111 1111 1111
PFCn	A:	FF40 0500 _H	FF40 0504 _H	FF40 050C _H	FF40 0510 _H
	I:	0000 _H	0000 _H	0000 _H	0000 _H
	B:	1111 1111 1111 1111	1111 1111 1111 111x	xxxx xxxx 1111 11xx	xxxx 1111 1111 1111
PFCEn	A:	FF40 0600 _H	FF40 0604 _H	FF40 060C _H	FF40 0610 _H
	I:	0000 _H	0000 _H	0000 _H	0000 _H
	B:	1111 1111 1111 1111	1111 1111 1111 111x	xxxx xxxx 1111 11xx	xxxx 1111 1111 1111 xxxx 11x1 1111 1111
PMSRn	A:	FF40 0800 _H	FF40 0804 _H	FF40 080C _H	FF40 0810 _H
	I:	0000 FFFF _H	0000 FFFF _H	0000 FFFF _H	0000 FFFF _H
	B:	1111 1111 1111 1111	1111 1111 1111 111x	xxxx xxxx 1111 11xx	xxxx 1111 1111 1111
PMCSRn	A:	FF40 0900 _H	FF40 0904 _H	FF40 090C _H	FF40 0910 _H
	I:	0000 0000 _H	0000 0000 _H	0000 0000 _H	0000 0000 _H
	B:	1111 1111 1111 1111	1111 1111 1111 111x	xxxx xxxx 1111 11xx	xxxx 1111 1111 1111

Table 2-34 V850E2/FG4-G port (groups 0, 1, 3, 4) control registers (2/2)

Register		Port group n =			
		0	1	3	4
PBCn	A:	FF40 4000 _H	FF40 4004 _H	FF40 400C _H	FF40 4010 _H
	I:	0000 _H	0000 _H	0000 _H	0000 _H
	B:	1111 1111 1111 1111	1111 1111 1111 111x	xxxx xxxx 1111 11xx	xxxx 1111 1111 1111
PBDCn	A:	FF40 4100 _H	FF40 4104 _H	FF40 410C _H	FF40 4110 _H
	I:	0000 _H	0000 _H	0000 _H	0000 _H
	B:	1111 1111 1111 1111	1111 1111 1111 111x	xxxx xxxx 1111 11xx	xxxx 1111 1111 1111
PIPCn	A:	FF40 4200 _H	FF40 4204 _H	FF40 420C _H	FF40 4210 _H
	I:	0000 _H	0000 _H	0000 _H	0000 _H
	B:	1111 1111 1111 1111	1111 1111 1111 111x	xxxx xxxx 1111 11xx	xxxx 1111 1111 1111
PUn	A:	FF40 4300 _H	FF40 4304 _H	FF40 430C _H	FF40 4310 _H
	I:	0000 _H	0000 _H	0000 _H	0000 _H
	B:	1111 1111 1111 1111	1111 1111 1111 111x	xxxx xxxx 1111 11xx	xxxx 1111 1111 1111
PDn	A:	FF40 4400 _H	FF40 4404 _H	FF40 440C _H	FF40 4410 _H
	I:	0000 _H	0000 _H	0000 _H	0000 _H
	B:	1111 1111 1111 1111	1111 1111 1111 111x	xxxx xxxx 1111 11xx	xxxx 1111 1111 1111
PODCn	A:	FF40 4500 _H	FF40 4504 _H	FF40 450C _H	FF40 4510 _H
	I:	0000 0000 _H	0000 0000 _H	0000 0000 _H	0000 0000 _H
	B:	1111 1111 1111 1111	1111 1111 1111 111x	xxxx xxxx 1111 11xx	xxxx 1111 1111 1111
PISn	A:	FF40 4700 _H	FF40 4704 _H	FF40 470C _H	FF40 4710 _H
	I:	FFFF _H	FFFF _H	FFFF _H	FFFF _H
	B:	1111 1111 1111 1111	1111 1111 1111 111x	xxxx xxxx 1111 11xx	xxxx 1111 1111 1111
PISEn	A:	FF40 4800 _H	FF40 4804 _H	FF40 480C _H	FF40 4810 _H
	I:	FFFF _H	FFFF _H	FFFF _H	FFFF _H
	B:	1111 1111 1111 1111	1111 1111 1111 111x	xxxx xxxx 1111 11xx	xxxx 1111 1111 1111
PPCMDn	A:	FF40 4C00 _H	FF40 4C04 _H	FF40 4C0C _H	FF40 4C10 _H
	I:	00 _H	00 _H	00 _H	00 _H
	B:	1111 1111	1111 1111	1111 1111	1111 1111
PPROTSn	A:	FF40 4B00 _H	FF40 4B04 _H	FF40 4B0C _H	FF40 4B10 _H
	I:	00 _H	00 _H	00 _H	00 _H
	B:	xxxx xxx1	xxxx xxx1	xxxx xxx1	xxxx xxx1

Table 2-35 V850E2/FG4-G port (groups 10, 27, JP0) control registers (1/2)

Register		Port group n =			
		10	27	JP0 ^a	
Pn	A:	FF40 0028 _H	FF40 006C _H	FF44 0000 _H	
	I:	0000 _H	0000 _H	00 _H	
	B:	1111 1111 1111 1111	xxxx xxxx xx11 1111	xx11 1111	
PSRn	A:	FF40 0128 _H	FF40 016C _H	FF44 0010 _H	
	I:	0000 0000 _H	0000 0000 _H	0000 0000 _H	
	B:	1111 1111 1111 1111	xxxx xxxx xx11 1111	xxxx xxxx xx11 1111	
PNOTn	A:	FF40 0728 _H	FF40 076C _H	FF44 0070 _H	
	I:	0000 _H	0000 _H	00 _H	
	B:	1111 1111 1111 1111	xxxx xxxx xx11 1111	xx11 1111	
PPRn	A:	FF40 0228 _H	FF40 026C _H	FF44 0020 _H	
	I:	0000 _H	0000 _H	00 _H	
	B:	1111 1111 1111 1111	xxxx xxxx xx11 1111	xx11 1111	
PMn	A:	FF40 0328 _H	FF40 036C _H	FF44 0030 _H	
	I:	FFFF _H	FFFF _H	FF _H	
	B:	1111 1111 1111 1111	xxxx xxxx xx11 1111	xx11 1111	
PMCn	A:	FF40 0428 _H	FF40 046C _H	FF44 0040 _H	
	I:	0000 _H	0000 _H	00 _H	
	B:	xxxx 111x xxxx xxxx	xxxx xxxx xx11 1111	xx1x 1111	
PFCn	A:	–	–	FF44 0050 _H	
	I:			00 _H	
	B:			xxxx 1111	
PFCEn	A:	–	–	–	
	I:				
	B:				
PMSRn	A:	FF40 0828 _H	FF40 086C _H	FF44 0080 _H	
	I:	0000 FFFF _H	0000 FFFF _H	0000 00FF _H	
	B:	1111 1111 1111 1111	xxxx xxxx xx11 1111	xxxx xxxx xx11 1111	
PMCSRn	A:	FF40 0928 _H	FF40 096C _H	FF44 0090 _H	
	I:	0000 0000 _H	0000 0000 _H	0000 0000 _H	
	B:	xxxx 111x xxxx xxxx	xxxx xxxx xx11 1111	xxxx xxxx xx1x 1111	
PIBCn	A:	FF40 4028 _H	FF40 406C _H	FF44 0400 _H	
	I:	0000 _H	0000 _H	00 _H	
	B:	xxxx 1111 1111 1111	xxxx xxxx xx11 1111	xx11 1111	
PBDCn	A:	FF40 4128 _H	FF40 416C _H	FF44 0410 _H	
	I:	0000 _H	0000 _H	00 _H	
	B:	1111 1111 1111 1111	xxxx xxxx xx11 1111	xx11 1111	
PIPCn	A:	–	–	–	
	I:				
	B:				
PU _n	A:	–	FF40 436C _H	FF44 0430 _H	
	I:		0000 _H	00 _H	
	B:		xxxx xxxx xx11 1111	xx11 1111	

Table 2-35 V850E2/FG4-G port (groups 10, 27, JP0) control registers (2/2)

Register		Port group n =			
		10	27	JP0 ^a	
PDn	A:	–	FF40 446C _H	FF44 0440 _H	
	I:		0000 _H	0000 _H	
	B:		xxxx xxxx xx11 1111	xx11 1111	
PODCn	A:	FF40 4528 _H	FF40 456C _H	FF44 0450 _H	
	I:	0000 0000 _H	0000 0000 _H	0000 0000 _H	
	B:	1111 1111 1111 1111	xxxx xxxx xx11 1111	xxxx xxxx xx11 1111	
PISn	A:	–	FF40 476C _H	FF44 0470 _H	
	I:		FFFF _H	FF _H	
	B:		xxxx xxxx xx11 1111	xx11 1111	
PISEn	A:	–	FF40 486C _H	FF44 0480 _H	
	I:		FFFF _H	FF _H	
	B:		xxxx xxxx xx11 1111	xx11 1111	
PPCMDn	A:	FF40 4C28 _H	FF40 4C6C _H	FF44 04C0 _H	
	I:	00 _H	00 _H	00 _H	
	B:	1111 1111	1111 1111	1111 1111	
PPROTSn	A:	FF40 4B28 _H	FF40 4B6C _H	FF44 04B0 _H	
	I:	00 _H	00 _H	00 _H	
	B:	xxxx xxx1	xxxx xxx1	xxxx xxx1	

a) The JTAG port group registers are identified by a “J” prefix, with n = 0. For example, JP0 stands for the register name of Pn.

2.4.5 Non-port input/output signals

Following signals are input/output via pins without port functionality. Thus no port control registers are available for these pins:

Table 2-36 General pin functions

Mode signals	<ul style="list-style-type: none"> FLMD0 RESET
Oscillator/clock connections	<ul style="list-style-type: none"> X1, X2
Power supply	<ul style="list-style-type: none"> all power supply and voltage reference signals

2.4.6 Alphabetic pin function list

The following table lists all pin signals in alphabetic order and the ports, they can be assigned to.

Pins which are not assigned to any ports, are also listed in the section “Non-port input/output signals” above.

Note The table shows all V850E2/Fx4-G signals and does not note the availability of a signal on a certain device.

Table 2-37 Alphabetic pin function list (1/4)

Pin name	I/O	Pin function	Port
A0VDD	–	A/D Converter 0 voltage supply	–
A0VSS	–	A/D Converter 0 ground	–
ADAA010	I	A/D Converter 0 input channel 0	P10_0
ADAA011	I	A/D Converter 0 input channel 1	P10_1
ADAA012	I	A/D Converter 0 input channel 2	P10_2
ADAA013	I	A/D Converter 0 input channel 3	P10_3
ADAA014	I	A/D Converter 0 input channel 4	P10_4
ADAA015	I	A/D Converter 0 input channel 5	P10_5
ADAA016	I	A/D Converter 0 input channel 6	P10_6
ADAA017	I	A/D Converter 0 input channel 7	P10_7
ADAA018	I	A/D Converter 0 input channel 8	P10_8
ADAA019	I	A/D Converter 0 input channel 9	P10_9
ADAA0I10	I	A/D Converter 0 input channel 10	P10_10
ADAA0I11	I	A/D Converter 0 input channel 11	P10_11
ADAA0I12	I	A/D Converter 0 input channel 12	P10_12
ADAA0I13	I	A/D Converter 0 input channel 13	P10_13
ADAA0I14	I	A/D Converter 0 input channel 14	P10_14
ADAA0I15	I	A/D Converter 0 input channel 15	P10_15
ADAA0TRG0	I	A/D Converter 0 trigger 0	P0_0, P10_9
ADAA0TRG1	I	A/D Converter 0 trigger 1	P0_3, P10_10
ADAA0TRG2	I	A/D Converter 0 trigger 2	P0_2, P10_11
APO	O	Wake-up Sequencer analog input signals sources activation	P0_15
CSIG0RY	I/O	Clocked Serial I/F G 0 handshake signal	P3_4
	O		P4_9
CSIG0SC	I/O	Clocked Serial I/F G 0 data clock	P0_15, P3_5, P4_5
CSIG0SI	I	Clocked Serial I/F G 0 serial data input	P0_13, P3_7, P4_3
CSIG0SO	O	Clocked Serial I/F G 0 serial data output	P0_14, P3_6, P4_4
CSIG0SSI	I	Clocked Serial I/F G 0 slave select input	P0_12
CSIG4RY	I	Clocked Serial I/F G 4 handshake signal	P4_10
CSIG4SC	I/O	Clocked Serial I/F G 4 data clock	P0_3, P4_8
CSIG4SI	I	Clocked Serial I/F G 4 serial data input	P0_2, P4_6
CSIG4SO	O	Clocked Serial I/F G 4 serial data output	P0_1, P4_7
CSIG4SSI	I	Clocked Serial I/F G 4 slave select input	P0_0

Table 2-37 Alphabetic pin function list (2/4)

Pin name	I/O	Pin function	Port
CSIG7RY	I/O	Clocked Serial I/F G 7 handshake signal	P1_5
CSIG7SC	I/O	Clocked Serial I/F G 7 data clock	P1_4
CSIG7SI	I	Clocked Serial I/F G 7 serial data input	P1_2
CSIG7SO	O	Clocked Serial I/F G 7 serial data output	P1_3
CSIG7SSI	I	Clocked Serial I/F G 7 slave select input	P1_6
DCUTRDY	O	Debug I/F ready signal	JP0_5
DCUTCK	I	Debug I/F clock	JP0_2
DCUTDI	I	Debug I/F data input	JP0_0
DCUTDO	O	Debug I/F data output	JP0_1
DCUTMS	I	Debug I/F mode select	JP0_3
DCUTRST	I	Debug I/F reset	JP0_4
DPIN0	I	Wake-up Sequencer digital input signal 0	P0_0
DPIN1	I	Wake-up Sequencer digital input signal 1	P0_1
DPIN2	I	Wake-up Sequencer digital input signal 2	P0_2
DPIN3	I	Wake-up Sequencer digital input signal 3	P0_3
DPIN4	I	Wake-up Sequencer digital input signal 4	P0_4
DPIN5	I	Wake-up Sequencer digital input signal 5	P0_5
DPIN6	I	Wake-up Sequencer digital input signal 6	P0_6
DPIN7	I	Wake-up Sequencer digital input signal 7	P0_7
DPIN8	I	Wake-up Sequencer digital input signal 8	P0_8
DPIN9	I	Wake-up Sequencer digital input signal 9	P0_9
DPIN10	I	Wake-up Sequencer digital input signal 10	P0_10
DPIN11	I	Wake-up Sequencer digital input signal 11	P0_11
DPIN12	I	Wake-up Sequencer digital input signal 12	P0_12
DPIN13	I	Wake-up Sequencer digital input signal 13	P0_13
DPO	O	Wake-up Sequencer digital input signals sources activation	P0_14
EnVDD	–	Port buffer voltage supply	–
EnVSS	–	Port buffer ground	–
FCN0RX	I	CAN I/F 0 receive input	P0_5, P1_7, P4_0
FCN0TX	O	CAN I/F 0 transmit output	P0_4, P1_1, P4_1
FCN1RX	I	CAN I/F 1 receive input	P0_6, P1_1, P4_2
FCN1TX	O	CAN I/F 1 transmit output	P0_7, P1_2, P4_3
FCN2RX	I	CAN I/F 2 receive input	P0_11, P1_8, P4_4
FCN2TX	O	CAN I/F 2 transmit output	P0_9, P1_9, P4_5
FCN3RX	I	CAN I/F 3 receive input	P0_10, P1_3, P4_6
FCN3TX	O	CAN I/F 3 transmit output	P0_8, P1_4, P4_7
FCN4RX	I	CAN I/F 4 receive input	P0_15, P1_5, P4_8
FCN4TX	O	CAN I/F 4 transmit output	P0_12, P1_6, P4_9
FCN5RX	I	CAN I/F 5 receive input	P0_14, P1_10, P4_10
FCN5TX	O	CAN I/F 5 transmit output	P0_13, P1_11, P4_11
FLCS0SCI	I	Flash programmer synchronous I/F clock input	JP0_2

Table 2-37 Alphabetic pin function list (3/4)

Pin name	I/O	Pin function	Port
FLCS0SI	I	Flash programmer synchronous I/F data input	JP0_0
FLCS0SO	O	Flash programmer synchronous I/F data output	JP0_1
FLMD0	I	Primary operating mode select pin	–
FLMD1	I	Secondary operating mode select pin	P0_1
FLUR0RTX	I/O	Flash programmer asynchronous I/F data input/output	JP0_0
I0VDD	–	Flash voltage supply	–
IICB0SCL	I/O	I ² C Interface 0 clock signal	P0_9
IICB0SDA	I/O	I ² C Interface 0 data/address signal	P0_8
INTP0	I	External interrupt input 0	P0_0, JP0_0, P27_0
INTP1	I	External interrupt input 1	P0_1, JP0_1, P27_1
INTP2	I	External interrupt input 2	P0_2, P4_4, JP0_2, P27_2
INTP3	I	External interrupt input 3	P0_3, P1_9, JP0_3, P27_3
INTP4	I	External interrupt input 4	P0_7, P1_10, P4_7, P27_4
INTP5	I	External interrupt input 5	P0_8, P1_11, P27_5
INTP6	I	External interrupt input 6	P0_9, P1_12,
INTP7	I	External interrupt input 7	P0_13, P1_13,
INTP8	I	External interrupt input 8	P0_12, P1_14
INTP9	I	External interrupt input 9	P0_10, P1_15
INTP10	I	External interrupt input 10	P0_11
INTP11	I	External interrupt input 11	P0_4
INTP12	I	External interrupt input 12	P0_5
KRI0	I	Key Return input 0	P0_12, P4_8
KRI1	I	Key Return input 1	P0_6, P4_7
KRI2	I	Key Return input 2	P0_7, P4_6
KRI3	I	Key Return input 3	P0_8, P4_5
KRI4	I	Key Return input 4	P0_9, P3_5
KRI5	I	Key Return input 5	P0_13, P3_4
KRI6	I	Key Return input 6	P0_14, P3_3
KRI7	I	Key Return input 7	P0_15, P3_2
NMI	I	External non-maskable interrupt	P0_6, JP0_5
OSCVDD	–	Oscillator voltage supply	–
OSCVSS	–	Oscillator ground	–
REGnC	–	Voltage regulators capacitor connections	–
REGnVDD	–	Voltage regulators input	–
REGnVSS	–	Voltage regulators ground	–
$\overline{\text{RESET}}$	I	External reset input	–
TAUB0I1	I	Timer Array Unit B 0 channel 1 input	P1_1
TAUB0I2	I	Timer Array Unit B 0 channel 2 input	P1_2, P3_2
TAUB0I3	I	Timer Array Unit B 0 channel 3 input	P1_3, P3_3
TAUB0I4	I	Timer Array Unit B 0 channel 4 input	P1_4, P3_4
TAUB0I5	I	Timer Array Unit B 0 channel 5 input	P1_5, P3_5

Table 2-37 Alphabetic pin function list (4/4)

Pin name	I/O	Pin function	Port
TAUB0I6	I	Timer Array Unit B 0 channel 6 input	P1_6, P3_6
TAUB0I7	I	Timer Array Unit B 0 channel 7 input	P1_7, P3_7
TAUB0I8	I	Timer Array Unit B 0 channel 8 input	P1_8
TAUB0I9	I	Timer Array Unit B 0 channel 9 input	P1_9
TAUB0I10	I	Timer Array Unit B 0 channel 10 input	P1_10
TAUB0I11	I	Timer Array Unit B 0 channel 11 input	P1_11
TAUB0I12	I	Timer Array Unit B 0 channel 12 input	P1_12
TAUB0I13	I	Timer Array Unit B 0 channel 13 input	P1_13, P4_0
TAUB0I14	I	Timer Array Unit B 0 channel 14 input	P1_14, P4_1
TAUB0I15	I	Timer Array Unit B 0 channel 15 input	P1_15, P4_2
TAUB0O1	O	Timer Array Unit B 0 channel 1 output	P1_1, P0_1
TAUB0O2	O	Timer Array Unit B 0 channel 2 output	P1_2, P3_2, P0_2
TAUB0O3	O	Timer Array Unit B 0 channel 3 output	P1_3, P3_3
TAUB0O4	O	Timer Array Unit B 0 channel 4 output	P1_4, P3_4
TAUB0O5	O	Timer Array Unit B 0 channel 5 output	P1_5, P3_5, P0_8
TAUB0O6	O	Timer Array Unit B 0 channel 6 output	P1_6, P3_6, P0_9
TAUB0O7	O	Timer Array Unit B 0 channel 7 output	P1_7, P3_7
TAUB0O8	O	Timer Array Unit B 0 channel 8 output	P1_8
TAUB0O9	O	Timer Array Unit B 0 channel 9 output	P1_9
TAUB0O10	O	Timer Array Unit B 0 channel 10 output	P1_10
TAUB0O11	O	Timer Array Unit B 0 channel 11 output	P1_11
TAUB0O12	O	Timer Array Unit B 0 channel 12 output	P1_12
TAUB0O13	O	Timer Array Unit B 0 channel 13 output	P1_13, P4_0
TAUB0O14	O	Timer Array Unit B 0 channel 14 output	P1_14, P4_1
TAUB0O15	O	Timer Array Unit B 0 channel 15 output	P1_15, P4_2
TAUJ0I0	I	Timer Array Unit J 0 channel 0 input	P0_12, JP0_0
TAUJ0I1	I	Timer Array Unit J 0 channel 1 input	P0_13, JP0_1
TAUJ0I2	I	Timer Array Unit J 0 channel 2 input	P0_14, JP0_2
TAUJ0I3	I	Timer Array Unit J 0 channel 3 input	P0_15, JP0_3
TAUJ0O0	O	Timer Array Unit J 0 channel 0 output	P0_12, JP0_0
TAUJ0O1	O	Timer Array Unit J 0 channel 1 output	P0_13, JP0_1
TAUJ0O2	O	Timer Array Unit J 0 channel 2 output	P0_14, JP0_2
TAUJ0O3	O	Timer Array Unit J 0 channel 3 output	P0_15, JP0_3
URTE2RX	I	Asynchronous Serial I/F 2 receive data input	P0_1, P4_1
URTE2TX	O	Asynchronous Serial I/F 2 receive data output	P0_2, P4_2
URTE10RX	I	Asynchronous Serial I/F 10 receive data input	P0_9, P4_4
URTE10TX	O	Asynchronous Serial I/F 10 receive data output	P0_8, P4_3
URTE11RX	I	Asynchronous Serial I/F 11 receive data input	P0_7, P0_11, P4_7
URTE11TX	O	Asynchronous Serial I/F 11 receive data output	P0_6, P0_10, P4_6
X1, X2	–	Main oscillator resonator connections	–

2.4.7 Port and pin functions in stand-by modes

Details about the port functions in stand-by modes are given in the chapter “Stand-by Controller”.

2.4.8 Port and pin functions during and after reset

Table 2-38 Ports and pins function during and after reset

Port	During reset	After reset	Comment
JP0_0 to JP0_3, JP0_5	high impedance	mode dependent	These ports are also used for the On-Chip Debug I/F. Thus their function after reset depends on the operation mode. ^a
JP0_4	input with internal pull-down resistor	mode dependent	
P0_0, P0_2 to P0_15	high impedance	high impedance	
P0_1	input	input	This port is also used as FLMD1 mode selection input. ^a
Port groups P1, P3, P4, P10, P27	high impedance	high impedance	
FLMD0	input	input	
RESET	input	input	

^{a)} Refer to the section “Mode pins and JP0 connections” in the “CPU System Functions” chapter.

2.4.9 Recommended connection of unused pins

In the following recommendations are given how to treat pins, which are not used on the application board.

As a reference the final table lists all pins which must be connected in any case.

(1) Unused pins with port functionality

Table 2-39 Recommended connection of unused pins with port functionality

Port	After reset	Connect to	Comment
P0_1/FLMD1 ^a	The function of these ports depends on the operation mode. Refer to the section "Mode pins and JP0 connections" in the "CPU System Functions" chapter.		
JP0_4/ DCUTRST ^a			
JP0_0 to JP0_3, JP0_5			
P0_0, P0_2 to P0_15, P5	high impedance ^b	leave open	If the high impedance reset configuration is changed to <ul style="list-style-type: none"> output: leave open input: connect to E0VDD or E0VSS via resistor
Port groups P1, P3, P4	high impedance ^b	leave open	If the high impedance reset configuration is changed to <ul style="list-style-type: none"> output: leave open input: connect to E1VDD or E1VSS via resistor
Port group P10	high impedance ^b	leave open	If the high impedance reset configuration is changed to <ul style="list-style-type: none"> output: leave open input: connect to A0VDD or A0VSS via resistor
Port group P27	high impedance ^b	leave open	If the high impedance reset configuration is changed to <ul style="list-style-type: none"> output: leave open input: connect to E1VDD or E1VSS via resistor

a) Refer also to "Mandatory connection of pins" below.

b) Refer to the note below.

Note It is recommended to leave pins, which are in high impedance state after reset release, in this state, if they are not used by the application.

(2) Unused pins without port functionality

Table 2-40 Recommended connection of unused pins without port functionality

Pin	Connect to	Comment
X1	connect to OSCVSS	If MainOsc not used
X2	leave open	
RESET	connect to E0VDD	If external RESET is not used, the device is only reset by on-chip Power-On-Clear POCRES

(3) Mandatory connection of pins**Table 2-41 Mandatory connection pins**

Pin	Comment
FLMD0 FLMD1/P0_1 DCUTRST/JP0_4	FLMD0 determines the operation mode of the device. FLMD1 and DCUTRST must not be left unconnected. Refer to the section <i>“Mode pins and JP0 connections”</i> in the <i>“CPU System Functions”</i> chapter.
REGnVDD/REGnVSS A0VDD, A0VSS EnVDD, EnVSS OSCVDD, OSCVSS I0VDD	All power supply pins must always be connected, although the external power supplies for the isolated areas (REGnVDD) may be switched off in DEEPSTOP stand-by mode.

2.5 Port Filters

The input signals at some pins are passed through a filter to remove noise and glitches. The microcontroller supports different types of analog and digital filters.

The first section provides an overview, which port input signals are equipped with which kind of filter type, their control registers and bits, the register addresses, and the power domain they are located on.

The last paragraph of this section informs about the clock signals for the port filters

A detailed description of the analog and digital filter types and their control registers follows in the section “*Port Filters Functional Description*”.

2.5.1 Port filters assignment

The following tables list the input signals, which are equipped with an analog filter or a digital filter.

(1) Input signals with analog filters type A

The analog filters type A are controlled by means of the following register:

- Filter control registers FCLAnCTLm (m = 0 to 7)
For each port with an analog filter a dedicated register FCLAnCTLm is provided, whereas each group “n” can handle up to 8 input signals “m”.

Table 2-42 Input signals with analog filters type A (1/2)

Signal	FCLA instance		
	Register	Address	
INTP0	FCLA0	CTL0	FF41 4000 _H
INTP1		CTL1	FF41 4004 _H
INTP2		CTL2	FF41 4008 _H
INTP3		CTL3	FF41 400C _H
INTP4		CTL4	FF41 4010 _H
INTP5		CTL5	FF41 4014 _H
INTP6		CTL6	FF41 4018 _H
INTP7		CTL7	FF41 401C _H
INTP8	FCLA1	CTL0	FF41 4020 _H
INTP9		CTL1	FF41 4024 _H
INTP10		CTL2	FF41 4028 _H
INTP11		CTL3	FF41 402C _H
INTP12		CTL4	FF41 4030 _H
NMI	FCLA2	CTL0	FF41 4040 _H

Table 2-42 Input signals with analog filters type A (2/2)

Signal	FCLA instance		
	Register	Address	
KR0	FCLA3	CTL0	FF41 4060 _H
KR1		CTL1	FF41 4064 _H
KR2		CTL2	FF41 4068 _H
KR3		CTL3	FF41 406C _H
KR4		CTL4	FF41 4070 _H
KR5		CTL5	FF41 4074 _H
KR6		CTL6	FF41 4078 _H
KR7		CTL7	FF41 407C _H

(2) Input signals with analog filters type B

The analog filters type B are controlled by means of the following register:

- Filter control registers FCLAnCTL_m (m = 0 to 7)
For each port with an analog filter a dedicated register FCLAnCTL_m is provided, whereas each group “n” can handle up to 8 input signals “m”.

Table 2-43 Input signals with analog filters type B

Signal	FCLA instance		
	Register	Address	
TAUJ010	FCLA4	CTL0	FF41 4080 _H
TAUJ011		CTL1	FF41 4084 _H
TAUJ012		CTL2	FF41 4088 _H
TAUJ013		CTL3	FF41 408C _H

(3) Input signals with analog filters type C

The analog filters type C have no control registers.

Table 2-44 Input signals with analog filters type C

Signal	FCLA instance	
	Register	Address
Always-On-Area:		
FLMD0	-	-
FLMD1		-
RESET		-

(4) Input signals with digital filters type D

The digital filters type D are controlled by means of the following register:

- Filter control registers FCLAnCTL_m (m = 0 to 7)
For each port with a digital filter a dedicated register FCLAnCTL_m is provided, whereas each group “n” can handle up to 8 input signals “m”.
- Digital noise elimination control registers DNFA_nCTL
Each DNFA_nCTL control register can handle a group “n” with up to 16 input signals with digital filters.
- Digital noise elimination enable registers DNFA_nEN
The bits DNFA_nNFEN[15:0] of this register enable digital filters of the group “n” of up to 16 input signals.

Caution If digital filtering shall not be applied to the input signal, the filter bypass must be activated by FCLAnCTL_m.FCLAnBYPS_m = 1.

Table 2-45 Input signals with digital filters type D (1/2)

Signal	DNFA instance			FCLA instance			
	Register	Address	Filter enable bit	Register	Address		
TAUB0I1	DNFA0EN DNFA0ENH DNFA0ENL	FF41 1004 _H FF41 1008 _H FF41 100C _H	DNFA0EN.DNFA0	NFEN1	FCLA5	CTL1	FF41 5004 _H
TAUB0I2				NFEN2		CTL2	FF41 5008 _H
TAUB0I3				NFEN3		CTL3	FF41 500C _H
TAUB0I4				NFEN4		CTL4	FF41 5010 _H
TAUB0I5				NFEN5		CTL5	FF41 5014 _H
TAUB0I6				NFEN6		CTL6	FF41 5018 _H
TAUB0I7				NFEN7		CTL7	FF41 501C _H
TAUB0I8				NFEN8	FCLA6	CTL0	FF41 5020 _H
TAUB0I9				NFEN9		CTL1	FF41 5024 _H
TAUB0I10				NFEN10		CTL2	FF41 5028 _H
TAUB0I11				NFEN11		CTL3	FF41 502C _H
TAUB0I12				NFEN12		CTL4	FF41 5030 _H
TAUB0I13				NFEN13		CTL5	FF41 5034 _H
TAUB0I14				NFEN14		CTL6	FF41 5038 _H
TAUB0I15				NFEN15		CTL7	FF41 503C _H
URTE10RX	DNFA1CTL DNFA1EN DNFA1ENH DNFA1ENL	FF41 1020 _H FF41 1024 _H FF41 1028 _H FF41 102C _H	DNFA1EN.DNFA1	NFEN0	FCLA7	CTL0	FF41 5040 _H
URTE11RX				NFEN1		CTL1	FF41 5044 _H
CSIG4SC				NFEN2		CTL2	FF41 5048 _H
CSIG4SI				NFEN3		CTL3	FF41 504C _H
CSIG4RY				NFEN4		CTL4	FF41 5050 _H
CSIG4SSI				NFEN5	CTL5	FF41 5054 _H	
ADAA0TRG0				NFEN6	FCLA8	CTL0	FF41 5060 _H
ADAA0TRG1				NFEN7		CTL1	FF41 5064 _H
ADAA0TRG2				NFEN8		CTL2	FF41 5068 _H

Table 2-45 Input signals with digital filters type D (2/2)

Signal	DNFA instance			FCLA instance			
	Register	Address	Filter enable bit	Register	Address		
CSIG7SC	DNFA9CTL DNFA9EN DNFA9ENH DNFA9ENL	FF41 20E0 _H FF41 20E4 _H FF41 20E8 _H FF41 20EC _H	DNFA9EN.DNFA9	NFEN8	FCLA23	CTL0	FF41 61C0 _H
CSIG7RY				NFEN9		CTL1	FF41 61C4 _H
CSIG7SI				NFEN10		CTL2	FF41 61C8 _H
CSIG7SSI				NFEN11		CTL3	FF41 61CC _H
CSIG0SC	DNFA10CTL DNFA10EN DNFA10ENH DNFA10ENL	FF41 2100 _H FF41 2104 _H FF41 2108 _H FF41 210C _H	DNFA10EN.DNFA10	NFEN0	FCLA24	CTL0	FF41 61E0 _H
CSIG0RY				NFEN1		CTL1	FF41 61E4 _H
CSIG0SI				NFEN2		CTL2	FF41 61E8 _H
CSIG0SSI				NFEN3		CTL3	FF41 61EC _H
URTE2RX	DNFA11CTL DNFA11EN DNFA11ENH DNFA11ENL	FF41 2120 _H FF41 2124 _H FF41 2128 _H FF41 212C _H	DNFA11EN.DNFA11	NFEN8	FCLA27	CTL0	FF41 6240 _H

2.5.2 Port filters clock supply

Following table summarizes the clock supplies for the port filter types on the different power domains:

Table 2-46 Port filter clock supply

Power domain	Filters clocks	Connected to
Always-On-Area	PCLK	Clock Controller CKSCLK_A02
Isolated-Area-0	PCLK	Clock Controller CKSCLK_001
	DNFATCKI	Clock Controller CKSCLK_016




Figure 2-2 Port filters clock supply

2.5.3 Port filters reset

The port filters and its registers are initialized by the following reset signal:

Table 2-47 Port filters reset signal

Port filters power domain	Reset signal
Always-On-Area	<ul style="list-style-type: none">Reset Controller SYSRES
Isolated-Area-0	<ul style="list-style-type: none">Reset Controller SYSRESStand-by Controller DPSTPWU (wake-up from DEEPSTOP mode)

2.6 Port Filters Functional Description

Depending on the purpose of the external input signal to be filtered, the external signals are passed through different filter types:

- Analog filters
 - Analog filter have a fixed filter characteristic.
 - Type A: analog filtered signals with edge or level detection
The output signals are used to signal an external event, whereas the timing of the external signal is not of concern, but its level or level changes.
An external interrupt is a typical case for such event signals.
 - Type B: analog filtered signals with filter bypass option
The timing of the filtered output signals is retained with this filter type. Bypassing of the filter is also possible.
A typical example for such signals is a timer input signal to measure its frequency.
 - Type C: analog filter only
The input signal are always passed through an analog filter, which can not be bypassed.
Such filters are typically used for external $\overline{\text{RESET}}$ inputs and mode signals.
- Digital filters
 - The characteristic of a digital filter can be adjusted to the application's needs.
 - Type D: configurable digital filtered signals with filter bypass option
The timing of the filtered output signals is retained with this filter type. Bypassing of the filter is also possible.
A typical example for such signals is a timer input signal to measure its frequency.

2.6.1 Analog filters

Analog filter characteristic	The characteristics of the analog filter as well as of the level and edge detectors are specified in the Data Sheet document.
Analog filters control registers	<p>For each input signal, that is equipped with an analog filter, a dedicated control register FCLAnCTLm is provided.</p> <p>The registers are ordered in groups of 8 registers with the same index n. The register index m ranges from 0 to 7:</p> <p>FCLA group n: FCLAnCTL0 to FCLAnCTL7</p> <p>The assignment of the input signals to the control registers and their addresses is given in the tables in the previous section “Port filters assignments”.</p>

Analog filter in stand-by mode All analog filters are located on the Always-On-Area.
The behaviour of an analog filter and its wake-up capability depend on the filter type. Refer to the description of the analog filter types below.

(1) Analog filter type A

The block diagram of the analog filter type A is shown in the diagram below.




Figure 2-3 Analog filter type A block diagram

After passing the external signal through an analog filter to eliminate noise and spikes, the event detection evaluates the level or any level change, i.e. an edge, of the signal and generates an output accordingly.

The detection mode is selected by the control bit FCLAnCTLm.FCLAnINTLm:

- FCLAnINTLm = 0: edge detection mode
The detection of a rising or falling edge can be activated separately by FCLAnCTLm.FCLAnINTRm and FCLAnCTLm.FCLAnINTFm respectively.
- FCLAnINTLm = 1: level detection mode
The detection of a high level or low level can be selected by FCLAnCTLm.FCLAnINTRm.

The table below summarizes the detection conditions of the analog filter.

Table 2-48 Analog filter event detection conditions

FCLAnINTLm	FCLAnINTFm	FCLAnINTRm	Edge detection	Level detection
0	0	0	no detection	not active
		1	rising edge	
	1	0	falling edge	
		1	both edges	
1	X	0	not active	low level
		1		high level

Default configuration

The default configuration of the analog filter type A is as follows:

- analog filter with edge detection

Analog filter type A in stand-by mode In case the clock PCLK is stopped in stand-by mode, the analog filter type A can only operate with the edge detection. Thus set $FCLAnINTLm = 0$ and select the required edge detection if the input signal shall be used as a stand-by mode wake-up signal.

(2) Analog filter type B

The block diagram of the analog filter type B is shown in the diagram below.




Figure 2-4 Analog filter type B block diagram

The analog filter can optionally be bypassed:

- $DCLAnCTLm.FCLAnBYPSm = 0$: the filtered signal is output
- $DCLAnCTLm.FCLAnBYPSm = 1$: the unfiltered input signal is output

Default configuration

The default configuration of the analog filter type B is as follows:

- analog filter active

Analog filter type B in stand-by mode The output signal of an analog filter type B can always be used as a stand-by mode wake-up signal.

(3) Analog filter type C

The block diagram of the analog filter type C is shown in the diagram below.




Figure 2-5 Analog filter type C block diagram

The output signal is always the analog filtered input signal.

Analog filter type C in stand-by mode The output signal of an analog filter type C can always be used as a stand-by mode wake-up signal.

2.6.2 Digital filters

Digital filter characteristic The digital filters allow to adjust the filter characteristics to the needs of the application.

The input signal is sampled with the sampling frequency f_s .

If a specified number of successive samples yield the same (high or low) level, the signal level is judged as valid and the filter output signal is set accordingly.

If an external signal level change is detected within the specified number of samples (same level samples s), the signal level is judged as noise - or a spike - and the filter output signal does not change.

The length of an external signal pulse to be judged as noise depends on the sampling frequency and the specified number of same level samples s .

Both parameters can be specified:

- DNFA_nCTL.DNFA_nPRS[2:0] allows to select the sampling frequency to

$$f_s = \frac{f_{\text{DNFATCKI}}}{2^{\text{DNFA}_n\text{PRS}[2:0]}}$$

where f_{DNFATCKI} is the frequency of the DNFATCKI clock.

- DNFA_nCTL.DNFA_nNFSTS[1:0] determines the number s of same level samples:

$$s = \text{DNFA}_n\text{NFSTS}[1:0] + 2$$

External signal pulses, shorter than

$$t_{\text{wDNF}(\text{min})} = (s - 1) \times \frac{1}{f_s}$$

are always suppressed. That means also, pulses with a width $\geq t_{\text{wDNF}(\text{min})}$ may pass the filter.

External signal pulses, longer than

$$t_{\text{wDNF}(\text{max})} = s \times \frac{1}{f_s}$$

are always judged as valid and are passed on to the filter output. That means also, pulses with a width $\leq t_{\text{wDNF}(\text{max})}$ may be suppressed.

Consequently, external signal pulses, with a t_{wDNF} width in the range

$$(s - 1) \times \frac{1}{f_s} \leq t_{\text{wDNF}} \leq s \times \frac{1}{f_s}$$

may be suppressed or judged as valid.

The filter effects a delay t_{dDNF} between the filter input and output pulse in the range

$$(s - 1) \times \frac{1}{f_s} + \frac{2}{f_{\text{DNFATCKI}}} \leq t_{\text{dDNF}} \leq s \times \left(\frac{1}{f_s} + \frac{3}{f_{\text{DNFATCKI}}} \right)$$

The filter operation is illustrated in the figure below with $\text{DNFAnNFSTS}[1:0] = 01_{\text{B}}$, i.e. $s = 3$ same level samples.




Figure 2-6 Digital filter function

Digital filter groups The input signals with digital filters are ordered in groups of up to 16 signals. The digital filter characteristics, specified by $\text{DNFAnCTL.DNFAnPRS}[2:0]$ and $\text{DNFAnNFSTS}[1:0]$ apply to the filters of the entire group. However the digital filter for each signal can be enabled respectively disabled separately by $\text{DNFAnEN.DNFAnNFENm}$.


Cautions 1. After enabling the digital filter by $\text{DNFAnEN.DNFAnNFENm} = 1$, the digital filter is in normal operation after the time period

$$\text{DNFAnNFSTS}[1:0] \times 1/f_s + 2 \times 1/f_{\text{DNFATCKI}}$$

and may generate unintended output signals during that time period.

Wait the above time span before enabling the function, the signal is supplied to.

2. If the levels of the external signal changes multiple times within a sample period $1/f_s$ (undersampling), the digital filter may not detect these level changes and thus may not suppress such signals. An example is show in the figure below (for $s = 3$).



Digital filter in stand-by mode

- DEEPSTOP mode:
All digital filter are located on an isolated power domain, that can be switched off during DEEPSTOP. Thus they are not in operation, when the respective power domain is in DEEPSTOP mode.
- STOP mode:
Digital noise elimination requires the clock supply DNFATCKI to operate. Since the DNFATCKI clock is never stopped, digitally filtered signals can always serve as STOP mode wake-up event.

Digital filters control registers

For each group of up to 16 digital filters a common digital filter setup register DNFA_nCTL and digital filter enable register DNFA_nEN is provided with the same index n.

While the filter setup by DNFA_nCTL effects the entire group, the control bits DNFA_nEN_m in the filter enable register DNFA_nEN allows to enable respectively disable each filter separately. The register index m is in the range from 0 to 15:

DNFA_nCTL is the control register of group n for the digital filters m = 0 to 15, enabled/disabled by the DNFA_nEN.DNAF_nEN₀ to DNFA_nEN.DNAF_nEN₁₅ control bits.

The edge detection setup is done via the filter dedicated control register FCLA_nCTL_m.

The FCLA_nCTL_m registers are ordered in groups of 8 registers with the same index n. The register index m is in the range from 0 to 7:

FCLA group n: FCLA_nCTL₀ to FCLA_nCTL₇

The assignment of the input signals to the control registers and their addresses is given in the table “*Input signals with digital filters*” in the previous section “*Analog and digital filter assignments*”.

Caution

Do not change any control register settings, while the concerned digital filter is enabled by DNFA_nEN.DNAF_nEN_m = 1. Otherwise an unintended filter output may be generated.

(1) Digital filter type D

The block diagram of the digital filter type D is shown in the diagram below.




Figure 2-7 Digital filter type D block diagram

The output signal depends on register settings, as shown in the table below:

Table 2-49 Output options of digital filter type D

FCLAnCTLm. FCLAnBYPSm	DNFAnEN. DNFAnNFENm	Output signal
0	0	fixed low level (input signal blocked)
	1	filtered input signal
1	X	not filtered input signal (filter bypass)

Default configuration The default configuration of the digital filter type D is as follows:

- input signal blocked

- Cautions**
- Per default, the input signal is blocked. Thus the digital filter type D must be configured to let the - filtered or non-filtered - input signal pass.
 - If digital filtering shall not be applied to the input signal, the filter bypass must be activated by FCLAnCTLm.FCLAnBYPSm = 1.

2.6.3 Filter control registers

The analog and digital filters are controlled and operated by the following registers:

Table 2-50 Filter registers overview

Register Name	Shortcut	Address
Filter control register m	FCLAnCTLm	The addresses are given in the tables in the previous section " <i>Port filters assignments</i> ".
Digital noise elimination control register	DNFAnCTL	
Digital noise elimination enable register	DNFAnEN	

(1) FCLAnCTLm – Filter control register

This register controls the analog and digital filter operation.

Access This register can be read/written in 8-bit units.

Address The assignment of the input signals to the FCLAnCTLm registers and their addresses is given in the tables in the previous section “Port filters assignments”.

Initial Value 00_H. This register is initialized by any reset.

7	6	5	4	3	2	1	0
FCLAn BYPSm	0	0	0	0	FCLAn INTLm	FCLAn INTFm	FCLAn INTRm
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 2-51 FCLAnCTLm register contents

Bit position	Bit name	Function
7	FCLAn BYPSm	Filter bypass control: 0: filter bypass disabled 1: filter bypass enabled Note: This bit is only effective for analog filters type B and digital filters type D.
2	FCLAn INTLm	Level/edge detection mode selection 0: edge detection enabled 1: level detection enabled Note: This bit is only effective for analog filters type A.
1	FCLAn INTFm	<ul style="list-style-type: none"> In level detection mode (FCLAnINTLm = 1): FCLAnINTFm has no effect In edge detection mode (FCLAnINTLm = 0): falling edge detection control 0: falling edge detection disabled 1: falling edge detection enabled Note: This bit is only effective for analog filters type A.
0	FCLAn INTRm	<ul style="list-style-type: none"> In level detection mode (FCLAnINTLm = 1): detection level selection 0: low level detection 1: high level detection In edge detection mode (FCLAnINTLm = 0): rising edge detection control 0: rising edge detection disabled 1: rising edge detection enabled Note: This bit is only effective for analog filters type A.

(2) DNFACTL – Digital noise elimination control register

This register specifies the filter characteristics of the digital noise elimination filter.

Note This register is only effective for digital filters type D.

Access This register can be read/written in 8-bit units.

Address The assignment of the input signals to the DNFACTL registers and their addresses is given in the tables in the previous section “*Port filters assignments*”.

Initial Value 00_H. This register is initialized by any reset.

7	6	5	4	3	2	1	0
0	DNFAnNFSTS[1:0]	0	0	DNFAnPRS[2:0]			
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 2-52 DNFACTL register contents

Bit position	Bit name	Function																		
6 to 5	DNFAnNFSTS[1:0]	DNFAAnNFSTS[1:0] specifies the number of same level samples, i.e. the number of samples with the same level to judge an external signal pulse as valid. <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>DNFAnNFSTS[1:0]</th> <th>Number of same level samples</th> </tr> </thead> <tbody> <tr> <td>00_B</td> <td>2 samples</td> </tr> <tr> <td>01_B</td> <td>3 samples</td> </tr> <tr> <td>10_B</td> <td>4 samples</td> </tr> <tr> <td>11_B</td> <td>5 samples</td> </tr> </tbody> </table>	DNFAnNFSTS[1:0]	Number of same level samples	00 _B	2 samples	01 _B	3 samples	10 _B	4 samples	11 _B	5 samples								
DNFAnNFSTS[1:0]	Number of same level samples																			
00 _B	2 samples																			
01 _B	3 samples																			
10 _B	4 samples																			
11 _B	5 samples																			
2 to 0	DNFAnPRS[2:0]	Digital filter sampling clock selection <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>DNFAnPRS[2:0]</th> <th>Sampling clock frequency</th> </tr> </thead> <tbody> <tr> <td>000_B</td> <td>DNFATCKI / 1</td> </tr> <tr> <td>001_B</td> <td>DNFATCKI / 2</td> </tr> <tr> <td>010_B</td> <td>DNFATCKI / 4</td> </tr> <tr> <td>011_B</td> <td>DNFATCKI / 8</td> </tr> <tr> <td>100_B</td> <td>DNFATCKI / 16</td> </tr> <tr> <td>101_B</td> <td>DNFATCKI / 32</td> </tr> <tr> <td>110_B</td> <td>DNFATCKI / 64</td> </tr> <tr> <td>111_B</td> <td>DNFATCKI / 128</td> </tr> </tbody> </table>	DNFAnPRS[2:0]	Sampling clock frequency	000 _B	DNFATCKI / 1	001 _B	DNFATCKI / 2	010 _B	DNFATCKI / 4	011 _B	DNFATCKI / 8	100 _B	DNFATCKI / 16	101 _B	DNFATCKI / 32	110 _B	DNFATCKI / 64	111 _B	DNFATCKI / 128
DNFAnPRS[2:0]	Sampling clock frequency																			
000 _B	DNFATCKI / 1																			
001 _B	DNFATCKI / 2																			
010 _B	DNFATCKI / 4																			
011 _B	DNFATCKI / 8																			
100 _B	DNFATCKI / 16																			
101 _B	DNFATCKI / 32																			
110 _B	DNFATCKI / 64																			
111 _B	DNFATCKI / 128																			

(3) DNFA_nEN – Digital noise elimination enable register

This register enables/disables the digital noise elimination for a certain input signal.

Note This register is only effective for digital filters type D.

Access This register can be read/written in 16-bit units.
The high byte DNFA_nNFEN[15:8] and low byte DNFA_nNFEN[7:0] can also be separately accessed in 8-bit units via the registers DNFA_nENH.DNFA_nNFEN[15:8] and DNFA_nENL.DNFA_nNFEN[7:0].

Address The assignment of the input signals to DNFA_nEN registers and their addresses is given in the tables in the previous section “Port filters assignments”.

Initial Value 0000_H. This register is initialized by any reset.

	15	14	13	12	11	10	9	8
	DNFA _n NFEN15	DNFA _n NFEN14	DNFA _n NFEN13	DNFA _n NFEN12	DNFA _n NFEN11	DNFA _n NFEN10	DNFA _n NFEN9	DNFA _n NFEN8
	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
	7	6	5	4	3	2	1	0
	DNFA _n NFEN7	DNFA _n NFEN6	DNFA _n NFEN5	DNFA _n NFEN4	DNFA _n NFEN3	DNFA _n NFEN2	DNFA _n NFEN1	DNFA _n NFEN0
	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 2-53 DNFA_nEN register contents

Bit position	Bit name	Function
15 to 0	DNFA _n NFEN[15:0]	Digital noise elimination control 0: digital noise elimination disabled 1: digital noise elimination enabled

Chapter 3 CPU System Functions

This chapter describes the registers of the CPU, the operation modes, the address space and the memory areas.

3.1 Overview

The CPU is founded on Harvard architecture and it supports a RISC instruction set. Basic instructions can be executed in one clock period. Optimized five-stage pipelining is supported. This improves instruction execution speed.

In order to make the microcontroller ideal for use in digital control applications, a 32-bit hardware multiplier enables this CPU to support multiply instructions, saturated multiply instructions, bit operation instructions, etc.

- CPU
 - CPU
 - Core: V850E2
 - Architecture: V850E2-V3 Architecture Class
 - Instruction execution times:

Device	Minimum instruction execution time	Maximum CPU clock
V850E2/FF4-G	15.7 ns	64 MHz
V850E2/FG4-G	15.7 ns	64 MHz

- 32 × 32 bits general registers
- 5 stage single issue pipeline
- Internal 32-bit architecture
- 4 GB linear address space for program and data

- Processor protection functions
 - Memory Protection Unit (MPU)
Protection against illegal execution from or data manipulation of CPU memory areas (four unified protection areas)
 - System Register Protection (SRP)
Protection against damage to the system registers by a non-trusted programs
- Instruction set**
- V850E2 instruction set (98 instructions) compatible to former V850 instruction sets plus additional powerful instructions for reduced code size and increasing execution speed
 - Signed multiplication operations in 1 clock
 - 16 bits × 16 bits → 32 bits
 - 32 bits × 32 bits → 32 bits or 64 bits
 - 32 bits × 32 bits → 64 bits
 - Saturated operation instructions with overflow/underflow detection
 - 32-bit shift instructions in 1 clock
 - Bit manipulation instructions (bit set, clear, not, test)
 - Load/store instructions with long/short format
 - Load/store displacement extension
 - Signed load instructions
 - QDIV/QDIVU for quick divide
 - CAXI instruction for Mutex
 - MAC operation
32 bit × 32 bit + 64 bit → 64 bit

3.2 Memory Protection Unit (MPU)

Caution DPA5 is always used in “base/mask specification mode”.

If the address of an accessed data is located below the configured upper boundary address of DPA5 and due to the length of the data, the access is crossing the upper boundary, an access violation will not be generated, although upper bytes of the unaligned access are located above the configured upper boundary of DPA5.

Therefore it is recommended to avoid any unaligned accesses, which could lead to crossing of the upper boundary of the DPA5 region.

Refer to V850E2 Architecture User's Manual (<tbid>) for the DPA5U and DPA5L registers description.

3.3 CPU Access Bus Structures and Latencies

The CPU accesses the configuration, control and status registers of all functional modules of the microcontroller in different ways, depending on where they are located:

- modules of the CPU Subsystem:
refer the section to “*CPU Subsystem modules access*” below
- modules externally to the CPU Subsystem (PBUS modules):
refer the section to “*PBUS modules access*” below.

Note For a detailed description of the CPU Subsystem refer to the section “*CPU Subsystem*” below in this chapter.

3.3.1 CPU Subsystem modules access

For accessing the registers of modules on the CPU Subsystem the dedicated busses LSPB and GSPB are provided. Both are controlled only by the CPU. Refer also to the section “*CPU Subsystem*” in this chapter.

Table 3-1 V850E2 CPU Subsystem control busses

Registers of module	CPU master bus
	rKB
Interrupt Controller (INTC)	R/W
DMA Controller (DMAC)	R/W

H/W lock function The rKB bus supports the hardware lock function. Thus bit manipulation instructions (CLR1, NOT1, SET1, TST1) can be applied to all registers accessed via the LSPB and GSPB bus, provided the register allows 8-bit access.

Byte/halfword access The rKB bus supports byte and halfword accesses. Thus each byte or halfword of all registers accessed via the rKB bus can be accessed separately.

3.3.2 PBUS modules access

The CPU communicates with PBUS modules - these are not located on the CPU Subsystem - via the CPU Subsystem's PBUS master interfaces.

H/W lock function The PBUS master I/F does not support the hardware lock function.

Byte/halfword access All PBUS and HBUS modules are accessed on 32-bit word aligned addresses. Further each read or write is carried out with 32-bit width on the bus.

However the CPU can also perform byte (load/store byte) and halfword (load/store halfword) access instructions with the following results:

- Byte read accesses
 - The CPU instructions LD.B and SLD.B (load of signed byte data) loads the word aligned byte to bits [7:0] of a CPU general purpose register. The general purpose register bits [31:8] will be sign extended.
 - The CPU instructions LD.BU and SLD.BU (load of unsigned byte data) loads the word aligned byte to bits [7:0] of a CPU general purpose register. The general purpose register bits [31:8] will be zero-extended.
- Halfword read accesses
 - The CPU instructions LD.H and SLD.H (load of signed halfword data) loads the word aligned halfword to bits [15:0] of a CPU general purpose register. The general purpose register bits [31:16] will be sign extended.
 - The CPU instructions LD.HU and SLD.H loads the word aligned halfword to bits [15:0] of a CPU general purpose register. The general purpose register bits [31:16] will be zero-extended.
- Write access
 - A byte (CPU instructions ST.B, SST.B) or halfword (CPU instructions ST.H, SST.H) write access corrupts the not written bytes of the word address.

Caution Do not perform byte or halfword write accesses, unless the write target is only 8 bit (for byte access) or 16 bit respectively (for halfword access) wide, so that the upper 3 bytes or 2 bytes respectively can not become corrupted.

Bus clocks The CPU Subsystem is supplied with the CKSCLK_000 clock (CPUCLK). If the CPU (respectively the DMA Controller) accesses modules, external to the CPU Subsystem, these modules are members of different clock domains. Thus the bus clocks may have to be synchronized, when the CPU accesses the concerned modules.

This section explains the bus structures and its clocks and defines access latencies, when different bus clocks have to be synchronized.

Bus clocks notation The bus clocks PCLK have an index, that indicates the clock, the bus is operating with. For instance, PCLK₀₀₀ denotes a PBUS with the PCLK clock synchronous to CKSCLK_000, or in general:

- PCLK_{mn} is a PBUS clock synchronous to CKSCLK_{mn}

Caution Since access to modules on clock domains with bus synchronizers may induce latencies of several cycles of the CPUCLK, the flow of the CPU program may become inconsistent.

That means a CPU instruction, that accesses CPU Subsystem modules (in particular INTC, DMAC), follows an instruction, that accesses a module with bus synchronizer latencies, the access to the CPU Subsystem module may become effective before the first one (module access via bus synchronizer). Refer to the further descriptions in this section for details.

The following diagram shows the bus structure for CPU accesses to PBUS modules.




Figure 3-1 CPU access bus structures

The CPU accesses all modules, except those of the CPU Subsystem, via their PBUS interface with the PCLK₀₀₀/2 clock.

CPU Subsystem modules The CPU accesses modules of the CPU Subsystem (DMA Controller, Interrupt Controller) via CPU Subsystem internal busses. The bus clock of these busses is CPUCLK (CKSCLK_000). Thus no bus synchronization is required.

Clock domains m_n All PBUS interfaces of the clock domains m_n, i.e. AWO_n and ISO0_n are supplied with clocks from different clock domains CKSCLK_mn.

Thus CPU accesses with PCLK₀₀₀/2 = CKSCLK_000/2 to the clock domain's m_n PBUS interfaces are synchronized to the target clock domain CKSCLK_mn.

Refer to the section "PBUS Synchronizer" below for information about the PBUS synchronizers latencies.

3.3.3 PBUS Synchronizer

The PBUS synchronizers synchronize the bus clock $PCLK_{000}/2$ from the CPU to the target clock domain's PBUS clock $PCLK_{mn}$.




Figure 3-2 PBUS synchronizer

The synchronizers generate latencies of CPU accesses to the PBUS modules on the clock domain m_n .

The maximum latency of a clock domain m_n PBUS access is calculated by the following formula:

$$\text{Latency cycles} = 4 \times PCLK_{000}/2 + 4 \times PCLK_{mn}$$

- Notes**
1. The synchronization latency always applies, even if both clocks are configured to use same clock source or frequency.
 2. The PBUS synchronizers are shown in the clock domain figures in section "Clock Domain Figures" in the chapter "Clock Controller".

(1) Overall PBUS latencies

The overall access latency of a CPU access to a PBUS module is calculated as follows:

- Read access:

$$T_{\text{accRD}} = 16 \cdot \text{PCLK}_{000} + 6 \cdot \text{PCLK}_{mn} + W_{\text{RD}} \cdot \text{PCLK}_{mn}$$

- Write access:

$$T_{\text{accWR}} = 6 \cdot \text{PCLK}_{000} + 6 \cdot \text{PCLK}_{mn} + W_{\text{WR}} \cdot \text{PCLK}_{mn}$$

W_{RD} and W_{WR} specify the number of wait clocks, induced by the PBUS module upon read respectively write access. Refer to the section “Module wait clocks insertion” below for the W_{RD} and W_{WR} values of the different modules.




Figure 3-3 Overall PBUS access latency

- CPU write access** If the PBUS is not occupied, i.e. the PBUS is idle, the write access is immediately forwarded and the CPU continues with the next instruction. If the PBUS is occupied because of a former CPU write or a DMA access, the CPU is stopped until the PBUS is idle.
- CPU read access** Upon a CPU read access to any PBUS module, CPU operation stops until the requested data is available.

(2) Module wait clocks insertion

The following modules insert wait states when accessed by the CPU.

Note All other module registers, which are not listed in the following table, do not inserted any wait clocks ($W_{RD} = W_{WR} = 0$).

Table 3-2 Module registers access wait clocks

Module	Registers	Read wait clocks W_{RD}	Write wait clocks W_{WR}
CAN Controller (FCN)	FCNnMmDAT[7:0]B FCNnMmDTLGB FCNnMmSTRB FCNnDNBMRX[3:0] FCNnMmCTL FCNnCMLISTR FCNnCMLOSTR	2 PCLK	2 PCLK
	FCNnCMRGRX FCNnCMTGTX FCNnMmDAT[6,4,2,0]H FCNnMmMID0H FCNnMmMID1H	2 PCLK	1 PCLK
	FCNnMmDAT[4,0]W FCNnMmMID0W	3 PCLK	2 PCLK
	FCNnCMCLCTL.FCNnCMCLSERC	n.a. (write only)	1 to 10 PCLK
	FCNnCMCLCTL except FCNnCMCLSERC bit	0 PCLK	3 PCLK

3.4 CPU Subsystem

This section gives an overview about the CPU Subsystems.

The CPU Subsystems comprise

- the CPU and CPU dedicated components, e.g. the processor protection functions
- busses to instruction and data memory
- various interfaces to the other microcontroller modules, e.g. the PBUS and data flash interface
- the Interrupt Controller (INTC)
- the DMA Controller (DMAC)
- On-chip Debug unit
- several bus systems with bus arbiters that allow access of the bus masters to all other modules

3.4.1 Power and clock domain

The CPU Subsystem lies on the Isolated-Area-0 and its clock CPUCLK is supplied from the domain clock CKSCLK_000.




Figure 3-4 CPU Subsystem clock supply

CPU Subsystem H/W reset The CPU Subsystem and its registers are initialized by the following reset signal:

Table 3-3 CPU Subsystem reset signal

CPU Subsystem	Reset signal
CPU Subsystem	<ul style="list-style-type: none"> • Reset Controller SYSRES • Stand-by Controller DPSTPWU (wake-up from DEEPSTOP mode)

3.4.2 CPU Subsystem busses overview

The table below gives an overview about the CPU Subsystem busses and their general purpose.

Refer to the following section for detailed information about the CPU Subsystems.

Table 3-4 Bus systems

CPU Subsystem	Bus	Purpose	Bus master
internal	CPU instruction bus	CPU access to <ul style="list-style-type: none"> • code flash • data RAM • PBUS modules • Data flash 	CPU
	CPU data bus	CPU access to <ul style="list-style-type: none"> • code flash • data RAM • PBUS modules • Data flash 	CPU
	rKB register bus	Access to registers of <ul style="list-style-type: none"> • Interrupt Controller INTC • DMA Controller DMAC 	CPU
	DMA data bus	DMAC access to <ul style="list-style-type: none"> • code flash • data RAM • PBUS modules • Data flash 	DMAC
external	PBUS	Access to all PBUS modules via the PBUS master I/F	CPU, DMAC ^a

a) Refer to the following sections for more information about the buses arbitration.

3.4.3 CPU Subsystem

The diagram below shows a CPU Subsystem block diagram of the V850E2/ Fx4-G product series.




Figure 3-5 CPU Subsystem

All busses for transferring data between the various modules are controlled by two masters:

- CPU
- DMA Controller (DMAC)

Table 3-5 CPU Subsystem data/instruction busses

Master	Bus	Code flash	Data RAM	Data flash	PBUS I/F
CPU	Instruction (32 bit)	R	R	–	–
	Data (32 bit)	R	R/W	R/W	R/W
DMA Controller	DMA data (32 bit)	R	R/W	R	R/W

(1) Code flash access

Table 3-6 Code flash access

Code flash	Code flash arbiter	← CPU instruction bus
		← CPU data bus
		← DMA data bus

(2) Data RAM access

Table 3-7 Data RAM access

Data RAM	Data RAM arbiter	← CPU instruction bus
		← CPU data bus
		← DMA data bus

Caution Before fetching any instruction code from the data RAM, make sure to initialize the 16-byte boundary area of the data RAM that contains the instruction code to fetch.

A 16-byte boundary area is an area from the address XXXX XXX0_H to XXXX XXXF_H.

For initializing the data RAM, any data values can be written, but the data RAM area must be initialized before an instruction is fetched from it.

If an instruction is fetched from an uninitialized data RAM area, a memory protection exception (MEP) might occur.

Note In general, it is recommended to initialize all the data RAM before reading it.

(3) Data flash I/F access**Table 3-8 Data flash I/F access**

Data flash I/F	PBUS/data flash arbiter	← CPU instruction bus
		← CPU data bus
		← DMA data bus

Data flash wait cycles Concerning data flash access refer also to the section “Data flash wait cycle control” below in this chapter.

(4) CPU Subsystem busses arbitration policies

The following tables specify the arbitration policies of the CPU Subsystem busses arbiters.

Table 3-9 CPU Subsystem busses arbitration policies

Arbiter	Policy	Masters
Code flash	Fixed priority	High: DMA
		Medium: CPU data bus
		Low: CPU instruction bus
Data RAM	Fixed priority	High: DMA
		Medium: CPU data bus
		Low: CPU instruction bus
Data flash	Fixed priority	High: DMA
		Medium: CPU data bus
		Low: CPU instruction bus

3.4.4 V850E2 system manual

Detailed descriptions of the various CPU Subsystem functions can be found in the following documents:

Table 3-10 CPU Subsystem functions information sources

Function	V850E2S Architecture <tbd>	This manual (R01UH0366EJ0100)
V850E2 CPU (including instruction set)	√	–
Processor protection functions (MPU, SPR)	√	–
DMA Controller (DMAC)	–	√
Interrupt Controller (INTC)	–	√
Code/Data flash	–	√
Data RAM	–	√

3.5 Data flash wait cycle control

CPU read accesses to the data flash require insertion of some wait cycles to access the flash memory.

The minimum number of wait cycles, in units of CPU Subsystem clock cycles CPUCLK, has to be selected via the wait cycle control register DCLKWAIT.

Caution The data flash wait cycle control register DCLKWAIT has to be set before the first CPU access to the data flash.

(1) DCLKWAIT – data flash wait cycle control register

This register is used to configure the number of wait cycles for accessing the data flash.

Access This register can be read/written in 8-bit units.

Address FF43 6000_H

Initial Value 1F_H

7	6	5	4	3	2	1	0
0	0	0	WAIT[4:0]				
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 3-11 DCLKWAIT register contents

Bit position	Bit name	Function
4 to 0	WAIT[4:0]	Sets the number of wait cycles, as shown in the table below: 11 _H : 17 wait cycles 1F _H : 31 wait cycles All other settings are prohibited.

3.6 Operation modes

This section describes the operation modes of the V850E2/Fx4-G and how the modes are selected.

The following operation modes are available:

- Normal operation mode
- Serial flash programming mode

After release of the Power-On-Clear reset or external $\overline{\text{RESET}}$ the microcontroller starts to fetch instructions from an internal boot ROM which contains the internal firmware. The firmware checks the FLMD0 pin, and optionally also the FLMD1 pin, to set the operation mode after reset release according to the table below.

Table 3-12 Selection of operation modes

Pins		Operation mode
FLMD0	FLMD1 (P0_1)	
VSS	VSS	Normal operation mode
	VDD	Setting prohibited
VDD	VSS	Serial flash programming mode
	VDD	Setting prohibited

For starting the microcontroller in a certain operation mode properly the mode pins and the ports of the JP0 port group have to be set up correctly, as described in the section “*Mode pins and JP0 connections*” below.

3.6.1 Normal operation mode

In normal operation mode, the internal flash memory is not re-programmed.

After reset release, the firmware branches to the start of the active boot swap cluster. User program execution is started.

Debug mode Debug mode is basically a normal operation mode, but the debugger changes the device into debug mode via DCUTRST upon reset release.

3.6.2 Flash programming mode

In serial flash programming mode, the internal flash memory is erased and reprogrammed.

After reset release, the firmware initiates loading of the user's program code from the external flash programmer and programs the flash memory.

After detaching the external flash programmer, the microcontroller can be started up with the new user's program in normal operation mode.

For more information see chapter “*Flash Memory*”.

3.7 Mode pins and JP0 connections

This section describes the wiring of the

- port group JP0 (JP0_0 to JP0_5)
- mode signals FLMD0, FLMD1 (P0_1)

in different microcontroller modes.

The function of the above mentioned pins depends on the mode:

Table 3-13 JP0 and mode pin functions

Pin/port	Operation mode			
	Normal operation	Debugger	Flash programming	
			Asynchronous	Synchronous
JP0_0	I/O port	DCUTDI	FLUR0RTX	FLCS0SI
JP0_1	I/O port	DCUTDO	I/O port	FLCS0SO
JP0_2	I/O port	DCUTCK	I/O port	FLCS0SCI
JP0_3	I/O port	DCUTMS	I/O port	I/O port
JP0_4	I/O port	$\overline{\text{DCUTRST}}$	I/O port	I/O port
JP0_5	I/O port	$\overline{\text{DCUTRDY}}$	I/O port	I/O port
FLMD0	FLMD0	FLMD0	FLMD0	FLMD0
P0_1	FLMD1/I/O port ^a	FLMD1/I/O port ^a	FLMD1/I/O port ^a	FLMD1/I/O port ^a

a) FLMD1 is used for mode setting, when the reset is released. Afterwards P0_1 can be used for general port and alternative functions.

- Notes**
1. FLMD0 has no port functionality and is exclusively used for mode setting.
 2. Usage as I/O port means, the port can be used in port input/output and alternative modes.

Pull-up/pull-down resistors

The size of the resistors, shown in the following descriptions, depends on several parameters like current flow through the resistors in active level, secure level detection with maximum specified leakage current and maximum drive level of the driving port. Refer to the Data Sheet for details.

3.7.1 Normal operation mode

In normal operation mode the JP0 port group can be used for general port and alternative functions.

Normal operation mode is selected by

FLMD0	FLMD1 (P0_1) ^a
low level	low level

a) FLMD1 can be used for general port and alternative functions after reset release.

FLMD0 has to be low level and therefore needs to be connected to GND via the resistor R1.

FLMD1 and $\overline{\text{DCUTRST}}$ have to be low level at reset release and therefore need to be connected to GND via the resistors R2. Afterwards P0_1 and JP0_4 can be used for general port and alternative functions.

The target value of R1 is 82 kΩ. For the exact dimensioning of the FLMD0 pull-down resistor R1 refer to the Data Sheet.




Figure 3-6 Pin connections in normal operation mode

3.7.2 Debug mode

In debug mode the debugger is connected to the pins of the port group JP0.

Debug mode is basically a normal operation mode, but the debugger changes the device into debug mode via $\overline{\text{DCUTRST}}$ upon reset release.

Debug mode is selected by

FLMD0	FLMD1 (P0_1) ^a
low level	low level

a) FLMD1 can be used for general port and alternative functions after reset release.

TDO, $\overline{\text{TRDY}}$ pull-up resistors

Since the microcontroller's $\overline{\text{DCUTDO}}$ and $\overline{\text{DCUTRDY}}$ outputs are in high-impedance state during $\overline{\text{RESET}}$, the R3 resistors maintain a high level at the On-chip Debugger's TDO and $\overline{\text{TRDY}}$ inputs during reset time.

The pull-up resistors R3 at TDO and $\overline{\text{TRDY}}$ may be recommended to be mounted on the debugger adapter board or cable in order to avoid temporarily undefined levels of TDO and $\overline{\text{TRDY}}$. Refer to the debugger's description for details.

The R3 resistors are not required in normal operation.

- Notes**
1. In debug mode on-chip pull-up resistors are automatically connected to DCUTCK, DCUTMS and DCUTDI.
 2. In debug mode all ports of the debugger interface are automatically configured and are not affected by any port register settings.




Figure 3-7 Pin connections in debug mode

Further information For further information about the debugger refer to the chapter “*On-Chip Debug Unit (OCD)*” and the debugger documentation
“User’s Manual QB-V850MINI, QB-V850MINIL”,
document number U17638EJxVxUM00 (xVx denotes the current version number).

3.7.3 Flash programming mode

In flash programming mode some ports of port group JP0 are connected to the flash programmer.

Flash programming mode is selected by

FLMD0	FLMD1 (P0_1)
high level	low level

The PG-FP5 flash programmer communicates with the V850 microcontroller via

- a single wire asynchronous interface FLUR0RTX
- a 3-wire synchronous interface FLCS0SCI, FLCS0SI, FLCS0SO
Ports JP0_3 to JP0_5 can be used for general port and alternative functions.

Flash programming mode is determined by FLMD0 at high and FLMD1 at low level. Both can be connected to the PG-FP5 flash programmer, that sets the pins to the correct levels. However FLMD1 connection to the flash programmer is not mandatory since FLMD1 is already set to low via the pull-down resistor R2.




Figure 3-8 Pin connections in flash programming mode (FLMD1 by PG-FP5)

Further information For further information about the debugger refer to the chapter “Flash Programming with Flash Programmer” in the chapter “Flash Memory” and the PG-FP5 flash programmer documentation

“User’s Manual PG-FP5”,

document number R20UT0008EJxxxx (xxxx denotes the current version number).

3.8 Address Space

In the following sections, the address space of the CPU is explained. Size and addresses of CPU address space and physical address space are explained. The address range of data space and program space together with their wrap-around properties are presented.

3.8.1 CPU data address and physical program address space

The CPU supports the following address space:

- 4 GB CPU data address space
With the 32-bit general purpose registers, addresses for a 4 GB memory can be generated. This is the maximum address space supported by the CPU.
- 64 MB physical program address space
The CPU provides 64 MB physical address space to access instruction opcodes in the program memory. This means that a maximum of 64 MB internal or external program memory can be accessed.

3.8.2 Program and data space

The figure below shows the assignment of the CPU address space to data and program space.




Figure 3-9 CPU address space

(1) Wrap-around of data space

If an operand address calculation exceeds 32 bits, only the lower 32 bits of the result are considered. Therefore, the addresses $0000\ 0000_H$ and $FFFF\ FFFF_H$ are contiguous addresses. This results in a wrap-around of the data space:




Figure 3-10 Wrap-around of data space

(2) Wrap-around of program space

If an instruction address calculation exceeds 25 bits, only the lower 25 bits of the result are considered. Therefore, the addresses $0000\ 0000_H$ and $01FF\ FFFF_H$ are contiguous addresses. This results in a wrap-around of the program space:




Figure 3-11 Wrap-around of program space

3.9 V850E2/Fx4-G CPU Address Map

In the following sections, the address map of the CPU and DMA is introduced. Specific memory areas are described in detail.

3.9.1 DMA address map

The DMA Controller can access all CPU address areas, except the address range

FFFF 6000_H to FFFF 7FFF_H

This area can only be accessed by the CPU.

3.9.2 Memory map




Figure 3-12 Memory map

- Notes**
1. These areas are not accessible by the DMA Controller.
 2. The code flash size, and thus the address range, is device dependent:

Series name	Product name	Size	Address range
FF4-G-256K	μPD70F4177	256 KB	0000 0000 _H - 0003 FFFF _H
FG4-G-256K	μPD70F4179		
FF4-G-512K	μPD70F4178	512 KB	0000 0000 _H - 0007 FFFF _H
FG4-G-512K	μPD70F4180		

3. The Data RAM size, and thus the address range, is device dependent:

Series name	Product name	Size	Address range
FF4-G-256K	μPD70F4177	32 KB	FEDF 8000 _H - FEDF FFFF _H
FG4-G-256K	μPD70F4179		
FF4-G-512K	μPD70F4178	64 KB	FEDF 0000 _H - FEDF FFFF _H
FG4-G-512K	μPD70F4180		

4. The Back-up RAM size, and thus the address range, is device dependent:

Series name	Product name	Size	Address range
FF4-G-256K	μPD70F4177	4 KB	FF76 0000 _H - FF76 0FFF _H
FG4-G-256K	μPD70F4179		
FF4-G-512K	μPD70F4178		
FG4-G-512K	μPD70F4180		

3.10 Back-up RAM (BURAM)

The Back-up RAMs are PBUS module.




Figure 3-13 Block diagram of the Back-up RAM

Access This BURAM can be read/written in 32-bit units.

BURAM addresses The BURAM addresses are listed in the following table:

Table 3-14 BURAM address

Device	Size	Address
Fx4-G-256K Fx4-G-512K	1K × 32 bit	FF76 0000 _H - FF76 0FFF _H

Clock supply The BURAM is supplied with the following clock.

Table 3-15 BURAM clock supply

BURAM	BURAM clock	Connected to
BURAM	PCLK	Clock Controller CKSCLK_A05




Figure 3-14 BURAM clock supply

Write permission Write access to the Back-up RAM must be explicitly enabled via the Back-up RAM control register BURC.

3.10.1 Back-up RAM protection

Write access to the Back-up RAM is disabled after reset release. Thus write access must be explicitly permitted by setting the write access permission bit BURC.BURWE = 1.

If a write access to the Back-up RAM occurs, while write is prohibited (BURC.BURWE = 0), the error bit BURAE.BURAERR is set.

The following registers control and monitor the write access to the Back-up RAM:

Table 3-16 Back-up RAM registers overview

Register name	Shortcut	Address
Back-up RAM control register	BURC	FF76 FE00 _H
Back-up RAM access error register	BURAE	FF76 FE04 _H
Back-up RAM access error clear register	BURAEAC	FF76 FE08 _H

(1) BURC – Back-up RAM control register

This register is used to permit respectively prohibit write access to the Back-up RAM.

Access This register can be read/written in 8-bit units.

Address FF76 FE00_H

Initial Value 00_H

7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	BURWE
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 3-17 BURC register contents

Bit position	Bit name	Function
0	BURWE	Back-up RAM write permission control: 0: write to Back-up RAM prohibited 1: write to Back-up RAM permitted

(2) BURAE – Back-up RAM access error register

This register reflects an erroneous write access to the Back-up RAM.

Access This register can be read in 8-bit units.

Address FF76 FE04_H

Initial Value 00_H

7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	BURA ERR
R	R	R	R	R	R	R	R

Table 3-18 BURAE register contents

Bit position	Bit name	Function
0	BURA ERR	Back-up RAM write access error flag 0: no Back-up RAM write access error 1: Back-up RAM write access error has occurred

(3) BURAE C – Back-up RAM access error clear register

This register is used to clear the Back-up RAM write access error flag BURAERR.

Access This register can be read/written in 8-bit units.

Address FF76 FE08_H

Initial Value Reading this register returns always 00_H.

7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	BURA ERRC
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 3-19 BURAE C register contents

Bit position	Bit name	Function
0	BURA ERRC	Back-up RAM write access error flag BURAERR clear 0: no function 1: clear BURAERR

3.11 Write protected Registers

Write protected registers are protected from inadvertent write access due to erroneous program execution, etc.

Writing to a write protected register requires a special register protection unlock sequence.

3.11.1 Register protection clusters

The protected registers are bundled in certain register protection clusters.

The protection mechanism treats all registers of the same cluster as a single protection unit.

If the protection unlock sequence for a register is initiated, no access to any other register of the same protection cluster is allowed. Otherwise the unlock sequence is disrupted and the register write fails.

The diagram below shows a disruption of the unlock sequence by an access to the same cluster within an interrupt service routine.




Figure 3-15 Disruption of register protection unlock sequence

Access to a register of another protection cluster during the unlock sequence does not disrupt the unlock sequence and the register write can be completed successfully.

The following diagram below shows such situation.




Figure 3-16 Successful register protection unlock sequence

The V850E2/Fx4-G register protection clusters are described in section "V850E2/Fx4-G write protected registers".

3.11.2 Register protection unlock sequence

Write access to a write protected register is only possible within a special protection unlock sequence:

1. Write the fixed value A5_H to the protection command register
2. Write the desired value to the protected register.
3. Write the bit-wise inversion of the desired value to the protected register.
4. Write the desired value to the protected register.
5. Verify successful write of the desired value to the protected register by verifying that the error monitor bit in the protection status register is "0".
In case the write was not successful, indicated by the error monitor bit set to "1", the entire sequence has to be restarted at step 1.

In case of any access to another register between step 1 to step 4 of the above sequence, the protection mechanism behaves as follows:

- If the second register belongs to the same cluster, the write to the protected register fails (indicated by the error monitor bit set to "1"). The entire sequence has to be restarted at step 1.
- If the second register does not belong to the same cluster, the protection unlock sequence is not disrupted and the write to the first register can be completed successfully.

3.11.3 Register protection and interrupt/emulation break

If an interrupt/emulation break occurs during the protection unlock sequence, the protection mechanism behaves as follows:

(1) Interrupts during protection unlock sequence

If an interrupt is acknowledged during the above protection unlock sequence and the interrupt service routine does not access any register of the same register protection cluster, the protection unlock sequence is not disrupted and the write to the protected register can be successfully completed after returning from the interrupt service routine.

(2) Emulator break during protection sequence

If an emulation break occurs during the above protection unlock sequence, e.g. because of a breakpoint hit, the register protection is suspended until normal operation is resumed.

This means even if any register of the same cluster is accessed during the break, the protection unlock sequence is not disrupted and the error monitor bit is not set to "1".

3.11.4 V850E2/Fx4-G write protected registers

The following table lists all V850E2/Fx4-G write protected registers:

Table 3-20 Write protected registers

Module	Protected register	Protection registers		Protection cluster
		Command	Status	
Clock Controller	CKSC_0n	PROTCMD0	PROTS0	Control protection cluster 0
Clock Controller	PLLE0	PROTCMD2	PROTS2	Control protection cluster 2
	MOSCE			
	ROSCE			
	CKSC_An			
Stand-by Controller	PSC0			
Reset Controller	SWRESA			
	LVICNT			
On-Chip Debug control	IDMODII	PROT0PCMD	PROTS3	OCD control protection cluster
Clock Monitors	CLMA _n CTL0	CLMA _n PCMD	CLMA _n PS	Clock Monitor protection cluster
Port control ^{a)}	PODC _n , JPODC _n	PPCMD _n	PPROTS _n	Port protection cluster 1 to 4
Self-programming control	FLMDCNT	FLMDPCMD	FLMDPS	Self-programming protection cluster

^{a)} Each port group n has its own protection command and status register. Refer to the section "Port protection clusters" below for details of port control registers protection.

(1) Port protection clusters

Following port registers feature write protection:

- Port open drain control registers PODCn, JPODCn

The above listed port control registers of certain port groups n are assigned to four port protection clusters:

Table 3-21 Port protection clusters

Port protection cluster	Port groups
1	JP0
2	P0
3	P1, P3, P4, P10, P27

Note Each port group n has its own port protection command register PPCMDn and port protection status register PPROTSn. However any port protection command register of the same port protection cluster can be used in the protection unlock sequence for enabling write access to all protected registers of the port protection cluster.

Register width The protected port control registers are 32-bit registers and the related protection command registers PPCMDn are 8-bit registers.

Caution All protected registers must be accessed by 32-bit accesses.

Thus the protection unlock sequence looks as follows:

1. Write the fixed value $A5_{\text{H}}$ to the protection command register PPCMDn.
2. Write the desired value to the protected register with the upper 16 bit bit[31:16] set to "0" (0000 xxxx_H).
3. Write the bit-wise inversion of the desired value to the protected register, thus the upper 16 bit bit[31:16] are set to "1" (FFFF xxxx_H).
4. Write the desired value to the protected register with the upper 16 bit bit[31:16] set to "0" (0000 xxxx_H).
5. Verify successful write of the desired value to the protected register by verifying that PPROTSn.PPROTSnERR = 0.

3.11.5 V850E2/Fx4-G Protection registers overview

The register write protection is controlled and operated by the following registers:

Table 3-22 Protection command registers overview (1/2)

Register Name	Shortcut	Address
Control protection clusters:		
Protection command register 0	PROTCMD0	FF42 4000 _H
Protection command register 2	PROTCMD2	FF42 0300 _H
Protection command register 3	PROTCMD3	FF42 0308 _H
Protection status register 0	PROTS0	FF42 4004 _H
Protection status register 2	PROTS2	FF42 0304 _H
Protection status register 3	PROTS3	FF42 030C _H
Clock monitors cluster:		
CLMA0:		
Protection command register	CLMA0PCMD	FF80 2010 _H
Protection status register	CLMA0PS	FF80 2014 _H
CLMA2:		
Protection command register	CLMA2PCMD	FF80 4010 _H
Protection status register	CLMA2PS	FF80 4014 _H
CLMA3:		
Protection command register	CLMA3PCMD	FF80 5010 _H
Protection status register	CLMA3PS	FF80 5014 _H
Port protection clusters		
Port protection cluster 1		
Protection command register	JPPCMD0	FF44 04C0 _H
Protection status register	JPPROTS0	FF44 04B0 _H
Port protection cluster 2		
Protection command registers	PPCMD0	FF40 4C00 _H
Protection status registers	PPROTS0	FF40 4B00 _H
Port protection cluster 3		
Protection command registers	PPCMD1	FF40 4C04 _H
	PPCMD3	FF40 4C0C _H
	PPCMD4	FF40 4C10 _H
	PPCMD10	FF40 4C28 _H
	PPCMD27	FF40 4C6C _H
Protection status registers	PPROTS1	FF40 4B04 _H
	PPROTS3	FF40 4B0C _H
	PPROTS4	FF40 4B10 _H
	PPROTS10	FF40 4B28 _H
	PPROTS27	FF40 4B6C _H
Self-programming protection cluster		
FLMD protection command register	FLMDPCMD	FF43 8004 _H

Table 3-22 Protection command registers overview (2/2)

Register Name	Shortcut	Address
FLMD protection error status register	FLMDPS	FF43 8008 _H
OCD control protection cluster		
OCD protection command register	PROT0PCMD	FF02 0308 _H
OCD protection error status register	PROT0PS	FF02 030C _H

3.11.6 Control protection clusters registers details

(1) PROTCMDn – Protection command registers

These registers are the protection command registers for initiating the write protection unlock sequence for write protected registers.

Index n “n” denotes the number of the protection command registers, refer to the table “*Protection command registers overview*” in the previous section.

Access This register can be written in 8-bit units.

Address Refer to the table “*Protection command registers overview*” in the previous section.

Initial Value Reading this register returns an undefined value.

7	6	5	4	3	2	1	0
–	–	–	–	–	–	–	–
W	W	W	W	W	W	W	W

The usage of these registers is detailed in section “*Register protection unlock sequence*” above.

Table 3-23 PROTCMDn register contents

Bit position	Bit name	Function
7 to 0	–	Protection commands to enable writing to Isolated-Area-m registers

(2) PROTSn – Protection status registers

This registers shows the status of the protection unlock sequence operated via PROTCMDn.

Index n “n” denotes the number of the protection command registers, refer to the table “*Protection command registers overview*” in the previous section.

Caution This register must not be written.

Access This register can be read in 8-bit units.

Address Refer to the table “*Protection command registers overview*” in the previous section.

Initial Value 00_H

7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	PROTSn ERR
R	R	R	R	R	R	R	R

Table 3-24 PROTSn register contents

Bit position	Bit name	Function
0	PROTSn ERR	Protected write sequence error monitor 0: no protection error 1: protection error occurred

3.11.7 Clock monitors protection cluster registers details

(1) CLMAnPCMD – CLMAn protection command register

This register is the protection command register for the CLMAnCTL0 register.

Index n “n” denotes the number of the Clock Monitor, refer to the table “*Protection command registers overview*” in the previous section.

Access This register can be written in 8-bit units.

Address Refer to the table “*Protection command registers overview*” in the previous section.

Initial Value Reading this register returns always 00_H.

7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0
W	W	W	W	W	W	W	W

Table 3-25 CLMAnPCMD register contents

Bit position	Bit name	Function
7 to 0	–	Protection commands to enable writing to CLMAnCTL0

(2) CLMAnPS – CLMAn protection status register

This register is used to verify whether the write protected register CLMAnCTL0 has been written successfully or not.

Index n “n” denotes the number of the Clock Monitor, refer to the table “*Protection command registers overview*” in the previous section.

Access This register can be read in 8-bit units.
Writing to this register is ignored.

Address Refer to the table “*Protection command registers overview*” in the previous section.

Initial Value 00_H

7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	CLMAn PRERR
R	R	R	R	R	R	R	R

Table 3-26 CLMAnPS register contents

Bit position	Bit name	Function
0	CLMAnPRERR	Indicates whether the write protected register CLMAnCTL0 has been written successfully: 0: Write operation successful 1: Write operation failed

3.11.8 Port protection clusters registers details

(1) PPCMDn – Port protection command register

PPCMDn is the protection command register for port group n.

Index n “n” denotes the port group, refer to the table “*Protection command registers overview*” in the previous section.

Access This register can be written in 8-bit units.

Address Refer to the table “*Protection command registers overview*” in the previous section.

Initial Value Reading this register returns an undefined value.

7	6	5	4	3	2	1	0
–	–	–	–	–	–	–	–
W	W	W	W	W	W	W	W

Table 3-27 PPCMDn register contents

Bit position	Bit name	Function
7 to 0	–	Protection commands to enable writing to several port registers

(2) PPROTSn – Port protection status register

PPROTSn is the protection status registers for write protected registers of port group n. It shows the status of the protection sequence operated via PPCMDn.

Index n “n” denotes the port group, refer to the table “*Protection command registers overview*” in the previous section.

Caution This register must not be written.

Access This register can be read in 8-bit units.

Address Refer to the table “*Protection command registers overview*” in the previous section.

Initial Value 00_H

7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	PPROTSn PRERR
R	R	R	R	R	R	R	R

Table 3-28 PPROTSn register contents

Bit position	Bit name	Function
0	PPROTSn PRERR	Protected write sequence error monitor 0: no protection error 1: protection error occurred

3.11.9 Self-programming protection cluster registers details

(1) FLMDPCMD – FLMD protection command register

This register is the protection command register for the FLMDCNT register.

Access This register can be written in 8-bit units.

Address Refer to the table “Protection command registers overview” in the previous section.

Initial Value Reading this register returns always 00_H.

7	6	5	4	3	2	1	0
–	–	–	–	–	–	–	–
W	W	W	W	W	W	W	W

Table 3-29 FLMDPCMD register contents

Bit position	Bit name	Function
7 to 0	–	Protection commands to enable writing to FLMDCNT

(2) FLMDPS – FLMD protection error status register

This register is used to verify whether the write protected register FLMDCNT has been written successfully or not.

Access This register can be read in 8-bit units.
Writing to this register is ignored.

Address Refer to the table “Protection command registers overview” in the previous section.

Initial Value 00_H

7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	FLMD PRERR
R	R	R	R	R	R	R	R

Table 3-30 FLMDPS register contents

Bit position	Bit name	Function
0	FLMDPRERR	Indicates whether the write protected register FLMDCNT has been written successfully: 0: Write operation successful 1: Write operation failed

3.11.10 OCD control protection cluster registers details

(1) PROT0PCMD – OCD protection command register

This register is the protection command register for the OCD control register IDMODI.

Access This register can be written in 8-bit units.

Address Refer to the table “Protection command registers overview” in the previous section.

Initial Value Reading this register returns always an undefined value.

7	6	5	4	3	2	1	0
OCDPC[7:0]							
W	W	W	W	W	W	W	W

Table 3-31 PROT0PCMD register contents

Bit position	Bit name	Function
7 to 0	OCDPC[7:0]	Protection commands to enable writing to IDMODI

(2) PROT0PS – OCD protection error status register

This register is used to verify whether the write protected register FLMDCNT has been written successfully or not.

Access This register can be read in 8-bit units.

Address Refer to the table “Protection command registers overview” in the previous section.

Initial Value 00_H

7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	OCD PRERR
R	R	R	R	R	R	R	R

Table 3-32 PROT0PS register contents

Bit position	Bit name	Function
0	OCDPRERR	Indicates whether the write protected register IDMODI has been written successfully: 0: Write operation successful 1: Write operation failed

Chapter 4 Interrupt Functions

This chapter describes the exception processing functions of this microcontroller.

At first an overview is given about all exception groups.

Afterwards all interrupt exceptions of this microcontroller are summarized and the interrupt control registers are described.

Finally the handling of the interrupts exceptions are detailed.

All other exceptions and their handling are described in the

V850E2 32-bit Microcontroller Core Architecture
Document number <td>

where “xxxx” denotes the version of this document.

4.1 Exceptions and Interrupts

The phenomenon of forcing a branch operation from a currently running program to another program, due to a specific cause, is called an exception.

The exceptions are classified in exception groups. Each exception group is assigned to a certain priority P1 to P7, that determines in which order exceptions are processed, if they occur concurrently.

This microcontroller supports the following types of exceptions.

Table 4-1 Exception and interrupt cause list (1/2)

Exception and interrupt name	Symbol	Cause group	Priority group	Exception level	Reference
CPU initialization	RESET	Reset input	P1	-	this manual “Reset Controller”
FE level non-maskable interrupt	FENMI	FENMI input	P2	FE	this chapter “V850E2/Fx4-G Interrupt Requests”
System error exception	SYSERR	SYSERR input	P3	FE	this chapter “V850E2/Fx4-G Exceptions”
EI level maskable interrupt	INT	Maskable interrupt input	P4	EI	this chapter “V850E2/Fx4-G Interrupt Requests”
Execution protection exception	MIP	Execution protection violation	P5	FE	V850E2 32-bit Microcontroller Core Architecture User Manual “Memory Protection”
Memory error exception	MEP	Instruction access error input	P6	FE	this chapter “V850E2/Fx4-G Exceptions”

Table 4-1 Exception and interrupt cause list (2/2)

Exception and interrupt name	Symbol	Cause group	Priority group	Exception level	Reference
Data protection exception	MDP	Data protection violation	P7	FE	V850E2 32-bit Microcontroller Core Architecture User Manual "Memory Protection"
Coprocessor unusable exception	UCPOP	Coprocessor instruction		FE	V850E2 32-bit Microcontroller Core Architecture User Manual "Exceptions"
Reserved instruction exception	RIEX	Reserved instruction		FE	V850E2 32-bit Microcontroller Core Architecture User Manual "Exceptions"
FE level software exception	FETRAPEX	FETRAP instruction (vector = 1 _H to F _H)		FE	V850E2 32-bit Microcontroller Core Architecture User Manual "Instructions"
EI level software exception	EITRAP0	TRAP0n instruction (vector = 00 _H to 0F _H)		EI	
EI level software exception	EITRAP1	TRAP1n instruction (vector = 10 _H to 1F _H)		EI	
System call exception	SYSCALLEX	SYSCALL instruction (vector = 00 _H to FF _H)		EI	V850E2 32-bit Microcontroller Core Architecture User Manual "Exceptions"

Priority order Priority group P1 has the highest, P7 the lowest priority.

Request Exception or interrupt request denotes the status, where an exception or interrupt event occurred and is registered in the CPU or Interrupt Controller respectively to be served.

Acknowledgement Exception or interrupt acknowledgement denotes the status, where the CPU branches to an exception or interrupt service or handler routine. Thus the current program flow is suspended.

Acknowledgement condition Before an exception or interrupt request is acknowledgement, certain acknowledgement conditions may have to be fulfilled. Note that certain exceptions are acknowledged unconditionally.

Resume Indicates whether execution restart from the last position at which program execution was interrupted - i.e. an exception or interrupt was acknowledged - is possible.

Restore Indicates whether restoring of the processor status (status of processor resources including general-purpose registers and system registers) at the time of program execution interruption is possible.

4.2 V850E2/Fx4-G Exceptions

This section describes the V850E2/Fx4-G exceptions.

For detailed information about how to handle exceptions refer to the chapter “Exceptions” in the “V850E2 32-bit Microcontroller Core Architecture”.

4.2.1 Memory error exceptions MEP

A memory error exception MEP indicates an error, that occurred during a CPU instruction fetch:

- MEP exception level: FE level without acknowledgement conditions
- MEP exception code: FEIC = 0000 0330_H
- MEP exception handler offset: 0030_H
- MEP priority level: P7

MEP exceptions are not maskable.

The MEP exception is generated upon reading instruction code from memory. Note that this must not necessarily be the time the CPU is fetching the instruction for execution. Also a cache or buffer preload can cause an MEP exception.

MEP sources The source of an MEP exception can be one of the following:

- uncorrectable ECC double-error detection during instruction fetch from the code flash
- uncorrectable ECC double-error detection during instruction fetch from the data RAM
- instruction fetch attempt from an undefined memory area (reserved area in the CPU address map)

MEP indicators The source of an MEP exception can be evaluated by the following:

- Code flash ECC double-error: CECCER.DEDFLG = 1
Refer to the section “Code flash error correction” below for further details
- For data RAM ECC double-error detections and undefined memory area access there is no source indication other than the address of the program counter in the CPU’s FEPC register, stored when the MEP occurred.

Note Single bit errors are corrected by the ECC and processing is continued using the fetched data after correction. No MEP is generated in this case.

MEP resume/restore Since an MEP is acknowledged unconditionally at the time of reading an instruction code from a memory, which may be different to the time of CPU fetch of this instruction code, neither resuming to the application program nor recovering of the CPU's status after the MEP service routine is possible. Thus a system reset must be applied or a substitute program to recover the status must be executed.

When an additional MEP exception occurs during execution of an MEP exception handler program, the MEP exception is acknowledged again and it's handler routine re-executed.

Moreover, even during MEP exception processing, SYSERR exceptions and FE level non-maskable interrupts may occur. If this happens, SYSERR exception or FE level non-maskable interrupt processing starts at the time the error occurs.

4.2.2 System error exceptions SYSERR

In case of a serious system error, a system error exception SYSERR can be generated.

SYSERR exception can be enabled or disabled. A flag register is provided to determine the cause of such errors.

- SYSERR exception level: FE level without acknowledgement conditions
- SYSERR exception code: refer to the table “*System errors summary*” below
- SYSERR exception handler offset: 0030_H
- SYSERR priority level: P3

SYSERR exceptions are maskable.

(1) System error causes

Error conditions The generation of a SYSERR exception can occur under following error conditions:

- error because of an uncorrectable ECC double-error detection during data read from the code flash
- error because of an uncorrectable ECC double-error detection during data read from the data RAM

These error conditions may be fulfilled during a CPU or DMA access.

SYSERR enable/disable For CPU accesses any of the above error conditions can be separately enabled/disabled to generate a SYSERR exception by use of the system error control register SEG_CONT.

For DMA accesses a single control bit in SEG_CONT.DMAE is provided to enable SYSERR generation for any of the above error conditions all together. Refer to the section “*Error response support*” in the chapter “*DMA Controller (DMAC)*” for further information concerning DMAC errors.

SYSERR flags The source of a SYSERR exception can be evaluated by the system error flag register SEG_FLAG, that holds

- dedicated flags for each of the error conditions, if the error condition was met during a CPU access.
- a single bit that indicates that any of the error condition was met during a DMA access.

- Notes**
1. If an error occurs during a CPU access, the exact error cause can be evaluated by the dedicated SEG_FLAG flags.
 2. Upon occurrence of an error caused by DMA access, SEG_FLAG.DMAF is set regardless of the exact cause of the error. Therefore, the CPU cannot determine the exact error cause from SEG_FLAG.
 3. Setting of the flags in SEG_FLAG is independent of the SYSERR enable/disable setting in the SEG_CONT register.

Table 4-2 System errors summary

Access by	System error cause	Error flag SEG_FLAG	SYSERR exception if SEG_CONT.	SYSERR exception code in FEIC
CPU	data read from code flash	FCHF = 1	FCHE = 1	0000 0231 _H
	data read from data RAM	RAMF = 1	RAME = 1	
DMA	<ul style="list-style-type: none"> • data read from code flash • data read from data RAM 	DMAF = 1	DMAE = 1	0000 0232 _H

(2) System error condition details

1. Error during data read from code flash
This error occurs when two defective bits are detected by the code flash ECC, which can not be corrected, as the result of read access to the code flash area.
2. Error during data read from data RAM
This error occurs when two defective bits are detected by the data RAM ECC, which can not be corrected, as the result of read access to the data RAM area.
3. Occurrence of error during DMA access
Upon detection of one of the above errors during DMA read/write accesses, the DMA controller stops the transfer operations of all channels. Refer to the section "Error response support" in the chapter "DMA Controller (DMAC)" for further information concerning DMAC errors.

(3) SEG_CONT - System error control register

This register enables respectively disables system error causes to generate a SYSERR exception.

Access This register can be read/written

- 16-bit units via the register SEG_CONT
- the lower 8 bits in 8-bit units via the register SEG_CONTL
- the higher 8 bits in 8-bit units via the register SEG_CONTH

Address SEG_CONT: FFFF 64B0_H
 SEG_CONTL: FFFF 64B0_H
 SEG_CONTH: FFFF 64B1_H

Initial Value 0000_H

15	14	13	12	11	10	9	8
0	0	0	0	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
7	6	5	4	3	2	1	0
DMAE	0	0	RAME	0	0	FCHE	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 4-3 SEG_CONT register contents

Bit position	Bit name	Function
7	DMAE	Enable SYSERR exception generation during DMA accesses 0: SYSERR generation disabled 1: SYSERR generation enabled
4	RAME	Enable SYSERR exception generation during CPU data read accesses to the data RAM 0: SYSERR generation disabled 1: SYSERR generation enabled
1	FCHE	Enable SYSERR exception generation during CPU data read accesses to the code flash 0: SYSERR generation disabled 1: SYSERR generation enabled

(4) SEG_FLAG - System error flag register

This register informs about the occurrence of a SYSERR condition.

Note that the concerned flag is set upon a SYSERR condition, independent of SYSERR generation enabled/disabled via the SEG_CONT register.

Access This register can be read/written

- 16-bit units via the register SEG_FLAG
- the lower 8 bits in 8-bit units via the register SEG_FLAGL
- the higher 8 bits in 8-bit units via the register SEG_FLAGH

Address SEG_FLAG: FFFF 64B2_H
 SEG_FLAGL: FFFF 64B2_H
 SEG_FLAGH: FFFF 64B3_H

Initial Value 0000_H

15	14	13	12	11	10	9	8
0	0	0	0	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
7	6	5	4	3	2	1	0
DMAF	0	0	RAMF	0	0	FCHF	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 4-4 SEG_FLAG register contents

Bit position	Bit name	Function
7	DMAF	SYSERR condition during DMA accesses 0: SYSERR condition has not occurred 1: SYSERR condition has occurred
4	RAMF	SYSERR condition during CPU data read accesses to the data RAM 0: SYSERR condition has not occurred 1: SYSERR condition has occurred
1	FCHF	SYSERR condition during CPU data read accesses to the code flash 0: SYSERR condition has not occurred 1: SYSERR condition has occurred

4.2.3 Code flash error correction

The code flash memory is equipped with an Error Correction module ECC. When the CPU or the DMA accesses the code flash, the ECC module automatically encodes/decodes the ECC code.

Single-bit errors In case of a single-bit error while reading from the code flash, the ECC module corrects this error automatically, i.e. the code flash ECC performs a single-error correction (SEC).

Detection and correction of a single-bit error is indicated by the SEC flag `CECCER.SECFLG = 1`.

The code flash address, where this single-bit error has occurred, is stored in the `CSECADR` register.

Double-bit errors In case of double-bit errors while reading from the code flash, the ECC module detects this error, i.e. the code flash ECC performs a double-error detection (DED).

Detection of a double-bit error is indicated by the DED flag `CECCER.DEDFLG = 1`.

The code flash address, where this double-bit error has occurred, is stored in the `CDEDADR` register.

Upon detection of a double-bit error an exception can be generated. Refer to the sections “*Memory error exceptions MEP*” and “*System error exceptions SYSERR*” about further information concerning exception processing of double-error detections.

Note Three or more erroneous bits may not detect.

(1) Code flash error correction registers overview

This section contains a description of all registers of the code flash error correction module.

Table 4-5 Code flash Error Correction module registers overview

Register name	Shortcut	Address
Code flash ECC error flag register	CECCER	FF43 2000 _H
Code flash ECC error flag clear register	CECCERC	FF43 2004 _H
Code flash ECC single-bit error correction address register	CSECADR	FF43 2008 _H
Code flash ECC double-bit error detection address register	CDEDADR	FF43 200C _H

(2) CECCER - Code flash ECC error flag register

This register informs about a correction of a single-bit (SEC) error and detection of a double-bit (DED) error.

To clear an asserted bit in this register use the CECCERC register.

Access These registers can be read in 8-bit units.

Address FF43 2000_H

Initial Value 00_H

7	6	5	4	3	2	1	0
0	0	0	0	0	0	DEDFLG	SECFLG
R	R	R	R	R	R	R	R

Table 4-6 CECCER register contents

Bit position	Bit name	Function
1	DEDFLG	double-bit error detection flag 0: double-bit error was not detected 1: double-bit error was not detected
0	SECFLG	single-bit error correction flag 0: single-bit error was not detected 1: single-bit error was detected

(3) CECCERC - Code flash ECC error flag clear register

This register allows to clear the ECC error flags of CECCER.

If a 1 is written to a bit in this register, the corresponding bit in the CECCER register is cleared.

Access These registers can be read/written in 8-bit units.

Address FF43 2004_H

Initial Value Reading this registers returns always 00_H.

7	6	5	4	3	2	1	0
0	0	0	0	0	0	DEDCLR	SECCLR
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 4-7 CECCERC register contents

Bit position	Bit name	Function
1	DEDCLR	Clear double-bit error detection flag 0: no function 1: clear CECCER.DEDFLG
0	SECCLR	Clear single-bit error detection flag 0: no function 1: clear CECCER.SECFLG

(4) CSECADR - Code flash ECC single-bit error correction address register

This register holds the address at which a single-bit error was detected and corrected.

Address storing in and clearing of this register depends on the single-bit error correction flag CECCER.SECFLG:

- The error address is only stored, if CECCER.SECFLG = 0.
- This register is cleared together with the flag CECCER.SECFLG by setting CECCERC.SECCLR = 1.

Thus only the address of the first detected error is stored. The addresses of all others which may follow, do not overwrite the first address, until the single-bit error flag - and thus this register - is cleared by CECCERC.SECCLR = 1.

Access These registers can be read in 32-bit units.

Address FF43 2008_H

Initial Value 0000 0000_H

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	CSECADR[24:16]								
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CSECADR[7:0]															
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Table 4-8 CSECADR register contents

Bit position	Bit name	Function
24 to 0	CSECADR [24:0]	single-bit error detection and correction address

(5) CDEDADR - Code flash ECC double-bit error detection address register

This register holds the address, at which a double-bit error was detected.

Address storing in and clearing of this register depends on the double-bit error detection flag CECCER.DEDFLG:

- The error address is only stored, if CECCER.DEDFLG = 0.
- This register is cleared together with the flag CECCER.DEDFLG by setting CECCERC.DEDCLR = 1.

Thus only the address of the first detected error is stored. The addresses of all others, which may follow, do not overwrite the first address, until the double-bit error flag - and thus this register - is cleared by CECCERC.DEDCLR = 1.

Access These registers can be read in 32-bit units.

Address FF43 200C_H

Initial Value 0000 0000_H

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	CDECADR[24:16]								
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CDECADR[7:0]															
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Table 4-9 CDEDADR register contents

Bit position	Bit name	Function
24 to 0	CDECADR [24:0]	double-bit error detection address

4.3 V850E2/Fx4-G Interrupt Requests

Interrupt types The V850E2/Fx4-G supports following types of interrupts:

- FE level non-maskable interrupt (FENMI)
 - FENMI is served immediately, even if an FE level maskable (FEINT) or EI level maskable (EIINT) interrupt is in service (CPU system register PSW.NP = 1).
 - resume not possible, recover not possible
- EI level maskable interrupt (EIINT)
 - EIINT may only be served, if no FE level interrupt - FENMI or FEINT - is in service (CPU system register PSW.NP = 0).
 - resume possible, recover possible
 - interrupt masking can be specified for each interrupt channel
 - 16 interrupt priority levels can be specified for each interrupt channel.

4.3.1 V850E2/Fx4-G interrupt sources

(1) FE level non-maskable interrupts

Priority group The FE level non-maskable interrupts have the priority P2.

Return PC An FE non-maskable interrupt does not allow to resume or recover.

Control register The control register of this interrupt is FNC.

Return instruction Since neither resume nor recover is possible, a reset must be applied.

Table 4-10 FE level non-maskable interrupt requests

Interrupt			Interrupt request		Unit	Priority group	Exception code	Handler address offset
Symbol	Control register		Name	Cause				
	Name	Address FFFF..						
FENMI	FNC	645C _H	NMI0	NMI0 input	Port	P2	0020 _H	0020 _H
			WDTA0NMI	Watchdog Timer 0 error NMI interrupt	WDTA0			
			WDTA1NMI	Watchdog Timer 1 error NMI interrupt	WDTA1			

FENMI sharing The source of the FENMI interrupt can be evaluated by a dedicated flag register. Refer to section 4.3.2 “FE level non-maskable interrupt sharing” on page 167 for details.

(2) EI level maskable interrupts

Interrupt naming The composition of the interrupt request signal names, their assigned interrupt control registers and the bits in these registers follow special rules.

In the following the name of the interrupt request is represented by *<name>*.

- Interrupt request name: **INT<name>**
The prefix “**INT**” is put in front of *<name>*.
- Interrupt request control register: **IC<name>**
The prefix “**IC**” is put in front of *<name>*.
The 16 bit of the 16-bit register **IC<name>** can also be accessed byte-wise with the following names:
 - low byte (bits[7:0]): **IC<name>L** at the address of **IC<name>**
The suffix “**L**” is appended to the register name **IC<name>**.
 - high byte (bits[15:8]): **IC<name>H** at the address of **IC<name>** + 1
The suffix “**H**” is appended to the register name **IC<name>**.
- Interrupt control register bit names: **RF<name>**, **MK<name>**, **P[2:0]<name>**
The bit prefix “**RF**”, “**MK**”, “**P[2:0]**” prepends the interrupt *<name>*.
- Each interrupt request is assigned to a certain interrupt channel number $n = 0$ to 255.
The functional description of the Interrupt Controller in this chapter refers to interrupt channel number n instead of to the interrupt name *<name>*.
If **INT<name>** is assigned to the interrupt channel number n , throughout this chapter
 - the interrupt request is named **INT n**
 - the assigned interrupt control register is named **IC n**
 - the interrupt control bits are named **RF n** , **MK n** , **P[2:0] n** .

Example The interrupt request of the second TAU A0 channel (*<name>* = *TAUA0I2*) is named

INTTAUA0I2

The related interrupt control registers are

ICTAUA0I2, **ICTAUA0I2L**, **ICTAUA0I2H**

The bits in this register are

RFTAUA0I2, **MKTAUA0I2**, **P[2:0]TAUA0I2**

If, for instance, the interrupt channel for **INTTAUA0I2** is $n = 22$, the functional description of the Interrupt Controller refers to

INT22,

the related control register as

IC22,

and their control register bit names

RF22, **MK22**, **P[2:0]22**.

The following tables list the references between the interrupt channel number *n*, the assigned V850E2/Fx4-G interrupt requests and control register names.

Priority group	The EI level maskable interrupts have the priority P8.
Return PC	The program counter (PC) value, set after returning from any interrupt service routine by the EIRET instruction is always the next address.
Return instruction	The return instruction from EI level maskable interrupt service routines is EIRET.

(3) V850E2/FF4-G EI level maskable interrupts

Table 4-11 V850E2/FF4-G EI level maskable interrupt requests (1/3)

Channel	Interrupt		Interrupt request			Default priority	Exception code	Handler address offset
	Control register		Name	Cause	Unit			
	Name	Address FFFF..						
0	ICWDTA0	6000 _H	INTWDTA0	WDTA0 75% interrupt	WDTA0	1	0080 _H	0080 _H
1	ICWDTA1	6002 _H	INTWDTA1	WDTA1 75% interrupt	WDTA1	2	0090 _H	0090 _H
2	ICLVI	6004 _H	INTLVI	LVI interrupt	LVI	3	00A0 _H	00A0 _H
3 to 8	—	6006 _H to 6010 _H	reserved			4 to 9	00B0 _H to 0100 _H	00B0 _H to 0100 _H
9	ICP0	6012 _H	INTP0	Edge detection interrupt	Port	10	0110 _H	0110 _H
10	ICP1	6014 _H	INTP1	Edge detection interrupt	Port	11	0120 _H	0120 _H
11	ICP2	6016 _H	INTP2	Edge detection interrupt	Port	12	0130 _H	0130 _H
12	ICP3	6018 _H	INTP3	Edge detection interrupt	Port	13	0140 _H	0140 _H
13	ICP4	601A _H	INTP4	Edge detection interrupt	Port	14	0150 _H	0150 _H
14	—	601C _H	reserved			15	0160 _H	0160 _H
15	ICP6	601E _H	INTP6	Edge detection interrupt	Port	16	0170 _H	0170 _H
16	—	6020 _H	reserved			17	0180 _H	0180 _H
17	ICP8	6022 _H	INTP8	Edge detection interrupt	Port	18	0190 _H	0190 _H
18	—	6024 _H	reserved			19	01A0 _H	01A0 _H
19	—	6026 _H	reserved			20	01B0 _H	01B0 _H
20	ICTAUB0I0	6028 _H	INTTAUB0I0	Interrupt for channel 0	TAUB0	21	01C0 _H	01C0 _H
21	ICTAUB0I1	602A _H	INTTAUB0I1	Interrupt for channel 1	TAUB0	22	01D0 _H	01D0 _H
22	ICTAUB0I2	602C _H	INTTAUB0I2	Interrupt for channel 2	TAUB0	23	01E0 _H	01E0 _H
23	ICTAUB0I3	602E _H	INTTAUB0I3	Interrupt for channel 3	TAUB0	24	01F0 _H	01F0 _H
24	ICTAUB0I4	6030 _H	INTTAUB0I4	Interrupt for channel 4	TAUB0	25	0200 _H	0200 _H
25	ICTAUB0I5	6032 _H	INTTAUB0I5	Interrupt for channel 5	TAUB0	26	0210 _H	0210 _H
26	ICTAUB0I6	6034 _H	INTTAUB0I6	Interrupt for channel 6	TAUB0	27	0220 _H	0220 _H
27	ICTAUB0I7	6036 _H	INTTAUB0I7	Interrupt for channel 7	TAUB0	28	0230 _H	0230 _H
28	ICTAUB0I8	6038 _H	INTTAUB0I8	Interrupt for channel 8	TAUB0	29	0240 _H	0240 _H
29	ICTAUB0I9	603A _H	INTTAUB0I9	Interrupt for channel 9	TAUB0	30	0250 _H	0250 _H
30	ICTAUB0I10	603C _H	INTTAUB0I10	Interrupt for channel 10	TAUB0	31	0260 _H	0260 _H
31	ICTAUB0I11	603E _H	INTTAUB0I11	Interrupt for channel 11	TAUB0	32	0270 _H	0270 _H
32	ICTAUB0I12	6040 _H	INTTAUB0I12	Interrupt for channel 12	TAUB0	33	0280 _H	0280 _H
33	ICTAUB0I13	6042 _H	INTTAUB0I13	Interrupt for channel 13	TAUB0	34	0290 _H	0290 _H
34	ICTAUB0I14	6044 _H	INTTAUB0I14	Interrupt for channel 14	TAUB0	35	02A0 _H	02A0 _H
35	ICTAUB0I15	6046 _H	INTTAUB0I15	Interrupt for channel 15	TAUB0	36	02B0 _H	02B0 _H
36 to 51	—	6048 _H to 6066 _H	reserved			37 to 52	02C0 _H to 03B0 _H	02C0 _H to 03B0 _H
52	ICADCA0ERR	6068 _H	INTADCA0ERR	Error interrupt	ADCA0	53	03C0 _H	03C0 _H
53	ICADCA0I0	606A _H	INTADCA0I0	End of CG0 conversion	ADCA0	54	03D0 _H	03D0 _H
54	ICADCA0I1	606C _H	INTADCA0I1	End of CG1 conversion	ADCA0	55	03E0 _H	03E0 _H
55	ICADCA0I2	606E _H	INTADCA0I2	End of CG2 conversion	ADCA0	56	03F0 _H	03F0 _H
56	ICADCA0LLT	6070 _H	INTADCA0LLT	Conversion interrupt	ADCA0	57	0400 _H	0400 _H

Table 4-11 V850E2/FF4-G EI level maskable interrupt requests (2/3)

Channel	Interrupt		Interrupt request			Default priority	Exception code	Handler address offset
	Control register		Name	Cause	Unit			
	Name	Address FFFF...						
57	ICFCNWUP	6072 _H	INTFCNWUP	Wake up interrupt	FCN [5:0] ^a	58	0410 _H	0410 _H
58	—	6074 _H	reserved			59	0420 _H	0420 _H
59	—	6076 _H	reserved			60	0430 _H	0430 _H
60	ICFCN0ERR	6078 _H	INTFCN0ERR	Error interrupt	FCN0	61	0440 _H	0440 _H
61	ICFCN0REC	607A _H	INTFCN0REC	Receive interrupt	FCN0	62	0450 _H	0450 _H
62	ICFCN0TRX	607C _H	INTFCN0TRX	Transmit interrupt	FCN0	63	0460 _H	0460 _H
63	ICCSIG0IRE	607E _H	INTCSIG0IRE	Reception error interrupt	CSIG0	64	0470 _H	0470 _H
64	ICCSIG0IR	6080 _H	INTCSIG0IR	Reception status interrupt	CSIG0	65	0480 _H	0480 _H
65	ICCSIG0IC	6082 _H	INTCSIG0IC	Communication status interrupt	CSIG0	66	0490 _H	0490 _H
66	ICDMA0	6084 _H	INTDMA0	DMA channel 0 transfer completion	DMA	67	04A0 _H	04A0 _H
67	ICDMA1	6086 _H	INTDMA1	DMA channel 1 transfer completion	DMA	68	04B0 _H	04B0 _H
68	ICDMA2	6088 _H	INTDMA2	DMA channel 2 transfer completion	DMA	69	04C0 _H	04C0 _H
69	ICDMA3	608A _H	INTDMA3	DMA channel 3 transfer completion	DMA	70	04D0 _H	04D0 _H
70	ICDMA4	608C _H	INTDMA4	DMA channel 4 transfer completion	DMA	71	04E0 _H	04E0 _H
71	ICDMA5	608E _H	INTDMA5	DMA channel 5 transfer completion	DMA	72	04F0 _H	04F0 _H
72	ICDMA6	6090 _H	INTDMA6	DMA channel 6 transfer completion	DMA	73	0500 _H	0500 _H
73	ICDMA7	6092 _H	INTDMA7	DMA channel 7 transfer completion	DMA	74	0510 _H	0510 _H
74	ICIICB0IA	6094 _H	INTIICB0IA	Data transmission/reception interrupt	IICB0	75	0520 _H	0520 _H
75	ICFCN1ERR	6096 _H	INTFCN1ERR	Error interrupt	FCN1	76	0530 _H	0530 _H
76	ICFCN1REC	6098 _H	INTFCN1REC	Receive interrupt	FCN1	77	0540 _H	0540 _H
77	ICFCN1TRX	609A _H	INTFCNTRX	Transmit interrupt	FCN1	78	0550 _H	0550 _H
78	ICTAUJ0I0	609C _H	INTTAUJ0I0	Interrupt for channel 0	TAUJ0	79	0560 _H	0560 _H
79	ICTAUJ0I1	609E _H	INTTAUJ0I1	Interrupt for channel 1	TAUJ0	80	0570 _H	0570 _H
80	ICTAUJ0I2	60A0 _H	INTTAUJ0I2	Interrupt for channel 2	TAUJ0	81	0580 _H	0580 _H
81	ICTAUJ0I3	60A2 _H	INTTAUJ0I3	Interrupt for channel 3	TAUJ0	82	0590 _H	0590 _H
82	ICOSTM0	60A4 _H	INTOSTM0	OSTM0 interrupt	OSTM0	83	05A0 _H	05A0 _H
83	ICCSIG4IRE	60A6 _H	INTCSIG4IRE	Reception error interrupt	CSIG4	84	05B0 _H	05B0 _H
84	ICCSIG4IR	60A8 _H	INTCSIG4IR	Reception status interrupt	CSIG4	85	05C0 _H	05C0 _H
85	ICCSIG4IC	60AA _H	INTCSIG4IC	Communication status interrupt	CSIG4	86	05D0 _H	05D0 _H
86 to 100	—	60AC _H to 60C8 _H	reserved			87 to 101	05E0 _H to 06C0 _H	05E0 _H to 06C0 _H
101	ICP11	60CA _H	INTP11	Edge detection interrupt	Port	102	06D0 _H	06D0 _H
102	ICP12	60CC _H	INTP12	Edge detection interrupt	Port	103	06E0 _H	06E0 _H
103 to 105	—	60CE _H to 60D2 _H	reserved			104 to 106	06F0 _H to 0710 _H	06F0 _H to 0710 _H
106	ICKR0	60D4 _H	INTKR0	Key return interrupt	KR0	107	0720 _H	0720 _H
107	ICLMA10IS	60D6 _H	INTLMA10IS	Status interrupt	LMA10	108	0730 _H	0730 _H
108	ICLMA10IR	60D8 _H	INTLMA10IR	Reception completion interrupt	LMA10	109	0740 _H	0740 _H
109	ICLMA10IT	60DA _H	INTLMA10IT	Transmission interrupt	LMA10	110	0750 _H	0750 _H

Table 4-11 V850E2/FF4-G EI level maskable interrupt requests (3/3)

Interrupt			Interrupt request			Default priority	Exception code	Handler address offset
Channel	Control register		Name	Cause	Unit			
	Name	Address FFFF...						
110	ICLMA11IS	60DC _H	INTLMA11IS	Status interrupt	LMA11	111	0760 _H	0760 _H
111	ICLMA11IR	60DE _H	INTLMA11IR	Reception completion interrupt	LMA11	112	0770 _H	0770 _H
112	ICLMA11IT	60E0 _H	INTLMA11IT	Transmission interrupt	LMA11	113	0780 _H	0780 _H
113	ICFCN2ERR	60E2 _H	INTFCN2ERR	Error interrupt	FCN2	114	0790 _H	0790 _H
114	ICFCN2REC	60E4 _H	INTFCN2REC	Receive interrupt	FCN2	115	07A0 _H	07A0 _H
115	ICFCN2TRX	60E6 _H	INTFCN2TRX	Transmit interrupt	FCN2	116	07B0 _H	07B0 _H
116	ICFCN3ERR ^b	60E8 _H	INTFCN3ERR	Error interrupt	FCN3	117	07C0 _H	07C0 _H
117	ICFCN3REC ^b	60EA _H	INTFCN3REC	Receive interrupt	FCN3	118	07D0 _H	07D0 _H
118	ICFCN3TRX ^b	60EC _H	INTFCN3TRX	Transmit interrupt	FCN3	119	07E0 _H	07E0 _H
119	ICFCN4ERR ^b	60EE _H	INTFCN4ERR	Error interrupt	FCN4	120	07F0 _H	07F0 _H
120	ICFCN4REC ^b	60F0 _H	INTFCN4REC	Receive interrupt	FCN4	121	0800 _H	0800 _H
121	ICFCN4TRX ^b	60F2 _H	INTFCN4TRX	Transmit interrupt	FCN4	122	0810 _H	0810 _H
122	ICFCN5ERR ^b	60F4 _H	INTFCN5ERR	Error interrupt	FCN5	123	0820 _H	0820 _H
123	ICFCN5REC ^b	60F6 _H	INTFCN5REC	Receive interrupt	FCN5	124	0830 _H	0830 _H
124	ICFCN5TRX ^b	60F8 _H	INTFCN5TRX	Transmit interrupt	FCN5	125	0840 _H	0840 _H
125 to 127	–	60FA _H to 60FE _H	reserved			126 to 128	0850 _H to 0870 _H	0850 _H to 0870 _H

- a) In μ PD70F4177, the target of this interrupt is FCN[2:0].
b) This interrupt is not available in μ PD70F4177.

(4) V850E2/FG4-G EI level maskable interrupts

Table 4-12 V850E2/FG4-G EI level maskable interrupt requests (1/3)

Channel	Interrupt		Interrupt request			Default priority	Exception code	Handler address offset
	Control register		Name	Cause	Unit			
	Name	Address FFFF...						
0	ICWDTA0	6000 _H	INTWDTA0	WDTA0 75% interrupt	WDTA0	1	0080 _H	0080 _H
1	ICWDTA1	6002 _H	INTWDTA1	WDTA1 75% interrupt	WDTA1	2	0090 _H	0090 _H
2	ICLVI	6004 _H	INTLVI	LVI interrupt	LVI	3	00A0 _H	00A0 _H
3 to 8	–	6006 _H to 6010 _H	reserved			4 to 9	00B0 _H to 0100 _H	00B0 _H to 0100 _H
9	ICP0	6012 _H	INTP0	Edge detection interrupt	Port	10	0110 _H	0110 _H
10	ICP1	6014 _H	INTP1	Edge detection interrupt	Port	11	0120 _H	0120 _H
11	ICP2	6016 _H	INTP2	Edge detection interrupt	Port	12	0130 _H	0130 _H
12	ICP3	6018 _H	INTP3	Edge detection interrupt	Port	13	0140 _H	0140 _H
13	ICP4	601A _H	INTP4	Edge detection interrupt	Port	14	0150 _H	0150 _H
14	ICP5	601C _H	INTP5	Edge detection interrupt	Port	15	0160 _H	0160 _H
15	ICP6	601E _H	INTP6	Edge detection interrupt	Port	16	0170 _H	0170 _H
16	ICP7	6020 _H	INTP7	Edge detection interrupt	Port	17	0180 _H	0180 _H
17	ICP8	6022 _H	INTP8	Edge detection interrupt	Port	18	0190 _H	0190 _H
18	ICP9	6024 _H	INTP9	Edge detection interrupt	Port	19	01A0 _H	01A0 _H
19	ICP10	6026 _H	INTP10	Edge detection interrupt	Port	20	01B0 _H	01B0 _H
20	ICTAUB0I0	6028 _H	INTTAUB0I0	Interrupt for channel 0	TAUB0	21	01C0 _H	01C0 _H
21	ICTAUB0I1	602A _H	INTTAUB0I1	Interrupt for channel 1	TAUB0	22	01D0 _H	01D0 _H
22	ICTAUB0I2	602C _H	INTTAUB0I2	Interrupt for channel 2	TAUB0	23	01E0 _H	01E0 _H
23	ICTAUB0I3	602E _H	INTTAUB0I3	Interrupt for channel 3	TAUB0	24	01F0 _H	01F0 _H
24	ICTAUB0I4	6030 _H	INTTAUB0I4	Interrupt for channel 4	TAUB0	25	0200 _H	0200 _H
25	ICTAUB0I5	6032 _H	INTTAUB0I5	Interrupt for channel 5	TAUB0	26	0210 _H	0210 _H
26	ICTAUB0I6	6034 _H	INTTAUB0I6	Interrupt for channel 6	TAUB0	27	0220 _H	0220 _H
27	ICTAUB0I7	6036 _H	INTTAUB0I7	Interrupt for channel 7	TAUB0	28	0230 _H	0230 _H
28	ICTAUB0I8	6038 _H	INTTAUB0I8	Interrupt for channel 8	TAUB0	29	0240 _H	0240 _H
29	ICTAUB0I9	603A _H	INTTAUB0I9	Interrupt for channel 9	TAUB0	30	0250 _H	0250 _H
30	ICTAUB0I10	603C _H	INTTAUB0I10	Interrupt for channel 10	TAUB0	31	0260 _H	0260 _H
31	ICTAUB0I11	603E _H	INTTAUB0I11	Interrupt for channel 11	TAUB0	32	0270 _H	0270 _H
32	ICTAUB0I12	6040 _H	INTTAUB0I12	Interrupt for channel 12	TAUB0	33	0280 _H	0280 _H
33	ICTAUB0I13	6042 _H	INTTAUB0I13	Interrupt for channel 13	TAUB0	34	0290 _H	0290 _H
34	ICTAUB0I14	6044 _H	INTTAUB0I14	Interrupt for channel 14	TAUB0	35	02A0 _H	02A0 _H
35	ICTAUB0I15	6046 _H	INTTAUB0I15	Interrupt for channel 15	TAUB0	36	02B0 _H	02B0 _H
36 to 51	–	6048 _H to 6066 _H	reserved			37 to 52	02C0 _H to 03B0 _H	02C0 _H to 03B0 _H
52	ICADCA0ERR	6068 _H	INTADCA0ERR	Error interrupt	ADCA0	53	03C0 _H	03C0 _H
53	ICADCA0I0	606A _H	INTADCA0I0	End of CG0 conversion	ADCA0	54	03D0 _H	03D0 _H
54	ICADCA0I1	606C _H	INTADCA0I1	End of CG1 conversion	ADCA0	55	03E0 _H	03E0 _H
55	ICADCA0I2	606E _H	INTADCA0I2	End of CG2 conversion	ADCA0	56	03F0 _H	03F0 _H
56	ICADCA0LLT	6070 _H	INTADCA0LLT	Conversion interrupt	ADCA0	57	0400 _H	0400 _H

Table 4-12 V850E2/FG4-G EI level maskable interrupt requests (2/3)

Channel	Interrupt		Interrupt request			Default priority	Exception code	Handler address offset
	Control register		Name	Cause	Unit			
	Name	Address FFFF...						
57	ICFCNWUP	6072 _H	INTFCNWUP	Wake up interrupt	FCN [5:0] ^a	58	0410 _H	0410 _H
58	–	6074 _H	reserved			59	0420 _H	0420 _H
59	–	6076 _H	reserved			60	0430 _H	0430 _H
60	ICFCN0ERR	6078 _H	INTFCN0ERR	Error interrupt	FCN0	61	0440 _H	0440 _H
61	ICFCN0REC	607A _H	INTFCN0REC	Receive interrupt	FCN0	62	0450 _H	0450 _H
62	ICFCN0TRX	607C _H	INTFCN0TRX	Transmit interrupt	FCN0	63	0460 _H	0460 _H
63	ICCSIG0IRE	607E _H	INTCSIG0IRE	Reception error interrupt	CSIG0	64	0470 _H	0470 _H
64	ICCSIG0IR	6080 _H	INTCSIG0IR	Reception status interrupt	CSIG0	65	0480 _H	0480 _H
65	ICCSIG0IC	6082 _H	INTCSIG0IC	Communication status interrupt	CSIG0	66	0490 _H	0490 _H
66	ICDMA0	6084 _H	INTDMA0	DMA channel 0 transfer completion	DMA	67	04A0 _H	04A0 _H
67	ICDMA1	6086 _H	INTDMA1	DMA channel 1 transfer completion	DMA	68	04B0 _H	04B0 _H
68	ICDMA2	6088 _H	INTDMA2	DMA channel 2 transfer completion	DMA	69	04C0 _H	04C0 _H
69	ICDMA3	608A _H	INTDMA3	DMA channel 3 transfer completion	DMA	70	04D0 _H	04D0 _H
70	ICDMA4	608C _H	INTDMA4	DMA channel 4 transfer completion	DMA	71	04E0 _H	04E0 _H
71	ICDMA5	608E _H	INTDMA5	DMA channel 5 transfer completion	DMA	72	04F0 _H	04F0 _H
72	ICDMA6	6090 _H	INTDMA6	DMA channel 6 transfer completion	DMA	73	0500 _H	0500 _H
73	ICDMA7	6092 _H	INTDMA7	DMA channel 7 transfer completion	DMA	74	0510 _H	0510 _H
74	ICIICB0IA	6094 _H	INTIICB0IA	Data transmission/reception interrupt	IICB0	75	0520 _H	0520 _H
75	ICFCN1ERR	6096 _H	INTFCN1ERR	Error interrupt	FCN1	76	0530 _H	0530 _H
76	ICFCN1REC	6098 _H	INTFCN1REC	Receive interrupt	FCN1	77	0540 _H	0540 _H
77	ICFCN1TRX	609A _H	INTFCN1TRX	Transmit interrupt	FCN1	78	0550 _H	0550 _H
78	ICTAUJ0I0	609C _H	INTTAUJ0I0	Interrupt for channel 0	TAUJ0	79	0560 _H	0560 _H
79	ICTAUJ0I1	609E _H	INTTAUJ0I1	Interrupt for channel 1	TAUJ0	80	0570 _H	0570 _H
80	ICTAUJ0I2	60A0 _H	INTTAUJ0I2	Interrupt for channel 2	TAUJ0	81	0580 _H	0580 _H
81	ICTAUJ0I3	60A2 _H	INTTAUJ0I3	Interrupt for channel 3	TAUJ0	82	0590 _H	0590 _H
82	ICOSTM0	60A4 _H	INTOSTM0	OSTM0 interrupt	OSTM0	83	05A0 _H	05A0 _H
83	ICCSIG4IRE	60A6 _H	INTCSIG4IRE	Reception error interrupt	CSIG4	84	05B0 _H	05B0 _H
84	ICCSIG4IR	60A8 _H	INTCSIG4IR	Reception status interrupt	CSIG4	85	05C0 _H	05C0 _H
85	ICCSIG4IC	60AA _H	INTCSIG4IC	Communication status interrupt	CSIG4	86	05D0 _H	05D0 _H
86 to 88	–	60AC _H to 60B0 _H	reserved			87 to 89	05E0 _H to 0600 _H	05E0 _H to 0600 _H
89	ICLMA2IS	60B2 _H	INTLMA2IS	Status interrupt	LMA2	90	0610 _H	0610 _H
90	ICLMA2IR	60B4 _H	INTLMA2IR	Reception completion interrupt	LMA2	91	0620 _H	0620 _H
91	ICLMA2IT	60B6 _H	INTLMA2IT	Transmission interrupt	LMA2	92	0630 _H	0630 _H
92 to 97	–	60B8 _H to 60C2 _H	reserved			93 to 98	0640 _H to 0690 _H	0640 _H to 0690 _H
98	ICCSIG7IRE	60C4 _H	INTCSIG7IRE	Reception error interrupt	CSIG7	99	06A0 _H	06A0 _H
99	ICCSIG7IR	60C6 _H	INTCSIG7IR	Reception status interrupt	CSIG7	100	06B0 _H	06B0 _H
100	ICCSIG7IC	60C8 _H	INTCSIG7IC	Communication status interrupt	CSIG7	101	06C0 _H	06C0 _H

Table 4-12 V850E2/FG4-G EI level maskable interrupt requests (3/3)

Interrupt			Interrupt request			Default priority	Exception code	Handler address offset
Channel	Control register		Name	Cause	Unit			
	Name	Address FFFF...						
101	ICP11	60CA _H	INTP11	Edge detection interrupt	Port	102	06D0 _H	06D0 _H
102	ICP12	60CC _H	INTP12	Edge detection interrupt	Port	103	06E0 _H	06E0 _H
103 to 105	–	60CE _H to 60D2 _H	reserved			104 to 106	06F0 _H to 0710 _H	06F0 _H to 0710 _H
106	ICKR0	60D4 _H	INTKR0	Key return interrupt	KR0	107	0720 _H	0720 _H
107	ICLMA10IS	60D6 _H	INTLMA10IS	Status interrupt	LMA10	108	0730 _H	0730 _H
108	ICLMA10IR	60D8 _H	INTLMA10IR	Reception completion interrupt	LMA10	109	0740 _H	0740 _H
109	ICLMA10IT	60DA _H	INTLMA10IT	Transmission interrupt	LMA10	110	0750 _H	0750 _H
110	ICLMA11IS	60DC _H	INTLMA11IS	Status interrupt	LMA11	111	0760 _H	0760 _H
111	ICLMA11IR	60DE _H	INTLMA11IR	Reception completion interrupt	LMA11	112	0770 _H	0770 _H
112	ICLMA11IT	60E0 _H	INTLMA11IT	Transmission interrupt	LMA11	113	0780 _H	0780 _H
113	ICFCN2ERR	60E2 _H	INTFCN2ERR	Error interrupt	FCN2	114	0790 _H	0790 _H
114	ICFCN2REC	60E4 _H	INTFCN2REC	Receive interrupt	FCN2	115	07A0 _H	07A0 _H
115	ICFCN2TRX	60E6 _H	INTFCN2TRX	Transmit interrupt	FCN2	116	07B0 _H	07B0 _H
116	ICFCN3ERR ^b	60E8 _H	INTFCN3ERR	Error interrupt	FCN3	117	07C0 _H	07C0 _H
117	ICFCN3REC ^b	60EA _H	INTFCN3REC	Receive interrupt	FCN3	118	07D0 _H	07D0 _H
118	ICFCN3TRX ^b	60EC _H	INTFCN3TRX	Transmit interrupt	FCN3	119	07E0 _H	07E0 _H
119	ICFCN4ERR ^b	60EE _H	INTFCN4ERR	Error interrupt	FCN4	120	07F0 _H	07F0 _H
120	ICFCN4REC ^b	60F0 _H	INTFCN4REC	Receive interrupt	FCN4	121	0800 _H	0800 _H
121	ICFCN4TRX ^b	60F2 _H	INTFCN4TRX	Transmit interrupt	FCN4	122	0810 _H	0810 _H
122	ICFCN5ERR ^b	60F4 _H	INTFCN5ERR	Error interrupt	FCN5	123	0820 _H	0820 _H
123	ICFCN5REC ^b	60F6 _H	INTFCN5REC	Receive interrupt	FCN5	124	0830 _H	0830 _H
124	ICFCN5TRX ^b	60F8 _H	INTFCN5TRX	Transmit interrupt	FCN5	125	0840 _H	0840 _H
125 to 127	–	60FA _H to 60FE _H	reserved			126 to 128	0850 _H to 0870 _H	0850 _H to 0870 _H

- a) In μ PD70F4179, the target of this interrupt is FCN[2:0].
b) This interrupt is not available in μ PD70F4179.

4.3.2 FE level non-maskable interrupt sharing

The FE level non-maskable interrupt FENMI is shared among several interrupt sources.

(1) FENMIF - FENMI factor register

This register contains information about which interrupt has generated the FE level non-maskable interrupt FENMI.

Access This register can be read in 32-bit units.

Address FF45 0000_H

Initial Value 0000 0000_H. This register is initialized by any reset.

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	0	0	0	0	0	WDTA1 NMIF	WDTA0 NMIF	NMIOF
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Table 4-13 FENMIF register contents

Bit position	Bit name	Function
2	WDTA1NMIF	Watchdog Timer WDTA1NMIF flag 0: no WDTA1NMIF occurred 1: WDTA1NMIF has occurred
1	WDTA0NMIF	Watchdog Timer WDTA0NMIF flag 0: no WDTA0NMIF occurred 1: WDTA0NMIF has occurred
0	NMIOF	Port interrupt NMIO flag 0: no NMIO occurred 1: NMIO has occurred

(2) FENMIFC - FENMI factor clear register

This register clears the FE level non-maskable flags of the FENMIF register.

Access This register can be written in 32-bit units.

Address FF45 0008_H

Initial Value Reading this registers returns always 0000 0000_H.

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
W	W	W	W	W	W	W	W	W	W	W	W	W	W	W	W
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	0	0	0	0	0	WDTA1 NMIFC	WDTA0 NMIFC	NMIOFC
W	W	W	W	W	W	W	W	W	W	W	W	W	W	W	W

Table 4-14 FENMIFC register contents

Bit position	Bit name	Function
2	WDTA1NMI FC	Watchdog Timer WDTA1NMIF flag clear 0: no function 1: clear FENMIF.WDTA1NMIF
1	WDTA0NMI FC	Watchdog Timer WDTA0NMIF flag clear 0: no function 1: clear FENMIF.WDTA0NMIF
0	NMIO FC	Port interrupt NMIO flag clear 0: no function 1: clear FENMIF.NMIOF

4.4 External Interrupts

4.4.1 Edge Detection Configuration

The external interrupts can be configured to generate an interrupt request upon a rising or falling edge or upon both edges of the external pin.

Following registers are used to specify the edge:

Table 4-15 External interrupt edge detection registers

Interrupt	Register
INTP0	FCLA0CTL0
INTP1	FCLA0CTL1
INTP2	FCLA0CTL2
INTP3	FCLA0CTL3
INTP4	FCLA0CTL4
INTP5	FCLA0CTL5
INTP6	FCLA0CTL6
INTP7	FCLA0CTL7
INTP8	FCLA1CTL0
INTP9	FCLA1CTL1
INTP10	FCLA1CTL2
INTP11	FCLA1CTL3
INTP12	FCLA1CTL4
NMI	FCLA2CTL0

Refer to the section “Port filters assignment” in the chapter “Port Functions” for details of these registers.

4.4.2 External interrupts as trigger and wake-up signals

The external interrupts can be used as

- DMA trigger factors
- A/D Converter H/W triggers
- stand-by wake-up factors

Table 4-16 External interrupts as triggers and wake-up

Interrupt	DMA trigger factor ^a	ADAA _n H/W trigger ^b	Stand-by wake-up factor ^c
INTP0	1	ADAA0TTIN201	WUFLm07
INTP1	2	ADAA0TTIN101	WUFLm08
INTP2	3	ADAA0TTIN001	WUFLm09
INTP3	4	ADAA0TTIN202	WUFLm10
INTP4	5	ADAA0TTIN102	WUFLm11
INTP5	6	ADAA0TTIN002	WUFLm12
INTP6	7	–	WUFLm13
INTP7	8	–	WUFLm14
INTP8	9	–	WUFLm15
INTP9	10	–	WUFLm16
INTP10	11	–	WUFLm17
INTP11	–	–	WUFLm18
INTP12	–	–	WUFLm19
NMI	–	–	WUFLm00

a) Refer to the chapter 5 “DMA Controller (DMAC)” on page 196 for details.

b) Refer to the chapter 22 “A/D Converter (ADAA)” on page 1143 for details.

c) The stand-by wake-up factors are indicated by their respective bit in the wake-up factor register WUFLm. refer to the chapter 8 “Stand-by Controller (STBC)” on page 322 for details.

Stand-by wake-up To use an external interrupt as a wake-up factor from DEEPSTOP mode, its analog filter must be set to edge detection mode (FCLAnINT_m = 0). Refer to the section “Port Filters Functional Description” in the “Port Functions” chapter for details.

4.5 Interrupt Controller Control Registers

(1) ICn - EI level interrupt control registers (n = 0 to 255)

These registers, each of which is for a channel n of EI level maskable interrupt INTn, are used to set a condition to control each channel.

Caution Do not access ICn registers of interrupt channels, not listed in above interrupt request tables.

Access These registers can be read/written in

- 16-bit units
 - via 16-bit registers ICn
- 8-bit or 1-bit units
 - bits 7 to 0 via 8-bit registers ICnL
 - bits 15 to 8 via 8-bit registers ICnH.

Address ICn: FFFF 6000_H + 2n
 ICnL: FFFF 6000_H + 2n, ICnH: FFFF 6001_H + 2n

Initial Value 008F_H. This register is initialized by any reset.

15	14	13	12	11	10	9	8
0	0	0	RFn	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
7	6	5	4	3	2	1	0
MKn	0	0	0	0	P[2:0]n		
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 4-17 ICn register contents (1/2)

Bit position	Bit name	Function
12	RFn	Interrupt request flag RFn is set upon occurrence of an EI level maskable interrupt INTn. RFn can also be set by the application program, which generates also an EI level maskable interrupt. 0: no interrupt request 1: interrupt request RFn is reset if the interrupt is acknowledged, i.e. the interrupt service routine is started. RFn can also be reset by the application program.

Table 4-17 ICn register contents (2/2)

Bit position	Bit name	Function
7	MKn	<p>Interrupt mask bit</p> <p>When the MKn bit is set, the interrupt request set to the interrupt request flag RFn is masked, so that the interrupt request is not issued from that channel to the CPU. From a channel with the MKn bit set, interrupt pending status is not displayed by the ICSR.PMF bit. The MKn bit does not mask a signal input from an interrupt input itself and, therefore, the corresponding interrupt request flag is set even when the MKn bit is set. The setting of the corresponding bit of the interrupt mask register IMR is also reflected.</p> <p>0: enables interrupt servicing 1: disables interrupt servicing</p>
2 to 0	P[2:0]n	<p>These bits specify 8 levels of interrupt priorities. The highest priority is 0 and the lowest is 7.</p> <p>If two or more interrupt requests of EI level are generated at the same time, the interrupt source having the higher priority specified by these bits is selected and reported to the CPU. If the priority specified by the P[2:0]n bits is the same, the source having the lower channel number is selected by a fixed priority.</p>

(2) IMRm - EI level interrupt mask registers (m = 0 to 15)

These registers are a collection of the MKn bits of the ICn registers. Each bit of IMRm reflects the setting of the corresponding ICn.MKn bit. Setting IMRm is reflected in the corresponding MKn bit.

Caution MKn bits for interrupt channels, not listed in above interrupt request tables, must be set to 1.

Access These registers can be read/written in:

- 16-bit units
 - via 16-bit registers IMRm
- 8-bit or 1-bit units
 - bits 7 to 0 via 8-bit registers IMRmL
 - bits 15 to 8 via 8-bit registers IMRmH.

Address

IMR0: FFFF 6400 _H	IMR1: FFFF 6402 _H
IMR2: FFFF 6404 _H	IMR3: FFFF 6406 _H
IMR4: FFFF 6408 _H	IMR5: FFFF 640A _H
IMR6: FFFF 640C _H	IMR7: FFFF 640E _H
IMR8: FFFF 6410 _H	IMR9: FFFF 6412 _H
IMR10: FFFF 6414 _H	IMR11: FFFF 6416 _H
IMR12: FFFF 6418 _H	IMR13: FFFF 641A _H
IMR14: FFFF 641C _H	IMR15: FFFF 641E _H
IMRmL: address of IMRm	IMRmH: address of IMRm + 1

Initial Value FFFF_H. This register is initialized by any reset.

15	14	13	12	11	10	9	8
IMRmMK m x 16 + 15	IMRmMK m x 16 + 14	IMRmMK m x 16 + 13	IMRmMK m x 16 + 12	IMRmMK m x 16 + 11	IMRmMK m x 16 + 10	IMRmMK m x 16 + 9	IMRmMK m x 16 + 8
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
7	6	5	4	3	2	1	0
IMRmMK m x 16 + 7	IMRmMK m x 16 + 6	IMRmMK m x 16 + 5	IMRmMK m x 16 + 4	IMRmMK m x 16 + 3	IMRmMK m x 16 + 2	IMRmMK m x 16 + 1	IMRmMK m x 16 + 0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 4-18 IMRm registers contents

Bit position	Bit name	Function
15 to 0	IMRmMK255 to IMRmMK0	These bits mask an interrupt from channels n = 0 to 255 of EI level maskable interrupt INTn. 0: interrupt request issued 1: interrupt request not issued

(3) ISPR - In-service priority register

This register holds the interrupt priority of an EI level maskable interrupt INT_n that is being processed by the CPU.

ISPR[7:0] setting When the CPU enters an interrupt service routine, i.e. acknowledges the interrupt, with interrupt request priority IC_n.P[2:0]_n = 0 to 7, the bit ISPR[7:0] of this register, corresponding to this priority, is set.

ISPR[7:0] clearing When the CPU has completed the interrupt service routine by the EIRET instruction, the ISPR[7:0] bit, that was set upon entering this interrupt service routine, is cleared.
Since the interrupt service routine with the highest priority is always completed first, the cleared bit is always the one, that corresponds to the highest priority.

Nested interrupt services If multiple EI level maskable interrupts with different priorities IC_n.P[2:0]_n have been acknowledged by the CPU (lower prioritized interrupt service routines have been interrupted by higher prioritized), the corresponding ISPR[7:0] bits of all interrupts in service are sequentially set.

ISPR[7:0] clearing by software Clearing this register is protected by a special sequence, involving the in-service priority clear register ISPC register.
All ISPR[7:0] bits can be cleared only all together by use of ISPC. For that purpose ISPC has to be written with FFFF_H, followed by writing 0000_H to ISPR.
Note that it is not possible to clear single ISPR[7:0] bits.
Refer also to 5 "ISPC - In-service priority clear register" on page 176 .

Access This register can be accessed as follows:

- writing 0000_H via the 16-bit register ISPR for clearing all ISPR[7:0], after ISPC has been written with FFFF_H
- reading
 - in 16-bit units via the 16-bit register ISPR
 - ISPR[7:0] in 8-bit units via the 8-bit register ISPRL

Address ISPR: FFFF 6440_H
ISPRL: FFFF 6440_H

Initial Value 0000_H. This register is initialized by any reset.

15	14	13	12	11	10	9	8
0	0	0	0	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
7	6	5	4	3	2	1	0
ISPR7	ISPR6	ISPR5	ISPR4	ISPR3	ISPR2	ISPR1	ISPR0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 4-19 ISPR register contents

Bit position	Bit name	Function
7 to 0	ISPR7 to ISPR0	These bits indicate the priority of the interrupt being acknowledged. 0: Interrupt request of the priority corresponding to the bit position is not acknowledged. 1: Interrupt request of the priority corresponding to the bit position is being processed by the CPU.

(4) PMR - Priority mask register

This register specifies an interrupt priority by which an interrupt request flag of EI level maskable interrupt INTn is to be masked. It disables all at once the interrupt requests from the INTn channel for which the interrupt priority specified by this register is set.

The position of each bit of this register corresponds to an interrupt priority. For example, if 1 is set to bit 0, channel of interrupt priority 0 can be masked.

Access This register can be read/written in

- in 16-bit units via the 16-bit register PMR
- PMR[7:0] in 8-bit or 1-bit units via the 8-bit register PMRL.

Address PMR: FFFF 6448_H
PMRL: FFFF 6448_H

Access This register can be read/written in 16-bit or 8-bit or 1-bit units.

Address FFFF 6448_H

Initial Value 0000_H. This register is initialized by any reset.

15	14	13	12	11	10	9	8
0	0	0	0	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
7	6	5	4	3	2	1	0
PMR7	PMR6	PMR5	PMR4	PMR3	PMR2	PMR1	PMR0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 4-20 PMR register contents

Bit position	Bit name	Function
7 to 0	PMR7 to PMR0	These bits specify an interrupt priority by which an interrupt request flag 0: Enables interrupt servicing of the priority corresponding to a specified bit position. 1: Disables interrupt servicing of the priority corresponding to a specified bit position.

(5) ISPC - In-service priority clear register

This register prepares to clear the in-service priority register ISPR.

For clearing ISPR proceed as follows:

1. write FFFF_H to ISPC
2. write 0000_H to ISPR

As a result, the internal mode registers of the Interrupt Controller for interrupt servicing, which indicate that an interrupt request is being processed by the CPU, are cleared.

At the same time, all the processing modes of FE level NMI, FE level maskable interrupt FEINT, and EI level maskable interrupts INT_n of the ICSR register are canceled.

After writing FFFF_H to ISPC, FFFF_H is also read back until ISPR has been cleared by writing ISPR = 0000_H. Afterwards ISPC is automatically cleared to 0000_H.

Before writing ISPR = 0000_H, ISPC can be reset by writing 0000_H, and thus disabling any ISPR clear attempt.

ISPC can only be written with FFFF_H or 0000_H. Writing any other value does not change the register content.

Refer also to 3 "ISPR - In-service priority register" on page 174 .

Caution Writing FFFF_H to ISPC and 0000_H to ISPR in order to clear ISPR does not need to maintain any time relation to each other. In particular this means, that any kind of other processes may take place between both write accesses.

Access This register can be read/written in 16-bit units.

Address FFFF 6450_H

Initial Value 0000_H. This register is initialized by any reset.

15	14	13	12	11	10	9	8
ISPC[15:8]							
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
7	6	5	4	3	2	1	0
ISPC[7:0]							
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 4-21 ISPC register contents

Bit position	Bit name	Function
15 to 0	ISPC[15:0]	ISPR clear preparation <ul style="list-style-type: none"> • writing FFFF_H: enables ISPR to be cleared by ISPR = 0000_H • writing 0000_H: disables ISPR to be cleared If ISPR has been cleared after ISPC. = FFFF _H , ISPC returns to 0000 _H automatically.

(6) SCR - Selected channel hold register

This register holds the channel number n of the EI level maskable interrupt INT_n , acknowledged by the CPU.

Access This register can be read only in

- in 16-bit units:
 - via 16-bit register SCR
- in 8-bit units:
 - SCR[7:0] via 8-bit register SCRL.

Address SCR: FFFF 6458_H
SCRL: FFFF 6458_H

Access This register can be read only in 16-bit or 8-bit units.

Address FFFF 6458_H

Initial Value 0000_H. This register is initialized by any reset.

15	14	13	12	11	10	9	8
0	0	0	0	0	0	0	0
R	R	R	R	R	R	R	R
7	6	5	4	3	2	1	0
SCR[7:0]							
R	R	R	R	R	R	R	R

Table 4-22 SCR register contents

Bit position	Bit name	Function
7 to 0	SCR[7:0]	Holds the channel number n of the maskable interrupt that has been acknowledged by the CPU. The value of these bits is updated when an interrupt vector is reported to the CPU. It is overwritten when multiple interrupts of EI level maskable interrupt (INT_n) are acknowledged. These bits are not updated when an FE level interrupt is acknowledged. Writing to this register is ignored.

(7) ICSR - Interrupt controller status register

This register indicates the operation status of the Interrupt Controller. Especially the FNE, FIE and EIE of this register serve as a mode register of interrupt servicing.

Access This register can be read only in

- 16-bit units:
 - via 16-bit register ICSR
- 8-bit or 1-bit units:
 - bits 7 to 0 via 8-bit register ICSRL
 - bits 15 to 8 via 8-bit register ICSRH

Address ICSR: FFFF 645A_H
ICSRL: FFFF 645A_H, ICSRH: FFFF 645B_H

Initial Value 0000_H. This register is initialized by any reset.

15	14	13	12	11	10	9	8
0	0	0	0	0	0	0	PMF
R	R	R	R	R	R	R	R
7	6	5	4	3	2	1	0
0	FNR	FIR	EIR	0	FNE	FIE	EIE
R	R	R	R	R	R	R	R

Table 4-23 ICSR register contents

Bit position	Bit name	Function
8	PMF	Indicates 1 if the request flag of a channel n of EI level interrupt INT _n , that has the interrupt priority prohibited by the setting of PMR from being serviced, is set.
6	FNR	Indicates 1 if an FE level non-maskable interrupt FENMI has been issued to the CPU.
5	FIR	Indicates 1 if an FE level maskable interrupt FEINT has been issued to the CPU.
4	EIR	Indicates 1 if an EI level maskable interrupt INT _n has been issued to the CPU.
2	FNE	Indicates 1 if the CPU is processing the FE level non-maskable interrupt FENMI.
1	FIE	Indicates 1 if the CPU is processing the FE level maskable interrupt FEINT.
0	EIE	Indicates 1 if the CPU is processing the EI level maskable interrupt INT _n .

(8) FNC - FE level NMI status register

This register informs about the occurrence of a FE level non-maskable interrupt FENMI.

Access This register can be read only in

- 16-bit units:
 - via 16-bit register FNC
- 8-bit or 1-bit units:
 - bits 15 to 8 via 8-bit register FNCH

Address FNC: FFFF 645C_H
FNCH: FFFF 645D_H

Initial Value 0000_H. This register is initialized by any reset.

15	14	13	12	11	10	9	8
0	0	0	FNRF	0	0	0	0
R	R	R	R	R	R	R	R
7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0
R	R	R	R	R	R	R	R

Table 4-24 FNC register contents

Bit position	Bit name	Function
12	FNRF	FENMI interrupt request flag 0: no interrupt request FENMI 1: FENMI interrupt request occurred

(9) FIC - FE level INT status register

This register informs about the occurrence of a FE level maskable interrupt FEINT.

Access This register can be read only in

- 16-bit units:
 - via 16-bit register FIC
- 8-bit or 1-bit units:
 - bits 15 to 8 via 8-bit register FICH

Address FiC: FFFF 645E_H
FICH: FFFF 645F_H

Initial Value 0000_H. This register is initialized by any reset

15	14	13	12	11	10	9	8
0	0	0	FIRF	0	0	0	0
R	R	R	R	R	R	R	R
7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0
R	R	R	R	R	R	R	R

Table 4-25 FIC register contents

Bit position	Bit name	Function
12	FIRF	FEINT interrupt request flag 0: no FEINT interrupt request 1: FEINT interrupt request occurred

4.6 Interrupt Acknowledgment and Restoring

This section describes the operation during interrupt acknowledgment and restoring from interrupt servicing.

CPU registers This section frequently refers to registers of the CPU. For a detailed description of these registers refer to the “V850E2 32-bit Microcontroller Core Architecture” user manual.

4.6.1 FE level non-maskable interrupt FENMI

When an FENMI interrupt is requested, an FE level non-maskable interrupt is generated in the CPU. This FE level non-maskable interrupt is used when a fatal system error occurs.

Caution Upon acknowledgment of the FENMI interrupt, generation of the next FENMI, FEINT, or INTn interrupt is pended until the FERET instruction is executed (interrupt request is acknowledged and held.)
FENMI can be acknowledged even when the NP bit of the program status word CPU register PSW is set to 1. Therefore, if the FENMI interrupt occurs during the processing of an FEINT exception, PPI exception, or other FE level exceptions, the save address is lost and cannot be restored. After a FENMI interrupt is requested and the required processing has been completed, execute a system reset, etc. Return to the original processing is not possible.




Figure 4-1 Processing upon occurrence of FENMI interrupt request

Note If a processor protection exception (MDP or MIP) occurs, the PSW.NPV, DMP, and IMP bits are always cleared, regardless of the status of MPM.AUE. MPM.AUE controls the execution level auto transition function, refer to the “V850E2 32-bit Microcontroller Core Architecture” (Document number R01US0037EJxxxx) for details.

FENMI restore An FE level non-maskable interrupt FENMI cannot be restored since such interrupt indicates a fatal system error.

Execute a system reset after exception processing.

4.6.2 FE level maskable interrupt FEINT

Caution A FE level maskable interrupt FEINT is recoverable. Upon acknowledgment of the FEINT interrupt, generation of the next FEINT or INTn interrupt is kept pending until the FERET instruction is executed. Interrupt request is acknowledged and held.




Figure 4-2 Processing upon occurrence of FEINT interrupt request

Note MPM.AUE controls the execution level auto transition function, refer to the “V850E2 32-bit Microcontroller Core Architecture” (Document number R01UH0037EJxxxx) for details.

FEINT restore Restore from FE level maskable interrupt FEINT servicing is performed using the FERET instructions. Execution of the FERET instruction while the PSW.EP bit status is cleared launches restore processing from the FE level maskable interrupt interrupt FEINT. Completely restoring from interrupt servicing when the PSW.EP bit is "1" is not possible (clearing of the ICSR, ISPR, and other registers is not performed). For return from FE level maskable interrupts, execute the FERET instruction with the PSW.EP bit always cleared.

Caution In the V850E2 CPU, although RETI instructions are provided for backward compatibility with V850E1 and V850E2 architectures, but their use is, in principle, prohibited. Replace all RETI instructions other than existing programs that cannot be modified with EIRET or FERET instructions.




Figure 4-3 Restore from FE level maskable interrupt (FEINT) servicing

4.6.3 EI level maskable interrupt INTn

When an EI level maskable interrupt is requested, an INTn interrupt is requested to the CPU (the transition to the interrupt handler occurs from the setting of the IMR register of the Interrupt Controller). This interrupt is a recoverable EI level interrupt.

In the case of an INTn interrupt, its channel number n is set to the selected channel hold register SCR. As a result, the channel number can be easily known when wishing to share the same interrupt vectors among several channels.

Caution Upon acknowledgment of the EI level interrupt, the priority level of the currently acknowledged interrupt is registered to the in-service priority register ISPR. Then, until execution of the EIRET instruction, interrupt with a priority level lower than that of this ISPR register are not generated. Interrupt request is acknowledged and held.

Registration of the priority level of the currently acknowledged interrupt and deletion of the priority level of the interrupt during EIRET to/from the ISPR register are automatically performed by the hardware. Write to the ISPR register cannot be performed by software. Write operations are ignored.




Figure 4-4 Processing upon occurrence of INTn interrupt request

Note MPM.AUE controls the execution level auto transition function, refer to the “V850E2 32-bit Microcontroller Core Architecture” (Document number R01US0037EJxxxx) for details.

INTn restore Restore from EI level maskable interrupt INTn is performed using the EIRET instruction. Execution of the EIRET instruction while the PSW.EP bit status is cleared launches restore processing from the interrupt. Completely restoring from interrupt servicing when the PSW.EP bit is "1" is not possible (clearing of the ICSR, ISPR, and other registers is not performed). For return from EI level maskable interrupt, execute the EIRET instruction with the PSW.EP bit always cleared.

Caution In the V850E2 CPU, although RETI instructions are provided for backward compatibility with V850E1 and V850E2 architectures, but their use is, in principle, prohibited. Replace all RETI instructions other than existing programs that cannot be modified with EIRET or FERET instructions.




Figure 4-5 Restore from EI level maskable interrupt INTn

4.7 Interrupt Operation

4.7.1 Mask function of EI level maskable interrupt INTn

Interrupt masking can be specified for each respective interrupt channel of INTn. Interrupt masking is performed by the following register settings.

ICn.MKn	Operation
1	Masks interrupt
0	Enables interrupt

The ICn.MKn bits can also be read and written via the corresponding IMRmEIMKn bits of the EI level interrupt mask registers IMRm.

- Operation example**
- When "1" is written to IMRm.IMRmEIMKn bits, interrupts are prohibited for the corresponding channels.
 - When the ICn.MKn bits are read, "1" is read.

Caution For MKn bit, the processing after interrupt hold is masked. Even if the MKn bit is set to 1, interrupt request acknowledgment and hold are performed. Therefore, even if software interrupts are requested for interrupts for which interrupt prohibit has been specified with MKn, no interrupt occurs. Moreover, when MKn bit is again set to 0 while an interrupt request is held, that interrupts occur at that timing. To delete an interrupt request that is already being held, clear the corresponding RFn bit.

4.7.2 Interrupt priority level judgment

When FENMI, FEINT, and INTn interrupts are input, priorities including other exceptions are determined, and the exception with the highest priority (including interrupts) is requested. Exceptions requested at the same time (including interrupts) are processed in a pre-allocated priority order (the default priority order). The priority orders of FENMI, FEINT, and INTn interrupts are as follows.

$$\text{FENMI} > \text{FEINT} > \text{INTn}$$

See "V850E2/Fx4-G Interrupt Requests" and the "V850E2 32-bit Microcontroller Core Architecture User Manual" for other exceptions.

For INTn interrupts, the priority level can be set independently for each interrupt source. The priority level is specified with ICn.P[2:0]n. Priority levels from 0 to 7 can be set. 0 is the highest priority level, and 7 the lowest. In the case of multiple INTn interrupts with the same priority level, the interrupt with the lowest interrupt channel number, i.e. with the highest default priority, has priority.

Table 4-26 Example of INTn interrupt priority level settings and priority levels

INTn ^a	ICn.P[2:0] setting ^b	Priority level during operation ^c
INT0	3	10
INT1	4	11
INT2	0	1
INT3	0	2
INT4	1	3
INT5	2	6
INT6	2	7
INT7	1	4
INT8	1	5
INT9	2	8
INT10	2	9

a) n = 0: highest default priority

b) 0: highest priority

c) 1: highest priority

During interrupt servicing, the Interrupt Controller also processes multiple interrupts acknowledging other interrupts. When multiple INTn interrupts are requested at the same time, the interrupt to be acknowledged is determined by the following procedure.

(1) Comparison with the priority level as the interrupt currently being serviced

Interrupts with the same or lower priority level as the interrupt currently being serviced are held pending.

The priority level of the interrupt currently being serviced is shown in the ISPR register.

Interrupts with a higher priority level than the interrupt currently being serviced proceed to the next priority judgment stage.

(2) Masking through priority mask register (PMR)

Only interrupts enabled by the PMR register proceed to the next priority judgment stage.

(3) The requested interrupt source with the highest priority level is selected

When interrupts are being simultaneously requested from multiple sources, the interrupt source from the highest priority level, determined by ICn.P[2:0]n, with the smallest interrupt channel number, i.e. highest default priority, is selected.

(4) Interrupt hold by CPU

Interrupt acknowledgment is pending according to the state of the NP and ID bits of the PSW register.

At this time, priority judgment

- among INTn interrupts, according to their assigned ICn.P[2:0] and their default priority (interrupt channel number n)
- and priority judgment among INTn, FEINT and FENMI interrupts

is performed even while interrupt acknowledgment is pending, and the interrupt with the highest priority is selected upon realization of the acknowledgment condition.

Example When a priority level ICn.P[2:0]n = 5 INTn interrupt has already been requested and interrupt generation is pending because the value of the PSW.ID bit is "1", a subsequent priority level ICn.P[2:0]n = 3 INTn interrupt is requested. Then, if the PSW.ID bit is cleared, the priority level 3 INTn interrupt is generated.

Multiple interrupt servicing in which an interrupt is acknowledged while another interrupt is being serviced is shown below.

When an interrupt request is acknowledged, the PSW.ID flag is automatically set to 1. Therefore, when multiple interrupts are to be used, clear the ID flag to 0 beforehand (for example, by placing the EI instruction in the interrupt service program) to set the interrupt enable mode.




Figure 4-6 Example of processing in which an interrupt request is issued while another interrupt is being serviced (1/2)

- Notes**
1. "a" to "h": in the figure are the temporary names of interrupt request signals shown for the sake of explanation.
 2. The default priority in the figure indicates the relative priority between two interrupt request signals.

Caution To perform multiple interrupt servicing, the values of the EIPC and EIPSW registers must be saved before executing the EI instruction. When returning from multiple interrupt servicing, restore the values of EIPC and EIPSW after executing the DI instruction.




Figure 4-7 Example of processing in which an interrupt request signal is issued while another interrupt is being serviced (2/2)

- Notes**
1. Interrupt request “t” has lower default priority than interrupt request “u”.
 2. “i” to “u” in the figure are the temporary names of interrupt request signals shown for the sake of explanation.

Caution To perform multiple interrupt servicing, the values of the EIPC and EIPSW registers must be saved before executing the EI instruction. When returning from multiple interrupt servicing, restore the values of EIPC and EIPSW after executing the DI instruction.




Figure 4-8 Example of servicing simultaneously generated interrupt requests

- Notes**
1. "a" to "c" in the figure are the temporary names of interrupt request signals shown for the sake of explanation.
 2. The default priority in the figure indicates the relative priority between two interrupt request signals.

Caution To perform multiple interrupt servicing, the values of the EIPC and EIPSW registers must be saved before executing the EI instruction. When returning from multiple interrupt servicing, restore the values of EIPC and EIPSW after executing the DI instruction.

4.7.3 Priority mask function

The priority mask function prohibits in batch INTn interrupts of the specified interrupt priority level.

The interrupt masking priority level is specified with the PMR register. Masking and acknowledgment can be set for each priority level.

The following operations are possible using this function:

- Temporary prohibition of interrupts that have a priority level that is lower than a given priority level
- Temporary prohibition of interrupts that have a given priority level

PMR.PMRm	Operation
0	Acknowledges requests from priority level m interrupt source.
1	Masks requests from priority level m interrupt source.

Note m = 0 to 7

The PMR register prohibits interrupt occurrence. Interrupt request is acknowledged and held even while the interrupt occurrence is prohibited.

The presence of INTn interrupts held pending with this function can be checked with the next section.

4.7.4 Pending interrupt report function

The state of the currently pending interrupt can be checked with the pending interrupt report function.

This function allows checking of the following states:

- When interrupts that are masked only by the priority mask function (PMR) exist
The ICSR.PMF bit is set to 1.
The ICSR.PMF bit is not set to 1 only when interrupts that are priority masked through ISPR register or interrupts masked through MKn bit exist. Thus, the existence of priority requests pending through the priority mask function can be checked while interrupts are prohibited through priority masking.
- When EI level maskable interrupt request is not output to the CPU
The ICSR.EIR bit is set to 1.
By looking at the ICSR.EIR bit in the interval during which PSW.ID = 1, it is possible to check whether an INTn interrupt request exists.
- When FE level maskable interrupt request is not output to the CPU
ICSR.FIR bit is set to 1.
By looking at the ICSR.FIR bit in the interval during which PSW.NP = 1, it is possible to check whether a FEINT interrupt request exists.

4.7.5 In-service priority clear function

This function initializes the internal status of the Interrupt Controller. It operates when the ISPC register is accessed. The following operations are possible using this function.

- Clear all contents of ISPR register
- Clear ICSR.EIE, FIE, and FNE bits

All the bits of ISPR register can be cleared to 0 by writing "1" to all the bits of this register and then writing "0" to all the bits of ISPR register. Moreover, the ICSR.EIE, FIE, and FNE bits, which all indicates the state in which an interrupt request is being processed in the CPU, are all be cleared.

The value of this register is automatically cleared to 0 by writing 0 to all the bits of ISPR. The values of the bits of ISPR remain unchanged in the case of write access that is not performed simultaneously to all the bits.

4.8 Exception Handler Address Switching Function

Interrupt handler addresses can be switched by software.

For details, refer to the chapter "*Exception Handler Address Switching Function*" in the "V850E2 32-bit Microcontroller Core Architecture" user manual.

Chapter 5 DMA Controller (DMAC)

This chapter contains a generic description of the DMA Controller (DMAC).
The first section describes all V850E2/Fx4-G specific properties.

5.1 V850E2/Fx4-G DMA Features

DMA channels This microcontroller has following number of DMA channels.

Table 5-1 Instances of FCN

DMA channels	Fx4-G
DMA channels	n = 0 to 7

Channel index n Throughout this chapter, the index n is used to indentify an individual DMA channel.

DMA address map Refer to the section “V850E2/Fx4-G CPU Address Map” in chapter “CPU System Functions” for details.

Clock supply Since the DMA Controller is part of the CPU Subsystem, it is supplied with the same clock CKSCLC_000 as the CPU Subsystem.
Refer to the section “CPU Subsystem” in chapter “CPU System Functions” for details.

DMAC H/W reset The DMA Controller and its registers are initialized by the following reset signal:

Table 5-2 DMAC reset signal

DMAC	Reset signal
DMAC	<ul style="list-style-type: none">Reset Controller SYSRESStand-by Controller DPSTPWU (wake-up from DEEPSTOP mode)

(1) DMA trigger factors

The assignment of a DMA trigger source to the DMA channel n is done by the DTFNRn.IFCn[5:0].

The following table lists all DMA triggers and how to select them by setting the DMA trigger factor register DTFNRn.

Table 5-3 DMA trigger factors selection

DTFRn.IFCn[6:0]	DMA trigger interrupt	DTFRn.IFCn[6:0]	DMA trigger interrupt
0	No DMA	32	INTADAA0I2
1	INTP0	33	INTADAA0LLT
2	INTP1	34	INTCSIG0IR
3	INTP2	35	INTCSIG0IC
4	INTP3	36	INTDMA0
5	INTP4	37	INTDMA1
6	INTP5	38	INTDMA2
7	INTP6	39	INTDMA3
8	INTP7	40	INTDMA4
9	INTP8	41	INTDMA5
10	INTP9	42	reserved
11	INTP10	43	INTIICB0IA
12	INTTAUB0I8	44	INTTAUJ0I0
13	INTTAUB0I9	45	INTTAUJ0I1
14	INTTAUB0I10	46	INTTAUJ0I2
15	INTTAUB0I11	47	INTTAUJ0I3
16	INTTAUB0I12	48	INTCSIG4IR
17	INTTAUB0I13	49	INTCSIG4IC
18	INTTAUB0I14	50	INTFCN5TRX
19	INTTAUB0I15	51	INTFCN5REC
20	INTFCN0REC	52	INTLMA2IT
21	INTFCN1REC	53	INTFCN0ERR
22	INTFCN2TRX	54	INTFCN1ERR
23	INTFCN2REC	55	INTFCN2ERR
24	INTFCN3TRX	56	INTCSIG7IR
25	INTFCN3REC	57	INTCSIG7IC
26	INTFCN4TRX	58	INTLMA10IR
27	INTFCN4REC	59	INTLMA10IT
28	INTFCN0TRX	60	INTLMA11IR
29	INTFCN1TRX	61	INTLMA11IT
30	INTADAA0I0	62	reserved
31	INTADAA0I1	63	reserved

5.2 Definition of Terms

The terms used in this document are defined as follows.

Table 5-4 Definition of terms

Term	Function
DMA transfer	Period from the start of the first DMA cycle to assertion of INTDMAn
DMA cycle	Period of transferring one unit of data (since a read cycle has been started and until a write cycle is completed).
Hardware DMA transfer request	64 hardware DMA transfer request (INTIN[63:0])
Software DMA transfer request	DMA transfer request by internal register (DTSnSR bit)
DMA transfer request	Hardware DMA transfer request or software DMA transfer request
Single transfer	One DMA cycle is executed per transfer request.
Block transfer	The number of transfers set in the transfer count setting register (DTCn) is executed per software DMA transfer request. Since the bus is released after each transfer, the CPU is able to take over the bus and interrupt the DMA transfers. If a higher-priority transfer request occurs during execution of a single step transfer, the single step transfer is aborted while the higher-priority transfer request is executed.

5.3 General

Direct memory access (DMA) function is used to access data without going via the CPU.

The DMA Controller incorporates following units:

- DMA trigger factor register (DTFR)
- DMA controller (DMAC)
- DMA data transfer unit (DMAT)

Note The number of DMA channels, expressed by the index *n*, is defined in the first section of this chapter under the key words “DMA channels” and “Channel index *n*”.

5.3.1 DMA Controller (DMAC) function

- Registers to store transfer information (transfer address, transfer size, etc.) and registers to control DMAC are included.
- When a DMA transfer request is accepted, a transfer request is generated, according to the contained transfer information.
- Hardware DMA transfer requests, DMA acknowledge signals, and DMA transfer completion interrupts are input and output.
- Write back information is written back to registers.

5.3.2 DMA trigger factor register (DTFR) function

The DMA transfer factors are selected from among interrupt signals.

Table 5-5 Transfer target spaces

Transfer source	Transfer destination	Peripheral I/O	External memory	Data RAM	Internal Code flash	Internal Data-Flash
Peripheral I/O		√	√	√	X	X
External memory		√	√	√	X	X
Data RAM		√	√	√	X	X
Internal Code flash		√	√	√	X	X
Internal Data-Flash		√	√	√	X	X




Figure 5-1 DMA trigger and interrupt signals connections

5.3.3 DMA access memory map

Refer to the section “V850E2/Fx4-G CPU Address Map” in chapter “CPU System Functions” for details.

5.3.4 Prioritization of channels

The following describes how the prioritization of the DMA subsystem's various transfer channels is determined.

The priority is set as

$$\text{CH0} > \text{CH1} > \text{CH2} > \text{CH3} > \text{CH4} > \text{CH5} > \text{CH6} > \text{CH7},$$

in which CH0 has the highest priority.

5.3.5 Stand-by function

A stop acknowledge signal is returned following a stop request when transfer of the DMA transfer unit is completed.

The transfer unit for DMA is one DMA cycle (from when read starts until write ends).

5.4 DMAC Function

5.4.1 Features

- Transfer data size**
- 8 bits
 - 16 bits
 - 32 bits

Transfer data Fixed to little endian
Misaligned data not supported

Maximum transfer count 32,768 (2^{15}) times

Channel priority control Fixed priority (highest priority (CH0) → lowest priority (CH7))

- Subject to transfer**
- Code flash (as source only)
 - Data RAM
 - Data-Flash (as source only)
 - Peripheral I/O area

Transfer type 2-cycle transfer (dual address transfer)

The address at both the transfer source and destination is accessed. Two bus cycles (read cycle + write cycle) are required to execute a single transfer. Because the bus is not locked between the read cycle and write cycle, a CPU bus cycle may take place.

Transfer modes	<ul style="list-style-type: none">• Single transfer mode (when hardware DMA transfer request is generated) When a hardware DMA transfer request is generated, the bus mastership is acquired, and the bus is always released after transfer has been executed once. If another hardware DMA transfer request is generated after that, transfer is executed once again. This operation is repeated until transfer has been executed the number of times specified by the transfer count register (DTC).• Block transfer mode (when software DMA transfer request is generated) When a software DMA transfer request is generated, the bus mastership is acquired, and the bus is released each time transfer has been executed once. Once a software DMA transfer request has been acknowledged, this operation is repeated until transfer has been executed the number of times specified by the transfer count register (DTC).
Transfer address control	<ul style="list-style-type: none">• Incremental• Fixed
Transfer error support	When the data from the transfer source contains an error, or if an error occurs at the transfer destination, DMA transfer is aborted, and a SYSERR exception is output for the CPU.
DMA transfer request	A hardware DMA transfer request or a software DMA transfer request can be selected for each channel. The software DMA transfer request can be set by software (by setting the DTS register). This register also has a status bit (DTS register) that indicates that a hardware DMA transfer request has been generated.
Transfer completion interrupt output function	This function outputs a transfer completion interrupt signal (INTDMA7 to INTDMA0) when DMA transfer of each channel has been completed the number of times specified by the transfer count register (DTC).
Stand-by support	When a stop mode request is generated, DMA transfer is aborted momentarily and the stop mode is entered.
DMA transfer abort function	This function supports aborting DMA transfer by software.

5.4.2 DMAC setting registers

Table 5-6 DMAC setting registers (1/2)

Address	Symbol	Function register name	R/W	Operable bits				Initial value
				1	8	16	32	
FFFF7300H	DTRC	DMA transfer request control register	R/W	√	√			00H
FFFF7314H	DSA0	DMA source address register CH0					√	00000000H
FFFF7314H	DSA0L	DMA source address register LCH0				√		0000H
FFFF7316H	DSA0H	DMA source address register HCH0				√		0000H
FFFF7324H	DDA0	DMA destination address register CH0					√	00000000H
FFFF7324H	DDA0L	DMA destination address register LCH0				√		0000H
FFFF7326H	DDA0H	DMA destination address register HCH0				√		0000H
FFFF7332H	DTC0	DMA transfer count register CH0				√		0000H
FFFF7338H	DTCT0	DMA transfer control register CH0				√		0000H
FFFF733AH	DTS0	DMA transfer status register CH0		√	√			00H
FFFF7344H	DSA1	DMA source address register CH1					√	00000000H
FFFF7344H	DSA1L	DMA source address register LCH1				√		0000H
FFFF7346H	DSA1H	DMA source address register HCH1				√		0000H
FFFF7354H	DDA1	DMA destination address register CH1					√	00000000H
FFFF7354H	DDA1L	DMA destination address register LCH1				√		0000H
FFFF7356H	DDA1H	DMA destination address register HCH1				√		0000H
FFFF7362H	DTC1	DMA transfer count register CH1				√		0000H
FFFF7368H	DTCT1	DMA transfer control register CH1				√		0000H
FFFF736AH	DTS1	DMA transfer status register CH1		√	√			00H
FFFF7374H	DSA2	DMA source address register CH2					√	00000000H
FFFF7374H	DSA2L	DMA source address register LCH2				√		0000H
FFFF7376H	DSA2H	DMA source address register HCH2				√		0000H
FFFF7384H	DDA2	DMA destination address register CH2					√	00000000H
FFFF7384H	DDA2L	DMA destination address register LCH2				√		0000H
FFFF7386H	DDA2H	DMA destination address register HCH2				√		0000H
FFFF7392H	DTC2	DMA transfer count register CH2				√		0000H
FFFF7398H	DTCT2	DMA transfer control register CH2				√		0000H
FFFF739AH	DTS2	DMA transfer status register CH2		√	√			00H
FFFF73A4H	DSA3	DMA source address register CH3					√	00000000H
FFFF73A4H	DSA3L	DMA source address register LCH3				√		0000H
FFFF73A6H	DSA3H	DMA source address register HCH3				√		0000H
FFFF73B4H	DDA3	DMA destination address register CH3					√	00000000H
FFFF73B4H	DDA3L	DMA destination address register LCH3				√		0000H
FFFF73B6H	DDA3H	DMA destination address register HCH3				√		0000H
FFFF73C2H	DTC3	DMA transfer count register CH3				√		0000H
FFFF73C8H	DTCT3	DMA transfer control register CH3				√		0000H
FFFF73CAH	DTS3	DMA transfer status register CH3		√	√			00H
FFFF73D4H	DSA4	DMA source address register CH4					√	00000000H

Table 5-6 DMAC setting registers (2/2)

Address	Symbol	Function register name	R/W	Operable bits				Initial value
				1	8	16	32	
FFFF73D4H	DSA4L	DMA source address register LCH4				√		0000H
FFFF73D6H	DSA4H	DMA source address register HCH4				√		0000H
FFFF73E4H	DDA4	DMA destination address register CH4					√	00000000H
FFFF73E4H	DDA4L	DMA destination address register LCH4				√		0000H
FFFF73E6H	DDA4H	DMA destination address register HCH4				√		0000H
FFFF73F2H	DTC4	DMA transfer count register CH4				√		0000H
FFFF73F8H	DTCT4	DMA transfer control register CH4				√		0000H
FFFF73FAH	DTS4	DMA transfer status register CH4		√	√			00H
FFFF7404H	DSA5	DMA source address register CH5					√	00000000H
FFFF7404H	DSA5L	DMA source address register LCH5				√		0000H
FFFF7406H	DSA5H	DMA source address register HCH5				√		0000H
FFFF7414H	DDA5	DMA destination address register CH5					√	00000000H
FFFF7414H	DDA5L	DMA destination address register LCH5				√		0000H
FFFF7416H	DDA5H	DMA destination address register HCH5				√		0000H
FFFF7422H	DTC5	DMA transfer count register CH5				√		0000H
FFFF7428H	DTCT5	DMA transfer control register CH5				√		0000H
FFFF742AH	DTS5	DMA transfer status register CH5		√	√			00H
FFFF7434H	DSA6	DMA source address register CH6					√	00000000H
FFFF7434H	DSA6L	DMA source address register LCH6				√		0000H
FFFF7436H	DSA6H	DMA source address register HCH6				√		0000H
FFFF7444H	DDA6	DMA destination address register CH6					√	00000000H
FFFF7444H	DDA6L	DMA destination address register LCH6				√		0000H
FFFF7446H	DDA6H	DMA destination address register HCH6				√		0000H
FFFF7452H	DTC6	DMA transfer count register CH6				√		0000H
FFFF7458H	DTCT6	DMA transfer control register CH6				√		0000H
FFFF745AH	DTS6	DMA transfer status register CH6		√	√			00H
FFFF7464H	DSA7	DMA source address register CH7					√	00000000H
FFFF7464H	DSA7L	DMA source address register LCH7				√		0000H
FFFF7466H	DSA7H	DMA source address register HCH7				√		0000H
FFFF7474H	DDA7	DMA destination address register CH7					√	00000000H
FFFF7474H	DDA7L	DMA destination address register LCH7				√		0000H
FFFF7476H	DDA7H	DMA destination address register HCH7				√		0000H
FFFF7482H	DTC7	DMA transfer count register CH7				√		0000H
FFFF7488H	DTCT7	DMA transfer control register CH7				√		0000H
FFFF748AH	DTS7	DMA transfer status register CH7		√	√			00H

Caution If an unmapped address is accessed, a write access is ignored and “0” is returned in response to a read access.

5.4.3 Enabling or disabling writing control registers

The following control registers cannot be written while DMA transfer is enabled. All these registers can always be read, however.

Table 5-7 Enabling/disabling writing control registers

Always writable	DTRC, DTSn
Writing prohibited while DMA transfer is enabled (DTE = 1) (Operation is not guaranteed if these registers are written.)	DSA, DSAnL, DSAnH, DDA, DDAnL, DDAnH, DTCn, DTCTn

5.5 DMA Control Registers

5.5.1 DTRC – DMA transfer request control register

Access This register can be read or written in 8-bit units.

Address FFFF 7300_H

Initial Value 00_H

7	6	5	4	3	2	1	0
ERR	0	0	0	0	0	0	ADS
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 5-8 DTRC0 registers contents

Bit position	Bit name	Function
7	ERR	DMA transfer error status This bit indicates that an error response has been received from the transfer target during DMA transfer. If an error response is received, the ERR and ADS bits are set and a system error exception SYSERR is generated. To clear this bit, write "0" to it. 0: No DMA transfer error 1: DMA transfer error
0	ADS	DMA transfer aborted This bit indicates that DMA transfer has been aborted by a transfer stop request. In addition, the current DMA transfer can be aborted if the user writes "1" to this bit. 0: DMA transfer not aborted 1: DMA transfer aborted/DMA transfer abort request

5.5.2 DSAnL – DMA source address register L

These registers hold the lower 16 bits of the transfer source address. The higher 16 bits of the transfer source address are accessible via the DSAnH register.

32-bit access The entire 26-bit address is also accessible through the 32-bit register DSAn. DSAn has the same address as the DSAnL register.

If the entire address shall be read, while the DMA transfer of channel is enables (DTSn.DTSnDTE = 1), proceed as follows in order to acquire the correct address:

- Read DSAn twice consecutively and compare the upper 10 address bits SA[25:16] of both read accesses.
- In case the upper 10 address bits SA[25:16] are identical between both read accesses the address SA[25:0] of the second read access represents the correct address.
- In case the upper 10 address bits SA[25:16] are different between both read accesses the address SA[25:0] of the first read access represents the correct address.

Access This register can be read or written in 16-bit units.

Address DSA7L: FFFF 7464_H, DSA6L: FFFF 7434_H, DSA5L: FFFF 7404_H, DSA4L: FFFF 73D4_H, DSA3L: FFFF 73A4_H, DSA2L: FFFF 7374_H, DSA1L: FFFF 7344_H, DSA0L: FFFF 7314_H

Initial Value 0000_H

15	14	13	12	11	10	9	8
SA[15:8]							
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
7	6	5	4	3	2	1	0
SA[7:0]							
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 5-9 DSAnL registers contents

Bit position	Bit name	Function
15 to 0	SA[15:0]	DMA source address lower 16 bits If this register is referenced during DMA transfer, the address from which data is to be transferred next can be read. When referencing this register, it is recommended to access this register together with DSAnH via the 32-bit register DSAn. When the entire DMA transfer has been completed, the values of these bits return to their initial values, i.e. when DMA transfer was started.

- Cautions**
1. Writing this register is prohibited while DMA transfer of channel n is enabled ($DTSn.DTSnDTE = 1$). If it is written, correct DMA operation is not guaranteed.
 2. Set an address by accessing in 32-bit units while DMA transfer of channel n is disabled ($DTSn.DTSnDTE = 0$) in order to avoid data being transferred from an address that has not been completely set.
 3. DMA transfer of misaligned data is not supported. The lower 2 bits of an address corresponding to the transfer data size are as follows (x indicates any bit).

The operation is not guaranteed if a setting other than the following is made.

Data size	SA1	SA0
8 bits	x	x
16 bits	x	0
32 bits	0	0

5.5.3 DSAnH – DMA source address register H

These registers hold the higher 10 bits of the transfer source address. The lower 16 bits of the transfer source address are accessible via the DSAnL register.

Access This register can be read or written in 16-bit units.

Address DSA7H: FFFF 7466_H, DSA6H: FFFF 7436_H, DSA5H: FFFF 7406_H, DSA4H: FFFF 73D6_H, DSA3H: FFFF 73A6_H, DSA2H: FFFF 7376_H, DSA1H: FFFF 7346_H, DSA0H: FFFF 7316_H

Initial Value 0000_H

15	14	13	12	11	10	9	8
0	0	0	0	0	0	SA[25:24]	
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
7	6	5	4	3	2	1	0
SA[23:16]							
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 5-10 DSAnH registers contents

Bit position	Bit name	Function
9 to 0	SA[25:16]	DMA source address If this register is referenced during DMA transfer, the address from which data is to be transferred next can be read. When referencing this register, it is recommended to access this register together with DSAnL in 32-bit units. When the entire DMA transfer has been completed, the values of these bits return to their initial values, i.e. when DMA transfer was started.

- Cautions**
1. Writing this register is prohibited while DMA transfer of channel n is enabled (DTSn.DTSnDTE = 1). If it is written, correct DMA operation is not guaranteed.
 2. Set an address by accessing in 32-bit units while DMA transfer of channel n is disabled (DTSn.DTSnDTE = 0) in order to avoid data being transferred from an address that has not been completely set.

5.5.4 DDAnL – DMA destination address register L

These registers hold the lower 16 bits of the transfer destination address. The higher 16 bits of the transfer destination address are accessible via the DDAnH register.

32-bit access The entire 29-bit address is also accessible through the 32-bit register DDAn. DDAn has the same address as the DDAnL register.

If the entire address shall be read, while the DMA transfer of channel is enables (DTSn.DTSnDTE = 1), proceed as follows in order to acquire the correct address:

- Read DDAn twice consecutively and compare the upper 10 address bits DA[25:16] of both read accesses.
- In case the upper 10 address bits DA[25:16] are identical between both read accesses the address DA[25:0] of the second read access represents the correct address.
- In case the upper 10 address bits DA[25:16] are different between both read accesses the address DA[25:0] of the first read access represents the correct address.

Access This register can be read or written in 16-bit units.

Address DDA7L: FFFF 7474_H, DDA6L: FFFF 7444_H, DDA5L: FFFF 7414_H,
DDA4L: FFFF 73E4_H, DDA3L: FFFF 73B4_H, DDA2L: FFFF 7384_H,
DDA1L: FFFF 7354_H, DDA0L: FFFF 7324_H

Initial Value 0000_H

15	14	13	12	11	10	9	8
DA[15:8]							
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
7	6	5	4	3	2	1	0
DA[7:0]							
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 5-11 DDAnL registers contents

Bit position	Bit name	Function
15 to 0	DA[15:0]DA0	DMA destination address If this register is referenced during DMA transfer, the address to which data is to be transferred next can be read. When referencing this register, it is recommended to access this register together with DDAnH in 32-bit units. When the entire DMA transfer has been completed, the values of these bits return to their initial values, i.e. when DMA transfer was started.

- Cautions**
1. Writing these bits is prohibited while DMA transfer of channel n is enabled (DTSn.DTSnDTE = 1). If they are written, the operation is not guaranteed.
 2. Set an address by accessing in 32-bit units while DMA transfer of channel n is disabled (DTSn.DTSnDTE = 0) in order to avoid data being transferred from an address that has not been completely set.
 3. If an error occurs in the transfer target in the read cycle of DMA transfer, the write cycle is not executed but the destination address is updated.
 4. DMA transfer of misaligned data is not supported. The lower 2 bits of an address corresponding to the transfer data size are as follows (x indicates any bit).

The operation is not guaranteed if a setting other than the following is made.

Data size	DA1	DA0
8 bits	x	x
16 bits	x	0
32 bits	0	0

5.5.5 DDAnH – DMA destination address register H

These registers hold the higher 10 bits of the transfer destination address. The lower 16 bits of the transfer destination address are accessible via the DDAnL register.

Note The entire 29-bit transfer destination address is accessible via the 32-bit register DDAn. Refer to the description of the DDAnL for details about the 32-bit access.

Access This register can be read or written in 16-bit units.

Address DDA7H: FFFF 7476_H, DDA6H: FFFF 7446_H, DDA5H: FFFF 7416_H,
DDA4H: FFFF 73E6_H, DDA3H: FFFF 73B6_H, DDA2H: FFFF 7386_H,
DDA1H: FFFF 7356_H, DDA0H: FFFF 7326_H

Initial Value 0000_H

15	14	13	12	11	10	9	8
0	0	0	0	0	0	DA[25:24]	
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
7	6	5	4	3	2	1	0
DA[23:16]							
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 5-12 DDAnH registers contents

Bit position	Bit name	Function
9 to 0	DA[25:16]	DMA destination address If this register is referenced during DMA transfer, the address to which data is to be transferred next can be read. When referencing this register, it is recommended to access this register together with DDAnL in 32-bit units. When the entire DMA transfer has been completed, the values of these bits return to their initial values, i.e. when DMA transfer was started.

- Cautions**
1. Writing these bits is prohibited while DMA transfer of channel n is enabled (DTSn.DTSnDTE = 1). If they are written, the operation is not guaranteed.
 2. Set an address by accessing in 32-bit units while DMA transfer of channel n is disabled (DTSn.DTSnDTE = 0) in order to avoid data being transferred from an address that has not been completely set.
 3. If an error occurs in the transfer target in the read cycle of DMA transfer, the write cycle is not executed but the destination address is updated.

5.5.6 DTCn – DMA transfer count register

Access This register can be read or written in 16-bit units.

Address DTC7: FFFF 7482_H, DTC6: FFFF 7452_H, DTC5: FFFF 7422_H,
DTC4: FFFF 73F2_H, DTC3: FFFF 73C2_H, DTC2: FFFF 7392_H,
DTC1: FFFF 7362_H, DTC0: FFFF 7332_H

Initial Value 0000_H

15	14	13	12	11	10	9	8
0	DTC[14:8]						
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
7	6	5	4	3	2	1	0
DTC[7:0]							
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 5-13 DTCn registers contents

Bit position	Bit name	Function										
14 to 0	DTC[14:0]	<p>DMA transfer count These bits specify the number of times of DMA transfers (DMA transfer count) for channel n. When this register is referenced during DMA transfer, the remaining number of times DMA transfer to be executed can be read. When the entire DMA transfer has been completed, the values of these bits return to their initial values, i.e. when DMA transfer was started.</p> <table border="1"> <thead> <tr> <th>DTC[14:0]</th><th>The operation</th></tr> </thead> <tbody> <tr> <td>0000_H</td><td>Transfer executed 32,768 times or until completion of transfer</td></tr> <tr> <td>0001_H</td><td>Transfer executed once or transfer to be executed once</td></tr> <tr> <td>:</td><td>:</td></tr> <tr> <td>7FFF_H</td><td>Transfer executed 32,767 times or 32,767 times of transfer to be executed</td></tr> </tbody> </table>	DTC[14:0]	The operation	0000 _H	Transfer executed 32,768 times or until completion of transfer	0001 _H	Transfer executed once or transfer to be executed once	:	:	7FFF _H	Transfer executed 32,767 times or 32,767 times of transfer to be executed
DTC[14:0]	The operation											
0000 _H	Transfer executed 32,768 times or until completion of transfer											
0001 _H	Transfer executed once or transfer to be executed once											
:	:											
7FFF _H	Transfer executed 32,767 times or 32,767 times of transfer to be executed											

- Cautions**
1. Writing these bits is prohibited while DMA transfer of channel n is enabled (DTSn.DTSnDTE = 1). If they are written, the operation is not guaranteed.
 2. If an error occurs in the transfer target in the read cycle of DMA transfer, the write cycle is not executed but the destination address is updated.

5.5.7 DTCTn – DMA transfer control register

Access This register can be read or written in 16-bit units.

Address DTCT7: FFFF 7488_H, DTCT6: FFFF 7458_H, DTCT5: FFFF 7428_H,
DTCT4: FFFF 73F8_H, DTCT3: FFFF 73C8_H, DTCT2: FFFF 7398_H,
DTCT1: FFFF 7368_H, DTCT0: FFFF 7338_H

Initial Value 0000_H

15	14	13	12	11	10	9	8
0	DTCTnDS[1:0]	DTCTnLE	0	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
7	6	5	4	3	2	1	0
DTCTnSACM[1:0]	DTCTnDACM[1:0]	0	0 ^a	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

a) The default value “0” of bit 2 must not be changed.

Caution The default value “0” of bit 2 must not be changed.

Table 5-14 DTCTn registers contents (1/2)

Bit position	Bit name	Function															
14 to 13	DTCTn DS[1:0]	DMA transfer data size These bits specify the DMA transfer data size of channel n. <table border="1" data-bbox="582 1176 1380 1422"> <thead> <tr> <th>DTCTn DS1</th><th>DTCTn DS0</th><th>Transfer data size</th></tr> </thead> <tbody> <tr> <td>0</td><td>0</td><td>8 bits</td></tr> <tr> <td>0</td><td>1</td><td>16 bits</td></tr> <tr> <td>1</td><td>0</td><td>32 bits</td></tr> <tr> <td>1</td><td>1</td><td>Setting prohibited</td></tr> </tbody> </table>	DTCTn DS1	DTCTn DS0	Transfer data size	0	0	8 bits	0	1	16 bits	1	0	32 bits	1	1	Setting prohibited
DTCTn DS1	DTCTn DS0	Transfer data size															
0	0	8 bits															
0	1	16 bits															
1	0	32 bits															
1	1	Setting prohibited															
12	DTCTn LE	This bit determines whether a new DMA transfer request is accepted, though a current DMA transfer on channel n is not completed (DTSn.DTSnTC = 0). If a new DMA transfer request is accepted (DTCTnLE = 1), channel n remains enabled (DTSnDTE = 1) in order to start the next DMA transfer. 0: transfer request is not accepted during ongoing transfer, DTSnDTE is cleared upon completion of ongoing transfer 1: transfer request is accepted during ongoing transfer, DTSnDTE is not cleared upon completion of ongoing transfer Note: This bit is effective only in single transfer mode.															
7 to 6	DTCTn SACM[1:0]	DMA transfer source address counting direction These bits specify the direction in which the transfer source address of channel n is to be counted. <table border="1" data-bbox="582 1825 1380 2038"> <thead> <tr> <th>SACM1</th><th>SACM0</th><th>Counting direction</th></tr> </thead> <tbody> <tr> <td>0</td><td>0</td><td>Incremented</td></tr> <tr> <td>0</td><td>1</td><td>Setting prohibited</td></tr> <tr> <td>1</td><td>0</td><td>Fixed</td></tr> <tr> <td>1</td><td>1</td><td>Setting prohibited</td></tr> </tbody> </table>	SACM1	SACM0	Counting direction	0	0	Incremented	0	1	Setting prohibited	1	0	Fixed	1	1	Setting prohibited
SACM1	SACM0	Counting direction															
0	0	Incremented															
0	1	Setting prohibited															
1	0	Fixed															
1	1	Setting prohibited															

Table 5-14 DTCTn registers contents (2/2)

Bit position	Bit name	Function															
5 to 4	DTCTn DACM[1:0]	DMA transfer destination address counting direction These bits specify the direction in which the transfer destination address of channel n is to be counted. <table border="1" data-bbox="582 409 1382 622"> <thead> <tr> <th>DACM1</th> <th>DACM0</th> <th>Counting direction</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Incremented</td> </tr> <tr> <td>0</td> <td>1</td> <td>Setting prohibited</td> </tr> <tr> <td>1</td> <td>0</td> <td>Fixed</td> </tr> <tr> <td>1</td> <td>1</td> <td>Setting prohibited</td> </tr> </tbody> </table>	DACM1	DACM0	Counting direction	0	0	Incremented	0	1	Setting prohibited	1	0	Fixed	1	1	Setting prohibited
DACM1	DACM0	Counting direction															
0	0	Incremented															
0	1	Setting prohibited															
1	0	Fixed															
1	1	Setting prohibited															

- Cautions**
1. Writing these bits is prohibited while DMA transfer of channel n is enabled (DTSn.DTSnDTE = 1). If they are written, the operation is not guaranteed.
 2. The operation cannot be guaranteed if the SACM[1:0] and DACM[1:0] bits are set to a prohibited status.

5.5.8 DTSn – DMA transfer status register

Access This register can be read or written in 8- or 1-bit units.

Address DTS7: FFFF 748A_H, DTS6: FFFF 745A_H, DTS5: FFFF 742A_H,
DTS4: FFFF 73FA_H, DTS3: FFFF 73CA_H, DTS2: FFFF 739A_H,
DTS1: FFFF 736A_H, DTS0: FFFF 733A_H

Initial Value 00_H

7	6	5	4	3	2	1	0
DTSnTC	DTSnDT	0	0	DTSnER	DTSnDR	DTSnSR	DTSnDTE
R/W	R/W	R	R	R	R	R/W	R/W

Table 5-15 DTSn registers contents (1/2)

Bit position	Bit name	Function
7	DTSnTC	DMA transfer end status This bit indicates that DMA transfer has been completed. Write “0” to this bit to clear it after reading “1” from it. It is recommended to write this bit using bit manipulation such as CLR1. 0: DMA transfer not completed 1: DMA transfer completed
6	DTSnDT	DT DMA transfer status This bit indicates that a DMA transfer request has been acknowledged and that DMA transfer is in progress. It is not set (to “1”) when only a DMA transfer request is issued. This bit is cleared (to “0”) when DMA transfer has been completed. If the DTE bit is “0”, this bit can be cleared by the user. (It can also be written at the same time as the DTE bit.) 0: DMA transfer request acknowledged 1: DMA transfer in progress
3	DTSnER	DMA transfer error flag This bit indicates that a DMA transfer error has occurred in channel n. It is cleared (to “0”) when the ERR bit of the DTRC register is cleared. Note that this bit is read-only. 0: No DMA transfer error 1: DMA transfer error
2	DTSnDR	Hardware DMA transfer request flag This bit indicates that channel n has a hardware DMA transfer request. It is cleared (to “0”) when the hardware DMA transfer request is deasserted. This bit operates regardless of the status of the DTE bit. It is not set (to “1”) by a software DMA transfer request, or by a hardware DMA transfer request when a software DMA transfer request is selected by the DMA transfer request select register. Note that this bit is read-only. 0: No hardware DMA transfer request 1: Hardware DMA transfer request
1	DTSnSR	Software DMA transfer request This bit selects a software DMA transfer request. If a software DMA transfer request is selected by the DMA transfer request select register, writing “1” to this bit and the DTE bit starts DMA transfer. This bit is automatically cleared (to “0”) when DMA transfer has been completed. Writing “0” to this bit aborts DMA transfer. 0: No software DMA transfer request 1: Software DMA transfer request

Table 5-15 DTSn registers contents (2/2)

Bit position	Bit name	Function
0	DTSnDTE	<p>DMA transfer enable</p> <p>This bit enables or disables DMA transfer. DMA transfer is executed if "1" is written to this bit and a DMA transfer request is issued. This bit is automatically cleared (to "0") if the MLE bit is "0" when DMA transfer has been completed. DMA transfer is aborted if "0" is written to this bit during DMA transfer.</p> <p>0: Disables DMA transfer 1: Enables DMA transfer</p>

5.6 DMAC Function Details

5.6.1 DMAC transfer setting flow

Figure 5-2 “DMAC transfer setting flow” shows the flow for setting DMAC transfer.




Figure 5-2 DMAC transfer setting flow

5.6.2 DMAC transfer modes

A single-transfer mode and a block transfer mode are supported as transfer modes.

In either mode, transfer is executed in two cycles (dual address transfer) and therefore, a read cycle and a write cycle are generated each time transfer is executed.

Note that the bus is not locked. Consequently, a CPU cycle may take place between the read and write cycles.

(1) Single transfer mode (when hardware DMA transfer request is generated)

When a hardware DMA transfer request is acknowledged, data of the transfer data size (8, 16, or 32 bits) is transferred. Each time transfer has been executed, the bus is released and the DMA controller waits for a DMA transfer request. At this time, the acknowledge signal that indicates that the hardware DMA transfer request has been acknowledged, is also output.

Each time a hardware DMA transfer request has been acknowledged, transfer is executed once. This operation is repeated the number of times specified by the DMA transfer count register n (DTCn).




Figure 5-3 Example of single transfer

(2) Block transfer mode (when software DMA transfer request is generated)

When a software DMA transfer request is acknowledged, data of the transfer data size (8, 16, or 32 bits) is transferred. Each time transfer has been executed, the bus is released. At this time, the acknowledge signal, that indicates that a hardware DMA transfer request has been acknowledged, is not output.

Once a software DMA transfer request has been acknowledged, this operation is repeated the number of times specified by the DMA transfer count register n (DTCn). Because the priority is identified each time transfer is executed, the DMA cycle of a channel having the higher priority may interrupt a lower priority channel.




Figure 5-4 Example of block transfer (DMA channel priority: CH0 (high) > CH1 (low))

5.6.3 DMAC channel priority control

The priority of each channel is fixed and is as follows.

$$CH0 > CH1 > CH2 > CH3 > CH4 > CH5 > CH6 > CH7$$

If another DMA transfer request with a high priority is generated, the DMA transfer request with the higher priority always takes precedence.

When a software DMA transfer request is generated, the bus is also released each time a DMA cycle has been completed.

If a DMA transfer request with a high priority is generated, therefore, the DMA transfer request with the higher priority always takes precedence.

An example where another DMA transfer request with a high priority is generated when DMA transfer is executed is shown below.




Figure 5-5 Example of priority control

5.6.4 Valid DMA transfer request conditions

Whether a DMA transfer request of channel *n* is acknowledged depends on the setting of the ERR and ADS bits of the DMA transfer request control register (DTRC), and the DTSnTC and DTSnDTE bits of the DMA transfer status register (DTSn).

Table 5-16 “Valid DMA transfer request conditions of channel *n*” shows the relationship between the setting of each of the above bits and whether a DMA transfer request is acknowledged.

Table 5-16 Valid DMA transfer request conditions of channel *n*

Situation	DTSn. DTSnDTE	DTSn. DTSnTC	DTCTn DTCTnLE	DTRC.ERR	DTRC.ADS	DMA transfer request
When DMA transfer is disabled	0	X	X	X	X	Invalid
When DMA transfer error occurs	X	X	X	1	X	Invalid
When DMA transfer is aborted	X	X	X	X	1	Invalid
When DMA transfer is completed, loop disabled	0	1	0	X	X	Invalid
When DMA transfer is completed, loop enabled	1	1	1	0	0	Valid
When DMA transfer is enabled	1	0	0	0	0	Valid

5.6.5 Aborting/resuming DMA transfer

(1) Aborting or resuming DMA transfer for all channels through software

By setting the DMA transfer abort bit (ADS) of the DMA transfer request control register (DTRC), the next DMA transfer and those that follow can be aborted.

During a DMA cycle, the next DMA transfer is aborted after the ongoing DMA cycle has been completed.

Note that the DMA transfer enable bit (DTSnDTE) and the software DMA transfer request bit (DTSnSR) of the DMA transfer status register (DTSn) are not cleared.

To resume the aborted DMA transfer, clear the ADS bit.

If a DMA transfer is requested at that point, the transfer of the channel having the highest priority at that time is executed.

To end DMA transfer, clear the DMA transfer request with the DTSnDTE bit cleared.

(2) Aborting or resuming DMA transfer by using DMA transfer enable bit (DTE)

By clearing the DMA transfer enable bit (DTSnDTE) of the DMA transfer status register (DTSn), the next DMA transfer and those that follow can be aborted.

During a DMA cycle, the next DMA transfer is aborted after the ongoing DMA cycle is completed. Note that the software DMA transfer request bit (DTSnSR) of DTSn is not cleared.

To resume the aborted DMA transfer, set the DTSnDTE bit.

If another channel is not executing DMA transfer at that point, the priority is identified as usual.

If another channel is executing DMA transfer, the priority is identified after that transfer has been completed.

To end DMA transfer, clear the DMA transfer request with the DTSnDTE bit cleared.

(3) Aborting or resuming DMA transfer by using software DMA transfer request bit (DTSnSR)

By clearing the software DMA transfer request bit (DTSnSR) of the DMA transfer status register, the next DMA transfer and those that follow can be aborted (DTS).

During a DMA cycle, the next DMA transfer is aborted after the ongoing DMA cycle has been completed.

To resume the aborted DMA transfer, set the DTSnSR bit.

If another channel is not executing DMA transfer at that point, the priority is identified as usual.

If another channel is executing DMA transfer, the priority is identified after that transfer has been completed.

5.6.6 Error response support

(1) Aborting DMA transfer by error response

When an error occurs at the DMA transfer source or destination, the DMA transfer abort bit (ADS) of the DMA transfer request control register (DTRC) to abort subsequent DMA transfers is set.

At the same time, the DMA transfer error status bit (ERR) is set and a SYSERR exception is generated towards the CPU.

The user can evaluate in which channel the error has occurred, by using the DMA transfer error flag (DTSnER) of the DMA transfer status register (DTSn), when the user has confirmed that ERR has been set.

In this case, note that, if an error response is acknowledged in the read cycle, the write cycle is not executed, but the transfer address and the transfer count are updated.

(2) Canceling transfer abort by error response

DMA transfer abort can be canceled by clearing the DMA transfer abort bit (ADS) and DMA transfer error status bit (ERR) of the DMA transfer request control register (DTRC).

Clear the DMA transfer enable bit (DTSnDTE) of the DMA transfer status register (DTSn) in advance, so that DMA transfer is not resumed after its abort has been canceled.

In the case of a software DMA transfer request, also clear the software DMA transfer request bit (DTSnSR).

5.6.7 Stand-by support

When a stop request is generated, DMA transfer stops until completion of the two DMA cycles currently being executed.

Unlike DMA transfer abort caused by software, this does not affect the DMA control register.

DMA transfer resumes upon cancellation of the stop request, and if a DMA request is already retained, that DMA transfer starts.

5.7 DTFR Function

The DMA trigger factor register (DTFR) selects DMA trigger factors from among interrupt signals, and requests DMAC for DMA transfer. DTFRn registers are included for selecting the signals to be used for DMA transfer requests from among the 64 input trigger signals.

5.7.1 Features

- | | |
|---|---|
| Number of transfer factors | DMA transfer requests (for 8 channels) are selected from among 64 trigger signals. |
| DMAC interface | The DMA transfer request signal n is output.
The DMA transfer request signal n is cleared by an acknowledge signal from DMA. |
| CPU interface | The last transfer signal from DMA is output as a CPU interrupt signal. |
| Clearing of transfer request | A function that clears transfer request signals sent to DMA through register access is provided. |
| Confirmation of transfer request | A function that checks transfer request signals sent to DMA through register access is provided. |

5.8 DTFR Control Registers

5.8.1 DTFRn – DMA trigger factor register

Access This register can be read or written in 16-bit units.

Address DTFR0: FFFF 7B00_H, DTFR1: FFFF 7B02_H, DTFR2: FFFF 7B04_H,
DTFR3: FFFF 7B06_H, DTFR4: FFFF 7B08_H, DTFR5: FFFF 7B0A_H,
DTFR6: FFFF 7B0C_H, DTFR7: FFFF 7B0E_H

Initial Value 0000_H

15	14	13	12	11	10	9	8
REQEN	0	0	0	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
7	6	5	4	3	2	1	0
0	0	IFCn[5:0]					
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 5-17 DTFRn registers contents

Bit position	Bit name	Function
15	REQEN	This bit enables or disables operation of the DMA source selector of channel n. 1: Enables operation of source selector 0: Stops operation of source selector. Does not issue DMA transfer request (DMARQ). The settings of IFC6 to IFC0 are valid. Requests are always sampled.
5 to 0	IFCn[5:0]	These bits select the transfer source. The set values are shown in the table in the first section of this chapter.

Caution Stopping DMA channel n by DTFRn.REQEN = 0 does not clear any pending DMA request for that channel. In order to clear also a pending DMA request, set also DRQCLR.RQCRn = 1.

5.8.2 DRQCLR – DMA request clear register

Access This register can be read or written in 16-bit units.

Address FFFF 7B40_H

Initial Value 0000_H

15	14	13	12	11	10	9	8
0	0	0	0	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
7	6	5	4	3	2	1	0
RQCR7	RQCR6	RQCR5	RQCR4	RQCR3	RQCR2	RQCR1	RQCR0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 5-18 DRQCLR register contents

Bit position	Bit name	Function
7	RQCR7	Setting "1" to this bit clears transfer request held in channel 7 to "0".
6	RQCR6	Setting "1" to this bit clears transfer request held in channel 6 to "0".
5	RQCR5	Setting "1" to this bit clears transfer request held in channel 5 to "0".
4	RQCR4	Setting "1" to this bit clears transfer request held in channel 4 to "0".
3	RQCR3	Setting "1" to this bit clears transfer request held in channel 3 to "0".
2	RQCR2	Setting "1" to this bit clears transfer request held in channel 2 to "0".
1	RQCR1	Setting "1" to this bit clears transfer request held in channel 1 to "0".
0	RQCR0	Setting "1" to this bit clears transfer request held in channel 0 to "0".

Note Writing "0" to bits 7 to 0 is ignored.

5.8.3 DRQSTR – DMA request check register

Access This register is read-only, in 16-bit units.

Address FFFF 7B44_H

Initial Value 0000_H

15	14	13	12	11	10	9	8
0	0	0	0	0	0	0	0
R	R	R	R	R	R	R	R
7	6	5	4	3	2	1	0
RQST7	RQST6	RQST5	RQST4	RQST3	RQST2	RQST1	RQST0
R	R	R	R	R	R	R	R

Table 5-19 DRQSTR register contents

Bit position	Bit name	Function
7	RQST7	1: Request issued (DMA transfer request signal 7 is "1"), 0: No request (DMA transfer request signal 7 is "0")
6	RQST6	1: Request issued (DMA transfer request signal 6 is "1"), 0: No request (DMA transfer request signal 6 is "0")
5	RQST5	1: Request issued (DMA transfer request signal 5 is "1"), 0: No request (DMA transfer request signal 5 is "0")
4	RQST4	1: Request issued (DMA transfer request signal 4 is "1"), 0: No request (DMA transfer request signal 4 is "0")
3	RQST3	1: Request issued (DMA transfer request signal 3 is "1"), 0: No request (DMA transfer request signal 3 is "0")
2	RQST2	1: Request issued (DMA transfer request signal 2 is "1"), 0: No request (DMA transfer request signal 2 is "0")
1	RQST1	1: Request issued (DMA transfer request signal 1 is "1"), 0: No request (DMA transfer request signal 1 is "0")
0	RQST0	1: Request issued (DMA transfer request signal 0 is "1"), 0: No request (DMA transfer request signal 0 is "0")

Chapter 6 Flash Memory

The following V850E2/Fx4-G devices are equipped with internal flash memory as follows:

Series name	Product name	Code flash	Data flash
FE4-G:			
FF4-G-256K	μPD70F4177	256 KB	32 KB
FF4-G-512K	μPD70F4178	512 KB	
FG4-G:			
FG4-G-256K	μPD70F4179	256 KB	32 KB
FG4-G-512K	μPD70F4180	512 KB	

The code flash memory is attached to the dedicated instruction fetch bus of the V850E2 CPU core. It is used for non-volatile storage of program code and constant data.

The data flash memory is accessible via the memory interface bus. It holds nonvolatile user's data, which are subject to be altered during normal program operation.

The flash memory can be written in different ways:

- mounted on the target board by connecting a dedicated flash programmer to the target system (Serial-Programming)
- by the microcontroller's application software (Self-Programming)

Additionally the flash memory is equipped with a configuration area to hold various configuration settings. Via these options start-up configurations can be set for e.g. the Watchdog Timer. The flash configuration options can be written by use of an external flash programmer and in Self-Programming mode. They are not accessible via the normal CPU address space.

6.1 Code Flash Memory Overview

6.1.1 Code flash memory features

- Erase/write with single power supply
- Two programming modes:
 - Serial-Programming with flash programmer using dedicated serial interfaces
 - Flash memory programming by Self-Programming

6.1.2 Code flash memory map

The microcontroller's internal code flash memory area is divided into blocks of 32 KB blocks and can be programmed/erased in block units.

Following tables list the block structures and address assignments for all V850E2/Fx4-G devices with code flash memory.

Table 6-1 Code flash memory configuration

	Block 15 (32 KB)	007 FFFF _H	Address
		...	
		007 8000 _H	
	...		
		...	
	Block 12 (32 KB)	0006 7FFF _H	
		...	
		0006 0000 _H	
	Block 11 (32 KB)	0005 FFFF _H	
		...	
		0005 8000 _H	
	...		
		...	
	Block 8 (32 KB)	0004 7FFF _H	
		...	
		0004 0000 _H	
Block 7 (32 KB)	Block 7 (32 KB)	0003 FFFF _H	
		...	
		0003 8000 _H	
...	...		
		...	
Block 1 (32 KB)	Block 1 (32 KB)	0000 FFFF _H	
		...	
		0000 8000 _H	
Block 0 (32 KB)	Block 0 (32 KB)	0000 7FFF _H	
		...	
		0000 0000 _H	
256 KB	512 KB	Code flash size	
32/64/96/128 KB		Boot swap cluster sizes	
Fx4-G-256K: • μPD70F4177 • μPD70F4179	Fx4-G-512K: • μPD70F4178 • μPD70F4180	Products	

6.1.3 Data flash memory map

The data flash memory is organized in blocks of 32 byte size.

Following tables list the block structures and address assignments for all V850E2/Fx4-G devices with data flash memory.

Table 6-2 V850E2/Fx4-G data flash memory

Product	Data flash size	Number of 32 byte blocks	Address range
• Fx4-G	32 KB	1024	FE00 0000 _H - FE00 7FFF _H

6.2 Code Flash Memory functional Outline

- Serial-Programming** The internal flash memory of the microcontroller can be written by using the erase and write functions of a flash programmer, also while the microcontroller has already been mounted on the target system.
- Self-Programming** The Self-Programming facility allows rewriting of the flash memory by the user program. It is ideal for program updates after production and shipment, since no additional programming equipment is required. During Self-Programming some software services as well as interrupt serving can still be in operation, e.g. to sustain communication with other devices.
- While the Self-Programming mode can be initiated from the normal operation mode the external flash programmer mode is entered immediately after release of a system reset.
- Refer to “Flash memory programming control” in the section “Flash Programming with Flash Programmer” in this chapter for details on how to enter normal operation or Serial-Programming mode.
- Configuration area** The flash memory contains a configuration area, used to store the settings of security and protection functions, initial settings for some modules.
- Boot swap** A boot swap function makes safe re-programming of the flash memory possible and is used to maintain an operable software version, even if re-programming fails for any reason, e.g. in a power fail situation.
- For further information concerning boot swapping refer to “Secure Self-Programming (boot cluster swapping)” below in this chapter.
- Protection** A set of protection flags can be specified during flash memory programming to prohibit access to the flash memory in different ways, such as read-out, write and erase protections for the external programmer interface. By these means the flash memory can be protected against read-out and rewrite of the flash memory content by unauthorized persons.
- For further information concerning data protection refer to the chapter “Code Protection and Security”.

Table 6-3 Flash memory write methods

Environment	Interface	Outline	Operation Mode
Serial-Programming	Dedicated serial interface	Flash memory programming is done by an external flash programmer. The device is mounted on the target system. The communication between the device and the flash programmer is using a dedicated serial interface. For details refer to the section “Flash Programming with Flash Programmer” in this chapter.	Flash memory programming mode
Self-Programming	Self-Programming library	Flash memory can be rewritten by executing a user program that has been written to the flash memory in advance by means of Serial-Programming. The Self-Programming library provides all necessary functions to be called by the application software. For details refer to the section “Code Flash Self-Programming” in this chapter.	Normal operation mode

Table 6-4 “Basic functions for flash memory modifications” on page 231 summarizes the functions used to modify flash memory content.

Table 6-4 Basic functions for flash memory modifications

Function	Functional outline	Support (√: supported, ×: not supported)	
		Serial-Programming	Self-Programming
Block erasure	The contents of specified memory blocks are erased.	√	√
Write	Writing to specified addresses, and a verify check to see if write level is secured are performed.	√	√
Verify	Data read from the flash memory is compared with data transferred from the flash programmer.	√	x ^a
Checksum	Microcontroller internally calculated CRC checksum over the entire flash memory content is compared with the checksum calculated by the serial programmer	√	x
Blank check	The erasure status of the entire memory is checked.	√	√
Protection settings	Following functions can be prohibited: <ul style="list-style-type: none"> • block erase • write • read • rewriting of the boot cluster • flash shield 	√	√ ^b

a) Can be carried out by the user's program.

b) Except protection against rewriting of the boot cluster all other protections have no effect in Self-Programming mode.

Protection settings can be activated in Self-Programming mode. Already activate protection settings can not be deactivated.

The following table lists the available flash memory protection functions.

For details refer to the chapter "Code Protection and Security".

Table 6-5 Protection functions

Function	Functional outline	Applicable (√: applies, ×: doesn't apply)	
		Serial-Programming	Self-Programming
Block erase command prohibit	Erasure of single blocks impossible.	√	×
Program command prohibit	Erasure and rewrite of single blocks impossible.	√	×
Read command prohibit	Read-out of any flash content impossible.	√	×
Rewriting boot area prohibit	Erasure (by block or chip erase) or writing of the boot cluster impossible.	√	√
Flash shield	Write/erase protection outside a defined window.	√	√

6.2.1 Code flash memory erasure and rewrite

Erase Each 32 KB flash memory block can be erased separately.

Rewrite In Self- and Serial-Programming mode it is possible to rewrite the flash memory in smaller units than one block. Once a complete block has been erased it can be rewritten in units of 256 byte. Each unit can be rewritten only once after erasure of the complete block.

6.3 Data Flash Memory

The V850E2/Fx4-G Series products contain data flash in addition to the code flash.

6.3.1 Data flash memory features

The data flash has the following features:

- data flash memory in 32 byte blocks
- write access in 16-bit steps
- erase in 32 byte blocks
- write, erase operations to the data flash while application code can be executed from code flash

6.3.2 Data flash reading and writing

The data flash can be read and written by using an external flash programming tool or the data flash access library.

Programming during normal operation is achieved by using the data flash access software library. For details refer to FDL (Data Flash Access Library).

Data flash read The data flash can only be read 16 bit units on halfword aligned addresses.

Due to the data flash cell structure (complementary read) the read value of an erased data flash is undefined. Use the blank check function of the provided FDL (Data Flash Access Library) for checking if the read value belongs to an erased flash.

Note Once a Data Flash location is written (even with value $FFFF_H$) it can not be overwrite without a previous erase.

6.4 Flash Programming with Flash Programmer

A dedicated flash programmer can be used for external writing of the flash memory in Serial-Programming mode.

Serial-Programming During Serial-Programming the target microcontroller remains mounted on its board. The board is equipped with a connector, that connects the flash programmer to the target microcontroller.

The microcontroller must be fully functional and operated in Serial-Programming mode, in particular

- All external power supplies must be active.
- The external resonator must be connected to the X1/X2 pins.

All other necessary microcontroller configurations are conducted by the on-chip firmware, that is processed in Serial-Programming mode.

Caution Connecting the flash programmer to the on-board microcontroller may yield conflicts with other signals. Pay attention to the hints given in section “*Potential conflicts with on-board signal connections*” on page 239.

6.4.1 Programming environment

The recommended environment to write data to the flash memory of the microcontroller is shown below.




Figure 6-1 Environment to write program to flash memory

A host machine is required for configure the flash programmer. The used flash programmer may also feature a stand-alone mode, so a host machine may not be necessary.

Following dedicated microcontroller serial interfaces can be used as the interface between the flash programmer and the microcontroller:

- single-wire asynchronous serial interface FLUR0
- clocked serial interface FLCS0

Mode pins The mode pins are used to set the microcontroller into flash programming mode.

Refer to the section “*Operation modes*” in the chapter “*CPU System Functions*” for further information.

Note In normal operation mode, i.e. not in flash programming mode, the serial interfaces FLUR0 and FLCS0 are not available. The used ports in flash programming mode are specified in the following sections. These are automatically configured for communicating with the flash programmer in flash programming mode.

6.4.2 Communication modes

(1) Asynchronous flash programming interface FLUR0

The single-wire asynchronous Serial-Programming interface FLUR0 uses following port for connecting to the flash programmer:

- JP0_0: reception/transmission data FLUR0RTX

The external flash programmer offers various choices of available baudrates.




Figure 6-2 Communication with flash programmer via FLUR0

(2) Synchronous flash programming interface FLCS0

The synchronous Serial-Programming interface FLCS0 uses following ports for connecting to the flash programmer:

- JP0_0: serial data input FLCS0SI
- JP0_1: serial data output FLCS0SO
- JP0_2: serial data clock input FLCS0SCI

The external flash programmer offers various choices of available clock rates.




Figure 6-3 Communication with flash programmer via FLCS0

The flash programmer outputs the serial data clock SCK and the microcontroller operates as a slave.

6.4.3 Pin connection with flash programmer PG-FP5

A connector must be mounted on the target system to connect the flash programmer for Serial-Programming. In addition, functions to switch between the normal operation mode and flash memory programming mode and to control the microcontroller's $\overline{\text{RESET}}$ pin must be provided on the board.

When the microcontroller flash memory programming mode is set, all the pins not used for flash memory programming are in the same status as immediately after reset.

Mode pins The mode pins are used to set the microcontroller into flash programming mode.
Refer to the section “*Operation modes*” in the chapter “*CPU System Functions*” for further information.

When the microcontroller flash memory programming mode is set, all the pins not used for flash memory programming are in the same status as immediately after reset.

If the PG-FP5 is used as the flash programmer, connect the PG-FP5 target interface connector to the microcontroller as follows:

Table 6-6 Connection of microcontroller flash programmer PG-FP5

Flash programmer FG-FP5 connection pin			Microcontroller signal (port) name			
Signal name	I/O	Function	FLUR0		FLCS0	
			Signal	Port	Signal	Port
SO/TxD	O	<ul style="list-style-type: none"> FLUR0: receive/transmit data FLCS0: transmit data 	FLUR0RTX	JP0_0	FLCS0SI	JP0_0
SI/RxD	I	Receive data	leave open		FLCS0SO	JP0_1
SCK	O	Transfer clock	leave open		FLCS0SCI	JP0_2
CLK	O	Clock to microcontroller	leave open		leave open	
			leave open		leave open	
$\overline{\text{RESET}}$	O	Reset signal	$\overline{\text{RESET}}$	–	$\overline{\text{RESET}}$	–
FLMD0	I	Mode selection	FLMD0	–	FLMD0	–
FLMD1	I	Mode selection	FLMD1 ^a	P0_1	FLMD1 ^a	P0_1
H/S	I	Handshake signal	leave open		leave open	
V _{DD}	I	Microcontroller supply voltage monitoring	Power supply of JP0 port group buffers ^b		Power supply of JP0 port group buffers ^b	
V _{DD2}	–	Supply voltage	leave open		leave open	
V _{PP}	–	Flash programming voltage	leave open		leave open	

Table 6-6 Connection of microcontroller flash programmer PG-FP5

Flash programmer FG-FP5 connection pin			Microcontroller signal (port) name			
Signal name	I/O	Function	FLUR0		FLCS0	
			Signal	Port	Signal	Port
GND	–	Ground	VSS		VSS	
VDE	–	Reserved	leave open		leave open	
RFU-1	–	Reserved	leave open		leave open	

- a) If FLMD1 is fixed to low level on the target board, the programmer's FLMD1 signal can be left unconnected.
 b) Refer to the chapter "Power Supply" to obtain the correct microcontroller's power supply pins for the JP0 port group.

Refer also to the section "Operation Modes" in chapter "CPU System Functions" for more details about flash programming mode setting.

For details concerning the PF-FP5 programmer, refer to the PG-FP5 User's Manual, document number R20UT0008EJxxxx (xxxx denotes the current version number).

6.4.4 Flash memory programming control

The procedure to program the flash memory is illustrated below.




Figure 6-4 Flash memory programming procedure

(1) Operation mode control

To rewrite the contents of the flash memory by using the flash programmer, set the microcontroller in the flash memory programming mode.

To enter the Serial-Programming mode, i.e. on-board programming by an external flash programmer, the FLMD0 pin has to be supplied with VDD and FLMD1 with VSS level at $\overline{\text{RESET}}$ release.

In the normal operation mode, VSS is input to the FLMD0 pin. A pull-down resistor at the FLMD0 pin ensures normal operation mode if no flash programmer is connected.

Note Refer to the sections “*Operation modes*” and “*Mode pins and JP0 connections*” in the “*CPU System Functions*” chapter for details about operation modes settings.

An example of connection of the FLMD0 and FLMD1 pins is shown below. FLMD1 can be connected to ground via a resistor. Alternatively the FLMD1 pin may also be connected directly to the FLMD1 signal of the flash programmer.




Figure 6-5 Example of connection to flash programmer PG-FP5

Once started in normal operation mode (FLMD0 = 0), FLMD0 pin is used for enabling Self-Programming. Refer also to 6.5 “*Code Flash Self-Programming*” on page 244 .

(2) Potential conflicts with on-board signal connections

Serial I/O signals If other devices are connected to the serial interface pins in use for flash memory programming in Serial-Programming mode take care that the concerned signals do not conflict with the signals of the flash programmer and the microcontroller. Output pins of the other devices must be isolated or set in high impedance state. Ensure that the other devices do not malfunction because of flash programmer signals.




Figure 6-6 Potential conflicts with serial interfaces signals

RESET Pay attention in particular if the flash programmer's $\overline{\text{RESET}}$ signal is connected also to an on-board reset generation circuit. The reset output of the reset generator may ruin the flash programming process and may need to be isolated or disabled.




Figure 6-7 Potential conflict with $\overline{\text{RESET}}$

Ports The V850 port pins adopts following status during Serial-Programming:

Ports used for programming are configured as FLUR0 respectively FLCS0 pins.

All other pins remain in their default state after reset release.

In case the default state after reset of the pins not used for programming is in port or high -impedance output port, pay attention to other devices connected to these pins. If these devices require defined levels at the pins, the ports may have to be connected to VDD or VSS via a resistors.

Oscillators Connect all oscillator pins in the same way as in the normal operation mode.

DCUTRST During flash memory programming, input a low level to $\overline{\text{DCUTRST}}$ (port JP0_4) or leave it open. Do not input a high level.

Power supply Supply the same power to all power supply pins, including reference voltages, power regulator pins, etc., as in the normal operation mode.

(3) Selection of the communication mode

The communication interface is chosen by applying a specified number of pulses to the FLMD0 pin after reset release. Note that this is handled by the flash programmer.

Figure 6-8 “Selection of communication mode” on page 241 gives an example how the FLCS0 is established for the communication between the flash programmer and the microcontroller.




Figure 6-8 Selection of communication mode

Note The number of clocks to be inserted differs depending on the chosen communication mode. For details, refer to Table 6-7 “FLMD0 pulses for communication mode setting” on page 241 .

Table 6-7 FLMD0 pulses for communication mode setting

FLMD0 pulses	Communication mode	Remarks
0	FLUR0	Communication rate: 9600 bps (after reset), LSB first
8	FLCS0	Microcontroller performs slave operation, MSB first
Other	–	Setting prohibited

When FLUR0 has been selected after reception of the FLMD0 pulses with 9600 bps, the flash programmer changes the baudrate according to the user’s choice via the flash programmer’s user interface.

(4) Communication commands

The flash programmer sends commands to the microcontroller. Depending on the commands, the microcontroller returns status information or the requested data.




Figure 6-9 Communication commands exchange

The following table lists the flash memory control commands of the microcontroller. All these commands are issued by the flash programmer, and the microcontroller performs the corresponding processing.

Table 6-8 Flash memory control commands (1/2)

Classification	Command name	Support		Function
		FLCS0	FLUR0	
Blank check	Block blank check	√	√	Checks erasure status of entire memory.
Erase	Block erase	√	√	Erases the memory contents of specified blocks. Note that the configuration area remains untouched.
Write	Write	√	√	Writes data by specifying write address and number of bytes to be written, and executes verify check.
	Chip write	√	√	Writes all flash memory contents
Read	Read	√	√	Reads data by specifying write address and number of bytes to be read.
Verify	Verify	√	√	Compares input data with all memory contents.
ID	Set ID code	√	√	Set the On-chip Debug ID to the registers OCDIDL, OCDIDM, OCDIDH
	Get ID code	√	√	Reads the On-chip Debug ID from the registers OCDIDL, OCDIDM, OCDIDH
CRC check	CRC check	√	√	Calculates a checksum over a specified number of flash blocks of the code flash or the data flash. Note that this checksum does not cover the configuration area.
	Chip CRC check	√	√	Calculates a checksum over the entire flash memory, including code flash, data flash and configuration area.

Table 6-8 Flash memory control commands (2/2)

Classification	Command name	Support		Function
		FLCS0	FLUR0	
Flash configuration option	Set flash configuration option	√	√	Set the flash configuration options to register OPBT0
	Get flash configuration option	√	√	Reads the flash configuration options from register OPBT0
Protection	Protection setting	√	√	Sets protection against chip erasure, block erasure, and writing.
	Get protection settings	√	√	Reads the protection settings.
System setting and control	Reset	√	√	Escapes from each status.
	Oscillation frequency setting	√	√	Sets oscillation frequency.
	Baudrate setting	–	√	Sets baudrate when UART is used.
	Silicon signature	√	√	Reads silicon signature information.

6.5 Code Flash Self-Programming

This V850 microcontroller supports a flash macro service that allows the user program to rewrite the internal flash memory by itself.

By using this flash macro service and a Self-Programming library (SPL), provided by Renesas, the user's program is able to rewrite the flash memory with data, transferred in advance to the internal RAM or the external memory.

Thus the user program can be upgraded and constant data can be rewritten in the field.




Figure 6-10 Concept of Self-Programming

During Self-Programming access to the flash memory is not possible. Thus program execution is only possible by instruction fetching from internal RAM or external memory.

Consequently the instructions of user re-programming software routines, which shall remain in operation during the Self-Programming procedure, must be copied from the flash memory to the internal RAM or external memory prior to activating the Self-Programming. Since interrupt processing by using the interrupt vectors in the flash memory is also impossible during Self-Programming, interrupt acknowledges need to be re-routed to interrupt vectors in the internal RAM (refer to *"Interrupt handling during flash Self-Programming"* on page 251).

It is recommended to refer to the User's Manual "<td>" for comprehensive information concerning flash Self-Programming. This document explains also the functions of the Self-Programming library.

6.5.1 Self-Programming enable

The Self-Programming function can be started out of the normal user mode of the microcontroller.

Self-Programming must be in particular enabled in order to avoid unintended re-programming of the flash. Two ways to enable Self-Programming are provided:

- by setting the external FLMD0 pin to high level
This requires some external components or wiring, e.g. connecting an output port to FLMD0.
- by setting the internal register bit FLMDCNT.FLMDPUP
This way does not need any special external components or wiring.

The following register is used to enable Self-Programming internally by software.

Note The FLMD0 pin must be connected to ground via a 82 kΩ resistor. Refer to the section “Mode pins and JP0 connections” in the “CPU System Functions” chapter and the Data Sheet for further details.

(1) FLMDCNT – FLMD control register

This register controls an internal pull-up respectively pull-down resistor, connected to the FLMD0 pin, and thus enables respectively disables Self-Programming.

Protection Writing to this register is protected by a special sequence of instructions by using the protection command register FLMDPCMD. Refer to the section “Write protected Registers” in chapter “CPU System Functions” for a detailed description how to write to write protected registers.

Access This register can be read/written in 8-bit units.

Address FF43 8000_H

Initial Value 00_H

7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	FLMDPUP
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 6-9 FLMDCNT register contents

Bit position	Bit name	Function
0	FLMDPUP	FLMD0 pull-up/pull-down control 0: pull-down resistor active at FLMD0 (Self-Programming mode disabled) 1: pull-up resistor active at FLMD0 (Self-Programming mode enabled)

6.5.2 Self-Programming library functions

Code flash memory Self-Programming by the user's program is supported by the Self-Programming library.

This library provides a set of C function calls to carry out basic functions like

- erase and rewrite of the flash memory
- boot cluster swapping, including definition of boot clusters
- setting of protection flags
- obtain various information concerning the code flash memory

Detailed information how to use the library functions is given in the User's Manual "<td>".

6.5.3 Self-Programming internal RAM occupancy

During Self-Programming the upper 4 KB of the internal RAM (address FEDF F000_H - FEDF FFFF_H) are occupied by the Self-Programming Library. Thus the content of this 4 KB RAM is altered during Self-Programming and may have to be recovered by the user's program.

Note Additional RAM may be necessary for intermediate storage of user data and code to be copied from flash memory to RAM during Self-Programming.

6.5.4 Secure Self-Programming (boot cluster swapping)

The V850 flash microcontrollers support a mechanism to swap a cluster of code flash memory blocks, starting from address 0000 0000_H, with another cluster of the same size, located immediately above the first one.

Boot swap cluster A group of boot blocks to be swapped. The cluster of blocks starting at address 0000 0000_H is named active boot swap cluster, since it contains the entry point of the user's program at the default reset vector 0000 0000_H.

Boot swap flag Which of the two clusters is the active boot cluster is controlled by the boot swap flag, that can be defined during flash programming via the Self-Programming library. The boot swap flag is stored in the flash memory configuration area.

Figure 6-11 "Boot swap cluster swapping function" on page 247 shows an example of the boot block swapping function with a cluster size of 4 flash memory blocks. After inverting the boot_flag - it becomes not(boot_flag) - blocks 4 to 7 become the active boot cluster. Thus after next reset release the user's program starts from the new boot swap cluster.




Figure 6-11 Boot swap cluster swapping function

Secure Self-Programming The boot cluster swapping function enables secure Self-Programming. In case the boot code shall be rewritten, the new code can be written to the inactive boot cluster, while the `boot_flag` remains in its previous state. If rewriting of the boot cluster has been completed successfully, the `boot_flag` can be inverted, making the new boot code active. If rewriting of the new boot code fails for any reason, e.g. power fail or unintended reset, the old boot code still remains active and rewriting can be started again.

Boot cluster The boot code size itself may be smaller than the boot swap cluster size. The number of flash memory blocks, which are part of the boot code, are named boot cluster. The number of boot blocks, which are member of the cluster, can be defined during Self-Programming via the Self-Programming library. The boot cluster size determines the boot swap cluster size. This is automatically evaluated from the number of boot blocks, defined during Self-Programming.

Table 6-10 "Relation between boot block and boot swap cluster" on page 249 shows the relation between the number of boot blocks, the boot cluster size and the boot swap cluster.

Number of boot blocks BTBLS The number of boot blocks (BTBLS) has to be defined by the user during self-programming. It determines the blocks, which are subject to the boot cluster protection, that allows to protect the boot blocks from any erase or write process.

Boot block protection To prohibit rewriting of the boot blocks, the boot cluster protection flag can be set during flash memory programming. When this flag is set, the blocks of the active boot cluster can neither be erased nor written. Boot cluster swapping is impossible as well. Note that only the blocks of the active boot cluster are protected. In the example according to *Figure 6-12 "Boot cluster swapping function" on page 250*, for instance, blocks 0 and 1 would be prohibited, while blocks 2 and 3 could still be erased and written.

Caution Once the boot cluster protection has been activated, it can never be deactivated again.

For further information concerning flash memory protection flags refer to the chapter *"Code Protection and Security"*.

Table 6-10 Relation between boot block and boot swap cluster

Number of boot blocks BTBLS	Boot cluster size	Boot swap		Boot cluster protection	
		Active boot swap cluster ↔ inactive boot swap cluster			
00 _H to 03 _H	Setting inhibited				
04 _H to 07 _H	32 KB	0000 0000 _H to 0000 7FFF _H ↔ 0000 8000 _H to 0000 FFFF _H		Size:	32 KB
				Address:	0000 0000 _H to 0000 7FFF _H
08 _H to 0F _H	64 KB	0000 0000 _H to 0000 FFFF _H ↔ 0001 0000 _H to 0001 FFFF _H		Size:	64 KB
				Address:	0000 0000 _H to 0000 FFFF _H
10 _H to 17 _H	128 KB	0000 0000 _H to 0001 FFFF _H ↔ 0002 0000 _H to 0003 FFFF _H		Size:	96 KB
				Address:	0000 0000 _H to 0001 7FFF _H
18 _H to 1F _H	128 KB	0000 0000 _H to 0001 FFFF _H ↔ 0002 0000 _H to 0003 FFFF _H		Size:	128 KB
				Address:	0000 0000 _H to 0001 FFFF _H
20 _H to 3F _H	256 KB	0000 0000 _H to 0003 FFFF _H ↔ 0004 0000 _H to 0007 FFFF _H		Size:	128 KB + (BTBLS - 1F _H) * 32 KB
				Address:	0000 0000 _H to (128 KB + (BTBLS - 1F _H) * 32 KB)
40 _H to FF _H	Setting inhibited				

Maximum boot swap cluster The maximum boot cluster size is 256 KB. Thus code flash above 512 KB can not be subject to boot cluster swapping.

Figure 6-12 “Boot cluster swapping function” on page 250 illustrates an example with following settings:

- number of boot blocks: 2 (boot cluster contains 2 blocks), thus the active boot cluster comprises
 - if boot_flag: blocks 0 and 1
 - if not(boot_flag): blocks 4 and 5
- active boot swap clusters comprises
 - if boot_flag: blocks 0 to 3
 - if not(boot_flag): blocks 4 to 7




Figure 6-12 Boot cluster swapping function

6.5.5 Interrupt handling during flash Self-Programming

This microcontroller provides functions to maintain interrupt servicing during the Self-Programming procedure.

Since neither the interrupt vector table nor the interrupt handler routines, which are normally located in the flash memory, are accessible while Self-Programming is active, interrupt acknowledges have to be re-routed to non-flash memory, i.e. to the internal RAM.

Therefore two prerequisites are necessary to enable interrupt servicing during Self-Programming:

- The concerned interrupt handler routine needs to be copied to non-flash memory, e.g. to the internal RAM. The user has to initiate this copy process.
- The concerned interrupt acknowledge has to be re-routed to that handler. Re-routing to the handler is done by use of the CPU registers SW_CFG/SW_BASE respectively EH_CFG/EH_BASE. Refer to the "Microcontroller Core Architecture User's Manual" for further details about these CPU registers.

Re-routing of the interrupt vectors offer two options:

- All interrupt can be mapped to the single interrupt vector of interrupt channel 0.
- The base address of the interrupt vector table can be mapped to a different address. In this case the offsets of the interrupt channels are added to the new base address and the correct interrupt vector is obtained upon interrupt acknowledgement.

It is recommended to refer to the User's Manual "<tbid>".

6.6 Flash configuration options

The flash memory contains a configuration area that holds user specified data for various purposes.

These flash configuration options become effective upon a release of an external RESET, a Power-On-Clear reset POCRES or debugger reset DBRES, thus determining initial settings of various modules.

Caution If the flash memory is programmed during a debug session with the on-chip debugger and any flash configuration options have been changed, a target reset command has to be issued in order to make the new option settings effective.

All flash configuration options can be read in all operation modes.

Modification of flash configuration options depend partly on the operation mode, some can not be modified at all.

The following table summarizes all flash configuration options and about the possibility to modify them in the different operation modes.

Table 6-11 Flash configuration options and setting

Function	Flash configuration option	Modification possible in mode			
		Normal	Flash Serial-Programming	Flash Self-Programming	Debug
JTAG port group JP0 control	OPBT0.OPBT0[31]	no	yes	yes	yes
VAC enable/disable of WDTA1	OPBT0.OPBT0[26]	no	yes	yes	yes
Automatic or S/W start of WDTA1	OPBT0.OPBT0[24]	no	yes	yes	yes
Enable/disable of WDTA1	OPBT0.OPBT0[23]	no	yes	yes	yes
VAC enable/disable of WDTA0	OPBT0.OPBT0[22]	no	yes	yes	yes
Automatic or S/W start of WDTA0	OPBT0.OPBT0[20]	no	yes	yes	yes
Enable/disable of WDTA0	OPBT0.OPBT0[19]	no	yes	yes	yes
Initial value of WDTAn count clock	OPBT0.OPBT0[18:16]	no	yes	yes	yes

6.6.1 OPBT0 - Flash configuration option register 0

Access In normal operation mode this register can be read in 32-bit units. Writing to this register is only possible in flash programming and self-programming mode.

Address FF47 000C_H

Initial Value User defined

31	30	...	0
OPBT0 [31]	OPBT0 [30]	...	OPBT0 [1] OPBT0 [0]
R	R	...	R R

Table 6-12 OPBT0 register contents

Bit position	Bit name	Connected to		Function
		Module	Signal	
31	OPBT0[31]	JTAG port group JP0	OPJTAG	Controls the functions of the JTAG port group JP0: 0: JP0 used for general purpose/alternative functions ports 1: JP0 used as JTAG ports
30 to 27	OPBT0[30:27]	–	–	Reserved, set to “0”
26	OPBT0[26]	WDTA1	OPWDVAC	Enables/disables the Variable Activation Code function (VAC) of WDTA1 0: VAC is disabled 1: VAC is enabled
25	OPBT0[25]	–	–	Reserved, set to “0”
24	OPBT0[24]	WDTA1	OPWDRUN	Specifies the start mode of WDTA1: 0: Software trigger start mode 1: Automatic start mode
23	OPBT0[23]		OPWDEN	Enables/disables WDTA1: 0: WDTA1 is disabled 1: WDTA1 is enabled
22	OPBT0[22]	WDTA0	OPWDVAC	Enables/disables the Variable Activation Code function (VAC) of WDTA0 0: VAC is disabled 1: VAC is enabled
21	OPBT0[21]	–	–	Reserved, set to “0”
20	OPBT0[20]	WDTA0	OPWDRUN	Specifies the start mode of WDTA0: 0: Software trigger start mode 1: Automatic start mode
19	OPBT0[19]		OPWDEN	Enables/disables WDTA0: 0: WDTA0 is disabled 1: WDTA0 is enabled
18 to 16	OPBT0[18:16]	WDTA0 WDTA1	OPWDOVF [2:0]	Specifies the reset value of the count clock WDTA0 and WDTA1 control bits WDTAnMD.WDTAnOVF[2:0].
15 to 0	OPBT0[15:0]	–	–	Reserved, set to “0”

Chapter 7 Clock Controller

This chapter describes the Clock Controller functions of the V850E2/Fx4-G microcontrollers.

The clock signals, their control registers, etc. follow a defined naming convention, that reflects their membership to a certain power domain and clock domain.

Power domain index m The index m is used to define the power area:

- m = 0: denotes the Isolated-Area-0 (Iso0)
- m = A: denotes the Always-On-Area (AWO)

Clock domain index n The index n is used to define the clock domain.

- n_0 denotes the clock domain indices of Isolated-Area-0 clock domains
- n_A denotes the clock domain indices of Always-On-Area clock domains

Power domain	Clock domains
Isolated-Area-0	$n_0 = 00, 05, 06, 07, 11, 12, 16, 28, 29, 32, 33, 34$
Always-On-Area	$n_A = 02, 03, 05, 07$

Examples:

The clock selector registers CKCS_0n select the clocks for the Isolated-Area-0, which are named CKSCLK_0n.

The clock signal CKSCLK_A06 is the clock, supplied to the clock domain 06 ($n = 06$) on Always-On-Area ($m = A$). This clock is selected via the clock selector register CKSC_A06.

7.1 Clock Controller Overview

Features summary The Clock Controller has the following functions:

- three oscillators:
 - Low Speed Internal Oscillator with a nominal frequency of 240 kHz
 - High Speed Internal Oscillator with a nominal frequency of 8 MHz
 - Main Oscillator 4 MHz to 20 MHz
- one PLL circuit: PLL0
- separate clock selector for each clock domain with individual stand-by control
- three Clock Monitors (CLMA0, CLMA2, CLMA3)
 - CLMA0: supervision of MainOsc
 - CLMA2: supervision of High Speed IntOsc
 - CLMA3: supervision of PLL0

Note For the specification of the clock generators frequencies, their tolerance and other parameters, refer to the document Data Sheet .

Clock sources overview The following table summarizes all clock sources and their typical respectively maximum frequencies:

Table 7-1 V850E2/Fx4-G clock sources overview

Source	Input	Frequency
MainOsc	external crystal	nom. 4, 5, 6, 8, 10, 12, 16, 20 MHz
PLL0	MainOsc	<ul style="list-style-type: none"> • V850E2/FF4-G: max. 64 MHz • V850E2/FG4-G: max. 64 MHz
Low Speed IntOsc	–	nom. 240 kHz
High Speed IntOsc	–	nom. 8 MHz

Clock Monitors outputs The Clock Monitors are generating following output signals to indicate abnormal clock frequencies of the supervised clock:

- $\overline{\text{CLMAnRES}}$: the reset outputs can generate a reset
- INTCLMA_n: the interrupt can generate
 - an interrupt, if connected to the Interrupt Controller
 - a wake-up from stand-by mode, if connected to the Stand-by Controller and if enabled as wake-up factor (refer to the chapter “*Stand-by Controller*” for details).

Table 7-2 CLMA_n output signals

CLMA	CLMA _n RES connected to	INTCLMA _n connected to
CLMA0	Reset Controller	Interrupt Controller Stand-by Controller
CLMA2	Reset Controller	Stand-by Controller
CLMA3	Reset Controller	Stand-by Controller

The following figure shows the main components of the Clock Controller.




Figure 7-1 Clock Controller overview

7.2 General Description of Clock Generation and Control

The Clock Controller generates a set of clock signals for each of the three power domains

- CKSCLK_On for clocks on the Isolated-Area-0 (Iso0)
- CKSCLK_An for clocks on the Always-On-Area (AWO).

Each clock signal CKSCLK_mn supplies the clock for the clock domain “mn”.

Common to all clock domains of a certain power area is, that they can be stopped all together in STOP stand-by mode, that requests the clocks of this domain to be stopped.

The following diagram outlines the basic structure of the Clock Controller.




Figure 7-2 Clock Controller structure

The Clock Controller provides

- a set of different clock generators, that generate clocks in different frequency ranges
- a set of clock selectors, that allow to select a clock, or fractions thereof, from the clock generators to supply all clock domains on the three power domains.

The clock generators as well as the selectors are controlled by Reset and Stand-by Controller signals:

- Reset Controller signals
 - PURES: power-up reset signal (Power-On-Clear POCRES or Debugger DBRES reset), which is asserted during power-up of the microcontroller
 - SYSRES: system reset signal, which is asserted by any internal and external reset source, including PURES

For detailed information about the Reset Controller signals, refer to the chapter *“Reset Controller”*.

- Stand-by Controller signals
 - STPREQ: Isolated Area-0 stop request signal
STPREQ is asserted, when the microcontroller enters an Isolated-Area-0 stand-by mode and is used to stop the clock generators and the Isolated-Area-0 and Always-On-Area domain clocks via the clock selectors CKSC_0n₀ and CKSC_An_A.
 - DPSTPWU: Isolated Area-0 DEEPSTOP wake-up signal
DPSTPWU is asserted, when the microcontroller wakes up from DEEPSTOP mode and is used to reset the Isolated-Area-0 clock selectors.
 - WUOSCSTA: Wake-up oscillator start signal
WUOSCSTA can optionally be asserted, when the MainOsc shall start operation upon wake-up from a stand-by mode. The generation of WUOSCSTA is controlled by a register of the Stand-by Controller.

For detailed information about the Stand-by Controller signals, refer to the chapter *“Stand-by Controller (STBC)”*.

Common to all clock generators and clock domains of a certain power domain is, that they can be stopped all together in STOP stand-by mode.

The Stand-by Controller issues the signal STPREQ stop request to the generators and selectors. However all clock generators and most of the domain clock selectors allow to mask the stop request in order to continue clock output to the concerned clock domain also in stand-by mode.

Since the Isolated-Area-0 clock selectors reside on the Isolated-Area-0 power domain, and thus their power supply are switched off in DEEPSTOP mode, the clock selectors are reset upon DEEPSTOP wake-up. So they have to be completely re-initialized afterwards.

The following figure shows the reset and stop request signals wiring of the clock generators and selectors.




Figure 7-3 Clock Controller stand-by mode and reset signals

The Clock Controller consists of two main parts.

7.2.1 Clock generators

Four clock generators are provided:

- Low Speed Internal Oscillator (Low Speed IntOsc)
This oscillator starts operation after power up and can not be stopped, hence it is always operating. It generates the clock f_{RL} with a nominal frequency of 240 KHz.
It does not require any external components.
- High Speed Internal Oscillator (High Speed IntOsc)
The High Speed IntOsc generates a clock with the nominal frequency of 8 MHz without any external components.
- Main Oscillator (MainOsc)
The MainOsc output clock f_X is the main system root clock, as f_X is input to the PLLs. The MainOsc operates with an external resonator (X1, X2).
- PLL0
The PLL0 circuit generate the high speed operation clock f_{PL0} for normal operation of the microcontroller.

The Low Speed IntOsc, High Speed IntOsc and MainOsc oscillators are located on the Always-On-Area, while the PLL0 resides on the Isolated-Area-0. Thus in DEEPSTOP stand-by mode PLL0 is switched off.

It is optionally possible to individually disable the generators (except the Low Speed IntOsc) in STOP stand-by mode.

The output clocks of the clock generators, except of the MainOsc f_X , are input to prescalers, which provide different fractions of these clocks.
Note that the prescalers for all clocks have different division factors.

(1) Automatic start of the MainOsc after stand-by wake-up

The MainOsc can be automatically started upon stand-by mode wake-up, independent of their status before stand-by.

Refer to the “Wake-up” section in the chapter “Stand-by Controller (STBC)” for details about this feature.

(2) Clock generators reset

The MainOsc and High Speed IntOsc clock generators are only reset by the power-up reset PURES (Power-On-Clear reset POCRES or Debugger reset DBRES).

Thus any internal reset neither stops these clock generators nor changes their configuration. Consequently the microcontroller start-up time after release from an internal reset is minimum, because the clock generator’s stabilization times have not to be regarded.

The PLL0 is reset by all internal and external reset sources via SYSRES.

(3) STOP stand-by mode request

The Stand-by Controller signal STPREQ is asserted upon entering Isolated-Area-0 STOP mode and is applied to the stop requests STPREQ of the MainOsc, High Speed IntOsc and PLL0.

STPREQ can be individually masked by the respective clock generator control register:

- MainOsc: MOSCE.MOSCESTPMK = 0:
STPRQ is not masked, thus f_x is stopped, if STPRQ is asserted
- High Speed IntOsc: ROSCE.ROSCESTPMK = 0:
STPRQ is not masked, thus f_{RH} is stopped, if STPRQ is asserted
- PLL0: PLLE0.PLLE0STPMK = 0:
STPRQ is not masked, thus f_{PL0} is stopped, if STPRQ is asserted

If the stop request is not masked, i.e. the clock generator is stopped during stand-by mode, it automatically restarts operation after wake-up from stand-by mode, provided it was operating before stand-by mode entry.

If the clock generator was stopped before stand-by mode, it remains stopped. However the MainOsc can be started after wake-up, even if they were not operating before stand-by. Refer to the section 1 “Automatic start of the MainOsc after stand-by wake-up” on page 260 above.

If the stop request is masked, the clock generator’s status is not changed during stand-by mode.

(4) DEEPSTOP stand-by mode

A DEEPSTOP stand-by mode asserts also the STPREQ_0 signal and impacts the clock generators in the same way like STOP stand-by mode.

Since the power supplies of the Isolated-Area-0 is switched off in DEEPSTOP stand-by mode, the PLL0 clock f_{PL0} stops operation.

After release from DEEPSTOP mode the PLL0 control registers take on their reset state and the PLL0 circuit has to be completely re-initialized.

- Notes**
1. Refer to 7.3 “Clock Generators” on page 263 for a detailed description of the clock generators.
 2. For the specification of the clock generators frequencies, their tolerance and other parameters, refer to the document Data Sheet.

7.2.2 Clock selectors

The clocks, generated by the clock generators, are input to the clock selectors CKSC_mn. A separate clock selector register CKSC_mn is provided for each clock domain.

Note that not all available clocks from the clock generators are input to each clock selector.

The two sets of clock selector registers are dedicated to the clock domains on one of the two power domains:

- n_0 registers CKSC_000 to CKSC_0n₀ for clock domains on the Isolated-Area-0.

- n_A registers CKSC_A00 to CKSC_An_A for clock domains on the Always-On-Area

By use of a clock selector register CKSC_mn one of its input clocks is selected as the clock CKSCLK_mn.

The clock selectors CKSCLK_mn, selecting the clock domain clocks for power domain m, are also located on the same power domain.

(1) Clock selectors reset

The clock selectors are reset by the SYSRES signal, which is asserted by any microcontroller internal or external reset. Hence after any reset the supply of all clock domains are set to their default configuration.

Additionally the clock selectors located on the Isolated-Area-0 power domain are reset if Isolated-Area-0 is woken up from DEEPSTOP mode.

(2) STOP stand-by mode request

The stop request for the Always-On-Area and Isolated-Area-0 is issued by the Stand-by Controller by asserting any of the stop request signals STPREQ upon entering STOP mode.

The stop request, supplied to all clock selectors, can be individually masked by the clock selector register CKSC_mn:

- CKSC_mn.STPMK_mn = 0:
STPREQ is not masked, thus CLSCLK_mn is stopped, if STPREQ is asserted
- CKSC_mn.STPMK_mn = 1:
STPREQ is masked, thus CLSCLK_mn remains in operation, even if STPREQ is asserted

Note Not all clock selectors CKSC_mn provide the stop mask function. These clock domains remain in operation during STOP mode. Refer to the section “Clock Selection” below in this chapter for details about each clock selector.

(3) DEEPSTOP stand-by mode

In a DEEPSTOP stand-by mode the power supply of the Isolated-Area-0 is switched off.

Since the clock selectors CKSC_0n₀ reside on the Isolated-Area-0 power domain, they are switched off as well in DEEPSTOP mode.

Upon wake-up they receive the reset signal DPSTPWU, and are in their default - i.e. reset - state after DEEPSTOP wake-up. Consequently the CKSC_0n₀ clock selectors have to be completely re-initialized.

Note Refer to 7.6 “Clock Selection” on page 1 for a detailed description of the clock selectors.

7.3 Clock Generators

7.3.1 Main Oscillator (MainOsc) clock generator

The Main Oscillator generates the clock f_X , which is supplied to the clock domain clock selectors CKSC_mn. f_X is also used as the PLL input clock PLLCLKIN.

The diagram below shows the basic structure and signals of the MainOsc clock generator.




Figure 7-4 Main Oscillator clock generator

After release of the power-up reset PURES the MainOsc is disabled.

Note During assertion of the external $\overline{\text{RESET}}$ the MainOsc is always operating with its maximum amplification gain. Refer to the description of the external $\overline{\text{RESET}}$ in the “Reset Controller” chapter for details. All other resets except PURES and $\overline{\text{RESET}}$ do not affect the MainOsc.

MainOsc enable/disable

The MainOsc can be enabled and disabled and its status can be checked:

- enable trigger: MOSCE.MOSCENTRG = 1, enabled status: MOSCS.MOSCSCLKEN = 1
- disable trigger: MOSCE.MOSCEDISTRG = 1 disabled status: MOSCS.MOSCSCLKEN = 0

MainOsc stabilization

The MainOsc stabilization counter starts counting down the stabilization time. During count down the MOSCSCLKSTAB signal disables the f_X output to the MainOsc prescaler.

If the stabilization counter has reached the stabilization count value, as defined in MOSCST.MOST[3:0], f_x is judged as stable and change of the MOSCSCLKSTAB signal inputs f_x to the prescaler. This status is indicated by the bit MOSCS.MOSCSCLKSTAB = 1.

The active f_x clock at the clock selectors CKSC_mn is indicated by MOSCS.MOSCSCLKACT = 1.

The stabilization counter clock OSCSTCLK is selected from two sources:

- OSCSTCLK = 8 MHz High Speed IntOsc clock f_{RH} , if this oscillator is operating (ROSCS.ROSCSCLKEN = 1)
- OSCSTCLK = 240 kHz Low Speed IntOsc clock f_{RL} , if the High Speed IntOsc is disabled (ROSCS.ROSCSCLKEN = 0)

The stabilization counter clock source is selected automatically by the High Speed IntOsc operation status.

MOSCST.MOST[3:0] determines the number of OSCSTCLK periods as the MainOsc stabilization time, which can be specified in the range of 2^2 to 2^{17} OSCSTCLK periods.

Short stabilization time mode

If the MainOsc has been stopped during stand-by mode (refer to the “STOP stand-by mode request” below) and is restarted after wake-up, the stabilization time - and so the wake-up time - can be shortened by selecting the short stabilization time mode (MOSCC.MOSCCSHTSTBY = 1). This sets the amplification gain of the MainOsc circuit to maximum.

Note that selection of the amplification gain by MOSCC.MOSCCSHTSTBY has only effect during the MainOsc stabilization. If the MainOsc is stable normal amplification gain is used.

Note Make sure to use the f_x clock only if MOSCS.MOSCSCLKACT = 1.

STOP stand-by mode requests

By use of the STPREQ signal the Stand-by Controller indicates stand-by status of the Isolated-Area-0 and the Always-On-Area. The stop request mask bit MOSCE.MOSCESTPMK controls whether the MainOsc is stopped during stand-by or continues operation.

If the MainOsc is stopped during stand-by (MOSCE.MOSCESTPMK = 0), it is automatically re-started upon wake-up from stand-by mode, provided it was operating before stand-by mode entry.

If the MainOsc was stopped before stand-by mode, it remains stopped.

Note The MainOsc can also be activated after stand-by wake-up, independent of its status before stand-by mode, via the wake-up oscillator start signal WUOSCSTA. Generation of WUOSCSTA is controlled by the oscillator wake-up mask register OSCWUFMSK. Refer to section “Wake-up” in the chapter “Stand-by Controller (STBC)” for details.

Clock Monitor control The MainOsc activity flag MOSCS.MOSCSCLKACT is output to the Clock Monitor CLMA0 to control its operation. In case the MainOsc is inactive, supervision of its output clock f_x by CLMA0 is also deactivated. The table below summarizes the different conditions for the Clock Monitor control.

Table 7-3 Clock Monitor 0 status control

MainOsc enable status	MainOsc stand-by control		MainOsc stand-by status	CLMA0 status
MOSCSCLKEN	MOSCESTPMK	STPREQ	MOSCSCLKACT	
0	X	X	0	stopped
1	0	0	1	active
		1	0	stopped
	1	X	1	active

MainOsc enable/disable trigger The MainOsc can be enabled and disabled by the enable and disable trigger control bits:

- enable trigger MOSCE.MOSCEENTRG = 1 starts the MainOsc
Note that setting the enable trigger is only effective if the MainOsc is inactive, i.e. if MOSCS.MOSCSCLKACT = 0.
- disable trigger MOSCE.MOSCEDISTRG = 1 stops the MainOsc
Note that setting the disable trigger is only effective if the MainOsc is active, i.e. if MOSCS.MOSCSCLKACT = 1.

7.3.2 Low Speed Internal Oscillator (Low Speed IntOsc) clock generator

The Low Speed Internal Oscillator generates the clock f_{RL} , which is supplied to the clock domain clock selectors CKSC_mn. f_{RL} has a nominal frequency of 240 KHz.

The diagram below shows the basic structure and signals of the Low Speed IntOsc clock generator.




Figure 7-5 Low Speed Internal Oscillator clock generator

After reset release the Low Speed IntOsc starts operation. It can not be stopped.

The Low Speed IntOsc clock f_{RL} is used as the sampling clock for Clock Monitors CMLA0 and CLMA2.

7.3.3 High Speed Internal Oscillator (High Speed IntOsc) clock generator

The High Speed Internal Oscillator generates the clock f_{RH} , which is supplied to the clock domain clock selectors $CKSC_{mn}$. f_{RH} has a nominal frequency of 8 MHz.

The diagram below shows the basic structure and signals of the High Speed IntOsc clock generator.




Figure 7-6 High Speed Internal Oscillator clock generator

After PURES release the High Speed IntOsc starts operation.

Note All other resets except PURES do not affect the High Speed IntOsc.

High Speed IntOsc enable/disable The High Speed IntOsc can be enabled and disabled and its status can be checked:

- enable trigger: $ROSCE.ROSCEENTRG = 1$,
enabled status: $ROSCS.ROSCSCLKEN = 1$
- disable trigger: $ROSCE.ROSCEDISTRG = 1$
disabled status: $ROSCS.ROSCSCLKEN = 0$

Caution Pay attention to clock domains, which are using the High Speed IntOsc clock as source via the clock selectors CKSC_mn, when disabling f_{RH} by ROSCE.ROSCEDISTRG = 1.
 In particular all resets set all clock selectors CKSCLK_mn to their default selection, but only the PURES enables the High Speed IntOsc.
 As a consequence all PBUS clocks PCLK will not operate after a reset - except PURES -, since the High Speed IntOsc is selected as their clock source, but the High Speed IntOsc is not enabled.

High Speed IntOsc stabilization The High Speed IntOsc stabilization counter starts counting down the stabilization time.
 As long as the High Speed IntOsc is not stable, the CLKSEL signal disables the f_{RH} output to the MainOsc prescaler.
 If the High Speed IntOsc stabilization counter has counted four periods of its input clock OSCSTCLK, f_{RH} is judged as stable and change of CLKSEL inputs f_{RH} to the prescaler, thus all prescaler outputs are available for the clock selectors CKSCmn.
 The f_{RH} clock stable status is indicated by the bit ROSCS.ROSCSCLKSTAB = 1 and its activation by ROSCS.ROSCSCLKACT = 1.
 The stabilization counter clock OSCSTCLK is the 240 kHz Low Speed IntOsc clock f_{RL} .

Note Make sure to use the f_{RH} clock only if ROSCS.ROSCSCLKACT = 1.

Stand-by mode requests By use of the STPREQ signal the Stand-by Controller indicates stand-by status of the Isolated-Area-0 and the Always-On-Area. The stop request mask bit ROSCE.ROSCSTPMK controls whether the High Speed IntOsc is stopped during stand-by or continues operation.
 If the High Speed IntOsc is stopped during stand-by (ROSC.ROSCSTPMK = 0), it is automatically re-started upon wake-up from stand-by mode, provided it was operating before stand-by mode entry.
 If the High Speed IntOsc was stopped before stand-by mode, it remains stopped.

Clock Monitor control The High Speed IntOsc activity flag ROSCS.ROSCSCLKACT is output to the Clock Monitor CLMA2 to control its operation. In case the High Speed IntOsc is inactive, supervision of its output clock f_{RH} by CLMA2 is also deactivated. The table below summarizes the different conditions for the Clock Monitor control.

Table 7-4 Clock Monitor 2 status control

High Speed IntOsc enable status ROSCSCLKEN	High Speed IntOsc stand-by control		High Speed IntOsc stand-by status ROSCSCLKACT	CLMA2 status
	ROSCSTPMK	STPREQ		
0	X	X	0	stopped
1	0	0	1	active
		1	0	stopped
	1	X	1	active

The High Speed IntOsc clock f_{RH} is used as the sampling clock for Clock Monitor CMLA3.

High Speed IntOsc enable/disable trigger The High Speed IntOsc can be enabled and disabled by the enable and disable trigger control bits:

- enable trigger ROSCE.ROSCEENTRG = 1 starts the High Speed IntOsc
Note that setting the enable trigger is only effective if the High Speed IntOsc is inactive, i.e. if ROSCS.ROSCSCLKACT = 0.
- disable trigger ROSCE.ROSCEDISTRG = 1 stops the High Speed IntOsc
Note that setting the disable trigger is only effective if the High Speed IntOsc is active, i.e. if ROSCS.ROSCSCLKACT = 1.

7.3.4 Phase-Locked Loop (PLL) clock generators

The Main Oscillator clock f_x is input to the Phase-Locked Loops clock generator PLL0. The PLL0 output clock f_{PL0} is a multiple of f_x and serve as the main operation clocks for the microcontroller.

The diagram below shows the basic structure and signals of the PLL0 clock generator.




Figure 7-7 PLL0 clock generator

After power-up of the microcontroller the PLL0 are disabled.

Note All resets (SYSRES) stop the PLL0.

PLL0 enable/disable The PLL0 can be enabled and disabled and its status can be checked:

- enable trigger: PLLE0.PLLE0ENTRG = 1,
enabled status: PLLS0.PLLS0CLKEN = 1 = 1
- disable trigger: PLLE0.PLLE0DISTRG = 1
disabled status: PLLS0.PLLS0CLKEN = 1 = 0

PLL0 stabilization The PLL0 stabilization counter starts counting down the stabilization time.

As long as the PLL0 is not stable, the CLKSEL signal disables the f_{PL0} output to the PLL0 prescaler.

If the PLL0 stabilization counter has reached the value, defined by PLLST0.PLLST0[2:0], f_{PL0} is judged as stable and change of CLKSEL inputs f_x to the prescaler, thus all prescaler outputs are available for the clock selectors CKSC_mn.

The f_{PL0} clock stable status is indicated by the bit

PLLS0.PLLS0CLKSTABk = 1 and its activation by PLLS0.PLLS0CLKACT = 1.

The stabilization counter clock OSCSTCLK is selected from two sources:

- OSCSTCLK = 8 MHz High Speed IntOsc clock f_{RH} , if this oscillator is operating (ROSCS.ROSCSCLKEN = 1)
- OSCSTCLK = 240 kHz Low Speed IntOsc clock f_{RL} , if the High Speed IntOsc is disabled (ROSCS.ROSCSCLKEN = 0)

The stabilization counter clock source is selected automatically by the High Speed IntOsc operation status.

PLLST0.PLLST0k[2:0] determines the number of OSCSTCLK periods as the PLL0 stabilization time, which can be specified in the range of 2^7 to 2^{14} OSCSTCLK periods.

Note Make sure to use the f_{PLk0} clock only if PLLS0.PLLS0CLKACT = 1.

Stand-by mode requests By use of the STPREQ signal the Stand-by Controller indicates stand-by status of the Isolated-Area-0 and the Always-On-Area. The stop request mask bit PLLE0.PLLE0STPMK controls whether the PLL0 is stopped during stand-by or continues operation.
If the PLL0 is stopped during stand-by (PLLE0.PLLE0STPMK = 0), it is automatically re-started upon wake-up from stand-by mode, provided it was operating before stand-by mode entry.
If the PLL0 was stopped before stand-by mode, it remains stopped.

Clock Monitor control The PLL0 activity signal CLKACT is output to the Clock Monitor CLMA3 to control its operation. In case the PLL0 is inactive, supervision of its output clock f_{PL0} by CLMA3 is also deactivated.
The table below summarizes the different conditions for the Clock Monitor control.

Table 7-5 Clock Monitor 3 status control

PLL0 enable status	PLL0 stand-by control		PLL0 stand-by status	CLMA3 status
	PLLS0CLKEN	PLLE0STPMK		
0	X	X	0	stopped
1	0	0	1	active
		1	0	stopped
	1	X	1	active

PLL0 enable/disable trigger The PLL0 can be enabled and disabled by the enable and disable trigger control bits:

- enable trigger PLLE0.PLLE0ENTRG = 1 starts the PLL0
Note that setting the enable trigger is only effective if the PLL0 is inactive, i.e. if PLLS0.PLLS0CLKACT = 0.
- disable trigger PLLE0.PLLE0DISTRG = 1 stops the PLL0
Note that setting the disable trigger is only effective if the PLL0 is active, i.e. if PLLS0.PLLS0CLKACT = 1.

(1) PLL parameters

The PLL is configured by a set of parameters, derived from the control register PLLC0.




Figure 7-8 PLL0 circuit

f_{PL0} The frequency f_{PL0} is calculated as follows:

$$f_{PL0} = f_x \cdot \frac{Nr}{Pr}$$

The values Nr, Mr and Pr are derived from PLLC0 register bits:

- $Nr = PLLC0.PLLCON[4:0] + 1$
- Pr is determined by PLLC0.PLLCOP[1:0] according to the following table:

PLLC0.PLLCOP[1:0]	Pr	PLL output frequency f_{PL0} range
10 _B	2	40 MHz to 64 MHz
11 _B	4	20 MHz to 32 MHz
0x _B	setting prohibited	

7.4 Clock Selection

This section specifies all clock selection options for all clock domain on the three power areas of the V850E2/Fx4-G products.

The names of clock selector control and status registers are using two indices to identify the power domain and the clock domain:

(1) Clock selectors indices

m = 0: The clock selectors CKSC_0n control the CKSCLK_0n clocks of any clock domain within Isolated-Area-0.

m = A: The clock selectors CKSC_An controls the clock of any CKSCLK_An clocks domain within the Always-On-Area.

For each clock selector register a separate table is provided that informs about

- the power and the clock domain
- the clock selector register name, its address and initial value
- the domain clock name
- the clock selection options, their ID and - if applicable - clock limitations
- the availability of the clock stop mask bit CKSC_mn.STPMK_mn, that allows to determine the domain clock operation during STOP stand-by mode.

(2) Clock ID and default clock selection

Clock ID Each input clock to a clock selector CKSC_mn is identified by a unique ID. This ID has to be written to the clock selector register CKSC_mn to select the clock.

Note The ID must be written to the bits CKSC_mn.CKSCID_mn[30:0], which are located in the CKSC_mn register bits 31 to 1. Thus to select the ID clock

$$\text{CKSC_mn} = 2 \times \text{ID}$$

must be written.

For details refer to the description of the CKSC_mn register in the section “Clock Controller Registers” of this chapter.

Default clock In the clock selection tables of the following section the default clock selection is emphasized in bold.

(3) Clock STOP mode

In STOP stand-by mode the clock output of the clock selector may be optionally stopped by setting the clock selection register bit CKSC_mn.STPMK_mn = 0. If

- STPMK_mn: available

Clock CKSCLK_mn operation in STOP mode can be selected:

- if CKSC_mn.STPMK_mn = 0: CKSCLK_mn is stopped in STOP mode
- if CKSC_mn.STPMK_mn = 1: CKSCLK_mn continues in STOP mode

- STPMK_mn: not available, no STOP
CKSC_mn.STPMK_mn is not available (STPMK_mn is fixed to 0).
The clock CKSCLK_mn can not be stopped in STOP mode.
- STPMK_mn: not available, always STOP
CKSC_mn.STPMK_mn is not available (STPMK_mn is fixed to 0).
The clock CKSCLK_mn is always stopped in STOP mode.

(4) Clock switching

Caution When changing the clock selection for a clock domain from one clock to another, make sure that both clocks are operating.

Legal ID When changing the source of a domain clock CKSCLK_mn by writing to the respective clock selector register CKSC_mn proceed as follows:

1. Write the ID of the new clock source:
 - CKSC_mn.CKSCID_mn = new_ID
2. Wait the time, as specified below under the key word “*Clock switching timing*”, before checking the status of the clock selector ID change in the next step.
3. Check that the domain clock CKSCLK_nm has changed to the new clock source, indicated by
 - CSCSTAT_mn.CLKSELID_mn[30:0] = new_ID
 - CSCSTAT_mn.CLKACT_mn = 1 (new clock active)

Caution Make sure that no accesses (by the CPU, DMA, etc.) to modules, supplied by the domain clock to be changed, are performed before activation of the new_ID is confirmed by CSCSTAT_mn.CLKACT_mn = 1.

Illegal ID If an illegal clock source ID, i.e. an ID not permitted for a certain clock domain m_n, is written to CKSC_mn.CKSCID_mn, the clock selector behaves as follows:

- clock source ID 0000_H (no clock selected) is a *legal* selection
 - illegal clock ID is not accepted, instead clock ID 0000_H is selected, thus the domain clock CKSCLK_mn is stopped
 - clock selector control register shows the illegal_ID:
CKSC_mn.CKSCID = illegal_ID
 - clock selector status register shows ID 0000_H as inactive:
CSCSTAT_mn.CLKSELID_mn[30:0] = 0000_H
CSCSTAT_mn.CLKACT_mn = 0

- clock source ID 0000_H (no clock selected) is *not a legal* selection
 - illegal clock ID is not accepted and the old clock ID remains valid, thus the domain clock CKSCLK_mn does not change
 - clock selector control register shows the old ID:
CKSC_mn.CKSCID = old_ID
 - clock selector status register shows the old ID as active:
CSCSTAT_mn.CLKSELID_mn[30:0] = old_ID
CSCSTAT_mn.CLKACT_mn = 1

Clock switching timing The time between writing an ID to a clock selector control register CKSC_mn (for mn ≠ 000) until the status can be evaluated via the content of its status register CSCSTAT_mn is calculated as follows:

Conditions: new_ID ≠ 0000_H, old_ID ≠ 0000_H, new_ID ≠ old_ID

- if the High Speed IntOsc is active (ROSCS.ROSCSCLKEN = 1):
 $13 / f_{RH} + 3 / f_{old_ID} + 3 / f_{new_ID}$
- if the High Speed IntOsc is inactive (ROSCS.ROSCSCLKEN = 0):
 $13 / f_{RL} + 3 / f_{old_ID} + 3 / f_{new_ID}$

with

- f_{RH} = frequency of the High Speed IntOsc (nom. 8 MHz)
- f_{RL} = frequency of the Low Speed IntOsc (nom. 240 kHz)
- f_{old_ID} = frequency of the old_ID clock source
- f_{new_ID} = frequency of the new_ID clock source

ID = 0000_H

If the old_ID = 0000_H or new_ID = 0000_H, i.e. no clock selected, the respective summand ($3/f_{new_ID}$) or ($3/f_{new_ID}$), respectively, becomes 0 ($f \rightarrow \infty$ in above formulas).

new_ID = old_ID

If new_ID = old_ID the clock switching time becomes 0.

Clock switching time for CKSCLK_000 (CPUCLK) domain clock

If the CPU clock CPUCLK (domain clock CKSCLK_000) is changed, the CPU operation stalls during the change of the clock.

The CPU stall time can be calculated as follows:

Conditions: new_ID ≠ old_ID

- if the High Speed IntOsc is active (ROSCS.ROSCSCLKEN = 1):
 $4 / f_{RH} + 3 / f_{new_ID}$
- if the High Speed IntOsc is inactive (ROSCS.ROSCSCLKEN = 0):
 $4 / f_{RL} + 3 / f_{new_ID}$

7.4.1 Clock domains of Always-On-Area

(1) Clock domain AWO_2

Clock selector control register: CKSC_A02		Power domain: Always-On-Area		
Address: FF42 2020_H		Clock domain: AWO_2		
Initial value: 0000 000E_H		STPMK_A02: available		
Clock source ID	Clock source	Clock limitation	Domain clock	Module: clock
0001 _H	Low Speed IntOsc [240 kHz] / 1	≤ 48 MHz	CKSCLK_A02	WDTA0: PCLK CLMA0: PCLK CLMA2: PCLK KR0: PCLK AWO port control and filters: PCLK ^a
0007_H	High Speed IntOsc [8 MHz] / 1			
0008 _H	High Speed IntOsc [8 MHz] / 2			
0009 _H	High Speed IntOsc [8 MHz] / 4			
000A _H	High Speed IntOsc [8 MHz] / 8			
0014 _H	PLL0 / 1			
0015 _H	PLL0 / 2			
0017 _H	PLL0 / 4			
001A _H	PLL0 / 8			
0000 _H	No clock selected, domain clock is stopped			
others than above	Setting prohibited			

a) Domain clock CKSCLK_A02 supplies the port control and filter modules of the Always-On-Area, i.e. for port groups P0, JP0.

(2) Clock domain AWO_3

Clock selector control register: CKSC_A03		Power domain: Always-On-Area					
Address: FF42 2030_H		Clock domain: AWO_3					
Initial value: 0000 000E_H		STPMK_A03: available					
Clock source ID	Clock source	Clock limitation	Domain clock	Module: clock			
0001 _H	Low Speed IntOsc [240 kHz] / 1	≤ 48 MHz	CKSCLK_A03	TAUJ0: PCLK			
0007_H	High Speed IntOsc [8 MHz] / 1						
000C _H	MainOsc						
0014 _H	PLL0 / 1						
0015 _H	PLL0 / 2						
0017 _H	PLL0 / 4						
001A _H	PLL0 / 8						
0000 _H	No clock selected, domain clock is stopped						
others than above	Setting prohibited						

(3) Clock domain AWO_5

Clock selector control register: CKSC_A05		Power domain: Always-On-Area		
Address: FF42 2050_H		Clock domain: AWO_5		
Initial value: 0000 000E_H		STPMK_A05: available		
Clock source ID	Clock source	Clock limitation	Domain clock	Module: clock
0007 _H	High Speed IntOsc [8 MHz] / 1	≤ 40 MHz	CKSCLK_A05	BURAM: PCLK
0014 _H	PLL0 / 1			
0015 _H	PLL0 / 2			
0017 _H	PLL0 / 4			
001A _H	PLL0 / 8			
others than above	Setting prohibited			

(4) Clock domain AWO_7

Clock selector control register: CKSC_A07		Power domain: Always-On-Area		
Address: FF42 2070_H		Clock domain: AWO_7		
Initial value: 0000 0006_H		STPMK_A07: available		
Clock source ID	Clock source	Clock limitation	Domain clock	Module: clock
0001 _H	Low Speed IntOsc [240 kHz] / 1	–	CKSCLK_A07	WDTA0: WDTACKI
0003 _H	Low Speed IntOsc [240 kHz] / 4			
0005 _H	Low Speed IntOsc [240 kHz] / 512			
others than above	Setting prohibited			

7.4.2 Clock domains of Isolated-Area-0

(1) Clock domain ISO0_0

Clock selector control register: CKSC_000		Power domain: Isolated-Area-0		
Address: FF42 6000 _H		Clock domain: ISO0_0		
Initial value: 0000 0074 _H		STPMK_000: not available, always STOP		
Clock source ID	Clock source	Clock limitation	Domain clock	Module: clock
0008 _H	High Speed IntOsc [8 MHz] / 2	–	CKSCLK_000	CPU Subsystem: CPUCLK
0009 _H	High Speed IntOsc [8 MHz] / 4			
000A _H	High Speed IntOsc [8 MHz] / 8			
000B _H	High Speed IntOsc [8 MHz] / 32			
000C _H	MainOsc			
0014 _H	PLL0 / 1			
0015 _H	PLL0 / 2			
0017 _H	PLL0 / 4			
001A _H	PLL0 / 8			
003A _H	High Speed IntOsc [8 MHz] (Low Speed IntOsc [240 kHz]) ^a			
others than above	Setting prohibited			

a) If the High Speed IntOsc is disabled, the Low Speed IntOsc is automatically selected.

(2) Clock domain ISO0_1

Clock selector control register: –		Power domain: Isolated-Area-0		
Address: –		Clock domain: ISO0_1		
Initial value: –		STPMK_001: –		
Clock source ID	Clock source	Clock limitation	Domain clock	Module: clock
–	CKSCLK_000: CPU system clock CPUCLK / 2	–	CKSCLK_001	WDTA1: PCLK CLMA3: PCLK Iso0 port control and filters: PCLK ^a

a) Domain clock CKSCLK_001 supplies the port control and filter modules of the Isolated-Area-0, i.e. for port groups P1, P3, P4, P10, P27.

CKSCLK_001 has no clock selector, but is supplied by the half of the CPU system clock CPUCLK (CPUCLK / 2 = CKSCLK_000 / 2).

(3) Clock domain ISO0_6

Clock selector control register: CKSC_006		Power domain: Isolated-Area-0		
Address: FF42 6060_H		Clock domain: ISO0_6		
Initial value: 0000 000E_H		STPMK_006: available		
Clock source ID	Clock source	Clock limitation	Domain clock	Module: clock
0007 _H	High Speed IntOsc [8 MHz] / 1	≤ 48 MHz	CKSCLK_006	TAUB0: PCLK
000C _H	MainOsc			
0014 _H	PLL0 / 1			
0015 _H	PLL0 / 2			
0017 _H	PLL0 / 4			
001A _H	PLL0 / 8			
0000 _H	No clock selected, domain clock is stopped			
others than above	Setting prohibited			

(4) Clock domain ISO0_7

Clock selector control register: CKSC_007		Power domain: Isolated-Area-0		
Address: FF42 6070_H		Clock domain: ISO0_7		
Initial value: 0000 0006_H		STPMK_007: not available, no STOP		
Clock source ID	Clock source	Clock limitation	Domain clock	Module: clock
0001 _H	Low Speed IntOsc [240 kHz] / 1	–	CKSCLK_007	WDTA1: WDTATCKI
0003 _H	Low Speed IntOsc [240 kHz] / 4			
others than above	Setting prohibited			

(5) Clock domain ISO0_11

Clock selector control register: CKSC_011		Power domain: Isolated-Area-0		
Address: FF42 60B0_H		Clock domain: ISO0_11		
Initial value: 0000 000E_H		STPMK_011: available		
Clock source ID	Clock source	Clock limitation	Domain clock	Module: clock
0007 _H	High Speed IntOsc [8 MHz] / 1	≤ 48 MHz	CKSCLK_011	URTE10: PCLK LMA10: PCLK URTE11: PCLK LMA11: PCLK CNTA2: PCLK CSIG4: PCLK
000C _H	MainOsc			
0014 _H	PLL0 / 1			
0015 _H	PLL0 / 2			
0017 _H	PLL0 / 4			
001A _H	PLL0 / 8			
0000 _H	No clock selected, domain clock is stopped			
others than above	Setting prohibited			

(6) Clock domain ISO0_12

Clock selector control register: CKSC_012		Power domain: Isolated-Area-0		
Address: FF42 60C0_H		Clock domain: ISO0_12		
Initial value: 0000 000E_H		STPMK_012: available		
Clock source ID	Clock source	Clock limitation	Domain clock	Module: clock
0007 _H	High Speed IntOsc [8 MHz] / 1	≤ 48 MHz	CKSCLK_012	ADAA0: PCLK
000C _H	MainOsc			
0014 _H	PLL0 / 1			
0015 _H	PLL0 / 2			
0017 _H	PLL0 / 4			
001A _H	PLL0 / 8			
0000 _H	No clock selected, domain clock is stopped			
others than above	Setting prohibited			

(7) Clock domain ISO0_16

Clock selector control register: CKSC_016		Power domain: Isolated-Area-0		
Address: FF42 6100_H		Clock domain: ISO0_16		
Initial value: 0000 000E_H		STPMK_016: not available, no STOP		
Clock source ID	Clock source	Clock limitation	Domain clock	Module: clock
0007_H	High Speed IntOsc [8 MHz] / 1	≤ 48 MHz	CKSCLK_016	Iso0 Port filters: DNFATCKI
0014 _H	PLL0 / 1			
0015 _H	PLL0 / 2			
0017 _H	PLL0 / 4			
001A _H	PLL0 / 8			
others than above	Setting prohibited			

(8) Clock domain ISO0_28

Clock selector control register: CKSC_028		Power domain: Isolated-Area-0		
Address: FF42 A080_H		Clock domain: ISO0_28		
Initial value: 0000 000E_H		STPMK_028: available		
Clock source ID	Clock source	Clock limitation	Domain clock	Module: clock
0007_H	High Speed IntOsc [8 MHz] / 1	≤ 48 MHz	CKSCLK_028	CSIG0: PCLK IICB0: PCLK
000C _H	MainOsc			
0014 _H	PLL0 / 1			
0015 _H	PLL0 / 2			
0017 _H	PLL0 / 4			
001A _H	PLL0 / 8			
others than above	Setting prohibited			

(9) Clock domain ISO0_29

Clock selector control register: CKSC_029		Power domain: Isolated-Area-0		
Address: FF42 A090 _H		Clock domain: ISO0_29		
Initial value: 0000 000E _H		STPMK_029: available		
Clock source ID	Clock source	Clock limitation	Domain clock	Module: clock
0007 _H	High Speed IntOsc [8 MHz] / 1	≤ 48 MHz	CKS CLK_029	CSIG7: PCLK
000C _H	MainOsc			
0014 _H	PLL0 / 1			
0015 _H	PLL0 / 2			
0017 _H	PLL0 / 4			
001A _H	PLL0 / 8			
others than above	Setting prohibited			

(10) Clock domain ISO0_32

Clock selector control register: CKSC_032		Power domain: Isolated-Area-0		
Address: FF42 A0C0 _H		Clock domain: ISO0_32		
Initial value: 0000 000E _H		STPMK_032: available		
Clock source ID	Clock source	Clock limitation	Domain clock	Module: clock
0007 _H	High Speed IntOsc [8 MHz] / 1	≤ 48 MHz	CKSCLK_032	OSTM0: PCLK
000C _H	MainOsc			
0014 _H	PLL0 / 1			
0015 _H	PLL0 / 2			
0017 _H	PLL0 / 4			
001A _H	PLL0 / 8			
others than above	Setting prohibited			

(11) Clock domain ISO0_33

Clock selector control register: CKSC_033		Power domain: Isolated-Area-0		
Address: FF42 A0D0_H		Clock domain: ISO0_33		
Initial value: 0000 000E_H		STPMK_033: available		
Clock source ID	Clock source	Clock limitation	Domain clock	Module: clock
0007 _H	High Speed IntOsc [8 MHz] / 1	≤ 48 MHz	CKSCLK_033	FCN0: PCLK FCN1 : PCLK FCN2 : PCLK FCN3 : PCLK FCN4 : PCLK FCN5 : PCLK
000C _H	MainOsc			
0014 _H	PLL0 / 1			
0015 _H	PLL0 / 2			
0017 _H	PLL0 / 4			
001A _H	PLL0 / 8			
others than above	Setting prohibited			

(12) Clock domain ISO0_34

Clock selector control register: CKSC_034		Power domain: Isolated-Area-0		
Address: FF42 A0E0_H		Clock domain: ISO0_34		
Initial value: 0000 000E_H		STPMK_034: available		
Clock source ID	Clock source	Clock limitation	Domain clock	Module: clock
0007 _H	High Speed IntOsc [8 MHz] / 1	≤ 48 MHz	CKSCLK_034	URTE2: PCLK LMA2: PCLK CNTA1: PCLK
000C _H	MainOsc			
0014 _H	PLL0 / 1			
0015 _H	PLL0 / 2			
0017 _H	PLL0 / 4			
001A _H	PLL0 / 8			
others than above	Setting prohibited			

7.5 Clock Domain Figures

The following figures show the PBUS structures with regards to the PBUS modules in the different clock domains.

Note CPU (domain clock CKSCLK_000) accesses to modules, located in a different clock domain are passed through bus synchronizers, as shown in the following figures.

These synchronizers induce an access latency of several clock cycles.

Refer to the section “*CPU Access Bus Structures and Latencies*” in the chapter “*CPU System Function*” for details.

(1) Clock domains AWO_2, AWO_3, AWO_5




Figure 7-9 Clock domains AWO_2, AWO_3, AWO_5

(2) Clock domains AWO_7




Figure 7-10 Clock domains AWO_7

(3) Clock domains ISO0_1, ISO0_6, ISO0_11, ISO0_12




Figure 7-11 Clock domains ISO0_1, ISO0_6, ISO0_11, ISO0_12

(4) Clock domains ISO0_7, ISO0_16




Figure 7-12 Clock domains ISO0_7, ISO0_16

(5) Clock domains ISO0_28, ISO0_29, ISO0_32 to ISO0_34




Figure 7-13 Clock domains ISO0_28, ISO0_29, ISO0_32 to ISO0_34

7.6 Clock Monitor A (CLMA)

This section contains a generic description of the Clock Monitor A (CLMA).

The first section describes all properties specific to the V850E2/Fx4-G, such as instances, register base addresses, input/output signal names, etc.

The subsequent sections describe the features that apply to all implementations.

7.6.1 V850E2/Fx4-G CLMA features

Instances This microcontroller has the following number of instances of the Clock Monitor A.

Table 7-6 Instances of CLMA

Clock Monitor A	
Instances	3
Names	CLMA0, CLMA2, CLMA3

Instances index n Throughout this chapter, the individual instances of a Clock Monitor A are identified by the index “n” (n = 0, 2, 3), for example, CLMA_nCTL0 for the control register 0 of CLMA_n.

Register addresses All CLMA_n register addresses are given as address offsets from the individual base address <CLMA_n_base>. The base address <CLMA_n_base> of each CLMA_n is listed in the following table:

Table 7-7 Register base addresses <CLMA_n_base>

CLMA _n instance	<CLMA _n _base> address
CLMA0	FF80 2000 _H
CLMA2	FF80 4000 _H
CLMA3	FF80 5000 _H

Clock supply The monitored and the sampling clocks of all Clock Monitors A are listed in the following table:

Table 7-8 CLMA_n clock supply

CLMA _n clock	CLMA _n clock	Connected to
CLMA0:		
CLMAT _{SMP}	CLMA0 sampling clock	Low Speed IntOsc f_{RL}
CLMAT _{MON}	CLMA0 monitored clock	MainOsc f_X
PCLK	PBUS clock	CKSCLK_A02
CLMA2:		
CLMAT _{SMP}	CLMA2 sampling clock	Low Speed IntOsc f_{RL}
CLMAT _{MON}	CLMA2 monitored clock	High speed IntOsc f_{RH}
PCLK	PBUS clock	CKSCLK_A02
CLMA3:		
CLMAT _{SMP}	CLMA3 sampling clock	High Speed IntOsc f_{RH}
CLMAT _{MON}	CLMA3 monitored clock	PLL0 f_{PL0}
PCLK	PBUS clock	CKSCLK_001




Figure 7-14 CLMA clock supply

Interrupts and reset outputs The interrupts and reset outputs of the CLMA_n are listed in the table below.

Table 7-9 CLMA interrupts and reset outputs

CLMA _n signals	Function	Connected to
CLMA0:		
$\overline{\text{CLMARES}}$	CLMA0 error reset	Reset Controller $\overline{\text{CLMA0RES}}$
CLMATI	CLMA0 error interrupt request	Interrupt Controller INTCLMA0
CLMA2:		
$\overline{\text{CLMARES}}$	CLMA2 error reset	Reset Controller $\overline{\text{CLMA2RES}}$
CLMATI	CLMA2 error interrupt request	not connected
CLMA3:		
$\overline{\text{CLMARES}}$	CLMA3 error reset	Reset Controller $\overline{\text{CLMA3RES}}$
CLMATI	CLMA3 error interrupt request	not connected

CLMA H/W reset The Clock Monitors A and their registers are initialized by the following reset signal:

Table 7-10 CLMA_n reset signal

CLMA _n instance	Reset signal
CLMA0, CLMA2	<ul style="list-style-type: none"> Reset Controller SYSRES
CLMA3	<ul style="list-style-type: none"> Reset Controller SYSRES Stand-by Controller DPSTPWU (wake-up from DEEPSTOP mode)

7.6.2 CLMA enable and start-up options

(1) CLMA enable and suspend/resume

Enable A Clock Monitor's operation must be generally enabled by $CLMA_{n}CTL0.CLMA_{n}CLME = 1$.
General enable after reset is also controlled by the start-up option $CLMATC0INI$, refer to the section "*CLMA start-up options*" below.

Suspend/resume If generally enabled, a Clock Monitor automatically

- suspends clock supervision, if the clock to be monitored is inactive
- resumes clock supervision, if the clock to be monitored is active.

For that purpose the clock generator, whose output is to be supervised, indicates its active - and stable - status by an active signal, that suspends respectively resumes the associated Clock Monitor's operation via the Clock Monitor's enable signal $CLMATEN$.

In case the monitored clock is stopped in STOP stand-by mode, the respective Clock Monitor suspends its operation and resumes it if the monitored clock is active and stable again.

Table 7-11 Clock Monitors start/stop signals

CLMA _n instance	CLMA _n enable signal	Clock generator active signal	Comment
CLMA0	CLMATEN	MainOsc MOSCSCLKACT	CLMA0 operation suspends/resumes, if MainOsc clock f_X is inactive/active.
CLMA2	CLMATEN	High Speed IntOsc ROSCSCLKACT	CLMA2 operation suspends/resumes, if High Speed IntOsc clock f_{RH} is inactive/active.
CLMA3	CLMATEN	PLL0 PLL0CLKACT	CLMA3 operation suspends/resumes, if PLL0 clock f_{PL0} is inactive/active.

(2) CLMA start-up options

The start-up options determine the start-up configuration of the CLMA after reset release. A description of the start-up options is given in the following table.

Table 7-12 CLMA start-up options

Start-up option	Function	Description	Connected to
CLMATC0INI	Defines whether CLMA _n is automatically enabled or stays disabled after a reset	Specifies the initial value of CLMA _n CTL0.CLMA _n CLME: 0: CLMA is disabled 1: CLMA is enabled	0
CLMATC1INI	Specifies the error indication method	Specifies the initial value of CLMA _n CTL1.CLMA _n OSEL: 0: Reset request $\overline{\text{CLMATRES}}$ on error 1: Interrupt request CLMATI on error	0
CLMATCSEL	Defines whether the default lower and upper thresholds are supplied by CLMATCLINI[11:0]/CLMATCHINI[11:0]	Specifies how the threshold registers CLMA _n CMPL/CLMA _n CMPH are set after reset release: 0: set to default reset values 1: set by CLMATCLINI[11:0] and CLMATCHINI[11:0]	0
CLMATCHINI [11:0]	Sets the initial value of the threshold register CLMA _n CMPH	Only effective if CLMATCSEL = 1	000 _H
CLMATCLINI [11:0]	Sets the initial value of the threshold register CLMA _n CMPL	Only effective if CLMATCSEL = 1	000 _H

7.6.3 Functional Overview

The Clock Monitor CLMAn indicates an abnormal frequency of the monitored clock.

Features summary It has the following features:

- continuous monitoring of the frequency of an input clock CLMATMON by using a sampling clock CLMATSMMP
- indication of abnormal clock frequencies by the following means:
 - output of a reset signal, or
 - generation of an interrupt
- configuration after reset is based on start-up options

Note Once enabled, the CLMAn can neither be configured nor stopped by software. Only a reset can stop the CLMAn.

The following figure shows the main components of the Clock Monitor.




Figure 7-15 Block diagram of the Clock Monitor A

7.6.4 Functional Description

The Clock Monitor CLMAn is used to ensure that the frequency of a clock (CLMATMON) stays between certain limits.

(1) Detection of abnormal clock frequencies

- Method**
- CLMAn counts the rising edges of the monitored clock CLMATMON within 16 cycles of the sampling clock CLMATSMP and then compares the counter with the configured thresholds:
 - CLMAnCMPL.CLMAnCMPL[11:0] defines the lower threshold.
 - CLMAnCMPH.CLMAnCMPH[11:0] defines the upper threshold.
 - When CLMATMON stops or its frequency is too low, the counter falls below CLMAnCMPL.CLMAnCMPL[11:0].
 - When the frequency of CLMATMON is too high, the counter exceeds CLMAnCMPH.CLMAnCMPH[11:0].

In both cases, CLMAn indicates an abnormal clock frequency as described in 2 “Indication of abnormal clock frequency” on page 297 .




Figure 7-16 Example: f_{CLMATMON} is too low




Figure 7-17 Example: f_{CLMATMON} is too high

Note When f_{CLMATMON} changes within the sampling interval, the counter might be within the valid range although f_{CLMATMON} became too high/low.

The abnormal f_{CLMATMON} is detected one sampling interval later.

(a) Calculation of thresholds CLMAnCMPL.CLMAnCMPL[11:0] and CLMAnCMPH.CLMAnCMPH[11:0]

The compare registers CLMAnCMPL and CLMAnCMPH are configured with the minimum and maximum number of clock cycles of CLMATMON that are assumed to be valid within 16 cycles of the sampling clock CLMATSMP. The expected number of clock cycles is denoted by N.

$$\frac{16}{f_{\text{CLMATSMP}}} = \frac{N}{f_{\text{CLMATMON}}}$$

$$N = \frac{f_{\text{CLMATMON}}}{f_{\text{CLMATSMP}}} \times 16$$

Considering the allowed frequency deviations of CLMATMON and CLMATSMP, the threshold values can be calculated by the following formulas:

$$\begin{aligned} \text{Lower threshold} &= N_{\min} \\ &= \text{round down} \left(\frac{f_{\text{CLMATMON}(\min)}}{f_{\text{CLMATSMP}(\max)}} \times 16 - 1 \right) \end{aligned}$$

$$\begin{aligned} \text{Upper threshold} &= N_{\max} \\ &= \text{round up} \left(\frac{f_{\text{CLMATMON}(\max)}}{f_{\text{CLMATSMP}(\min)}} \times 16 + 1 \right) \end{aligned}$$

Example For $f_{\text{CLMATSMP}} = 240 \text{ kHz} (\pm 8\%)$ and $f_{\text{CLMATMON}} = 16 \text{ MHz} (\pm 5\%)$ the recommended threshold values are the following:

$$\begin{aligned} N_{\min} &= [(15.2 \text{ MHz} / 259.2 \text{ kHz}) \times 16] - 1 \\ &= 937.27 \\ \text{CLMAnCMPL} &= 937 = 03A9_{\text{H}} \end{aligned}$$

$$\begin{aligned} N_{\max} &= [(16.8 \text{ MHz} / 220.8 \text{ kHz}) \times 16] + 1 \\ &= 1218.38 \\ \text{CLMAnCMPH} &= 1219 = 04C3_{\text{H}} \end{aligned}$$

Minimum thresholds

The following restrictions must be taken into account:

- $\text{CLMAnCMPL} \geq 0001_{\text{H}}$
- $\text{CLMAnCMPH} \geq \text{CLMAnCMPL} + 0003_{\text{H}}$

(b) Definition of the initial value input of the threshold registers

CLMATCSEL = 1 When CLMATCSEL is active, the initial values of the threshold registers are set by the following input signals:

- CLMAnCMPL[11:0] is set by CLMATCLINI[11:0].
- CLMAnCMPH[11:0] is set by CLMATCHINI[11:0].

CLMATCSEL = 0 If CLMATCSEL is inactive, the initial values of the threshold registers are set in such a way, that the maximum frequency deviation of the monitored clock is allowed:

- CLMAnCMPL[11:0] = 0001_H
- CLMAnCMPH[11:0] = 03FF_H

Note Refer to the above section “CLMA enable and start-up options” about the setting of the CLMATCSEL signal.

(2) Indication of abnormal clock frequency

In case an abnormal frequency is detected, following indications are generated:

Table 7-13 Abnormal frequency indications

CLMAnCTL1. CLMAnOSEL	Monitored clock frequency f_{CLMATMON} is	
	too low	too high
1	Interrupt: assertion of CLMATI	Reset: assertion of $\overline{\text{CLMATRES}}$
0	Reset: assertion of $\overline{\text{CLMATRES}}$	

Note that if a too high frequency is detected the reset CLMATRES is always generated, while in case of too low frequency detection the control bit CLMAnCTL1.CLMAnOSEL determines the generated indicator.

Note The initial value of CLMAnCTL1.CLMAnOSEL is defined by the input signal CLMATC1INI. Refer to the section “CLMA enable and start-up options” above.

(3) Enabling and disabling CLMA

Enabling CLMA CLMA is enabled by CLMAnCTL0.CLMAnCLME = 1.

The initial value of CLMAnCTL0 is defined by the input signal CLMATC0INI, refer to the section “CLMA enable and start-up options” above. This allows to define whether CLMA is automatically enabled after a reset or stays disabled.

Table 7-14 Initial value of CLMAnCTL0

CLMATC0INI	Initial value of CLMAnCTL0	Function
Low	00 _H	Disable CLMA
High	01 _H	Enable CLMA

Refer to the section “CLMA enable and start-up options” above for information about CLMATC0INI.

Disabling CLMA_n CLMA_n can only be disabled by a reset, not by writing to CLMA_nCTL0.

Note Once enabled, the CLMA_n can neither be configured nor stopped by software, except by a reset.

(4) Suspend/resume control

The operation is suspended respectively resumed under control of the CLMATEN signal.

Refer to the section “*CLMA enable and start-up options*” above.

7.6.5 Clock Monitor registers

This section contains a description of all registers of the Clock Monitor.

(1) Writing to protected registers

Write protected registers are protected from inadvertent write access due to erroneous program execution, etc.

Following Clock Monitor registers feature this special write protection:

- CLMAn control register 0 CLMAnCTL0

Refer to the section “*Write protected Registers*” in the chapter “*CPU System Functions*” for a detailed description how to write to write protected registers.

(2) Clock Monitor registers overview

The Clock Monitor is controlled and operated by the following registers.

Table 7-15 Clock Monitor registers overview

Register name	Shortcut	Address
CLMAn control register 0	CLMAnCTL0	<CLMAn_base> + 00 _H
CLMAn control register 1	CLMAnCTL1	<CLMAn_base> + 04 _H
CLMAn comparison register L	CLMAnCMPL	<CLMAn_base> + 08 _H
CLMAn comparison register H	CLMAnCMPH	<CLMAn_base> + 0C _H
CLMAn emulation register 0	CLMAnEMU0	<CLMAn_base> + 18 _H

<CLMAn_base> The base addresses <CLMAn_base> of the CLMAn are defined in the first part of section “*Clock Monitor A (CLMA)*” in this chapter under the key word “*Register addresses*”.

(3) CLMAnCTL0 – CLMAn control register 0

This register is used to enable the clock monitor CLMAn.

Protection Writing to this register is protected by a special sequence of instructions by using the protection command register CLMAnPCMD. Refer to the section “*Write protected Registers*” in the chapter “*CPU System Functions*” for a detailed description how to write to write protected registers.

Access This register can be read/written in 8-bit units.

Address <CLMAn_base> + 00_H

Initial Value Depends on start-up option CLMATC0INI. Refer to the section “*CLMA enable and start-up options*” above.

7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	CLMAn CLME
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 7-16 CLMAnCTL0 register contents

Bit position	Bit name	Function
0	CLMAnCLME	Enables/disables the clock monitor: 0: Disable CLMAn 1: Enable CLMAn This bit can only be cleared by a reset if not automatically enabled by CLMATC0INI.

(4) CLMAnCTL1 – CLMAn control register 1

This register specifies the abnormal frequency detection indicator generation output when the frequency of the monitored clock CLMATMON is too low.

Access This register can be read/written in 8-bit units.
It can only be written when CLMAn is disabled
(CLMAnCTL0.CLMAnCLME = 0).

Address <CLMAn_base> + 04_H

Initial Value Depends on start-up option CLMATC1INI. Refer to the section “CLMA enable and start-up options” above.

7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	CLMAn OSEL
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 7-17 CLMAnCTL1 register contents

Bit position	Bit name	Function
0	CLMAnOSEL	Specifies the indicator signals that are generated when the frequency of CLMATMON is too low: 0: reset CLMATRES 1: interrupt CLMATI

(5) CLMAnCMPL – CLMAn comparison register L

This register specifies the *lower* frequency limit.

Refer to a “Calculation of thresholds CLMAnCMPL.CLMAnCMPL[11:0] and CLMAnCMPH.CLMAnCMPH[11:0]” on page 296 for details.

Access This register can be read/written in 16-bit units. It can only be written, when CLMA is disabled (CLMAnCTL0.CLMAnCLME = 0).

Address <CLMAn_base> + 08_H

Initial Value 0001_H
When CLMATCSEL is active, the initial value is set by the input signals CLMATCLINI[11:0]. Refer to the section “CLMA enable and start-up options” above.

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	CLMAnCMPL[11:0]											
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 7-18 CLMAnCMPL register contents

Bit position	Bit name	Function
11 to 0	CLMAnCMPL[11:0]	Specifies the lower threshold <ul style="list-style-type: none"> The recommended value is round down$[(f_{\text{CLMATMON}(\text{min})} / f_{\text{CLMATSMPL}(\text{max})}) \times 16 - 1]$ The minimum value is 0001_H.

(6) CLMAnCMPH – CLMAn comparison register H

This register specifies the *upper* frequency limit.

Refer to a “Calculation of thresholds CLMAnCMPL.CLMAnCMPL[11:0] and CLMAnCMPH.CLMAnCMPH[11:0]” on page 296 for details.

Access This register can be read/written in 16-bit units. It can only be written, when CLMA is disabled (CLMAnCTL0.CLMAnCLME = 0).

Address <CLMAn_base> + 0C_H

Initial Value 03FF_H

When CLMATCSEL is active, the initial value is set by the input signals CLMATCHINI[11:0]. Refer to the section “CLMA enable and start-up options” above.

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	CLMAnCMPH[11:0]											
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 7-19 CLMAnCMPH register contents

Bit position	Bit name	Function
11 to 0	CLMAnCMPH[11:0]	Specifies the upper threshold <ul style="list-style-type: none"> The recommended value is round up$[(f_{\text{CLMATMON(max)}}/f_{\text{CLMATSMPL(min)}}) \times 16 + 1]$ The minimum value is CLMAnCMPL + 0003_H.

(7) CLMAnEMU0 – CLMAn emulation register 0

This register provides bits to emulate a frequency deviation error while the microcontroller is set in break mode during debugging.

Access This register can be read/written in 8-bit units.

Address <CLMAn_base> + 18_H

Initial Value 00_H

7	6	5	4	3	2	1	0
0	0	0	0	0	0	CLMAn SLFST	CLMAn SLSLW
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 7-20 CLMAnEMU0 register contents

Bit position	Bit name	Function
0	CLMAnSLSLW	Specifies whether f_{CLMATMON} is assumed to be too low during emulation: 0: CLMATMON is within the normal frequency range 1: CLMATMON is too slow
1	CLMAnSLFST	Specifies whether f_{CLMATMON} is assumed to be too high during emulation: 0: CLMATMON is within the normal frequency range 1: CLMATMON is too fast

Caution It is prohibited to emulate a too low and too high CLMATMON at the same time. Thus CLMAnEMU0 must not be set to 03_H.

7.7 Clock Controller Registers

This section contains a description of all registers of the Clock Controller.

7.7.1 Writing to protected registers

Write protected registers are protected from inadvertent write access due to erroneous program execution, etc.

Following Clock Controller registers feature this special write protection:

- MainOsc enable register MOSCE
- High Speed IntOsc enable register ROSCE
- PLL0 enable registers PLLE0
- Clock selector control registers CKSC_mn

Refer to the section “*Write protected Registers*” in the chapter “*CPU System Functions*” for a detailed description how to write to write protected registers.

7.7.2 Clock Controller registers overview

The Clock Controller is controlled and operated by the following registers:

Table 7-21 Clock Controller registers overview (1/2)

Register name	Shortcut	Address
Clock generators registers:		
MainOsc enable register	MOSCE	FF42 1010 _H
MainOsc status register	MOSCS	FF42 1014 _H
MainOsc control register	MOSCC	FF42 1018 _H
MainOsc stabilization time register	MOSCST	FF42 101C _H
High Speed IntOsc enable register	ROSCE	FF42 1000 _H
High Speed IntOsc status register	ROSCS	FF42 1004 _H
PLL0 enable register	PLLE0	FF42 5000 _H
PLL0 status register	PLLS0	FF42 5004 _H
PLL0 control register	PLLC0	FF42 5008 _H
PLL0 stabilization time register	PLLST0	FF42 500C _H
Always-On-Area clock selector registers:		
Clock selector control registers for Always_On_Area	CKSC_An	FF42 2000 _H + n x 16
Clock selector status registers for Always_On_Area	CSCSTAT_An	FF42 2004 _H + n x 16

Table 7-21 Clock Controller registers overview (2/2)

Register name	Shortcut	Address
Isolated-Area-0 clock selector registers:		
Clock selector control registers for Isolated-Area-0	CKSC_0n	FF42 6000 _H + n x 16
	CKSC_1n	FF42 A000 _H + n x 16
Clock selector status registers for Isolated-Area-0	CSCSTAT_0n	FF42 6004 _H + n x 16
	CSCSTAT_1n	FF42 A004 _H + n x 16

7.7.3 Clock generators registers

(1) MOSCE - MainOsc enable register

This register is used to start and stop the MainOsc and to specify its operation during stand-by modes.

Protection Writing to this register is protected by a special sequence of instructions by using the protection command register PROTCMD2. Refer to the section “Write protected Registers” in the chapter “CPU System Functions” for a detailed description how to write protected registers.

Access This register can be read/written in 32-bit units.

Address FF42 1010_H

Initial Value 0000 0004_H. This register is initialized by the power-up reset PURES (Power-On-Clear or debugger reset).

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	0	0	0	0	0	MOSCE STP MK	MOSCE DIS TRG	MOSCE EN TRG
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 7-22 MOSCE register contents

Bit position	Bit name	Function
2	MOSCE STPMK	MainOsc stop request mask 0: stop request not masked 1: stop request masked If the MainOsc stop request is masked (MOSCESTPMK = 1) a stop request does not change the status of the MainOSC. If MOSCESTPMK = 0, the MainOsc is stopped in stand-by mode. Upon wake-up from stand-by mode, the MainOsc returns to its status as before stand-by mode, i.e. continues operation when it was operating or remains stopped, when it was stopped before. Note: The MainOsc can also be activated after stand-by wake-up, independent of its status before stand-by mode. This features is controlled by the oscillator wake-up mask register OSCWUFMSK. Refer to section “Wake-up” in the chapter “Stand-by Controller (STBC)” for details.
1	MOSCE DISTRG	MainOsc disable trigger 0: no function 1: stops MainOsc Stopping the MainOsc by MOSCEDISTRG = 1 is only possible, if the MainOsc is active, i.e. MOSCS.MOSCSCLKACT = 1. Reading of this bit returns always 0.
0	MOSCE ENTRG	MainOsc enable trigger 0: no function 1: starts MainOsc Starting the MainOsc by MOSCEENTRG = 1 is only possible, if the MainOsc is inactive, i.e. MOSCS.MOSCSCLKACT = 0. Reading of this bit returns always 0.

(2) MOSCS - MainOsc status register

This register provides various status information about the MainOsc status.

Access This register can be read in 32-bit units.

Address FF42 1014_H

Initial Value 0000 0000_H. This register is initialized by the power-up reset PURES (Power-On-Clear or debugger reset).

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	0	0	0	0	0	MOSCS CLK EN	MOSCS CLK ACT	MOSCS CLK STAB
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Table 7-23 MOSCS register contents

Bit position	Bit name	Function
2	MOSCS CLKEN	MainOsc enable status 0: MainOsc is disabled 1: MainOsc is enabled
1	MOSCS CLKACT	MainOsc activation status 0: MainOsc is inactive 1: MainOsc is active
0	MOSCS CLKSTAB	MainOsc stabilization status 0: MainOsc is unstable 1: MainOsc is stable

(3) MOSCC - MainOsc control register

This register is used to specify several options of the MainOsc start-up behaviour.

This register can only be written, if the MainOsc is disabled (MOSCS.MOSCSCLKEN = 0).

Access This register can be read/written in 32-bit units.

Address FF42 1018_H

Initial Value 0000 0000_H. This register is initialized by the power-up reset PURES (Power-On-Clear or debugger reset).

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	0	0	0	0	0	MOSCC SHT STBY	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 7-24 MOSCC register contents

Bit position	Bit name	Function
2	MOSCC SHTSTBY	Short stabilization time mode 0: normal stabilization time mode: normal amplification gain 1: short stabilization time mode: MainOsc amplification gain is maximum Note: MOSCCSHTSTBY = 1 is only effective during the MainOsc stabilization time. After the MainOsc has become active (MOSCS.MOSCSCLKACT = 1), normal amplification gain is used.

Caution During assertion of the external $\overline{\text{RESET}}$ the MainOsc is always operating with its maximum amplification gain.
Refer to the description of the external $\overline{\text{RESET}}$ in the “Reset Controller” chapter for details.

(4) MOSCST - MainOsc stabilization time register

This register determines the MainOsc stabilization time.

This register can only be written, if the MainOsc is disabled (MOSCS.MOSCCLKEN = 0).

Access This register can be read/written in 32-bit units.

Address FF42 101C_H

Initial Value 0000 0000_H. This register is initialized by the power-up reset PURES (Power-On-Clear or debugger reset).

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	0	0	0	0	MOST[3:0]			
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 7-25 MOSCST register contents

Bit position	Bit name	Function																																																					
3 to 0	MOST[3:0]	<p>MainOsc stabilization time setting Per default the MainOsc stabilization counter is operating with the High Speed IntOsc. If the High Speed IntOsc is disabled (ROSCS.ROSCSCLKEN = 0), the stabilization counter clock is automatically changed to the Low Speed IntOsc.</p> <table border="1"> <thead> <tr> <th rowspan="2">MOST[3:0]</th> <th colspan="2">MainOsc stabilization time</th> </tr> <tr> <th>High Speed IntOsc enabled (ROSCS.ROSCSCLKEN = 1)</th> <th>High Speed IntOsc disabled (ROSCS.ROSCSCLKEN = 0)</th> </tr> </thead> <tbody> <tr><td>0000_B</td><td>$2^2 / 8 \text{ MHz} = 0.5 \mu\text{s}$</td><td>$2^2 / 240 \text{ kHz} = 17.7 \mu\text{s}$</td></tr> <tr><td>0001_B</td><td>$2^3 / 8 \text{ MHz} = 1 \mu\text{s}$</td><td>$2^3 / 240 \text{ kHz} = 33.3 \mu\text{s}$</td></tr> <tr><td>0010_B</td><td>$2^4 / 8 \text{ MHz} = 2 \mu\text{s}$</td><td>$2^4 / 240 \text{ kHz} = 66.7 \mu\text{s}$</td></tr> <tr><td>0011_B</td><td>$2^5 / 8 \text{ MHz} = 4 \mu\text{s}$</td><td>$2^5 / 240 \text{ kHz} = 133 \mu\text{s}$</td></tr> <tr><td>0100_B</td><td>$2^6 / 8 \text{ MHz} = 8 \mu\text{s}$</td><td>$2^6 / 240 \text{ kHz} = 267 \mu\text{s}$</td></tr> <tr><td>0101_B</td><td>$2^7 / 8 \text{ MHz} = 16 \mu\text{s}$</td><td>$2^7 / 240 \text{ kHz} = 533 \mu\text{s}$</td></tr> <tr><td>0110_B</td><td>$2^8 / 8 \text{ MHz} = 32 \mu\text{s}$</td><td>$2^8 / 240 \text{ kHz} = 1.067 \text{ ms}$</td></tr> <tr><td>0111_B</td><td>$2^9 / 8 \text{ MHz} = 64 \mu\text{s}$</td><td>$2^9 / 240 \text{ kHz} = 2.133 \text{ ms}$</td></tr> <tr><td>1000_B</td><td>$2^{10} / 8 \text{ MHz} = 128 \mu\text{s}$</td><td>$2^{10} / 240 \text{ kHz} = 4.267 \text{ ms}$</td></tr> <tr><td>1001_B</td><td>$2^{11} / 8 \text{ MHz} = 256 \mu\text{s}$</td><td>$2^{11} / 240 \text{ kHz} = 8.533 \text{ ms}$</td></tr> <tr><td>1010_B</td><td>$2^{12} / 8 \text{ MHz} = 512 \mu\text{s}$</td><td>$2^{12} / 240 \text{ kHz} = 17.06 \text{ ms}$</td></tr> <tr><td>1011_B</td><td>$2^{13} / 8 \text{ MHz} = 1.024 \text{ ms}$</td><td>$2^{13} / 240 \text{ kHz} = 34.13 \text{ ms}$</td></tr> <tr><td>1100_B</td><td>$2^{14} / 8 \text{ MHz} = 2.048 \text{ ms}$</td><td>$2^{14} / 240 \text{ kHz} = 68.27 \text{ ms}$</td></tr> <tr><td>1101_B</td><td>$2^{15} / 8 \text{ MHz} = 4.096 \text{ ms}$</td><td>$2^{15} / 240 \text{ kHz} = 136.5 \text{ ms}$</td></tr> <tr><td>1110_B</td><td>$2^{16} / 8 \text{ MHz} = 8.192 \text{ ms}$</td><td>$2^{16} / 240 \text{ kHz} = 273.1 \text{ ms}$</td></tr> <tr><td>1111_B</td><td>$2^{17} / 8 \text{ MHz} = 16.38 \text{ ms}$</td><td>$2^{17} / 240 \text{ kHz} = 546.1 \text{ ms}$</td></tr> </tbody> </table> <p>Notes:</p> <ul style="list-style-type: none"> • 8 MHz is the nominal frequency of the High Speed IntOsc. • 240 kHz is the nominal frequency of the Low Speed IntOsc. 	MOST[3:0]	MainOsc stabilization time		High Speed IntOsc enabled (ROSCS.ROSCSCLKEN = 1)	High Speed IntOsc disabled (ROSCS.ROSCSCLKEN = 0)	0000 _B	$2^2 / 8 \text{ MHz} = 0.5 \mu\text{s}$	$2^2 / 240 \text{ kHz} = 17.7 \mu\text{s}$	0001 _B	$2^3 / 8 \text{ MHz} = 1 \mu\text{s}$	$2^3 / 240 \text{ kHz} = 33.3 \mu\text{s}$	0010 _B	$2^4 / 8 \text{ MHz} = 2 \mu\text{s}$	$2^4 / 240 \text{ kHz} = 66.7 \mu\text{s}$	0011 _B	$2^5 / 8 \text{ MHz} = 4 \mu\text{s}$	$2^5 / 240 \text{ kHz} = 133 \mu\text{s}$	0100 _B	$2^6 / 8 \text{ MHz} = 8 \mu\text{s}$	$2^6 / 240 \text{ kHz} = 267 \mu\text{s}$	0101 _B	$2^7 / 8 \text{ MHz} = 16 \mu\text{s}$	$2^7 / 240 \text{ kHz} = 533 \mu\text{s}$	0110 _B	$2^8 / 8 \text{ MHz} = 32 \mu\text{s}$	$2^8 / 240 \text{ kHz} = 1.067 \text{ ms}$	0111 _B	$2^9 / 8 \text{ MHz} = 64 \mu\text{s}$	$2^9 / 240 \text{ kHz} = 2.133 \text{ ms}$	1000 _B	$2^{10} / 8 \text{ MHz} = 128 \mu\text{s}$	$2^{10} / 240 \text{ kHz} = 4.267 \text{ ms}$	1001 _B	$2^{11} / 8 \text{ MHz} = 256 \mu\text{s}$	$2^{11} / 240 \text{ kHz} = 8.533 \text{ ms}$	1010 _B	$2^{12} / 8 \text{ MHz} = 512 \mu\text{s}$	$2^{12} / 240 \text{ kHz} = 17.06 \text{ ms}$	1011 _B	$2^{13} / 8 \text{ MHz} = 1.024 \text{ ms}$	$2^{13} / 240 \text{ kHz} = 34.13 \text{ ms}$	1100 _B	$2^{14} / 8 \text{ MHz} = 2.048 \text{ ms}$	$2^{14} / 240 \text{ kHz} = 68.27 \text{ ms}$	1101 _B	$2^{15} / 8 \text{ MHz} = 4.096 \text{ ms}$	$2^{15} / 240 \text{ kHz} = 136.5 \text{ ms}$	1110 _B	$2^{16} / 8 \text{ MHz} = 8.192 \text{ ms}$	$2^{16} / 240 \text{ kHz} = 273.1 \text{ ms}$	1111 _B	$2^{17} / 8 \text{ MHz} = 16.38 \text{ ms}$	$2^{17} / 240 \text{ kHz} = 546.1 \text{ ms}$
MOST[3:0]	MainOsc stabilization time																																																						
	High Speed IntOsc enabled (ROSCS.ROSCSCLKEN = 1)	High Speed IntOsc disabled (ROSCS.ROSCSCLKEN = 0)																																																					
0000 _B	$2^2 / 8 \text{ MHz} = 0.5 \mu\text{s}$	$2^2 / 240 \text{ kHz} = 17.7 \mu\text{s}$																																																					
0001 _B	$2^3 / 8 \text{ MHz} = 1 \mu\text{s}$	$2^3 / 240 \text{ kHz} = 33.3 \mu\text{s}$																																																					
0010 _B	$2^4 / 8 \text{ MHz} = 2 \mu\text{s}$	$2^4 / 240 \text{ kHz} = 66.7 \mu\text{s}$																																																					
0011 _B	$2^5 / 8 \text{ MHz} = 4 \mu\text{s}$	$2^5 / 240 \text{ kHz} = 133 \mu\text{s}$																																																					
0100 _B	$2^6 / 8 \text{ MHz} = 8 \mu\text{s}$	$2^6 / 240 \text{ kHz} = 267 \mu\text{s}$																																																					
0101 _B	$2^7 / 8 \text{ MHz} = 16 \mu\text{s}$	$2^7 / 240 \text{ kHz} = 533 \mu\text{s}$																																																					
0110 _B	$2^8 / 8 \text{ MHz} = 32 \mu\text{s}$	$2^8 / 240 \text{ kHz} = 1.067 \text{ ms}$																																																					
0111 _B	$2^9 / 8 \text{ MHz} = 64 \mu\text{s}$	$2^9 / 240 \text{ kHz} = 2.133 \text{ ms}$																																																					
1000 _B	$2^{10} / 8 \text{ MHz} = 128 \mu\text{s}$	$2^{10} / 240 \text{ kHz} = 4.267 \text{ ms}$																																																					
1001 _B	$2^{11} / 8 \text{ MHz} = 256 \mu\text{s}$	$2^{11} / 240 \text{ kHz} = 8.533 \text{ ms}$																																																					
1010 _B	$2^{12} / 8 \text{ MHz} = 512 \mu\text{s}$	$2^{12} / 240 \text{ kHz} = 17.06 \text{ ms}$																																																					
1011 _B	$2^{13} / 8 \text{ MHz} = 1.024 \text{ ms}$	$2^{13} / 240 \text{ kHz} = 34.13 \text{ ms}$																																																					
1100 _B	$2^{14} / 8 \text{ MHz} = 2.048 \text{ ms}$	$2^{14} / 240 \text{ kHz} = 68.27 \text{ ms}$																																																					
1101 _B	$2^{15} / 8 \text{ MHz} = 4.096 \text{ ms}$	$2^{15} / 240 \text{ kHz} = 136.5 \text{ ms}$																																																					
1110 _B	$2^{16} / 8 \text{ MHz} = 8.192 \text{ ms}$	$2^{16} / 240 \text{ kHz} = 273.1 \text{ ms}$																																																					
1111 _B	$2^{17} / 8 \text{ MHz} = 16.38 \text{ ms}$	$2^{17} / 240 \text{ kHz} = 546.1 \text{ ms}$																																																					

Note Refer to the Data Sheet for information about the MainOsc stabilization time.

(5) ROSCE - High Speed IntOsc enable register

This register is used to start and stop the High Speed IntOsc and to specify its operation during stand-by modes.

Protection Writing to this register is protected by a special sequence of instructions by using the protection command register PROTCMD2.

Refer to the section “*Write protected Registers*” in the chapter “*CPU System Functions*” for a detailed description how to write to write protected registers.

Access This register can be read/written in 32-bit units.

Address FF42 1000_H

Initial Value 0000 0004_H. This register is initialized by the power-up reset PURES (Power-On-Clear or debugger reset).

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	0	0	0	0	0	ROSCE STP MK	ROSCE DIS TRG	ROSCE EN TRG
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 7-26 ROSCE register contents

Bit position	Bit name	Function
2	ROSCE STPMK	High Speed IntOsc stop request mask 0: stop request not masked 1: stop request masked If the High Speed IntOsc stop request is masked (STPMK = 1) the High Speed IntOsc continues operation in any stand-by mode. If STPMK = 0, the High Speed IntOsc is stopped in a stand-by mode and is re-started upon wake-up from stand-by mode.
1	ROSCE DISTRG	High Speed IntOsc disable trigger 0: no function 1: stops High Speed IntOsc Stopping the High Speed IntOsc by ROSCEDISTRG = 1 is only possible, if the High Speed IntOsc is active, i.e. ROSCS.ROSCSCLKACT = 1. Reading of this bit returns always 0.
0	ROSCE ENTRG	High Speed IntOsc enable trigger 0: no function 1: starts High Speed IntOsc Starting the High Speed IntOsc by ROSCEENTRG = 1 is only possible, if the High Speed IntOsc is inactive, i.e. ROSCS.ROSCSCLKACT = 0. Reading of this bit returns always 0.

- Cautions**
1. Pay attention to clock domains, which are using the High Speed IntOsc clock as source via the clock selectors CKSC_mn, when disabling f_{RH} by ROSCE.ROSCEDISTRG = 1.
In particular all resets set all clock selectors CKSCLK_mn to their default selection, but only the PURES enables the High Speed IntOsc.
As a consequence all PBUS clocks PCLK will not operate after a reset - except PURES -, since the High Speed IntOsc is selected as their clock source, but the High Speed IntOsc is not enabled.
 2. If the High Speed IntOsc is stopped and a reset occurs during a Back-up RAM access, the Back-up RAM may get corrupted. Thus do not disable the High Speed IntOsc in order to avoid Back-up RAM corruption.
-

(6) ROSCS - High Speed IntOsc status register

This register provides various status information about the High Speed IntOsc status.

Access This register can be read in 32-bit units.

Address FF42 1004_H

Initial Value 0000 0004_H. This register is initialized by the power-up reset PURES (Power-On-Clear or debugger reset).

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	0	0	0	0	0	ROSCS CLK EN	ROSCS CLK ACT	ROSCS CLK STAB
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Table 7-27 ROSCS register contents

Bit position	Bit name	Function
2	ROSCS CLKEN	High Speed IntOsc enable status 0: High Speed IntOsc is disabled 1: High Speed IntOsc is enabled
1	ROSCS CLKACT	High Speed IntOsc activation status 0: High Speed IntOsc is inactive 1: High Speed IntOsc is active
0	ROSCS CLKSTAB	High Speed IntOsc stabilization status 0: High Speed IntOsc is unstable 1: High Speed IntOsc is stable

(7) PLLE0 - PLL0 enable register

This register is used to start and stop the PLL0 and to specify its operation during stand-by modes.

Protection Writing to this register is protected by a special sequence of instructions by using the protection command register PROTCMD2.

Refer to the section “*Write protected Registers*” in the chapter “*CPU System Functions*” for a detailed description how to write to write protected registers.

Access This register can be read/written in 32-bit units.

Address FF42 5000_H

Initial Value 0000 0004_H. This register is initialized by the system reset SYSRES.

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	0	0	0	0	0	PLLE0 STP MK	PLLE0 DIS TRG	PLLE0 EN TRG
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 7-28 PLLE0 register contents

Bit position	Bit name	Function
2	PLLE0 STPMK	PLL0 stop request mask 0: stop request not masked 1: stop request masked If the PLL0 stop request is masked (PLLE0STPMK = 1) the PLL0 continues operation in any STOP mode. If PLLE0STPMK = 0, the PLL0 is stopped in Isolated-Area-0 STOP mode and is re-started upon wake-up from stand-by mode. Note that the power supply of PLL0 is switched off, if the Isolated-Area-0 is in DEEPSTOP mode.
1	PLLE0 DISTRG	PLL0 disable trigger 0: no function 1: stops PLL0 Stopping the PLL0 by PLLE0DISTRG = 1 is only possible, if the PLL0 is active, i.e. PLLS0.PLLS0CLKACT = 1. Reading of this bit returns always 0.
0	PLLE0 ENTRG	PLL0 enable trigger 0: no function 1: starts PLL0 Starting the PLL0 by PLLE0ENTRG = 1 is only possible, if the PLL0 is inactive, i.e. PLLS0.PLLS0CLKACT = 0. Reading of this bit returns always 0.

(8) PLLS0 - PLL0 status register

This register provides various status information about the PLL0 status.

Access This register can be read in 32-bit units.

Address FF42 5004_H

Initial Value 0000 0000_H. This register is initialized by any reset.

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	0	0	0	0	0	PLLS0 CLK EN	PLLS0 CLK ACT	PLLS0 CLK STAB
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Table 7-29 PLLS0 register contents

Bit position	Bit name	Function
2	PLLS0 CLKEN	PLL0 enable status 0: PLL0 is disabled 1: PLL0 is enabled
1	PLLS0 CLKACT	PLL0 activation status 0: PLL0 is inactive 1: PLL0 is active
0	PLLS0 CLKSTAB	PLL0 stabilization status 0: PLL0 is unstable 1: PLL0 is stable

(9) PLLC0 - PLL0 control register

This register is used to specify the PLL0 output clock f_{PL0} frequency.

This register can only be written, if the PLL0 is disabled (PLLS0.PLLS0CLKEN = 0).

Access This register can be read/written in 32-bit units.

Address FF42 5008_H

Initial Value 0000 0000_H. This register is initialized by any reset.

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0 ^a	0 ^a	0 ^a	0 ^a	0 ^a	0 ^a	0 ^a	0 ^a	0 ^a
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

a) The default values 0 of these bits must not be changed.

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0 ^a	0 ^a	0 ^a	0 ^a	0 ^a	0 ^a	PLLC0P[1:0]	0 ^a	0 ^a	0 ^a	PLLC0N[4:0]					
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

a) The default values 0 of these bits must not be changed.

Table 7-30 PLLC0 register contents

Bit position	Bit name	Function															
9 to 8	PLLC0 P[1:0]	P divider selection <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>PLLC0 P[1:0]</th><th>Divider value Pr</th><th>PLL output frequency range</th></tr> </thead> <tbody> <tr> <td>00_B</td><td>–</td><td>setting prohibited</td></tr> <tr> <td>01_B</td><td>–</td><td>setting prohibited</td></tr> <tr> <td>10_B</td><td>2</td><td>40 MHz to 64 MHz</td></tr> <tr> <td>11_B</td><td>4</td><td>20 MHz to 32 MHz</td></tr> </tbody> </table>	PLLC0 P[1:0]	Divider value Pr	PLL output frequency range	00 _B	–	setting prohibited	01 _B	–	setting prohibited	10 _B	2	40 MHz to 64 MHz	11 _B	4	20 MHz to 32 MHz
PLLC0 P[1:0]	Divider value Pr	PLL output frequency range															
00 _B	–	setting prohibited															
01 _B	–	setting prohibited															
10 _B	2	40 MHz to 64 MHz															
11 _B	4	20 MHz to 32 MHz															
4 to 0	PLLC0 N[4:0]	Divider value Nr <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>PLLC0N[4:0]</th><th>Divider value Nr = PLLCKN[4:0] + 1</th></tr> </thead> <tbody> <tr> <td>0 0100_B</td><td>5</td></tr> <tr> <td>0 0101_B</td><td>6</td></tr> <tr> <td>...</td><td>...</td></tr> <tr> <td>1 1110_B</td><td>31</td></tr> <tr> <td>1 1111_B</td><td>32</td></tr> </tbody> </table>	PLLC0N[4:0]	Divider value Nr = PLLCKN[4:0] + 1	0 0100 _B	5	0 0101 _B	6	1 1110 _B	31	1 1111 _B	32			
PLLC0N[4:0]	Divider value Nr = PLLCKN[4:0] + 1																
0 0100 _B	5																
0 0101 _B	6																
...	...																
1 1110 _B	31																
1 1111 _B	32																

(10) PLLST0 - PLL0 stabilization time register

This register determines the PLL0 stabilization time.

This register can only be written, if the PLL0 is disabled (PLLS0.PLLS0CLKEN = 0).

Access This register can be read/written in 32-bit units.

Address FF42 500C_H

Initial Value 0000 0000_H. This register is initialized by any reset.

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	0	0	0	0	0	PLLST0[2:0]		
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 7-31 PLLST0 register contents

Bit position	Bit name	Function																													
2 to 0	PLLST0[2:0]	<p>PLL0 stabilization time setting</p> <p>Per default the PLL0 stabilization counter is operating with the High Speed IntOsc. If the High Speed IntOsc is disabled (ROSCS.ROSCSCLKEN = 0), the stabilization counter clock is automatically changed to the Low Speed IntOsc.</p> <table border="1"> <thead> <tr> <th rowspan="2">PLLST0[2:0]</th><th colspan="2">PLL0 stabilization time</th></tr> <tr> <th>High Speed IntOsc enabled (ROSCS.ROSCSCLKEN = 1)</th><th>High Speed IntOsc disabled (ROSCS.ROSCSCLKEN = 0)</th></tr> </thead> <tbody> <tr> <td>000_B</td><td>$2^7 / 8 \text{ MHz} = 16 \mu\text{s}$</td><td>$2^7 / 240 \text{ kHz} = 533 \mu\text{s}$</td></tr> <tr> <td>001_B</td><td>$2^8 / 8 \text{ MHz} = 32 \mu\text{s}$</td><td>$2^8 / 240 \text{ kHz} = 1.067 \text{ ms}$</td></tr> <tr> <td>010_B</td><td>$2^9 / 8 \text{ MHz} = 64 \mu\text{s}$</td><td>$2^9 / 240 \text{ kHz} = 2.133 \text{ ms}$</td></tr> <tr> <td>011_B</td><td>$2^{10} / 8 \text{ MHz} = 128 \mu\text{s}$</td><td>$2^{10} / 240 \text{ kHz} = 4.267 \text{ ms}$</td></tr> <tr> <td>100_B</td><td>$2^{11} / 8 \text{ MHz} = 256 \mu\text{s}$</td><td>$2^{11} / 240 \text{ kHz} = 8.533 \text{ ms}$</td></tr> <tr> <td>101_B</td><td>$2^{12} / 8 \text{ MHz} = 512 \mu\text{s}$</td><td>$2^{12} / 240 \text{ kHz} = 17.057 \text{ ms}$</td></tr> <tr> <td>110_B</td><td>$2^{13} / 8 \text{ MHz} = 1.024 \text{ ms}$</td><td>$2^{13} / 240 \text{ kHz} = 34.133 \text{ ms}$</td></tr> <tr> <td>111_B</td><td>$2^{14} / 8 \text{ MHz} = 2.048 \text{ ms}$</td><td>$2^{14} / 240 \text{ kHz} = 68.267 \text{ ms}$</td></tr> </tbody> </table> <p>Note:</p> <ul style="list-style-type: none"> 8 MHz is the nominal frequency of the High Speed IntOsc. 240 kHz is the nominal frequency of the Low Speed IntOsc. 	PLLST0[2:0]	PLL0 stabilization time		High Speed IntOsc enabled (ROSCS.ROSCSCLKEN = 1)	High Speed IntOsc disabled (ROSCS.ROSCSCLKEN = 0)	000 _B	$2^7 / 8 \text{ MHz} = 16 \mu\text{s}$	$2^7 / 240 \text{ kHz} = 533 \mu\text{s}$	001 _B	$2^8 / 8 \text{ MHz} = 32 \mu\text{s}$	$2^8 / 240 \text{ kHz} = 1.067 \text{ ms}$	010 _B	$2^9 / 8 \text{ MHz} = 64 \mu\text{s}$	$2^9 / 240 \text{ kHz} = 2.133 \text{ ms}$	011 _B	$2^{10} / 8 \text{ MHz} = 128 \mu\text{s}$	$2^{10} / 240 \text{ kHz} = 4.267 \text{ ms}$	100 _B	$2^{11} / 8 \text{ MHz} = 256 \mu\text{s}$	$2^{11} / 240 \text{ kHz} = 8.533 \text{ ms}$	101 _B	$2^{12} / 8 \text{ MHz} = 512 \mu\text{s}$	$2^{12} / 240 \text{ kHz} = 17.057 \text{ ms}$	110 _B	$2^{13} / 8 \text{ MHz} = 1.024 \text{ ms}$	$2^{13} / 240 \text{ kHz} = 34.133 \text{ ms}$	111 _B	$2^{14} / 8 \text{ MHz} = 2.048 \text{ ms}$	$2^{14} / 240 \text{ kHz} = 68.267 \text{ ms}$
PLLST0[2:0]	PLL0 stabilization time																														
	High Speed IntOsc enabled (ROSCS.ROSCSCLKEN = 1)	High Speed IntOsc disabled (ROSCS.ROSCSCLKEN = 0)																													
000 _B	$2^7 / 8 \text{ MHz} = 16 \mu\text{s}$	$2^7 / 240 \text{ kHz} = 533 \mu\text{s}$																													
001 _B	$2^8 / 8 \text{ MHz} = 32 \mu\text{s}$	$2^8 / 240 \text{ kHz} = 1.067 \text{ ms}$																													
010 _B	$2^9 / 8 \text{ MHz} = 64 \mu\text{s}$	$2^9 / 240 \text{ kHz} = 2.133 \text{ ms}$																													
011 _B	$2^{10} / 8 \text{ MHz} = 128 \mu\text{s}$	$2^{10} / 240 \text{ kHz} = 4.267 \text{ ms}$																													
100 _B	$2^{11} / 8 \text{ MHz} = 256 \mu\text{s}$	$2^{11} / 240 \text{ kHz} = 8.533 \text{ ms}$																													
101 _B	$2^{12} / 8 \text{ MHz} = 512 \mu\text{s}$	$2^{12} / 240 \text{ kHz} = 17.057 \text{ ms}$																													
110 _B	$2^{13} / 8 \text{ MHz} = 1.024 \text{ ms}$	$2^{13} / 240 \text{ kHz} = 34.133 \text{ ms}$																													
111 _B	$2^{14} / 8 \text{ MHz} = 2.048 \text{ ms}$	$2^{14} / 240 \text{ kHz} = 68.267 \text{ ms}$																													

Note Refer to the Data Sheet for information about the PLL0 stabilization time.

7.7.4 Clock selector control register

(1) CKSC_mn – Clock selector control registers

These registers select the clock for all clock domains which allow to select different clocks. For details on the selectable values for each register and its initial value refer to the section “*Clock Selection*” of this chapter.

Caution Changing safely the clock selection for a clock domain requires particular attention.
Refer to “*Clock switching*” in the section “*Clock Selection*” of this chapter.

Protection Writing to these registers is protected by a special sequence of instructions by using a protection command register, that depends on the power area:

- m = 0: Iso0
The access to writing CKSC_0n registers is protected by the protection register PRTCMD0.
- m = A: AWO
The access to writing CKSC_An registers is protected by the protection register PRTCMD2.

Refer to the section “*Write protected Registers*” in the chapter “*CPU System Functions*” for a detailed description how to write to write protected registers.

Access These registers can be read/written in 32-bit units.

Address Isolated-Area-0 clock selectors CKSC_0n: FF42 6000_H + n x 16
Always-On-Area clock selectors CKSC_An: FF42 2000_H + n x 16

Initial Value Refer to the section “*Clock Selection*”.

These registers are initialized following resets:

- Isolated-Area-0 clock selectors CKSC_0n:
 - Reset Controller: SYSRES
 - Stand-by Controller: DPSTPWU (wake-up from DEEPSTOP mode)
- Always-On-Area clock selectors CKSC_An:
 - Reset Controller: SYSRES

31	30	29	28	27	26	25	24
CKSCID_mn[30:23]							
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
23	22	21	20	19	18	17	16
CKSCID_mn[22:15]							
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
15	14	13	12	11	10	9	8
CKSCID_mn[14:7]							
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

7	6	5	4	3	2	1	0
CKSCID_mn[6:0]							STPMK_mn
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 7-32 CKSC_mn register contents

Bit position	Bit name	Function
31 to 1	CKSCID_mn[30:0]	Clock Source ID: These bits specify the clock CKSCLK_mn for clock domain mn.
0	STPMK_mn	Controls the clock output CKSCLK_mn during stand-by mode: 0: output clock CKSCLK_mn is stopped during stand-by mode 1: output clock CKSCLK_mn continues during stand-by mode

(2) CSCSTAT_mn – Clock selector status registers

These status registers return the ID of the clock source, that is currently selected by CKSC_mn and its activity status.

Access These registers can be read in 32-bit units.

Address Isolated-Area-0 clock selectors status CSCSTAT_0n: FF42 6004_H + n x 16
Always-On-Area clock selectors status CSCSTAT_An: FF42 2004_H + n x 16

Initial Value Refer to the section “Clock Selection”.

These registers are initialized following resets:

- Isolated-Area-0 clock selectors CKSC_0n:
 - Reset Controller: SYSRES
 - Stand-by Controller: DPSTPWU (wake-up from DEEPSTOP mode)
- Always-On-Area clock selectors CKSC_An:
 - Reset Controller: SYSRES

31	30	29	28	27	26	25	24
CLKSELID_mn[30:23]							
R	R	R	R	R	R	R	R
23	22	21	20	19	18	17	16
CLKSELID_mn[22:15]							
R	R	R	R	R	R	R	R
15	14	13	12	11	10	9	8
CLKSELID_mn[14:7]							
R	R	R	R	R	R	R	R
7	6	5	4	3	2	1	0
CLKSELID_mn[6:0]							CLKACT_mn
R	R	R	R	R	R	R	R

Table 7-33 CSCSTAT_mn register contents

Bit position	Bit name	Function
31 to 1	CLKSELID_mn[30:0]	Clock source ID of the current CKSC_mn clock selection
0	CLKACT_mn	CKSCLK_mn activity indicator 0: CKSCLK_mn is disabled 1: CKSCLK_mn is enabled

Chapter 8 Stand-by Controller (STBC)

This chapter contains a generic description of the Stand-by Controller.

The first section describes all V850E2/Fx4-G specific properties, such as register base addresses and wake-up factors.

The subsequent sections describe the features that apply to all implementations.

8.1 V850E2/Fx4-G Stand-by Controller Features

STBC reset The Stand-by Controller and its registers are initialized by the following reset signal:

Table 8-1 STBC reset signal

STBC	Reset signal
Stand-by Controller	<ul style="list-style-type: none"> Reset Controller SYSRES Reset Controller PURES

Wake-up factors The wake-up events for terminating a power save mode are controlled and monitored by the following Stand-by Controller registers:

- WUFL0, WUFMSKL0, WUFCL0
- WUFM0, WUFMSKM0, WUFM0
- WUFH0, WUFMSKH0, WUFCH0

The assignment of the wake-up events to the wake-up factors control and status register bits is given in the table below.

- WUF[L,M,H]m[31:00] are bits of the wake-up factor registers WUF[L,M,H]m
- WUFMSK[L,M,H]m[31:00] are bits of the wake-up factor mask registers WUFMSK[L,M,H]m
- WUFC[L,M,H]m[31:00] are bits of the wake-up factor clear registers WUFC[L,M,H]m

For details about the wake-up factors control and status registers refer to the section “Wake-up factor controller registers details” later on in this chapter.

Table 8-2 Wake-up factors registers assignments (WUFL0/WUFMSKL0/WUFCL0) (1/2)

Assignment of WUFL0/WUFMSKL0/WUFCL0 register bits			Wake-up source			
			Wake up event	Module	Power area	Domain clock
WUFL000	WUFMSKL000	WUFCL000	NMI	Port	AWO	-
WUFL001	WUFMSKL001	WUFCL001	INTWDTA0	WDTA0	AWO	CKSCLK_A07
WUFL002	WUFMSKL002	WUFCL002	INTLVI	LVI	AWO	-
WUFL003	WUFMSKL003	WUFCL003	INTKR0	KR0	AWO	CKSCLK_A02

**Table 8-2 Wake-up factors registers assignments (WUFL0/WUFMSKL0/WUFCL0)
(2/2)**

Assignment of WUFL0/WUFMSKL0/WUFCL0 register bits			Wake-up source			
			Wake up event	Module	Power area	Domain clock
WUFL007	WUFMSKL007	WUFCL007	INTP0	Port	AWO	-
WUFL008	WUFMSKL008	WUFCL008	INTP1	Port		-
WUFL009	WUFMSKL009	WUFCL009	INTP2	Port		-
WUFL010	WUFMSKL010	WUFCL010	INTP3	Port		-
WUFL011	WUFMSKL011	WUFCL011	INTP4	Port		-
WUFL012	WUFMSKL012	WUFCL012	INTP5	Port		-
WUFL013	WUFMSKL013	WUFCL013	INTP6	Port		-
WUFL014	WUFMSKL014	WUFCL014	INTP7	Port		-
WUFL015	WUFMSKL015	WUFCL015	INTP8	Port		-
WUFL016	WUFMSKL016	WUFCL016	INTP9	Port		-
WUFL017	WUFMSKL017	WUFCL017	INTP10	Port		-
WUFL018	WUFMSKL018	WUFCL018	INTP11	Port		-
WUFL019	WUFMSKL019	WUFCL019	INTP12	Port		-
WUFL023	WUFMSKL023	WUFCL023	FCN0RX	Port	AWO ^a	-
WUFL024	WUFMSKL024	WUFCL024	FCN1RX	Port		-
WUFL025	WUFMSKL025	WUFCL025	FCN2RX	Port	AWO ^a	-
WUFL026	WUFMSKL026	WUFCL026	FCN3RX	Port	AWO ^a	-
WUFL027	WUFMSKL027	WUFCL027	FCN4RX	Port	AWO ^a	-
WUFL028	WUFMSKL028	WUFCL028	FCN5RX	Port	AWO ^a	-
WUFL029	WUFMSKL029	WUFCL028	INTFCN0REC	FCN0	ISO0	CKSCLK_033
WUFL030	WUFMSKL030	WUFCL030	INTFCN1REC	FCN1	ISO0	CKSCLK_033
WUFL031	WUFMSKL031	WUFCL031	SEQWU	SEQ0	AWO	-

a) Though the CAN Controllers FCNn reside on the Isolated-Area-0, the CAN bus receive inputs FCNnRX can be selected as a wake-up source in any DEEPSTOP mode.

**Table 8-3 Wake-up factors registers assignments (WUFM0/WUFMSKM0/WUFM0)
(1/2)**

Assignment of WUFM0/WUFMSKM0/WUFM0 register bits			Wake-up source			
			Wake up event	Module	Power area	Domain clock
WUFM002	WUFMSKM002	WUFM002	INTTAUJ0I0	TAUJ0	AWO	CKSCLK_A03
WUFM003	WUFMSKM003	WUFM003	INTTAUJ0I1			
WUFM004	WUFMSKM004	WUFM004	INTTAUJ0I2			
WUFM005	WUFMSKM005	WUFM005	INTTAUJ0I3			
WUFM015	WUFMSKM015	WUFM015	INTWDTA1	WDTA1	ISO0	CKSCLK_007
WUFM016	WUFMSKM016	WUFM016	INTFCN2REC	FCN2	ISO0	CKSCLK_033
WUFM017	WUFMSKM017	WUFM017	INTLMA10IT	LMA10	ISO0	CKSCLK_011
WUFM018	WUFMSKM018	WUFM018	INTLMA10IR			
WUFM019	WUFMSKM019	WUFM019	INTLMA10IS			

**Table 8-3 Wake-up factors registers assignments (WUFM0/WUFMSKM0/WUFCM0)
(2/2)**

Assignment of WUFM0/WUFMSKM0/WUFCM0 register bits			Wake-up source			
			Wake up event	Module	Power area	Domain clock
WUFM020	WUFMSKM020	WUFCM020	INTLMA11IT	LMA11	ISO0	CKSCLK_011
WUFM021	WUFMSKM021	WUFCM021	INTLMA11IR			
WUFM022	WUFMSKM022	WUFCM022	INTLMA11IS			
WUFM023	WUFMSKM023	WUFCM023	INTCSIG4IC	CSIG4	ISO0	CKSCLK_011
WUFM024	WUFMSKM024	WUFCM024	INTCSIG4IR			
WUFM025	WUFMSKM025	WUFCM025	INTCSIG4IRE			
WUFM026	WUFMSKM026	WUFCM026	INTFCN3REC	FCN3	ISO0	CKSCLK_033
WUFM027	WUFMSKM027	WUFCM027	INTFCN4REC	FCN4	ISO0	CKSCLK_033
WUFM028	WUFMSKM028	WUFCM028	INTFCN5REC	FCN5	ISO0	CKSCLK_033
WUFM029	WUFMSKM029	WUFCM029	INTTAUB0I0	TAUB0	ISO0	CKSCLK_006
WUFM030	WUFMSKM030	WUFCM030	INTTAUB0I1			
WUFM031	WUFMSKM031	WUFCM031	INTTAUB0I2			

Table 8-4 Wake-up factors registers assignments (WUFH0/WUFMSKH0/WUFCH0)

Assignment of WUFM0/WUFMSKM0/WUFCM0 register bits			Wake-up source			
			Wake up event	Module	Power area	Domain clock
WUFH000	WUFMSKH000	WUFCH000	INTTAUB0I3	TAUB0	ISO0	ISO0_6
WUFH001	WUFMSKH001	WUFCH001	INTTAUB0I4			
WUFH002	WUFMSKH002	WUFCH002	INTTAUB0I5			
WUFH003	WUFMSKH003	WUFCH003	INTTAUB0I6			
WUFH004	WUFMSKH004	WUFCH004	INTTAUB0I7			
WUFH005	WUFMSKH005	WUFCH005	INTTAUB0I8			
WUFH006	WUFMSKH006	WUFCH006	INTTAUB0I9			
WUFH007	WUFMSKH007	WUFCH007	INTTAUB0I10			
WUFH008	WUFMSKH008	WUFCH008	INTTAUB0I11			
WUFH009	WUFMSKH009	WUFCH009	INTTAUB0I12			
WUFH010	WUFMSKH010	WUFCH010	INTTAUB0I13			
WUFH011	WUFMSKH011	WUFCH011	INTTAUB0I14			
WUFH012	WUFMSKH012	WUFCH012	INTTAUB0I15			
WUFH013	WUFMSKH013	WUFCH013	WDTA0NMI	WDTA0	AWO	CKSCLK_A07
WUFH014	WUFMSKH014	WUFCH014	WDTA1NMI	WDTA1	ISO0	CKSCLK_007

Wake-up by URTE_nRX Though the URTE_nRx signals can not be directly used as wake-up factors, external interrupts INTP_x can be used instead, since URTE_nRX and INTP_x are alternative port functions of the same pin.

8.2 Stand-by Controller functions

The V850E2/Fx4-G supports following operation respectively stand-by - or power save - modes:

- **HALT mode**
HALT mode can be entered from normal run mode by performing the CPU instruction "HALT". This stops the CPU operation, while all clocks continue to operate and all areas remain under power.
- **STOP mode**
In STOP mode the clock supply of the entire CPU Subsystem, including the CPU, is stopped. Thus no program is executed in STOP mode. Additionally certain clock supplies of a power domain can be stopped. The selection of the clock to stop respectively continue in STOP mode, is done by the clock selector's stop mask CKSC_mn.STPMK_mn.
- **DEEPSTOP mode**
In order to reduce power consumption further, the power supply of the Isolated-Area-0 can be switched off. The power supply of the I/O buffer of the isolated area in DEEPSTOP can also be stopped.
- **RUN**
All operation modes with the CPU system on Isolated-Area-0 in operation are called RUN modes.

Always-On-Area STOP mode Always-On-Area STOP mode is no separate stand-by mode, but is activated together with

- STOP mode
- DEEPSTOP mode

and means, that Always-On-Area domain clocks CKSCLK_An can be stopped.

Note that the Always-On-Area's power supply has to be active all the time.

8.2.1 Stand-by Controller signal connections

The Stand-by controller's main signal connections with other microcontroller modules is shown in the diagram below.




Figure 8-1 Stand-by Controller main signal connections

Wake-up events and factors Wake-up events are used from various other modules. Each wake-up event can be separately enabled to wake-up from stand-by mode, and thus becomes a wake-up factor.

Refer to the wake-up factor tables in the first section of this chapter under the key word “*Wake-up factors*”.

Power supply control signals If the Isolated-Area-0 area is set into DEEPSTOP mode, the Stand-by Controller generates following signal towards the Power Sequencer in order to switch off the power supply of the Isolated-Area-0:

- DPSTPREQ is asserted, when the Isolated-Area-0 is set in DEEPSTOP mode.

Refer to the chapter 24 “*Power Supply*” on page 1211 for details concerning the Power supply control.

Clock Controller signals Upon entering stand-by mode or wake-up from DEEPSTOP the Stand-by Controller generates following signals towards the Clock Controller:

- STPREQ is asserted upon entering STOP or DEEPSTOP mode and is used to stop clock generators and the Isolated-Area-0 and Always-On-Area domain clocks.
- DPSTPWU is asserted upon wake-up from DEEPSTOP and is used to reset the Isolated-Area-0 clock selectors.
- WUOSCSTA can optionally be asserted, when the MainOsc shall start operation upon wake-up from a stand-by mode. The generation of WUOSCSTA is controlled by the OSCWUFMSK.

Refer to the 7 “*Clock Controller*” on page 254 chapter for details about the Clock Controller behaviour in stand-by.

8.2.2 Stand-by modes control

This section describes how the microcontroller is set into stand-by mode.

(1) HALT mode control

The HALT mode has no influence on any power or clock domain. Thus this mode is not subject to this chapter. Refer to the document “*V850E2 32-bit Microprocessor Core Architecture*” for details concerning the HALT mode.

(2) STOP and DEEPSTOP control

STOP and DEEPSTOP control is accomplished by the stand-by control register PSC0.

The power save control registers PSC0 holds bits to

- select a stand-by mode and initiate its entry (PSC0POF, PSC0STP)
- control the I/O buffers of the Isolated-Area-0 (PSC0IOHLDSET, PSC0IOHLDMSK, PSC0IOHLDCLR), for details refer to the section “*I/O buffer control*” in this chapter
- control the power-down and -up process for DEEPSTOP mode entry and wake-up (PSC1REGSTP), for detail refer to the chapter 24 “*Power Supply*” on page 1211 .

Stand-by mode entry To enter a stand-by mode the stand-by mode trigger bit PSC0STP has to be set to 1.

Whether STOP or DEEPSTOP mode is entered by PSC0STP = 1, is determined by the power-off selection bit PSC0POF:

- PSC0STP = 1 and PSC0POF = 0: STOP mode
- PSC0STP = 1 and PSC0POF = 1: DEEPSTOP mode

The following table gives an overview about the stand-by control options:

Table 8-5 Stand-by modes control

Power domain	PSC0STP = 1	
	PSC0POF = 0	PSC0POF = 1
Always-On-Area	STOP	STOP
Isolated-Area-0	STOP	DEEPSTOP

(3) Stand-by status

The status of each power domain can be evaluated by use of the power status register PWS0. This register holds bits, indicating the status of the Isolated-Area-0.

- operational or stand-by mode
 - PWS0PSS = 0: Isolated-Area-0 and Always-On-Area are not in stand-by
 - PWS0PSS = 1: Isolated-Area-0 Isolated-Area-0 and Always-On-Area are in stand-by respectively transition to stand-by ongoing
- I/O buffer hold mode (PWS0IOHOLD)

8.2.3 Stand-by modes overview

The clock and power supply options are summarized in the table below.

Table 8-6 Stand-by modes overview

Mode	Always-On	Isolated-Area-0	
	Clock	Power	Clock
RUN	not stopped	on	not stopped
	PSC0STP=0		
STOP	stopped	on	stopped
	PSC0STP=1, PSC0POF=0		
DEEPSTOP	stopped	off	stopped
	PSC0STP=1, PSC0POF=1		

- Notes**
1. The clock status in the above table has the following meaning:
 - “not stopped”:
The clock selectors of the respective power domain do not receive a stop request. Thus its status are not changed.
 - “stopped”:
The clock selectors of the respective power domain receive a stop request. Thus a certain clock domain clock is stopped, if the clock stop is unmasked by CKSC_mn.STPMK_mn = 0.

Refer to the section 7.4 “Clock Selection” on page 273 for details concerning clock stop masking.
 2. The power status in the above table has the following meaning:
 - on:
The power supply of the Isolated-Area-0 is retained.
 - off:
The power supply of the Isolated-Area-0 is switched off.

Stand-by and On-Chip Debug Setting the device in STOP or DEEPSTOP mode is not possible, if the microcontroller is operated under control of an On-Chip Debugger.

8.2.4 Clock generators in stand-by

Following table shows the status of the various clock generators in the different stand-by modes.

Table 8-7 Clock sources in power-save modes

Mode	Always-On			Isolated-Area-0
	Low Speed IntOsc	High Speed IntOsc	MainOsc	PLL0
RUN	enabled	not stopped	not stopped	not stopped
STOP		stopped	stopped	stopped
DEEPSTOP		stopped	stopped	off

Note The clock generator status in the above table has the following meaning:

- “not stopped”:
The respective clock generator does not receive a stop request and its status is not changed. Thus it remains stopped when it was stopped or is operating in stand-by mode, when it was enabled.
- “stopped”:
The respective clock generator receives a stop request. Thus it is stopped, if the clock stop is unmasked by the associated stop request enable bit
 - MOSCE.MOSCESTPMK = 1 for the MainOsc
 - ROSCE.ROSCESTPMK = 1 for the High Speed IntOsc
 - PLLE0.PLLEKSTPMK = 1 for the PLL0
 Refer to the section 7.3 “Clock Generators” on page 263 for details concerning clock stop masking.
- “off”:
The power supply of the PLL0, which is located on the Isolated-Area-0, is switched off in DEEPSTOP mode.

(1) Module clocks during transition to stand-by mode

If Isolated-Area-0 is set in any stand-by mode, the domain clocks CKSCLK_0n of all modules on Isolated-Area-0 must be

- *either* active, i.e. the clock source, selected by the clock ID CKSC_0n.CKSCID[30:0], must be active
- *or* stopped by setting CKSC_0n = 0.

Caution Do not set Isolated-Area-0 in stand-by mode, if any module on Isolated-Area-0 is connected to a non-active clock.

8.2.5 Wake-up

(1) Wake-up events

Following wake-up events are provided to leave a stand-by mode:

Table 8-8 Wake-up events

Mode	Reset	NMI	INTLVI	INTPx ^a	Functional module on power domain ^{ab}	CAN reception FCNnRX ^a	OCD
STOP	yes	yes	yes	yes	<ul style="list-style-type: none"> operating on AWO operating on Iso0 	yes	yes
DEEPSTOP	yes	yes	yes	yes	<ul style="list-style-type: none"> operating on AWO 	yes	yes

a) The effective wake-up event must be available as a wake-up factor. Refer to the wake-up factor tables in the first section of this chapter under the key word “Wake-up factors”.

b) The functional module to issue a wake-up event must be supplied with its clock from the Clock Controller. If its clock domain is subject to the STOP mode, the stand-by mode request must be masked (CKSC_mn.STPMK_mn = 1), thus the clock for the functional module remains in operation during stand-by mode.

HALT mode wake-up The wake-up events that terminate the HALT mode are described in the document “V850E2 32-bit Microcontroller Core Architecture”.

External interrupts INTPx wake-up All external interrupts INTPx can terminate all stand-by modes. If an external interrupt INTPx shall be used to wake-up from a DEEPSTOP mode, the analog filter of INTPx must be configured for edge detection (FCLAnINTm = 0). Refer to the section 2.6 “Port Filters Functional Description” on page 95 for details.

CAN FCNnRX wake-up A falling edge of a CAN reception signal FCNnRX can generate a wake-up from stand-by mode. For further information about CAN wake-up refer to the section “Stand-by Modes” in the chapter “CAN Controller (FCN)”. If FCNnRX wakes up from DEEPSTOP mode, the FCNnRX interrupt service routine is not processed. In this case the FCNnRX is only used as a wake-up factor, thus is not part of any data communication via the CAN interface.

Functional modules interrupt wake-up Interrupts from a functional module can generate a wake-up, provided

- the functional module is not located on Isolated-Area-0 in DEEPSTOP mode (power of Isolated-Area-0 is switched off) and
- the functional module is supplied with its operation clock (clock stop is masked by CKSC_mn.STPMK_m0 = 1) and
- the functional module event is enabled as a wake-up factor (refer to the wake-up factor tables in the first section of this chapter under the key word “Wake-up factors)

On-Chip Debug wake-up The On-Chip Debug unit (OCD) is generating a wake-up event while the microcontroller runs the application program in following cases:

- the debugger issues a stop request
- a breakpoint is hit

In either case any stand-by mode is terminated, provided the OCD debug event is enabled as a wake-up factor via the WUFMSKH register.

Caution If the OCD wake-up event is disabled, it is not possible to wake-up the microcontroller from stand-by mode by a manual stop via the debugger. Thus it is recommended to enable the OCD wake-up for terminating all stand-by modes by setting

$$\text{WUFMSKH0.WUFMSKH015} = 0.$$

(2) Wake-up control

All wake-up events can be separately enabled to trigger a wake-up from stand-by mode by means of a set of wake-up factors control registers:

- $\text{WUFMSKL0, WUFMSKM0, WUFMSKH0} = \text{WUFMSK[L,M,H]0}$
- $\text{WUFL0, WUFM0, WUFH0} = \text{WUF[L,M,H]0}$
- $\text{WUFCLO, WUFM0, WUFCH0} = \text{WUFC[L,M,H]0}$.
- Wake-up mask registers: WUFMSK[L,M,H]0
Each bit of these registers is assigned to a certain wake-up event. Wake-up by this event is enabled if its mask bit $\text{WUFMSK[L,M,H]0.WUFMSK[L,M,H]0[31:0]}$ is set to 0. Upon occurrence of the enabled wake-up event the microcontroller is woken up.
- Wake-up factor registers: WUF[L,M,H]0
Upon occurrence of an unmasked wake-up event, the associated wake-up factor flag $\text{WUF[L,M,H]0.WUF[L,M,H]0[31:0]}$ is set to 1. By use of this register the application program can identify the wake-up source.
- Wake-up factor clear registers: WUFC[L,M,H]0
In order to reset a wake-up factor flag WUF[L,M,H]0[31:0] of a wake-up factor register, its assigned bit $\text{WUFC[L,M,H]0.WUFC[L,M,H]0[31:0]}$ has to be set to 1.

- Notes**
1. The wake-up factor flags in the wake-up factors registers WUF[L,M,H]0 indicate only the occurrence of a wake-up factor. Thus an asserted wake-up factor flag does not mean, that the transition from stand-by to operation mode of the concerned power domain is already accomplished. Refer to 3 “Stand-by status” on page 328 for information how to check the stand-by and operational status.
 2. If an interrupt event can also be used as a wake-up event, and this wake-up event is not masked ($\text{WUFMSK[L,M,H]0[31:0]} = 0$), the occurrence of this interrupt event sets also its wake-up factor flag WUF[L,M,H]0[31:0] , even if the device is not in stand-by mode.

(3) CPU wake-up interrupt factor processing

Depending on the stand-by mode, the CPU has to react on wake-up by an interrupt differently:

- **STOP mode**
If the microcontroller is woken up from STOP mode, the wake-up interrupt event sets an interrupt request flag (ICn.RFn = 1), provided the interrupt event was not masked (ICn.MKn = 0). Thus normal interrupt acknowledge can be performed, after interrupt acknowledgement has been enabled by the “EI” instruction.
- **DEEPSTOP mode**
If the microcontroller is woken up from DEEPSTOP mode, the wake-up interrupt event is not recorded as an interrupt request, i.e. no interrupt request flag ICn.RFn = 1 is set. Thus the CPU has to read the wake-up factor registers WUF[L,M,H]0 to evaluate the wake-up interrupt event and proceed accordingly.

(4) MainOsc wake-up

The MainOsc can be automatically started with the wake-up from stand-by. For that purpose the Stand-by Controller generates the wake-up oscillator start signal WUOSCSTA towards the Clock Controller, that starts the MainOsc.

Every wake-up factor, i.e. a wake-up event with its mask WUFMSK[L,M,H]0n cleared, can start the MainOsc.

A control bit in the OSCWUFMSK register allow to select whether to start also the MainOsc upon wake-up:

- OSCWUFMSK.OSCWUFMSK00 = 0
enables the MainOsc start with wake-up.
- OSCWUFMSK.OSCWUFMSK00 = 1
disables the MainOsc start with wake-up.




Figure 8-2 MainOsc start and wake-up

(a) MainOsc operating before stand-by

If the MainOsc was operating before stand-by, it is operating also after wake-up.

The behaviour of the MainOsc during stand-by mode is determined by the MainOsc's stop mask MOSCE.MOSCESTPMK.

Note The MainOsc's start refers to the start of their stabilization counter.

STOP mode In case of STOP mode the MainOsc wake-up mask OSCWUFMSK00 has no influence.
If stopped during STOP mode, the MainOsc is started at wake-up.

Table 8-9 MainOsc operating before STOP mode

MOSCE STPMSK	During DEEPSTOP	OSCWUFMSK00	Comment	After wake-up
1	operating	X	MainOsc remains in operation	operating
0	stopped		MainOsc is restarted at wake-up	

DEEPSTOP mode In case of DEEPSTOP mode the MainOsc's wake-up mask OSCWUFMSK00 has an influence on the time the MainOsc is started, as shown in the figure below.




Figure 8-3 OSCWUFMSK effect on MainOsc start time

- <1> If the MainOsc wake-up factor mask is not set (OSCWUFMSK00 = 0), the MainOsc is started upon DEEPSTOP wake-up (DEEPSTOP request signal DPSTPREQ is de-asserted). Thus the MainOsc is started before the Power Sequencer has switched on the Isolated-Area-0 power supply ISO0VDD and released its reset ISO0RES.
- <2> If the MainOsc wake-up factor mask is set (OSCWUFMSK00 = 1), the MainOsc is started if the power supply of the Isolated-Area-0 (ISO0VDD) is switched on and it is released from reset.

Refer to the chapter 24 "Power Supply" on page 1211 for detailed information about the Power Sequencer and the wake-up procedures from DEEPSTOP mode.

Table 8-10 MainOsc operating before DEEPSTOP mode

MOSCE STPMSK	During DEEPSTOP	OSCWUFMSK00	Comment	After wake-up
1	operating	X	MainOsc remains in operation	operating
0	stopped	1	MainOsc is restarted at Isolated-Area-0 power on (<2>)	
		0	MainOsc is restarted at wake-up (<1>)	

(b) MainOsc stopped before stand-by

If the MainOsc was stopped before stand-by, it remains stopped in stand-by in any case.

The MainOsc's stop mask MOSCE.MOSCESTPMK has no impact.

Depending on the MainOsc wake-up mask OSCWUFMSK00 the MainOsc may remain stopped or start automatically, as shown in the table below:

Table 8-11 MainOsc stopped before stand-by

MOSCE STPMSK	During DEEPSTOP	OSCWUFMSK00	Comment	After wake-up
X	stopped	1	MainOsc wake-up masked, no automatic start	stopped
		0	MainOsc wake-up unmasked, automatic start at wake-up	operating

For details about the MainOsc control refer to the description of the MainOsc in the chapter 7 "Clock Controller" on page 254 .

8.2.6 I/O buffer control

This section describes the behaviour of the I/O buffers during various stand-by modes.

Note The buffers of the port groups P0, P5 and JP0, which reside on the Always-On-Area, always remain in their active state, independent of any stand-by mode.

(1) I/O buffer hold state

If an I/O buffer is set into I/O buffer hold state, the state of the buffer is frozen. Thus its input and/or output remains in the state before entering I/O buffer hold state. No external or internal signal can change its state, until the I/O buffer hold state is terminated.

Besides I/O buffer hold states during stand-by modes, the application software can also set all buffers of the Isolated-Area-m into I/O buffer hold state via the power save control registers PSC0:

- PSC0.PSC0IOHLDSET = 1:
Isolated-Area-0 buffers enter I/O buffer hold state
- PSC0.PSC0IOHLDSET = 0:
Isolated-Area-0 buffers terminate I/O buffer hold state

Note The I/O buffers of the port groups P0 and JP0, which are located on the Always-On-Area, do not support the I/O hold function.

(2) I/O buffers during STOP mode

The I/O buffers of areas in STOP mode (clock has been stopped) remain in their configuration. Since the functional module or port function, that is connected to the I/O buffer, also remains in the state before entering STOP mode, it still controls the I/O buffer.

(3) I/O buffers during DEEPSTOP mode

The I/O buffers of Isolated-Area-0 in DEEPSTOP are changing into I/O buffer hold state by default, thus the buffer status is not changed.

After wake-up the user application has to re-configure the peripheral or port function, that generates the signals connected to a certain I/O buffer.

Afterwards the I/O buffer hold state has to be terminated by setting PSC0.PSC0IOHLDCLR = 1.

After setting this I/O buffer hold clear function trigger the concerned I/O buffer operates as configured by the peripheral or port function.

The automatic change to I/O buffer hold state upon entering DEEPSTOP mode can be suppressed via the power save control registers PSC0:

- PSC0.PSC0IOHLDMSK = 0:
Isolated-Area-0 buffers *enter* I/O buffer hold state in DEEPSTOP
- PSC0.PSC0IOHLDMSK = 1:
Isolated-Area-0 buffers *do not enter* I/O buffer hold state in DEEPSTOP

8.2.7 Mode transitions

Note Following abbreviations are used in the figure above:

- AWO: Always-On-Area
- Iso0: Isolated-Area-0

(1) Stand-by mode transitions

The following diagram shows the possible transition between the various operation and stand-by modes.




Figure 8-4 Stand-by mode transitions

8.3 Stand-by modes entry and exit example flows

In the following some recommended example flows are shown how to enter and exit stand-by modes.

-
- Cautions**
1. Make sure that all modules, which are subject to a stand-by mode are not in operation before starting stand-by mode preparations.
 2. If you intend to stop any clock sources (High Speed IntOsc, MainOsc, PLL0) before entering any stand-by mode, make one of the following provisions:
 - Make sure to switch clock domains using a clock source to be stopped to another clock source, that remains active.
 - Stop the respective clock domains by setting the CKSC_mn register to 0.
-

8.3.1 STOP mode

In STOP mode selectable domain clocks of the Always-On-Area (CKSCLK_An) and Isolated-Area-0 (CKSCLK_0n) can be stopped.

(1) STOP preparation

Depending on the succession of the STOP mode preparation steps, early occurring wake-up events, to be used as valid wake-up factors, may be discarded or saved as wake-up factors.

Here only one option for preparing the STOP mode is described. Refer to the section "*Application hint: Handling of wake-up events during stand-by mode preparation*" below for other options.

DMA/interrupt stop • Stop all DMA Controller (DMAC) and interrupt activities.

Interrupts Disable interrupt acknowledgement by the CPU instruction "DI".

Interrupt handling, in particular interrupt masking, has no influence on the wake-up behaviour. However if wake-up interrupts shall launch automatic interrupt acknowledgement after wake-up, proceed as follows:

- Clear the interrupt flags (ICn.RFn = 0) and
 - mask non-wake-up interrupts (ICn.MKn = 1)
 - unmask wake-up interrupts (ICn.MKn = 0).

Prepare domain clocks • Select the clock domains to stop or continue operation during STOP. Set the clock stop masks:

- CKSC_mn.STPMK_mn = 1:
domain clock CKSCLK_mn operates during STOP mode
- CKSC_mn.STPMK_mn = 0:
domain clock CKSCLK_mn stops during STOP mode.

Prepare clock generators • Choose clock generators to operate respectively stop during stand-by mode (by MOSCE.MOSCESTPMK, ROSCE.ROSCESTPMK, PLLE0.PLLE0STPMK bits).

- Choose if the MainOsc shall be automatically started upon a wake-up from selected isolated areas via the OSCWUFMSK register.

Note Make sure that clock generators, used as the clock source for domain clocks CKSCLK_mn, which shall not stop in stand-by mode (CKSC_mn.STPMK_mn = 1), must also not be stopped in stand-by.

-
- Wake-up factors**
- Clear wake-up factor flags in the WUF[L,M,H]0 registers (by WUFC[L,M,H]0n = 1 in WUFC[L,M,H]0 registers) and
 - mask non-wake-up factors (WUFMSK[L,M,H]0n = 1 in WUFMSK[L,M,H]0 registers)
 - unmask wake-up factors to allow them to issue a wake-up (WUFMSK[L,M,H]0n = 0 in WUFMSK[L,M,H]0 registers).
-

Caution If any previously set wake-up factor flag remains set in WUF[L,M,H]0 when starting transition to stand-by mode, an early wake-up will immediately occur and the microcontroller will not enter stand-by mode.

(2) STOP entry

- Set PSC0.PSC0POF = 0 and PSC0.PSC0STP = 1 to trigger Isolated-Area-0 transition to STOP mode.
- Since PWS0.PWS0PSS turns immediately to "1" after PSC0STP = 1, run an infinite loop by waiting for PWS0.PWS0PSS = 0.
- While the CPU remains in the infinite loop, transition STOP starts.
- When transition to STOP mode is completed, all domain clocks are stopped, if their stop mask is not set (CKSC_mn.STPMK_mn = 0). The CPU is stopped in any case.

(3) Wake-up before STOP completion (early wake-up)

If a wake-up occurs before the transition to DEEPSTOP is completed, PWS0.PWS0PSS is set to 0 and the infinite loop is left, before the Isolated-Area-0 set in STOP mode. Wake-up service can start immediately.

(4) Wake-up service

- The wake-up factor is evaluated via the wake-up factor flags, which shall be cleared afterwards.
- If the wake-up factor was an interrupt, the interrupt request is stored in the Interrupt Controller and can be acknowledged after interrupt acknowledgement is enabled by the "EI" instruction, if it is unmasked.
- If the wake-up factor was not an interrupt, the wake-up service routine may be called.




Figure 8-5 Recommended flow of STOP mode

8.3.2 DEEPSTOP mode

In DEEPSTOP mode the power supply of the Isolated-Area-0 is switched off. Selectable Always-On-Area domain clocks CKSCLK_An are stopped. Note that also the PLL0 is stopped in DEEPSTOP. This requires to change all Isolated-Area-0 and Always-On-Area domain clocks (CKSCLK_0n, CKSCLK_An) to an active non-PLL0 clock source or to stop the clock domain prior to DEEPSTOP mode.

(1) DEEPSTOP preparation

Depending on the succession of the DEEPSTOP mode preparation steps, early occurring wake-up events, to be used as valid wake-up factors, may be discarded or saved as wake-up factors.

Here only one option for preparing the DEEPSTOP mode is described. Refer to the section “*Application hint: Handling of wake-up events during stand-by mode preparation*” below for other options.

DMA/interrupt stop • Stop all DMA Controller (DMAC) and interrupt activities.

Interrupts Disable interrupt acknowledgement by the CPU instruction “DI”.

Interrupt handling, in particular interrupt masking, has no influence on the wake-up behaviour. However if wake-up interrupts shall launch automatic interrupt acknowledgement under certain wake-up conditions (refer to 3 “*Wake-up before DEEPSTOP completion (early wake-up)*” on page 342), proceed as follows:

- Clear the interrupt flags (ICn.RFn = 0) and
 - mask non-wake-up interrupts (ICn.MKn = 1)
 - unmask wake-up interrupts (ICn.MKn = 0).

Prepare Iso0 clocks • Change all Isolated-Area-0 domain clocks CKSCLK_0n

- to a currently active clock sources, which is not derived from PLL0, or
- stop the respective clock domains by setting the CKSC_0n register to 0.

Prepare AWO clocks • Select the Always-On-Area clock domains to stop or continue operation during DEEPSTOP. Set the clock stop masks:

- CKSC_An.STPMK = 1:
domain clock CKSCLK_An operates during DEEPSTOP mode
- CKSC_An.STPMK = 0:
domain clock CKSCLK_An stops during DEEPSTOP mode.

 • Change all Always-On-Area domain clocks CKSCLK_An to currently active clock sources, which are not derived from any PLL, or stop the clock domains by CKSC_An.CKSCID_An = 0000_H.

-
- Prepare clock generators**
- Choose clock generators to operate respectively stop during stand-by mode (by MOSCE.MOSCESTPMK, ROSCE.ROSCESTPMK bits).
 - Choose if the MainOsc shall be automatically started upon a wake-up from selected isolated areas via the OSCWUFMSK register.
- Wake-up factors**
- Clear wake-up factor flags in the WUF[L,M,H]0 registers (by WUFC[L,M,H]0n = 1 in WUFC[L,M,H]0 registers) and
 - mask non-wake-up factors (WUFMSK[L,M,H]0n = 1 in WUFMSK[L,M,H]0 registers)
 - unmask wake-up factors to allow them to issue a wake-up (WUFMSK[L,M,H]0n = 0 in WUFMSK[L,M,H]0 registers).

Caution If any previously set wake-up factor flag remains set in WUF[L,M,H]0 when starting transition to stand-by mode, an early wake-up will immediately occur and the microcontroller will not enter stand-by mode.

(2) DEEPSTOP entry

- Set PSC0.PSC0POF = PSC0.PSC0STP = 1 to trigger transition to DEEPSTOP mode.
- Since PWS0.PWS0PSS turns immediately to "1" after PSC0STP = 1, run an infinite loop by waiting for PWS0.PWS0PSS = 0.
- While the CPU remains in the infinite loop, transition to DEEPSTOP starts.

(3) Wake-up before DEEPSTOP completion (early wake-up)

If a wake-up occurs before the transition to DEEPSTOP is completed, PWS0.PWS0PSS is set to 0 and the infinite loop is left, before the Isolated-Area-0 power supply is switched off. Proceed as described in 5 “*DEEPSTOP wake-up processing*” on page 343 .

(4) Wake-up after DEEPSTOP completion

When transition to DEEPSTOP mode is completed, the power supply for Isolated-Area-0, i.e. also for the CPU, is switched off. Thus the CPU starts from its reset state upon wake-up.

- The reset cause can be evaluated in the following succession:
 - If any reset flag in the RESF register is set, the reset flag in RESF indicates the reset cause.
 - If no wake-up factor flag is set in WUF[L,M,H]0 registers, a power-up reset (Power-On-Clear or debugger reset) occurred.
 - If non of the above reset causes apply, the reset was caused by a DEEPSTOP wake-up.

(5) DEEPSTOP wake-up processing

- Since the Isolated-Area-0 was reset, the CPU conducts complete initialization of Isolated-Area-0.

- Iso0 ports**
- Isolated-Area-0 port buffer operation is resumed by
 - configuration of the Iso0 ports
 - release of the Iso0 I/O buffers hold (PSC0.PSC0IOHLDCLR = 1)

- Wake-up service**
- The wake-up factor is evaluated via the wake-up factor flags, which can be cleared afterwards.
 - According to the evaluated wake-up factor from the WUF[L,M,H]0 registers, the user program may have to serve the concerned wake-up. Note that also a wake-up interrupt does not generate an interrupt request towards the CPU after wake-up from DEEPSTOP mode, so an interrupt is not acknowledged automatically after enabling interrupt acknowledgement by the “EI” CPU instruction.




Figure 8-6 Recommended flow of DEEPSTOP mode

8.3.3 Application hint: Handling of wake-up events during stand-by mode preparation

This application hint describes in more detail how the stand-by mode preparation determines, at which point of the flow wake-up events provoke an early wake-up or are discarded.

Wake-up interrupts set their interrupt request flag (the related interrupt control register bit ICn.RFn), however not all wake-up events are interrupts.

Additionally in case of DEEPSTOP mode, all interrupt request flags will be discarded, if the microcontroller completely enters DEEPSTOP mode.

Thus the occurrence of *all* wake-up events during stand-by mode preparation can only be saved as wake-up flags in the wake-up factor registers WUF[L,M,H]0. Wake-up servicing can then be performed after wake-up from stand-by mode by evaluating the wake-up factor registers.

It depends on the application requirements, after which step of the stand-by entry procedure wake-up events must be recorded and served. In the following two different flows are described as examples.

- Non wake-up interrupts** All examples assume that interrupts, which shall not be used for wake-up, in particular all interrupts related to modules
- on an isolated area to enter DEEPSTOP
 - which are to be stopped in a STOP mode,
- are deactivated in the first step of the stand-by mode preparation. As these interrupts will be masked as interrupts and wake-up events afterwards, they shall not occur.

(1) Discarding wake-up events during stand-by preparation

The following diagram shows a stand-by preparation flow, where all wake-up events, occurring during the stand-by preparation sequence, are discarded and will not be served after stand-by wake-up.




Figure 8-7 Discarding wake-up events during stand-by preparation

<1> Wake-up interrupts

- are not masked, but not acknowledged yet (because of “DI”),
- are also not saved as wake-up, because wake-up flags WUF[L,M,H]0 are cleared later in <2>.

<1> – <2> During <1> and <2> all occurring wake-up events are discarded, thus will neither cause a wake-up nor any wake-up service routine after stand-by wake-up.

<2> Since wake-up events are unmasked, their occurrence will be saved in the wake-up flag registers WUF[L,M,H]0 from now on.

<3> If an unmasked wake-up event is registered in WUF[L,M,H]0 before stand-by mode is completely entered, an early wake-up will occur.

<4> All unmasked wake-up events occurring after stand-by mode was completely entered terminate the stand-by mode.

(2) Saving wake-up events during stand-by preparation

The following diagram shows a stand-by preparation flow, where wake-up events are registered as wake-up factors already during the stand-by preparation sequence.




Figure 8-8 Saving wake-up events during stand-by preparation

<1> All intended wake-up events are unmasked here, thus they will be saved as wake-up factors in the WUF[L,M,H]0 registers upon occurrence and will cause an early wake-up later on.

<1> – <2> In case wake-up interrupts are already enabled (ICn.MKn = 0), they will be served. Since a wake-up interrupt is served here and is also registered as a wake-up factor, the related wake-up factor must be cleared via the WUFC[L,M,H]0 registers in this interrupt service routine. Otherwise it remains registered as a wake-up factor and may be served a second time after stand-by wake-up.

<2> After disabling interrupt service in general (DI) and masking all non wake-up interrupts all wake-up events are only saved as wake-up factors in WUF[L,M,H]0 and cause an early wake-up later on.

<3> All unmasked wake-up events occurring after stand-by mode was completely entered terminate stand-by mode.

8.4 Stand-by Controller Registers

This section contains a description of all the registers of the Stand-by Controller.

8.4.1 Writing to protected registers

Write protected registers are protected from inadvertent write access due to erroneous program execution, etc.

Following Stand-by Controller registers feature this special write protection:

- Power save control registers PSC0

Refer to the section “3.11 *Write protected Registers*” on page 135 for a detailed description how to write to write protected registers.

8.4.2 Stand-by Controller registers overview

The Stand-by Controller is controlled and operated by the following registers:

Table 8-12 Stand-by Controller register overview

Register Name	Shortcut	Address
Power save registers:		
Power save control register 0	PSC0	FF42 0000 _H
Power status register 0	PWS0	FF42 0004 _H
Wake-up factor control registers:		
Wake-up factor register L	WUFL0	FF42 0100 _H
Wake-up factor register M	WUFM0	FF42 0110 _H
Wake-up factor register H	WUFH0	FF42 0120 _H
Wake-up factor mask register L	WUFMSKL0	FF42 0104 _H
Wake-up factor mask register M	WUFMSKM0	FF42 0114 _H
Wake-up factor mask register H	WUFMSKH0	FF42 0124 _H
Wake-up factor clear register L	WUFCL0	FF42 0108 _H
Wake-up factor clear register M	WUFM0	FF42 0118 _H
Wake-up factor clear register H	WUFCH0	FF42 0128 _H
Oscillators wake-up registers:		
Oscillator wake-up mask register	OSCWUFMSK	FF42 01A4 _H

8.4.3 Stand-by Controller control registers details

(1) PSC0 – Power save control register 0

This register controls the stand-by modes.

Protection Writing to this register is protected by a special sequence of instructions by using the protection command register PROTCMD2. Refer to the section “Write protected Registers” in the chapter “CPU System Functions” for a detailed description how to write protected registers.

Access This register can be read/written in 32-bit units.

Address FF42 0000_H

Initial Value 0000 0000_H. This register is initialized by a system reset SYSRES.

31	30	29	28	27	26	25	24
0	0	0	0	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
15	14	13	12	11	10	9	8
0	0	0	0	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
7	6	5	4	3	2	1	0
0	PSC0 IOHLDSET	PSC0 IOHLDMSK	0 ^a	PSC0 IOHLDCLR	0	PSC0 POF	PSC0 STP
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

a) The default value “0” of bit 4 of PSC0 must be changed to “1”, when using DEEPSTOP mode.

Caution The default value “0” of bit 4 of PSC0 must be changed to “1”, when using DEEPSTOP mode.

Table 8-13 PSC0 register contents (1/2)

Bit position	Bit name	Function
6	PSC0 IOHLDSET	Isolated-Area-0 I/O buffer hold function trigger 0: terminate Isolated-Area-0 I/O buffer hold function 1: enter Isolated-Area-0 I/O buffer hold function Read value of this bit is always “0”.
5	PSC0 IOHLDMSK	Isolated-Area-0 I/O buffer hold function mask 0: enable Isolated-Area-0 I/O buffer hold function 1: disable Isolated-Area-0 I/O buffer hold function If the PSC0IOHLDMSK = 1, the I/O buffers of Isolated-Area-0 do not go into hold mode during DEEPSTOP mode.
4	Bit 4	The default value “0” of bit 4 of PSC0 must be changed to “1”, when using DEEPSTOP mode.

Table 8-13 PSC0 register contents (2/2)

Bit position	Bit name	Function
3	PSC0 IOHLDCLR	Isolated-Area-0 I/O buffer hold clear function trigger 0: no function 1: clear I/O buffer hold function Reading of this bit returns always 0. Note: Setting PSC0IOHLDCLR = 1 clears the I/O hold state of all Isolated-Area-0 buffers, independent of how I/O buffer hold was entered: either by setting PSC0IOHLDSET = 1 or automatically during transition to DEEPSTOP mode.
1	PSC0 POF	Isolated-Area-0 power-off, i.e. DEEPSTOP, selection 0: Isolated-Area-0 power remains on during stand-by mode (= STOP) 1: Isolated-Area-0 power switched off during stand-by mode (= DEEPSTOP)
0	PSC0 STP	Always-On-Area and Isolated-Area-0 stand-by mode trigger 0: no function 1: Always-On-Area and Isolated-Area-0 enter stand-by mode Reading of this bit returns always 0. Upon entering stand-by mode with PSC0STP = 1, <ul style="list-style-type: none"> • Always-On-Area always enters STOP mode • Isolated-Area-0 enters STOP (if PSC0POF = 0) or DEEPSTOP (if PSC0POF = 1) mode

(2) PWS0 – Power status register 0

This register shows the stand-by mode status of the Isolated-Area-0.

Access This register can be read in 32-bit units.

Address FF42 0004_H

Initial Value 0000 0001_H. This register is initialized by a system reset SYSRES.

31	30	29	28	27	26	25	24
0	0	0	0	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
15	14	13	12	11	10	9	8
0	0	0	0	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
7	6	5	4	3	2	1	0
PWS0 PSS	0	0	0	0	0	PWS0 IOHOLD	1
R	R	R	R	R	R	R	R

Table 8-14 PWS0 register contents

Bit position	Bit name	Function
7	PWS0 PSS	Stand-by status: 0: microcontroller is in RUN mode 1: microcontroller is in the transition to or is in stand-by mode PWS0PSS is set to 1 immediately after stand-by mode trigger was issued (PSC0.PSC0STP = 1). Thus PWS0PSS = 1 indicates the state of transition to stand-by mode and the stand-by mode status. If the stand-by mode was entered, the CPU is also stopped and this register can not be read any more.
1	PWS0 IOHOLD	I/O buffer hold status of Isolated-Area-0 0: I/O buffers of Isolated-Area-0 are not in hold mode 1: /O buffers of Isolated-Area-0 are in hold mode

Note This register can not be read in stand-by mode.

8.4.4 Wake-up factor controller registers details

(1) WUF[L,M,H]0 – Wake-up factor registers

This register informs about the wake-up factor of Isolated-Area-m.

- Notes**
1. For the assignment of the wake-up factors to wake-up factor register bits refer to the key word “Wake-up factors” in the first section of this chapter.
 2. Wake-up factor bits WUF0n, which are not assigned to a valid wake-up factor, are fixed to 0.
 3. To clear an asserted bit in this register use the WUFC[L,M,H]0 registers.

Access This register can be read in 32-bit units.

Address WUFL0: FF42 0100_H
 WUFM0: FF42 0110_H,
 WUFH0: FF42 0120_H

Initial Value 0000 0000_H. This register is initialized by a system reset SYSRES.

31	30	29	28	27	26	25	24
WUF[L,M,H]0[31:24]							
R	R	R	R	R	R	R	R
23	22	21	20	19	18	17	16
WUF[L,M,H]0[23:16]							
R	R	R	R	R	R	R	R
15	14	13	12	11	10	9	8
WUF[L,M,H]0[15:8]							
R	R	R	R	R	R	R	R
7	6	5	4	3	2	1	0
WUF[L,M,H]0[7:0]							
R	R	R	R	R	R	R	R

Table 8-15 WUF[L,M,H]0 registers contents

Bit position	Bit name	Function
31 to 0	WUF[L,M,H]0n	Indicates occurrence of wake-up factor WUF[L,M,H]0n (n = 0 to 31) 0: wake-up factor WUF[L,M,H]0n did not occur 1: wake-up factor WUF[L,M,H]0n occurred

(2) WUFMSK[L,M,H]0 – Wake-up factor mask registers

This register enables wake-up factors.

- Notes**
1. For the assignment of the wake-up factors to wake-up factor register bits refer to the key word “Wake-up factors” in the first section of this chapter.
 2. Wake-up mask bits WUFMSK[L,M,H]0n, which are not assigned to a valid wake-up factor, are fixed to 1.

Access This register can be read/written in 32-bit units.

Address WUFMSKL0: FF42 0104_H
 WUFMSKM0: FF42 0114_H,
 WUFMSKH0: FF42 0124_H

Initial Value FFFF FFFF_H. This register is initialized by a system reset SYSRES.

31	30	29	28	27	26	25	24
WUFMSK[L,M,H]0[31:24]							
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
23	22	21	20	19	18	17	16
WUFMSK[L,M,H]0[23:16]							
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
15	14	13	12	11	10	9	8
WUFMSK[L,M,H]0[15:8]							
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
7	6	5	4	3	2	1	0
WUFMSK[L,M,H]0[7:0]							
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 8-16 WUFMSK[L,M,H]0 registers contents

Bit position	Bit name	Function
31 to 0	WUFMSK[L,M,H]0n	Enable of wake-up factor WUF[L,M,H]0n 0: wake-up factor WUF[L,M,H]0n enabled 1: wake-up factor WUF[L,M,H]0n disabled

(3) WUFC[L,M,H]0 – Wake-up factor clear registers

This register clears wake-up factor indicated in the WUF[L,M,H]0 registers.

- Notes**
1. For the assignment of the wake-up factors to wake-up factor register bits refer to the key word “Wake-up factors” in the first section of this chapter.
 2. Wake-up factor clear bits WUFC[L,M,H]0n, which are not assigned to a valid wake-up factor, must be written with “0”.

Access This register can be written in 32-bit units.

Address WUFCL0: FF42 0108_H
 WUFM0: FF42 0118_H,
 WUFCH0: FF42 0128_H

Initial Value Reading these registers returns always 0000 0000_H.

31	30	29	28	27	26	25	24
WUFC[L,M,H]0[31:24]							
W	W	W	W	W	W	W	W
23	22	21	20	19	18	17	16
WUFC[L,M,H]0[23:16]							
W	W	W	W	W	W	W	W
15	14	13	12	11	10	9	8
WUFC[L,M,H]0[15:8]							
W	W	W	W	W	W	W	W
7	6	5	4	3	2	1	0
WUFC[L,M,H]0[7:0]							
W	W	W	W	W	W	W	W

Table 8-17 WUFC[L,M,H]0 registers contents

Bit position	Bit name	Function
31 to 0	WUFC [L,M,H]0n	Clear of wake-up factor WUF[L,M,H]0n of the wake-up factor registers 0: no function 1: clear WUF[L,M,H]0n

8.4.5 Oscillator wake-up registers details

(1) OSCWUFMSK – Oscillator wake-up mask register

This register controls the start of the MainOsc upon a wake-up factor.

Access This register can be read/written in 32-bit units.

Address FF42 01A4_H

Initial Value 0000 0001_H. This register is initialized by a Power-up reset PURES.

31	30	29	28	27	26	25	24
0	0	0	0	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
15	14	13	12	11	10	9	8
0	0	0	0	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	OSCWUF MSK00
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 8-18 OSCWUFMSK register contents

Bit position	Bit name	Function
0	OSCWUF MSK00	Enables wake-up factor for starting the MainOsc 0: MainOsc starts by wake-up factor 1: MainOsc does not start by wake-up factor

Note If OSCWUFMSK00 = 0, the MainOsc is always started upon wake-up, even if the MainOsc was stopped before the stand-by mode was entered.

Chapter 9 Wake-up Sequencer (SEQ)

This chapter contains a generic description of the Wake-up Sequencer (SEQ).

The first section describes all properties specific to the V850E2/Fx4-G, such as instances, register base addresses, input/output signal names, etc.

The subsequent sections describe the features that apply to all implementations.

9.1 V850E2/Fx4-G SEQ Features

Instances This microcontroller has the following number of instances of the Wake-up Sequencers.

Table 9-1 Instances of SEQ

Wake-up Sequencer	
Instances	1
Names	SEQ0

Instances index n Throughout this chapter, the individual instances of a Wake-up Sequencers are identified by the index “n” (n = 0), for example, SEQnSCTR for the SEQn control register.

Digital input signal index m Throughout this chapter, the digital input signals are identified by the index “m”. Thus the digital signal inputs are named DPINm. The valid index “m” for each V850E2/Fx4-G device is given in the table below.

Table 9-2 Digital input signal index m

Index	V850E2/FF4-G V850E2/FG4-G
m =	0 to 13

Register addresses All SEQn register addresses are given as address offsets from the individual base address <SEQn_base>. The base address <SEQn_base> of each SEQn is listed in the following table:

Table 9-3 Register base addresses <SEQn_base>

SEQn instance	<SEQn_base> address
SEQ0	FF41 F000 _H

Clock supply All Wake-up Sequencers provide one clock input.

Table 9-4 SEQn clock supply

SEQn instance	SEQn clock	Connected to
SEQ0	PCLK	Low Speed IntOsc f_{RL}

SEQ H/W reset The Wake-up Sequencers and their registers are initialized by the following reset signal:

Table 9-5 SEQn reset signal

SEQn	Reset signal
SEQ0	• Reset Controller: SYSRES

I/O signals The I/O signals of the Wake-up Sequencers are listed in the following table.

Table 9-6 SEQn I/O signals

SEQn signal	Function	Connected to
SEQ0:		
DPIN0	Digital input 0	Port P0_0
DPIN1	Digital input 1	Port P0_1
DPIN2	Digital input 2	Port P0_2
DPIN3	Digital input 3	Port P0_3
DPIN4	Digital input 4	Port P0_4
DPIN5	Digital input 5	Port P0_5
DPIN6	Digital input 6	Port P0_6
DPIN7	Digital input 7	Port P0_7
DPIN8	Digital input 8	Port P0_8
DPIN9	Digital input 9	Port P0_9
DPIN10	Digital input 10	Port P0_10
DPIN11	Digital input 11	Port P0_11
DPIN12	Digital input 12	Port P0_12
DPIN13	Digital input 13	Port P0_13
DPO	Digital signal sources activation	Port P0_14
APO	Analog signal sources activation	Port P0_15

For using the P0_m ports as Wake-up Sequencer I/O signals, refer to 9.2 "I/O signals port configuration" on page 358 .

Internal signals The internal signal connections of the Wake-up Sequencer is shown in the following table.

Table 9-7 SEQn internal signal connections

SEQn signal	Function	Connected to
SEQ0:		
INTTAUJ0I0	Timer interrupt 0	TAUJ0 INTTAUJ0I0
INTTAUJ0I1	Timer interrupt 1	TAUJ0 INTTAUJ0I1
INTTAUJ0I2	Timer interrupt 2	TAUJ0 INTTAUJ0I2
SEQ0WUR	Wake-up request	Stand-by Controller SEQ0WUR

9.2 I/O signals port configuration

The Wake-up Sequencer I/O signals use alternative functions of the respective ports.

Beside the correct setting of the concerned port control registers, the function of some ports require also to enable the Wake-up Sequencer (via the sequencer control register bit SEQnSCTRL.SEQnSEQEN = 1) and to enable the respective DPINm signal to be evaluated by the Wake-up Sequencer (via the sequencer DPIN selection register bits SEQnDPINSR.SEQnDPINSRm = 1).

The table below shows the correct setting of these registers in order to use the respective ports as Wake-up Sequencer I/O signals:

All Wake-up Sequencer ports are using the ports in alternative mode 1. Thus following setting of the port control registers is common to all Wake-up Sequencer ports:

$$PMC0_m = 1, PFC0_m = 0, PFCE0_m = 0$$

Table 9-8 SEQn port configuration

Port	PMn_m setting	SEQnSEQEN	SEQnDPINSRm	Port function
P0_0	PM0_0 = 1 (ALT_IN1)	x	x	DPIN0
P0_1	PM0_1 = 1 (ALT_IN1)	x	x	DPIN1
P0_2	PM0_2 = 1 (ALT_IN1)	x	x	DPIN2
P0_3	PM0_3 = 1 (ALT_IN1)	x	x	DPIN3
P0_4	PM0_4 = 1 (ALT_IN1)	x	x	DPIN4
P0_5	PM0_5 = 1 (ALT_IN1)	1	1	DPIN5
		else		FCN0RX
P0_6	PM0_6 = 1 (ALT_IN1)	1	1	DPIN6
		else		FCN1RX
P0_7	PM0_7 = 1 (ALT_IN1)	1	1	DPIN7
		else		URTE11RX
P0_8	PM0_8 = 1 (ALT_IN1)	x	x	DPIN8
P0_9	PM0_9 = 1 (ALT_IN1)	1	1	DPIN9
		else		URTE10RX
P0_10	PM0_10 = 1 (ALT_IN1)	x	x	DPIN10
P0_11	PM0_11 = 1 (ALT_IN1)	1	1	DPIN11
		else		URTE11RX
P0_12	PM0_12 = 1 (ALT_IN1)	1	1	DPIN12
		else		TAUJ0I0
P0_13	PM0_13 = 1 (ALT_IN1)	1	1	DPIN13
		else		TAUJ0I1
P0_14	PM0_14 = 0 (ALT_OUT1)	1	x	DPO
		else		TAUJ0O2
P0_15	PM0_15 = 0 (ALT_OUT1)	1	x	APO ^a
		else		TAUJ0O3

a) Output of the Analog signal sources activation signal (APO) only in mixed input mode, i.e. if SEQnSCTRL.SEQnSEQMD = 1.

9.3 Functional Overview

The Wake-Up Sequencer supports minimization of the standby-modes power consumption in cyclic wake-up applications.

- Features summary**
- periodical check of up to 14 external events
 - automatic stand-by mode wake-up upon selectable external events
 - automated signals generation for activation of external signal sources
 - two operation modes selectable:
 - digital input mode
 - mixed (digital and analog) input mode

The following diagram shows the Wake-up Sequencer and its connections to microcontroller internal and external circuits.




Figure 9-1 Wake-up Sequencer environment

9.4 Functional description

- Digital input mode** The Wake-up Sequencer periodically evaluates up to 14 external digital signals and generates a wake-up from DEEPSTOP or STOP stand-by mode, if any of the digital signals has changed its level.
- Mixed input mode** In mixed input mode the Wake-up Sequencer additionally wakes up the microcontroller to get the CPU and the A/D Converter (ADAA) involved for evaluation of analog input signals.
In this case the Wake-up Sequencer activates the external analog signals sources before the CPU and A/D Converter are in operation. This allows concurrent stabilization of the external analog signals sources and CPU startup, and thus minimization of the power-on time of the CPU and A/D Converter.
- Timing** All required time instances, as interval and stabilization times, are generated by the Timer Array Unit TAUJ0.
TAUJ0 is operated in a specific mode for generating the Wake-up Sequencer timings. Refer to 9.6 “Wake-up Sequencer specific operation of TAUJ0” on page 381 for a description of this specific mode.
- Power domains** The Wake-up Sequencer, as well as all other necessary modules, are located on the Always-On-Area, since the Isolated-Area-0 power supply is switched off in DEEPSTOP mode.

9.4.1 Mode selection

The mode, the Wake-up Sequencer shall operate in, is selected via a bit of the sequencer control register SEQnSCTLR:

- SEQnSEQMD = 0: digital input mode
- SEQnSEQMD = 1: mixed input mode

9.4.2 Starting and stopping the sequencer

The Wake-up Sequencer is started and stopped via a bit of the sequencer control register SEQnSCTLR:

- SEQnSEQEN = 0: the sequencer is started
- SEQnSEQEN = 1: the sequencer is stopped

9.4.3 Digital input signals selection

The selection which of the 14 digital input signals shall take part in the evaluation, i.e. the comparison with the reference values, is done via control bits in the DPIN selection register SEQnDPINSR:

- SEQnDmEN = 0: signal DPINm is not enabled for evaluation
- SEQnDmEN = 1: signal DPINm is enabled for evaluation

- DPINm timing requirements** In order to detect safely any level change of a DPINm signal, the signal must fulfil following timing conditions:
- minimum high level width t_{DPH} : $2 T_{PCLK}$
 - minimum low level width t_{DPL} : $2 T_{PCLK}$
- T_{PCLK} : cycle duration of the PCLK clock




Figure 9-2 DPINm timing

9.4.4 Event flag

If the comparison between the currently read in digital values and their reference values show a mismatch, the event flag is set in the event flag register SEQnEFR:

- SEQnDPINEVF = 0: current DPINm values equals their reference values
- SEQnDPINEVF = 1: current DPINm values differ from their reference values

Note that the SEQnDPINEVF can be cleared only via the sequencer clear register SEQnSCR.

9.4.5 CPU processing acceleration

If the CPU Subsystem is woken up by the Wake-up Sequencer, it operates with following clocks:

- After wake-up from DEEPSTOP
The CPU clock CKSCLK_000 operates with the
 - High Speed IntOsc clock f_{RH} , if it was enabled before DEEPSTOP mode entry (ROSCS.ROSCSCLKEN = 1).
 - Low Speed IntOsc clock f_{RL} , if the High Speed IntOsc clock f_{RH} was disabled before DEEPSTOP entry (ROSCS.ROSCSCLKEN = 0).
- After wake-up from STOP
The CPU clock CKSCLK_000 operates with the clock used before STOP mode entry.

Note It is recommended to select the High Speed IntOsc clock as the CPU clock CKSCLK_000 before stand-by entry and to stop the High Speed IntOsc during stand-by unmasking its stop request, i.e. ROSCE.ROSCSTPMSK = 0.

In order to accelerate the CPU processing in the evaluation intervals the High Speed IntOsc frequency of nominal 8 MHz can be set to 13 MHz by setting SEQnSCTRL.SEQnACT13M = 1.

9.4.6 Operation clocks

The operation clocks of the involved modules can be selected from different clock sources, whose availability depend on the stand-by mode.

Though the Timer Array Unit TAUJ0, the CPU and the A/D Converter (used in mixed input mode) could be supplied by various clock sources, it is recommended to setup the clock controller as follows before stand-by entry in order to minimize the overall power consumption:

- Stop the MainOsc (MOSCEDISTRG = 1) and the PLLs (PLLEKDISTRG = 1).
- Enable the High Speed IntOsc (ROSCE.ROSCEENTRG = 1) and unmask its stop request for stopping the High Speed IntOsc during stand-by (ROSCE.ROSCESTOPMSK = 0).
- Set the High Speed IntOsc frequency f_{RH} to nominal 13 MHz (SEQnSCTRL.SEQnACT13M = 1) for minimizing the CPU Subsystem and A/D Converters operation time after wake-up.
- Select the High Speed IntOsc clock via the respective clock selector register as the
 - CPU clock CKSCLK_000 (CKSCID_000 = 003A_H),
 - A/D Converter clock CKSCLK_012 (CSKCID_012 = 0007_H).
- Select the Low Speed IntOsc clock as the TAUJ0 clock CKSCLK_A03 (CKSC_A03.CKSCID_A03 = 0001_H).
 Since the Timer Array Unit TAUJ0 is used during stand-by mode, mask the stop request of the TAUJ0 PCLK clock CKSCLK_A03.STPMSK_A03 = 1.

-
- Cautions**
1. If the High Speed IntOsc nominal frequency is set to 13 MHz (SEQnSCTRL.SEQnACT13M = 1), it must not be selected as the clock source for the TAUJ0 (CKSC_A03.CKSCID_A03 ≠ 0007_H).
 2. If the High Speed IntOsc nominal frequency is set to 13 MHz (SEQnSCTRL.SEQnACT13M = 1), it must be stopped in DEEPSTOP mode (ROSCE.ROSCESTOPMSK = 0).
 3. The High Speed IntOsc nominal frequency must be set back to 8 MHz (SEQnSCTRL.SEQnACT13M = 0), when normal operation of the device is resumed.
-

9.4.7 Wake-up Sequencer setup

Prior starting the Wake-up Sequencer and entering stand-by, a reference value of the digital input signals has to be acquired. This reference value is used for comparison by the sequencer later on.

Several control bits in the sequencer control register SEQnSCTLR are used to generate the reference values by software:

- SEQnDPOSET = 1 sets the DPO output signal to high level, thus activates the external digital signals sources.
- SEQnAPOSET = 1 sets the APO output signal to high level, thus activates the external analog signals sources.
- SEQnDPITRG = 1 triggers the read in of the reference values from the enabled (SEQnSCTLR.SEQnDPmEN = 1) digital input signal ports.

Note that the SEQnDPOSET and SEQnAPOSET can be cleared only via the sequencer clear register SEQnSCR.

Analog references If the Wake-up Sequencer shall operate in mixed input mode during DEEPSTOP stand-by mode and the analog input signals shall be compared against analog reference values, the respective analog signals are converted by use of the A/D Converter and these reference values must be stored in the Back-up RAM or data flash memory.
Note that the CPU RAM content is undefined after wake-up due to Isolated-Area-0 power off in DEEPSTOP mode.

Clocks setup Refer to the section 9.4.6 “Operation clocks” on page 362 .

DPINm port configuration For using ports as Wake-up Sequencer I/O signals, refer to the section “I/O signals port configuration” above in this chapter.

TAUJ0 initialization TAUJ0 is operated in a specific mode for generating the Wake-up Sequencer timings. Refer to 9.6 “Wake-up Sequencer specific operation of TAUJ0” on page 381 for a description of this specific mode.

The figure below shows a recommended setup flow.




Figure 9-3 Wake-up Sequencer setup

9.4.8 Digital input mode

(1) Basic operation in digital input mode

In digital input mode (SEQnSCTLR.SEQMD = 0), the Wake-up Sequencer compares at regular intervals the state of the selected digital inputs DPINm with their reference values, which were stored during the sequencer setup.

Periodically with the cycle duration T_{EVAL} the Wake-up Sequencer

- sets the output signal DPO to high level, that can be used to activate the sources e.g. sensors or switches) of the digital inputs signals to check
- waits a certain time T_{DISTAB} to stabilize the external digital input sources
- reads in the digital signals
- performs a compare of the current signals against their reference values
 - If at least one currently read digital input value does not match its reference value, the event flag SEQnEFR.SEQnDPINEVF is set and the stand-by wake-up request STBYWU is asserted towards the Stand-by Controller, which wakes up the Isolated-Area-0. After the stand-by wake-up the CPU is taking over the control.
 - If the currently read digital input values match the reference values, the output signal DPO is reset to low level (for deactivating the digital input signal sources) and the Wake-up Sequencer waits for the next evaluation period.

The following figure shows the basic operation of the Wake-up Sequencer in digital input mode:




Figure 9-4 Digital input mode flow

(2) CPU operation

After wake-up, the CPU is able to detect the wake-up source by evaluating the wake-up factor registers WUF[L,M,H]0 and the event flag SEQnEFR.SEQnDPINEVF to identify a change of the state of the digital inputs as wake-up source.

The CPU then deactivates the external sources of the digital input signals by

setting SEQnSCR.SEQnDPOCLR = 1 and clears the event flag by SEQnSCR.SEQnEFRCLR = 1.

For details about wake-up factors refer to the chapter “Stand-by Controller”.

(3) Timing

All required timing instances are realized by Timer Array Unit TAUJ0 interrupts.

TAUJ0 is operated in a specific mode for generating the Wake-up Sequencer timings. Refer to 9.6 “Wake-up Sequencer specific operation of TAUJ0” on page 381 for a description of this specific mode.

The time T_{CKx} in the formulas below refer to cycle duration of one of the CK0 to CK3 clocks, selected by TAUJ0 clock selector.

Interval time The interval time for the cyclic start of the evaluation of the input signals is determined by the Timer Array Unit TAUJ0 channel 0, that generates periodically its interrupt INTTAUJ0I0 with the cycle duration T_{EVAL} :

$$T_{EVAL} = T_{CKx} \cdot (TAUJ0CDR0 + 1)$$

Digital stabilization time The digital signal sources stabilization time T_{DISTAB} is counted by the TAUJ0 channel 1, that generates its interrupt INTTAUJ0I1, when the stabilization time has elapsed.

$$T_{DISTAB} = T_{CKx} \cdot (TAUJ0CDR1 + 1)$$

Master/slave channels The interval timer TAUJ0 channels 0 acts as the master channel, while channel 1 is configured as a slave channel.

(4) Digital input mode: digital input signals DPINm do not change

The diagram below depicts the situation, where none of the enabled (SEQnDPINSR.DmEN = 1) digital input signals DPINm has changed its level after the reference values were stored during the setup phase.




Figure 9-5 Wake-up Sequencer operation in digital input mode - no DPINm change

- <1> After the configured interval time T_{EVAL} has passed, channel 0 of TAUJ0 generates its interrupt request INTTAUJ0I0.
- <2> The DPO output is set to high level in order to activate the external digital input signals DPINm sources. Channel 1 of TAUJ0 starts counting down the digital input sources stabilization time T_{DISTAB} to ensure the digital input signals to settle.
- <3> T_{DISTAB} has elapsed and the digital inputs signals DPINm are stable.
- <4> The digital input signals DPINm are read and the read values are compared against their reference values.
- <5> Since all read values and their reference values match, the Wake-up Sequencer resets the DPO output signal to low level (deactivation of external digital input sources) and waits for the next INTTAUJ0I0 interrupt, that starts the next evaluation.

(5) Digital input mode: digital input signals DPINm change

The diagram below depicts the situation, where at least one of the enabled (SEQnDPINSR.DmEN = 1) digital input signals DPINm has changed its level after the reference values were stored during the setup phase.




Figure 9-6 Wake-up Sequencer operation in digital input mode - DPINm change

- <1> After the configured interval time T_{EVAL} has passed, channel 0 of TAUJ0 generates its interrupt request INTTAUJ0I0.
- <2> The DPO output is set to high level in order to activate the external digital input signals DPINm sources. Channel 1 of TAUJ0 starts counting down the digital input sources stabilization time T_{DISTAB} to ensure the digital input signals to settle.
- <3> T_{DISTAB} has elapsed and the digital inputs signals DPINm are stable.
- <4> The digital input signals DPINm are read and the read values are compared against their reference values.
- <5> Since at least one read value and its reference value does not match, the evaluation flag SEQnEFR.SEQnDPINEVF is set and the Isolated-Area-0 wake-up signal SEQWU is generated towards the Stand-by Controller.
- <6> The Isolated-Area-0 is woken up and the CPU starts operation.

9.4.9 Mixed input mode

(1) Basic operation in mixed input mode

In mixed input mode (SEQnSCTLR.SEQMD = 0), the Wake-up Sequencer compares the state of the selected digital inputs DPINm with their reference at regular intervals, as in digital input mode.

Additionally the microcontroller is also prepared to evaluate the level of analog signals, acquired via an A/D conversion, with a minimum of power-on time, thus minimizing the overall power consumption.

Periodically with the cycle duration T_{EVAL} the Wake-up Sequencer

- generates the stand-by mode wake-up request SEQWU towards the Stand-by Controller, which wakes up the Isolated-Area-0 and starts the CPU Subsystem,
- sets the output signals DPO and APO to high level, which can be used to activate the sources of the digital and analog inputs signals to evaluate,
- waits a certain time T_{ADJUST} to adjust the startup time of the CPU Subsystem on Isolated-Area-0 with the stabilization time of the external analog input sources,
- waits a certain time T_{DISTAB} to stabilize the external digital input sources,
- reads in the digital input signals
- performs a compare of the current digital signals against their reference values
 - If the currently read digital input values do not match the reference values, the event flag SEQnEFR.SEQnDPINEVF is set.
 - If the currently read digital input values match the reference values, the event flag SEQnEFR.SEQnDPINEVF remains reset.
- resets the output signal DPO to low level (for deactivating the digital input signal sources)

The following figure shows the basic operation of the Wake-up Sequencer in mixed input mode:




Figure 9-7 Mixed input mode flow

(2) CPU operation

After wake-up, the CPU is able to detect the Wake-up Sequencer as the wake-up source by evaluating the wake-up factor registers WUF[L,M,H]0. For details about wake-up factors refer to the chapter “Stand-by Controller”.

The event flag SEQnEFR.SEQnDPINEVF = 1 notifies a change of the state of the digital inputs DPINm.

For evaluation of analog input signals the CPU configures A/D Converter (ADAA) and triggers conversion of the analog signals.

Note To reduce processing time for evaluating the analog inputs values, the “Conversion result upper/lower limit compare function” of A/D Converter can be used. This will automatically generate an interrupt if the conversion result is not within certain limits. The limits applied could be analog values, taken just before entering stand-by. Refer to the section “Result check functions” in chapter “A/D Converter (ADAA)” for details.

After evaluation of the analog conversion result, the CPU can deactivate the analog input signals sources by setting APO to low level by $SEQnSCR.APOCLR = 1$.

If there was a change in the digital inputs during this interval, the CPU needs to clear the event flag as well by $SEQnSCR.EFRCLR = 1$.

(3) Timing

All required time instances, as interval, adjustment and stabilization times, are generated by the Timer Array Unit TAUJ0.

TAUJ0 is operated in a specific mode for generating the Wake-up Sequencer timings. Refer to 9.6 "Wake-up Sequencer specific operation of TAUJ0" on page 381 for a description of this specific mode.

The time T_{CKx} in the formulas below refer to cycle duration of one of the CK0 to CK3 clocks, selected by TAUJ0 clock selector.

Interval time The interval time for the cyclic start of the evaluation of the input signals is determined by the Timer Array Unit TAUJ0 channel 0, that generates periodically its interrupt INTTAUJ0I0 with the cycle duration T_{EVAL} :

$$T_{EVAL} = T_{CKx} \cdot (TAUJ0CDR0 + 1)$$

Analog stabilization and CPU start-up time The analog signal sources stabilization and CPU startup time adjustment T_{ADJUST} is set by the TAUJ0 channel 1 interrupt INTTAUJ1I1.

$$T_{ADJUST} = T_{CKx} \cdot (TAUJ0CDR1 + 1)$$

The adjustment time is calculated as follows:

$$T_{ADJUST} = T_{CPUSU} - T_{ANSTAB}$$

T_{CPUSU} : CPU startup time, i.e. the time from Isolated-Area-0 wake-up to the first CPU instruction fetch

T_{ANSTAB} : Stabilization time of the analog signals sources

For the value of CPU start-up time T_{CPUSU} refer to the Data Sheet.

Digital stabilization time The digital signal sources stabilization time T_{DISTAB} is counted by the TAUJ0 channel 2, that generates its interrupt INTTAUJ0I2, when the stabilization time has elapsed.

$$T_{DISTAB} = T_{CKx} \cdot (TAUJ0CDR2 + 1)$$

Master/slave channels The interval timer TAUJ0 channels 0 acts as the master channel, while channels 1 and 2 are configured as slave channels.

(4) Mixed input mode: digital input signals DPINm do not change

The diagram below depicts the situation, where none of the enabled (SEQnDPINSR.DmEN = 1) digital input signals DPINm has changed its level after the reference values were stored during the setup phase.




Figure 9-8 Wake-up Sequencer operation in mixed input mode - no DPINm change

- <1> After the configured interval time T_{EVAL} has passed, channel 0 of TAUJ0 generates its interrupt request INTTAUJ0I0.
- <2> The Isolated-Area-0 wake-up signal SEQWU is generated towards the Stand-by Controller, which launches Isolated-Area-0 wake-up, and thus the startup of the CPU.
Channel 1 of TAUJ0 starts counting down the adjustment time T_{ADJUST} to adjust the wake-up time of the CPU Subsystem on Isolated-Area-0 with the stabilization time of the external analog input sources.
- <3> The adjustment time T_{ADJUST} has elapsed.
- <4> The DPO and APO outputs are set to high level in order to activate the external digital and analog input signals sources.
Stabilization of the analog input signals sources and CPU startup are running concurrently.
Channel 1 of TAUJ0 starts counting down the digital input sources stabilization time T_{DISTAB} to ensure the digital input signals to settle.
- <5> T_{DISTAB} has elapsed and the digital inputs signals DPINm are stable.
- <6> The digital input signals DPINm are read and the read values are compared against their reference values.
- <7> Since all read values and their reference values match, the event flag SEQnDPINEVF remains reset.

The Wake-up Sequencer resets the DPO output signal to low level (deactivation of external digital input sources).

<8> The CPU starts operation and the analog inputs signals are stable.

(5) Mixed input mode: digital input signals DPINm change

The diagram below depicts the situation, where at least one of the enabled (SEQnDPINSR.DmEN = 1) digital input signals DPINm has changed its level after the reference values were stored during the setup phase.




Figure 9-9 Wake-up Sequencer operation in mixed input mode - DPINm change

- <1> After the configured interval time T_{EVAL} has passed, channel 0 of TAUJ0 generates its interrupt request INTTAUJ010.
- <2> The Isolated-Area-0 wake-up signal SEQWU is generated towards the Stand-by Controller, which launches Isolated-Area-0 wake-up, and thus the startup of the CPU.
Channel 1 of TAUJ0 starts counting down the adjustment time T_{ADJUST} to adjust the wake-up time of the CPU Subsystem on Isolated-Area-0 with the stabilization time of the external analog input sources.
- <3> The adjustment time T_{ADJUST} has elapsed.
- <4> The DPO and APO outputs are set to high level in order to activate the external digital and analog input signals sources.
Stabilization of the analog input signals sources and CPU startup are running concurrently.
Channel 1 of TAUJ0 starts counting down the digital input sources stabilization time T_{DISTAB} to ensure the digital input signals to settle.
- <5> T_{DISTAB} has elapsed and the digital inputs signals DPINm are stable.
- <6> The digital input signals DPINm are read and the read values are compared against their reference values.
- <7> Since at least one read value and its reference value does not match, the evaluation flag SEQnEFR.SEQnDPINEVF is set.

The Wake-up Sequencer resets the DPO output signal to low level (deactivation of external digital input sources).

<8> The CPU starts operation and the analog inputs signals are stable.

9.5 Wake-up Sequencer registers

This section contains a description of all registers of the Wake-up Sequencer.

9.5.1 Wake-up Sequencer registers overview

The Wake-up Sequencer is controlled and operated by the following registers:

Table 9-9 Wake-up Sequencer registers overview

Register name	Shortcut	Address
DPINm selection register	SEQnDPINSR	<SEQn_base>
Control register	SEQnSCTLR	<SEQn_base> + 4 _H
Event flag register	SEQnEFR	<SEQn_base> + 8 _H
Clear register	SEQnSCR	<SEQn_base> + C _H

<SEQn_base> The base addresses <SEQn_base> of the SEQn is defined in the first section of this chapter under the key word “Register addresses”.

9.5.2 Wake-up Sequencer registers details

(1) SEQnDPINSR - DPIN selection register

This register selects the digital inputs signals that will be evaluated by the Wake-up Sequencer.

Access This register can be read/written in 16-bit units.

Address <SEQn_base>

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	SEQn D13EN	SEQn D12EN	SEQn D11EN	SEQn D10EN	SEQn D9EN	SEQn D8EN	SEQn D7EN	SEQn D6EN	SEQn D5EN	SEQn D4EN	SEQn D3EN	SEQn D2EN	SEQn D1EN	SEQn D0EN
R	R	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 9-10 SEQnDPINSR register contents

Bit position	Bit name	Function
13 to 0	SEQnDmEN	Enable of related digital inputs DPINm 0: DPINm is not enabled for evaluation 1: DPINm is enabled for evaluation

(2) SEQnSCTLR - Control register

This register contains various control bits.

Access This register can be read/written in 16-bit units.

Address <SEQn_base> + 4_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
SEQn APO SET	SEQn DPO SET	0	0	0	0	0	0	SEQn ACT 13M	0	0	0	0	SEQn DPI TRG	SEQn SEQ MD	SEQn SEQ EN
W	W	R	R	R	R	R	R	R/W	R	R	R	R	W	R/W	R/W

Table 9-11 SEQnSCTLR register contents

Bit position	Bit name	Function
15	SEQn APOSET	Set the output signal APO to high level for activating the analog input signal sources 0: no function 1: sets APO to high level This bit can only be cleared via the clear register SEQnSCR.SEQnAPOCLR = 1. Reading of this bit returns always 0.
14	SEQn DPOSET	Set the output signal DPO to high level for activating the digital input signal sources 0: no function 1: sets DPO to high level This bit can only be cleared via the clear register SEQnSCR.SEQnDPOCLR = 1. Reading of this bit returns always 0.
7	SEQn ACT13M	Change nominal frequency of the High Speed IntOsc 0: High Speed IntOsc runs at nominal frequency $f_{RH} = 8$ MHz 1: High Speed IntOsc runs at nominal frequency $f_{RH} = 13$ MHz
2	SEQn DPITRG	Trigger acquisition of digital reference values 0: no function 1: current state of enabled digital input signals DPINm is stored as the reference value Reading of this bit returns always 0.
1	SEQn SEQMD	Wake-up sequencer mode selection 0: digital input mode 1: mixed input mode
0	SEQn SEQEN	General enable of the Wake-up Sequencer 0: sequencer operation disabled 1: sequencer operation enabled

(3) SEQnEFR - Event flag register

This register indicates the result of the last comparison between the latest read in values of the digital input signals and their reference values.

Access This register can be read in 16-bit units.

Address <SEQn_base> + 8_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	SEQn DPIN EVF
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Table 9-12 SEQnEFR register contents

Bit position	Bit name	Function
0	SEQn DPINEVF	Result of current and reference values comparison: 0: current values match reference values, i.e. no DPINm change detected 1: current values do not match reference values, i.e. at least one DPINm change detected This bit can only be cleared via the clear register SEQnSCR.SEQnEFRCLR = 1.

(4) SEQnSCR - Clear register

This register clears the active state of the SEQnAPOSET and SEQnDPOSET bits of the SEQnSCTRL register and the SEQnDPINEVF of the SEQnEFR register.

Access This register can be written in 16-bit units.

Address <SEQn_base> + C_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
SEQn APO CLR	SEQn DPO CLR	0	0	0	0	0	0	0	0	0	0	0	0	0	SEQn EFR CLR
W	W	R	R	R	R	R	R	R	R	R	R	R	R	R	W

Table 9-13 SEQnSCR register contents

Bit position	Bit name	Function
15	SEQn APOCLR	Clear of SEQnSCTRL.SEQnAPOSET 0: no function 1: clear SEQnSCTRL.SEQnAPOSET, i.e. APO output signal is set to low level
14	SEQn DPOCLR	Clear of SEQnSCTRL.SEQnDPOSET 0: no function 1: clear SEQnSCTRL.SEQnDPOSET, i.e. DPO output signal is set to low level
0	SEQn EFRCLR	Clear of SEQnEFR.SEQnDPINEVF 0: no function 1: SEQnEFR.DPINEVF event flag is cleared

9.6 Wake-up Sequencer specific operation of TAUJ0

This section describes the operation modes and setup of the Timer Array Unit TAUJ0, as needed to interact with the Wake-up Sequencer.

9.6.1 TAUJ0 operation overview

The Wake-up Sequencer is used in combination with TAUJ0 to generate the required timings for interval time and stabilization times of external input signals.

For a general description of TAUJ refer to chapter “*Timer Array Unit J (TAUJ)*”.

TAUJ0 operation clock

Though the TAUJ0 can be supplied by various clock sources, it is recommend to select the Low Speed IntOsc as its clock source.

Thus throughout this chapter it is assumed that TAUJ0 is supplied with the Low Speed IntOsc clock f_{RL} during RUN and STOP/DEEPSTOP stand-by modes.

(1) Digital input mode

The following figure shows the general timing diagram of TAUJ0 used for the Wake-up Sequencer in digital input mode:




Figure 9-10 Timing diagram of TAUJ0 in SEQn digital input mode

Channel 0 operates as the master channel in interval timer mode and counts the interval time T_{EVAL} of the wake-up cycle.

When the master channel counter reaches $0000\ 0000_H$, it asserts its interrupt INTTAUJ010 and generates an internal signal which in turn starts the count operation of slave channel 1 and reloads the channel 0 counter value.

Slave channel 1 operates in One Count Mode and counts the stabilization time T_{DISTAB} needed by the external digital input signals to settle. The required value is depending on the electrical characteristics of the application circuitry.

When slave channel 1 counter reaches $0000\ 0000_H$, it asserts its interrupt INTTAUJ011, that is used to trigger the read in of the digital input signals DPINm and the comparison of the current state of the selected digital input signals with their reference value.

Note The typical minimum stabilization time that can be configured is 1 count of TAUJ0 channel 1:

$$\text{min. } T_{DISTAB} = 1 / f_{RL} = 4.2 \mu\text{s}$$

with nominal $f_{RL} = 240 \text{ kHz}$.

For characteristics of Low Speed IntOsc refer to the Data Sheet.

(2) Mixed input mode

The following figure shows the general timing diagram of TAUJ0 used for the Wake-up Sequencer in mixed input mode:




Figure 9-11 Timing diagram of TAUJ0 in SEQn mixed input mode

Channel 0 operates as the master channel in interval timer mode and counts the interval time T_{EVAL} of the wake-up cycle.

When the master channel counter reaches 0000 0000_H, it asserts its interrupt INTTAUJ0I0 and generates an internal signal which in turn starts the count operation of slave channel 1 and reloads the channel 0 counter value.

Slave channel 1 operates in One Count Mode and counts the adjustment time T_{ADJUST} , i.e. the difference between the CPU startup time and the stabilization time of the external analog signals sources.

The adjustment time is calculated as follows:

$$T_{ADJUST} = T_{CPUSU} - T_{ANSTAB}$$

T_{CPUSU} : CPU startup time, i.e. the time from Isolated-Area-0 wake-up to the first CPU instruction fetch

T_{ANSTAB} : Stabilization time of the analog signals sources

For the value of CPU start-up time T_{CPUSU} refer to the Data Sheet.

T_{ANSTAB} is depending on the electrical characteristics of the application circuitry.

When the slave channel 1 counter reaches 0000 0000_H it asserts its interrupt INTTAUJ0I1 and generates an internal that starts the count operation of slave channel 2.

Slave channel 2 operates in One Count Mode and counts the stabilization time T_{DISTAB} needed by the external digital input signals to settle. The required value is depending on the electrical characteristics of the application circuitry.

When slave channel 2 counter reaches $0000\ 0000_H$, it asserts its interrupt $INTTAUJ0I2$, that is used to trigger the read in of the digital input signals $DPINm$ and the comparison of the current state of the selected digital input signals with their reference value.

Note The typical minimum stabilization time that can be configured is 1 count of TAUJ0 channel 2:

$$\text{min. } T_{DISTAB} = 1 / f_{RL} = 4.2 \mu\text{s}$$

with nominal $f_{RL} = 240 \text{ kHz}$.

For characteristics of Low Speed IntOsc refer to the Data Sheet.

9.6.2 TAUJ0 register settings

In the following, only the register settings to support SEQn operation will be described for TAUJ0.

Only these specific register settings are allowed to be used to operate TAUJ0 in conjunction with the Wake-up Sequencer SEQn.

(1) Register settings for the master channel 0

(a) TAUJ0CMOR0 for the master channel 0

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]		CCS[1:0]		MAS	STS[2:0]			COS[1:0]		-	MD[4:1]			MD0	

Table 9-14 TAUJ0CMOR0 settings for the master channel of the PWM Output Function

Bit name	Setting
CKS[1:0]	00: Prescaler output CK0 01: Prescaler output CK1 10: Prescaler output CK2 11: Prescaler output CK3 The value of the CKS[1:0] bit of the master and slave channel(s) must be identical.
CCS[1:0]	00: Operation clock is used as the count clock
MAS	1: Channel is master channel
STS[2:0]	000: Counter triggered by software trigger
COS[1:0]	Not used, so set to 00.
MD[4:1]	0000: Interval Timer Mode
MD0	0: Does not generate INTTAUJ0I0 at operation start

(b) TAUJ0CMUR0 for the master channel

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
														TIS[1:0]	

Table 9-15 TAUJ0CMUR0 settings for the master channel of the PWM Output Function

Bit name	Setting
TIS[1:0]	Not used, so set to 00.

(c) Channel output mode for the master channel

The channel output mode is not used by this function. However, it can be used by other functions or in Independent Channel Output Mode Controlled by Software.

(d) Simultaneous rewrite for the master channel

The simultaneous rewrite settings of the master and slave channel must be identical.

Table 9-16 Simultaneous rewrite settings for the master channel

Bit name	Setting
TAUJ0RDE. RDE00	0: Disables simultaneous rewrite
TAUJ0RDM. RDM00	Not used, so set to 0.

(2) Register settings for the slave channel 1**(a) TAUJ0CMOR1 for the slave channel 1**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]		CCS[1:0]		MAS	STS[2:0]		COS[1:0]		-	MD[4:1]				MD0	

Table 9-17 TAUJ0CMOR1 settings for the slave channel 1

Bit name	Setting
CKS[1:0]	00: Prescaler output CK0 01: Prescaler output CK1 10: Prescaler output CK2 11: Prescaler output CK3 The value of the CKS[1:0] bit of the master and slave channel(s) must be identical.
CCS[1:0]	00: Operation clock is used as the count clock
MAS	0: Channel is a slave channel
STS[2:0]	100: INTTAUJ0I0 of the master channel is the start trigger
COS[1:0]	Not used, so set to 00.
MD[4:1]	0100: One Count Mode
MD0	1: Generates INTTAUJ0I1

(b) TAUJ0CMUR1 for the slave channel 1

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
														TIS[1:0]	

Table 9-18 TAUJ0CMUR1 settings for the slave channel 1

Bit name	Setting
TIS[1:0]	Not used, so set to 00.

(c) Channel output mode for the slave channel 1**Table 9-19 Control bit settings for Independent Channel Output Mode 1**

Bit name	Setting
TAUJ0TOE. TOE01	0: Disables Independent Channel Output
TAUJ0TOM. TOM01	Not used, so set to 0.
TAUJ0TOC. TOC01	Not used, so set to 0.
TAUJ0TOL. TOL01	Not used, so set to 0.

(d) Simultaneous rewrite for the slave channel 1

The simultaneous rewrite settings of the master and slave channel must be identical.

Table 9-20 Simultaneous rewrite settings for the slave channel 1

Bit name	Setting
TAUJ0RDE. RDE01	0: Disables simultaneous rewrite
TAUJ0RDM. RDM01	Not used, so set to 0.

(3) Register settings for the slave channel 2**(a) TAUJ0CMOR2 for the slave channel 2**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]		CCS[1:0]		MAS	STS[2:0]		COS[1:0]		-	MD[4:1]				MD0	

Table 9-21 TAUJ0CMOR2 settings for the slave channel 2

Bit name	Setting
CKS[1:0]	00: Prescaler output CK0 01: Prescaler output CK1 10: Prescaler output CK2 11: Prescaler output CK3 The value of the CKS[1:0] bit of the master and slave channel(s) must be identical.
CCS[1:0]	00: Operation clock is used as the count clock
MAS	0: Channel is a slave channel
STS[2:0]	101: INTTAUJ0I1 of the upper channel is the start trigger
COS[1:0]	Not used, so set to 00.
MD[4:1]	0100: One Count Mode
MD0	1: Generates INTTAUJ0I2

(b) TAUJ0CMUR2 for the slave channel 2

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
														TIS[1:0]	

Table 9-22 TAUJ0CMUR2 settings for the slave channel 2

Bit name	Setting
TIS[1:0]	Not used, so set to 00.

(c) Channel output mode for the slave channel 2**Table 9-23 Control bit settings for Independent Channel Output Mode 1**

Bit name	Setting
TAUJ0TOE. TOE02	0: Disables Independent Channel Output
TAUJ0TO02. TO0202	Not used, so set to 0.
TAUJ0TOC. TOC02	Not used, so set to 0.
TAUJ0TOL. TOL02	Not used, so set to 0.

(d) Simultaneous rewrite for the slave channel 2

The simultaneous rewrite settings of the master and slave channel must be identical.

Table 9-24 Simultaneous rewrite settings for the slave channel 2

Bit name	Setting
TAUJ0RDE. RDE02	0: Disables simultaneous rewrite
TAUJ0RDM. RDM02	Not used, so set to 0.

Chapter 10 Code Protection and Security

10.1 Overview

The microcontroller supports various methods for protecting the program code in the flash memory from undesired access, such as illegal read-out or illegal reprogramming.

Some interfaces offer in general access to the internal flash memory: Nexus debug interface, external flash programmer interface, Self-Programming facilities and test interfaces.

In the following the security relevant items are listed. The features to protect the internal flash memory data from being read by unauthorized persons are described.

For more information about the flash memory, see chapter *"Flash Memory"*.

The following sections give an overview about supported code protection methods.

10.2 Flash Programmer and Self-Programming Protection

In general, illegal read-out and re-programming of the flash memory contents is possible via the flash programmer interface and the Self-Programming feature. For protection of the flash memory, the following flags provide various protection levels.

The flags can be set by flash programmers. For a description of flash memory programming see chapter “Flash Memory”.

(1) Block erase protection flag (Block erase protection function)

Set this flag to disable the feature to erase single blocks via the flash programmer interface. This flag does not affect the Self-Programming interface.

The flag is valid for the whole flash memory.

(2) Program protection flag (Program protection function)

Set this flag to disable the programming function via the flash programmer interface. This flag does not affect the Self-Programming interface.

The flag is valid for the whole flash memory.

(3) Read-out protection flag (Read-out protection function)

Set this flag to disable the feature that allows reading back the flash memory via the flash programmer interface. This flag does not affect the Self-Programming interface.

This flag is valid for the whole flash memory.

(4) Boot block cluster protection flag

Set this flag to disable erasure and rewrite of the boot block cluster. The boot block cluster can not be manipulated in any way (no erase/write).

This applies in Serial- and Self-Programming mode.

Once this flag is set, it is impossible to reset this flag. Thus the boot block cluster content can not be changed any more.

(5) Flash shielding

Flash shielding allows to specify a random number of consecutive code flash memory blocks, the flash shield window, which can be erased and written. Erasure of and writing to all flash memory blocks outside the flash shield window is impossible.

10.3 On-Chip Debug Interface Protection

In general, illegal read-out of the flash memory contents is possible via the Nexus On-Chip Debug interface. For protection of the flash memory, the usage of the debug interface can be disabled.

The debug interface is protected via a 95-bit ID code and an internal control flag (On-Chip Debug enable control).

When the debugger is started, the status of the control flag in the internal flash memory is queried. Setting this flag to zero disables the On-Chip Debugger.

When debugging is enabled (On-Chip Debug enable flag is set), you have to enter the 95-bit ID code via the debugger. The code is compared with the ID code stored in the internal flash memory. If the codes do not match, debugging is not possible.

It is also possible to temporarily enable the On-Chip Debug interface by setting the On-Chip Debug enable flag via the user program, stored in the internal flash memory.

However after the device receives an external $\overline{\text{RESET}}$ or a Power-On-Clear reset POCRES, the On-Chip Debug enable flag is reset again and thus the On-Chip Debug interface is disabled, provided the On-Chip Debug enable flag in the flash memory is 0.

The On-Chip Debug enable flag and the ID code are stored in the flash memory configuration area and can be accessed via the OCDIDL, OCDIDM, OCDIDH registers.

10.3.1 On-Chip Debug enable flag

On-Chip Debugging is controlled by the On-Chip Debug enable flag OCDIDH.OCDID[95].

(1) Permanent On-Chip Debug enable/disable

The On-Chip Debug enable flag can be permanently set or reset

- while reprogramming the flash memory by an external flash programmer
- by the user's program with the Self-Programming feature.

Both methods change the content of the internal flash memory.

Any modification of the On-Chip Debug control flag OCDIDH.OCDID[95] by reprogramming of the flash memory becomes effective after next release from an external RESET or a Power-On-Clear reset POCRES.

(2) Temporary On-Chip Debug enable/disable

Temporarily enabling respectively disabling the On-Chip Debugging is done by the On-Chip Debug control register IDMODI:

- IDMODI.IDEN = 1 and IDMODI.IDDATA = 0 sets OCDIDH.OCDID[95] = 0 and disables On-Chip Debugging
- IDMODI.IDEN = 1 and IDMODI.IDDATA = 1 sets OCDIDH.OCDID[95] = 1 and enables On-Chip Debugging

- Notes**
1. After release from the next external $\overline{\text{RESET}}$ or Power-On-Clear reset POCRES, the On-Chip Debug control flag OCDIDH.OCDID[95] takes on the value from the internal flash memory.
 2. Writing to IDMODI with IDMODI.IDEN = 0 does not modify the On-Chip Debug control flag.

10.3.2 On-Chip Debug ID code

The 95-bit ID code is accessible via the register bits OCDIDH.OCDID[94:64], OCDIDM.OCDID[63:32] and OCDIDL.OCDID[31:0].

The ID code can be specified

- while reprogramming the flash memory by an external flash programmer
- by the user's program with the Self-Programming feature.

Both methods change the content of the internal flash memory.

Any modification of the ID code OCDIDH.OCDID[94:64], OCDIDM.OCDID[63:32] and OCDIDL.OCDID[31:0] by re-programming of the flash memory becomes effective after next release from an external $\overline{\text{RESET}}$ or a Power-On-Clear reset POCRES.

10.3.3 On-Chip Debug protection levels summary

The following table summarizes the protection levels of the On-Chip Debug interface:

Table 10-1 On-Chip Debug protection levels

On-Chip Debug enable flag	ID code	Protection Level
0	X ^a	Level 2: Full protection On-Chip debug interface can not be used.
1	user-specific ID code	Level 1: ID code protection On-Chip Debug interface can only be used if the user enters the correct ID code.
	ID code is all ones ^b	Level 0: No protection On-Chip Debug interface can be used.

a) ID codes are not compared

b) This is the default state after the flash memory has been erased.

Note Once the On-Chip Debug interface has been set as “use-prohibited”, it cannot be used until the On-Chip Debug enable flag is set to 1 by the user's program or by Self-Programming.

10.3.4 On-Chip Debug control registers

Following registers are dedicated to the On-Chip Debugger:

Table 10-2 On-Chip Debug control registers overview

Register Name	Shortcut	Address
On-Chip Debug ID register L	OCDIDL	FF47 0000 _H
On-Chip Debug ID register M	OCDIDM	FF47 0004 _H
On-Chip Debug ID register H	OCDIDH	FF47 0008 _H
On-Chip Debug control register	IDMODI	FF47 0000 _H

(1) OCDIDL/M/H - On-Chip Debug ID registers

These registers hold the 95-bit ID code, the user is requested to enter upon start of a debug session.

By use of the OCDID[95] bit On-Chip Debugging can generally be disabled respectively enabled.

Access In normal operation mode these registers can be read in 32-bit units. Writing to this register is only possible in flash programming and Self-Programming mode.

On-chip Debug control bit OCDID[95] can be temporarily modified via the IDMOD1 register also in normal operation mode.

Address OCDIDL: FF47 0000_H, OCDIDM: FF47 0004_H, OCDIDH: FF47 0008_H

Initial Value User defined

OCDIDH:

31	30	...	0
OCDID [95]	OCDID [94]	...	OCDID [65] OCDID [64]
R	R	...	R R

OCDIDM:

31	30	...	0
OCDID [63]	OCDID [62]	...	OCDID [33] OCDID [32]
R	R	...	R R

OCDIDL:

31	30	...	0
OCDID [31]	OCDID [30]	...	OCDID [1] OCDID [0]
R	R	...	R R

Table 10-3 OCDIDH/M/L registers contents

Register	Bit position	Bit name	Function
OCDIDH	31	OCDID[95]	Enable/disable On-Chip Debug: 0: On-Chip Debug disabled 1: On-Chip Debug enabled
OCDIDH	30 - 0	OCDID[94:64]	95-bit On-Chip Debug ID code
OCDIDM	31 - 0	OCDID[63:32]	
OCDIDL	31 - 0	OCDID[31:0]	

(2) IDMODI - On-Chip Debug control register

This register allows to temporarily enable/disable On-Chip Debugging in normal operation mode, i.e. by the user's software.

This is performed by modifying the OCDIDH.OCDID[95] On-Chip Debug control bit.

Note Any modification of the On-Chip Debug control bit OCDIDH.OCDID[95] by the user's software becomes invalid after the next release from an external $\overline{\text{RESET}}$ or a Power-On-Clear reset POCRES.

Protection Writing to this register is protected by a special sequence of instructions by using a protection command register.
Refer to the section "Write protected Registers" in chapter "CPU System Functions" for a detailed description how to write to write protected registers.

Access This register can be written in 32-bit units.
Reading this register returns the value of OCDIDL.

Address FF47 0000_H

Initial Value User defined

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
W	W	W	W	W	W	W	W	W	W	W	W	W	W	W	W
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	0	0	0	0	0	0	IDEN	IDDATA
W	W	W	W	W	W	W	W	W	W	W	W	W	W	W	W

Table 10-4 IDMODI register contents

Bit position	Bit name	Function											
1 0	IDEN IDDATA	Modify enable/disable On-Chip Debug control bit OCDIH.OCDI[95]											
		<table border="1"> <thead> <tr> <th>IDEN</th><th>IDDATA</th><th>OCDIH.OCDI[95] modification</th></tr> </thead> <tbody> <tr> <td>0</td><td>X</td><td>not modified</td></tr> <tr> <td rowspan="2">1</td><td>0</td><td>set to 0 (On-Chip Debug disabled)</td></tr> <tr> <td>1</td><td>set to 1 (On-Chip Debug enabled)</td></tr> </tbody> </table>	IDEN	IDDATA	OCDIH.OCDI[95] modification	0	X	not modified	1	0	set to 0 (On-Chip Debug disabled)	1	set to 1 (On-Chip Debug enabled)
IDEN	IDDATA	OCDIH.OCDI[95] modification											
0	X	not modified											
1	0	set to 0 (On-Chip Debug disabled)											
	1	set to 1 (On-Chip Debug enabled)											

Chapter 11 Reset Controller

11.1 Functional Overview

Several system reset functions are provided in order to initialize the microcontroller hardware and its registers.

Features summary A reset can be caused by the following events:

- External reset signal $\overline{\text{RESET}}$
Noise in the external reset signal is eliminated by an analog filter.
- Power-On-Clear (POCRES)
- Overflow of the Watchdog Timers (WDTA0RES, WDTA1RES)
- Clock Monitors reset ($\overline{\text{CLMA0RES}}$, $\overline{\text{CLMA2RES}}$, $\overline{\text{CLMA3RES}}$)
- Low-Voltage Indicator reset (LVIRES)
- Software reset (SWRES)
- Debugger reset (DBRES)

The following block diagram shows the main components of the Reset Controller.




Figure 11-1 Block diagram of the Reset Controller

(1) Internal reset signals

The Reset Controller manages the generation of two reset signals upon occurrence of reset signals from various reset sources:

- system reset SYSRES
The system reset is generated by all reset sources. SYSRES is applied to all microcontroller components, except the clock generator circuits. Consequently all clock generators continue operation, provided they were operating before the SYSRES.
- power-up reset PURES
The power-up reset PURES is activated by the Power-On-Clear reset POCRES and the debugger reset DBRES. It resets some clock generators. Hence these clock generators stop operation and must be restarted. Refer to chapter 7 “Clock Controller” on page 254 detailed information, which clock generators are stopped by PURES.
Assertion of PURES generates also a SYSRES, thus all microcontroller components are reset as well.

(2) Operation mode control

The microcontroller’s operation mode is determined upon release of the Power-On-Clear reset or the external $\overline{\text{RESET}}$.

Refer to the section “Operation modes” in the “CPU System Functions” chapter for details about the operation modes.

(3) Isolated areas power supply

Any reset switches off the power supplies of the Isolated-Area-0. Thus after a reset the Isolated-Area-0 has the same status as after initial power-up or after wake-up from DEEPSTOP mode, i.e. it has to be completely re-initialized.

Note Be aware that also after any reset the internal Data RAM content is undefined.

(4) Reset flags

The reset source flag register RESF holds a flag for each reset source, that is set, when the respective reset was asserted.

All reset flags are only cleared by a power-up reset PURES or by software. Refer to section 11.2.1 “Reset flags” on page 402 for details.

Note In case of concurrently asserted power-up reset PURES and external $\overline{\text{RESET}}$, setting of the RESF.RESF8 flag, that indicates the occurrence of an external $\overline{\text{RESET}}$, depends on the time relation between PURES and the $\overline{\text{RESET}}$. Refer to the Data Sheet for details.

(5) Interrupts

The Low-Voltage Indicator generates the interrupt INTLVI. Refer to section 11.2.3 “Low-Voltage Indicator (LVI)” on page 404 .

(6) On-chip modules resets

Watchdog Timers reset The Watchdog Timers can generate the resets WDTA0RES and WDTA1RES. Refer to section 11.2.6 “Watchdog Timers reset (WDTAnRES)” on page 410 .

Clock Monitor resets The Clock Monitors can generate the resets $\overline{\text{CLMA0RES}}$, $\overline{\text{CLMA2RES}}$ and $\overline{\text{CLMA3RES}}$. Refer to section 11.2.8 “Clock Monitors reset (CLMAAnRES)” on page 410 for details.

Debugger reset In case a debugger is connected, it can generate the reset DBRES, which leads to a power-up reset PURES>. Refer to chapter “ 11.2.9 “Debugger reset (DBRES)” on page 410 for details.

(7) Software controlled resets

SWRES A software reset can be generated by use of the software reset control register SWRESA. Refer to section 11.2.7 “Software reset (SWRES)” on page 410 for details.

(8) Power supply supervision

Several circuits observe the level of the external power supply REG0VDD and generate different actions, depending on REG0VDD level.

Power-On Clear The Power-On-Clear circuit (POC) permanently compares the power supply voltage VDD with an internal reference voltage. It ensures that the microcontroller only operates as long as the power supply exceeds a well-defined limit. Refer to section 11.2.2 “Power-On Clear (POC)” on page 403 for details.

Low-Voltage Indicator The Low-Voltage Indicator (LVI) generates the LVIRES reset, if the voltage level of REG0VDD drops below a certain level. The level can be adjusted and the LVIRES can be masked. Refer to section 11.2.3 “Low-Voltage Indicator (LVI)” on page 404 for details.

Very-Low-Voltage Indicator The Very-Low-Voltage Indicator (VLVI) flag VLVF.VLVF0 indicates, that REG0VDD dropped below a certain level and retention of the microcontroller’s on-chip Back-up RAMs (BURAM) content is not guaranteed. Refer to section 11.3.6 “Very Low-Voltage flag control registers” on page 417 for details.

11.2 Functional Description

11.2.1 Reset flags

The reset flag register RESF provides reset flags for each reset source.

If a reset has occurred, the assigned flag is set. This way the source of the reset can be evaluated.

All flags in RESF are not cleared, except by a power-up reset PURES (POCRES or DBRES). Thus this register behaves cumulative: each reset source sets its own flag, independent of all others.

11.2.2 Power-On Clear (POC)

The Power-On-Clear circuit (POC) permanently compares the power supply voltage REG0VDD with the internal reference voltage V_{POC} . It ensures that the microcontroller only operates as long as the power supply exceeds a well-defined limit.

If REG0VDD falls below the internal reference voltage ($REG0VDD < V_{POC}$), the internal reset signal POCRES, and thus a power-up reset PURES and the system reset SYSRES are generated.

Refer to the Data Sheet for the specification of the internal voltage reference level V_{POC} .

Clock generator reset The Power-On-Clear reset POCRES resets also some clock generators via PURES. Hence these clock generators stop operation and must be restarted. Refer to chapter “Clock Controller” for detailed information, which clock generators are stopped by POCRES, respectively PURES.

At Power-On Clear reset, the reset status flag register RESF is cleared.

The Power-On-Clear function holds the microcontroller in reset state as long as the power supply voltage REG0VDD does not exceed the threshold level V_{POC} .

The following figure illustrates the timing of a POCRES.




Figure 11-2 POC reset timing

Delay A delay time is induced between REG0VDD crossing the V_{POC} level and assertion of POCRES. Refer to the Data Sheet for the delay time specification.

11.2.3 Low-Voltage Indicator (LVI)

The Low-Voltage Indicator circuit (LVI) permanently compares the power supply voltage REG0VDD with the LVI internal reference voltage V_{LVI} .

If REG0VDD falls below the internal reference voltage ($REG0VDD < V_{LVI}$), the internal reset signal $\overline{LVIRE\overline{S}}$, the interrupt INTLVI, and the system reset SYSRES are generated.

Additionally the $\overline{LVIRE\overline{S}}$ flag RESF.RESF7 is set.

RESF.RESF7 is not cleared automatically, if REG0VDD exceeds V_{LVI} . It is cleared by

- setting RESFC.RESFC7 = 1
- power-up reset PURES (POCRES or DBRES)

LVI reference voltage The LVI reference voltage V_{LVI} can be selected from 6 different levels by LVICNT.LVICNT[2:0]. If LVICNT.LVICNT[2:0] is set to 00_B, the LVI is disabled. Refer to the Data Sheet for the specification of the internal voltage reference levels V_{LVI} .

LVI interrupt The LVI interrupt INTLVI is asserted if

- REG0VDD falls below the reference voltage ($REG0VDD < V_{LVI}$)
- REG0VDD rises above the reference voltage ($REG0VDD > V_{LVI}$)

The INTLVI interrupt can be used as a wake-up source from any stand-by mode. Refer to the chapter 8 “Stand-by Controller (STBC)” on page 322 for details.

$\overline{LVIRE\overline{S}}$ mask Generation of the $\overline{LVIRE\overline{S}}$ can be disabled:

- LVICNT.LVIRESMSK = 0: $\overline{LVIRE\overline{S}}$ not masked (enabled)
- LVICNT.LVIRESMSK = 1: $\overline{LVIRE\overline{S}}$ masked (disabled)

The following figure illustrates the timing of a $\overline{LVIRE\overline{S}}$ and RESF.RESF7.




Figure 11-3 LVI reset and interrupt timing

Delay A delay time is induced between REG0VDD crossing the V_{LVI} level and assertion of \overline{LVIRES} respectively setting of RESF.RESF7. Refer to the Data Sheet for the delay time specification.

11.2.4 Very-Low-Voltage Indicator (VLVI)

The Very-Low-Voltage Indicator circuit (VLVI) permanently compares the power supply voltage REG0VDD with the VLVI internal reference voltage V_{VLVI} .

Refer to the Data Sheet for the specification of the internal voltage reference level V_{VLVI} .

BURAM content retention If the power supply voltage REG0VDD does not fall below V_{VLVI} , the content of the on-chip Back-up RAMs (BURAM) is retained and must not be restored. If REG0VDD falls below V_{VLVI} the BURAM content must be assumed to have altered. Thus the entire BURAM must be restored before continuing.

If REG0VDD falls below the internal reference voltage ($REG0VDD < V_{VLVI}$), the flag VLVF.VLVF0 is set.

VLVF.VLVF0 is not cleared automatically, if REG0VDD exceeds V_{VLVI} . It is cleared by

- setting VLVFC.VLVFC0 = 1

Note VLVF.VLVF0 is not affected by any reset.

The following figure illustrates the timing of VLVF.VLVF0.




Figure 11-4 VLVI timing

- <1> REG0VDD exceeds: V_{VLVI} -> VLVF.VLVF0 = 1
- <2> POCRES is released, because REG0VDD exceeds V_{POC} , VLVF.VLVF0 = 1 indicates, that the BURAM is not initialized
- <3> VLVF.VLVF0 = 0 must be set by software
- <4> to <5> While REG0VDD remains below Power-On-Clear voltage V_{POC} , POCRES is asserted
- <6> REG0VDD drops below Power-On-Clear voltage V_{POC} , POCRES is asserted

- <7> REG0VDD drops below V_{VLVI} -> VLVF.VLVF0 = 1
- <8> Though REG0VDD rises above V_{VLVI} , VLVF.VLVF0 stays 1
- <9> REG0VDD rises above V_{POC} , POCRES is de-asserted
- <10> VLVF.VLVF0 = 0 must be set by software

Delay A delay time is induced between REG0VDD crossing the V_{VLVI} level setting of VLVF.VLVF0.
Refer to the Data Sheet for the delay time specification.

11.2.5 External $\overline{\text{RESET}}$

Reset is performed when a low level signal is applied to the $\overline{\text{RESET}}$ pin.

Additionally the $\overline{\text{RESET}}$ flag RESF.RESF8 is set.

RESF.RESF8 is not cleared automatically, if $\overline{\text{RESET}}$ is de-asserted. It is cleared by

- setting RESFC.RESFC8 = 1
- power-up reset PURES (POCRES or DBRES)

The $\overline{\text{RESET}}$ is passed through an analog noise filter to prevent erroneous resets due to noise.

The following figure shows the timing when an external reset is performed. It explains the effect of the noise eliminator.




Figure 11-5 External $\overline{\text{RESET}}$ timing

The analog delay is caused by the analog filter. The filter regards pulses up to a certain width as noise and suppresses them.

For the minimum $\overline{\text{RESET}}$ pulse width refer to the Data Sheet.

(1) MainOsc during $\overline{\text{RESET}}$

During assertion of the external $\overline{\text{RESET}}$ the MainOsc is operating with its maximum amplification gain, provided its power supply is active.

The figure below shows the behaviour of the MainOsc under different circumstances, in particular in relation to the power-up reset PURES.

PURES The power-up reset PURES is activated by the Power-On-Clear reset POCRES or the debugger reset DBRES.
Note that the MainOsc is disabled after a PURES.

MainOsc status The figure shows the MainOsc status as follows:

- max = maximum amplification gain, which means short stabilization mode (MainOsc control register MOSCC.MOSCCSHTSTBY = 1)
- norm = normal amplification gain, which means normal stabilization mode (MainOsc control register MOSCC.MOSCCSHTSTBY = 0)
- off = MainOsc is stopped

MainOsc start/stop The MainOsc is started respectively stop by software via the MainOsc enable register MOSCE as follows:

- S/W start: MOSCENTRG = 1
- S/W stop: MOSCEDISTRG = 1

For details concerning the MainOsc control and amplification gain refer to the description of the MainOsc and its control registers in the “Clock Controller” chapter.




Figure 11-6 MainOsc behaviour during $\overline{\text{RESET}}$

- <1> The MainOsc operates, as long as $\overline{\text{RESET}}$ stays active, even if PURES is deactivated before $\overline{\text{RESET}}$. However the MainOsc stops upon de-assertion of $\overline{\text{RESET}}$.
- <2> The MainOsc is started by S/W and stopped by PURES.
- <3> MainOsc is operating with maximum amplification gain during active $\overline{\text{RESET}}$.
- <4> The MainOsc is operating with normal amplification gain and it is set to maximum during active $\overline{\text{RESET}}$. After de-assertion of $\overline{\text{RESET}}$ the amplification gain returns to its previous level.
- <5> If the MainOsc was disabled, it operates with maximum amplification gain during active $\overline{\text{RESET}}$ and is stopped after de-assertion of $\overline{\text{RESET}}$.

11.2.6 Watchdog Timers reset (WDTAnRES)

The Watchdog Timers can be configured to generate a reset if the watchdog time expires. After watchdog reset, the Watchdog Timer reset flags RESF.RESF1 for WDTA0RES respectively RESF.RESF2 for WDTA1RES are set and the system reset SYSRES is asserted.

RESF.RESF1 (RESF.RESF2) is not cleared automatically, if WDTA0RES (WDTA1RES) is de-asserted. It is cleared by

- setting RESFC.RESFC1 = 1 (RESFC.RESFC2 = 1)
- power-up reset PURES (POCRES or DBRES)

11.2.7 Software reset (SWRES)

The software reset SWRES can be asserted by setting SWRESA.SWRESA0 = 1.

This generates a system reset SYSRES and sets the reset flag RESF.RESF0 = 1.

RESF.RESF0 is not cleared automatically. It is cleared by

- setting RESFC.RESFC0 = 1
- power-up reset PURES (POCRES or DBRES)

11.2.8 Clock Monitors reset ($\overline{\text{CLMA}n\text{RES}}$)

The Clock Monitors can generate the resets:

- $\overline{\text{CLMA}0\text{RES}}$, if a MainOsc fail is detected
- $\overline{\text{CLMA}2\text{RES}}$, if a High Speed IntOsc fail is detected
- $\overline{\text{CLMA}3\text{RES}}$, if a PLL0 fail is detected

Upon a Clock Monitor reset, the system reset SYSRES is generated and the respective reset flag in the RESF register is set.

These flags are not cleared automatically. They are cleared by

- setting RESFC.RESFC3 = 1 for $\overline{\text{CLMA}0\text{RES}}$, (RESFC.RESFC5 = 1 for $\overline{\text{CLMA}2\text{RES}}$, RESFC.RESFC6 = 1 for $\overline{\text{CLMA}3\text{RES}}$)
- power-up reset PURES (POCRES or DBRES)

11.2.9 Debugger reset (DBRES)

In case a debugger is connected, it can generate the reset DBRES.

DBRES activates the power-up reset PURES, thus operates in the same way like the Power-On-Clear reset POCRES:

- It resets some clock generators. Hence these clock generators stop operation and must be restarted.
- The reset status flag register RESF is cleared.

11.3 Reset Controller Registers

This section contains a description of all registers of the Reset Controller.

11.3.1 Writing to protected registers

Write protected registers are protected from inadvertent write access due to erroneous program execution, etc.

Following Reset Controller registers feature this special write protection:

- Software reset register SWRESA

Refer to the section 3.11 “Write protected Registers” on page 135 for a detailed description how to write to write protected registers.

11.3.2 Reset Controller registers overview

The Reset Controller is controlled and operated by the following registers:

Table 11-1 Reset Controller registers overview

Register name	Shortcut	Address
General reset flags registers		
Reset factor register	RESF	FF42 0160 _H
Reset factor clear register	RESFC	FF42 0168 _H
Software reset control registers		
Software reset register	SWRESA	FF42 0204 _H
Low-Voltage Indicator reset control registers		
LVI control register	LVICNT	FF42 0200 _H
Very-Low-Voltage flag control registers		
VLVF register	VLVF	FF42 0180 _H
VLVF clear register	VLVFC	FF42 0188 _H

11.3.3 Reset Controller general control registers details

(1) RESF- Reset factor register

This register contains information about which type of resets occurred since the last Power-On Clear reset.

Each reset condition sets the corresponding flag in the register.

For example, if a Clock Monitor $\overline{\text{CLMA0RES}}$ occurs after a Watchdog Timer reset $\overline{\text{WDTA0RES}}$, RESF reads 0000 000A_H.

Access This register can be read in 32-bit units.

Address FF42 0160_H

Initial Value 0000 0000_H. This register is initialized by a power-up reset PURES (POCRES and DBRES).

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	RES F8	RES F7	RES F6	RES F5	0	RES F3	RES F2	RES F1	RES F0
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Table 11-2 RESF register contents (1/2)

Bit position	Bit name	Function
8	RESF8	External reset flag 0: no RESET reset occurred 1: RESET reset has occurred Note: In case of concurrently asserted power-up reset PURES and external RESET, setting of the RESF.RESF8 flag, that indicates the occurrence of an external RESET, depends on the time relation between PURES and the RESET. Refer to the Electrical Target Specification for details.
7	RESF7	Low-Voltage Indicator reset flag 0: no LVIRESET reset occurred 1: LVIRESET reset has occurred
6	RESF6	PLL0 Clock Monitor CLMA3 reset flag 0: no CLMA3RES reset occurred 1: CLMA3RES reset has occurred
5	RESF5	High Speed IntOsc Clock Monitor CLMA2 reset flag 0: no CLMA2RES reset occurred 1: CLMA2RES reset has occurred
3	RESF3	MainOsc Clock Monitor CLMA0 reset flag 0: no CLMA0RES reset occurred 1: CLMA0RES reset has occurred

Table 11-2 RESF register contents (2/2)

Bit position	Bit name	Function
2	RESF2	Watchdog Timer WDTA1 reset flag 0: no WDTA1RES reset occurred 1: WDTA1RES reset has occurred
1	RESF1	Watchdog Timer WDTA0 reset flag 0: no WDTA0RES reset occurred 1: WDTA0RES reset has occurred
0	RESF0	Software reset flag 0: no SWRES reset occurred 1: SWRES reset has occurred

(2) RESFC - Reset factor clear register

This register clears the reset flags of the RESF register.

Access This register can be read/written in 32-bit units.
Reading this register returns always 0000 0000_H.

Address FF42 0168_H

Initial Value Reading this registers returns always 0000 0000_H.

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	RES FC8	RES FC7	RES FC6	RES FC5	0	RES FC3	RES FC2	RES FC1	RES FC0
R	R	R	R	R	R	R	R/W	R/W	R/W	R/W	R	R/W	R/W	R/W	R/W

Table 11-3 RESFC register contents

Bit position	Bit name	Function
8	RESFC8	External reset flag RESF.RESF8 flag clear 0: no function 1: clear RESF.RESF8
7	RESFC7	Low-Voltage Indicator reset flag RESF.RESF7 flag clear 0: no function 1: clear RESF.RESF7
6	RESFC6	PLL0 Clock Monitor CLMA3 reset flag RESF.RESF6 flag clear 0: no function 1: clear RESF.RESF6
5	RESFC5	High-Speed IntOsc Clock Monitor CLMA2 reset flag RESF.RESF5 flag clear 0: no function 1: clear RESF.RESF5
3	RESFC3	MainOsc Clock Monitor CLMA0 reset flag RESF.RESF3 flag clear 0: no function 1: clear RESF.RESF3
2	RESFC2	Watchdog Timer WDTA1 reset flag RESF.RESF2 flag clear 0: no function 1: clear RESF.RESF2
1	RESFC1	Watchdog Timer WDTA0 reset flag RESF.RESF1 flag clear 0: no function 1: clear RESF.RESF1
0	RESFC0	Software reset flag RESF.RESF0 flag clear 0: no function 1: clear RESF.RESF0

11.3.4 Software reset control registers details

(1) SWRESA - Software reset register

This register is used to generate a software reset SWRES.

Protection Writing to this register is protected by a special sequence of instructions by using the protection command register PROTCMD2. Refer to the section “*Write protected Registers*” in chapter “*CPU System Functions*” for a detailed description how to write protected registers.

Access This register can be read/written in 32-bit units. Reading this register returns always 0000 0000_H.

Address FF42 0204_H

Initial Value Reading this registers returns always 0000 0000_H.

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	SW RESA0
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R/W

Table 11-4 SWRESA register contents

Bit position	Bit name	Function
0	SWRESA0	Software reset control 0: no function 1: generate software reset SWRES

11.3.5 Low-Voltage Indicator reset control registers

(1) LVICNT - LVI control register

This register is used to control the Low-Voltage Indicator and to select the LVI detection level.

Protection Writing to this register is protected by a special sequence of instructions by using the protection command register PROTCMD2. Refer to the section “Write protected Registers” in chapter “CPU System Functions” for a detailed description how to write to protected registers.

Access This register can be read/written in 32-bit units.

Address FF42 0200_H

Initial Value 0000 0000_H. This register is initialized by a power-up reset PURES (POCRES and DBRES).

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	0	0	0	0	LVIRE SMK	LVICNT[2:0]		
R	R	R	R	R	R	R	R	R	R	R	R	R/W	R/W	R/W	R/W

Table 11-5 LVICNT register contents

Bit position	Bit name	Function																
3	LVIRESMK	LVI reset LVIRESMK mask 0: LVIRESMK unmasked 1: LVIRESMK masked (LVIRESMK is not generated)																
2 to 0	LVICNT[2:0]	LVI detection level <table border="1"> <thead> <tr> <th>LVICNT[2:0]</th><th>Detection level</th></tr> </thead> <tbody> <tr> <td>000_B</td><td>LVI is deactivated</td></tr> <tr> <td>001_B</td><td>LVI level 1 (VLVIL₁)</td></tr> <tr> <td>010_B</td><td>LVI level 2 (VLVIL₂)</td></tr> <tr> <td>011_B</td><td>LVI level 3 (VLVIL₃)</td></tr> <tr> <td>100_B</td><td>LVI level 4 (VLVIL₄)</td></tr> <tr> <td>101_B</td><td>LVI level 5 (VLVIL₅)</td></tr> <tr> <td>11X_B</td><td>LVI level 6 (VLVIL₆)</td></tr> </tbody> </table> <p>Refer to the Data Sheet for the specification of the LVI detection levels.</p>	LVICNT[2:0]	Detection level	000 _B	LVI is deactivated	001 _B	LVI level 1 (VLVIL ₁)	010 _B	LVI level 2 (VLVIL ₂)	011 _B	LVI level 3 (VLVIL ₃)	100 _B	LVI level 4 (VLVIL ₄)	101 _B	LVI level 5 (VLVIL ₅)	11X _B	LVI level 6 (VLVIL ₆)
LVICNT[2:0]	Detection level																	
000 _B	LVI is deactivated																	
001 _B	LVI level 1 (VLVIL ₁)																	
010 _B	LVI level 2 (VLVIL ₂)																	
011 _B	LVI level 3 (VLVIL ₃)																	
100 _B	LVI level 4 (VLVIL ₄)																	
101 _B	LVI level 5 (VLVIL ₅)																	
11X _B	LVI level 6 (VLVIL ₆)																	

Note If the selected LVI detection level is close to the Power-On-Clear detection level, both may detect low voltage at the same time. In this case the Power-On-Clear reset POCRES is performed and the reset factor register RESF is cleared. Thus the LVI reset flag RESF.RESF7 does not indicate the LVI detection.

11.3.6 Very Low-Voltage flag control registers

(1) VLVF - Very-Low-Voltage flag register

This register shows the status of the VLVF detection.

Access This register can be read in 32-bit units.

Address FF42 0180_H

Initial Value 0000 0001_H

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	VLVF0
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Table 11-6 VLVF register contents

Bit position	Bit name	Function
0	VLVF0	VLVI status 0: Very low voltage not detected 1: Very low voltage detected

(2) VLVFC - Very-Low-Voltage flag clear register

This register clears the VLVF0 flag of the VLVF register.

Access This register can be read/written in 32-bit units.
Reading this register returns always 0000 0000_H.

Address FF42 0188_H

Initial Value Reading this registers returns always 0000 0000_H.

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	VLVFC0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 11-7 VLVFC register contents

Bit position	Bit name	Function
0	VLVFC0	VLVI flag VLVF.VLVF0 flag clear 0: no function 1: clear VLVF.VLVF0

Chapter 12 OS Timer (OSTM)

This chapter contains a generic description of the OS Timer.

The first section describes all properties specific to the V850E2/Fx4-G, such as instances, register base addresses, input/output signal names, etc. The subsequent sections describe the features that apply to all implementations.

12.1 V850E2/Fx4-G OSTM Features

Instances This microcontroller has the following number of instances of the OS Timer.

Table 12-1 Instances of OS Timer

OS Timer	
Instances	1
Names	OSTM0

Instances index n Throughout this chapter, the individual instances of the OS Timer are identified by the index “n” (n = 0), for example OSTMnCTL for the OS Timer n control register.

Register addresses All OS Timer register addresses are given as address offsets from the individual base addresses <OSTMn_base>. The <OSTMn_base> addresses of each OSTMn are listed in the following table:

Table 12-2 Register base addresses <OSTMn_base>

OSTMn instance	<OSTMn_base> address
OSTM0	FF80 0000 _H

Clock supply All OS Timers provide one clock input.

Table 12-3 OSTM clock supply

OSTMn instance	OSTMn clock	Connected to
OSTM0	PCLK	Clock Controller CKSCLK_032




Figure 12-1 OSTM clock supply

Interrupts The OS Timers can generate the following interrupt requests:

Table 12-4 OSTMn interrupt requests

OSTMn signals	Function	Connected to
OSTM0TINT	OSTMn interrupt	Interrupt Controller INTOSTM0

OSTM H/W reset The OS Timers and their registers are initialized by the following reset signal:

Table 12-5 OSTMn reset signal

OSTMn	Reset signal
OSTM0	<ul style="list-style-type: none"> Reset Controller SYSRES Stand-by Controller DPSTPWU (wake-up from DEEPSTOP mode)

12.2 Functional Overview

Features summary The OS Timer has two operation modes

- Interval timer mode
- Free-run compare mode

The following block diagram shows the main components of the OS Timer.




Figure 12-2 Block diagram of the OS Timer

12.3 Functional Description

The OS Timer is a 32-bit timer/counter.

It can be used as an interval timer or in free-run compare mode. The selected operation mode specifies the count direction and controls the interrupt request generation.

12.3.1 Count clock

The count clock of the OS Timer is defined by PCLK clock input. This is illustrated in the following figures.




Figure 12-3 Counter operation

12.3.2 Interrupt request generation

By default, interrupt request OSTMnTINT is generated on counter underflow (interval timer mode) or when the counter matches the compare value (free-run compare mode).

Additionally, an interrupt request can be generated at counter start or counter restart. This is controlled by bit OSTMnCTL.OSTMnMD0.

This is illustrated in the following figure.




Figure 12-4 Interrupt generation at count start

12.3.3 Starting and stopping the timer

The OS Timer is started and stopped as follows:

Start The timer is started by setting the bit OSTMnTS.OSTMnTSF = 1 or Status bit OSTMnTE.OSTMnTEF is set to 1 and bit OSTMnTS.OSTMnTSF returns to zero.

Depending on the operation mode, the counter starts to count down or to count up. Refer to 12.3.4 "Interval timer mode" on page 422 and 12.3.5 "Free-run compare mode" on page 426 for details.

Stop The timer is stopped by setting the bit OSTMnTT.OSTMnTTF = 1. Status bit OSTMnTE.OSTMnTEF is cleared and bit OSTMnTT.OSTMnTTF immediately returns to zero.

When the counter is stopped, the register OSTMnCNT holds its current value until a new count operation starts.

12.3.4 Interval timer mode

In interval timer mode, the OSTM can be used as a reference timer generating interrupt requests at fixed intervals.

(1) Basic operation in interval timer mode

In interval timer mode, the timer counts down, starting from the value specified in the OSTMnCMP register. When the counter underflows ($0000\ 0000_H$ is reached), an interrupt request OSTMnTINT is generated.

The interval timer mode is set by OSTMnCTL.OSTMnMD1 = 0.

The OSTMnCMP register can be rewritten at any time. If it is rewritten during count operation, the counter loads the new OSTMnCMP value when the next $0000\ 0000_H$ is reached. Then the counter continues with the new value.

OSTMnTINT period The period of OSTMnTINT is:

- OSTMnTINT occurrence period = count clock period * (OSTMnCMP + 1)

The following figure shows the basic operation of the OS Timer in interval timer mode with counter start interrupt enabled (OSTMnCTL.OSTMnMD0 = 1):




Figure 12-5 Timing diagram of OSTM in interval timer mode

- (1) After counter start (OSTMnTS.OSTMnTSF = 1), the OSTMnTE.OSTMnTEF bit is set to indicate that the counter is enabled. OSTMnTS.OSTMnTSF returns to 0 in order to start the timer. The counter counts down starting from the value of OSTMnCMP. The counter value is indicated in register OSTMnCNT. OSTMnTINT is asserted.
- (2) When the counter reaches $0000\ 0000_H$, the interrupt request OSTMnTINT is asserted. The counter loads the new start value from OSTMnCMP and continues to count down.
- (3) At counter stop (OSTMnTT.OSTMnTTF = 1), the OSTMnTE.OSTMnTEF bit is cleared to indicate that the counter is disabled. OSTMnTT.OSTMnTTF returns to 0. The counter holds its current value until the counter is restarted.
- (4) If the counter is restarted (OSTMnTS.OSTMnTSF = 1), the counter loads the new start value from OSTMnCMP and continues to count down.

Forced restart A forced restart of the counter is performed by setting $OSTMnTS.OSTMnTSF = 1$ during the count operation.

The counter loads the start value from the $OSTMnCMP$ register and continues to count down.

The following figure shows the forced restart of the OS Timer in interval timer mode, with counter start interrupt enabled ($OSTMnCTL.OSTMnMD0 = 1$):




Figure 12-6 Timing diagram of forced restart in interval timer mode

The timing diagram above shows the following:

- (1) The counter is started and stopped as shown and explained in *Figure 12-5* "Timing diagram of OSTM in interval timer mode" on page 423.
- (2) The counter is started again ($OSTMnTS.OSTMnTSF = 1$), while it is operating ($OSTMnTE.OSTMnTEF = 1$). The counter immediately restarts counting down, starting with the current value of $OSTMnCMP$. The interrupt request $OSTMnTINT$ is asserted.

(2) Operation when OSTMnCMP = 0000 0000_H

When OSTMnCMP = 0000 0000_H the OSTMnTINT interrupt request is set to 1, while the counter is enabled.

The following figure shows the operation of the OS Timer, when OSTMnCMP = 0000 0000_H, counter start interrupt is enabled (OSTMnCTL.OSTMnMD0 = 1):




Figure 12-7 Timing diagram when OSTMnCMP = 0000 0000_H in interval timer mode

The timing diagram above shows the following:

- (1) After counter start, the counter starts counting, but will be reloaded with the OSTMnCMP value, and thus remains 0000 0000_H.
- (2) The interrupt request OSTMnTINT is continuously asserted.
- (3) After counter stop, the interrupt request OSTMnTINT is deasserted.

(3) Initialization for interval timer mode

The setting procedure in interval timer mode after a reset release is described below:

- Initialization**
1. Set the start value of the down-counter in the OSTMnCMP register.
 2. Select the interval timer mode by clearing bit OSTMnCTL.OSTMnMD1.
 3. Select the interrupt mode at counter start (OSTMnCTL.OSTMnMD0).

12.3.5 Free-run compare mode

(1) Basic operation in free-run compare mode

In free-run compare mode, the counter counts up from 0000 0000_H to FFFF FFFF_H. When the value of the OSTMnCMP register matches the current count value, the OSTMnTINT interrupt request is output.

The free-run compare mode is selected by setting OSTMnCTL.OSTMnMD1 = 1.

The OSTMnCMP register can be rewritten at any time.

The following figure shows the basic operation of the OS Timer in free-run compare mode with counter start enabled (OSTMnCTL.OSTMnMD0 = 1):




Figure 12-8 Timing diagram of OSTM in free-run compare mode

The timing diagram above shows the following:

- (1) After counter start (OSTMnTS.OSTMnTSF = 1), the OSTMnTE.OSTMnTEF bit is set to indicate that the counter is enabled. OSTMnTS.OSTMnTSF returns to 0 in order to start the counter. The counter counts up from 0000 0000_H to FFFF FFFF_H. The counter value is indicated in register OSTMnCNT.
- (2) When the value of the OSTMnCMP register matches the current count value, the interrupt request OSTMnTINT is asserted.
- (3) At counter stop (OSTMnTT.OSTMnTTF = 1), the OSTMnTE.OSTMnTEF bit is cleared to indicate that the counter is disabled. OSTMnTT.OSTMnTTF returns to 0. The counter holds its current value until the counter is restarted.
- (4) If the counter is restarted (OSTMnTS.OSTMnTSF = 1), the counter starts counting from 0000 0000_H.

The OSTMnTINT occurrence period is different at count start and depends on the old and new compare value if OSTMnCMP is rewritten during operation:

Table 12-6 OSTMnTINT occurrence timing

Old compare	New compare	Counter value at time of rewrite	OSTMnTINT occurrence period	Label in timing diagram
Counter start			$(A + 1) * \text{count clock period}$	(a)
A	A	No rewrite	$(\text{FFFF FFFF}_H + 1) * \text{count clock period}$	(b)
B	$C > B$	$B < \text{counter value} < C$	$(C - B) * \text{count clock period}$	(c)
C	$D < C$	Counter value $> D, C$	$(\text{FFFF FFFF}_H - C + D + 1) * \text{count clock period}$	(d)

Forced restart A forced restart operation is not performed even if the bit OSTMnTS.OSTMnTSF is set during the count operation. The counter ignores this setting and continues counting.

(2) Operation when OSTMnCMP = 0000 0000_H

The following figure shows the operation of the OS Timer when OSTMnCMP = 0000 0000_H, counter start interrupt is enabled (OSTMnCTL.OSTMnMD0 = 1).




Figure 12-9 Timing diagram when OSTMnCMP = 0000 0000_H in free-run compare mode

The timing diagram above shows the following:

- (1) After counter start, the counter starts counting up from 0000 0000_H to FFFF FFFF_H.
- (2) The interrupt request OSTMnTINT at counter start is generated.
- (3) If the current count value matches OSTMnCMP, the compare interrupt is generated. In the above case with OSTMnCMP = 0000 0000_H, OSTMnTINT stays active for 2 PCLK periods.
- (4) Every FFFF FFFF_H clock cycles the interrupt request OSTMnTINT is asserted.

(3) Initialization for free-run compare mode

The setting procedure in free-run compare mode after a reset release is described below:

- Initialization**
1. Set the compare value in the OSTMnCMP register.
 2. Select the free-run compare mode by setting the bit OSTMnCTL.OSTMnMD1.
 3. Select the interrupt mode at counter start by the bit OSTMnCTL.OSTMnMD0.

12.4 OS Timer Registers

This section contains a description of all registers of the OS Timer.

12.4.1 OS Timer registers overview

The OS Timer is controlled and operated by the following registers:

Table 12-7 OS Timer registers overview

Register name	Shortcut	Address
OSTM compare register	OSTMnCMP	<OSTMn_base>
OSTM counter register	OSTMnCNT	<OSTMn_base> + 4 _H
OSTM count enable status register	OSTMnTE	<OSTMn_base> + 10 _H
OSTM count start trigger register	OSTMnTS	<OSTMn_base> + 14 _H
OSTM count stop trigger register	OSTMnTT	<OSTMn_base> + 18 _H
OSTM control register	OSTMnCTL	<OSTMn_base> + 20 _H
OSTM emulation register	OSTMnEMU	<OSTMn_base> + 24 _H

<OSTMn_base> The base addresses <OSTMn_base> of the OSTMn is defined in the first section of this chapter under the key word "Register addresses".

12.4.2 OS Timer registers details

(1) OSTMnCMP - OSTM compare register

This register stores the start value of the down-counter or the value with which the counter is compared, depending on the operation mode.

Access This register can be read/written in 32-bit units.

Address <OSTMn_base>

Initial Value 0000 0000_H

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
OSTMnCMP[31:16]															
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
OSTMnCMP[15:0]															
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 12-8 OSTMnCMP register contents

Bit position	Bit name	Function
31 to 0	OSTMnCMP[31:0]	<ul style="list-style-type: none"> In interval timer mode: start value of the down-counter In free-run compare mode: compare value

(2) OSTMnCNT - OSTM counter register

This register indicates the count value of the timer.

Access This register can be read in 32-bit units.

Address <OSTMn_base> + 4_H

Initial Value The initial value depends on the operation mode of the OS Timer, see *Table 12-10 "Correlation between operation mode, counting direction and initial value" on page 430*.

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
OSTMnCNT[31:16]															
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
OSTMnCNT[15:0]															
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Table 12-9 OSTMnCNT register contents

Bit position	Bit name	Function
31 to 0	OSTMnCNT[31:0]	32-bit counter value

The following table shows the correlation between operation mode, counting direction and initial value. The initial value is the value that is read after the operating mode has been changed.

Table 12-10 Correlation between operation mode, counting direction and initial value

Timer operation mode	OSTMnCTL.OSTMnMD1	Counting direction	Initial value
Interval Timer Mode	0 ^a	Down	FFFF FFFF _H
Free Running Compare Mode	1	Up	0000 0000 _H

^{a)} Value after reset.

(3) OSTMnTE - OSTM count enable status register

This register indicates whether the counter is enabled or disabled.

Access This register can be read in 8-bit units.

Address <OSTMn_base> + 10_H

Initial Value 00_H

7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	OSTMn TEF
R	R	R	R	R	R	R	R

Table 12-11 OSTMnTE register contents

Bit position	Bit name	Function
0	OSTMn TEF	Indicates, whether the counter is enabled or disabled: 0: Counter disabled 1: Counter enabled Setting OSTMnTS.OSTMnTSF to 1 sets this bit to 1. Setting OSTMnTT.OSTMnTTF to 1 resets this bit to 0.

Note If the counter is disabled, the counter value OSTMnCNT remains its value.

If the counter is restarted again, it

- continues with this value in interval timer mode.
- restarts with count value 0000 0000_H in free-run compare mode.

(4) OSTMnTS - OSTM count start trigger register

This register starts the counter.

Access This register can be written in 8-bit units. It is always read as 00_H.

Address <OSTMn_base> + 14_H

Initial Value 00_H

7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	OSTMn TSF
R	R	R	R	R	R	R	W

Table 12-12 OSTMnTS register contents

Bit position	Bit name	Function
0	OSTMn TSF	Starts the counter: 0: No function 1: Starts the counter and sets OSTMnTE.OSTMnTEF = 1. When the counter is enabled, this bit returns to 0. • In interval timer mode, forced restart is executed when this bit is set while OSTMnTE.OSTMnTEF = 1. • In free-run compare mode, setting this bit is ignored while OSTMnTE.OSTMnTEF = 1.

(5) OSTMnTT - OSTM count stop trigger register

This register stops the counter.

Access This register can be written in 8-bit units. It is always read as 00_H.

Address <OSTMn_base> + 18_H

Initial Value 00_H

7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	OSTMn TTF
R	R	R	R	R	R	R	W

Table 12-13 OSTMnTT register contents

Bit position	Bit name	Function
0	OSTMn TTF	Stops the counter: 0: No function 1: Stops the counter and clears the bit OSTMnTE.OSTMnTEF. When the counter has stopped, this bit returns to 0.

(6) OSTMnCTL - OSTM control register

This register specifies the counter operation mode and controls the generation of the interrupt request OSTMnTINT at counter start.

Access This register can be read/written in 8-bit units. It can only be written when the counter is disabled (OSTMnTE.OSTMnTEF = 0).

Address <OSTMn_base> + 20_H

Initial Value 00_H

7	6	5	4	3	2	1	0
0	0	0	0	0	0	OSTMn MD1	OSTMn MD0
R	R	R	R	R	R	R/W	R/W

Table 12-14 OSTMnCTL register contents

Bit position	Bit name	Function
1	OSTMnMD1	Specifies the counter operation mode: 0: Interval timer mode 1: Free-run compare mode
0	OSTMnMD0	Controls the OSTMnTINT interrupt request at counter start: 0: Disables interrupt at counter start 1: Enables interrupt at counter start

(7) OSTMnEMU - OSTMn emulation register

This register controls whether the OSTMn can be stopped during emulation, for instance upon a breakpoint hit.

Access This register can be read/written in 8-bit units.

Address <OSTMn_base> + 24_H

Initial Value 0000_H

	7	6	5	4	3	2	1	0
OSTMn SVSDIS	0	0	0	0	0	0	0	0
	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 12-15 OSTMnEMU register contents

Bit position	Bit name	Function
7	OSTMn SVSDIS	Emulation control 0: OSTMn can be stopped during emulation 1: OSTMn continuous operating during emulation

Chapter 13 Window Watchdog Timer A (WDTA)

This chapter contains a generic description of the Window Watchdog Timer A (WDTA).

The first section describes all properties specific to the V850E2/Fx4-G, such as instances, register base addresses, input/output signal names, etc. The subsequent sections describe the features that apply to all implementations.

13.1 V850E2/Fx4-G WDTA Features

Instances This microcontroller has the following number of instances of the Window Watchdog Timer A.

Table 13-1 Instances of WDTA

Window Watchdog Timer A	
Instances	2
Names	WDTA0, WDTA1

Instances index n Throughout this chapter, the individual instances of a Window Watchdog Timer A are identified by the index “n” (n = 0 to 1), for example, WDTAnWDTE for the WDTAn Watchdog Timer enable register.

Register addresses All WDTAn register addresses are given as address offsets from the individual base address <WDTAn_base>. The base address <WDTAn_base> of each WDTAn is listed in the following table:

Table 13-2 Register base addresses <WDTAn_base>

WDTAn instance	<WDTAn_base> address
WDTA0	FF80 6000 _H
WDTA1	FF80 7000 _H

Clock supply All Window Watchdog Timers A provide two clock inputs.

Table 13-3 WDTAn clock supply

WDTAn instance	WDTAn clock	Connected to
WDTA0	PCLK	Clock Generator CKSCLK_A02
	WDTATCKI	Clock Generator CKSCLK_A07
WDTA1	PCLK	Clock Generator CKSCLK_001
	WDTATCKI	Clock Generator CKSCLK_007




Figure 13-1 WDTA clock supply

Interrupts and reset outputs The interrupts and reset outputs of the WDTAn are listed in the table below.

Table 13-4 WDTA interrupts and reset outputs

WDTAn signals	Function	Connected to
WDTA0:		
WDTA0RES	WDTA0 error reset	Reset Controller WDTA0RES
WDTA0TNMI	WDTA0 error NMI	Interrupt Controller WDTA0TNMI ^a
INTWDT0	WDTA0 75% interrupt	Interrupt Controller INTWDT0 ^a
WDTA1:		
WDTA1RES	WDTA1 error reset	Reset Controller WDTA1RES
WDTA1TNMI	WDTA1 error NMI	Interrupt Controller WDTA1TNMI ^a
INTWDT1	WDTA1 75% interrupt	Interrupt Controller INTWDT1 ^a

a) These interrupts can be used as a wake-up source from any stand-by mode. Refer to the chapter “Stand-by Controller (STBC)” for details.

WDTA H/W reset The Window Watchdog Timers A and their registers are initialized by the following reset signal:

Table 13-5 WDTAn reset signal

WDTAn	Reset signal
WDTA0	<ul style="list-style-type: none"> Reset Controller SYSRES
WDTA1	<ul style="list-style-type: none"> Reset Controller SYSRES Stand-by Controller DPSTPWU (wake-up from DEEPSTOP mode)

WDTA during DEEPSTOP mode If the V850E2/Fx4-G enters the DEEPSTOP stand-by mode, WDTA0 remains in operation and would need to be retriggered, although the CPU is not operating.
In order to stop also WDTA0 during DEEPSTOP, its operation clock CKSCLK_A07 can be stopped by setting CKSC_A07.STPMK_A07 = 0.

WDTA during debugging When operating the V850E2/Fx4-G microcontroller under control of a debugger and the microcontroller is stopped, e.g. because of a breakpoint hit, the WDTA is stopped and all WDTA registers can not be written. In particular it is not possible to re-trigger the WDTA by the debugger's single-step execution.

13.2 WDTA Start-up Options

The start-up options determine the start-up configuration of the WDTA after reset release. They are described in the following table.

Table 13-6 WDTA start-up options

Start-up option	Function	Description	Connected to
OPWDEN	WDTA enabler/disabler	Enables/disables the WDTA: 0: WDTA is disabled 1: WDTA is enabled	<ul style="list-style-type: none"> WDTA0: Flash configuration option OPBT0.OPBT0[19] WDTA1: Flash configuration option OPBT0.OPBT0[23]
OPWDOVF[2:0]	Count clock setting	Specifies the reset value of the count clock control bits WDTAnMD.WDTAnOVF[2:0].	WDTA0/WDTA1: Flash configuration option OPBT0.OPBT0[18:16]
OPWDTPR	Start mode signal selector	Specifies the signal that sets the start mode: 0: OPWDRUN start-up option 1: WDTATRYP input signal If WDTATRYP is selected (OPWDTPR = 1), the start mode depends on the reset type. Refer to section "V850E2/Fx4-G WDTAn start modes" below and "WDTA after reset release" in the section "Functional Description" for details.	fixed to 0
OPWDRUN	Automatic start enabler	Specifies the start mode: 0: Software trigger start mode 1: Automatic start mode Refer to section "V850E2/Fx4-G WDTAn start modes" below and "WDTA after reset release" in the section "Functional Description" for details.	<ul style="list-style-type: none"> WDTA0: Flash configuration option OPBT0.OPBT0[20] WDTA1: Flash configuration option OPBT0.OPBT0[24]
OPWDWS[1:0]	Initial open window size setting	Specifies the reset value of the open window size control bits WDTAnMD.WDTAnWS[1:0]. The open window size control bits only apply after the first WDTA trigger and not after reset release. After reset release the open window size is 100%. Refer to "Window function" in the section "Functional Description" for details.	fixed to 11 _B
OPWDINT	INTWDTn (75% interrupt) request generation	Specifies the reset value of control bit WDTAnMD.WDTAnWIE. This bit enables/disables the output of the 75% interrupt request INTWDTn. Refer to "75% interrupt output" in the section "Functional Description" for details.	fixed to 0

13.2.1 V850E2/Fx4-G WDTA start modes

If a Watchdog Timer is enabled (OPWDEN = 1), its start mode depends on OPWDRUN:

- OPWDRUN = 0: software trigger mode
- OPWDRUN = 0: automatic start mode

Caution If the Watchdog Timer is disabled (OPWDEN = 0), it can not be enabled afterwards.

13.3 Functional Overview

Features summary The Window Watchdog Timer A has the following functions:

- Operation mode after reset selectable by using start-up options
- Fixed activation code and variable activation code (VAC) selectable
- Two start modes available:
 - Automatic start mode
 - Software trigger mode
- Reset-dependent start mode selection
- Operation upon error detection selectable:
 - Generation of NMI request WDTAnTNMI on error detection
 - Generation of reset WDTAnTRES on error detection
- Interrupt request generation at 75% of the counter overflow value
- Window function

The following figure shows the main components of the Window Watchdog Timer A:




Figure 13-2 Block diagram of the Window Watchdog Timer A

13.4 Functional Description

The Window Watchdog Timer A generates a reset or a non-maskable interrupt if the 16-bit counter overflows or if any other error condition is fulfilled.

For a description of all error conditions, refer to the section “*Error detection*”.

The counter is cleared and restarted every time a WDTA trigger occurs in the open window period.

Refer to the sections “*WDTA trigger*” and “*Window function*” for details.

At 75% of the maximum counter value, the WDTA can generate an interrupt request INTWDTn.

Refer to the section “*75% interrupt output*” for details.

After reset release, the start-up options specify the start mode and the WDTA settings. The settings can be modified by writing the Watchdog Timer mode register WDTAnMD.

Refer to the section “*WDTA after reset release*” for details.

13.4.1 WDTA after reset release

(1) Start modes

The WDTA provides two modes for the counter start after reset release:

- Software trigger start mode

The counter value remains 0000_H after reset release.

The counter is started with the first WDTA trigger.

The first trigger can occur any time after reset release.

- Automatic start mode

The counter starts automatically after reset release.

The first trigger must occur before the counter overflows.

(2) Start mode selection

The start mode can be selected as follows:

- By start-up options
- By the WDTATRTYP input signal

This signal indicates the reset type. Thus, the selected start mode after reset release depends on the reset type.

The start mode selection is listed in the following table.

Table 13-7 Start mode selection

Start-up options		Input signal	Reset type	Start mode
OPWDTPR	OPWDRUN	WDTATRTYP		
0	0	Ignored	Ignored	Software trigger
	1			Automatic
1	0	Ignored	Ignored	Software trigger
	1	0	Any apart from automatic start reset source	Software trigger
		1	Automatic start reset source	Automatic

(3) WDTA settings after reset release

The WDTA settings are as follows between reset release and the first trigger:

Function	Setting	Remark
Start mode	Specified by start-up options	For a description of the start modes, refer to the section "WDTA after reset release".
Count clock		
75% interrupt mode		
Error mode	Reset mode	Any error condition before the first trigger generates a reset.
Open window size	100%	If automatic start mode is specified, the first trigger is valid any time before the counter overflows.

Change WDTA settings

After the first trigger, the WDTA continues according to the settings of the Watchdog Timer mode register WDTAnMD.

To change the WDTA settings, WDTAnMD must be written *before* the first trigger. Changing the value of WDTAnMD *after* the first trigger leads to an error.

If WDTAnMD is not changed before the first trigger, the WDTA mode is specified by the initial value of WDTAnMD.

The new or initial value of WDTAnMD applies after the first trigger.

Automatic start mode timing

The automatic start mode timing and the changes to the WDTA settings are illustrated in the following figure.




Figure 13-3 Timing diagram of WDTA start in automatic start mode

The timing diagram above shows the following:

1. After reset release, the counter starts immediately.
The count clock is specified by the start-up options, for example:
 - Count clock after reset release = $WDTATCKI / 2^{13}$
(OPWDOVF[2:0] = 100_B)

2. WDTAnMD is written before the first trigger. However, the settings are not applied immediately.
3. The first trigger must occur before the counter overflows.
After the first trigger, the settings specified in WDTAnMD are applied, for example a new count clock:
 - Count clock after first trigger = $WDTATCKI / 2^{16}$
(WDTAnMD.WDTAnOVF[2:0] = 111_B)
 With the decreased count clock, the counter value rises more slowly over time.

Software trigger start mode timing

The software trigger start mode timing and the changes to the WDTA settings are illustrated in the following figure.




Figure 13-4 Timing diagram of WDTA start in software trigger start mode

The timing diagram above shows the following:

1. After reset release, the counter remains 0000_H until the first trigger. The count clock is specified by the start-up options, but it does not have any effect.
2. WDTAnMD is written before the first trigger. However, the settings are not applied immediately.
3. The counter starts at the first trigger. The count clock and other settings specified in WDTAnMD are applied.

13.4.2 WDTA trigger

The WDTA trigger has the following functions:

- Counter start trigger in software trigger start mode
- Counter restart trigger to avoid counter overflow

The trigger register to be used differs depending on whether the activation code is fixed or variable. The type of activation code and the associated trigger register are specified by using the start-up option OPWDVAC.

Table 13-8 Trigger register and activation code

Type of activation code	Trigger register	Activation code
Fixed	WDTAnWDTE	AC _H
Variable	WDTAnEVAC	Refer to the section “ <i>Varying Activation Code calculation</i> ” for details.

(1) Variable activation code calculation

The variable activation code (ExpectWDTE) is calculated using a reference value in register WDTAnREF. The reference value in WDTAnREF is updated each time the trigger register WDTAnEVAC is written.

- Use the expression below to calculate the variable activation code (ExpectWDTE):

$$\text{ExpectWDTE} = \text{AC}_H - \text{WDTAnREF (old)}$$
- Use the expression below to calculate how the WDTAnREF value is updated:

$$\text{WDTAnREF (new)} = \text{rotate left 1 bit (ExpectWDTE)}$$

Note WDTAnREF is also updated upon an erroneous WDTA trigger, i.e.:

- When the value written to WDTAnEVAC differs from the expected activation code.
- When writing to WDTAnEVAC outside the open window.

In either case, a WDTAnTRES reset or WDTAnTNMI interrupt request is also generated.

The table below lists the variable activation codes according to the number of triggers.

Table 13-9 Expected activation code development

No ^a	WDTAnREF (old)		ExpectWDE (AC _H - WDTAnREF)		WDTAnREF (new)	
0	0000 0000	00 _H	1010 1100	AC _H	0101 1001	59 _H
1	0101 1001	59 _H	0101 0011	53 _H	1010 0110	A6 _H
2	1010 0110	A6 _H	0000 0110	06 _H	0000 1100	0C _H
...

a) Number of triggers after reset

This generates a sequence of 122 different numbers that have to be used to re-trigger the Watchdog Timer.

Note Bit 7 of the WDTAnEVAC register (WDTAnEVAC7) cannot be cleared to 0 after the WDTA has been started. Thus even if bit 7 of the activation code is 0, the WDTA will not stop.

13.4.3 Error detection

The conditions for error detection are:

- Overflow interval time is exceeded (counter overflow)
- Wrong activation code is written to the trigger register
- Writing to the trigger register outside the open window.
- Illegal update of Watchdog Timer mode register WDTAnMD:
 - Writing a *new* value to WDTAnMD after the first trigger leads to an error detection.
 - Writing the same value to WDTAnMD after the first trigger does *not* lead to an error detection.

Error mode When an error is detected, either an NMI request (WDTAnTNMI) or a reset (WDTAnTRES) is generated.

WDTAnMD.WDTAnERM selects the error mode:

- WDTAnMD.WDTAnERM = 0: NMI mode
- WDTAnMD.WDTAnERM = 1: reset mode

Caution Due to the fact, that any modification of the WDTAnMD register becomes effective with the first WDTA trigger, the initial value of WDTAnMD remains active until the first WDTA trigger.

This means in particular, that a WDTAnTRES is generated in the following case:

- WDTA is changed to NMI mode by WDTAnMD.WDTAnERM = 0
- WDTAnMD is written again before the first WDTA trigger (error condition)

- After error detection** After detection of an error the Watchdog Timer operation is stopped. For restarting the Watchdog Timer a reset is necessary.
- In NMI mode:
The NMI service routine has to initiate assertion of a reset, e.g. by applying a software reset.
 - In reset mode:
The Watchdog Timer generates the reset by itself.

The following figure shows the reset or NMI request generation when the counter overflows and automatic start mode is selected.




Figure 13-5 Timing diagram of WDTA NMI request or reset generation

The timing diagram above shows the following:

1. After reset release, the counter starts (automatic start mode is selected).
2. WDTAnMD is written before the first trigger. However, the settings are not applied immediately.
3. The counter is cleared at the first trigger and the new WDTA settings are applied.
4. When the counter overflows, an error is detected. Depending on the error mode, either interrupt request WDTAnTNMI or reset WDTAnTRES is generated.
The counter value remains, the Watchdog Timer is stopped and can not be restarted, until a system reset is performed.
5. When the system is reset, the counter is cleared and stopped until reset release.

13.4.4 75% interrupt output

When the counter reaches 75% of the maximum counter value, the interrupt request INTWDTn is generated.

This function can be automatically enabled with the start-up option OPWDINT = 1.

By use of WDTAnMD.WDTAnWIE this function can be enabled respectively disabled afterwards.

The following figure shows the 75% interrupt request generation under following conditions:

- Automatic start mode selected
- Count clock changes after first trigger




Figure 13-6 Timing diagram of WDTA 75% interrupt output

13.4.5 Window function

When the open window size is set to less than 100%, an error is detected if the trigger occurs outside the open window.

The definition of the open window size differs before and after the first trigger:

- After reset release, the open window size is 100%.
OPWDWS[1:0] and bits WDTAnMD.WDTAnWS[1:0] are not applied.
- After the first trigger, the open window size is specified by bits WDTAnMD.WDTAnWS[1:0].

The following figure shows WDTA operation with an open window size of 25% and with automatic start mode selected.




Figure 13-7 Timing diagram of WDTA window function

The timing diagram above shows the following:

1. The open window size is fixed to 100% for the first trigger.
2. A trigger that occurs in the open window does not generate an error.
3. A trigger that occurs in the closed window generates a WDTAnTNMI request or a WDTAnTRES reset, depending on the selected error mode.

13.5 Application hint: Evaluation of the Watchdog status

In case the Watchdog Timer status needs to be evaluated, the following procedures could for example be used.

Variable activation code disabled

- if $WDTAnWDTE = 2C_H$: Watchdog was not activated
- if $WDTAnWDTE = AC_H$: Watchdog was activated

Variable activation code enabled

- if $WDTAnREF \neq 0$: Watchdog was activated
- if $WDTAnREF = 0$:
 - if $WDTAnEVAC = 2C_H$: Watchdog was not activated
 - if $WDTAnEVAC \neq 2C_H$: Watchdog was activated

13.6 WDTA registers

This section contains a description of all registers of the WDTA.

13.6.1 WDTA registers overview

The WDTA is controlled and operated by the following registers:

Table 13-10 WDTA register overview

Register name	Shortcut	Address
WDTA enable register	WDTAnWDTE	<WDTAn_base> + 0000 _H
WDTA VAC enable register	WDTAnEVAC	<WDTAn_base> + 0004 _H
WDTA reference value register	WDTAnREF	<WDTAn_base> + 0008 _H
WDTA mode register	WDTAnMD	<WDTAn_base> + 000C _H

<WDTAn_base> The base addresses <WDTAn_base> of the WDTAn is defined in the first section of this chapter under the key word “Register addresses”.

13.6.2 WDTA registers details

(1) WDTAnWDTE – WDTA enable register

This register is the WDTA start control and trigger register if the VAC function is not used (start-up option OPWDVAC = 0).

WDTA trigger Writing AC_H to this register restarts the counter.
Refer to the section “WDTA trigger” for details.

The behaviour of this register depends on activation of the VAC function, refer to the table “WDTAnWDTE behaviour” below.

Access This register can be read/written in 8-bit units.

Address <WDTAn_base> + 0000_H

Initial Value x010 1100_B. The initial value of the “x” bit depend on the start-up options OPWDEN, OPWDTPR, WDTATRTP, OPWDRUN and OPWDVAC. Refer to the table “WDTAnRUN initial value” below.

	7	6	5	4	3	2	1	0
WDTAnRUN	0	1	0	1	1	1	0	0
	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 13-11 WDTAnWDTE register contents

Bit position	Bit name	Function
7	WDTAnRUN	Enables/disables the WDTAn: 0: WDTAn disabled 1: WDTAn enabled Since the WDTA can not be stopped once it was started, this bit can only be cleared by a reset.

Initial value WDTAnRUN is only valid if WDTA is enabled (OPWDEN = 1) and VAC is disabled (OPWDVAC = 0). In this case, the initial value of bit WDTAnRUN depends on other start-up options is listed below:

Table 13-12 WDTAnRUN initial value

Start-up options		Input signal	Start mode	Initial value of WDTAnRUN
OPWD TPR	OPWD RUN	WDTATRTP		
0	0	Ignored	Software trigger	0
0	1	Ignored	Automatic	1
1	Ignored	0	Software trigger	0
1	Ignored	1	Automatic	1

The behaviour of WDTAnWDTE during read/write accesses depends on activation of the VAC mode, as shown in the table below.

Table 13-13 WDTAnWDTE behaviour

OPWDVAC	WDTAnWDTE		Remark
	Read	Write	
0	AC _H	WDTA trigger AC _H ^a	VAC disabled: WDTAnWDTE enabled
1	2C _H	ignored	VAC enabled: WDTAnWDTE disabled

a) Any other write value will lead to an error detection.

(2) WDTAnEVAC – WDTA enable VAC register

This register is the start control and trigger register if the VAC function is used (start-up option OPWDVAC = 1).

WDTA trigger Writing the correct activation code to this register restarts the counter. Refer to the section “WDTA trigger”.

The behaviour of this register depends on activation of the VAC function, refer to the table “WDTAnEVAC behaviour” below.

Access This register can be read/written in 8-bit units.

Address <WDTAn_base> + 0004_H

Initial Value x010 1100_B. The initial value of the “x” bit depend on the start-up options OPWDEN, OPWDTPR, WDTATRTP, OPWDRUN and OPWDVAC. Refer to the table “WDTAnRUN initial value” below.

	7	6	5	4	3	2	1	0
WDTAnEVAC7	0	1	0	1	1	1	0	0
	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 13-14 WDTAnEVAC register contents

Bit position	Bit name	Function
7	WDTAnEVAC7	Enables/disables the WDTAn: 0: WDTAn disabled 1: WDTAn enabled Since the WDTA can not be stopped once it was started, this bit can only be cleared by a reset. Thus even if bit 7 of the activation code is 0, the WDTA will not stop.

Initial value WDTAnEVAC7 is only valid if WDTA is enabled (OPWDEN = 1) and VAC is enabled (OPWDVAC = 1). In this case, the initial value of bit WDTAnEVAC7 depends on other start-up options is listed below:

Table 13-15 WDTAnRUN initial value

Start-up options		Input signal	Start mode	Initial value of WDTAnEVAC7
OPWD TPR	OPWD RUN	WDTATRTP		
0	0	Ignored	Software trigger	0
0	1	Ignored	Automatic	1
1	Ignored	0	Software trigger	0
1	Ignored	1	Automatic	1

The behaviour of WDTAnEVAC during read/write accesses depends on activation of the VAC mode, as shown in the table below.

Table 13-16 WDTAnEVAC behaviour

OPWDVAC	WDTAnEVAC		Remark
	Read	Write	
0	2C _H	ignored	VAC disabled: WDTAnEVAC disabled
1	last written VAC	WDTA trigger VAC ^a	VAC enabled: WDTAnEVAC enabled

^{a)} Any other write value will lead to an error detection.

(3) WDTAnREF – WDTA reference value register

This register contains the reference value for calculating the activation code of the VAC function. It is automatically updated after every trigger operation. Refer to the section “WDTA trigger”.

If VAC is disabled (OPWDVAC = 0), reading this register returns 00_H.

Access This register can be read in 8-bit units.

Address <WDTAn_base> + 0008_H

Initial Value 00_H

7	6	5	4	3	2	1	0
WDTAnREF[7:0]							
R	R	R	R	R	R	R	R

Table 13-17 WDTAnREF register contents

Bit position	Bit name	Function
7 to 0	WDTAnREF[7:0]	Reference value for activation code calculation.

(4) WDTAnMD – WDTA mode register

This register specifies the overflow interval time, the 75% interrupt output mode, the error mode, and the open window size.

It can be updated only once after reset release and before the first trigger.

Caution The updated WDTAnMD value is effective after the next WDTA trigger.

Updating this register after the WDTA has been started leads to error detection, but the read value of this register can be written without generating an error.

Access This register can be read/written in 8-bit units.

Address <WDTAn_base> + 000C_H

Initial Value 0xxx x1xx_B. The initial value of the “x” bits depend on the start-up options OPWDOVF[2:0], OPWDINT and OPWDWS[1:0]. Refer to “WDTA Start-up Options” in the first section of this chapter.

7	6	5	4	3	2	1	0
0	WDTAnOVF[2:0]			WDTAnWIE	WDTAnERM	WDTAnWS[1:0]	
R/W ^a	R/W	R/W	R/W	R/W	R/W	R/W	R/W

a) Writing to this bit is ignored, reading returns 0.

Table 13-18 WDTAnMD register contents (1/2)

Bit position	Bit name	Function																																				
6 to 4	WDTAnOVF[2:0]	<p>Selects the count clock and thus the overflow interval time:</p> <table border="1"> <thead> <tr> <th>WDTAnOVF2</th> <th>WDTAnOVF1</th> <th>WDTAnOVF0</th> <th>Count clock</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>0</td> <td>WDTATCKI / 2⁹</td> </tr> <tr> <td>0</td> <td>0</td> <td>1</td> <td>WDTATCKI / 2¹⁰</td> </tr> <tr> <td>0</td> <td>1</td> <td>0</td> <td>WDTATCKI / 2¹¹</td> </tr> <tr> <td>0</td> <td>1</td> <td>1</td> <td>WDTATCKI / 2¹²</td> </tr> <tr> <td>1</td> <td>0</td> <td>0</td> <td>WDTATCKI / 2¹³</td> </tr> <tr> <td>1</td> <td>0</td> <td>1</td> <td>WDTATCKI / 2¹⁴</td> </tr> <tr> <td>1</td> <td>1</td> <td>0</td> <td>WDTATCKI / 2¹⁵</td> </tr> <tr> <td>1</td> <td>1</td> <td>1</td> <td>WDTATCKI / 2¹⁶</td> </tr> </tbody> </table> <p>The overflow interval time is calculated from the count clock: Overflow interval time = 1 / count clock frequency</p> <p>The reset values of WDTAnOVF[2:0] depend on start-up option OPWDOVF[2:0].</p>	WDTAnOVF2	WDTAnOVF1	WDTAnOVF0	Count clock	0	0	0	WDTATCKI / 2 ⁹	0	0	1	WDTATCKI / 2 ¹⁰	0	1	0	WDTATCKI / 2 ¹¹	0	1	1	WDTATCKI / 2 ¹²	1	0	0	WDTATCKI / 2 ¹³	1	0	1	WDTATCKI / 2 ¹⁴	1	1	0	WDTATCKI / 2 ¹⁵	1	1	1	WDTATCKI / 2 ¹⁶
WDTAnOVF2	WDTAnOVF1	WDTAnOVF0	Count clock																																			
0	0	0	WDTATCKI / 2 ⁹																																			
0	0	1	WDTATCKI / 2 ¹⁰																																			
0	1	0	WDTATCKI / 2 ¹¹																																			
0	1	1	WDTATCKI / 2 ¹²																																			
1	0	0	WDTATCKI / 2 ¹³																																			
1	0	1	WDTATCKI / 2 ¹⁴																																			
1	1	0	WDTATCKI / 2 ¹⁵																																			
1	1	1	WDTATCKI / 2 ¹⁶																																			
3	WDTAnWIE	<p>Enables/disables the 75% interrupt request INTWDTn:</p> <p>0: INTWDTn disabled 1: INTWDTn enabled</p> <p>The reset value of WDTAnWIE depends on start-up option OPWDINT.</p>																																				

Table 13-18 WDTAnMD register contents (2/2)

Bit position	Bit name	Function															
2	WDTAnERM	Specifies the error mode: 0: NMI request mode 1: Reset mode															
1 to 0	WDTAnWS[1:0]	Selects the open window size: <table border="1" data-bbox="579 432 1385 685"> <thead> <tr> <th>WDTAnWS1</th> <th>WDTAnWS0</th> <th>Open window size</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>25%</td> </tr> <tr> <td>0</td> <td>1</td> <td>50%</td> </tr> <tr> <td>1</td> <td>0</td> <td>75%</td> </tr> <tr> <td>1</td> <td>1</td> <td>100%</td> </tr> </tbody> </table> <p>The reset values of WDTAnWS[1:0] depend on start-up option OPWDWS[1:0].</p>	WDTAnWS1	WDTAnWS0	Open window size	0	0	25%	0	1	50%	1	0	75%	1	1	100%
WDTAnWS1	WDTAnWS0	Open window size															
0	0	25%															
0	1	50%															
1	0	75%															
1	1	100%															

Chapter 14 Timer Array Unit B (TAUB)

This chapter contains a generic description of the Timer Array Unit B (TAUB).

The first section describes all V850E2/Fx4-G specific properties, such as instances, register base addresses, input/output signal names, etc. The subsequent sections describe the features that apply to all implementations.

14.1 V850E2/Fx4-G TAUB Features

Instances This microcontroller has the following number of instances of the Timer Array Unit B.

Table 14-1 Instances of TAUB

Timer Array Unit B	V850E2/FF4-G V850E2/FG4-G
Instance	1
Name	TAUB0

Instances index n Throughout this chapter, the individual instances of a Timer Array Unit B is identified by the index “n” (n = 0), for example, TAUBnTOM for the TAUBn channel output mode register.

Channel index m The Timer Array Unit B has 16 channels. Throughout this chapter, the individual channels are identified by the index “m” (m = 0 to 15), thus a certain channel is denoted as CHm. The even numbered channels (m = 0, 2, 4, 6, 8, 10, 12, 14) are denoted as CHm_even. The odd numbered channels (m = 1, 3, 5, 7, 9, 11, 13, 15) are denoted as CHm_odd.

Register addresses All TAUBn register addresses are given as address offsets to the individual base address <TAUBn_base>. The base address <TAUBn_base> of each TAUBn is listed in the following table:

Table 14-2 Register base addresses <TAUBn_base>

TAUBn instance	<TAUBn_base> address
TAUB0	FF80 8000 _H

Clock supply All Timer Array Units B provide one clock input:

Table 14-3 TAUBn clock supply

TAUBn instance	TAUBn clock	Connected to
TAUB0	PCLK	Clock Controller CKSCLK_006




Figure 14-1 TAUB clock supply

Interrupts and DMA The Timer Array Unit B can generate the following interrupt and DMA requests:

Table 14-4 TAUBn interrupt and DMA requests (1/2)

TAUBn signals	Function	Connected to
TAUB0:		
INTTAUB0I0	Channel 0 interrupt	Interrupt Controller INTTAUB0I0 ^a
INTTAUB0I1	Channel 1 interrupt	Interrupt Controller INTTAUB0I1 ^a
INTTAUB0I2 to INTTAUB0I3	Channel 2 to 3 interrupt	Interrupt Controller INTTAUB0I2 ^a to INTTAUB0I3 ^a
INTTAUB0I4	Channel 4 interrupt	Interrupt Controller INTTAUB0I4 ^a
INTTAUB0I5	Channel 5 interrupt	Interrupt Controller INTTAUB0I5 ^a
INTTAUB0I6 to INTTAUB0I7	Channel 6 to 7 interrupt	Interrupt Controller INTTAUB0I6 ^a to INTTAUB0I7 ^a
INTTAUB0I8	Channel 8 interrupt	Interrupt Controller INTTAUB0I8 ^a DMA Controller trigger 12
INTTAUB0I9	Channel 9 interrupt	Interrupt Controller INTTAUB0I9 ^a DMA Controller trigger 13
INTTAUB0I10	Channel 10 interrupt	Interrupt Controller INTTAUB0I10 ^a DMA Controller trigger 14
INTTAUB0I11	Channel 11 interrupt	Interrupt Controller INTTAUB0I10 ^a DMA Controller trigger 15
INTTAUB0I12	Channel 12 interrupt	Interrupt Controller INTTAUB0I12 ^a DMA Controller trigger 16
INTTAUB0I13	Channel 13 interrupt	Interrupt Controller INTTAUB0I13 ^a DMA Controller trigger 17

Table 14-4 TAUBn interrupt and DMA requests (2/2)

TAUBn signals	Function	Connected to
INTTAUB0114	Channel 14 interrupt	Interrupt Controller INTTAUB0114 ^a DMA Controller trigger 18
INTTAUB0115	Channel 15 interrupt	Interrupt Controller INTTAUB0115 ^{ab} DMA Controller trigger 19

- a) These interrupts can be used as a wake-up source from any stand-by mode. Refer to the chapter “*Stand-by Controller (STBC)*” for details.
- b) These signal can be used to as a trigger source to start the A/D Converter. Refer to the section “*H/W Trigger Expansion*” in the chapter “*A/D Converter (ADAA)*”.

TAUB H/W reset The Time Array Units B and their registers are initialized by the following reset signal:

Table 14-5 TAUBn reset signal

TAUBn	Reset signal
TAUBn	<ul style="list-style-type: none"> Reset Controller SYSRES Stand-by Controller DPSTPWU (wake-up from DEEPSTOP mode)

I/O signals The I/O signals of the Timer Array Unit B are listed in the following table.

Table 14-6 TAUBn I/O signals

TAUB signal	Function	Connected to
TAUB0:		
TAUB0TTIN0	Channel 0 input	FCN0 TSOUT or port URTE10RX or TAUJ0 INTTAUJ0I3 ^b
TAUB0TTIN1	Channel 1 input	Port TAUB011 ^a or FCN1 TSOUT or port URTE11RX or TAUB0TTIN0 ^b
TAUB0TTIN2	Channel 2 input	Port TAUB012 ^a or port URTE2RX ^b
TAUB0TTIN3	Channel 3 input	Port TAUB013 ^a or TAUB0TTIN2 ^b
TAUB0TTIN4	Channel 4 input	Port TAUB014 ^a
TAUB0TTIN5	Channel 5 input	Port TAUB015 ^a or TAUB0TTIN4 ^b
TAUB0TTIN6	Channel 6 input	Port TAUB016 ^a
TAUB0TTIN7	Channel 7 input	Port TAUB017 ^a or TAUB0TTIN6 ^b
TAUB0TTIN8	Channel 8 input	Port TAUB018 ^a
TAUB0TTIN9	Channel 9 input	Port TAUB019 ^a or TAUB0TTIN8 ^b
TAUB0TTIN10	Channel 10 input	Port TAUB0110 ^a or FCN0 TSOUT ^b
TAUB0TTIN11	Channel 11 input	Port TAUB0111 ^a or FCN1 TSOUT or TAUB0TTIN10 ^b
TAUB0TTIN12	Channel 12 input	Port TAUB0112 ^a
TAUB0TTIN13	Channel 13 input	Port TAUB0113 ^a or TAUB0TTIN12 ^b
TAUB0TTIN14	Channel 14 input	Port TAUB0114 ^a
TAUB0TTIN15	Channel 15 input	Port TAUB0115 ^a or TAUJ0 INTTAUJ0I3 or TAUB0TTIN14 ^b
TAUB0TTOUT0	Channel 0 output	not connected
TAUB0TTOUT1 to TAUB0TTOUT15	Channel 15 output	Port TAUB0IO1 to TAUB0O15

- a) These input signals are passed through a noise filter, refer to the section “Port Filters” in the chapter “Port Functions”.
- b) Refer to the section “TAUB Input Selections” below.

14.2 TAUB0 Input Selections

The TAUB0 has several options to connect its input signals:

- FCN0, FCN1, FCN2, FCN3, FCN4, FCN5 time stamp output signals TSOUT for timing measurements
- URTE2, URTE10, URTE11 data receive signals URTE_nRX for baud rate measurement
- odd numbered TAUB0 input signals TAUB0TTIN_m can be connected to even numbered input signals
- TAUJ0 interrupt INTTAUJ0I3 for timing measurements

The following figure depicts the TAUB0 input selection scheme:




Figure 14-2 TAUB0 input selector scheme

The following tables show the optional inputs to several TAUB0 inputs:

Table 14-7 TAUB0 input selections - TAUB0TTIN0 to TAUB0TTIN2

TAUB0 input	Input options	Selection control		
		TISLTA0 register bit	TRXSLTA0 register bits	TJSLTB0 register bits
TAUB0TTIN0	FCN0 TSOUT (CAN I/F 0 time stamp output)	X	TRXSLTA0[1:0] = 01 _B	X
	Port URTE10RX (URTE10 data receive signal)		TRXSLTA0[1:0] = 11 _B	TJSLTB00 = 0
	TAUJ0 INTTAUJ0I3 (TAUJ0 channel 3 interrupt)			TJSLTB00 = 1
TAUB0TTIN1	Port TAUB0I1	TISLTA00 = 0	TRXSLTA0[3:2] = x0 _B	X
	FCN1 TSOUT (CAN I/F 1 time stamp output)		TRXSLTA0[3:2] = 01 _B	
	Port URTE11RX (URTE11 data receive signal)		TRXSLTA0[3:2] = 11 _B	
TAUB0TTIN2	Port TAUB0I12	X	TRXSLTA06 = 0	X
	Port URTE2RX (URTE2 data receive signal)		TRXSLTA06 = 1	

Table 14-8 TAUB0 input selections - TAUB0TTIN3 to TAUB0TTIN9

TAUB0 input	Input options	Selection control TISLTA0 register bits
TAUB0TTIN3	Port TAUB0I3	TISLTA01 = 0
	Input to TAUB0TTIN2	TISLTA01 = 1
TAUB0TTIN4	Port TAUB0I4	X
TAUB0TTIN5	Port TAUB0I5	TISLTA02 = 0
	Input to TAUB0TTIN4	TISLTA02 = 1
TAUB0TTIN6	Port TAUB0I6	X
TAUB0TTIN7	Port TAUB0I7	TISLTA03 = 0
	Input to TAUB0TTIN6	TISLTA03 = 1
TAUB0TTIN8	Port TAUB0I8	X
TAUB0TTIN9	Port TAUB0I9	TTISLTA04 = 0
	Input to TAUB0TTIN8	TTISLTA04 = 1

Table 14-9 TAUB0 input selections - TAUB0TTIN10 to TAUB0TTIN15

TAUB0 input	Input options	Selection control		
		TISLTA0 register bit	TSOSLTA0 register bits	TJSLTB0 register bits
TAUB0TTIN10	Port TAUB0I10	X	TSOSLTA00 = 0	X
	FCN0 TSOUT (CAN I/F 0 time stamp output)		TSOSLTA00 = 1	
TAUB0TTIN11	Port TAUB0I11	TISLTA05 = 0	TSOSLTA01 = 0	X
	FCN1 TSOUT (CAN I/F 1 time stamp output)		TSOSLTA01 = 1	
	Input to TAUB0TTIN10	TISLTA05 = 1	X	
TAUB0TTIN12	Port TAUB0I12	X	TSOSLTA02 = 0	X
	FCN2 TSOUT (CAN I/F 2 time stamp output)	X	TSOSLTA02 = 1	X
TAUB0TTIN13	Port TAUB0I13	TISLTA06 = 0	X	X
	Input to TAUB0TTIN12	TISLTA06 = 1		
	FCN3 TSOUT (CAN I/F 3 time stamp output)	X	TSOSLTA03 = 1	
TAUB0TTIN14	Port TAUB0I14	X	TSOSLTA04 = 0	X
	FCN4 TSOUT (CAN I/F 4 time stamp output)	X	TSOSLTA04 = 1	X
TAUB0TTIN15	Port TAUB0I15	TISLTA07 = 0	X	TJSLTB01 = 0
	TAUJ0 INTTAUJ0I3 (TAUJ0 channel 3 interrupt)			TJSLTB01 = 1
	Input to TAUB0TTIN14	TISLTA07 = 1	X	X
	FCN5 TSOUT (CAN I/F 5 time stamp output)	X	TSOSLTA05 = 1	X

(1) TISLTA0 - TAUB0 odd inputs selection register

This register selects the input signals to the odd TAUB0 inputs.

Access This register can be read/written in 8-bit units.

Address FF77 1000_H

Initial Value 00_H

7	6	5	4	3	2	1	0
TISLTA07	TISLTA06	TISLTA05	TISLTA04	TISLTA03	TISLTA02	TISLTA01	TISLTA00
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 14-10 TISLTA0 register contents

Bit position	Bit name	Function
7	TISLTA07	Selection of TAUB0TTIN15: 0: Port TAUB015 or TAUJ0 interrupt INTTAUJ0I3 ^a 1: TAUB0TTIN14 input
6	TISLTA06	Selection of TAUB0TTIN13: 0: Port TAUB013 1: TAUB0TTIN12 input
5	TISLTA05	Selection of TAUB0TTIN11: 0: Port TAUB011 or FCN1 time stamp TSOUT ^b 1: TAUB0TTIN10 input
4	TISLTA04	Selection of TAUB0TTIN9: 0: Port TAUB019 1: TAUB0TTIN8 input
3	TISLTA03	Selection of TAUB0TTIN7: 0: Port TAUB017 1: TAUB0TTIN6 input
2	TISLTA02	Selection of TAUB0TTIN5: 0: Port TAUB015 1: TAUB0TTIN4 input
1	TISLTA01	Selection of TAUB0TTIN3: 0: Port TAUB013 1: TAUB0TTIN2 input
0	TISLTA00	Selection of TAUB0TTIN1: 0: Port TAUB011 or FCN1 time stamp TSOUT or port URTE11RX ^c 1: TAUB0TTIN0 input

- a) Refer also to the TJSLTB0 register description.
 b) Refer also to the TSOSLTA0 register description.
 c) Refer also th the TRXSLTA0 register description.

(2) TRXSLTA0 - TAUB0 receive input selection register

This register selects the input signals to several TAUB0 inputs out of signals related to other functional modules (FCN, URTE).

Access This register can be read/written in 8-bit units.

Address FF77 1004_H

Initial Value 00_H

7	6	5	4	3	2	1	0
0	TRXSLTA 06	0	0	TRXSLTA0 [3:2]	TRXSLTA0 [1:0]		
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 14-11 TRXSLTA0 register contents

Bit position	Bit name	Function									
6	TRXSLTA 06	Selection of TAUB0TTIN2: <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>TRXSLTA06</th> <th>TAUB0TTIN2 selector input</th> </tr> </thead> <tbody> <tr> <td>0_B</td> <td>Port TAUB0I2</td> </tr> <tr> <td>1_B</td> <td>Port URTE2RX</td> </tr> </tbody> </table>	TRXSLTA06	TAUB0TTIN2 selector input	0 _B	Port TAUB0I2	1 _B	Port URTE2RX			
TRXSLTA06	TAUB0TTIN2 selector input										
0 _B	Port TAUB0I2										
1 _B	Port URTE2RX										
3, 2	TRXSLTA 0[3:2]	Selection of TAUB0TTIN1 selector TISLTA0.TISLTA00 input: <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>TRXSLTA0[3:2]</th> <th>TAUB0TTIN1 selector input</th> </tr> </thead> <tbody> <tr> <td>00_B</td> <td rowspan="2">Port TAUB0I1</td> </tr> <tr> <td>10_B</td> </tr> <tr> <td>01_B</td> <td>FCN1 time stamp TSOUT</td> </tr> <tr> <td>11_B</td> <td>Port URTE11RX</td> </tr> </tbody> </table>	TRXSLTA0[3:2]	TAUB0TTIN1 selector input	00 _B	Port TAUB0I1	10 _B	01 _B	FCN1 time stamp TSOUT	11 _B	Port URTE11RX
TRXSLTA0[3:2]	TAUB0TTIN1 selector input										
00 _B	Port TAUB0I1										
10 _B											
01 _B	FCN1 time stamp TSOUT										
11 _B	Port URTE11RX										
1, 0	TRXSLTA 0[1:0]	Selection of TAUB0TTIN0: <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>TRXSLTA0[1:0]</th> <th>TAUB0TTIN0</th> </tr> </thead> <tbody> <tr> <td>01_B</td> <td>FCN0 time stamp TSOUT</td> </tr> <tr> <td>11_B</td> <td>Port URTE10RX or TAUJ0 interrupt TAUJ0I3^a</td> </tr> </tbody> </table>	TRXSLTA0[1:0]	TAUB0TTIN0	01 _B	FCN0 time stamp TSOUT	11 _B	Port URTE10RX or TAUJ0 interrupt TAUJ0I3 ^a			
TRXSLTA0[1:0]	TAUB0TTIN0										
01 _B	FCN0 time stamp TSOUT										
11 _B	Port URTE10RX or TAUJ0 interrupt TAUJ0I3 ^a										

^{a)} Refer also the the TJSLTB0 register description.

(3) TSOSLTA0 - TAUB0 input selection register

This register selects the input signals to several TAUB0 inputs out of signals related to other functional blocks (FCN, URTE).

Access This register can be read/written in 8-bit units.

Address FF77 2014_H

Initial Value 00_H

7	6	5	4	3	2	1	0
0	0	TSOSLTA 05	TSOSLTA 04	TSOSLTA 03	TSOSLTA 02	TSOSLTA 01	TSOSLTA 00
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 14-12 TSOSLTA0 register contents

Bit position	Bit name	Function						
5	TSOSLTA 05	Selection of TAUB0TTIN15 selector TISLTA0.TISLTA07 input: <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>TSOSLTA05</th> <th>TAUB0TTIN15 selector input</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>Port TAUB0I15</td> </tr> <tr> <td style="text-align: center;">1</td> <td>FCN5 time stamp TSOUT</td> </tr> </tbody> </table>	TSOSLTA05	TAUB0TTIN15 selector input	0	Port TAUB0I15	1	FCN5 time stamp TSOUT
TSOSLTA05	TAUB0TTIN15 selector input							
0	Port TAUB0I15							
1	FCN5 time stamp TSOUT							
4	TSOSLTA 04	Selection of TAUB0TTIN14: <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>TSOSLTA04</th> <th>TAUB0TTIN14</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>Port TAUB0I14</td> </tr> <tr> <td style="text-align: center;">1</td> <td>FCN4 time stamp TSOUT</td> </tr> </tbody> </table>	TSOSLTA04	TAUB0TTIN14	0	Port TAUB0I14	1	FCN4 time stamp TSOUT
TSOSLTA04	TAUB0TTIN14							
0	Port TAUB0I14							
1	FCN4 time stamp TSOUT							
3	TSOSLTA 03	Selection of TAUB0TTIN13 selector TISLTA0.TISLTA06 input: <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>TSOSLTA03</th> <th>TAUB0TTIN13 selector input</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>Port TAUB0I13</td> </tr> <tr> <td style="text-align: center;">1</td> <td>FCN3 time stamp TSOUT</td> </tr> </tbody> </table>	TSOSLTA03	TAUB0TTIN13 selector input	0	Port TAUB0I13	1	FCN3 time stamp TSOUT
TSOSLTA03	TAUB0TTIN13 selector input							
0	Port TAUB0I13							
1	FCN3 time stamp TSOUT							
2	TSOSLTA 02	Selection of TAUB0TTIN12: <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>TSOSLTA02</th> <th>TAUB0TTIN12</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>Port TAUB0I12</td> </tr> <tr> <td style="text-align: center;">1</td> <td>FCN2 time stamp TSOUT</td> </tr> </tbody> </table>	TSOSLTA02	TAUB0TTIN12	0	Port TAUB0I12	1	FCN2 time stamp TSOUT
TSOSLTA02	TAUB0TTIN12							
0	Port TAUB0I12							
1	FCN2 time stamp TSOUT							
1	TSOSLTA 01	Selection of TAUB0TTIN11 selector TISLTA0.TISLTA05 input: <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>TSOSLTA01</th> <th>TAUB0TTIN11 selector input</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>Port TAUB0I11</td> </tr> <tr> <td style="text-align: center;">1</td> <td>FCN1 time stamp TSOUT</td> </tr> </tbody> </table>	TSOSLTA01	TAUB0TTIN11 selector input	0	Port TAUB0I11	1	FCN1 time stamp TSOUT
TSOSLTA01	TAUB0TTIN11 selector input							
0	Port TAUB0I11							
1	FCN1 time stamp TSOUT							
0	TSOSLTA 00	Selection of TAUB0TTIN12: <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>TSOSLTA00</th> <th>TAUB0TTIN12</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>Port TAUB0I12</td> </tr> <tr> <td style="text-align: center;">1</td> <td>FCN0 time stamp TSOUT</td> </tr> </tbody> </table>	TSOSLTA00	TAUB0TTIN12	0	Port TAUB0I12	1	FCN0 time stamp TSOUT
TSOSLTA00	TAUB0TTIN12							
0	Port TAUB0I12							
1	FCN0 time stamp TSOUT							

(4) TJSLTB0 - TAUB0 input selection register

This register selects the TAUJ0 interrupt signal INTTAUJ0I3 as an input signal to several TAUB0 inputs.

Access This register can be read/written in 8-bit units.

Address FF77 0418_H

Initial Value 00_H

7	6	5	4	3	2	1	0
0	0	0	0	0	0	TJSLTB 01	TJSLTB 00
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 14-13 TJOSLTB0 register contents

Bit position	Bit name	Function						
1	TJSLTB 01	Selection of TAUB0TTIN15 selector TISLTA0.TISLTA07 input: <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>TJSLTB01</th> <th>TAUB0TTIN11 selector input</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>Port TAUB0I15</td> </tr> <tr> <td style="text-align: center;">1</td> <td>TAUJ0 interrupt INTTAUJ0I3</td> </tr> </tbody> </table>	TJSLTB01	TAUB0TTIN11 selector input	0	Port TAUB0I15	1	TAUJ0 interrupt INTTAUJ0I3
TJSLTB01	TAUB0TTIN11 selector input							
0	Port TAUB0I15							
1	TAUJ0 interrupt INTTAUJ0I3							
0	TJSLTB 00	Selection of selector TRXSLTA0.TRXSLTA01 input: <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>TJSLTB00</th> <th>TRXSLTA01 selector input</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>Port URTE10RX</td> </tr> <tr> <td style="text-align: center;">1</td> <td>TAUJ0 interrupt INTTAUJ0I3</td> </tr> </tbody> </table>	TJSLTB00	TRXSLTA01 selector input	0	Port URTE10RX	1	TAUJ0 interrupt INTTAUJ0I3
TJSLTB00	TRXSLTA01 selector input							
0	Port URTE10RX							
1	TAUJ0 interrupt INTTAUJ0I3							

14.3 Functional Overview

Features summary The TAUB has the following functions:

- 16 channels
- 16-bit counter and 16-bit data register per channel
- Independent channel operation
- Synchronous channel operation (master and slave operation)
- Generation of different types of output signal
- Counter can be triggered by external signal
- Interrupt generation

The following figure shows the main components of the TAUB:




Figure 14-3 Block diagram of the TAUB

The prefix "TAUBn" has been omitted from the register names for the sake of clarity in the above figure.

14.3.1 Terms

In this chapter, the following terms are used:

- **Independent / synchronous channel operation**

Independent or synchronous channel operation describes the dependency of channels on each other:

- If a channel operates independent of all other channels, this is called independent channel operation.
- If a channel operates depending on other channels, this is called synchronous channel operation.

- **Channel group**

In synchronous channel operation, all channels that depend on each other are referred to as a “channel group”.

A channel group has one master channel and one or more slave channels.

- **Operation mode**

An operation mode can be selected for every channel m . The operation mode defines the *basic* operation and features of a channel.

In synchronous channel operation, every channel in the channel group can operate in a different operation mode.

Examples are “Capture Mode”, “Event Count Mode”, and “Interval Timer Mode”.

- **Channel output mode**

The channel output mode defines the operation of $TAUBnTTOUm$

- of a single channel (independent output operation) or
- of all channels in a channel group (synchronous output operation).

Examples are “Independent Channel Output Mode” and “Synchronous Channel Output Mode with Dead Time”.

- **Channel operation function**

The channel operation function defines the *complete* function and all features

- of a single channel (independent channel operation) or
- of all channels in a channel group (synchronous channel operation).

It defines the operation mode, start and capture trigger, count clock, the real-time trigger generation, and the channel output mode.

Examples are “Divider Function” and “Triangle PWM Output Function”

- **Upper / lower channel**

Depending on the channel number m , a neighboring channel can be referred to as “upper” or “lower” channel:

- Upper channel: Channel with a smaller channel number
- Lower channel: Channel with a higher channel number

Example:

For channel 5, channel 3 is an upper channel and channel 9 is a lower channel.

14.4 Functional Description

The Timer Array Unit B is used to perform various count or timer operations and to output a signal which depends on the result of the operation. It contains one prescaler block for count clock generation and 16 channels, each equipped with a 16 bit counter TAUBnCNTm and a 16-bit data register TAUBnCDRm to hold the start or compare value of the counter.

It also contains several control and status registers.

Independent and synchronous operation

Every channel can operate in different operation modes, either independently or in combination with other channels (synchronously), i.e. multiple channels depend on each other with one master and one or more slave channels.

When a channel is operated independently, its operation mode and functions are not affected by those of other channels. When a channel is operated synchronously it is either a master or a slave. A master channel can have multiple slaves, and the state of one channel affects that of the other channels. For example, this means that one channel can control when another starts to count, is reset, etc.

The following describes the functional blocks:

Prescaler block

The prescaler block provides up to 4 clock signals (CK0 to CK3) that can be used as count clocks for all channels.

Count clocks CK0 to CK3 are derived from PCLK by a configurable prescaler division factor of 2^0 to 2^{15} .

Clock and count clock selection

For every channel, the count clock selector selects which of the following is used as the clock source:

- One of the clocks CK0 to CK3 (selected by the clock selector)
- INTTAUBnIm from master channel
- Edge detected TAUBnTTINm input signal

Controller

The controller controls the main operations of the counter:

- Operation mode (selected by bits TAUBnCMORm.MD[4:0])
- Counter start enable (TAUBnTS.TSm) and counter stop (TAUBnTT.TTm)
When counter start is enabled, status flag TAUBnTE.TEm is set.
- Count direction (can be controlled by master channel)

Trigger selector

Depending on the selected operation mode, the counter starts automatically when it is enabled (TAUBnTE.TEm = 1), or it waits for an external start trigger signal. Any of the following signals can be used as the start trigger:

- Synchronous channel start trigger input TAUBnTSSTm
- TAUBnTTINm input valid edge
- INTTAUBnIm from the master or any upper channel
- Up/down output trigger signal TAUBnTUDSm of the master channel
- Dead-time output signal TAUBnTDL.TDLm of the TAUBnTTOUtm generation unit.

Simultaneous rewrite controller

Simultaneous rewrite control is a special function that can be used in synchronous operation modes. The data registers of all channels in a channel group can be rewritten at any time. The simultaneous rewrite controller

ensures that new data register values of all channels become effective at the same time.

TAUBnTO Controller The output control of every channel enables the generation of various output signal forms such as PWM signals or triangular waves.

Signals The TAUB has various input and output signals. A full list can be found in the first section of this chapter under the keyword "I/O signals".

14.5 General Operating Procedure

The following lists the general operation procedure for the TAUBn:

After reset release, the operation of each channel is stopped. Clock supply is started and writing to each register is enabled. All circuits and registers of all channels are initialized. The control register of TAUBnTTOUTm is also initialized and outputs a low level.

1. Set the TAUBnTPS register to specify the clock frequency of CK0 to CK3.
2. Configure the desired TAUBn function:
 - Set the operation mode
 - Set the channel output mode
 - Set any other control bits
3. Enable the counter by setting the TAUBnTS.TSm bit to 1.
The counter starts to count immediately, or when an appropriate trigger is detected, depending on the bit settings.
The function is in operation.
4. If desired, and if possible for the configured function, stop the counter or perform a forced restart operation.
5. Stop the function by setting the TAUBnTT.TTm bit to 0.

Note A detailed description of the required control bits and the operation of the individual functions is given in 14.13 “Independent Channel Operation Functions” on page 501 and 14.18 “Synchronous Channel Operation Functions” on page 592 .

14.6 Operation Modes

The TAUB contains 12 operation modes. These determine the basic behavior of a channel, for example whether a timer counts up or down, whether the data register TAUBnCDRm acts as a compare register or stores the initial value of the counter, etc.

One operation mode can be set for each channel. It is specified using the TAUBnCMOR.MD[4:0] bits.

When choosing a function, these settings cannot be specified individually, but are grouped under the term operation mode. If a function uses multiple channels, the operation mode of each channel must be set correctly for the function to work correctly.

For more information about the operation modes required by each function, refer to the required function in *14.13 "Independent Channel Operation Functions" on page 501* and *14.18 "Synchronous Channel Operation Functions" on page 592*.

14.7 Concepts of Synchronous Channel Operation

In synchronous channel operation, multiple channels depend on each other, or are affected by changes in another channel. Therefore, several rules apply for the use of synchronous channel functions. These rules are detailed in *14.7.1 "Rules"*.

Two special features for synchronous channel operation are detailed in the following subchapters:

- *14.7.2 "Simultaneous start and stop of synchronous channel counters" on page 478*
- *14.8 "Simultaneous Rewrite" on page 479*

14.7.1 Rules

- Number of masters and slaves**
- Only even channels (CH0, CH2, CH4, ...) can be set as master channels. Any channel apart from CH0 can be set as a slave channel.
 - Only channels lower than the master channel can be set as slave channels, and several slave channels can be set for one master channel.
Example: If CH2 is a master channel, CH3 and the lower channels (CH4, CH5, ...) can be set as slave channels.
 - If multiple master channels are used, slave channels cannot cross the master channels.
Example: If CH0 and CH4 are master channels, CH1 to CH3 can be set as slave channels for CH0, but CH5 to CH7 cannot.
- Operation clock**
- The same operation clock must be set for the slave channel and the master channel. This is achieved using the TAUBnCMORm.CKS[1:0] bits of the slave and master channel.

The basic concepts of master/slave usage and operation clocks are illustrated in the following figure.




Figure 14-4 Grouping of the channels and assignment of operation clocks

INTTAUBnIm, start trigger, and count clock

- Master channels can transfer an interrupt request (INTTAUBnI), the start trigger, and the count clock to slave channels.
- Slave channels can use INTTAUBnI, the start trigger, and the count clock of the master channels but cannot transfer their INTTAUBnI, start trigger, or count clock to the lower channels.
- A master channel cannot use INTTAUBnI, the start trigger, or the count clock of the higher master channels.

14.7.2 Simultaneous start and stop of synchronous channel counters

Channels that are operated synchronously can be started and stopped simultaneously, both within a TAUB unit, and between TAUB units.

(1) Simultaneous start and stop within a TAUB unit

- To simultaneously start synchronized channels, the TAUBnTS.TSm bits of the channels must be set at the same time.
- To simultaneously stop synchronized channels, the TAUBnTT.TTm bits of the channels must be set at the same time.

Writing to the TAUBnTS.TSm bits sets the corresponding TAUBnTE.TEm bits to 1, enabling counting. TAUBnTS.TSm = 1 only enables the corresponding counter to start; the exact time that it starts depends on the operation mode.

(2) Simultaneous start between TAUB units

Counters in different TAUB units can also be started simultaneously if the corresponding counters are enabled before receiving the simultaneous trigger signal. The simultaneous start trigger register is then sent to the TAUBnTSSTm input.

14.8 Simultaneous Rewrite

14.8.1 Introduction

Simultaneous rewrite describes the ability to change the compare/start value and the output logic of multiple channels at the same time.

The corresponding data and control registers (TAUBnCDRm and TAUBnTOLm) can nevertheless be written at any time. The new value does not affect the counter operation or the output signal until simultaneous rewrite is triggered.

Simultaneous rewrite can be triggered by:

- The counter on the master channel or upper channel (depending on the selected operation mode) reaching a certain value
- INTTAUBnI being issued on the upper channel specified by TAUBnRDC.RDCm

There are four methods for simultaneous rewrite. These are listed in the following table, along with how to specify them and when they cause simultaneous rewrite to be triggered.

Table 14-14 Simultaneous rewrite methods and when they are triggered

Method	Simultaneous rewrite triggered when	TAUBn RDE. RDEm	TAUB nRDS. RDSm	TAUBn RDM. RDMm
—	No simultaneous rewrite	0	0	0
A	The master channel (re)starts counting	1	0	0
B	The slave channel starts counting down at the upper peak of a triangular cycle	1	0	1
C1	INTTAUBnIm is generated on an upper channel specified by TAUBnRDC.RDCm	1	1	0
TOLm	For TOLm, the following table shows whether TOLm can be rewritten during operation. The TOLm rewrite method is the same as that of CDRn.			

The following table lists which of these four methods is available for each channel operation function. For more information about the individual channel operation functions, see the corresponding sections in 14.13 “Independent Channel Operation Functions” on page 501 and 14.18 “Synchronous Channel Operation Functions” on page 592.

Table 14-15 Channel operation functions and methods they use (1/2)

Function	A	B	C1	TOLm
Simultaneous Rewrite Trigger Output Function Type 1			X	
PWM Output Function	X		X	X
One-Shot Pulse Output Function	X			
Delay Pulse Output Function	X			
Triangle PWM Output Function		X	X	X

Table 14-15 Channel operation functions and methods they use (2/2)

Function	A	B	C1	TOLm
Triangle PWM Output Function with Dead Time		X	X	
AD Conversion Trigger Output Function Type 1	X		X	
AD Conversion Trigger Output Function Type 2		X	X	

14.8.2 How to control simultaneous rewrite

The following figure shows the general procedure for simultaneous rewrite. The three main blocks (Initial settings, Start counter & count operation, and Simultaneous rewrite) are explained afterwards.




Figure 14-5 General procedure for simultaneous rewrite

(1) Initial settings

- To enable simultaneous rewrite in channel m, set `TAUBnRDE.RDEm = 1`
- To select the type of simultaneous rewrite, set `TAUBnRDM.RDMm` and `TAUBnRDS.RDSm` according to the values in *Table 14-14 "Simultaneous rewrite methods and when they are triggered"* on page 479
- To select which upper channel is monitored for the simultaneous rewrite trigger use `TAUBnRDC.RDCm` (prerequisite: `TAUBnRDS.RDSm` is set to upper channel)

(2) Start counter and count operation

- To start all the TAUBnCNTm counters in the channel group, set the corresponding TAUBnTS.TSm bits to 1. TAUBnTOL.TOLm and the values in the data registers (TAUBnCDRm) are written to the corresponding TAUBnTOL.TOLm buffer (TAUBnTOL.TOLm buf) and data buffer registers (TAUBnCDRm buf) and the counters start.
- Setting the reload data trigger bit (TAUBnRDT.RDTm) to 1 sets the reload flag (TAUBnRSF.RSFm) to 1, enabling simultaneous rewrite. TAUBnRDT.RDTm then immediately returns to 0, but TAUBnRSF.RSFm remains at 1 until simultaneous rewrite has taken place.
- When the specified trigger for simultaneous rewrite is detected, the TAUBnRSF.RSFm bit is checked to see if simultaneous rewrite is enabled (TAUBnRSF.RSFm = 1). If it is, simultaneous rewrite is carried out. Otherwise the value of the TAUBnRSF.RSFm bit is re-evaluated the next time the trigger is detected.

(3) Simultaneous rewrite

- When the simultaneous rewrite trigger is detected and simultaneous rewrite is enabled (TAUBnRSF.RSFm = 1), the current values of the data registers are copied to their buffers. These values are then written to the corresponding counters and the values are applied the next time the counter starts or restarts.
- The TAUBnRSF.RSFm bit is set to 0, and the system awaits the next simultaneous rewrite trigger.

14.8.3 Other general rules of simultaneous rewrite

The following rules also apply:

- TAUBnRDE.RDEm, TAUBnRDS.RDSm, TAUBnRDM.RDMm, and TAUBnRDC.RDCm cannot be changed while the counter is in operation (TAUBnTE.TEm = 1).
- TAUBnTOL.TOLm can only be rewritten during operation when in PWM output function or triangle PWM output function. For all other output functions, TAUBnTOL.TOLm must be written before the counter starts. If it is rewritten in another function, TAUBnTOUTm outputs an invalid wave.
- When an upper channel is used as the channel issuing the simultaneous rewrite trigger (TAUBnRDS.RDSm = 1), the TAUBnRDC.RDCm bit controls all the lower channels. This means that if the TAUBnRDC.RDCm bits of CH2 and CH7 are set to 1 and the TAUBnRDC.RDCm bits of other channels are set to 0, CH2 and CH7 serve as simultaneous rewrite trigger generation channels. CH2 controls the lower channels CH3 to CH6, and CH7 controls the lower channels CH8 to CH15.
- If simultaneous rewrite is enabled and an upper channel is selected for the simultaneous rewrite trigger (TAUBnRDE.RDEm and TAUBnRDS.RDSm = 1) but no upper channel is set (TAUBnRDC.RDC[15:0] = 0), simultaneous rewrite cannot take place.

14.8.4 Types of simultaneous rewrite

In the following section the four simultaneous rewrite methods are explained using timing diagrams.

(1) Simultaneous rewrite when the master channel (re)starts counting (method A)




Figure 14-6 Simultaneous rewrite when the master channel (re)starts counting

Setup:

- CH0 is the master channel, counting down, CH1 represents an arbitrary slave channel, and simultaneous rewrite method A is applied.

Description:

1. When the counter starts, the value of TAUBnCDRm is copied to the TAUBnCDRm buffer and the value of TAUBnTOL.TOLm is copied to the TAUBnTOL.TOLm buffer. The TAUBnCDRm buffer value is written to the counter.
2. The TAUBnCDRm and TAUBnTOL.TOLm registers can be written at any time, but the values do not affect the counter as the counter reads the buffer values.
3. CH0 restarts counting, but simultaneous rewrite does not occur because it is disabled (TAUBnRSF.RSFm = 0).
4. The reload data trigger bit (TAUBnRDT.RDTm) is set to 1 which sets the status flag (TAUBnRSF.RSFm = 1), enabling simultaneous rewrite.
5. Simultaneous rewrite is triggered by counter TAUBnCNT0 starting to count down. The TAUBnCDRm value is written to the TAUBnCDRm buffer and the TAUBnTOL.TOLm value is written to the TAUBnTOL.TOLm buffer.
 - The counter starts to count down from the value in the TAUBnCDRm buffer and the TAUBnRSF.RSFm bit is reset to 0.
 - The output logic specified by TAUBnTOL.TOLm becomes effective.
6. The counters count down and await the next simultaneous rewrite trigger. The values of TAUBnCDRm and TAUBnTOL.TOLm can be changed again.

(2) Simultaneous rewrite at the peak of a triangular cycle of the slave channel (method B)




Figure 14-7 Simultaneous rewrite at the peak of a triangular cycle of the slave channel

Setup:

- CH0 is the master channel, counting up and down, CH1 represents an arbitrary slave channel, and simultaneous rewrite method B is applied.

Description:

1. When the counter starts, the value of TAUBnCDRm is copied to the TAUBnCDRm buffer. The buffer value is written to the counter.
2. The TAUBnCDRm and TAUBnTOL registers can be written at any time, but the values do not affect the counter as the counter reads the buffer values.
3. Simultaneous rewrite does not occur because it is disabled (TAUBnRSF.RSFm = 0).
4. The reload data trigger bit (TAUBnRDT.RDTm) is set to 1 which sets the status flag (TAUBnRSF.RSFm = 1), enabling simultaneous rewrite.
5. Even though simultaneous rewrite is enabled, it does not take place because it is only triggered by the slave channel starting to count down at an upper peak.
6. Simultaneous rewrite is triggered; the TAUBnCDRm value is written to the TAUBnCDRm buffer, the TAUBnTOL.TOLm value is written to the TAUBnTOL.TOLm buffer.
 - The counters start to count down from the value in the TAUBnCDRm buffer and the TAUBnRSF.RSFm bit is reset to 0.
 - The output logic specified by TAUBnTOL.TOLm becomes effective.
7. The counters count down and await the next simultaneous rewrite trigger. The values of TAUBnCDRm and TAUBnTOL.TOLm can be changed again.

(3) Simultaneous rewrite when INTTAUBn1m is generated on an upper channel specified by TAUBnRDC.RDCm (method C1)




Figure 14-8 Simultaneous rewrite when INTTAUBn1m is generated on an upper channel specified by TAUBnRDC.RDCm

Setup:

- CH1 is an upper channel, counting down. CH2 is a master channel, CH3 is the slave channel, and simultaneous rewrite method C1 is applied. The TAUBnRDC register specifies which upper channel is monitored for an INTTAUBn1 trigger.

Description:

1. When the counter starts, the value of TAUBnCDRm is copied to the TAUBnCDRm buffer. The buffer value is written to the counter.
2. The TAUBnCDRm register can be written at any time, but the value does not affect the counter as the counter reads the buffer value.
3. The reload data trigger bit (TAUBnRDT.RDTm) is set to 1 which sets the status flag (TAUBnRSF.RSFm = 1), enabling simultaneous rewrite.
4. Even though simultaneous rewrite is enabled, it does not take place because it is only triggered by an interrupt on channel 1.
5. Simultaneous rewrite is triggered by INT1 which is caused by counter 1 reaching 0000_H. The TAUBnCDRm values are written to the corresponding TAUBnCDRm buffers, the counters start to count down from the values in the TAUBnCDRm buffers, and the TAUBnRSF.RSFm bit is reset to 0.
6. The counter counts down and awaits the next simultaneous rewrite trigger. The values of the TAUBnCDRm registers can be changed again.

14.9 Channel Output Modes

The output of the TAUBnTTOUTm pin can be controlled in two ways, the latter of which can be further split into individual modes:

- By software (Direct Channel Output Mode, TAUBnTOE.TOEm = 0)

When controlled by software, the output register bit (TAUBnTO.TOm) can be written and the value of the bit is transferred to the output pin (TAUBnTTOUTm).

- By TAUB signals (TAUBnTOE.TOEm = 1)

When operated by TAUB signals, the output level of TAUBnTTOUTm is set or reset or toggled by internal signals. The value of TAUBnTO.TOm is updated accordingly to reflect the value of TAUBnTTOUTm.

- Independently (Independent Channel Output Mode, TAUBnTOM.TOMm = 0)

When operated independently, the output of the TAUBnTTOUTm pin is only affected by settings of channel m. Therefore, independent channel operation must be selected (TAUBnTOM.TOMm = 0).

- Synchronously (Synchronous Channel Output Mode, TAUBnTOM.TOMm = 1)

When operated synchronously, the output of the TAUBnTTOUTm pin is affected by settings of channel m and those of other channels. Therefore, synchronous channel operation must be selected for all participating channels (TAUBnTOM.TOMm = 1).

The TAUBnTO.TOm bit can always be read to determine the current value of TAUBnTTOUTm, regardless of whether the pin is controlled by software, operated independently, or operated synchronously.

Control bits The settings of the control bits required to select a specific channel output mode are listed in *Table 14-16 “Channel output modes” on page 490*.

The channel output modes are described in detail in

- *14.9.2 “Channel output modes controlled independently by TAUBn signals” on page 492*
- *14.9.3 “Channel output modes controlled synchronously by TAUBn signals” on page 493*.

Output logic Positive logic or inverted logic of the output is specified by control bit TAUBnTOL.TOLm.

The value of the TAUBnTOL.TOLm bit must be set before the counter is started. It can only be changed during operation in PWM output function or triangle PWM output function. Otherwise, changes to TAUBnTOL.TOLm result in an invalid TAUBnTTOUTm signal.

Refer to *14.8 “Simultaneous Rewrite” on page 479*.

The various channel output modes and the channel output control bits are listed in the following table.

Multiple outputs For a function on channel m that uses its output and the outputs of other channels (q):

- If channel m requires a certain operation mode for channel q, set the operation mode on channel q.
- If channel m does not require a certain operation mode for channel q, the counter on channel q must be disabled ($TAUBnTE.TEq = 0$), i.e. no operation mode can be used on channel q, even one that does not generate an output.

Table 14-16 Channel output modes

Channel output mode	TAUBn TOE. TOEm	TAUBn TOM. TOMm	TAUBn TOC. TOCm	TAUBn TDE. TDEm
By software				
Direct Channel Output Mode	0	x		
By timer signals, independently (Independent Channel Output Mode)				
Independent Channel Output Mode 1	1	0	0	0
Independent Channel Output Mode 2			1	
By timer signals, synchronously (Synchronous Channel Output Mode)				
Synchronous Channel Output Mode 1	1	1	0	0
Synchronous Channel Output Mode 2			1	
with Dead Time Output				1

- All combinations not listed in this table are forbidden.
- Bits marked with an x can be set to any value.

Note The following bits cannot be changed during count operation ($TAUBnTE.TE = 1$):

- TAUBnTOM.TOMm,
- TAUBnTOC.TOCm,
- TAUBnTDE.TDEm

14.9.1 General procedure for specifying a channel output mode

The following steps describe the general procedure for specifying a TAUBnTTOUTm channel output mode. The prerequisite is that timer output operation is disabled (TAUBnTOE.TOEm = 0).

1. Set TAUBnTO.TOm to specify the initial level of the TAUBnTTOUTm output.
2. Set the channel output mode using *Table 14-16 “Channel output modes” on page 490* and the output logic using the TAUBnTOL.TOLm bit.
3. Start the counter (TAUBnTS.TSm = 1).




Figure 14-9 General procedure for specifying a TAUBnTTOUTm channel output mode

The following figure shows a general illustration of how the output changes when the counter is enabled:




Figure 14-10 General change of the TAUBnTTOUTm output

- TAUBnTO.TOm sets the initial value of TAUBnTTOUTm and can be changed while TAUBnTOE.TOEm = 0.
- TAUBnTOL.TOLm specifies whether the set signal sets TAUBnTO.TOm to high (TAUBnTOL.TOLm = 0) or low (inverted logic, TAUBnTOL.TOLm = 1).

14.9.2 Channel output modes controlled independently by TAUBn signals

This chapter lists the channel output modes that are controlled independently by TAUBn signals. The control bits used to specify a mode are listed in *Table 14-16 "Channel output modes" on page 490*.

(1) Independent Channel Output Mode 1

Set/reset conditions In this output mode, TAUBnTTOUTm toggles when INTTAUBnIm is detected. The value of TAUBnTOL.TOLm is ignored.

Prerequisites None, other than those in *Table 14-16 "Channel output modes" on page 490*.

(2) Independent Channel Output Mode 2

Set/reset conditions In this output mode, TAUBnTTOUTm is set when INTTAUBnIm occurs upon count start and reset when INTTAUBnIm occurs due to a match between TAUBnCnTm and TAUBnCnDRm.

Prerequisites None, other than those in *Table 14-16 "Channel output modes" on page 490*.

14.9.3 Channel output modes controlled synchronously by TAUBn signals

This chapter lists the channel output modes that are controlled synchronously by TAUBn signals. The control bits used to specify a mode are listed in *Table 14-16 "Channel output modes" on page 490*.

(1) Synchronous Channel Output Mode 1

Set/reset conditions In this output mode, INTTAUBnIm of the master channel serves as the set signal and INTTAUBnIm of the slave channel as the reset signal. If INTTAUBnIm of the master channel and INTTAUBnIm of the slave channel are generated at the same time, INTTAUBnIm of the slave channel (reset signal) has priority over INTTAUBnIm (set signal) of the master channel, i.e. the master channel is ignored.

Prerequisites None, other than those in *Table 14-16 "Channel output modes" on page 490*.

(2) Synchronous Channel Output Mode 2

In this output mode, the operation mode must be set to Up Down Count mode. The result is a triangle PWM wave at TAUBnTTOUTm. For details refer to 14.21.1 “Triangle PWM Output Function” on page 636 .

Set/reset conditions TAUBnCNTm of the slave channel counts down and up alternatively. When it passes 0001_H it generates an interrupt, causing TAUBnTTOUTm to toggle.

Prerequisites A set of two channels is required to generate the triangle PWM output. TAUBnTTOUTm must be set to 0 before the function starts.

(3) Synchronous Channel Output Mode 2 with Dead Time Output

In this output mode, a dead time delay is added to TAUBnTTOUTm. The set/reset conditions are shown in the following figure.

Set/reset conditions




Figure 14-11 Set/reset conditions for Synchronous Channel Output Mode 2 with Dead Time Output

The edge to which the dead time is added is specified using the TAUBnTDL.TDLm bit; for rising edge set TAUBnTDL.TDLm = 0 and for falling edge set TAUBnTDL.TDLm = 1.

Prerequisites Dead time control requires a set of three channels, each operating in the following modes:

- One master channel

The master channel must be set to Interval Timer Mode

- One even slave channel

The even slave channel must be set to Up Down Count Mode

- One odd slave channel (even channel + 1)

The odd slave channel must be set to One Count Mode

The values of the following bits must be the same for the odd channel and the even channel:

- TAUBnTOE.TOEm,
- TAUBnTOM.TOMm,
- TAUBnTOC.TOCm,
- TAUBnTDE.TDEm

14.10 Start Timing of Operating Modes

This chapter describes when the counters of the different operating modes start after the TAUBnTS.TSm bit is set to 1.

In all modes, the value of the data register and whether or not an interrupt is issued depends on the individual mode and corresponding register settings.

14.10.1 Interval Timer Mode, Judge Mode, Capture Mode, Up Down Count Mode

The counter starts at the start of the next count clock cycle after TAUBnTS.TSm is set to 1. The value of data register is also loaded at the point the counter starts.




Figure 14-12 Start timing of Interval Timer Mode, Judge Mode, Capture Mode, Up Down Count Mode

Note In Up Down Count Mode, MD0 must be set to 0.

14.10.2 Event Mode

The value of the data register is loaded as soon as $TAUBnTS.TSm$ is set to 1. The counter also starts immediately. The value of the data register changes with the subsequent count clock cycles.




Figure 14-13 Start timing of Event Mode

14.10.3 All other operating modes

In all other operating modes, the count clock cycles are ignored with regard to starting the counter. The counter is only triggered by detection of a valid $TAUBnTTINm$ edge. The value of data register is also loaded at the point the counter starts. Nevertheless, the count clock cycles determine the frequency with which all operations take place.




Figure 14-14 Start timing of all other operating modes

14.11 TAUBnTTOUTm toggle and INTTAUBnIm Generation when Counter start is triggered (MD0-bit)

It is possible to specify whether an INTTAUBnIm is generated when the counter starts, gets restarted or is triggered by an external signal, using the TAUBnCMOR.MD0 bit. The effect of the bit depends on the selected mode, as shown in the following table. The effects of INTTAUBnIm on TAUBnTTOUTm depend on the selected channel operation function.

Table 14-17 Effect of CMOR.MD0 bit on generation of INTTAUBnIm when counter is triggered

Mode	TAUBnCMOR.MD0 bit	INTTAUBnIm generated when counter is (re)started or triggered by TINm input signal
Interval Timer Mode	0	No
Capture Mode	1	Yes
Count Capture Mode	1	Yes
Capture & One Count Mode	0	No
Capture & Gate Count Mode	0	No
Event Count Mode	0	No
Up Down Count Mode	0	No
One Count Mode	0/1	No, regardless of setting of TAUBnCMOR.MD0 bit.
Gate Count Mode	0/1	No, regardless of setting of TAUBnCMOR.MD0 bit.
Pulse One Count Mode	0/1	Yes, regardless of setting of TAUBnCMOR.MD0 bit.

Note As an example see figure 14-23 “Forced restart operation, TAUBnCMORm.MD0 = 1” and figure 14-24 “Forced restart operation, TAUBnCMORm.MD0 = 0”. Refer to the description of “Role of the MD0 bit” also.




Figure 14-15 INTTAUBnIm generated when counter starts




Figure 14-16 INTTAUBnIm not generated when counter starts

14.12 TAUBnTTINm Edge Detection

Edge detection is based on the operation clock. This means that an edge can only be detected at the next rising edge of the operation clock. This can lead to a maximum delay of one operation clock cycle.

The following figure shows when edge detection takes place.




Figure 14-17 Basic edge detection timing

14.13 Independent Channel Operation Functions

The following sections list the independent channel operation functions provided by the Timer Array Unit B. For a general overview of independent channel operation, see 14.4 “*Functional Description*” on page 472 .

14.14 Independent Channel Interrupt Functions

This chapter describes functions that generate interrupts at regular intervals or with a specified delay.

- 14.14.1 “*Interval Timer Function*”
- 14.14.2 “*TAUBnTTINm Input Interval Timer Function*”
- 14.14.3 “*One-Pulse Output Function*”

14.14.1 Interval Timer Function

(1) Overview

Summary This function is used as a reference timer for generating timer interrupts (INTTAUBnIm) at regular intervals. When an interrupt is generated, the TAUBnTTOUTm signal toggles, resulting in a square wave.

- Prerequisites**
- The operation mode must be set to Interval Timer Mode, refer to *Table 14-18 "TAUBnCMORm settings for Interval Timer Function" on page 504*
 - The channel output mode must be set to Independent Channel Output Mode 1, refer to *14.9 "Channel Output Modes" on page 489*

Description The counter is started by setting the channel trigger bit (TAUBnTS.TSm) to 1. This in turn sets TAUBnTE.TEm = 1, enabling count operation. The current value of TAUBnCDRm is written to TAUBnCNTm and the counter starts to count down from this value.

When the counter reaches 0000_H, INTTAUBnIm is generated and the TAUBnTTOUTm signal toggles. TAUBnCNTm then reloads the TAUBnCDRm value and subsequently continues operation.

The value of TAUBnCDRm can be rewritten at any time, and the changed value of TAUBnCDRm is applied the next time the counter starts to count down.

The counter can be stopped by setting TAUBnTT.TTm to 1, which in turn sets TAUBnTE.TEm to 0. TAUBnCNTm and TAUBnTTOUTm stop but retain their values. The counter can be reset by setting TAUBnTS.TSm to 1. The counter can also be forcibly restarted (without stopping it first) by setting TAUBnTS.TSm to 1 during operation.

Conditions If the TAUBnCMORm.MD0 bit is set to 0, the first interrupt after a start or restart is not generated, and therefore TAUBnTTOUTm does not toggle. This results in an inverted TAUBnTTOUTm signal compared to when TAUBnCMORm.MD0 is set to 1. For details refer to *14.11 "TAUBnTTOUTm toggle and INTTAUBnIm Generation when Counter start is triggered (MD0-bit)" on page 498*.

(2) Equations

$\text{INTTAUBnIm cycle} = \text{count clock cycle} \times (\text{TAUBnCDRm} + 1)$

$\text{TAUBnTTOUTm square wave cycle} = \text{count clock cycle} \times (\text{TAUBnCDRm} + 1) \times 2$

(3) Block diagram and general timing diagram




Figure 14-18 Block diagram for Interval Timer Function

The following settings apply to the general timing diagram:

- INTTAUBnIm generated at operation start (TAUBnCMORM.MD0 = 1)




Figure 14-19 General timing diagram for Interval Timer Function

(4) Register settings**(a) TAUBnCMORm**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	-	CCS0	MAS	STS[2:0]			COS[1:0]		-	MD[4:1]				MD0	

Table 14-18 TAUBnCMORm settings for Interval Timer Function

Bit name	Setting
CKS[1:0]	00: Operation clock = CK0 01: Operation clock = CK1 10: Operation clock = CK2 11: Operation clock = CK3
CCS0	0: Operation clock is used as the count clock
MAS	0: Not used, so set to 0
STS[2:0]	000: Counter triggered by software trigger
COS[1:0]	00: Not used, so set to 00
MD[4:1]	0000: Interval Timer Mode
MD0	0: INTTAUBnIm not generated and TAUBnTTOUTm does not toggle at operation start or restart 1: Generates INTTAUBnIm and toggles TAUBnTTOUTm at operation start or restart

(b) TAUBnCMURm

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	TIS[1:0]	

Table 14-19 TAUBnCMURm settings for Interval Timer Function

Bit name	Setting
TIS[1:0]	00: Not used, so set to 00

(c) Channel output mode**Table 14-20 Control bit settings for Independent Channel Output Mode 1**

Bit name	Setting
TOE.TOEm	1: Disables Direct Channel Output Mode
TOM.TOMm	0: Independent channel output
TOC.TOCm	0: Operation mode 1 (= Toggle mode if TAUBnTOM.TOMm = 0)
TOL.TOLm	0: Positive logic
TDE.TDEm	0: Disables dead time operation
TDL.TDLm	0: When dead time operation is disabled (TAUBnTDE.TDEm = 0), set these bits to 0

Note The channel output mode can also be set to Direct Channel Output Mode by setting TAUBnTOE.TOEm = 0. TAUBnTTOUTm can then be controlled independently of the interrupts. For details refer to 14-16 “Channel output modes” on page 490 .

(d) Simultaneous rewrite

The simultaneous rewrite registers (TAUBnRDE, TAUBnRDS, TAUBnRDM, and TAUBnRDC) cannot be used with the Interval Timer Function. Therefore, these registers must be set to 0.

Table 14-21 Simultaneous rewrite settings for Interval Timer Function


Bit name	Setting
RDE.RDEm	0: Disables simultaneous rewrite
RDS.RDSm	0: When simultaneous rewrite is disabled (TAUBnRDE.RDEm = 0), set these bits to 0
RDM.RDMm	
RDC.RDCm	

(5) Operating procedure for Interval Timer Function


Table 14-22 Operating procedure for Interval Timer Function

	Operation	Status of TAUBn
Restart	Initial channel setting Set the TAUBnCMORm register and TAUBnCMURm registers as described in <i>Table 14-18 "TAUBnCMORm settings for Interval Timer Function" on page 504</i> and <i>Table 14-19 "TAUBnCMURm settings for Interval Timer Function" on page 504</i> Set the value of the TAUBnCDRm register Set the channel output mode by setting the control bits as described in <i>Table 14-20 "Control bit settings for Independent Channel Output Mode 1" on page 505</i>	Channel operation is stopped. (A clock is supplied, and a small amount of power is consumed.)
	Start operation Set TAUBnTS.TSm to 1. TAUBnTS.TSm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm is set to 1 and the counter starts. TAUBnCNTm loads the TAUBnCDRm value. When TAUBnCMORm.MD0 = 1, INTTAUBnIm is generated and TAUBnTTOUTm toggles.
	During operation The TAUBnCDRm register value can be changed at any time. The TAUBnCNTm register can be read at all times.	TAUBnCNTm counts down. When the counter reaches 0000 _H : <ul style="list-style-type: none"> • TAUBnCNTm reloads the TAUBnCDRm value and continues count operation • INTTAUBnIm is generated and TAUBnTTOUTm toggles.
	Stop operation Set TAUBnTT.TTm to 1. TAUBnTT.TTm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm is cleared to 0 and the counter stops. TAUBnCNTm and TAUBnTTOUTm stop and retain their current values.

(6) Specific timing diagrams

(a) $TAUBnCDRm = 0000_H$, count clock = $PCLK/2$ Figure 14-20 $TAUBnCDRm = 0000_H$, count clock = $PCLK/2$

- If $TAUBnCDRm = 0000_H$ and the count clock = $PCLK/2^1$, the $TAUBnCDRm$ value is written to $TAUBnCNTm$ every count clock, meaning that $TAUBnCNTm$ is always 0000_H .
- $INTTAUBnIm$ is generated every count clock, resulting in $TAUBnTOUTm$ toggling every count clock.

(b) $TAUBnCDRm = 0000_H$, count clock = $PCLK$ Figure 14-21 $TAUBnCDRm = 0000_H$, count clock = $PCLK$

- If $TAUBnCDRm = 0000_H$ and the count clock = $PCLK$, the $TAUBnCDRm$ value is written to $TAUBnCNTm$ every $PCLK$ clock, meaning that $TAUBnCNTm$ is always 0000_H .
- $INTTAUBnIm$ is generated continuously, resulting in $TAUBnTOUTm$ toggling every $PCLK$ clock.

(c) Operation stop and restart




Figure 14-22 Operation stop and restart, TAUBnCMORm.MD0 = 1

- The counter can be stopped by setting TAUBnTT.TTm to 1, which in turn sets TAUBnTE.TEm to 0.
- TAUBnCNTm and TAUBnTTOUTm stop but retain their values.
- The counter can be restarted by setting TAUBnTS.TSm to 1.

(d) Forced restart




Figure 14-23 Forced restart operation, TAUBnCMORm.MD0 = 1

- The counter can be forcibly restarted (without stopping it first) by setting TAUBnTS.TSm to 1 during operation.
- If the TAUBnCMORm.MD0 bit is set to 1, an interrupt at start or restart is generated and the output TOUTm toggles.




Figure 14-24 Forced restart operation, TAUBnCMORm.MD0 = 0

- The counter can be forcibly restarted (without stopping it first) by setting TAUBnTS.TSm to 1 during operation.
- If the TAUBnCMORm.MD0 bit is set to 0, the interrupt at start or restart is not generated and TOUTm does not toggle..

14.14.2 TAUBnTTINm Input Interval Timer Function

(1) Overview

Summary This function is used as a reference timer for generating timer interrupts (INTTAUBnIm) at regular intervals or when a valid TAUBnTTINm input edge is detected. When an interrupt is generated, the TAUBnTTOUtm signal toggles, resulting in a square wave.

- Prerequisites**
- The operation mode must be set to Interval Timer Mode, refer to *Table 14-23 "TAUBnCMORm settings for TAUBnTTINm Input Interval Timer Function" on page 512*
 - The channel output mode must be set to Independent Channel Output Mode 1, refer to *14.9 "Channel Output Modes" on page 489*

Description This function operates in an identical manner to the Interval Timer Function (see *14.14.1 "Interval Timer Function" on page 502*), except that this function is restarted by a valid TAUBnTTINm input edge. The type of edge used as the trigger is specified using the TAUBnCMURm.TIS[1:0] bits. Either rising edge, falling edge, or rising and falling edge can be selected.

(2) Equations

$$\text{INTTAUBnIm cycle} = \text{count clock cycle} \times (\text{TAUBnCDRm} + 1)$$

$$\text{TAUBnTTOUtm square wave cycle} = \text{count clock cycle} \times (\text{TAUBnCDRm} + 1) \times 2$$

(3) Block diagram and general timing diagram




Figure 14-25 Block diagram for TAUBnTTINm Input Interval Timer Function

The following settings apply to the general timing diagram:

- INTTAUBnIm generated at operation start (TAUBnCMORM.MD0 = 1) and valid edge detection of input signal.
- Rising edge detection (TAUBnCMURm.TIS[1:0] = 01_B)




Figure 14-26 General timing diagram for TAUBnTTINm Input Interval Timer Function

(4) Register settings**(a) TAUBnCMORm**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	—	CCS0	MAS	STS[2:0]			COS[1:0]		—	MD[4:1]				MD0	

Table 14-23 TAUBnCMORm settings for TAUBnTTINm Input Interval Timer Function

Bit name	Setting
CKS[1:0]	00: Operation clock = CK0 01: Operation clock = CK1 10: Operation clock = CK2 11: Operation clock = CK3
CCS0	0: Operation clock is used as the count clock
MAS	0: Not used, so set to 0
STS[2:0]	001: Valid TAUBnTTINm input edge signal is used as the external start trigger
COS[1:0]	00: Not used, so set to 00
MD[4:1]	0000: Interval Timer Mode
MD0	0: INTTAUBnIm not generated and TAUBnTTOUtm does not toggle at operation start 1: Generates INTTAUBnIm and toggles TAUBnTTOUtm at operation start

(b) TAUBnCMURm

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	TIS[1:0]	

Table 14-24 TAUBnCMURm settings for TAUBnTTINm Input Interval Timer Function

Bit name	Setting
TIS[1:0]	00: Falling edge detection 01: Rising edge detection 10: Rising and falling edge detection

(c) Channel output mode**Table 14-25 Control bit settings for Independent Channel Output Mode 1**

Bit name	Setting
TOE.TOEm	1: Disables Direct Channel Output Mode
TOM.TOMm	0: Independent channel output
TOC.TOCm	0: Operation mode 1 (= Toggle mode if TAUBnTOM.TOMm = 0)
TOL.TOLm	0: Positive logic
TDE.TDEm	0: Disables dead time operation
TDL.TDLm	0: When dead time operation is disabled (TAUBnTDE.TDEm = 0), set these bits to 0

Note The channel output mode can also be set to Direct Channel Output Mode by setting TAUBnTOE.TOEm = 0. TAUBnTTOUTm can then be controlled independently of the interrupts. For details refer to 14-16 “Channel output modes” on page 490 .

(d) Simultaneous rewrite

The simultaneous rewrite registers (TAUBnRDE, TAUBnRDS, TAUBnRDM, and TAUBnRDC) cannot be used with the TAUBnTTINm Input Interval Timer Function. Therefore, these registers must be set to 0.

Table 14-26 Simultaneous rewrite settings for TAUBnTTINm Input Interval Timer Function

Bit name	Setting
RDE.RDEm	0: Disables simultaneous rewrite
RDS.RDSm	0: When simultaneous rewrite is disabled (TAUBnRDE.RDEm = 0), set these bits to 0
RDM.RDMm	
RDC.RDCm	

(5) Operating procedure for TAUBnTTINm Input Interval Timer Function

Table 14-27 Operating procedure for TAUBnTTINm Input Interval Timer Function

	Operation	Status of TAUBn
Restart	Initial channel setting Set the TAUBnCMORm register and TAUBnCMURm registers as described in <i>Table 14-23 "TAUBnCMORm settings for TAUBnTTINm Input Interval Timer Function" on page 512</i> and <i>Table 14-24 "TAUBnCMURm settings for TAUBnTTINm Input Interval Timer Function" on page 512</i> Set the value of the TAUBnCDRm register Set the channel output mode by setting the control bits as described in <i>Table 14-25 "Control bit settings for Independent Channel Output Mode 1" on page 513</i>	Channel operation is stopped. (A clock is supplied, and a small amount of power is consumed.)
	Start operation Set TAUBnTS.TSm to 1. TAUBnTS.TSm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm is set to 1 and the counter starts. TAUBnCNTm loads the TAUBnCDRm value. When TAUBnCMORm.MD0 = 1, INTTAUBnIm is generated and TAUBnTTOUTm toggles.
	During operation The values of the TAUBnCMURm.TIS[1:0] and TAUBnTO.TOm bits and the TAUBnCDRm register can be changed at any time. The TAUBnCNTm register can be read at all times. Detection of TAUBnTTINm edge	TAUBnCNTm counts down. When the counter reaches 0000 _H : <ul style="list-style-type: none"> TAUBnCNTm reloads the TAUBnCDRm value and continues count operation INTTAUBnIm is generated and TAUBnTTOUTm toggles When a TAUBnTTINm input valid edge is detected during count operation, TAUBnCNTm reloads the TAUBnCDRm value and continues count operation. Afterwards, this procedure is repeated.
	Stop operation Set TAUBnTT.TTm to 1. TAUBnTT.TTm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm is cleared to 0 and the counter stops. TAUBnCNTm and TAUBnTTOUTm stop and retain their current values.

(6) Specific timing diagrams

The timing diagrams in 14.14.1 "Interval Timer Function" on page 502 also apply, except for this function the counter can also be restarted by a valid TAUBnTTINm input edge.




Figure 14-27 Counter triggered by rising TAUBnTTINm input edge
(TAUBnCMURm.TIS[1:0] = 01_B), TAUBnCMORM.MD0 = 1

- If a valid TAUBnTTINm input edge is detected, an interrupt is generated which causes TAUBnTTOUTm to toggle. In this example, the valid edge is a rising edge (TAUBnCMURm.TIS[1:0] = 01_B).

14.14.3 One-Pulse Output Function

(1) Overview

Summary This function generates an interrupt (INTTAUBnIm) when a valid TAUBnTTINm input edge is detected and also a specific interval later. TAUBnTTINm input signal pulses that occur within the defined interval are ignored. When an interrupt is generated, the TAUBnTTOUm signal toggles, resulting in a square wave.

- Prerequisites**
- The operation mode must be set to Pulse One Count Mode, refer to *Table 14-28 "TAUBnCMORm settings for One-Pulse Output Function" on page 518*
 - The channel output mode must be set to Independent Channel Output Mode 1, refer to *14.9 "Channel Output Modes" on page 489*
 - Trigger detection must be disabled during counting (TAUBnCMORn.MD0 = 0).

Description The counter is enabled by setting the channel trigger bit (TAUBnTS.TSm) to 1. This in turn sets TAUBnTE.TEm = 1, enabling count operation.

The counter starts when a valid TAUBnTTINm input edge is detected. The value of TAUBnCDRm is written to TAUBnCNTm and the counter starts to count down from the TAUBnCDRm value. An interrupt is generated and TAUBnTTOUm toggles.

When the counter reaches 0001_H an interrupt is generated and TAUBnTTOUm toggles. The counter stops at 0000_H and awaits the next valid TAUBnTTINm input edge.

When the counter is counting down, further TAUBnTTINm input signals are ignored, i.e. the counter does not reset.

The value of TAUBnCDRm can be rewritten at any time, and the changed value of TAUBnCDRm is applied the next time the counter starts to count down.

Conditions The type of edge used as the trigger is specified by the TAUBnCMURm.TIS[1:0] bits:

- If TAUBnCMURm.TIS[1:0] = 00_B, falling edges trigger the counter.
- If TAUBnCMURm.TIS[1:0] = 01_B, rising edges trigger the counter.
- If TAUBnCMURm.TIS[1:0] = 10_B, rising and falling edges trigger the counter.

(2) Equations

Interval between TAUBnTTINm and INTTAUBnIm = TAUBnTTOUm (timer output) width = count clock cycle × TAUBnCDRm

(3) Block diagram and general timing diagram




Figure 14-28 Block diagram for One-Pulse Output Function

The following settings apply to the general timing diagram:

- Falling edge detection ($TAUBnCMURm.TIS[1:0] = 00_B$)




Figure 14-29 General timing diagram for One-Pulse Output Function

(4) Register settings**(a) TAUBnCMORm**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	—	CCS0	MAS	STS[2:0]			COS[1:0]		—	MD[4:1]				MD0	

Table 14-28 TAUBnCMORm settings for One-Pulse Output Function

Bit name	Setting
CKS[1:0]	00: Operation clock = CK0 01: Operation clock = CK1 10: Operation clock = CK2 11: Operation clock = CK3
CCS0	0: Operation clock is used as the count clock
MAS	0: Not used, so set to 0
STS[2:0]	001: Valid TAUBnTTINm input edge signal is used as the external start trigger
COS[1:0]	00: Not used, so set to 00
MD[4:1]	1010: Pulse One Count Mode
MD0	0: INTTAUBnIm not generated and TAUBnTTOUtm does not toggle at operation start

(b) TAUBnCMURm

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	TIS[1:0]	

Table 14-29 TAUBnCMURm settings for One-Pulse Output Function

Bit name	Setting
TIS[1:0]	00: Falling edge detection 01: Rising edge detection 10: Rising and falling edge detection (low width measurement)

(c) Channel output mode**Table 14-30 Control bit settings for Independent Channel Output Mode 1**

Bit name	Setting
TOEm	1: Disables Direct Channel Output Mode
TOMm	0: Independent channel output
TOCm	1: Independent Channel Output Mode 2
TOLm	0: Positive logic 1: Inverted logic
TDEm	0: Disables dead time operation
TDLm	0: When dead time operation is disabled (TAUBnTDE.TDEm = 0), set these bits to 0

Note The channel output mode can also be set to Direct Channel Output Mode by setting TAUBnTOE.TOEm = 0. TAUBnTTOUTm can then be controlled independently of the interrupts. For details refer to *Table 14-16 “Channel output modes” on page 490*.

(d) Simultaneous rewrite

The simultaneous rewrite registers (TAUBnRDE, TAUBnRDS, TAUBnRDM, and TAUBnRDC) cannot be used with the One-Pulse Output Function. Therefore, these registers must be set to 0.

Table 14-31 Simultaneous rewrite settings for One-Pulse Output Function

Bit name	Setting
RDEm	0: Disables simultaneous rewrite
RDSm	0: When simultaneous rewrite is disabled (TAUBnRDE.RDEm = 0), set these bits to 0
RDMm	
RDCm	

(5) Operating procedure for One-Pulse Output Function

Table 14-32 Operating procedure for One-Pulse Output Function

	Operation	Status of TAUBn
Initial channel setting	Set the TAUBnCMORm register and TAUBnCMURm registers as described in <i>Table 14-28 "TAUBnCMORm settings for One-Pulse Output Function" on page 518</i> and <i>Table 14-29 "TAUBnCMURm settings for One-Pulse Output Function" on page 518</i>	Channel operation is stopped. (A clock is supplied, and a small amount of power is consumed.)
	Set the value of the TAUBnCDRm register	
	Set the channel output mode by setting the control bits as described in <i>Table 14-30 "Control bit settings for Independent Channel Output Mode 1" on page 519</i>	
Start operation	Set TAUBnTS.TSm to 1. TAUBnTS.TSm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm is set to 1 and TAUBnCNTm waits for detection of the TAUBnTTINm start edge.
	Detection of TAUBnTTINm start edge	When a start edge is detected, TAUBnCNTm loads the TAUBnCDRm value.
During operation	The value of TAUBnCDRm can be changed at any time. The TAUBnCNTm register can be read at all times.	INTTAUBnIm is generated when TAUBnCNTm starts and TAUBnTTOUTm is set to its active level. TAUBnCNTm counts down. When the counter reaches 0001 _H : <ul style="list-style-type: none"> • INTTAUBnIm is generated • TAUBnTTOUTm is set to its inactive level. TAUBnCNTm stops counting and waits for a trigger. If a trigger occurs while TAUBnCNTm is counting, the trigger is ignored. Afterwards, this procedure is repeated.
Stop operation	Set TAUBnTT.TTm to 1. TAUBnTT.TTm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm is cleared to 0 and the counter stops. TAUBnCNTm and TAUBnTTOUTm stop and retain their current values.

Restart

14.15 Independent Channel Signal Measurement Functions

This chapter describes functions that measure the widths of an individual TAUBnTTINm pulse or the total width of successive TAUBnTTINm pulses. It also describes functions that measure the interval of the signal or that compare the width of a pulse with a reference value.

- 14.15.1 *“TAUBnTTINm Input Pulse Interval Measurement Function”*
- 14.15.2 *“TAUBnTTINm Input Signal Width Measurement Function”*
- 14.15.3 *“Overflow Interrupt Output Function (During TAUBnTTINm Width Measurement)”*
- 14.15.4 *“TAUBnTTINm Input Period Count Detection Function”*
- 14.15.5 *“Overflow Interrupt Output Function (During TAUBnTTINm Input Period Count Detection)”*
- 14.15.6 *“TAUBnTTINm Input Pulse Interval Judgment Function”*
- 14.15.7 *“TAUBnTTINm Input Signal Width Judgment Function”*

14.15.1 TAUBnTTINm Input Pulse Interval Measurement Function

(1) Overview

Summary This function captures the count value and uses this value and the overflow bit TAUBnCSRm.OVF to measure the interval of the TAUBnTTINm input signal.

- Prerequisites**
- The operation mode must be set to Capture Mode, refer to *Table 14-34 “TAUBnCMORm settings for TAUBnTTINm Input Pulse Interval Measurement Function”* on page 524
 - TAUBnTTOUTm is not used for this function

Description The counter is started by setting the channel trigger bit (TAUBnTS.TSm) to 1. This in turn sets TAUBnTE.TEm = 1, enabling count operation. The counter TAUBnCNTm starts counting up from 0000_H. When a valid TAUBnTTINm edge is detected, the value of TAUBnCNTm is captured, transferred to TAUBnCDRm, and an interrupt INTTAUBnIm is generated. The counter resets to 0000_H and subsequently continues operation.

If the counter reaches FFFF_H before a valid TAUBnTTINm edge is detected, it overflows to 0000_H. The counter is reset to 0000_H and subsequently continues operation. The values transferred to TAUBnCDRm and TAUBnCSRm.OVF respectively depend on the values of bits TAUBnCMORm.COS[1:0]:

Table 14-33 Effects of an overflow

TAUBnCMORm.COS[1:0]	When overflow occurs		When a valid TAUBnTTINm input is then detected	
	TAUBnCDRm	TAUBnCSRm.OVF	TAUBnCDRm and TAUBnCNTm	TAUBnCSRm.OVF
00	Unchanged	0	TAUBnCNTm written to TAUBnCDRm	1
01		1		
10	Set to FFFF _H	0	TAUBnCNTm set to 0, TAUBnCDRm unchanged	0
11		1		

If an overflow is set (TAUBnCSRm.OVF = 1), it can only be cleared by a CPU command that sets TAUBnCSCm.CLOV = 1.

The combination of the value of TAUBnCDRm and TAUBnCSRm.OVF can be used to deduce the interval of the TAUBnTTINm signal. However, if an overflow occurs multiple times before a valid TAUBnTTINm input is detected, the overflow bit TAUBnCSRm.OVF cannot indicate this.

The function can be stopped by setting TAUBnTT.TTm = 1, which in turn sets TAUBnTE.TEm = 0. TAUBnCNTm stops but retains its value. While the function is stopped, TAUBnTTINm input valid edge detection and TAUBnCNTm capture are not performed.

The function can be restarted by setting TAUBnTS.TSm = 1. The counter is reset to 0000_H and subsequently continues operation. The counter can also be forcibly restarted (without stopping it first) by setting TAUBnTS.TSm = 1 during operation.

Conditions If the TAUBnCMORm.MD0 bit is set to 0, the interrupt at start or restart is not generated. For details refer to *14.11 “TAUBnTTOUTm toggle and INTTAUBnIm Generation when Counter start is triggered (MD0-bit)”* on page 498.

Note When $\text{TAUBnCMORm.COS}[1:0] = 11_{\text{B}}$, the value of TAUBnCNTm is *not* written to TAUBnCDRm when the first valid TAUBnTTINm input edge occurs after an overflow. However, an interrupt is generated.

(2) Equations

$$\text{TAUBnTTINm input pulse interval} = \text{count clock cycle} \times [(\text{TAUBnCSRm.OVF} \times (\text{FFFF}_{\text{H}} + 1)) + \text{TAUBnCDRm capture value} + 1]$$

(3) Block diagram and general timing diagram




Figure 14-30 Block diagram for TAUBnTTINm Input Pulse Interval Measurement Function

The following settings apply to the general timing diagram:

- INTTAUBnIm not generated at operation start ($\text{TAUBnCMORm.MD0} = 0$)
- Falling edge detection ($\text{TAUBnCMURm.TIS}[1:0] = 00_{\text{B}}$)
- When a valid TAUBnTTINm input is detected after an overflow TAUBnCDRm is changed and TAUBnCSRm.OVF is set to 1 ($\text{TAUBnCMORm.COS}[1:0] = 00_{\text{B}}$)




Figure 14-31 General timing diagram for TAUBnTTINm Input Pulse Interval Measurement Function

(4) Register settings**(a) TAUBnCMORm**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	-	CCS0	MAS	STS[2:0]			COS[1:0]		-	MD[4:1]				MD0	

Table 14-34 TAUBnCMORm settings for TAUBnTTINm Input Pulse Interval Measurement Function

Bit name	Setting
CKS[1:0]	00: Operation clock = CK0 01: Operation clock = CK1 10: Operation clock = CK2 11: Operation clock = CK3
CCS0	0: Operation clock is used as the count clock
MAS	0: Not used, so set to 0
STS[2:0]	001: Valid edge of the TAUBnTTINm input signal is the external capture trigger
COS[1:0]	See Table 14-33 "Effects of an overflow" on page 522
MD[4:1]	0010: Capture Mode
MD0	0: INTTAUBnIm not generated at operation start 1: Generates INTTAUBnIm at operation start

(b) TAUBnCMURm

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	TIS[1:0]	

Table 14-35 TAUBnCMURm settings for TAUBnTTINm Input Pulse Interval Measurement Function

Bit name	Setting
TIS[1:0]	00: Falling edge detection 01: Rising edge detection 10: Rising and falling edge detection (low width measurement) 11: Rising and falling edge detection (high width measurement)

(c) Channel output mode

The channel output mode is not used by this function. However, it can be used in Direct Channel Output Mode.

(d) Simultaneous rewrite

The simultaneous rewrite registers (TAUBnRDE, TAUBnRDS, TAUBnRDM, and TAUBnRDC) cannot be used with the TAUBnTTINm Input Pulse Interval Measurement Function. Therefore, these registers must be set to 0.

Table 14-36 Simultaneous rewrite settings for TAUBnTTINm Input Pulse Interval Measurement Function

Bit name	Setting
RDE.RDEm	0: Disables simultaneous rewrite
RDS.RDSm	0: When simultaneous rewrite is disabled (TAUBnRDE.RDEm = 0), set these bits to 0
RDM.RDMm	
RDC.RDCm	

(5) Operating procedure for TAUBnTTINm Input Pulse Interval Measurement Function

Table 14-37 Operating procedure for TAUBnTTINm Input Pulse Interval Measurement Function

	Operation	Status of TAUBn
Initial channel setting	Set the TAUBnCMORm register and TAUBnCMURm registers as described in Table 14-34 "TAUBnCMORm settings for TAUBnTTINm Input Pulse Interval Measurement Function" on page 524 and Table 14-35 "TAUBnCMURm settings for TAUBnTTINm Input Pulse Interval Measurement Function" on page 524 Set the value of the TAUBnCDRm register	Channel operation is stopped. (A clock is supplied, and a small amount of power is consumed.)
Start operation	Set TAUBnTS.TSm to 1. TAUBnTS.TSm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm is set to 1 and the counter starts. TAUBnCNTm is cleared to 0000 _H . INTTAUBnIm is generated when TAUBnCMORm.MD0 is set to 1.
During operation	Detection of TAUBnTTINm edges. The TAUBnCMURm.TIS[1:0] bits can be changed at any time. The TAUBnCDRm and TAUBnCSRm registers can be read at any time.	TAUBnCNTm starts to count up from 0000 _H . When a TAUBnTTINm valid edge is detected: <ul style="list-style-type: none"> • TAUBnCNTm transfers (captures) its value to TAUBnCDRm, and returns to 0000_H • INTTAUBnIm is then generated. Afterwards, this procedure is repeated.
Stop operation	Set TAUBnTT.TTm to 1. TAUBnTT.TTm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm is cleared to 0 and the counter stops. TAUBnCNTm stops and both it and TAUBnCSRm.OVF retain their current values.

Restart

(6) Specific timing diagrams: overflow behavior


(a) $TAUBnCMORm.COS[1:0] = 00_B$ 

Figure 14-32 $TAUBnCMORm.COS[1:0] = 00_B$, $TAUBnCMORm.MD0 = 0$,
 $TAUBnCMURm.TIS[1:0] = 00_B$

- When an overflow occurs, the value of $TAUBnCDRm$ remains unchanged and $TAUBnCSRm.OVF$ remains = 0.
- Upon detection of the next valid $TAUBnTTINm$ input edge, the value of $TAUBnCNTm$ is written to $TAUBnCDRm$ and $TAUBnCSRm.OVF$ is set to 1.


(b) $TAUBnCMORm.COS[1:0] = 01_B$ 

Figure 14-33 $TAUBnCMORm.COS[1:0] = 01_B$, $TAUBnCMORm.MD0 = 0$,
 $TAUBnCMURm.TIS[1:0] = 00_B$

- When an overflow occurs, the value of $TAUBnCDRm$ remains unchanged and $TAUBnCSRm.OVF$ is set to 1.
- Upon detection of the next valid $TAUBnTTINm$ input edge, the value of $TAUBnCNTm$ is written to $TAUBnCDRm$.
- $TAUBnCSRm.OVF$ is only cleared by a CPU command.


(c) $TAUBnCMORm.COS[1:0] = 10_B$ 

Figure 14-34 $TAUBnCMORm.COS[1:0] = 10_B$, $TAUBnCMORm.MD0 = 0$,
 $TAUBnCMURm.TIS[1:0]=00_B$

- When an overflow occurs, $TAUBnCDRm$ is set to $FFFF_H$ and $TAUBnCSRm.OVF$ remains = 0.
- Upon detection of the next valid $TAUBnTTINm$ input edge, $TAUBnCNTm$ is reset to 0, but $TAUBnCDRm$ and $TAUBnCSRm.OVF$ remain unchanged.
- Thus, the next $TAUBnTTINm$ input valid edge after the overflow is ignored.


(d) $TAUBnCMORm.COS[1:0] = 11_B$ 

Figure 14-35 $TAUBnCMORm.COS[1:0] = 11_B$, $TAUBnCMORm.MD0 = 0$,
 $TAUBnCMURm.TIS[1:0]=00_B$

- When an overflow occurs, $TAUBnCDRm$ is set to $FFFF_H$, and $TAUBnCSRm.OVF$ is set to 1.
- Upon detection of the next valid $TAUBnTTINm$ input edge, $TAUBnCNTm$ is reset to 0, but $TAUBnCDRm$ and $TAUBnCSRm.OVF$ remain unchanged.
- Thus, the next $TAUBnTTINm$ input valid edge after the overflow is ignored.
- $TAUBnCSRm.OVF$ is cleared by a CPU command.

14.15.2 TAUBnTTINm Input Signal Width Measurement Function

(1) Overview

Summary This function measures the width of a TAUBnTTINm input signal.

- Prerequisites**
- The operation mode must be set to Capture & One Count Mode, refer to Table 14-39 “TAUBnCMORm settings for TAUBnTTINm Input Signal Width Measurement Function” on page 532
 - TAUBnTTOUTm is not used for this function
 - TAUBnCMORm.MD0 must be set to 0

Description The counter is started by setting the channel trigger bit (TAUBnTS.TSm) to 1. This in turn sets TAUBnTE.TEm = 1, enabling count operation. When a valid TAUBnTTINm start edge is detected, the counter TAUBnCNTm starts counting up from 0000_H. When a valid TAUBnTTINm stop edge is detected, the value of TAUBnCNTm is captured, transferred to TAUBnCDRm, and an interrupt INTTAUBnIm is generated. The counter retains its value and awaits the next valid TAUBnTTINm input start edge.

If the counter reaches FFFF_H before a valid TAUBnTTINm stop edge is detected, it overflows. The counter is reset to 0000_H and subsequently continues operation. The values transferred to TAUBnCDRm and TAUBnCSRm.OVF respectively depend on the values of bits TAUBnCMORm.COS[1:0]:

Table 14-38 Effects of an overflow

TAUBnCMORm.COS[1:0]	When overflow occurs		When a valid TAUBnTTINm input stop edge is detected	
	TAUBnCDRm	TAUBnCSRm.OVF	TAUBnCDRm and TAUBnCNTm	TAUBnCSRm.OVF
00	Unchanged	0	TAUBnCNTm written to TAUBnCDRm	1
01		1		
10	Set to FFFF _H	0	TAUBnCNTm stops counting TAUBnCDRm unchanged	0
11		1		

If an overflow is set (TAUBnCSRm.OVF = 1), it can only be cleared by a CPU command that sets TAUBnCSCm.CLOV = 1.

The combination of the value of TAUBnCDRm and TAUBnCSRm.OVF can be used to deduce the width of the TAUBnTTINm signal. However, if an overflow occurs multiple times before a valid TAUBnTTINm input is detected, the overflow bit TAUBnCSRm.OVF cannot indicate this.

This function cannot be forcibly restarted.

Note When TAUBnCMORm.COS[1:0] = 11_B, the value of TAUBnCNTm is *not* written to TAUBnCDRm when the first valid TAUBnTTINm input edge occurs after an overflow. However, an interrupt is generated.

(2) Equations

TAUBnTTINm input signal width = count clock cycle × [(TAUBnCSRm.OVF × (FFFF_H + 1)) + TAUBnCDRm capture value + 1]

(3) Block diagram and general timing diagram




Figure 14-36 Block diagram for TAUBnTTINm Input Signal Width Measurement Function

The following settings apply to the general timing diagram:

- Rising and falling edge detection = high width measurement (TAUBnCMURm.TIS[1:0] = 11_B)
- When a valid TAUBnTTINm input is detected after an overflow TAUBnCDRm is changed and TAUBnCSRm.OVF is set to 1 (TAUBnCMORm.COS[1:0] = 00_B)




Figure 14-37 General timing diagram for TAUBnTTINm Input Signal Width Measurement Function

(4) Register settings**(a) TAUBnCMORm**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	—	CCS0	MAS	STS[2:0]			COS[1:0]		—	MD[4:1]				MD0	

Table 14-39 TAUBnCMORm settings for TAUBnTTINm Input Signal Width Measurement Function

Bit name	Setting
CKS[1:0]	00: Operation clock = CK0 01: Operation clock = CK1 10: Operation clock = CK2 11: Operation clock = CK3
CCS0	0: Operation clock is used as the count clock
MAS	0: Not used, so set to 0
STS[2:0]	010: Valid edge of the TAUBnTTINm input signal is the external start trigger and the reverse edge is the stop trigger
COS[1:0]	See Table 14-38 "Effects of an overflow" on page 530
MD[4:1]	0110: Capture & One Count Mode
MD0	0: INTTAUBnIm not generated at operation start

(b) TAUBnCMURm

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	TIS[1:0]	

Table 14-40 TAUBnCMURm settings for TAUBnTTINm Input Signal Width Measurement Function

Bit name	Setting
TIS[1:0]	10: Rising and falling edge detection (low width measurement) 11: Rising and falling edge detection (high width measurement)

(c) Channel output mode

The channel output mode is not used by this function. However, it can be used in Direct Channel Output Mode.

(d) Simultaneous rewrite

The simultaneous rewrite registers (TAUBnRDE, TAUBnRDS, TAUBnRDM, and TAUBnRDC) cannot be used with the TAUBnTTINm Input Signal Width Measurement Function. Therefore, these registers must be set to 0.

Table 14-41 Simultaneous rewrite settings for TAUBnTTINm Input Signal Width Measurement Function

Bit name	Setting
RDE.RDEm	0: Disables simultaneous rewrite
RDS.RDSm	0: When simultaneous rewrite is disabled (TAUBnRDE.RDEm = 0), set these bits to 0
RDM.RDMm	
RDC.RDCm	

(5) Operating procedure for TAUBnTTINm Input Signal Width Measurement Function

Table 14-42 Operating procedure for TAUBnTTINm Input Signal Width Measurement Function

	Operation	Status of TAUBn
Restart	Initial channel setting Set the TAUBnCMORm register and TAUBnCMURm registers as described in Table 14-39 "TAUBnCMORm settings for TAUBnTTINm Input Signal Width Measurement Function" on page 532 and Table 14-40 "TAUBnCMURm settings for TAUBnTTINm Input Signal Width Measurement Function" on page 532 Set the value of the TAUBnCDRm register	Channel operation is stopped. (A clock is supplied, and a small amount of power is consumed.)
	Start operation Set TAUBnTS.TSm to 1. TAUBnTS.TSm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm is set to 1 and TAUBnCNTm waits for detection of the TAUBnTTINm start edge. When a TAUBnTTINm start is detected, TAUBnCNTm starts to count up.
	During operation Detection of TAUBnTTINm edges. The TAUBnCMURm.TIS[1:0] bits can be changed at any time. The TAUBnCDRm and TAUBnCSRm registers can be read at any time.	TAUBnCNTm starts to count up from 0000 _H . When a TAUBnTTINm valid edge is detected: <ul style="list-style-type: none"> • TAUBnCNTm transfers (captures) its value to TAUBnCDRm, and retains its value • INTTAUBnIm is then generated. Afterwards, this procedure is repeated.
	Stop operation Set TAUBnTT.TTm to 1. TAUBnTT.TTm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm is cleared to 0 and the counter stops. TAUBnCNTm stops and both it and TAUBnCSRm.OVF retain their current values.

(6) Specific timing diagrams: overflow behavior


(a) TAUBnCMORm.COS[1:0] = 00_B

Figure 14-38 TAUBnCMORm.COS[1:0] = 00_B, TAUBnCMORm.MD0 = 0,
TAUBnCMURm.TIS[1:0]=11_B

- When an overflow occurs, the value of TAUBnCDRm remains unchanged and TAUBnCSRm.OVF remains = 0.
- Upon detection of the next valid TAUBnTTINm input edge, the value of TAUBnCNTm is written to TAUBnCDRm and TAUBnCSRm.OVF is set to 1.


(b) $\text{TAUBnCMORm.COS}[1:0] = 01_{\text{B}}$ 

Figure 14-39 $\text{TAUBnCMORm.COS}[1:0] = 01_{\text{B}}$, $\text{TAUBnCMORm.MD0} = 0$,
 $\text{TAUBnCMURm.TIS}[1:0] = 11_{\text{B}}$

- When an overflow occurs, the value of TAUBnCDRm remains unchanged and TAUBnCSRm.OVF is set to 1.
- Upon detection of the next valid TAUBnTTINm input edge, the value of TAUBnCNTm is written to TAUBnCDRm .
- TAUBnCSRm.OVF is only cleared by a CPU command.


(c) $\text{TAUBnCMORm.COS}[1:0] = 10_{\text{B}}$ 

Figure 14-40 $\text{TAUBnCMORm.COS}[1:0] = 10_{\text{B}}$, $\text{TAUBnCMORm.MD0} = 0$,
 $\text{TAUBnCMURm.TIS}[1:0] = 11_{\text{B}}$

- When an overflow occurs, TAUBnCDRm is set to FFFF_{H} and TAUBnCSRm.OVF remains = 0.
- Upon detection of the next valid TAUBnTTINm input edge, TAUBnCNTm is reset to 0, but TAUBnCDRm and TAUBnCSRm.OVF remain unchanged.
- Thus, the next TAUBnTTINm input valid edge after the overflow is ignored.


(d) $\text{TAUBnCMORm.COS}[1:0] = 11_{\text{B}}$ 

Figure 14-41 $\text{TAUBnCMORm.COS}[1:0] = 11_{\text{B}}$, $\text{TAUBnCMORm.MD0} = 0$,
 $\text{TAUBnCMURm.TIS}[1:0] = 11_{\text{B}}$

- When an overflow occurs, TAUBnCDRm is set to FFFF_{H} , and TAUBnCSRm.OVF is set to 1.
- Upon detection of the next valid TAUBnTTINm input edge, TAUBnCNTm is reset to 0, but TAUBnCDRm and TAUBnCSRm.OVF remain unchanged.
- Thus, the next TAUBnTTINm input valid edge after the overflow is ignored.
- TAUBnCSRm.OVF is cleared by a CPU command.

14.15.3 Overflow Interrupt Output Function (During TAUBnTTINm Width Measurement)

(1) Overview

- Summary** This function measures the width of an individual TAUBnTTINm input signal. An interrupt is generated if the TAUBnTTINm input width is longer than FFFF_H.
- Prerequisites**
- The operation mode must be set to One Count Mode, refer to *Table 14-43 “TAUBnCMORm settings for Overflow Interrupt Output Function (During TAUBnTTINm Width Measurement)” on page 540*
 - TAUBnTTOUTm is not used for this function
 - The value of TAUBnCDRm must be set to FFFF_H.
- Description** The counter is enabled by setting the channel trigger bit (TAUBnTS.TSm) to 1. This in turn sets TAUBnTE.TEm = 1, enabling count operation.
- The counter starts when a valid TAUBnTTINm input start edge is detected. FFFF_H is written to TAUBnCNTm and the counter starts to count down.
- When a valid stop edge is detected, the counter stops and retains the current value.
- When the next TAUBnTTINm input start edge is detected, TAUBnCNTm reloads FFFF_H and starts to count down.
- If the counter reaches 0000_H before a stop edge is detected, an interrupt is generated.
- Conditions** The valid start and stop edges are specified by the TAUBnCMURm.TIS[1:0] bits:
- If TAUBnCMURm.TIS[1:0] = 10_B, the TAUBnTTINm input low width is measured. The start trigger is a falling edge and the stop trigger is a rising edge.
 - If TAUBnCMURm.TIS[1:0] = 11_B, the TAUBnTTINm input high width is measured. The start trigger is a rising edge and the stop trigger is a falling edge.
- Note** The counter cannot be restarted during operation.

(2) Block diagram and general timing diagram




Figure 14-42 Block diagram for Overflow Interrupt Output Function (During TAUBnTTINm Width Measurement)

The following settings apply to the general timing diagram:

- Rising and falling edge detection = high width measurement (TAUBnCMURm.TIS[1:0] = 11_B)




Figure 14-43 General timing diagram for Overflow Interrupt Output Function (During TAUBnTTINm Width Measurement)

(3) Register settings**(a) TAUBnCMORm**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	—	CCS0	MAS	STS[2:0]			COS[1:0]		—	MD[4:1]				MD0	

Table 14-43 TAUBnCMORm settings for Overflow Interrupt Output Function (During TAUBnTTINm Width Measurement)

Bit name	Setting
CKS[1:0]	00: Operation clock = CK0 01: Operation clock = CK1 10: Operation clock = CK2 11: Operation clock = CK3
CCS0	0: Operation clock is used as the count clock
MAS	0: Not used, so set to 0
STS[2:0]	010: Valid edge of the TAUBnTTINm input signal is the external start trigger and the reverse edge is the stop trigger
COS[1:0]	00: Not used, so set to 00
MD[4:1]	0100: One Count Mode
MD0	0: INTTAUBnIm not generated at operation start

(b) TAUBnCMURm

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	TIS[1:0]	

Table 14-44 TAUBnCMURm settings Overflow Interrupt Output Function (During TAUBnTTINm Width Measurement)

Bit name	Setting
TIS[1:0]	10: Rising and falling edge detection (Low width measurement) 11: Rising and falling edge detection (High width measurement)

(c) Channel output mode

The channel output mode is not used by this function. However, it can be used in Direct Channel Output Mode.

(d) Simultaneous rewrite

The simultaneous rewrite registers (TAUBnRDE, TAUBnRDS, TAUBnRDM, and TAUBnRDC) cannot be used with the Overflow Interrupt Output Function (During TAUBnTTINm Width Measurement). Therefore, these registers must be set to 0.

(4) Operating procedure for Overflow Interrupt Output Function**Table 14-45 Simultaneous rewrite settings for Overflow Interrupt Output Function (During TAUBnTTINm Width Measurement)**

Bit name	Setting
RDEm	0: Disables simultaneous rewrite
RDSm	0: When simultaneous rewrite is disabled (TAUBnRDE.RDEm = 0), set these bits to 0
RDMm	
RDCm	

(During TAUBnTTINm Width Measurement)**Table 14-46 Operating procedure for Overflow Interrupt Output Function (During TAUBnTTINm Width Measurement)**

	Operation	Status of TAUBn
Restart ↓	Initial channel setting Set the TAUBnCMORm register and TAUBnCMURm registers as described in <i>Table 14-43 "TAUBnCMORm settings for Overflow Interrupt Output Function (During TAUBnTTINm Width Measurement)" on page 540</i> and <i>Table 14-44 "TAUBnCMURm settings Overflow Interrupt Output Function (During TAUBnTTINm Width Measurement)" on page 540</i> Set the value of the TAUBnCDRm register	Channel operation is stopped. (A clock is supplied, and a small amount of power is consumed.)
	Start operation Set TAUBnTS.TSm to 1. TAUBnTS.TSm is a trigger bit, so it is automatically cleared to 0. Detection of TAUBnTTINm start edge	TAUBnTE.TEm is set to 1 and TAUBnCNTm waits for detection of the start edge. When a start edge is detected, TAUBnCNTm loads the TAUBnCDRm value (FFFF _H).
	During operation The TAUBnCNTm register can be read at any time. Detection of TAUBnTTINm edges.	TAUBnCNTm counts down. When the counter reaches 0000 _H : <ul style="list-style-type: none"> • INTTAUBnIm is generated • TAUBnCNTm stops counting at FFFF_H and waits for a trigger. When a reverse edge of TAUBnTTINm is detected during count operation: <ul style="list-style-type: none"> • TAUBnCNTm stops counting and waits for a trigger. Afterwards, this procedure is repeated.
	Stop operation Set TAUBnTT.TTm to 1. TAUBnTT.TTm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm is cleared to 0 and the counter stops. TAUBnCNTm stops and retains its current value.

14.15.4 TAUBnTTINm Input Period Count Detection Function

(1) Overview

Summary This function measures the cumulative width of a TAUBnTTINm input signal.

- Prerequisites**
- The operation mode must be set to Capture & Gate Count Mode, refer to Table 14-47 “TAUBnCMORm settings for TAUBnTTINm Input Period Count Detection Function” on page 545
 - TAUBnTTOUTm is not used for this function

Description The counter is enabled by setting the channel trigger bit (TAUBnTS.TSm) to 1. This in turn sets TAUBnTE.TEm = 1, enabling count operation. The counter awaits a valid TAUBnTTINm input edge.

When a valid TAUBnTTINm input start edge is detected, the counter starts to count from 0000_H.

When a valid TAUBnTTINm input stop edge is detected, the current TAUBnCNTm value is written to TAUBnCDRm and an interrupt (INTTAUBnIm) is generated. The counter stops and retains its value until the next valid TAUBnTTINm input start edge is detected.

If the counter reaches FFFF_H the bit TAUBnCSRm.OVF is set to 1 and the counter restarts from 0000_H. The value of TAUBnCSRm.OVF is reset by the CPU by setting TAUBnCSCm.CLOV = 1.

Note The input TAUBnTTINm is sampled at the frequency of the operation clock, specified by the TAUBnCMORm.CKS[1:0] bits. As a result, the output cycle of TAUBnTTOUTm has an error of ± 1 operation clock cycle.

- Conditions** The valid start and stop edges are specified by the TAUBnCMURm.TIS[1:0] bits:
- If TAUBnCMURm.TIS[1:0] = 10_B, the TAUBnTTINm input low width is measured. The start trigger is a falling edge and the stop trigger is a rising edge.
 - If TAUBnCMURm.TIS[1:0] = 11_B, the TAUBnTTINm input high width is measured. The start trigger is a rising edge and the stop trigger is a falling edge.

(2) Equations

Cumulative TAUBnTTINm input width =
count clock cycle × ((FFFF_H × TAUBnCSRm.OVF) + (TAUBnCDRm capture value + 1))

(3) Block diagram and general timing diagram




Figure 14-44 Block diagram for TAUBnTTINm Input Period Count Detection Function

The following settings apply to the general timing diagram:

- Rising and falling edge detection = high width measurement (TAUBnCMURm.TIS[1:0] = 11_B)




Figure 14-45 General timing diagram for TAUBnTTINm Input Period Count Detection Function

(4) Register settings**(a) TAUBnCMORm**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	—	CCS0	MAS	STS[2:0]			COS[1:0]		—	MD[4:1]				MD0	

Table 14-47 TAUBnCMORm settings for TAUBnTTINm Input Period Count Detection Function

Bit name	Setting
CKS[1:0]	00: Operation clock = CK0 01: Operation clock = CK1 10: Operation clock = CK2 11: Operation clock = CK3
CCS0	0: Operation clock is used as the count clock
MAS	0: Not used, so set to 0
STS[2:0]	010: Valid edge of the TAUBnTTINm input signal is the external start trigger and the reverse edge is the stop trigger
COS[1:0]	01: Overflow (TAUBnCSRm.OVF) set upon counter overflow and cleared by a CPU instruction
MD[4:1]	1101: Capture & Gate Count Mode
MD0	0: INTTAUBnIm not generated at operation start and start trigger during count disabled

(b) TAUBnCMURm

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	TIS[1:0]	

Table 14-48 TAUBnCMURm settings for TAUBnTTINm Input Period Count Detection Function

Bit name	Setting
TIS[1:0]	10: Rising and falling edge detection (Low width measurement) 11: Rising and falling edge detection (High width measurement)

(c) Channel output mode

The channel output mode is not used by this function. However, it can be used in Direct Channel Output Mode.

(d) Simultaneous rewrite

The simultaneous rewrite registers (TAUBnRDE, TAUBnRDS, TAUBnRDM, and TAUBnRDC) cannot be used with the TAUBnTTINm Input Period Count Detection Function. Therefore, these registers must be set to 0.

Table 14-49 Simultaneous rewrite settings for TAUBnTTINm Input Period Count Detection Function

Bit name	Setting
RDEm	0: Disables simultaneous rewrite
RDSm	0: When simultaneous rewrite is disabled (TAUBnRDE.RDEm = 0), set these bits to 0
RDMm	
RDCm	

(5) Operating procedure for TAUBnTTINm Input Period Count Detection Function

Table 14-50 Operating procedure for TAUBnTTINm Input Period Count Detection Function

	Operation	Status of TAUBn
Initial channel setting	Set the TAUBnCMORm register and TAUBnCMURm registers as described in Table 14-47 "TAUBnCMORm settings for TAUBnTTINm Input Period Count Detection Function" on page 545 and Table 14-48 "TAUBnCMURm settings for TAUBnTTINm Input Period Count Detection Function" on page 545	Channel operation is stopped. (A clock is supplied, and a small amount of power is consumed.)
	Set the value of the TAUBnCDRm register	
Start operation	Set TAUBnTS.TSm to 1. TAUBnTS.TSm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm is set to 1 and TAUBnCNTm waits for detection of the TAUBnTTINm start edge.
	Detection of TAUBnTTINm start edge	When a start edge is detected, TAUBnCNTm is cleared to 0000 _H and TAUBnCNTm starts to count up.
During operation	Detection of TAUBnTTINm edges.	When a TAUBnTTINm start edge (rising edge for high width measurement, falling edge for low width measurement) is detected, TAUBnCNTm starts to count up from the stop value.
	The TAUBnCDRm, TAUBnCNTm, and TAUBnCSRm registers can be read at any time. The TAUBnCSC.CLOV bit can be set to 1.	When TAUBnCNTm detects a capture edge (falling edge for high width measurement, rising edge for low width measurement), it transfers the value to TAUBnCDRm and INTTAUBnIm is generated. Counting stops at the "value transferred to TAUBnCDRm + 1" value and TAUBnCNTm waits for detection of the TAUBnTTINm start edge. If the TAUBnCNTm reaches FFFF _H , the counter overflows and TAUBnCSR.OVF is set to 1. Afterwards, this procedure is repeated.
Stop operation	Set TAUBnTT.TTm to 1. TAUBnTT.TTm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm is cleared to 0 and the counter stops. TAUBnCNTm stops and it and TAUBnCSRm.OVF retain their current values.

Restart

(6) Specific timing diagrams

(a) Operation stop and restart




Figure 14-46 Operation stop and restart, TAUBnCMURm.TIS[1:0] = 11_B

- The counter can be stopped by setting TAUBnTT.TTm to 1, which in turn sets TAUBnTE.TEm to 0.
- TAUBnCNTm stops and the current value is retained.
- If the counter is stopped, valid TAUBnTTINm input edges are ignored.
- The counter can be restarted by setting TAUBnTS.TSm to 1. TAUBnCNTm restarts to count from 0000_H.

14.15.5 Overflow Interrupt Output Function (During TAUBnTTINm Input Period Count Detection)

(1) Overview

Summary This function measures the cumulative width of a TAUBnTTINm input signal. An interrupt is generated if the cumulative TAUBnTTINm input width is longer than $FFFF_H$.

- Prerequisites**
- The operation mode must be set to Gate Count Mode, refer to *Table 14-51 “TAUBnCMORm settings for Overflow Interrupt Output Function (During TAUBnTTINm Input Period Count Detection)” on page 551*
 - TAUBnTTOUTm is not used for this function
 - The value of TAUBnCDRm must be set to $FFFF_H$.

Description The counter is enabled by setting the channel trigger bit (TAUBnTS.TSm) to 1. This in turn sets TAUBnTE.TEm = 1, enabling count operation.

The counter starts when a valid TAUBnTTINm input start edge is detected. $FFFF_H$ is written to TAUBnCNTm and the counter starts to count down.

When a valid stop edge is detected, the counter stops and retains the current value. The counter awaits the next TAUBnTTINm input start edge and then continues to count down from the current value.

When the counter reaches 0000_H an interrupt is generated. $FFFF_H$ is written to TAUBnCNTm and the counter continues to count down until a TAUBnTTINm input stop edge is detected.

Conditions The valid start and stop edges are specified by the TAUBnCMURm.TIS[1:0] bits:

- If TAUBnCMURm.TIS[1:0] = 10_B , the TAUBnTTINm input low width is measured. The start trigger is a falling edge and the stop trigger is a rising edge.
- If TAUBnCMURm.TIS[1:0] = 11_B , the TAUBnTTINm input high width is measured. The start trigger is a rising edge and the stop trigger is a falling edge.

Note The counter cannot be restarted during operation.

(2) Block diagram and general timing diagram




Figure 14-47 Block diagram for Overflow Interrupt Output Function (During TAUBnTTINm Input Period Count Detection)

The following settings apply to the general timing diagram:

- Rising and falling edge detection = high width measurement (TAUBnCMURm.TIS[1:0] = 11_B)




Figure 14-48 General timing diagram for Overflow Interrupt Output Function (During TAUBnTTINm Input Period Count Detection)

(3) Register settings**(a) TAUBnCMORm**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	—	CCS0	MAS	STS[2:0]			COS[1:0]		—	MD[4:1]				MD0	

Table 14-51 TAUBnCMORm settings for Overflow Interrupt Output Function (During TAUBnTTINm Input Period Count Detection)

Bit name	Setting
CKS[1:0]	00: Operation clock = CK0 01: Operation clock = CK1 10: Operation clock = CK2 11: Operation clock = CK3
CCS0	0: Operation clock is used as the count clock
MAS	0: Not used, so set to 0
STS[2:0]	010: Valid edge of the TAUBnTTINm input signal is the external start trigger and the reverse edge is the stop trigger
COS[1:0]	00: Not used, so set to 00
MD[4:1]	1100: Gate Count Mode
MD0	0: INTTAUBnIm not generated at operation start

(b) TAUBnCMURm

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	TIS[1:0]	

Table 14-52 TAUBnCMURm settings for Overflow Interrupt Output Function (During TAUBnTTINm Input Period Count Detection)

Bit name	Setting
TIS[1:0]	10: Rising and falling edge detection (Low width measurement) 11: Rising and falling edge detection (High width measurement)

(c) Channel output mode

The channel output mode is not used by this function. However, it can be used in Direct Channel Output Mode.

(d) Simultaneous rewrite

The simultaneous rewrite registers (TAUBnRDE, TAUBnRDS, TAUBnRDM, and TAUBnRDC) cannot be used with the Overflow Interrupt Output Function (During TAUBnTTINm Input Period Count Detection). Therefore, these registers must be set to 0.

Table 14-53 Simultaneous rewrite settings for Overflow Interrupt Output Function (During TAUBnTTINm Input Period Count Detection)

Bit name	Setting
RDEm	0: Disables simultaneous rewrite
RDSm	0: When simultaneous rewrite is disabled (TAUBnRDE.RDEm = 0), set these bits to 0
RDMm	
RDCm	

(4) **Operating procedure for Overflow Interrupt Output Function
(during TAUBnTTINm input period count detection)**

**Table 14-54 Operating procedure for Overflow Interrupt Output Function
(during TAUBnTTINm input period count detection)**

	Operation	Status of TAUBn
Initial channel setting	Set the TAUBnCMORm register and TAUBnCMURm registers as described in <i>Table 14-51 "TAUBnCMORm settings for Overflow Interrupt Output Function (During TAUBnTTINm Input Period Count Detection)" on page 551</i> and <i>Table 14-52 "TAUBnCMURm settings for Overflow Interrupt Output Function (During TAUBnTTINm Input Period Count Detection)" on page 551</i> Set the value of the TAUBnCDRm register	Channel operation is stopped. (A clock is supplied, and a small amount of power is consumed.)
Start operation	Set TAUBnTS.TSm to 1. TAUBnTS.TSm is a trigger bit, so it is automatically cleared to 0. Detection of TAUBnTTINm start edge	TAUBnTE.TEm is set to 1 and TAUBnCNTm waits for detection of the start edge. When a start edge is detected, TAUBnCNTm loads the TAUBnCDRm value (FFFF _H).
	During operation	The TAUBnCNTm register can be read at all times. TAUBnCNTm counts down. When the counter reaches 0000 _H : <ul style="list-style-type: none"> • INTTAUBnIm is generated • TAUBnCNTm loads the TAUBnCDRm value (FFFF_H) and continues to count down. When a reverse edge of TAUBnTTINm is detected during count operation: <ul style="list-style-type: none"> • TAUBnCNTm counts down from the stop value. Afterwards, this procedure is repeated.
Stop operation	Set TAUBnTT.TTm to 1. TAUBnTT.TTm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm is cleared to 0 and the counter stops. TAUBnCNTm stops and retains its current value.



14.15.6 TAUBnTTINm Input Pulse Interval Judgment Function

(1) Overview

Summary This function outputs the result of a comparison between the count value (TAUBnCNTm) and the value in the channel data register (TAUBnCDRm) when a TAUBnTTINm input pulse occurs. An interrupt signal INTTAUBnIm is generated if the result of the comparison is true.

- Prerequisites**
- The operation mode must be set to Judge Mode, refer to *Table 14-55 "TAUBnCMORm settings for TAUBnTTINm Input Pulse Interval Judgment Function" on page 556*
 - TAUBnTTOUTm is not used for this function

Description The counter is started by setting the channel trigger bit (TAUBnTS.TSm) to 1. This in turn sets TAUBnTE.TEm = 1, enabling count operation. The current value of TAUBnCDRm is written to TAUBnCNTm and the counter starts to count down from this value.

When a TAUBnTTINm valid edge is detected or TAUBnTS.TSm is set to 1, the function compares the current values of TAUBnCNTm and TAUBnCDRm. An interrupt signal INTTAUBnIm is generated if the result of the comparison is true. TAUBnCNTm reloads the value of TAUBnCDRm and subsequently continues operation, regardless of the result of the comparison.

If the counter reaches 0000_H before a TAUBnTTINm valid edge is detected, TAUBnCNTm overflows and is set to FFFF_H. It then continues to count down.

The value of TAUBnCDRm can be rewritten at any time, and the changed value of TAUBnCDRm is applied the next time the function starts to count down.

- Conditions** The TAUBnCMORm.MD0 bit specifies the type of comparison:
- If TAUBnCMORm.MD0 = 0, INTTAUBnIm is generated when TAUBnCNTm ≤ TAUBnCDRm.
 - If TAUBnCMORm.MD0 = 1, INTTAUBnIm is generated when TAUBnCNTm > TAUBnCDRm.

(2) Block diagram and general timing diagram




Figure 14-49 Block diagram for TAUBnTTINm Input Pulse Interval Judgment Function

The following settings apply to the general timing diagram:

- INTTAUBnIm not generated at operation start (TAUBnCMORm.MD0 = 0)
- Falling edge detection (TAUBnCMURm.TIS[1:0] = 00_B)




Figure 14-50 General timing diagram for TAUBnTTINm Input Pulse Interval Judgment Function

(3) Register settings**(a) TAUBnCMORm**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	—	CCS0	MAS	STS[2:0]			COS[1:0]		—	MD[4:1]				MD0	

Table 14-55 TAUBnCMORm settings for TAUBnTTINm Input Pulse Interval Judgment Function

Bit name	Setting
CKS[1:0]	00: Operation clock = CK0 01: Operation clock = CK1 10: Operation clock = CK2 11: Operation clock = CK3
CCS0	0: Operation clock is used as the count clock
MAS	0: Not used, so set to 0
STS[2:0]	001: Valid edge of the TAUBnTTINm input signal is the external start trigger
COS[1:0]	00: Not used, so set to 00
MD[4:1]	0001: Judge Mode
MD0	0: INTTAUBnIm is generated when TAUBnCNTm ≤ TAUBnCDRm 1: INTTAUBnIm is generated when TAUBnCNTm > TAUBnCDRm

(b) TAUBnCMURm

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	TIS[1:0]	

Table 14-56 TAUBnCMURm settings for TAUBnTTINm Input Pulse Interval Judgment Function

Bit name	Setting
TIS[1:0]	00: Falling edge detection 01: Rising edge detection 10: Rising and falling edge detection (low width measurement) 11: Rising and falling edge detection (high width measurement)

(c) Channel output mode

The channel output mode is not used by this function. However, it can be used in Direct Channel Output Mode.

(d) Simultaneous rewrite

The simultaneous rewrite registers (TAUBnRDE, TAUBnRDS, TAUBnRDM, and TAUBnRDC) cannot be used with the TAUBnTTINm Input Pulse Interval Judgment Function. Therefore, these registers must be set to 0.

Table 14-57 Simultaneous rewrite settings for TAUBnTTINm Input Pulse Interval Judgment Function

Bit name	Setting
RDE.RDEm	0: Disables simultaneous rewrite
RDS.RDSm	0: When simultaneous rewrite is disabled (TAUBnRDE.RDEm = 0), set these bits to 0
RDM.RDMm	
RDC.RDCm	

(4) Operating procedure for for TAUBnTTINm Input Pulse Interval Judgment Function

Table 14-58 Operating procedure for TAUBnTTINm Input Pulse Interval Judgment Function

	Operation	Status of TAUBn
Initial channel setting	Set the TAUBnCMORm register and TAUBnCMURm registers as described in <i>Table 14-55 "TAUBnCMORm settings for TAUBnTTINm Input Pulse Interval Judgment Function" on page 556</i> and <i>Table 14-56 "TAUBnCMURm settings for TAUBnTTINm Input Pulse Interval Judgment Function" on page 556</i>	Channel operation is stopped. (A clock is supplied, and a small amount of power is consumed.)
	Set the value of the TAUBnCDRm register	
Start operation	Set TAUBnTS.TSm to 1. TAUBnTS.TSm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm is set to 1 and the counter starts. TAUBnCNTm loads the TAUBnCDRm value.
During operation	Detection of TAUBnTTINm edges. The value of TAUBnCDRm can be changed at any time. The TAUBnCNTm register can be read at any time.	TAUBnCNTm counts down. When a TAUBnTTINm input edge is detected <ul style="list-style-type: none"> • TAUBnCNTm reloads TAUBnCDRm and continues count operation. • TAUBnCNTm compares the values and judges the condition according to the TAUBnCMORm.MD0 setting. • If the condition is satisfied, INTTAUBnIm is generated. Afterwards, this procedure is repeated.
Stop operation	Set TAUBnTT.TTm to 1. TAUBnTT.TTm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm is cleared to 0 and the counter stops. TAUBnCNTm stops and retains its current value.

Restart

14.15.7 TAUBnTTINm Input Signal Width Judgment Function

(1) Overview

Summary This function outputs the result of a comparison between the count value (TAUBnCNTm) and the value in the channel data register (TAUBnCDRm) at a valid stop edge of a TAUBnTTINm input signal. An interrupt signal INTTAUBnIm is generated if the result of the comparison is true.

- Prerequisites**
- The operation mode must be set to Judge & One Count Mode, refer to *Table 14-59 "TAUBnCMORm settings for TAUBnTTINm Input Signal Width Judgment Function"* on page 561
 - TAUBnTTOUTm is not used for this function

Description The counter is started by setting the channel trigger bit (TAUBnTS.TSm) to 1. This in turn sets TAUBnTE.TEm = 1, enabling count operation. When a valid TAUBnTTINm input start edge is detected, the current value of TAUBnCDRm is written to TAUBnCNTm and the counter starts to count down from this value.

When a TAUBnTTINm valid stop edge is detected, the function compares the current values of TAUBnCNTm and TAUBnCDRm. An interrupt signal INTTAUBnIm is generated if the result of the comparison is true. The counter TAUBnCNTm retains its value until the next TAUBnTTINm valid start edge is detected, regardless of the result of the comparison.

If the counter reaches 0000_H before a valid TAUBnTTINm stop edge is detected, TAUBnCNTm overflows and is set to FFFF_H. It then continues to count down.

The value of TAUBnCDRm can be rewritten at any time, and the changed value of TAUBnCDRm is applied the next time the function starts to count down.

- Conditions**
- The TAUBnCMORm.MD0 bit specifies the type of comparison:
 - If TAUBnCMORm.MD0 = 0, INTTAUBnIm is generated when $TAUBnCNTm \leq TAUBnCDRm$.
 - If TAUBnCMORm.MD0 = 1, INTTAUBnIm is generated when $TAUBnCNTm > TAUBnCDRm$.
 - The TAUBnCMURm.TIS[1:0] bits specify the type of width measurement:
 - For high width measurement, the start edge is a rising TAUBnTTINm edge and the stop edge is a falling TAUBnTTINm edge.
 - For low width measurement, the start edge is a falling TAUBnTTINm edge and the stop edge is a rising TAUBnTTINm edge.
 - Forced restart is not possible for this function.

(2) Block diagram and general timing diagram




Figure 14-51 Block diagram for TAUBnTTINm Input Signal Width Judgment Function

The following settings apply to the general timing diagram:

- INTTAUBnIm is generated when $TAUBnCNTm \leq TAUBnCDRm$ ($TAUBnCMORm.MD0 = 0$)
- TAUBnTTINm valid start edge = rising edge, TAUBnTTINm valid stop edge = falling edge ($TAUBnCMURm.TIS[1:0] = 11_B$)




Figure 14-52 General timing diagram for TAUBnTTINm Input Signal Width Judgment Function

(3) Register settings**(a) TAUBnCMORm**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	—	CCS0	MAS	STS[2:0]			COS[1:0]		—	MD[4:1]				MD0	

Table 14-59 TAUBnCMORm settings for TAUBnTTINm Input Signal Width Judgment Function

Bit name	Setting
CKS[1:0]	00: Operation clock = CK0 01: Operation clock = CK1 10: Operation clock = CK2 11: Operation clock = CK3
CCS0	0: Operation clock is used as the count clock
MAS	0: Not used, so set to 0
STS[2:0]	010: Valid edge of the TAUBnTTINm input signal is the external start trigger and the reverse edge is the stop trigger
COS[1:0]	00: Not used, so set to 00
MD[4:1]	0111: Judge & One Count Mode
MD0	0: INTTAUBnIm is generated when $TAUBnCNTm \leq TAUBnCDRm$ 1: INTTAUBnIm is generated when $TAUBnCNTm > TAUBnCDRm$

(b) TAUBnCMURm

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	TIS[1:0]	

Table 14-60 TAUBnCMURm settings for TAUBnTTINm Input Signal Width Judgment Function

Bit name	Setting
TIS[1:0]	10: Rising and falling edge detection (low width measurement) 11: Rising and falling edge detection (high width measurement)

(c) Channel output mode

The channel output mode is not used by this function. However, it can be used in Direct Channel Output Mode.

(d) Simultaneous rewrite

The simultaneous rewrite registers (TAUBnRDE, TAUBnRDS, TAUBnRDM, and TAUBnRDC) cannot be used with the TAUBnTTINm Input Signal Width Judgment Function. Therefore, these registers must be set to 0.

Table 14-61 Simultaneous rewrite settings for TAUBnTTINm Input Signal Width Judgment Function

Bit name	Setting
RDE.RDEm	0: Disables simultaneous rewrite
RDS.RDSm	0: When simultaneous rewrite is disabled (TAUBnRDE.RDEm = 0), set these bits to 0
RDM.RDMm	
RDC.RDCm	

(4) Operating procedure for TAUBnTTINm Input Signal Width Judgment Function

Table 14-62 Operating procedure for TAUBnTTINm Input Signal Width Judgment Function

	Operation	Status of TAUBn
Initial channel setting	Set the TAUBnCMORm register and TAUBnCMURm registers as described in <i>Table 14-59 "TAUBnCMORm settings for TAUBnTTINm Input Signal Width Judgment Function" on page 561</i> and <i>Table 14-60 "TAUBnCMURm settings for TAUBnTTINm Input Signal Width Judgment Function" on page 561</i>	Channel operation is stopped. (A clock is supplied, and a small amount of power is consumed.)
	Set the value of the TAUBnCDRm register	
Start operation	Set TAUBnTS.TSm to 1. TAUBnTS.TSm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm is set to 1 and TAUBnCNTm waits for detection of the TAUBnTTINm start edge.
	Detection of TAUBnTTINm start edge	When a TAUBnTTINm start edge is detected, TAUBnCNTm loads the TAUBnCDRm value.
During operation	Detection of TAUBnTTINm edges	TAUBnCNTm counts down. When a TAUBnTTINm stop edge is detected:
	The value of TAUBnCDRm can be changed at any time. The TAUBnCNTm register can be read at any time.	<ul style="list-style-type: none"> • TAUBnCNTm stops and waits for detection of the TAUBnTTINm start edge. • TAUBnCNTm compares the values and judges the condition according to the TAUBnCMORm.MD0. • If the condition is satisfied, INTTAUBnIm is generated. Afterwards, this procedure is repeated.
Stop operation	Set TAUBnTT.TTm to 1. TAUBnTT.TTm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm is cleared to 0 and the counter stops. TAUBnCNTm stops and retains its current value.

Restart

14.16 Independent Channel Simultaneous Rewrite Functions

This chapter describes functions that carry out simultaneous rewrite:

- 14.16.1 *“Simultaneous Rewrite Trigger Generation Function Type 1”*

14.16.1 Simultaneous Rewrite Trigger Generation Function Type 1

(1) Overview

Summary This function generates an interrupt on a specific channel that can be used by lower channels as a simultaneous rewrite trigger. The interrupt is generated at regular intervals.

- Prerequisites**
- Two (or more) channels, each with simultaneous rewrite enabled (TAUBnRDE.RDEm = 1)
 - The operation mode of the upper channel must be set to Interval Timer Mode, refer to *Table 14-63 “TAUBnCMORm settings for Simultaneous Rewrite Trigger Generation Function Type 1” on page 568*
 - The operation mode of the lower channel(s) can be set as desired

Description The counters are started by setting the channel trigger bits (TAUBnTS.TSm and TAUBnTS.TSm_lower) to 1. This in turn sets TAUBnTE.TEm and TAUBnTE.TEm_lower = 1, enabling count operation. The current value of the data register buffer of the upper channel (TAUBnCDRm buf) is written to the counter (TAUBnCNTm) and the counter starts to count down from this value. The counter(s) of the lower channel(s) start to count as specified by their selected operating modes.

When a counter reaches 0000_H, an interrupt is generated from the channel. The corresponding TAUBnCNTm then reloads the current TAUBnCDRm buffer value and subsequently continues operation.

If the channel where the interrupt occurs is specified as the trigger channel for simultaneous rewrite (TAUBnRDC.RDCm = 1) and is an upper channel, simultaneous rewrite takes place on all lower channels in which simultaneous rewrite is currently possible (TAUBnRSF.RSFm = 1).

The values of the data registers are copied to the corresponding data register buffers. Each time a counter starts to count down, it reads the value in the data register buffer and counts down from this value.

The value of a data register can be changed at any time, but it is only transferred to the corresponding data register buffer when simultaneous rewrite occurs.

- Conditions**
- The channel which is monitored for INTTAUBnIm is specified by setting TAUBnRDC.RDCm = 1 for the corresponding channel. The TAUBnRDC.RDCm bit must be 0 for all other channels in which simultaneous rewrite should take place.
 - If the TAUBnCMORm.MD0 bit is set to 0, the first interrupt after a start or restart is not generated. For details refer to *14.11 “TAUBnTTOUTm toggle and INTTAUBnIm Generation when Counter start is triggered (MD0-bit)” on page 498*.

(2) Equations

Simultaneous rewrite trigger generation cycle = count clock cycle × (TAUBnCDRm + 1)

To control simultaneous rewrite, the following condition must be satisfied:

$$\text{TAUBnCDRm} = [(\text{value of TAUBnCDRm of master channel subject to simultaneous rewrite} + 1) \times \text{number of interrupts}] - 1$$

That is, the ratio of TAUBnCDRm + 1 and TAUBnCDRm_master + 1 must be an integer. This integer corresponds to the number of interrupts.

(3) Block diagram and general timing diagram




Figure 14-53 Block diagram for Simultaneous Rewrite Trigger Generation Function Type 1

The following settings apply to the general timing diagram:

- INTTAUBnIm generated at operation start (TAUBnCMORm.MD0 = 1)




Figure 14-54 General timing diagram for Simultaneous Rewrite Trigger Generation Function Type 1

(4) Register settings for the upper channel**(a) TAUBnCMORm for the upper channel**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	—	CCS0	MAS	STS[2:0]			COS[1:0]		—	MD[4:1]				MD0	

Table 14-63 TAUBnCMORm settings for Simultaneous Rewrite Trigger Generation Function Type 1

Bit name	Setting
CKS[1:0]	00: Operation clock = CK0 01: Operation clock = CK1 10: Operation clock = CK2 11: Operation clock = CK3
CCS0	0: Operation clock is used as the count clock
MAS	0: Not used, so set to 0
STS[2:0]	000: Counter triggered by software trigger
COS[1:0]	00: Not used, so set to 00
MD[4:1]	0000: Interval Timer Mode
MD0	0: INTTAUBnIm not generated at operation start 1: Generates INTTAUBnIm at operation start

(b) TAUBnCMURm for the upper channel

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	TIS[1:0]

Table 14-64 TAUBnCMURm settings for Simultaneous Rewrite Trigger Generation Function Type 1

Bit name	Setting
TIS[1:0]	00: Not used, so set to 00

(c) Channel output mode for the upper channel

The channel output mode is not used by this function. However, it can be used in Direct Channel Output Mode.

(d) Simultaneous rewrite for the upper channel

Table 14-65 Simultaneous rewrite settings for Simultaneous Rewrite Trigger Generation Function Type 1

Bit name	Setting
RDE.RDEm	1: Enables simultaneous rewrite
RDS.RDSm	1: Selects an upper channel as the control channel for simultaneous rewrite
RDM.RDMm	0: The signal that controls simultaneous rewrite is loaded when the master channel starts counting
RDC.RDCm	1: Channel is monitored for an INTTAUBnIm signal that is used as the simultaneous rewrite trigger

(5) Register settings for the lower channel(s)**(a) TAUBnCMORm for the lower channel(s)**

The TAUBnCMORm register of the lower channel(s) can be set arbitrarily.

(b) TAUBnCMURm for the lower channel(s)

The TAUBnCMURm register of the lower channel(s) can be set arbitrarily.

(c) Channel output mode for the lower channel(s)

The channel output mode is not used by this function. However, it can be used in Direct Channel Output Mode.

(d) Simultaneous rewrite for the lower channel(s)

Table 14-66 Simultaneous rewrite settings for the lower channel in Simultaneous Rewrite Trigger Generation Function Type 1

Bit name	Setting
RDE.RDEm	1: Enables simultaneous rewrite
RDS.RDSm	1: Selects an upper channel as the control channel for simultaneous rewrite
RDM.RDMm	0: The signal that controls simultaneous rewrite is loaded when the master channel starts counting
RDC.RDCm	0: Channel is not monitored for an INTTAUBnIm signal that is used as the simultaneous-rewrite trigger

(6) Operating procedure for Simultaneous Rewrite Trigger Generation Function Type 1

Table 14-67 Operating procedure for Simultaneous Rewrite Trigger Generation Function Type 1

	Operation	Status of TAUBn
Restart	Initial channel setting Set the TAUBnCMORm register and TAUBnCMURm registers for the upper channel as described in <i>Table 14-63 "TAUBnCMORm settings for Simultaneous Rewrite Trigger Generation Function Type 1" on page 568</i> and <i>Table 14-64 "TAUBnCMURm settings for Simultaneous Rewrite Trigger Generation Function Type 1" on page 568</i> Set the TAUBnCMORm register and TAUBnCMURm registers for the lower channel as described in <i>5 "Register settings for the lower channel(s)"</i> Set the value of the TAUBnCDRm register	Channel operation is stopped. (A clock is supplied, and a small amount of power is consumed.)
	Start operation Set TAUBnTS.TSm to 1. TAUBnTS.TSm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm is set to 1 and the counter starts. TAUBnCNTm loads the TAUBnCDRm value. When TAUBnCMORm.MD0 = 1, INTTAUBnIm is generated and TAUBnTTOUTm toggles.
	During operation TAUBnRDT.RDTm can be changed. TAUBnRSF.RSFm can be read at all times.	TAUBnCNTm counts down. When the counter reaches 0000 _H : <ul style="list-style-type: none"> • TAUBnCNTm reloads the TAUBnCDRm value and continues count operation • INTTAUBnIm is generated • TAUBnTTOUTm toggles. Simultaneous rewrite is controlled when INTTAUBnIm is generated from the channel where TAUBnRDC.RDCm is set to 1. Afterwards, this procedure is repeated.
	Stop operation Set TAUBnTT.TTm to 1. TAUBnTT.TTm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm is cleared to 0 and the counter stops. TAUBnCNTm stops and both it and TAUBnTTOUTm retain their current values. When TAUBnTOE.TOEm is 0, TAUBnTTOUTm output is initialized to the value set by TAUBnTO.TOm.

14.17 Other Independent Channel Functions

This chapter describes a function that generates an interrupt when a certain number of TAUBnTTINm pulses has occurred, a function that divides the frequency of TAUBnTTINm, and a function that measures the duration between the function start and a TAUBnTTINm input signal:

- 14.17.1 *“External Event Count Function”*
- 14.17.2 *“Clock Divide Function”*
- 14.17.3 *“TAUBnTTINm Input Position Detection Function”*

14.17.1 External Event Count Function

(1) Overview

Summary This function is used as an event timer. It generates an interrupt (INTTAUBnIm) when a specific number of TAUBnTTINm input pulses has occurred.

Prerequisites

- The operation mode must be set to Event Count Mode, refer to *Table 14-68 “TAUBnCMORm settings for External Event Count Function” on page 574*
- TAUBnTTOUTm is not used for this function

Description The counter is enabled by setting the channel trigger bit (TAUBnTS.TSm) to 1. This in turn sets TAUBnTE.TEm = 1, enabling count operation. When the counter starts, the current value of TAUBnCDRm is written to TAUBnCNTm.

When a valid TAUBnTTINm input edge is detected, the value of TAUBnCNTm reduces by 1. TAUBnCNTm retains this value until a valid TAUBnTTINm input edge is detected or the counter is restarted.

When the counter value reaches 0000_H, INTTAUBnIm is generated. TAUBnCNTm then reloads the TAUBnCDRm value and subsequently continues operation.

The counter can be stopped by setting TAUBnTT.TTm to 1, which in turn sets TAUBnTE.TEm to 0. TAUBnCNTm stops and retains its value. The counter can be restarted by setting TAUBnTS.TSm to 1. The counter can also be restarted without stopping it first (forced restart) by setting TAUBnTS.TSm to 1 during operation.

The value of TAUBnCDRm can be rewritten at any time, and the changed value of TAUBnCDRm is applied the next time the counter starts to count down.

Conditions The type of edge used as the trigger is specified by the TAUBnCMURm.TIS[1:0] bits:

- If TAUBnCMURm.TIS[1:0] = 00_B, the falling edges are counted.
- If TAUBnCMURm.TIS[1:0] = 01_B, the rising edges are counted.
- If TAUBnCMURm.TIS[1:0] = 10_B, the rising and falling edges are counted.

(2) Equations

Number of valid edges,
detected before INTTAUBnIm is generated = TAUBnCDRm + 1

(3) Block diagram and general timing diagram




Figure 14-55 Block diagram for External Event Count Function

The following settings apply to the general timing diagram:

- Rising edge detection (TAUBnCMURm.TIS[1:0] = 01_B)




Figure 14-56 General timing diagram for External Event Count Function

(4) Register settings**(a) TAUBnCMORm**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	—	CCS0	MAS	STS[2:0]			COS[1:0]		—	MD[4:1]				MD0	

Table 14-68 TAUBnCMORm settings for External Event Count Function

Bit name	Setting
CKS[1:0]	00: Operation clock = CK0 01: Operation clock = CK1 10: Operation clock = CK2 11: Operation clock = CK3
CCS0	1: Valid TAUBnTTINm input edge is used as the count clock
MAS	0: Not used, so set to 0
STS[2:0]	000: Counter triggered by software trigger
COS[1:0]	00: Not used, so set to 00
MD[4:1]	0011: Event Count Mode
MD0	0: INTTAUBnIm not generated at operation start

(b) TAUBnCMURm

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	TIS[1:0]

Table 14-69 TAUBnCMURm settings for External Event Count Function

Bit name	Setting
TIS[1:0]	00: Falling edge 01: Rising edge 10: Rising and falling edge

(c) Channel output mode

The channel output mode is not used by this function. However, it can be used in Direct Channel Output Mode.

(d) Simultaneous rewrite

The simultaneous rewrite registers (TAUBnRDE, TAUBnRDS, TAUBnRDM, and TAUBnRDC) cannot be used with the External Event Count Function. Therefore, these registers must be set to 0.

Table 14-70 Simultaneous rewrite settings for External Event Count Function

Bit name	Setting
RDEm	0: Disables simultaneous rewrite
RDSm	0: When simultaneous rewrite is disabled (TAUBnRDE.RDEm = 0), set these bits to 0
RDMm	
RDCm	

(5) Operating procedure for External Event Count Function

Table 14-71 Operating procedure for External Event Count Function

	Operation	Status of TAUBn
Restart	Initial channel setting Set the TAUBnCMORm register and TAUBnCMURm registers as described in Table 14-68 "TAUBnCMORm settings for External Event Count Function" on page 574 and Table 14-69 "TAUBnCMURm settings for External Event Count Function" on page 574 Set the value of the TAUBnCDRm register	Channel operation is stopped. (A clock is supplied, and a small amount of power is consumed.)
	Start operation Set TAUBnTS.TSm to 1. TAUBnTS.TSm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm is set to 1 and the counter starts. TAUBnCNTm loads the TAUBnCDRm value and waits for detection of the TAUBnTTINm input edge.
	During operation Detection of TAUBnTTINm edges. The value of TAUBnCDRm can be changed at any time. The TAUBnCNTm register can be read at any time.	TAUBnCNTm performs count-down operation each time a TAUBnTTINm input edge is detected. When the counter reaches 0000 _H : <ul style="list-style-type: none"> TAUBnCNTm reloads the TAUBnCDRm value and continues count operation INTTAUBnIm is generated. Afterwards, this procedure is repeated.
	Stop operation Set TAUBnTT.TTm to 1. TAUBnTT.TTm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm is cleared to 0 and the counter stops. TAUBnCNTm stops and retains its current value.

(6) Specific timing diagrams

(a) TAUBnCDRm = 0000H




Figure 14-57 TAUBnCDRm = 0000H, TAUBnCMURm.TIS[1:0] = 01

- If 0000H = TAUBnCDRm, 0000H is written to TAUBnCNTm every time a valid TAUBnTTINm input edge is detected.

This means, INTTAUBnIm is generated every time a valid TAUBnTTINm input edge is detected.

(b) Operation stop and restart




Figure 14-58 Operation stop and restart, TAUBnCMURm.TIS[1:0] = 01

- The counter can be stopped by setting TAUBnTT.TTm to 1, which in turn sets TAUBnTE.TEm to 0.
- TAUBnCNTm stops and the current value is retained. TAUBnTTINm continues and TAUBnCNTm ignores the valid edge.
- The counter can be restarted by setting TAUBnTS.TSm to 1. TAUBnCNTm loads the TAUBnCDRm value and restarts count operation.

(c) Forced restart




Figure 14-59 Forced restart, $TAUBnCMURm.TIS[1:0] = 01$

A forced restart applies a change to $TAUBnCDRm$ immediately.

- The counter can be restarted (without stopping it first), by setting $TAUBnTS.TSm$ to 1 during operation.
- The value of $TAUBnCDRm$ is written to $TAUBnCNTm$ and the counter awaits the next valid $TAUBnTTINm$ input edge.

14.17.2 Clock Divide Function

(1) Overview

Summary This function is used as a frequency divider. The frequency of the input signal TAUBnTTINm is divided by a factor related to TAUBnCDRm, and the resulting signal is output to TAUBnTTOUTm.

- Prerequisites**
- TAUBnTTINm must have a fixed frequency
 - The operation mode must be set to Interval Timer Mode, refer to *Table 14-72 “TAUBnCMORm settings for Clock Divide Function” on page 581*
 - The channel output mode must be set to Independent Channel Output Mode 1, refer to *14.9 “Channel Output Modes” on page 489*

Description The counter is started by setting the channel trigger bit (TAUBnTS.TSm) to 1. This in turn sets TAUBnTE.TEm = 1, enabling count operation. The current value of TAUBnCDRm is written to TAUBnCNTm and the counter starts to count down from this value, using TAUBnTTINm as the count clock.

When the counter value reaches 0000_H, INTTAUBnIm is generated and the TAUBnTTOUTm signal toggles. TAUBnCNTm then reloads the TAUBnCDRm value and subsequently continues operation.

The value of TAUBnCDRm can be rewritten at any time, and the changed value of TAUBnCDRm is applied the next time the function starts to count down.

The counter can be stopped by setting TAUBnTT.TTm = 1, which in turn sets TAUBnTE.TEm = 0. TAUBnCNTm and TAUBnTTOUTm stop but retain their values. The function can be restarted by setting TAUBnTS.TSm = 1. The counter can also be forcibly restarted (without stopping it first) by setting TAUBnTS.TSm = 1 during operation.

Conditions If the TAUBnCMORm.MD0 bit is set to 0, the first interrupt after a start or restart is not generated, and therefore TAUBnTTOUTm does not toggle. This results in an inverted TAUBnTTOUTm signal compared to when TAUBnCMORm.MD0 is set to 1. For details refer to *14.11 “TAUBnTTOUTm toggle and INTTAUBnIm Generation when Counter start is triggered (MD0-bit)” on page 498*.

Note The input TAUBnTTINm is sampled at the frequency of the operation clock, specified by TAUBnCMORm.CKS[1:0] bits. As a result, the output cycle of TAUBnTTOUTm has an error of ± 1 operation clock cycle.

(2) Equations

- When rising edge detection is selected:

$$\text{TAUBnTTOUTm frequency} = \text{TAUBnTTINm frequency} / [(\text{TAUBnCDRm} + 1) \times 2]$$
- When falling edge detection is selected:

$$\text{TAUBnTTOUTm frequency} = \text{TAUBnTTINm frequency} / [(\text{TAUBnCDRm} + 1) \times 2]$$
- When rising and falling edge detection is selected:

$$\text{TAUBnTTOUTm frequency} = \text{TAUBnTTINm frequency} / (\text{TAUBnCDRm} + 1)$$

(3) Block diagram and general timing diagram




Figure 14-60 Block diagram for Clock Divide Function

The following settings apply to the general timing diagram:

- INTTAUBnIm generated at operation start (TAUBnCMORM.MD0 = 1)
- Rising edge detection (TAUBnCMURm.TIS[1:0] = 01_B)




Figure 14-61 General timing diagram for Clock Divide Function

(4) Register settings**(a) TAUBnCMORm**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	—	CCS0	MAS	STS[2:0]			COS[1:0]		—	MD[4:1]				MD0	

Table 14-72 TAUBnCMORm settings for Clock Divide Function

Bit name	Setting
CKS[1:0]	00: Operation clock = CK0 01: Operation clock = CK1 10: Operation clock = CK2 11: Operation clock = CK3
CCS0	1: Valid TAUBnTTINm input edge is used as the count clock
MAS	0: Not used, so set to 0
STS[2:0]	000: Counter triggered by software trigger
COS[1:0]	00: Not used, so set to 00
MD[4:1]	0000: Interval Timer Mode
MD0	0: INTTAUBnIm not generated and TAUBnTTOUTm does not toggle at operation start 1: Generates INTTAUBnIm and toggles TAUBnTTOUTm at operation start

(b) TAUBnCMURm

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	TIS[1:0]	

Table 14-73 TAUBnCMURm settings for Clock Divide Function

Bit name	Setting
TIS[1:0]	00: Falling edge detection 01: Rising edge detection 10: Rising and falling edge detection

(c) Channel output mode**Table 14-74 Control bit settings for Independent Channel Output Mode 1**

Bit name	Setting
TOE.TOEm	1: Disables Direct Channel Output Mode
TOM.TOMm	0: Independent channel output
TOC.TOCm	0: Operation mode 1 (= Toggle mode if TAUBnTOM.TOMm = 0)
TOL.TOLm	0: Positive logic
TDE.TDEm	0: Disables dead time operation
TDL.TDLm	0: When dead time operation is disabled (TAUBnTDE.TDEm = 0), set these bits to 0

Note The channel output mode can also be set to Direct Channel Output Mode by setting TAUBnTOE.TOEm = 0. TAUBnTTOUTm can then be controlled independently of the interrupts. For details refer to *Table 14-16 “Channel output modes” on page 490*.

(d) Simultaneous rewrite

The simultaneous rewrite registers (TAUBnRDE, TAUBnRDS, TAUBnRDM, and TAUBnRDC) cannot be used with the Clock Divide Function. Therefore, these registers must be set to 0.

Table 14-75 Simultaneous rewrite settings for Clock Divide function

Bit name	Setting
RDE.RDEm	0: Disables simultaneous rewrite
RDS.RDSm	0: When simultaneous rewrite is disabled (TAUBnRDE.RDEm = 0), set these bits to 0
RDM.RDMm	
RDC.RDCm	

(5) Operating procedure for Clock Divide Function

Table 14-76 Operating procedure for Clock Divide Function

	Operation	Status of TAUBn
Restart	Initial channel setting Set the TAUBnCMORm register and TAUBnCMURm registers as described in <i>Table 14-72 "TAUBnCMORm settings for Clock Divide Function" on page 581</i> and <i>Table 14-73 "TAUBnCMURm settings for Clock Divide Function" on page 581</i> Set the value of the TAUBnCDRm register Set the channel output mode by setting the control bits as described in <i>Table 14-74 "Control bit settings for Independent Channel Output Mode 1" on page 582</i>	Channel operation is stopped. (A clock is supplied, and a small amount of power is consumed.)
	Start operation Set TAUBnTS.TSm to 1. TAUBnTS.TSm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm is set to 1 and the counter starts. TAUBnCNTm loads the TAUBnCDRm value. When TAUBnCMORm.MD0 is set to 1, INTTAUBnIm is generated and TAUBnTTOUTm toggles.
	During operation The value of TAUBnCDRm can be changed at any time. The TAUBnCNTm register can be read at all times.	When a TAUBnTTINm input edge is detected, TAUBnCNTm counts down. When the counter reaches 0000 _H : <ul style="list-style-type: none"> • TAUBnCNTm reloads the TAUBnCDRm value and continues count operation • INTTAUBnIm is generated • TAUBnTTOUTm toggles. Afterwards, this procedure is repeated.
	Stop operation Set TAUBnTT.TTm to 1. TAUBnTT.TTm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm is cleared to 0 and the counter stops. TAUBnCNTm stops and both it and TAUBnTTOUTm retain their current values. When TAUBnTOE.TOEm is 0, TAUBnTTOUTm output is initialized to the value set by TAUBnTO.TOm.

(6) Specific timing diagrams

(a) TAUBnCDRm = 0000H




Figure 14-62 TAUBnCDRm = 0000H, TAUBnCMORm.MD0 = 1, TAUBnCMURm.TIS[1:0] = 01

- If TAUBnCDRm is 0000H, TAUBnCNTm is also always 0000H.
- INTTAUBnIm is generated every count clock, resulting in TAUBnTTOUTm toggling every count clock.

(b) Restart




Figure 14-63 Restart, TAUBnCMORm.MD0 = 1, TAUBnCMURm.TIS[1:0] = 01

To reset the value of TAUBnTTOUTm:

- Set TAUBnTOE.TOEm = 0 when the counter is stopped (TAUBnTE.TEm = 0)
- Then write either 0 or 1 to TAUBnTO.TOm to set the new start value of TAUBnTTOUTm

(c) Forced restart




Figure 14-64 Forced restart, TAUBnCMORm.MD0 = 1, TAUBnCMURm.TIS[1:0] = 01

- The counter can be forcibly restarted (without stopping it first) by setting TAUBnTS.TSm = 1 during operation.
- The value of TAUBnCDRm is written to TAUBnCNTm and the count operation restarts.
- TAUBnTOUTm restarts at the same level as before the forced restart.

14.17.3 TAUBnTTINm Input Position Detection Function

(1) Overview

Summary This function measures the duration between the function start and a TAUBnTTINm input signal.

- Prerequisites**
- The operation mode must be set to Count Capture Mode, refer to *Table 14-77 "TAUBnCMORm settings for TAUBnTTINm Input Position Detection Function" on page 588*
 - TAUBnTTOUTm is not used for this function

Description The counter is enabled by setting the channel trigger bit (TAUBnTS.TSm) to 1. This in turn sets TAUBnTE.TEm = 1, enabling count operation. The counter starts to count from 0000_H. When a valid TAUBnTTINm input stop edge is detected, the current TAUBnCNTm value is written to TAUBnCDRm and an interrupt (INTTAUBnIm) is generated. The counter continues to count from the current value until the next valid TAUBnTTINm input edge is detected.

When the counter reaches FFFF_H, the bit TAUBnCSRm.OVF is set to 1 and the counter restarts from 0000_H. The value of TAUBnCSRm.OVF is reset by the CPU by TAUBnCSCm.CLOV = 1.

Note The input TAUBnTTINm is sampled at the frequency of the operation clock, specified by the TAUBnCMORm.CKS[1:0] bits. As a result, the output cycle of TAUBnTTOUTm has an error of ± 1 operation clock cycle.

Conditions If the TAUBnCMORm.MD0 bit is set to 0, the first interrupt after a start or restart is not generated. For details refer to *14.11 "TAUBnTTOUTm toggle and INTTAUBnIm Generation when Counter start is triggered (MD0-bit)" on page 498*.

(2) Equations

Function duration at a TAUBnTTINm input pulse =

count clock cycle × [(FFFF_H+1 × TAUBnCSRm.OVF) + (TAUBnCDRm capture value + 1)]

(3) Block diagram and general timing diagram




Figure 14-65 Block diagram for TAUBnTTINm Input Position Detection Function

The following settings apply to the general timing diagram:

- INTTAUBnIm not generated at operation start (TAUBnCMORM.MD0 = 0)
- Falling edge detection (TAUBnCMURm.TIS[1:0] = 00_B)




Figure 14-66 General timing diagram for TAUBnTTINm Input Position Detection Function

(4) Register settings**(a) TAUBnCMORm**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	—	CCS0	MAS	STS[2:0]			COS[1:0]		—	MD[4:1]				MD0	

Table 14-77 TAUBnCMORm settings for TAUBnTTINm Input Position Detection Function

Bit name	Setting
CKS[1:0]	00: Operation clock = CK0 01: Operation clock = CK1 10: Operation clock = CK2 11: Operation clock = CK3
CCS0	0: Operation clock is used as the count clock
MAS	0: Not used, so set to 0
STS[2:0]	001: Valid TAUBnTTINm input edge signal is used as the external capture trigger
COS[1:0]	01: Overflow (TAUBnCSRm.OVF) set upon counter overflow and cleared by a CPU instruction
MD[4:1]	1011: Count Capture Mode
MD0	0: INTTAUBnIm not generated at operation start 1: Generates INTTAUBnIm at operation start

(b) TAUBnCMURm

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	TIS[1:0]	

Table 14-78 TAUBnCMURm settings for TAUBnTTINm Input Position Detection Function

Bit name	Setting
TIS[1:0]	00: Falling edge detection 01: Rising edge detection 10: Rising and falling edge detection

(c) Channel output mode

The channel output mode is not used by this function. However, it can be used in Direct Channel Output Mode.

(d) Simultaneous rewrite

The simultaneous rewrite registers (TAUBnRDE, TAUBnRDS, TAUBnRDM, and TAUBnRDC) cannot be used with the TAUBnTTINm Input Position Detection Function. Therefore, these registers must be set to 0.

Table 14-79 Simultaneous rewrite settings for TAUBnTTINm Input Position Detection Function

Bit name	Setting
RDEm	0: Disables simultaneous rewrite
RDSm	0: When simultaneous rewrite is disabled (TAUBnRDE.RDEm = 0), set these bits to 0
RDMm	
RDCm	

(5) Operating procedure for TAUBnTTINm Input Position Detection Function

Table 14-80 Operating procedure for TAUBnTTINm Input Position Detection Function

	Operation	Status of TAUBn
Restart ↑	Initial channel setting Set the value of the TAUBnCDRm register	Channel operation is stopped. (A clock is supplied, and a small amount of power is consumed.)
	Start operation Set TAUBnTS.TSm to 1. TAUBnTS.TSm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm is set to 1 and the counter starts. INTTAUBnIm is generated when TAUBnCMORm.MD0 is set to 1.
	During operation The TAUBnCMURm.TIS[1:0] bits can be changed at any time. The TAUBnCDRm and TAUBnCSRm registers can be read at any time.	TAUBnCNTm starts to count up from 0000 _H . When a TAUBnTTINm valid edge is detected: <ul style="list-style-type: none"> • TAUBnCNTm transfers (captures) its value to TAUBnCDRm • TAUBnTTINm is output. • The counter value is not cleared to 0000_H and TAUBnCNTm continues count operation. Afterwards, this procedure is repeated.
	Stop operation Set TAUBnTT.TTm to 1. TAUBnTT.TTm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm is cleared to 0 and the counter stops. TAUBnCNTm stops and both it and TAUBnCSRm.OVF retain their current values.

(6) Specific timing diagrams

(a) Operation stop and restart




Figure 14-67 Operation stop and restart, TAUBnCMORm.MD0 = 0, TAUBnCMURm.TIS[1:0] = 00

- The counter can be stopped by setting TAUBnTT.TTm to 1, which in turn sets TAUBnTE.TEm to 0.
- TAUBnCNTm stops and the current value is retained.
- If the counter is stopped, valid TAUBnTTINm input edges are ignored.
- The counter can be restarted by setting TAUBnTS.TSm to 1. TAUBnCNTm restarts to count from 0000_H.

14.18 Synchronous Channel Operation Functions

This section lists all the synchronous channel operation functions provided by the Timer Array Unit B. For a general overview of synchronous channel operation, see 14.4 “*Functional Description*” on page 472 .

14.19 Synchronous PWM Signal Functions Triggered at Regular Intervals

This chapter describes functions that generate PWM signals at regular intervals, that can be reset by a TAUBnTTINm input, with and without dead time.

- 14.19.1 “*PWM Output Function*”
- 14.19.2 “*Delay Pulse Output Function*”
- 14.19.3 “*AD Conversion Trigger Output Function Type 1*”

14.19.1 PWM Output Function

(1) Overview

- Summary** This function generates multiple PWM outputs by using a master and multiple slave channels. It enables the pulse cycle (frequency) and the pulse width (duration) of the TAUBnTTOUTm to be set. The pulse cycle is set in the master channel. The pulse width is set in the slave channel.
- Prerequisites**
- Two channels
 - The operation mode of the master channel must be set to Interval Timer Mode, refer to *Table 14-81 “TAUBnCMORm settings for the master channel of the PWM Output Function” on page 596*
 - The operation mode of the slave channel(s) must be set to One Count Mode, refer to *Table 14-84 “TAUBnCMORm settings for the slave channel of the PWM Output Function” on page 598*
 - TAUBnTTOUTm is not used for the master channel of this function
 - The channel output mode of the slave channel(s) must be set to Synchronous Channel Output Mode 1 (*14.9 “Channel Output Modes” on page 489*)
- Description** The counters are started by setting the channel trigger bits (TAUBnTS.TSm) to 1. This in turn sets TAUBnTE.TEm = 1, enabling count operation. The current value of TAUBnCDRm is written to TAUBnCNTm and the counters start to count down from these values. INTTAUBnIm is generated on the master channel and TAUBnTTOUTm (slave) toggles.
- Master channel:

When the counter of the master channel reaches 0000_H, pulse cycle time has elapsed and INTTAUBnIm is generated. The counter reloads the TAUBnCDRm value and counts down.
 - Slave channel(s)

The INTTAUBnIm of the master channel triggers the counter of the slave channel(s). The current value of TAUBnCDRm (slave) is written to TAUBnCNTm (slave) and the counter starts to count down from this value. The TAUBnTTOUTm signal is set.

When the counter reaches 0000_H, i.e. duty time has elapsed, INTTAUBnIm is generated and the TAUBnTTOUTm signal is reset. The counter returns to FFFF_H and awaits the next INTTAUBnIm of the master channel, and thus the start of the next pulse cycle.

The counter can be stopped by setting TAUBnTT.TTm to 1 for the master and slave channel(s), which in turn sets TAUBnTE.TEm to 0. TAUBnCNTm and TAUBnTTOUTm of master and slave channel(s) stop but retain their values. The counters can be restarted by setting TAUBnTS.TSm to 1.
- Note** If a forced restart is executed during operation, the counter value becomes invalid and TAUBnTTOUTm is not output as expected PWM signal.
- Conditions** Simultaneous rewrite can be used with this function. Please refer to *14.8 “Simultaneous Rewrite” on page 479*

(2) Equations

Pulse cycle = (TAUBnCDRm (master) + 1) x count clock cycle

Duty cycle [%] = (TAUBnCDRm (slave) / (TAUBnCDRm (master) + 1)) x 100

– Duty cycle = 0 %

TAUBnCDRm (slave) = 0000_H

– Duty cycle = 100 %

TAUBnCDRm (slave) ≥ TAUBnCDRm (master) + 1


(3) Block diagram and general timing diagram

Figure 14-68 Block diagram for PWM Output Function

The following settings apply to the general timing diagram:

- Slave channel: Positive logic (TAUBnTOL.TOLm = 0)




Figure 14-69 General timing diagram for PWM Output Function

Note The interval between the slave channel starting to count and an interrupt being generated is the value of corresponding TAUBnCDRm, whereas for the master channel the interval is the corresponding TAUBnCDRm + 1.

(4) Register settings for the master channel**(a) TAUBnCMORm for the master channel**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	—	CCS0	MAS	STS[2:0]			COS[1:0]		—	MD[4:1]				MD0	

Table 14-81 TAUBnCMORm settings for the master channel of the PWM Output Function

Bit name	Setting
CKS[1:0]	00: Prescaler output CK0 01: Prescaler output CK1 10: Prescaler output CK2 11: Prescaler output CK3 The value of the CKS[1:0] bit of the master and slave channel(s) must be identical.
CCS0	0: Operation clock is used as the count clock
MAS	1: Channel is master channel
STS[2:0]	000: Counter triggered by software trigger
COS[1:0]	00: Not used, so set to 00
MD[4:1]	0000: Interval Timer Mode
MD0	1: Generates INTTAUBnIm at operation start

(b) TAUBnCMURm for the master channel

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	TIS[1:0]	

Table 14-82 TAUBnCMURm settings for the master channel of the PWM Output Function

Bit name	Setting
TIS[1:0]	00: Not used so set to 00

(c) Channel output mode for the master channel

The channel output mode is not used by this function. However, it can be used by other functions or in Direct Channel Output Mode.

(d) Simultaneous rewrite for the master channel

The simultaneous rewrite settings of the master and slave channel must be identical.

Table 14-83 Simultaneous rewrite settings for the master channel of the PWM Output Function

Bit name	Setting
RDE.RDEm	1: Enables simultaneous rewrite
RDS.RDSm	0: The master channel is monitored for the simultaneous rewrite trigger 1: An upper channel outside the channel group is monitored for the simultaneous rewrite trigger
RDM.RDMm	0: The simultaneous rewrite trigger signal is generated when the master channel starts counting
RDC.RDCm	0: Channel is not monitored for an INTTAUBnIm signal that is used as the simultaneous rewrite trigger. If TAUBnRDS.RDSm = 0, the master channel is monitored for the simultaneous rewrite trigger regardless of the value of this bit.

(5) Register settings for the slave channel(s)**(a) TAUBnCMORm for the slave channel(s)**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	—	CCS0	MAS	STS[2:0]			COS[1:0]		—	MD[4:1]				MD0	

Table 14-84 TAUBnCMORm settings for the slave channel of the PWM Output Function

Bit name	Setting
CKS[1:0]	00: Prescaler output CK0 01: Prescaler output CK1 10: Prescaler output CK2 11: Prescaler output CK3 The value of the CKS[1:0] bit of the master and slave channel(s) must be identical.
CCS0	0: Operation clock is used as the count clock
MAS	0: Channel is a slave channel
STS[2:0]	100: INTTAUBnIm of the master channel is the start trigger
COS[1:0]	00: Not used, so set to 00
MD[4:1]	0100: One Count Mode
MD0	1: Generates INTTAUBnIm and toggles TAUBnTTOUTm at operation start

(b) TAUBnCMURm for the slave channel(s)

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	TIS[1:0]	

Table 14-85 TAUBnCMURm settings for the slave channel of the PWM Output Function

Bit name	Setting
TIS[1:0]	00: Not used so set to 00

(c) Channel output mode for the slave channel(s)**Table 14-86 Control bit settings for Independent Channel Output Mode 1**

Bit name	Setting
TOEm	1: Disables Direct Channel Output Mode
TOMm	1: Synchronous channel operation
TOCm	0: Operation mode 1
TOLm	0: Positive logic 1: Inverted logic
TDEm	0: Disables dead time operation
TDLm	0: When dead time operation is disabled (TAUBnTDE.TDEm = 0), set these bits to 0

(d) Simultaneous rewrite for the slave channel(s)

The simultaneous rewrite settings of the master and slave channel must be identical.

Table 14-87 Simultaneous rewrite settings for the slave channel of the PWM Output Function

Bit name	Setting
RDE.RDEm	1: Enables simultaneous rewrite
RDS.RDSm	0: The master channel is monitored for the simultaneous rewrite trigger 1: An upper channel outside the channel group is monitored for the simultaneous rewrite trigger
RDM.RDMm	0: The simultaneous rewrite trigger signal is generated when the master channel starts counting
RDC.RDCm	0: Channel is not monitored for an INTTAUBnIm signal that is used as the simultaneous rewrite trigger. If TAUBnRDS.RDSm = 0, the master channel is monitored for the simultaneous rewrite trigger regardless of the value of this bit.

(6) Operating procedure for PWM Output Function

Table 14-88 Operating procedure for PWM Output Function

	Operation	Status of TAUBn
Restart ↑	Initial channel setting Master channel: set the TAUBnCMORm and TAUBnCMURm registers and the channel output mode as described in 4 "Register settings for the master channel" on page 596 Slave channel: set the TAUBnCMORm and TAUBnCMURm registers and the channel output mode as described in 5 "Register settings for the slave channel(s)" on page 598 Set the values of the TAUBnCDRm registers of all channels	Channel operation is stopped. (A clock is supplied, and a small amount of power is consumed.)
	Start operation Set TAUBnTS.TSm of the master and slave channels to 1 simultaneously. TAUBnTS.TSm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm (master and slave channels) is set to 1 and the counters of the master and slave channels start. INTTAUBnIm is generated on the master channel and TAUBnTTOUTm (slave) is set.
	During operation TAUBnCDRm can be changed at any time. TAUBnCNTm and TAUBnRSF.RSFm can be read at any time. TAUBnRDT.RDTm can be changed during operation.	TAUBnCNTm of the master channel loads TAUBnCDRm and counts down. When the counter reaches 0000 _H : <ul style="list-style-type: none"> • INTTAUBnIm (master) is generated • TAUBnCNTm (master) reloads the TAUBnCDRm value and continues count operation • TAUBnCNTm (slave) reloads the TAUBnCDRm value and counts down • TAUBnTTOUTm (slave) is set When TAUBnCNTm (slave) reaches 0000 _H : <ul style="list-style-type: none"> • INTTAUBnIm (slave) is generated • TAUBnTTOUTm (slave) is reset
	Stop operation Set TAUBnTT.TTm of the master and slave channels to 1 simultaneously. TAUBnTT.TTm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm is cleared to 0 and the counter stops. TAUBnCNTm and TAUBnTTOUTm stop and retain their current values. When TAUBnTOE.TOEm is 0, TAUBnTTOUTm output is initialized to the value set by TAUBnTO.TOm.

(7) Specific timing diagrams

(a) Duty cycle = 0 %




Figure 14-70 TAUBnCDRm (slave) = 0000_H,
positive logic (TAUBnTOL.TOLm (slave) = 0)

- Every time the master channel generates an interrupt (INTTAUBnIm), 0000_H is written to TAUBnCNTm (slave). Therefore, TAUBnCNTm (slave) cannot start to count and TAUBnTOUTm remains at not active state.
- TAUBnCNTm (slave) generates an interrupt every time the value of TAUBnCDRm is reloaded. The slave and the master channel generate interrupts in the same cycle.

(b) Duty cycle = 100 %




Figure 14-71 TAUBnCDRm (slave) \geq TAUBnCDRm (master) + 1, positive logic (TAUBnTOL.TOLm (slave) = 0)

- If the value TAUBnCDRm (slave) is higher than the value TAUBnCDRm (master), the counter of the slave channel cannot reach 0000_H and cannot generate interrupts. The TAUBnTOUTm remains at active state.

(c) Stop and restart operation




Figure 14-72 Stop and restart operation,
positive logic (TAUBnTOL.TOLm (slave) = 0)

- The counter can be stopped by setting TAUBnTT.TTm of the master and slave channel(s) to 1, which in turn sets TAUBnTE.TEm to 0.
- TAUBnCNTm and TAUBnTTOUTm of all channels stop and the current values are retained. No interrupts are generated.
- The counter can be restarted by setting TAUBnTS.TSm of master and slave channel(s) to 1. TAUBnCNTm of master and slave channel reload the current values of TAUBnCDRm and start to count down from these values.

14.19.2 Delay Pulse Output Function

(1) Overview

Summary This function outputs two signals. The reference signal has a defined pulse width and pulse cycle specified using the master channel and slave channel 1. Slave channels 2 and 3 output the reference signal with a specified delay. The delay signal is identical to the reference signal, but delayed by amount specified in slave channel 2.

The signal values are specified in the following way:

- The pulse cycle is specified using the master channel.
- The duty cycle of the reference signal is specified using slave channel 1. The duty cycle of the delay signal is specified using slave channel 3. The values of TAUBnCDRm of these both channels have to be identical.
- The delay is specified in slave channel 2.

- Prerequisites**
- Four channels
 - The operation mode of the master channel must be set to Interval Timer Mode, refer to *Table 14-89 "TAUBnCMORm settings for the master channel of the Delay Pulse Output Function" on page 608*
 - The operation mode of slave channel 1 and 2 must be set to One Count Mode, refer to *Table 14-92 "TAUBnCMORm settings for slave channel 1 of the Delay Pulse Output Function" on page 610*
 - The operation mode of slave channel 3 must be set to Pulse One Count Mode, refer to *Table 14-96 "TAUBnCMORm settings for slave channel 2 of the Delay Pulse Output Function" on page 612*
 - TAUBnTTOUTm is not used for the master channel and slave channel 2
 - The channel output mode of slave channel 1 must be set to Synchronous Channel Output Mode 1 (refer to *14.9 "Channel Output Modes" on page 489*)
 - The channel output mode of slave channel 3 must be set to Independent Channel Output Mode 1 (refer to *14.9 "Channel Output Modes" on page 489*)

Description The counters of the channel group are started by setting the channel trigger bit (TAUBnTS.TSm) to 1. This in turn sets TAUBnTE.TEm, enabling count operation.

- Master channel:

The current value of TAUBnCDRm is written to TAUBnCNTm and the counter starts to count down from this value. INTTAUBnIm is generated on the master channel.

When the counter of the master channel reaches 0000_H, pulse cycle time has elapsed and INTTAUBnIm is generated. The counter reloads the TAUBnCDRm value and counts down.

- Slave channels 1 and 2:

When the slave channels 1 and 2 detect an interrupt from the master channel, they start to count down from the current value of TAUBnCDRm. The TAUBnTTOUTm signal (slave 1) is set.

- Slave channel 1:

When the counter of slave channel 1 reaches 0000_H, duty time has elapsed, INTTAUBnIm is generated and the TAUBnTTOUTm signal is reset. The counter returns to FFFF_H and awaits the next INTTAUBnIm of the master channel.

- Slave channel 2:

When the counter of slave channel 2 reaches 0000_H, delay time has elapsed and INTTAUBnIm is generated. The counter returns to FFFF_H and awaits the next INTTAUBnIm of the master channel.

INTTAUBnIm (slave 2) triggers the counter of slave channel 3

- Slave channel 3:

When slave channel 3 detects an interrupt from slave channel 2, it starts to count down from the current value of TAUBnCDRm. INTTAUBnIm is generated and the TAUBnTTOUTm signal (slave 3) toggles.

When the counter of slave channel 3 reaches 0000_H, duty time has elapsed, INTTAUBnIm is generated and the TAUBnTTOUTm signal toggles again.

The output from slave channel 3 is the delayed PWM pulse

The counter can be stopped by setting TAUBnTT.TTm to 1 for the master and slave channels, which in turn sets TAUBnTE.TEm to 0. TAUBnCNTm and TAUBnTTOUTm of master and slave channels stop but retain their values. The counters can be restarted by setting TAUBnTS.TSm to 1.

Conditions Simultaneous rewrite can be used with this function. Please refer to 14.8 “Simultaneous Rewrite” on page 479

Equations Pulse cycle = (TAUBnCDRm (master) + 1) × count clock cycle
 Duty cycle = (TAUBnCDRm (slave 1 and 3)) × count clock cycle
 Delay = (TAUBnCDRm (slave 2) + 1) × count clock cycle

(2) Block diagram and general timing diagram




Figure 14-73 Block diagram for Delay Pulse Output Function

The following settings apply to the general timing diagram:

- All channels
 - INTTAUBnIm is generated at operation start (TAUBnCMORm.MD0 = 1)




Figure 14-74 General timing diagram for Delay Pulse Output Function

(3) Register settings for the master channel**(a) TAUBnCMORm for the master channel**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	—	CCS0	MAS	STS[2:0]			COS[1:0]		—	MD[4:1]				MD0	

Table 14-89 TAUBnCMORm settings for the master channel of the Delay Pulse Output Function

Bit name	Setting
CKS[1:0]	00: Prescaler output CK0 01: Prescaler output CK1 10: Prescaler output CK2 11: Prescaler output CK3 The value of the CKS[1:0] bit of the master and slave channel must be identical.
CCS0	0: Operation clock is used as the count clock
MAS	1: Channel is master channel
STS[2:0]	000: Counter triggered by software trigger
COS[1:0]	00: Not used, so set to 00
MD[4:1]	0000: Interval Timer Mode
MD0	1: Generates INTTAUBnIm at operation start

(b) TAUBnCMURm for the master channel

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	TIS[1:0]	

Table 14-90 TAUBnCMURm settings for the master channel of the Delay Pulse Output Function

Bit name	Setting
TIS[1:0]	00: Not used so set to 00

(c) Channel output mode for the master channel

The channel output mode is not used by the master channel of this function. However, it can be used by other functions or in Direct Channel Output Mode.

(d) Simultaneous rewrite for the master channel

The simultaneous rewrite settings of the master and slave channels must be identical.

Table 14-91 Simultaneous rewrite settings for the master channel of the Delay Pulse Output Function

Bit name	Setting
RDE.RDEm	1: Enables simultaneous rewrite
RDS.RDSm	0: The master channel is the control channel for simultaneous rewrite
RDM.RDMm	0: The simultaneous rewrite trigger signal is generated when the master channel starts counting
RDC.RDCm	0: Channel is not monitored for an INTTAUBnIm signal that is used as the simultaneous rewrite trigger. If TAUBnRDS.RDSm = 0, the master channel is monitored for the simultaneous rewrite trigger regardless of the value of this bit.

(4) Register settings for slave channel 1**(a) TAUBnCMORm for slave channel 1**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	—	CCS0	MAS	STS[2:0]			COS[1:0]		—	MD[4:1]				MD0	

Table 14-92 TAUBnCMORm settings for slave channel 1 of the Delay Pulse Output Function

Bit name	Setting
CKS[1:0]	00: Prescaler output CK0 01: Prescaler output CK1 10: Prescaler output CK2 11: Prescaler output CK3 The value of the CKS[1:0] bit of the master and slave channel must be identical.
CCS0	0: Operation clock is used as the count clock
MAS	0: Channel is a slave channel
STS[2:0]	100: TAUBnTTOUTm of the master channel is the start trigger
COS[1:0]	00: Not used, so set to 00
MD[4:1]	0100: One Count Mode
MD0	1: Generates INTTAUBnIm and toggles TAUBnTTOUTm at operation start (and enables start trigger during counting).

(b) TAUBnCMURm for slave channel 1

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	TIS[1:0]	

Table 14-93 TAUBnCMURm settings for slave channel 1 of the Delay Pulse Output Function

Bit name	Setting
TIS[1:0]	00: Not used so set to 00

(c) Channel output mode for slave channel 1**Table 14-94 Control bit settings for slave channel 1 of the Synchronous Channel Output Mode 2**

Bit name	Setting
TOEm	1: Disables Direct Channel Output Mode
TOMm	1: Synchronous channel operation
TOCm	0: Operation mode 1
TOLm	0: Positive logic 1: Inverted logic
TDEm	0: Disables dead time operation
TDLm	0: When dead time operation is disabled (TAUBnTDE.TDEm = 0), set these bits to 0

(d) Simultaneous rewrite for slave channel 1

The simultaneous rewrite settings of the master and slave channels must be identical.

Table 14-95 Simultaneous rewrite settings for slave channel 1 of the Delay Pulse Output Function

Bit name	Setting
RDE.RDEm	1: Enables simultaneous rewrite
RDS.RDSm	0: The master channel is the control channel for simultaneous rewrite
RDM.RDMm	0: The simultaneous rewrite trigger signal is generated when the master channel starts counting
RDC.RDCm	0: Channel is not monitored for an INTTAUBnIm signal that is used as the simultaneous rewrite trigger. If TAUBnRDS.RDSm = 0, the master channel is monitored for the simultaneous rewrite trigger regardless of the value of this bit.

(5) Register settings for slave channel 2**(a) TAUBnCMORm for slave channel 2**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	—	CCS0	MAS	STS[2:0]			COS[1:0]		—	MD[4:1]				MD0	

Table 14-96 TAUBnCMORm settings for slave channel 2 of the Delay Pulse Output Function

Bit name	Setting
CKS[1:0]	00: Prescaler output CK0 01: Prescaler output CK1 10: Prescaler output CK2 11: Prescaler output CK3 The value of the CKS[1:0] bit of the master and slave channel must be identical.
CCS0	0: Operation clock is used as the count clock
MAS	0: Channel is a slave channel
STS[2:0]	100: TAUBnTTOUTm of the master channel is the start trigger
COS[1:0]	00: Not used, so set to 00
MD[4:1]	0100: One Count Mode
MD0	1: Generates INTTAUBnIm at operation start (and enables start trigger during counting)

(b) TAUBnCMURm for slave channel 2

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	TIS[1:0]	

Table 14-97 TAUBnCMURm settings for slave channel 2 of the Delay Pulse Output Function

Bit name	Setting
TIS[1:0]	00: Not used so set to 00

(c) Channel output mode for slave channel 2

The channel output mode is not used by this function. However, it can be used by other functions or in Direct Channel Output Mode.

(d) Simultaneous rewrite for slave channel 2

The simultaneous rewrite settings of the master and slave channels must be identical.

Table 14-98 Simultaneous rewrite settings for slave channel 2 of the Delay Pulse Output Function

Bit name	Setting
RDE.RDEm	1: Enables simultaneous rewrite
RDS.RDSm	0: The master channel is the control channel for simultaneous rewrite
RDM.RDMm	0: The simultaneous rewrite trigger signal is generated when the master channel starts counting
RDC.RDCm	0: Channel is not monitored for an INTTAUBnIm signal that is used as the simultaneous rewrite trigger. If TAUBnRDS.RDSm = 0, the master channel is monitored for the simultaneous rewrite trigger regardless of the value of this bit.

(6) Register settings for slave channel 3**(a) TAUBnCMORm for slave channel 3**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	—	CCS0	MAS	STS[2:0]			COS[1:0]		—	MD[4:1]				MD0	

Table 14-99 TAUBnCMORm settings for slave channel 3 of the Delay Pulse Output Function

Bit name	Setting
CKS[1:0]	00: Prescaler output CK0 01: Prescaler output CK1 10: Prescaler output CK2 11: Prescaler output CK3 The value of the CKS[1:0] bit of the master and slave channel must be identical.
CCS0	0: Operation clock is used as the count clock
MAS	0: Channel is a slave channel
STS[2:0]	101: INTTAUBnIm of the upper channel (m-1) is the start trigger, regardless of the master setting
COS[1:0]	00: Not used, so set to 00
MD[4:1]	1010: Pulse One Count Mode
MD0	1: Generates INTTAUBnIm and toggles TAUBnTTOUTm at operation start (and enables start trigger during counting)

(b) TAUBnCMURm for slave channel 3

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	TIS[1:0]	

Table 14-100 TAUBnCMURm settings for slave channel 3 of the Delay Pulse Output Function

Bit name	Setting
TIS[1:0]	00: Not used so set to 00

(c) Channel output mode for slave channel 3**Table 14-101 Control bit settings for Synchronous Channel Output Mode 2**

Bit name	Setting
TOEm	1: Disables Direct Channel Output Mode
TOMm	0: Independent channel output
TOCm	0: Operation mode 1
TOLm	0: Positive logic 1: Inverted logic
TDEm	0: Disables dead time operation
TDLm	0: When dead time operation is disabled (TAUBnTDE.TDEm = 0), set these bits to 0

(d) Simultaneous rewrite for slave channel 3

The simultaneous rewrite settings of the master and slave channels must be identical.

Table 14-102 Simultaneous rewrite settings for slave channel 3 of the Delay Pulse Output Function

Bit name	Setting
RDE.RDEm	1: Enables simultaneous rewrite
RDS.RDSm	0: The master channel is the control channel for simultaneous rewrite
RDM.RDMm	0: The simultaneous rewrite trigger signal is generated when the master channel starts counting
RDC.RDCm	0: Channel is not monitored for an INTTAUBnIm signal that is used as the simultaneous rewrite trigger. If TAUBnRDS.RDSm = 0, the master channel is monitored for the simultaneous rewrite trigger regardless of the value of this bit.

(7) Operating procedure for Delay Pulse Output Function

Table 14-103 Operating procedure for Delay Pulse Output Function (1/2)

	Operation	Status of TAUBn
Initial channel setting	Master channel: set the TAUBnCMORm and TAUBnCMURm registers and the channel output mode as described in 3 "Register settings for the master channel" on page 608	Channel operation is stopped. (A clock is supplied, and a small amount of power is consumed.)
	Slave channel 1: set the TAUBnCMORm and TAUBnCMURm registers and the channel output mode as described in 4 "Register settings for slave channel 1" on page 610	
	Slave channel 2: set the TAUBnCMORm and TAUBnCMURm registers and the channel output mode as described in 5 "Register settings for slave channel 2" on page 612	
	Slave channel 3: set the TAUBnCMORm and TAUBnCMURm registers and the channel output mode as described in 6 "Register settings for slave channel 3" on page 614	
	Set the values of the TAUBnCDRm registers of all channels	

Table 14-103 Operating procedure for Delay Pulse Output Function (2/2)

	Operation	Status of TAUBn
Restart	Start operation Set TAUBnTS.TSm of the master and slave channels to 1 simultaneously. TAUBnTS.TSm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm (master and slave channels) is set to 1 and the counters of the master channel and slave channels 1 and 2 start. INTTAUBnIm is generated on the master channel and TAUBnTTOUTm (slave 1) is set.
	During operation TAUBnCDRm can be changed at any time. TAUBnCNTm and TAUBnRSF.RSFm can be read at any time. TAUBnRDT.RDTm can be changed during operation.	TAUBnCNTm of the master channel and slave channels 1 and 2 load TAUBnCDRm and count down. When the counter of the master channel reaches 0000 _H : <ul style="list-style-type: none"> • INTTAUBnIm (master) is generated • TAUBnCNTm (master) reloads the TAUBnCDRm value and continues count operation • TAUBnCNTm (slave 1 and slave 2) reload the TAUBnCDRm value and start counting down • TAUBnTTOUTm (slave 1) is set When TAUBnCNTm (slave 1) reaches 0000 _H : <ul style="list-style-type: none"> • INTTAUBnIm (slave 1) is generated The output from slave channel 1 acts as the reference pulse • TAUBnTTOUTm (slave 1) is reset When TAUBnCNTm (slave 2) reaches 0000 _H : <ul style="list-style-type: none"> • INTTAUBnIm (slave 2) is generated • TAUBnTTOUTm (slave 3) toggles • TAUBnCNTm (slave 3) reloads the TAUBnCDRm value and starts counting down When TAUBnCNTm (slave 3) reaches 0000 _H : <ul style="list-style-type: none"> • INTTAUBnIm (slave 3) is generated • TAUBnTTOUTm (slave 3) toggles The output from slave channel 3 is the delayed PWM pulse
	Stop operation Set TAUBnTT.TTm of the master and slave channels to 1 simultaneously. TAUBnTT.TTm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm is cleared to 0 and the counter stops. TAUBnCNTm and TAUBnTTOUTm stop and retain their current values. When TAUBnTOE.TOEm is 0, TAUBnTTOUTm output is initialized to the value set by TAUBnTO.TOm.

(8) Specific timing diagrams**(a) Duty cycle (slave 3) = 100 %**

The following values apply to the figure below:

- TAUBnCDRm (master) = 000A_H
- TAUBnCDRm (slave 1) = 000B_H
- TAUBnCDRm (slave 2) = 0000_H
- TAUBnCDRm (slave 3) = 000B_H




Figure 14-75 Duty cycle (slave 3) = 100 %

- If the value of TAUBnCDRm (slave 1 and 3) is higher than the value of TAUBnCDRm (master), the counter of the slave channels cannot reach 0000_H and cannot generate interrupts. TAUBnTTOUTm of channels 1 and 3 remain in the active state.

(b) TAUBnTTOUTm (slave 1) = TAUBnTTOUTm (slave 3)

The following values apply to the figure below:

- TAUBnCDRm (master) = 000A_H
- TAUBnCDRm (slave 1) = 0005_H
- TAUBnCDRm (slave 2) = 0000_H
- TAUBnCDRm (slave 3) = 0005_H




Figure 14-76 TAUBnTTOUTm (slave 1) = TAUBnTTOUTm (slave 3)

- If TAUBnCDRm (slave 2) = 0000_H, the counter of slave channel 3 starts counting one count clock later than the counter of slave channel 1. The reference pulse and the delay pulse are output with a delay of one clock count.

14.19.3 AD Conversion Trigger Output Function Type 1

(1) Overview

Summary This function is identical to 14.19.1 "PWM Output Function" on page 593 except that TAUBnTTOUTm is not output.

This is achieved by setting the channel output mode of the slave to Direct Channel Output Mode.

(2) Block diagram and general timing diagram




Figure 14-77 Block diagram for AD Conversion Trigger Output Function Type 1

(3) General timing diagram

The following settings apply to the general timing diagram:

- Slave channel: Positive logic (TAUBnTOL.TOLm = 0)




Figure 14-78 General timing diagram for AD Conversion Trigger Output Function Type 1

14.20 Synchronous PWM Signal Functions Triggered by an External Signal

This chapter describes functions that generate PWM signals and which are triggered by an external signal.

- 14.20.1 *“One-Shot Pulse Output Function”*

14.20.1 One-Shot Pulse Output Function

(1) Overview

Summary This function outputs a signal pulse with a defined pulse width and a specific delay time compared to an external input signal pulse by using a master and a slave channel. The delay time is specified using the master channel. The pulse width is specified using the slave channel.

- Prerequisites**
- Two channels
 - The operation mode of the master channel must be set to One Count Mode, refer to *Table 14-104 "TAUBnCMORm settings for the master channel of the One-Shot Pulse Output Function" on page 626*
 - The operation mode of the slave channel must be set to Pulse One Count Mode, refer to *Table 14-107 "TAUBnCMORm settings for the slave channel of the One-Shot Pulse Output Function" on page 628*
 - TAUBnTTOUTm is not used for the master channel of this function
 - The channel output mode of the slave channel must be set to Synchronous Channel Output Mode 2 (refer to *14.9 "Channel Output Modes" on page 489*)
 - TAUBnTTINm (master) has to be detected while TAUBnCNTm (master) and TAUBnCNTm (slave) await a trigger. Furthermore, the slave is only triggered by an interrupt from the master channel and not by TAUBnTTINm.

Description The counters are enabled by setting the channel trigger bits (TAUBnTS.TSm) to 1. This in turn sets TAUBnTE.TEm, enabling count operation.

- Master channel:

When the next valid TAUBnTTINm input edge is detected, the current value of TAUBnCDRm is written to TAUBnCNTm. The counter starts to count down from this value. If TAUBnCMORm.MD0 = 0, a trigger (TAUBnTTINm) which is detected within the delay time is ignored.

When the counter of the master channel reaches 0000_H, INTTAUBnIm is generated. The counter returns to FFFF_H and awaits the next valid TAUBnTTINm input edge.

- Slave channel

The INTTAUBnIm of the master channel triggers the counter of the slave channel. The current value of TAUBnCDRm (slave) is written to TAUBnCNTm (slave) and the counter starts to count down from this value. An interrupt is generated and the TAUBnTTOUTm signal is set.

When the counter reaches 0001_H, INTTAUBnIm is generated and the TAUBnTTOUTm signal is reset. The counter remains at 0001_H and awaits the next INTTAUBnIm of the master channel.

The counter can be stopped by setting TAUBnTT.TTm to 1 for the master and slave channel, which in turn sets TAUBnTE.TEm to 0. TAUBnCNTm and TAUBnTTOUTm of master and slave channel stop but retain their values. The counters can be restarted by setting TAUBnTS.TSm to 1.

The counter of the master channel can be restarted without stopping it first (forced restart) by setting TAUBnTS.TSm to 1 during operation.

- Notes**
1. If a forced restart of the slave channel is executed during operation, the width of the output signal does not correspond to the value of TAUBnCDRm (slave).
 2. The input TAUBnTTINm is sampled at the frequency of the operating clock, specified by TAUBnCMORm.CKS[1:0] bits. As a result, the output cycle of TAUBnTTOUTm has an error of ± 1 operation clock cycle.

- Conditions**
- If TAUBnCMORn.MD0 of the master channel is set to 0, during counting detected TAUBnTTINm input edges are ignored.
 - Simultaneous rewrite can be used with this function. Please refer to 14.8 “Simultaneous Rewrite” on page 479

Equations

Delay to input pulse = (TAUBnCDRm (master) + 1) × count clock cycle

Pulse width = (TAUBnCDRm (slave)) × count clock cycle

(2) Block diagram and general timing diagram




Figure 14-79 Block diagram for One-Shot Pulse Output Function

The following settings apply to the general timing diagram:

- Start trigger detection disabled during counting (TAUBnCMORm.MD0 = 0)
- Falling edge detection (TAUBnCMURm.TIS[1:0] = 00_B)




Figure 14-80 General timing diagram for One-Shot Pulse Output Function

(3) Register settings for the master channel**(a) TAUBnCMORm for the master channel**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	—	CCS0	MAS	STS[2:0]			COS[1:0]		—	MD[4:1]				MD0	

Table 14-104 TAUBnCMORm settings for the master channel of the One-Shot Pulse Output Function

Bit name	Setting
CKS[1:0]	00: Prescaler output CK0 01: Prescaler output CK1 10: Prescaler output CK2 11: Prescaler output CK3 The value of the CKS[1:0] bit of the master and slave channel must be identical.
CCS0	0: Operation clock is used as the count clock
MAS	1: Channel is master channel
STS[2:0]	001: Valid TAUBnTTINm input edge signal is used as the start trigger
COS[1:0]	00: Not used, so set to 00
MD[4:1]	0100: One Count Mode
MD0	0: Disables start trigger detection during counting 1: Enables start trigger detection during counting The value of the MD0 bit of the master and slave channel must be identical.

(b) TAUBnCMURm for the master channel

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	TIS[1:0]	

Table 14-105 TAUBnCMURm settings for the master channel of the One-Shot Pulse Output Function

Bit name	Setting
TIS[1:0]	00: Falling edge detection 01: Rising edge detection 10: Rising and falling edge detection 11: Setting prohibited

(c) Channel output mode for the master channel

The channel output mode is not used by this function. However, it can be used by other functions or in Direct Channel Output Mode.

(d) Simultaneous rewrite for the master channel

The simultaneous rewrite settings of the master and slave channel must be identical.

Table 14-106 Simultaneous rewrite settings for the master channel of the One-Shot Pulse Output Function

Bit name	Setting
RDE.RDEm	1: Enables simultaneous rewrite
RDS.RDSm	0: The master channel is the control channel for simultaneous rewrite
RDM.RDMm	0: The simultaneous rewrite trigger signal is generated when the master channel starts counting
RDC.RDCm	0: Channel is not monitored for an INTTAUBnIm signal that is used as the simultaneous rewrite trigger. If TAUBnRDS.RDSm = 0, the master channel is monitored for the simultaneous rewrite trigger regardless of the value of this bit.

(4) Register settings for the slave channel**(a) TAUBnCMORm for the slave channel**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	—	CCS0	MAS	STS[2:0]			COS[1:0]		—	MD[4:1]				MD0	

Table 14-107 TAUBnCMORm settings for the slave channel of the One-Shot Pulse Output Function

Bit name	Setting
CKS[1:0]	00: Prescaler output CK0 01: Prescaler output CK1 10: Prescaler output CK2 11: Prescaler output CK3 The value of the CKS[1:0] bit of the master and slave channel must be identical.
CCS0	0: Operation clock is used as the count clock
MAS	0: Channel is a slave channel
STS[2:0]	100: TAUBnTTOUTm of the master channel is the start trigger
COS[1:0]	00: Not used, so set to 00
MD[4:1]	1010: Pulse One Count Mode
MD0	0: Disables start trigger detection during counting 1: Enables start trigger detection during counting The value of the MD0 bit of the master and slave channel must be identical.

(b) TAUBnCMURm for the slave channel

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	TIS[1:0]	

Table 14-108 TAUBnCMURm settings for the slave channel of the One-Shot Pulse Output Function

Bit name	Setting
TIS[1:0]	00: Not used so set to 00

(c) Channel output mode for the slave channel**Table 14-109 Control bit settings for Synchronous Channel Output Mode 2**

Bit name	Setting
TOEm	1: Disables Direct Channel Output Mode
TOMm	0: Independent channel output
TOCm	1: Operation mode 2
TOLm	0: Positive logic 1: Inverted logic
TDEm	0: Disables dead time operation
TDLm	0: When dead time operation is disabled (TAUBnTDE.TDEm = 0), set these bits to 0

(d) Simultaneous rewrite for the slave channel

The simultaneous rewrite settings of the master and slave channel must be identical.

Table 14-110 Simultaneous rewrite settings for the slave channel of the One-Shot Pulse Output Function

Bit name	Setting
RDE.RDEm	1: Enables simultaneous rewrite
RDS.RDSm	0: The master channel is the control channel for simultaneous rewrite
RDM.RDMm	0: The simultaneous rewrite trigger signal is generated when the master channel starts counting
RDC.RDCm	0: Channel is not monitored for an INTTAUBnIm signal that is used as the simultaneous rewrite trigger. If TAUBnRDS.RDSm = 0, the master channel is monitored for the simultaneous rewrite trigger regardless of the value of this bit.

(5) Operating procedure for One-Shot Pulse Output Function

Table 14-111 Operating procedure for One-Shot Pulse Output Function

	Operation	Status of TAUBn
Restart ↓	Initial channel setting Master channel: set the TAUBnCMORm and TAUBnCMURm registers and the channel output mode as described in 3 "Register settings for the master channel" on page 626 Slave channel: set the TAUBnCMORm and TAUBnCMURm registers and the channel output mode as described in 4 "Register settings for the slave channel" on page 628 Set the values of the TAUBnCDRm registers of all channels	Channel operation is stopped. (A clock is supplied, and a small amount of power is consumed.)
	Start operation Set TAUBnTS.TSm of the master and slave channels to 1 simultaneously. TAUBnTS.TSm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm (master and slave channels) is set to 1 and the master channel awaits a TAUBnTTINm input. INTTAUBnIm is generated on the master channel.
	During operation TAUBnCDRm can be changed at any time. TAUBnCNTm and TAUBnRSF.RSFm can be read at any time. TAUBnRDT.RDTm can be changed during operation.	When a valid TAUBnTTINm input edge is detected, TAUBnCNTm of the master channel loads TAUBnCDRm and counts down. When the counter reaches 0000H: <ul style="list-style-type: none"> • INTTAUBnIm (master) is generated • TAUBnCNTm (master) reloads the TAUBnCDRm value and continues count operation • TAUBnCNTm (slave) reloads the TAUBnCDRm value and starts to count down • INTTAUBnIm (slave) is generated • TAUBnTTOUTm (slave) is set When TAUBnCNTm (slave) reaches 0001H: <ul style="list-style-type: none"> • INTTAUBnIm (slave) is generated • TAUBnTTOUTm (slave) is reset If a TAUBnTTINm input is detected on the master channel while the counter is counting, the input is ignored when TAUBnCMORm.MD0 = 0.
	Stop operation Set TAUBnTT.TTm of the master and slave channels to 1 simultaneously. TAUBnTT.TTm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm is cleared to 0 and the counter stops. TAUBnCNTm and TAUBnTTOUTm stop and retain their current values. When TAUBnTOE.TOEm is 0, TAUBnTTOUTm output is initialized to the value set by TAUBnTO.TOm.

(6) Specific timing diagrams

(a) TAUBnCDRm (master) = 0000H

The following settings apply to this diagram:

- Start trigger detection disabled during counting (TAUBnCMORm.MD0 = 0)
- Falling edge detection (TAUBnCMURm.TIS[1:0] = 00_B)




Figure 14-81 TAUBnCDRm (master) = 0000H

- When a valid TAUBnTTINm input edge is detected, the value 0000H is written to TAUBnCNTm (master). The counter is set to 0000H for one count and returns to FFFFH.

Thus the slave channel starts to count down one count clock later to TAUBnTTINm (master).

(b) TAUBnCDRm (slave) = 0000_H

The following settings apply to this diagram:

- Start trigger detection disabled during counting (TAUBnCMORm.MD0 = 0)
- Falling edge detection (TAUBnCMURm.TIS[1:0] = 00_B)




Figure 14-82 TAUBnCDRm (slave) = 0000_H

- The counter of the slave channel reloads the value 0000_H and returns to returns to FFFF_H one clock count later.

TAUBnTOUTm remains at not active state, because the pulse width is zero.

(c) TAUBnCMORm.MD0 = 1

The following settings apply to this diagram:

- Start trigger detection enabled during counting (TAUBnCMORm.MD0 = 1)
- Falling edge detection (TAUBnCMURm.TIS[1:0] = 00_B)




Figure 14-83 TAUBnCMORm.MD0 = 1

- If a valid TAUBnTTINm input edge is detected while the counter of the master channel counts down, TAUBnCNTm reloads the value of TAUBnCDRm. The counter restarts to count down.

This means the delay is extended by the value of TAUBnCNTm at the time a valid TAUBnTTINm input edge is detected.

(d) Restarting the master channel while the slave channel is counting

The following settings apply to this diagram:

- Start trigger detection disabled during counting (TAUBnCMORm.MD0 = 0)
- Falling edge detection (TAUBnCMURm.TIS[1:0] = 00_B)




Figure 14-84 Interval of TAUBnTTINm ≤ delay time + pulse width + 1

- If the master channel generates an interrupt before the counter of the slave channel has reached 0001_H or exactly when 0001_H is reached (*1), the interrupt (master) is ignored.
- If an interrupt of the master channel occurs when the counter of the slave channel awaits the next trigger, the value of TAUBnCDRm (slave) is reloaded. An interrupt is generated and TAUBnTTOUTm toggles. If TAUBnCNTm (master) has started to count down while the TAUBnCNTm (slave) is still counting (*2), TAUBnTTOUTm is not output with the expected delay time.
- To generate the correct one-shot pulse, the start trigger for the master channel must be detected while the master and slave channels are waiting for the start trigger, and not while they are counting.

14.21 Synchronous Triangle PWM Functions

This chapter describes functions that generate a triangle PWM output.

- 14.21.1 *“Triangle PWM Output Function”*
- 14.21.2 *“Triangle PWM Output Function with Dead Time”*
- 14.21.3 *“AD Conversion Trigger Output Function Type 2”*

14.21.1 Triangle PWM Output Function

(1) Overview

Summary This function generates multiple triangle PWM outputs by using a master and one or more slave channels. It enables the pulse cycle (frequency) and the duty cycle of TAUBnTTOUTm to be set using the master and slave channel(s) respectively.

The slave channel generates a carrier cycle from two pulse cycles. The first pulse of the master channel controls the down status and the second pulse controls the up status of the slaves counter.

Counting up and down TAUBnCNTm (slave) means that signal duration of TAUBnTTOUTm (slave) is double that of the difference between TAUBnCDRm (master) +1 and TAUBnCDRm (slave).

- Prerequisites**
- Two channels
 - The operation mode of the master channel must be set to Interval Timer Mode, refer to *Table 14-112 "TAUBnCMORm settings for the master channel of the Triangle PWM Output Function" on page 640*
 - The operation mode of the slave channel(s) must be set to Up Down Count Mode, refer to *Table 14-116 "TAUBnCMORm settings for the slave channel of the Triangle PWM Output Function" on page 642*
 - The channel output mode of the master channel must be set to Independent Channel Output Mode 1 (refer to *14.9 "Channel Output Modes" on page 489*)
 - The channel output mode of the slave channel(s) must be set to Synchronous Channel Output Mode 2 (refer to *14.9 "Channel Output Modes" on page 489*)
 - The following settings establish TAUBnTTOUTm at high level for the down status of the carrier cycle.
 - If the TAUBnCMORm.MD0 (master) bit is set to 0, TAUBnTO.TOm must be set to 1 while TAUBnTOE.TOEm is 0.
 - If the TAUBnCMORm.MD0 (master) bit is set to 1, TAUBnTO.TOm must be set to 0 while TAUBnTOE.TOEm is 0.

Description The counters are started by setting the channel trigger bit (TAUBnTS.TSm) to 1 for every channel. This in turn sets TAUBnTE.TEm, enabling count operation. The current values of TAUBnCDRm (master and slave) are written to TAUBnCNTm (master and slave) and the counters start to count down from these values. Depending on the setting of the master channel TAUBnCMORm.MD0 bit an interrupt is generated and TAUBnTTOUTm signal of the master toggles.

- Master channel:

When the counter of the master channel reaches 0000_H, pulse cycle time has elapsed, INTTAUBnIm is generated and the TAUBnTTOUTm signal toggles. TAUBnCNTm then reloads the TAUBnCDRm value and counts down.

- Slave channel:

The INTTAUBnIm of the master channel triggers the counter of the slave channel:

- If the slave counter currently counts down, it changes count direction .
- If the slave counter currently counts up, the value of TAUBnCDRm is reloaded and the counter counts down.

When the counter of the slave channel reaches 0001_H while counting up or down, INTTAUBnIm is generated and the TAUBnTTOUTm (slave) signal toggles:

- It is set in the count-down status
- It is reset in the count-up status

The counter continues to count down or up and awaits the next INTTAUBnIm of the master channel.

TAUBnTTOUTm can be switched between positive and negative phase setting TAUBnTOL.TOLm during operation.

The counters can be stopped by setting TAUBnTT.TTm to 1 for the master and slave channel(s), which in turn sets TAUBnTE.TEm to 0. TAUBnCNTm and TAUBnTTOUTm of master and slave channel(s) stop but retain their values.

Note If a forced restart is executed during operation, TAUBnTTOUTm is not output as a triangle PWM signal.

Conditions Simultaneous rewrite can be used with this function. Please refer to 14.8 “Simultaneous Rewrite” on page 479

(2) Equations

Pulse cycle = (TAUBnCDRm (master) + 1) x count clock cycle

Carrier cycle (down/up) = (TAUBnCDRm (master) + 1) x 2 x count clock cycle

Duty cycle [%] =

$$\frac{[(TAUBnCDRm (master) + 1 - TAUBnCDRm (slave))]}{(TAUBnCDRm (master) + 1)} \times 100$$

- Duty cycle = 100 %

TAUBnCDRm (slave) = 0000_H

- Duty cycle = 0 %

TAUBnCDRm (slave) ≥ TAUBnCDRm (master) + 1

(3) Block diagram and general timing diagram




Figure 14-85 Block diagram for Triangle PWM Output Function

The following settings apply to the general timing diagram:

- Master channel
 - INTTAUBnIm is generated at operation start (TAUBnCMORm.MD0 = 1)




Figure 14-86 General timing diagram for Triangle PWM Output Function

(4) Register settings for the master channel**(a) TAUBnCMORm for the master channel**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	—	CCS0	MAS	STS[2:0]			COS[1:0]		—	MD[4:1]				MD0	

Table 14-112 TAUBnCMORm settings for the master channel of the Triangle PWM Output Function

Bit name	Setting
CKS[1:0]	00: Prescaler output CK0 01: Prescaler output CK1 10: Prescaler output CK2 11: Prescaler output CK3 The value of the CKS[1:0] bit of the master and slave channel(s) must be identical.
CCS0	0: Operation clock is used as the count clock
MAS	1: Channel is master channel
STS[2:0]	000: Counter triggered by software trigger
COS[1:0]	00: Not used, so set to 00
MD[4:1]	0000: Interval Timer Mode
MD0	0: INTTAUBnIm not generated and TAUBnTTOUtm does not toggle at operation start 1: Generates INTTAUBnIm and toggles TAUBnTTOUtm at operation start

(b) TAUBnCMURm for the master channel

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	TIS[1:0]	

Table 14-113 TAUBnCMURm settings for the master channel of the Triangle PWM Output Function

Bit name	Setting
TIS[1:0]	00: Not used so set to 00

(c) Channel output mode for the master channel**Table 14-114 Control bit settings for Independent Channel Output Mode 1**

Bit name	Setting
TOEm	1: Disables Direct Channel Output Mode
TOMm	0: Independent channel output
TOCm	0: Operation mode 1 (= Toggle mode if TAUBnTOM.TOMm = 0)
TOLm	0: Positive logic
TDEm	0: Disables dead time operation
TDLm	0: When dead time operation is disabled (TAUBnTDE.TDEm = 0), set these bits to 0

(d) Simultaneous rewrite for the master channel

The simultaneous rewrite settings of the master and slave channel must be identical.

Table 14-115 Simultaneous rewrite settings for the master channel of the Triangle PWM Output Function

Bit name	Setting
RDE.RDEm	1: Enables simultaneous rewrite
RDS.RDSm	0: The master channel is monitored for the simultaneous rewrite trigger 1: An upper channel outside the channel group is monitored for the simultaneous rewrite trigger
RDM.RDMm	1: The simultaneous rewrite trigger signal is generated when the master channel starts counting and the corresponding slave channel is at the peak of a triangular wave
RDC.RDCm	0: Channel is not monitored for an INTTAUBnIm signal that is used as the simultaneous rewrite trigger. If TAUBnRDS.RDSm = 0, the master channel is monitored for the simultaneous rewrite trigger regardless of the value of this bit.

(5) Register settings for the slave channel(s)**(a) TAUBnCMORm for the slave channel(s)**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	—	CCS0	MAS	STS[2:0]			COS[1:0]		—	MD[4:1]				MD0	

Table 14-116 TAUBnCMORm settings for the slave channel of the Triangle PWM Output Function

Bit name	Setting
CKS[1:0]	00: Prescaler output CK0 01: Prescaler output CK1 10: Prescaler output CK2 11: Prescaler output CK3 The value of the CKS[1:0] bit of the master and slave channel(s) must be identical.
CCS0	0: Operation clock is used as the count clock
MAS	0: Channel is a slave channel
STS[2:0]	111: The up/down output trigger signal TAUBnTUDSm of the master channel is the start trigger
COS[1:0]	00: Not used, so set to 00
MD[4:1]	1001: Up Down Count Mode
MD0	0: INTTAUBnIm not generated at operation start

(b) TAUBnCMURm for the slave channel(s)

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	TIS[1:0]	

Table 14-117 TAUBnCMURm settings for the slave channel of the Triangle PWM Output Function

Bit name	Setting
TIS[1:0]	00: Not used so set to 00

(c) Channel output mode for the slave channel(s)**Table 14-118 Control bit settings for Synchronous Channel Output Mode 2**

Bit name	Setting
TOEm	1: Disables Direct Channel Output Mode
TOMm	1: Synchronous channel operation
TOCm	1: Operation mode 2
TOLm	0: Positive logic 1: Inverted logic
TDEm	0: Disables dead time operation
TDLm	0: When dead time operation is disabled (TAUBnTDE.TDEm = 0), set these bits to 0

(d) Simultaneous rewrite for the slave channel(s)

The simultaneous rewrite settings of the master and slave channel must be identical.

Table 14-119 Simultaneous rewrite settings for the slave channel of the Triangle PWM Output Function

Bit name	Setting
RDE.RDEm	1: Enables simultaneous rewrite
RDS.RDSm	0: The master channel is monitored for the simultaneous rewrite trigger 1: An upper channel is monitored for the simultaneous rewrite trigger
RDM.RDMm	1: The simultaneous rewrite trigger signal is generated when the master channel starts counting and the corresponding slave channel is at the peak of a triangular wave
RDC.RDCm	0: Channel is not monitored for an INTTAUBnIm signal that is used as the simultaneous rewrite trigger. If TAUBnRDS.RDSm = 0, the master channel is monitored for the simultaneous rewrite trigger regardless of the value of this bit.

(6) Operating procedure for Triangle PWM Output Function

Table 14-120 Operating procedure for Triangle PWM Output Function

	Operation	Status of TAUBn
Restart	Initial channel setting Master channel: set the TAUBnCMORm and TAUBnCMURm registers and the channel output mode as described in 4 "Register settings for the master channel" on page 640 Slave channel: set the TAUBnCMORm and TAUBnCMURm registers and the channel output mode as described in 5 "Register settings for the slave channel(s)" on page 642 Set the values of the TAUBnCDRm registers of all channels	Channel operation is stopped. (A clock is supplied, and a small amount of power is consumed.)
	Start operation Set TAUBnTS.TSm of the master and slave channels to 1 simultaneously. TAUBnTS.TSm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm (master and slave channels) is set to 1 and the counters of the master and slave channels start. INTTAUBnIm is generated on the master channel, depending on TAUBnCMORm.MD0.
	During operation TAUBnCDRm can be changed at any time. TAUBnCNTm and TAUBnRSF.RSFm can be read at any time. TAUBnRDT.RDTm can be changed during operation.	TAUBnCNTm of the master and slave channel loads TAUBnCDRm and counts down. When the counter of the master channel reaches 0000 _H : <ul style="list-style-type: none"> • INTTAUBnIm (master) is generated • TAUBnTTOUTm (master) toggles • TAUBnCNTm (master) reloads the TAUBnCDRm value and continues count operation. • TAUBnCNTm (slave) reloads the TAUBnCDRm value or counts in the reverse direction. When TAUBnCNTm of the slave = 0001 _H : <ul style="list-style-type: none"> • INTTAUBnIm (slave) is generated • TAUBnTTOUTm (slave) is set (in count-down status) or reset (in count-up status)
	Stop operation Set TAUBnTT.TTm of the master and slave channels to 1 simultaneously. TAUBnTT.TTm is a trigger bit, so it is automatically cleared to 0.	TAUBnTE.TEm is cleared to 0 and the counter stops. TAUBnCNTm and TAUBnTTOUTm stop and retain their current values. When TAUBnTOE.TOEm is 0, TAUBnTTOUTm is initialized to the value set by TAUBnTO.TOm.

(7) Specific timing diagrams**(a) Duty cycle = 0 %**

The following settings apply to the general timing diagram:

- Master channel:
 - INTTAUBnIm is generated at operation start ($TAUBnCMORm.MD0 = 1$)
 - $TAUBnCDRm = a = 5_H$
- Slave channel:
 - $TAUBnCDRm = 6_H$




Figure 14-87 $TAUBnCDRm (slave) \geq TAUBnCDRm (master) + 1$

- If $TAUBnCDRm (slave) \geq TAUBnCDRm (master)$ the counter of slave channel cannot reach 0001_H during *counting down*. The set signal is never detected, so $TAUBnTOUTm$ remains at low state.

(b) Duty cycle = 100 %

The following settings apply to the general timing diagram:

- Master channel:
 - INTTAUBnIm is generated at operation start ($\text{TAUBnCMORm.MD0} = 1$)
 - $\text{TAUBnCDRm} = a = 5_{\text{H}}$
- Slave channel:
 - $\text{TAUBnCDRm} = 0_{\text{H}}$




Figure 14-88 $\text{TAUBnCDRm (slave)} = 0000_{\text{H}}$

- If $\text{TAUBnCDRm (slave)} = 0000_{\text{H}}$ the counter of slave channel cannot reach 0001_{H} during *counting up*. The reset signal is never detected, so TAUBnTTOUTm remains at high state.

14.21.2 Triangle PWM Output Function with Dead Time

(1) Overview

Summary This function generates multiple triangle PWM outputs with a defined dead time by using a master and two or more slave channels. The resulting PWM signals are output via TAUBnTTOUTm of the slave channels 2 and 3. It enables the pulse cycle (frequency) and the duty cycle of TAUBnTTOUTm to be set using the master and slave channel(s) respectively.

Slave channel 2 generates a carrier cycle from two pulse cycles from the master channel. The first pulse controls the down status and the second pulse controls the up status of the slaves counter.

Counting up and down TAUBnCNTm (slave 2) means that signal duration of TAUBnTTOUTm (slave) is double that of the difference between TAUBnCDRm (master) +1 and TAUBnCDRm (slave 2).

An interrupt on slave 2 causes TAUBnTTOUTm of the slave channels to toggle. Depending on the settings of TAUBnTDL.TDLm, delay time is added to positive or negative logic side of the signal (i.e. whether TAUBnTTOUTm toggles immediately or after dead time has elapsed). The duration of the dead time is specified by slave channel 3.

- Prerequisites**
- Three channels
 - The operation mode of the master channel must be set to Interval Timer Mode, refer to *Table 14-122 "TAUBnCMORm settings for the master channel of the Triangle PWM Output Function with Dead Time" on page 652*
 - Slave channel 1 is not used for this function. This ensures that slave channel 2 is an odd channel, and slave channel 3 is an even channel.
 - The operation mode of slave channel 2 must be set to Up Down Mode, refer to *Table 14-126 "TAUBnCMORm settings for slave channel 2 of the Triangle PWM Output Function with Dead Time" on page 654*
Furthermore, slave channel 2 must be an even channel
 - The operation mode of slave channel 3 must be set to One Count Mode, refer to *Table 14-130 "TAUBnCMORm settings for slave channel 3 of the Triangle PWM Output Function with Dead Time" on page 656*
Furthermore, slave channel 3 must be an odd channel
 - The channel output mode of the master channel must be set to Independent Channel Output Mode 1 (refer to *14.9 "Channel Output Modes" on page 489*)
 - The channel output mode of the slave channels 2 and 3 must be set to Synchronous Channel Output Mode 2 with Dead Time Output (refer to *14.9 "Channel Output Modes" on page 489*)
 - The following settings establish TAUBnTTOUTm at high level for the down status of the carrier cycle.
 - If the TAUBnCMORm.MD0 (master) bit is set to 0, TAUBnTO.TOm must be set to 1 while TAUBnTOE.TOEm is 0.
 - If the TAUBnCMORm.MD0 (master) bit is set to 1, TAUBnTO.TOm must be set to 0 while TAUBnTOE.TOEm is 0.

Note Slave channel 1 is not used for Triangle PWM Output Function with Dead Time.

Description The counters are started by setting the channel trigger bits (TAUBnTS.TSm) to 1. This in turn sets TAUBnTE.TEm, enabling count operation. The current values of TAUBnCDRm is written to TAUBnCNTm and the counters start to

count down from these values. Depending on the setting of the master channel TAUBnCMORm.MD0 bit an interrupt is generated and TAUBnTTOUTm signal of the master toggles.

- Master channel:

When the counter of the master channel reaches 0000_H, INTTAUBnIm is generated and the TAUBnTTOUTm signal toggles. The counter reloads the TAUBnCDRm value and counts down.

- Slave channel 2:

The INTTAUBnIm of the master channel triggers the counter of the slave channel 2:

- If the slave counter currently counts down, it changes count direction.
- If the slave counter currently counts up, the value of TAUBnCDRm is reloaded and the counter counts down.

The counter continues to count down or up and awaits the next INTTAUBnIm of the master channel.

- Slave channel 3:

INTTAUBnIm of slave channel 2 triggers the counter of slave channel 3. The current value of TAUBnCDRm (slave 3) is written to TAUBnCNTm (slave 3) and the counter starts to count down from this value.

When the counter reaches 0000_H, dead time has elapsed, INTTAUBnIm is generated. The counter returns to FFFF_H and awaits the next INTTAUBnIm of slave channel 2.

An interrupt on slave channel 2 causes TAUBnTTOUTm to toggle as follows:

- It is set by the interrupt when slave channel 2 is counting down
- It is reset by the interrupt when slave channel 2 is counting up.

However, the TAUBnTDL.TDLm settings of the corresponding channel specify whether it is set/reset immediately, or after dead time has elapsed, as shown in *Table 14-121 "Behavior of TAUBnTTOUTm when an interrupt occurs on slave channel 2" on page 649*.

The TAUBnTOL.TOLm settings specify whether set corresponds to a high signal (TAUBnTOL.TOLm = 0) or a low signal (TAUBnTOL.TOLm = 1).

In Triangle PWM Output Function with Dead Time, TAUBnTTOUTm can be switched between positive and negative phase by setting TAUBnTOL.TOLm during operation.

The counter can be stopped by setting TAUBnTT.TTm to 1 for the master and slave channel(s), which in turn sets TAUBnTE.TEm to 0. TAUBnCNTm and TAUBnTTOUTm of master and slave channel(s) stop but retain their values.

TAUBnCDRm value of slave channel 2 can be set to 0000_H to output 100 % TAUBnTTOUTm.

Note If a forced restart is executed during operation, TAUBnTTOUTm is not output as a triangle PWM signal.

Conditions Simultaneous rewrite can be used with this function. Please refer to 14.8 “Simultaneous Rewrite” on page 479

TAUBnTOL.TOLm bits should be set before the counter starts, and slave channels 2 and 3 should have opposite TAUBnTOL.TOLm settings or opposite TAUBnTDL.TDLm settings.

Table 14-121 Behavior of TAUBnTTOUTm when an interrupt occurs on slave channel 2

TAUBnTDL.TDLm	Count direction of slave channel 2 when interrupt is generated	TAUBnTTOUTm toggles
0	Down	Set after dead time has elapsed
	Up	Reset immediately
1	Down	Set immediately
	Up	Reset after dead time has elapsed

- Notes**
- When the set and reset condition for TAUBnTTOUTm occur simultaneously:
 - If TAUBnTOL.TOLm = 0, the reset condition has priority
 - If TAUBnTOL.TOLm = 1, the set condition has priority .
 - To generate a two-phase PWM output with added dead time, the settings of TAUBnTOL.TOLm bit of slave channels 2 and 3 must not be changed.

(2) Equations

Pulse cycle = (TAUBnCDRm (master) + 1) × count clock cycle

Carrier cycle (down/up) = (TAUBnCDRm (master) + 1) × 2 × count clock cycle

Duty cycle [%] =

$$\frac{[(\text{TAUBnCDRm (master)} + 1 - \text{TAUBnCDRm (slave)}) / (\text{TAUBnCDRm (master)} + 1)] \times 100}{}$$

– Duty cycle = 100 %

TAUBnCDRm (slave) = 0000_H

– Duty cycle = 0 %

TAUBnCDRm (slave) ≥ TAUBnCDRm (master) + 1

PWM signal width (positive phase) = $[(\text{TAUBnCDRm (master)} + 1 - \text{TAUBnCDRm (slave 2)} \times 2) - (\text{TAUBnCDRm (slave 3)} + 1)] \times \text{count clock cycle}$

PWM signal width (negative phase) = $[(\text{TAUBnCDRm (master)} + 1 - \text{TAUBnCDRm (slave 2)} \times 2) + (\text{TAUBnCDRm (slave 3)} + 1)] \times \text{count clock cycle}$

(3) Block diagram and general timing diagram




Figure 14-89 Block diagram for Triangle PWM Output Function with Dead Time

The following settings apply to the general timing diagram:

- Master channel:
 - INTTAUBnIm is generated at operation start (TAUBnCMORm.MD0 = 1)
- Slave channel 2:
 - INTTAUBnIm not generated at operation start (TAUBnCMORm.MD0 = 0)
 - TAUBnTDL.TDLm = 0
 - Positive logic (TAUBnTOL.TOLm = 0)
- Slave channel 3:
 - INTTAUBnIm is generated at operation start (TAUBnCMORm.MD0 = 1)
 - TAUBnTDL.TDLm = 1
 - Negative logic (TAUBnTOL.TOLm = 1)




Figure 14-90 General timing diagram for Triangle PWM Output Function with Dead Time

(4) Register settings for the master channel**(a) TAUBnCMORm for the master channel**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	—	CCS0	MAS	STS[2:0]			COS[1:0]		—	MD[4:1]				MD0	

Table 14-122 TAUBnCMORm settings for the master channel of the Triangle PWM Output Function with Dead Time

Bit name	Setting
CKS[1:0]	00: Prescaler output CK0 01: Prescaler output CK1 10: Prescaler output CK2 11: Prescaler output CK3 The value of the CKS[1:0] bit of the master and slave channel(s) must be identical.
CCS0	0: Operation clock is used as the count clock
MAS	1: Channel is master channel
STS[2:0]	000: Counter triggered by software trigger
COS[1:0]	00: Not used, so set to 00
MD[4:1]	0000: Interval Timer Mode
MD0	0: INTTAUBnIm not generated and TAUBnTTOUtm does not toggle at operation start 1: Generates INTTAUBnIm and toggles TAUBnTTOUtm at operation start

(b) TAUBnCMURm for the master channel

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	TIS[1:0]	

Table 14-123 TAUBnCMURm settings for the master channel of the Triangle PWM Output Function with Dead Time

Bit name	Setting
TIS[1:0]	00: Not used so set to 00

(c) Channel output mode for the master channel**Table 14-124 Control bit settings for Independent Channel Output Mode 1**

Bit name	Setting
TOEm	1: Disables Direct Channel Output Mode
TOMm	0: Independent channel output
TOCm	0: Operation mode 1 (= Toggle mode if TAUBnTOM.TOMm = 0)
TOLm	0: Positive logic
TDEm	0: Disables dead time operation
TDLm	0: When dead time operation is disabled (TAUBnTDE.TDEm = 0), set these bits to 0

(d) Simultaneous rewrite for the master channel

The simultaneous rewrite settings of the master and slave channels must be identical.

Table 14-125 Simultaneous rewrite settings for the master channel of the Triangle PWM Output Function with Dead Time

Bit name	Setting
RDE.RDEm	1: Enables simultaneous rewrite
RDS.RDSm	0: The master channel is monitored for the simultaneous rewrite trigger 1: An upper channel outside the channel group is monitored for the simultaneous rewrite trigger
RDM.RDMm	1: The simultaneous rewrite trigger signal is generated when the master channel starts counting and the corresponding slave channel is at the peak of a triangular wave
RDC.RDCm	0: Channel is not monitored for an INTTAUBnIm signal that is used as the simultaneous rewrite trigger. If TAUBnRDS.RDSm = 0, the master channel is monitored for the simultaneous rewrite trigger regardless of the value of this bit.

(5) Register settings for slave channel 2**(a) TAUBnCMORm for slave channel 2**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	—	CCS0	MAS	STS[2:0]			COS[1:0]		—	MD[4:1]				MD0	

Table 14-126 TAUBnCMORm settings for slave channel 2 of the Triangle PWM Output Function with Dead Time

Bit name	Setting
CKS[1:0]	00: Prescaler output CK0 01: Prescaler output CK1 10: Prescaler output CK2 11: Prescaler output CK3 The value of the CKS[1:0] bit of the master and slave channel(s) must be identical.
CCS0	0: Operation clock is used as the count clock
MAS	0: Channel is a slave channel
STS[2:0]	111: The up/down output trigger signal TAUBnTUDSm of the master channel is the start trigger
COS[1:0]	00: Not used, so set to 00
MD[4:1]	1001: Up Down Count Mode
MD0	0: INTTAUBnIm not generated at operation start

(b) TAUBnCMURm for slave channel 2

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	TIS[1:0]	

Table 14-127 TAUBnCMURm settings for slave channel 2 of the Triangle PWM Output Function with Dead Time

Bit name	Setting
TIS[1:0]	00: Not used so set to 00

(c) Channel output mode for slave channel 2**Table 14-128 Control bit settings for Synchronous channel Output Mode 2 with Dead Time Output**

Bit name	Setting
TOEm	1: Disables Direct Channel Output Mode
TOMm	1: Synchronous channel operation
TOCm	1: Operation mode 2
TOLm	0: Positive logic 1: Inverted logic
TDEm	1: Enables dead time operation
TDLm	0: Dead time is added to the positive phase 1: Dead time is added to the negative phase

(d) Simultaneous rewrite for slave channel 2

The simultaneous rewrite settings of the master and slave channels must be identical.

Table 14-129 Simultaneous rewrite settings for slave channel 2 of the Triangle PWM Output Function

Bit name	Setting
RDE.RDEm	1: Enables simultaneous rewrite
RDS.RDSm	0: The master channel is monitored for the simultaneous rewrite trigger 1: An upper channel outside the channel group is monitored for the simultaneous rewrite trigger
RDM.RDMm	1: The simultaneous rewrite trigger signal is generated when the master channel starts counting and the corresponding slave channel is at the peak of a triangular wave
RDC.RDCm	0: Channel is not monitored for an INTTAUBnIm signal that is used as the simultaneous rewrite trigger. If TAUBnRDS.RDSm = 0, the master channel is monitored for the simultaneous rewrite trigger regardless of the value of this bit.

(6) Register settings for slave channel 3**(a) TAUBnCMORm for slave channel 3**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	—	CCS0	MAS	STS[2:0]			COS[1:0]		—	MD[4:1]				MD0	

Table 14-130 TAUBnCMORm settings for slave channel 3 of the Triangle PWM Output Function with Dead Time

Bit name	Setting
CKS[1:0]	00: Prescaler output CK0 01: Prescaler output CK1 10: Prescaler output CK2 11: Prescaler output CK3 The value of the CKS[1:0] bit of the master and slave channel(s) must be identical.
CCS0	0: Operation clock is used as the count clock
MAS	0: Channel is a slave channel
STS[2:0]	111: The up/down output trigger signal TAUBnTUDSm of the master channel is the start trigger
COS[1:0]	00: Not used, so set to 00
MD[4:1]	0100: One Count Mode
MD0	1: Enables start trigger detection during counting

(b) TAUBnCMURm for slave channel 3

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	TIS[1:0]	

Table 14-131 TAUBnCMURm settings for slave channel 3 of the Triangle PWM Output Function with Dead Time

Bit name	Setting
TIS[1:0]	00: Not used so set to 00

(c) Channel output mode for slave channel 3**Table 14-132 Control bit settings for Synchronous channel Output Mode 2 with Dead Time Output**

Bit name	Setting
TOEm	1: Disables Direct Channel Output Mode
TOMm	1: Synchronous channel operation
TOCm	1: Operation mode 2
TOLm	0: Positive logic 1: Inverted logic
TDEm	1: Enables dead time operation
TDLm	0: Dead time is added to the positive phase 1: Dead time is added to the negative phase

(d) Simultaneous rewrite for slave channel 3

The simultaneous rewrite settings of the master and slave channel must be identical.

Table 14-133 Simultaneous rewrite settings for slave channel 3 of the Triangle PWM Output Function

Bit name	Setting
RDE.RDEm	1: Enables simultaneous rewrite
RDS.RDSm	0: The master channel is monitored for the simultaneous rewrite trigger 1: An upper channel outside the channel group is monitored for the simultaneous rewrite trigger
RDM.RDMm	1: The simultaneous rewrite trigger signal is generated when the master channel starts counting and the corresponding slave channel is at the peak of a triangular wave
RDC.RDCm	0: Channel is not monitored for an INTTAUBnIm signal that is used as the simultaneous rewrite trigger. If TAUBnRDS.RDSm = 0, the master channel is monitored for the simultaneous rewrite trigger regardless of the value of this bit.

(7) Operating procedure for Triangle PWM Output Function with Dead Time**Table 14-134 Operating procedure for Triangle PWM Output Function with Dead Time (1/2)**

	Operation	Status of TAUBn
Initial channel setting	<p>Master channel: set the TAUBnCMORm and TAUBnCMURm registers and the channel output mode as described in 4 <i>“Register settings for the master channel”</i> on page 652</p> <p>Slave channel 2: set the TAUBnCMORm and TAUBnCMURm registers and the channel output mode as described in 5 <i>“Register settings for slave channel 2”</i> on page 654</p> <p>Slave channel 3: set the TAUBnCMORm and TAUBnCMURm registers and the channel output mode as described in 6 <i>“Register settings for slave channel 3”</i> on page 656</p> <p>Set the values of the TAUBnCDRm registers of all channels</p>	<p>Channel operation is stopped. (A clock is supplied, and a small amount of power is consumed.)</p>

Table 14-134 Operating procedure for Triangle PWM Output Function with Dead Time (2/2)

	Operation	Status of TAUBn	
Restart ↓	Start operation	<p>Set TAUBnTS.TSm of the master and slave channels to 1 simultaneously. TAUBnTS.TSm is a trigger bit, so it is automatically cleared to 0.</p>	<p>TAUBnTE.TEm (master and slave channels) is set to 1 and the counters of the master and slave channels start.</p> <p>INTTAUBnIm is generated on the master channel., depending on the setting of TAUBnCMORm.MD0.</p>
	During operation	<p>TAUBnCDRm can be changed at any time. TAUBnCNTm and TAUBnRSF.RSFm can be read at any time.</p> <p>TAUBnRDT.RDTm can be changed during operation.</p>	<p>TAUBnCNTm of the master channel and slave channel 2 load TAUBnCDRm and count down. When the counter of the master channel reaches 0000_H:</p> <ul style="list-style-type: none"> • INTTAUBnIm (master) is generated • TAUBnCNTm (master) reloads the TAUBnCDRm value and continues count operation • TAUBnCNTm (slave 2) reloads the TAUBnCDRm value or counts in the reverse direction <p>When TAUBnCNTm (slave 2) reaches 0001_H:</p> <ul style="list-style-type: none"> • INTTAUBnIm (slave 2) is generated • TAUBnTTOUTm is reset (TAUBnTOL.TOLm = 0) • TAUBnCNTm of slave channel 3 reloads the TAUBnCDRm value and counts down <p>When TAUBnCNTm of slave channel 3 = 0000_H:</p> <ul style="list-style-type: none"> • INTTAUBnIm is generated • TAUBnTTOUTm is set (TAUBnTOL.TOLm = 0) <p>Whether TAUBnTTOUTm (slave 2 and 3) are set/reset with INTTAUBnIm (slave 2) simultaneously or after dead time has elapsed depends on the settings in TAUBnTDL.TDLm and TAUBnTOL.TOLm (refer to <i>Table 14-121 "Behavior of TAUBnTTOUTm when an interrupt occurs on slave channel 2" on page 649</i>).</p>
	Stop operation	<p>Set TAUBnTT.TTm of the master and slave channels to 1 simultaneously. TAUBnTT.TTm is a trigger bit, so it is automatically cleared to 0.</p>	<p>TAUBnTE.TEm is cleared to 0 and the counter stops.</p> <p>TAUBnCNTm and TAUBnTTOUTm stop and retain their current values.</p> <p>When TAUBnTOE.TOEm is 0, TAUBnTTOUTm of slave channels 2 and 3 is initialized to the value set by TAUBnTO.TOm.</p>

(8) Specific timing diagrams

(a) Duty cycle = 0 %

The following settings apply to the diagram below:

- Slave channel 2:
 - Positive logic (TAUBnTOL.TOLm = 0)
- Slave channel 3:
 - Negative logic (TAUBnTOL.TOLm = 1)




Figure 14-91 $TAUBnCDRm (slave) \geq TAUBnCDRm (master) + 1$

- If $TAUBnCDRm (slave\ 2) \geq TAUBnCDRm (master)$ the counter of slave channel cannot reach 0000_H during counting down. Therefore TAUBnTTOUTm cannot toggle, i.e. it remains at its initial state. The interrupt from slave channel 2 occurs during count up, therefore it is a reset signal.

(b) Duty cycle = 100 %

The following settings apply to the diagram below:

- Slave channels 2:
 - Positive logic (TAUBnTOL.TOLm = 0)
- Slave channels 3:
 - Negative logic (TAUBnTOL.TOLm = 1)




Figure 14-92 TAUBnCDRm (slave) = 0000_H

- If TAUBnCDRm (slave 2) = 0000_H the counter of slave channel cannot reach 0001_H while counting up and therefore cannot generate an INTTAUBnIm while counting up.
 - The set conditions for a channel in which TAUBnTDL.TDLm = 0 are met after dead time has elapsed. TAUBnTTOUTm toggles but remains in the new state because the reset conditions never occur for such a channel.
 - Slave channel 3 in the diagram above is set when the counter starts. However, the reset conditions for a channel in which TAUBnTDL.TDLm = 1 never occur so TAUBnTTOUTm remains in its initial state for such a slave channel. In slave 3 in the diagram above, the initial state is high because TAUBnTOL.TOLm = 1.

(c) **TAUBnTTOUTm (slave 2) = 0 % and TAUBnTTOUTm (slave 3) > 0 %**

The following settings apply to the diagram below:

- Slave channel 2:
 - Positive logic (TAUBnTOL.TOLm = 0)
- Slave channel 3:
 - Negative logic (TAUBnTOL.TOLm = 1)




Figure 14-93 TAUBnCDRm (master) = 0005_H, TAUBnCDRm (slave 2) = 0005_H,
TAUBnCDRm (slave 3) = 0004_H

- When the counter of slave channel 2 reaches 0000_H , INTTAUBnIm (slave 2) is generated. The counter of slave channel 3 starts to count down.
- If another INTTAUBnIm (slave 2) is generated while the counter of slave channel 3 is still counting down, the value of TAUBnCDRm (slave 3) is reloaded and the counter restarts counting down from this value.
- In the diagram above, the first interrupt on channel 2 occurs while the counter is counting down, and the second whilst it is counting up.
- After the first interrupt, a slave for which TAUBnTDL.TDLm = 0 waits for dead time to elapse before setting. However, before the dead time has elapsed, another interrupt occurs on slave 2, this time while the counter is counting up. This acts as a reset signal, meaning that a channel for which TAUBnTDL.TDLm = 0 always remains inactive.
- TAUBnTTOUTm of a slave channel for which TAUBnTDL.TDLm = 1 is set and reset as normal when the corresponding INTTAUBnIm is generated.

(d) TAUBnTTOUTm (slave 2) > 0 % and TAUBnTTOUTm (slave 3) = 100 %

The following settings apply to the diagram below:

- Slave channel 2:
 - Positive logic (TAUBnTOL.TOLm = 0)
- Slave channel 3:
 - Negative logic (TAUBnTOL.TOLm = 1)




Figure 14-94 TAUBnCDRm (master) = 0005_H, TAUBnCDRm (slave 2) = 0002_H,
 TAUBnCDRm (slave 3) = 0004_H
 PWM signal width (negative phase) ≥ Carrier cycle

- After the second interrupt, a slave for which $TAUBnTDL.TDLm = 1$ waits for dead time to elapse before resetting. However, before the dead time has elapsed, another interrupt occurs on slave 2, this time while the counter is counting up. This acts as a set signal, meaning that a channel for which $TAUBnTDL.TDLm = 1$ always remains active.
- $TAUBnTTOUTm$ of a slave channel for which $TAUBnTDL.TDLm = 0$ is set and reset as normal when the corresponding $INTTAUBnIm$ is generated.

(e) Inhibited $INTTAUBnIm$ to set $TAUBnTTOUTm$ positive phase period

The following settings apply to the diagram below:

- Slave channel 2:
 - Positive logic ($TAUBnTOL.TOLm = 0$)
- Slave channel 3:
 - Negative logic ($TAUBnTOL.TOLm = 1$)




Figure 14-95 TAUBnCDRm (master) = 0005_H, TAUBnCDRm (slave 2) = 0005_H, TAUBnCDRm (slave 3) = 0001_H
 PWM signal width (positive phase) = 0

- The counter of slave channel 3 reaches 0000_H and generates an INTTAUBnIm to set the TAUBnTTOUTm of slave channel for which TAUBnTDL.TDLm = 0 (slave channel 2 in this example).
- If channel 2 generates an INTTAUBnIm to reset TAUBnTTOUTm simultaneously, this reset signal has priority (assuming TAUBnTOL.TOLm = 0, otherwise the set signal has priority).
- Therefore, TAUBnTTOUTm of a slave channel for which TAUBnTDL.TDLm = 0 remains in its initial state.

(f) **Inhibited INTTAUBnIm to set TAUBnTOUTm negative phase period**

The following settings apply to the diagram below:

- Slave channel 2:
 - Positive logic (TAUBnTOL.TOLm = 0)
- Slave channel 3:
 - Negative logic (TAUBnTOL.TOLm = 1)




Figure 14-96 TAUBnCDRm (master) = 0005_H, TAUBnCDRm (slave 2) = 0001_H, TAUBnCDRm (slave 3) = 0001_H
 PWM signal width (negative phase) = carrier cycle

- The counter of slave channel 3 reaches 0000_H and generates an INTTAUBnIm to set the TAUBnTTOUTm of slave channel for which TAUBnTDL.TDLm = 1 (slave 3 in this example).
- If channel 2 generates an INTTAUBnIm to reset TAUBnTTOUTm simultaneously, the set signal has priority (assuming TAUBnTOL.TOLm = 1, otherwise the reset signal has priority).
- Therefore, TAUBnTTOUTm of slave channel for which TAUBnTDL.TDLm = 1 remains in its initial state.

14.21.3 AD Conversion Trigger Output Function Type 2

(1) Overview

Summary This function is identical to 14.21.1 "Triangle PWM Output Function" on page 636 except that TAUBnTTOUTm is not output.

This is achieved by setting the channel output mode of the slave to Direct Channel Output Mode.

(2) Block diagram and general timing diagram




Figure 14-97 Block diagram for AD Conversion Trigger Output Function Type 2

The following settings apply to the general timing diagram:

- Master channel
 - INTTAUBnIm is generated at operation start (TAUBnCMORm.MD0 = 1)




Figure 14-98 General timing diagram for AD Conversion Trigger Output Function Type 2

14.22 Registers

This section contains a description of all the registers of the 16-bit Timer Array Unit B.

14.22.1 TAUBn registers overview

The TAUBn is controlled and operated by the registers in the following table. Where there is one register per channel, this is indicated by an “m”, where m runs from 0 to 15.

Table 14-135 TAUBn registers overview

Register name	Shortcut	Address
TAUBn prescaler registers		
TAUBn prescaler clock select register	TAUBnTPS	<TAUBn_base> + 240 _H
TAUBn control registers		
TAUBn channel data register m	TAUBnCDRm	<TAUBn_base> + m × 4 _H
TAUBn channel counter register m	TAUBnCNTm	<TAUBn_base> + 80 _H + m × 4 _H
TAUBn channel mode OS register m	TAUBnCMORm	<TAUBn_base> + 200 _H + m × 4 _H
TAUBn channel mode user register m	TAUBnCMURm	<TAUBn_base> + C0 _H + m × 4 _H
TAUBn channel status register m	TAUBnCSRm	<TAUBn_base> + 140 _H + m × 4 _H
TAUBn channel status clear trigger register m	TAUBnCSCm	<TAUBn_base> + 180 _H + m × 4 _H
TAUBn channel start trigger register	TAUBnTS	<TAUBn_base> + 1C4 _H
TAUBn channel enable status register	TAUBnTE	<TAUBn_base> + 1C0 _H
TAUBn channel stop trigger register	TAUBnTT	<TAUBn_base> + 1C8 _H
TAUBn output registers		
TAUBn channel output enable register	TAUBnTOE	<TAUBn_base> + 5C _H
TAUBn channel output register	TAUBnTO	<TAUBn_base> + 58 _H
TAUBn channel output mode register	TAUBnTOM	<TAUBn_base> + 248 _H
TAUBn channel output configuration register	TAUBnTOC	<TAUBn_base> + 24C _H
TAUBn channel output active level register	TAUBnTOL	<TAUBn_base> + 040 _H
TAUBn channel dead time output enable register	TAUBnTDE	<TAUBn_base> + 250 _H
TAUBn channel dead time output level register	TAUBnTDL	<TAUBn_base> + 54 _H
TAUBn reload data registers		
TAUBn channel reload data enable register	TAUBnRDE	<TAUBn_base> + 260 _H
TAUBn channel reload data mode register	TAUBnRDM	<TAUBn_base> + 264 _H
TAUBn channel reload data control CH select register	TAUBnRDS	<TAUBn_base> + 268 _H
TAUBn channel reload data control register	TAUBnRDC	<TAUBn_base> + 26C _H
TAUBn channel reload data trigger register	TAUBnRDT	<TAUBn_base> + 44 _H
TAUBn channel reload status register	TAUBnRSF	<TAUBn_base> + 48 _H
TAUBn emulation register		
TAUBn emulation register	TAUBnEMU	<TAUBn_base> + 290 _H

<TAUBn_base> The <TAUBn_base> addresses of the registers are defined in the first section of this chapter under the keyword “Register addresses”.

14.22.2 TAUBn prescaler registers details

(1) TAUBnTPS - TAUBn prescaler clock select register

This register specifies the PCLK prescalers for clocks CK0, CK1, CK2, and CK3 for all channels.

Access This register can be read/written in 16-bit units.

Address <TAUBn_base> + 240_H

Initial Value FFFF_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
PRS3[3:0]				PRS2[3:0]				PRS1[3:0]				PRS0[3:0]			
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 14-136 TAUBnTPS register contents (1/2)

Bit position	Bit name	Function																
15 to 12	PRS3[3:0]	Specifies the CK3 clock. <table border="1" data-bbox="550 869 1385 1211"> <thead> <tr> <th>PRS3[3:0]</th> <th>CK3 clock</th> </tr> </thead> <tbody> <tr><td>0000_B</td><td>PCLK/2⁰</td></tr> <tr><td>0001_B</td><td>PCLK/2¹</td></tr> <tr><td>0010_B</td><td>PCLK/2²</td></tr> <tr><td>0011_B</td><td>PCLK/2³</td></tr> <tr><td>...</td><td>...</td></tr> <tr><td>1110_B</td><td>PCLK/2¹⁴</td></tr> <tr><td>1111_B</td><td>PCLK/2¹⁵</td></tr> </tbody> </table> These bits can only be rewritten when all counters using CK3 are stopped (TAUBnTE.TEm = 0).	PRS3[3:0]	CK3 clock	0000 _B	PCLK/2 ⁰	0001 _B	PCLK/2 ¹	0010 _B	PCLK/2 ²	0011 _B	PCLK/2 ³	1110 _B	PCLK/2 ¹⁴	1111 _B	PCLK/2 ¹⁵
PRS3[3:0]	CK3 clock																	
0000 _B	PCLK/2 ⁰																	
0001 _B	PCLK/2 ¹																	
0010 _B	PCLK/2 ²																	
0011 _B	PCLK/2 ³																	
...	...																	
1110 _B	PCLK/2 ¹⁴																	
1111 _B	PCLK/2 ¹⁵																	
11 to 8	PRS2[3:0]	Specifies the CK2 clock. <table border="1" data-bbox="550 1323 1385 1666"> <thead> <tr> <th>PRS2[3:0]</th> <th>CK2 clock</th> </tr> </thead> <tbody> <tr><td>0000_B</td><td>PCLK/2⁰</td></tr> <tr><td>0001_B</td><td>PCLK/2¹</td></tr> <tr><td>0010_B</td><td>PCLK/2²</td></tr> <tr><td>0011_B</td><td>PCLK/2³</td></tr> <tr><td>...</td><td>...</td></tr> <tr><td>1110_B</td><td>PCLK/2¹⁴</td></tr> <tr><td>1111_B</td><td>PCLK/2¹⁵</td></tr> </tbody> </table> These bits can only be rewritten when all counters using CK2 are stopped (TAUBnTE.TEm = 0).	PRS2[3:0]	CK2 clock	0000 _B	PCLK/2 ⁰	0001 _B	PCLK/2 ¹	0010 _B	PCLK/2 ²	0011 _B	PCLK/2 ³	1110 _B	PCLK/2 ¹⁴	1111 _B	PCLK/2 ¹⁵
PRS2[3:0]	CK2 clock																	
0000 _B	PCLK/2 ⁰																	
0001 _B	PCLK/2 ¹																	
0010 _B	PCLK/2 ²																	
0011 _B	PCLK/2 ³																	
...	...																	
1110 _B	PCLK/2 ¹⁴																	
1111 _B	PCLK/2 ¹⁵																	

Table 14-136 TAUBnTPS register contents (2/2)

Bit position	Bit name	Function																
7 to 4	PRS1[3:0]	<p>Specifies the CK1 clock.</p> <table border="1"> <thead> <tr> <th>PRS1[3:0]</th> <th>CK1 clock</th> </tr> </thead> <tbody> <tr> <td>0000_B</td> <td>PCLK/2⁰</td> </tr> <tr> <td>0001_B</td> <td>PCLK/2¹</td> </tr> <tr> <td>0010_B</td> <td>PCLK/2²</td> </tr> <tr> <td>0011_B</td> <td>PCLK/2³</td> </tr> <tr> <td>...</td> <td>...</td> </tr> <tr> <td>1110_B</td> <td>PCLK/2¹⁴</td> </tr> <tr> <td>1111_B</td> <td>PCLK/2¹⁵</td> </tr> </tbody> </table> <p>These bits can only be rewritten when all counters using CK1 are stopped (TAUBnTE.TEm = 0).</p>	PRS1[3:0]	CK1 clock	0000 _B	PCLK/2 ⁰	0001 _B	PCLK/2 ¹	0010 _B	PCLK/2 ²	0011 _B	PCLK/2 ³	1110 _B	PCLK/2 ¹⁴	1111 _B	PCLK/2 ¹⁵
PRS1[3:0]	CK1 clock																	
0000 _B	PCLK/2 ⁰																	
0001 _B	PCLK/2 ¹																	
0010 _B	PCLK/2 ²																	
0011 _B	PCLK/2 ³																	
...	...																	
1110 _B	PCLK/2 ¹⁴																	
1111 _B	PCLK/2 ¹⁵																	
3 to 0	PRS0[3:0]	<p>Specifies the CK0 clock.</p> <table border="1"> <thead> <tr> <th>PRS0[3:0]</th> <th>CK0 clock</th> </tr> </thead> <tbody> <tr> <td>0000_B</td> <td>PCLK/2⁰</td> </tr> <tr> <td>0001_B</td> <td>PCLK/2¹</td> </tr> <tr> <td>0010_B</td> <td>PCLK/2²</td> </tr> <tr> <td>0011_B</td> <td>PCLK/2³</td> </tr> <tr> <td>...</td> <td>...</td> </tr> <tr> <td>1110_B</td> <td>PCLK/2¹⁴</td> </tr> <tr> <td>1111_B</td> <td>PCLK/2¹⁵</td> </tr> </tbody> </table> <p>These bits can only be rewritten when all counters using CK0 are stopped (TAUBnTE.TEm = 0).</p>	PRS0[3:0]	CK0 clock	0000 _B	PCLK/2 ⁰	0001 _B	PCLK/2 ¹	0010 _B	PCLK/2 ²	0011 _B	PCLK/2 ³	1110 _B	PCLK/2 ¹⁴	1111 _B	PCLK/2 ¹⁵
PRS0[3:0]	CK0 clock																	
0000 _B	PCLK/2 ⁰																	
0001 _B	PCLK/2 ¹																	
0010 _B	PCLK/2 ²																	
0011 _B	PCLK/2 ³																	
...	...																	
1110 _B	PCLK/2 ¹⁴																	
1111 _B	PCLK/2 ¹⁵																	

Note The TAUBn clock input PCLK is specified in the first section of this chapter under the keyword “Clock supply”.

14.22.3 TAUBn control registers details

(1) TAUBnCDRm - TAUBn channel data register

This register functions either as a compare register or as a capture register, depending on the operation mode specified in TAUBnCMORm.MD[4:0].

Access This register can be read/written in 16-bit units.

- In capture mode, only reading is possible. Write operation is ignored.
- In compare mode, reading and writing is possible.

Address <TAUBn_base> + 0_H + m × 4_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CDR[15:0]															
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 14-137 TAUBnCDRm register contents

Bit position	Bit name	Function
15 to 0	CDR[15:0]	Data register for the capture/compare value.

(2) TAUBnCNTm - TAUBn channel counter register

This register is the channel m counter register.

Access This register can be read in 16-bit units.

Address <TAUBn_base> + 80_H + m × 4_H

Initial Value 0000_H or FFFF_H The initial value depends on the operation mode, see *Table 14-139 "TAUBnCNTm read values after the counter is re-enabled" on page 676*.

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CNT[15:0]															
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Table 14-138 TAUBnCNTm register contents

Bit position	Bit name	Function
15 to 0	CNT[15:0]	16-bit counter value.

The read value depends on the counter, the operation mode change, and the values of the TAUBnTS.TSm and TAUBnTT.TTm bits.

The *initial* counter read value depends on the operation mode and how the counter was stopped:

- by a reset
- by a counter stop trigger (TAUBnTT.TTm = 1)

The following table lists the initial counter read values after the counter has stopped (TAUBnTE.TEm= 0) and re-enabled (TAUBnTS.TSm = 1).

The table also contains the counter read value one count after the counter is enabled (TAUBnTS.TSm = 1) for modes where the counter waits for a start trigger.

Table 14-139 TAUBnCNTm read values after the counter is re-enabled

Mode name	Count method (up/down)	TAUBnCNTm value		
		After reset	After stop trigger	After one count
Interval Timer mode	Count down	FFFF _H	Stop value	—
Judge mode	Count down	FFFF _H	Stop value	—
Capture mode	Count up	0000 _H	Stop value	—
Event Count mode	Count down	FFFF _H	Stop value	—
One Count mode	Count down	FFFF _H	Stop value	FFFF _H
Capture & One Count mode	Count up	0000 _H	Stop value	Captured value + 1 (TAUBnCDRm)
Judge & One Count mode	Count down	FFFF _H	Stop value	TAUBnCNTm value - 1
Up Down Count mode	Count up/down	FFFF _H	Stop value	—
Pulse One Count mode	Count down	FFFF _H	Stop value	0000 _H
Count Capture Mode	Count up	0000 _H	Stop value	—
Gate Count Mode	Count down	FFFF _H	Stop value	Stop value
Capture & Gate Count Mode	Count up	0000 _H	Stop value	Stop value

Note If the operation mode is changed while the counter is stopped, the initial counter value after counter restart is undefined. The operation mode is changed by register TAUBnCMORm.MD[4:0].

(3) TAUBnCMORm - TAUBn channel mode OS register

This register controls channel m operation. It specifies, for example, the operation clock, count clock, and master/slave function.

Access This register can be read/written in 16-bit units. It can only be written when the counter is stopped (TAUBnTE.TEm = 0).

Address <TAUBn_base> + 200_H + m × 4_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	—	CCS0	MAS	STS[2:0]			COS[1:0]		—	MD[4:0]					
R/W	R/W	R	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R	R/W	R/W	R/W	R/W	R/W

Table 14-140 TAUBnCMORm register contents (1/3)

Bit position	Bit name	Function															
15,14	CKS[1:0]	<p>Selects the operation clock. The operation clock is used for the TAUBnTTINm input edge detection circuit. It can also be used as the count clock depending on bit TAUBnCMORm.CCS0.</p> <table border="1"> <thead> <tr> <th>CKS1</th><th>CKS0</th><th>Selected operation clock</th></tr> </thead> <tbody> <tr> <td>0</td><td>0</td><td>CK0</td></tr> <tr> <td>0</td><td>1</td><td>CK1</td></tr> <tr> <td>1</td><td>0</td><td>CK2</td></tr> <tr> <td>1</td><td>1</td><td>CK3</td></tr> </tbody> </table>	CKS1	CKS0	Selected operation clock	0	0	CK0	0	1	CK1	1	0	CK2	1	1	CK3
CKS1	CKS0	Selected operation clock															
0	0	CK0															
0	1	CK1															
1	0	CK2															
1	1	CK3															
12	CCS0	<p>Selects the count clock for TAUBnCNTm counter: 0: Operation clock as specified by TAUBnCMORm.CKS[1:0] 1: Valid edge of TAUBnTTINm input signal</p>															
11	MAS	<p>Specifies the channel as master or slave channel during synchronous channel operation: 0: Slave 1: Master This bit is only valid for even channels (CHm_even). For odd channels (CHm_odd), it is fixed to 0.</p>															

Table 14-140 TAUBnCMORm register contents (2/3)

Bit position	Bit name	Function																																				
10 to 8	STS[2:0]	<p>Selects the external start trigger:</p> <table border="1"> <thead> <tr> <th>STS2</th> <th>STS1</th> <th>STS0</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>0</td> <td>Software trigger</td> </tr> <tr> <td>0</td> <td>0</td> <td>1</td> <td>Valid edge of the TAUBnTTINm input signal. TAUBnCMURm.TIS[1:0] specifies the valid edge.</td> </tr> <tr> <td>0</td> <td>1</td> <td>0</td> <td>Valid edge of the TAUBnTTINm input signal is the start trigger and the reverse edge is the stop (capture) trigger</td> </tr> <tr> <td>0</td> <td>1</td> <td>1</td> <td>Setting prohibited</td> </tr> <tr> <td>1</td> <td>0</td> <td>0</td> <td>INTTAUBnI of the master channel</td> </tr> <tr> <td>1</td> <td>0</td> <td>1</td> <td>INTTAUBnI of the upper channel (m-1), regardless of the master setting</td> </tr> <tr> <td>1</td> <td>1</td> <td>0</td> <td>Dead-time output signal TAUBnTTDL of the TAUBnTTOUTm generation unit</td> </tr> <tr> <td>1</td> <td>1</td> <td>1</td> <td>Up/down output trigger signal TAUBnTUDSm of the master channel.</td> </tr> </tbody> </table>	STS2	STS1	STS0	Description	0	0	0	Software trigger	0	0	1	Valid edge of the TAUBnTTINm input signal. TAUBnCMURm.TIS[1:0] specifies the valid edge.	0	1	0	Valid edge of the TAUBnTTINm input signal is the start trigger and the reverse edge is the stop (capture) trigger	0	1	1	Setting prohibited	1	0	0	INTTAUBnI of the master channel	1	0	1	INTTAUBnI of the upper channel (m-1), regardless of the master setting	1	1	0	Dead-time output signal TAUBnTTDL of the TAUBnTTOUTm generation unit	1	1	1	Up/down output trigger signal TAUBnTUDSm of the master channel.
STS2	STS1	STS0	Description																																			
0	0	0	Software trigger																																			
0	0	1	Valid edge of the TAUBnTTINm input signal. TAUBnCMURm.TIS[1:0] specifies the valid edge.																																			
0	1	0	Valid edge of the TAUBnTTINm input signal is the start trigger and the reverse edge is the stop (capture) trigger																																			
0	1	1	Setting prohibited																																			
1	0	0	INTTAUBnI of the master channel																																			
1	0	1	INTTAUBnI of the upper channel (m-1), regardless of the master setting																																			
1	1	0	Dead-time output signal TAUBnTTDL of the TAUBnTTOUTm generation unit																																			
1	1	1	Up/down output trigger signal TAUBnTUDSm of the master channel.																																			
7, 6	COS[1:0]	<p>Specifies when the capture register TAUBnCDRm and the overflow flag TAUBnCSRm.OVF of channel m are updated. These bits are only valid if channel m is in capture mode.</p> <table border="1"> <thead> <tr> <th>COS1</th> <th>COS0</th> <th>Capture register</th> <th>TAUBnCSRm.OVF</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Updated upon detection of a TAUBnTTINm input valid edge.</td> <td> Updated (cleared or set) upon detection of a TAUBnTTINm input valid edge: <ul style="list-style-type: none"> If a counter overflow has occurred since the last valid edge detection, TAUBnCSRm.OVF is set. If no counter overflow has occurred since the last valid edge detection, TAUBnCSR.OVF is cleared. </td> </tr> <tr> <td>0</td> <td>1</td> <td></td> <td>Set upon counter overflow and cleared by a CPU instruction.</td> </tr> <tr> <td>1</td> <td>0</td> <td>Updated upon detection of a TAUBnTTINm input valid edge and upon counter overflow:</td> <td>Not set.</td> </tr> <tr> <td>1</td> <td>1</td> <td> Updated upon detection of a TAUBnTTINm input valid edge and upon counter overflow: <ul style="list-style-type: none"> TAUBnTTINm input valid edge: Counter value is written to TAUBnCDRm Overflow: FFFF_H is written to TAUBnCDRm. The next TAUBnTTINm input valid edge detection is ignored. </td> <td>Set upon counter overflow and cleared by a CPU instruction.</td> </tr> </tbody> </table>	COS1	COS0	Capture register	TAUBnCSRm.OVF	0	0	Updated upon detection of a TAUBnTTINm input valid edge.	Updated (cleared or set) upon detection of a TAUBnTTINm input valid edge: <ul style="list-style-type: none"> If a counter overflow has occurred since the last valid edge detection, TAUBnCSRm.OVF is set. If no counter overflow has occurred since the last valid edge detection, TAUBnCSR.OVF is cleared. 	0	1		Set upon counter overflow and cleared by a CPU instruction.	1	0	Updated upon detection of a TAUBnTTINm input valid edge and upon counter overflow:	Not set.	1	1	Updated upon detection of a TAUBnTTINm input valid edge and upon counter overflow: <ul style="list-style-type: none"> TAUBnTTINm input valid edge: Counter value is written to TAUBnCDRm Overflow: FFFF_H is written to TAUBnCDRm. The next TAUBnTTINm input valid edge detection is ignored. 	Set upon counter overflow and cleared by a CPU instruction.																
COS1	COS0	Capture register	TAUBnCSRm.OVF																																			
0	0	Updated upon detection of a TAUBnTTINm input valid edge.	Updated (cleared or set) upon detection of a TAUBnTTINm input valid edge: <ul style="list-style-type: none"> If a counter overflow has occurred since the last valid edge detection, TAUBnCSRm.OVF is set. If no counter overflow has occurred since the last valid edge detection, TAUBnCSR.OVF is cleared. 																																			
0	1		Set upon counter overflow and cleared by a CPU instruction.																																			
1	0	Updated upon detection of a TAUBnTTINm input valid edge and upon counter overflow:	Not set.																																			
1	1	Updated upon detection of a TAUBnTTINm input valid edge and upon counter overflow: <ul style="list-style-type: none"> TAUBnTTINm input valid edge: Counter value is written to TAUBnCDRm Overflow: FFFF_H is written to TAUBnCDRm. The next TAUBnTTINm input valid edge detection is ignored. 	Set upon counter overflow and cleared by a CPU instruction.																																			

Table 14-140 TAUBnCMORm register contents (3/3)

Bit position	Bit name	Function																																																																																										
4 to 0	MD[4:0]	Specifies the operation mode. <table border="1"> <thead> <tr> <th>MD4</th> <th>MD3</th> <th>MD2</th> <th>MD1</th> <th>MD0</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>1/0</td> <td>Interval Timer mode</td> </tr> <tr> <td>0</td> <td>0</td> <td>0</td> <td>1</td> <td>1/0</td> <td>Judge mode</td> </tr> <tr> <td>0</td> <td>0</td> <td>1</td> <td>0</td> <td>1/0</td> <td>Capture mode</td> </tr> <tr> <td>0</td> <td>0</td> <td>1</td> <td>1</td> <td>0</td> <td>Event Count mode</td> </tr> <tr> <td>0</td> <td>1</td> <td>0</td> <td>0</td> <td>1/0</td> <td>One Count mode</td> </tr> <tr> <td>0</td> <td>1</td> <td>0</td> <td>1</td> <td>1/0</td> <td>Setting prohibited</td> </tr> <tr> <td>0</td> <td>1</td> <td>1</td> <td>0</td> <td>0</td> <td>Capture & One Count mode</td> </tr> <tr> <td>0</td> <td>1</td> <td>1</td> <td>1</td> <td>1/0</td> <td>Judge & One Count mode</td> </tr> <tr> <td>1</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>Setting prohibited</td> </tr> <tr> <td>1</td> <td>0</td> <td>0</td> <td>1</td> <td>0</td> <td>Up Down Count mode</td> </tr> <tr> <td>1</td> <td>0</td> <td>1</td> <td>0</td> <td>1/0</td> <td>Pulse One Count mode</td> </tr> <tr> <td>1</td> <td>0</td> <td>1</td> <td>1</td> <td>1/0</td> <td>Count Capture mode</td> </tr> <tr> <td>1</td> <td>1</td> <td>0</td> <td>0</td> <td>0</td> <td>Gate Count mode</td> </tr> <tr> <td>1</td> <td>1</td> <td>0</td> <td>1</td> <td>0</td> <td>Capture & Gate Count mode</td> </tr> </tbody> </table>	MD4	MD3	MD2	MD1	MD0	Description	0	0	0	0	1/0	Interval Timer mode	0	0	0	1	1/0	Judge mode	0	0	1	0	1/0	Capture mode	0	0	1	1	0	Event Count mode	0	1	0	0	1/0	One Count mode	0	1	0	1	1/0	Setting prohibited	0	1	1	0	0	Capture & One Count mode	0	1	1	1	1/0	Judge & One Count mode	1	0	0	0	0	Setting prohibited	1	0	0	1	0	Up Down Count mode	1	0	1	0	1/0	Pulse One Count mode	1	0	1	1	1/0	Count Capture mode	1	1	0	0	0	Gate Count mode	1	1	0	1	0	Capture & Gate Count mode
MD4	MD3	MD2	MD1	MD0	Description																																																																																							
0	0	0	0	1/0	Interval Timer mode																																																																																							
0	0	0	1	1/0	Judge mode																																																																																							
0	0	1	0	1/0	Capture mode																																																																																							
0	0	1	1	0	Event Count mode																																																																																							
0	1	0	0	1/0	One Count mode																																																																																							
0	1	0	1	1/0	Setting prohibited																																																																																							
0	1	1	0	0	Capture & One Count mode																																																																																							
0	1	1	1	1/0	Judge & One Count mode																																																																																							
1	0	0	0	0	Setting prohibited																																																																																							
1	0	0	1	0	Up Down Count mode																																																																																							
1	0	1	0	1/0	Pulse One Count mode																																																																																							
1	0	1	1	1/0	Count Capture mode																																																																																							
1	1	0	0	0	Gate Count mode																																																																																							
1	1	0	1	0	Capture & Gate Count mode																																																																																							
Mode	Role of the MD0 bit																																																																																											
Interval Timer mode Capture mode Count Capture mode	Specifies whether an INTTAUBnIm is generated when the counter is triggered: 0: No INTTAUBnIm generated 1: INTTAUBnIm generated																																																																																											
Event Count mode Up Down Count mode	This bit must be set to 0: 0: No INTTAUBnIm generated when the counter is triggered 1: —																																																																																											
One Count mode Gate Count mode	Enables/disables start trigger detection during counting: 0: Disabled 1: Enabled INTTAUBnIm and TAUBnTTOUTm are not output when the counter is triggered.																																																																																											
Pulse One Count mode	Enables/disables start trigger detection during counting: 0: Disabled 1: Enabled INTTAUBnIm and TAUBnTTOUTm are output when the counter is triggered.																																																																																											
Capture & One Count mode Capture & Gate Count mode	This bit must be set to 0: 0: No INTTAUBnIm generated when the counter is triggered. Start trigger is disabled during counting. 1: —																																																																																											
Judge mode Judge One Count mode	Specifies when INTTAUBnIm is generated: 0: When TAUBnCNTm ≤ TAUBnCDRm 1: When TAUBnCNTm > TAUBnCDRm																																																																																											

(4) TAUBnCMURm - TAUBn channel mode user register

This register specifies the type of valid edge detection used for the TAUBnTTINm input.

Access This register can be read/written in 8-bit units.

Address <TAUBn_base> + C0_H + m × 4_H

Initial Value 00_H

7	6	5	4	3	2	1	0
—	—	—	—	—	—	TIS[1:0]	
R	R	R	R	R	R	R/W	R/W

Table 14-141 TAUBnCMURm register contents

Bit position	Bit name	Function															
1, 0	TIS[1:0]	<p>Specifies the valid edge of the TAUBnTTINm input:</p> <table border="1"> <thead> <tr> <th>TIS1</th> <th>TIS0</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td style="text-align: center;">0</td> <td>Falling edge</td> </tr> <tr> <td style="text-align: center;">0</td> <td style="text-align: center;">1</td> <td>Rising edge</td> </tr> <tr> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> <td>Rising and falling edges (low-width measurement selection). Start trigger: falling edge Stop trigger (capture): rising edge</td> </tr> <tr> <td style="text-align: center;">1</td> <td style="text-align: center;">1</td> <td>Rising and falling edges (high-width measurement selection). Start trigger: rising edge Stop trigger (capture): falling edge This setting is only valid if the start trigger selection is set to TAUBnCMORm.STS[2:0] = 010_B</td> </tr> </tbody> </table> <ul style="list-style-type: none"> To detect rising and falling edges when TAUBnCMORm.STS[2:0] is not set to 010_B, set TAUBnCMURm.TIS[1:0] = 10_B. Edge detection for TAUBnTTINm input signals is performed based on the operation clock selected by TAUBnCMORm.CKS[1:0]. 	TIS1	TIS0	Description	0	0	Falling edge	0	1	Rising edge	1	0	Rising and falling edges (low-width measurement selection). Start trigger: falling edge Stop trigger (capture): rising edge	1	1	Rising and falling edges (high-width measurement selection). Start trigger: rising edge Stop trigger (capture): falling edge This setting is only valid if the start trigger selection is set to TAUBnCMORm.STS[2:0] = 010 _B
TIS1	TIS0	Description															
0	0	Falling edge															
0	1	Rising edge															
1	0	Rising and falling edges (low-width measurement selection). Start trigger: falling edge Stop trigger (capture): rising edge															
1	1	Rising and falling edges (high-width measurement selection). Start trigger: rising edge Stop trigger (capture): falling edge This setting is only valid if the start trigger selection is set to TAUBnCMORm.STS[2:0] = 010 _B															

(5) TAUBnCSRm - TAUBn channel status register

This register indicates the count direction and the overflow status of channel m's counter.

Access This register can be read in 8-bit units.

Address <TAUBn_base> + 140_H + m × 4_H

Initial Value 00_H

7	6	5	4	3	2	1	0
—	—	—	—	—	—	CSF	OVF
R	R	R	R	R	R	R	R

Table 14-142 TAUBnCSRm register contents

Bit position	Bit name	Function
1	CSF	Indicates the count direction: 0: Counts up 1: Counts down The read value of this bit is only valid in the following mode: <ul style="list-style-type: none"> • Up Down Count mode For channel 0 this bit is fixed to 0.
0	OVF	Indicates the counter overflow status: 0: No overflow occurred 1: Overflow occurred This bit is only used in the following modes: <ul style="list-style-type: none"> • Capture mode • Capture & One Count mode • Count Capture mode • Capture & Gate Count mode The function of this bit depends on the setting of control bits TAUBnCMORm.COS[1:0]. OVF is not be set when TAUBnCMORm.COS[1:0] = 10 _B .

(6) TAUBnCSCm - TAUBn channel status clear register

This register is a trigger register for clearing the overflow flag TAUBnCSRm.OVF of a channel m.

Access This register can be written in 8-bit units. It is always read as 0000_H.

Address <TAUBn_base> + 180_H + m × 4_H

Initial Value 00_H

7	6	5	4	3	2	1	0
—	—	—	—	—	—	0	CLOV
R	R	R	R	R	R	R	W

Table 14-143 TAUBnCSCm register contents

Bit position	Bit name	Function
0	CLOV	0: No function 1: Clears the overflow flag TAUBnCSRm.OVF

(7) TAUBnTS - TAUBn channel start trigger register

This register enables the counter for each channel.

Access This register can be written in 16-bit units. It is always read as 0000_H.

Address <TAUBn_base> + 1C4_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
TS	TS	TS	TS	TS	TS	TS	TS	TS	TS	TS	TS	TS	TS	TS	TS
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
W	W	W	W	W	W	W	W	W	W	W	W	W	W	W	W

Table 14-144 TAUBnTS register contents

Bit position	Bit name	Function
15 to 0	TSm	Enables the counter for channel m: 0: No function 1: Enables the counter and sets TAUBnTE.TEm = 1. When the counter is enabled, this bit immediately returns to 0. TAUBnTE.TEm = 1 only <i>enables</i> counter. Whether the counter <i>starts</i> depends on the selected operation mode.

(8) TAUBnTE - TAUBn channel enable status register

This register indicates whether counter is enabled or disabled.

Access This register can be read in 16-bit units.

Address <TAUBn_base> + 1C0_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
TE	TE	TE	TE	TE	TE	TE	TE	TE	TE	TE	TE	TE	TE	TE	TE
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Table 14-145 TAUBnTE register contents

Bit position	Bit name	Function
15 to 0	TE _m	Indicates whether counter for channel m is enabled or disabled: 0: Counter disabled 1: Counter enabled Setting TAUBnTS.TS _m to 1 or trigger input detection TAUBnTSS _m = 1 sets this bit to 1. Setting TAUBnTT.TT _m to 1 resets this bit to 0.

(9) TAUBnTT - TAUBn channel stop trigger register

This register stops the counter for each channel.

Access This register can be written in 16-bit units. It is always read as 0000_H.

Address <TAUBn_base> + 1C8_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
TT	TT	TT	TT	TT	TT	TT	TT	TT	TT	TT	TT	TT	TT	TT	TT
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
W	W	W	W	W	W	W	W	W	W	W	W	W	W	W	W

Table 14-146 TAUBnTT register contents

Bit position	Bit name	Function
15 to 0	TT _m	Stops the counter of channel m: 0: No function 1: Stops the counter and sets TAUBnTE.TE _m = 0. When the counter has stopped, this bit immediately returns to 0. TAUBnCNT _m stops counting and TAUBnCNT _m , TAUBnTO.TO _m , and TAUBnTTOUT _m all retain the values they had before the counter was stopped.

14.22.4 TAUBn output registers details

(1) TAUBnTOE - TAUBn channel output enable register

This register enables and disables Direct Channel Output Mode.

Access This register can be read/written in 16-bit units.

Address <TAUBn_base> + 5C_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
TOE 15	TOE 14	TOE 13	TOE 12	TOE 11	TOE 10	TOE 09	TOE 08	TOE 07	TOE 06	TOE 05	TOE 04	TOE 03	TOE 02	TOE 01	TOE 00
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 14-147 TAUBnTOE register contents

Bit position	Bit name	Function
15 to 0	TOEm	Enables/disables Direct Channel Output Mode: 0: Enables Direct Channel Output Mode (TAUBnTTOUT m output is controlled by the application software) 1: Disables Direct Channel Output Mode (TAUBnTTOUT m output is controlled by the timer)

(2) TAUBnTOM - TAUBn channel output mode register

This register specifies the output mode of each channel.

Access This register can be read/written in 16-bit units. It can only be written when the counter is stopped (TAUBnTE.TEm = 0).

Address <TAUBn_base> + 248_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
TOM 15	TOM 14	TOM 13	TOM 12	TOM 11	TOM 10	TOM 09	TOM 08	TOM 07	TOM 06	TOM 05	TOM 04	TOM 03	TOM 02	TOM 01	TOM 00
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 14-148 TAUBnTOM register contents

Bit position	Bit name	Function
15 to 0	TOMm	Specifies the timer controlled channel output mode, if Direct Channel Output Mode is disabled (TAUBnTOE.TEm = 1): 0: Independent Channel Output Mode 1: Synchronous Channel Output Mode The output mode depends on several channel output control bits, as can be seen in Table 14-16 "Channel output modes" on page 490.

(3) TAUBnTOC - TAUBn channel output configuration register

This register specifies the output mode of each channel in combination with TAUBnTOMm.

Access This register can be read/written in 16-bit units. It can only be written when the counter is stopped (TAUBnTE.TEm = 0).

Address <TAUBn_base> + 24C_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
TOC 15	TOC 14	TOC 13	TOC 12	TOC 11	TOC 10	TOC 09	TOC 08	TOC 07	TOC 06	TOC 05	TOC 04	TOC 03	TOC 02	TOC 01	TOC 00
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 14-149 TAUBnTOC register contents

Bit position	Bit name	Function													
15 to 0	TOCm	<p>Specifies the output mode: 0: Operation mode 1 1: Operation mode 2 The output mode also depends on TAUBnTOM.TOMm, as can be seen in the following table.</p> <table border="1"> <thead> <tr> <th>TOMm</th><th>TOCm</th><th>Description</th></tr> </thead> <tbody> <tr> <td rowspan="2">0</td><td>0</td><td>Toggle mode: TAUBnTTOUTm toggles when INTTAUBnIm occurs.</td></tr> <tr> <td>1</td><td>Set/reset mode: TAUBnTTOUTm set when INTTAUBnIm occurs upon count start and reset when INTTAUBnIm occurs due to detection of a match between TAUBnCNTm and TAUBnCDRm, or, in One-Shot Pulse Output Function when the counter is 0.</td></tr> <tr> <td rowspan="2">1</td><td>0</td><td>Synchronous Channel Operation Mode 1: TAUBnTTOUTm set when INTTAUBnI occurs on the master channel and reset when INTTAUBnI occurs on the slave channel.</td></tr> <tr> <td>1</td><td>Synchronous Channel Operation Mode 2: TAUBnTTOUTm set when INTTAUBnIm occurs while the slave channel is counting down and reset when INTTAUBnIm occurs while the slave channel is counting up.</td></tr> </tbody> </table>	TOMm	TOCm	Description	0	0	Toggle mode: TAUBnTTOUTm toggles when INTTAUBnIm occurs.	1	Set/reset mode: TAUBnTTOUTm set when INTTAUBnIm occurs upon count start and reset when INTTAUBnIm occurs due to detection of a match between TAUBnCNTm and TAUBnCDRm, or, in One-Shot Pulse Output Function when the counter is 0.	1	0	Synchronous Channel Operation Mode 1: TAUBnTTOUTm set when INTTAUBnI occurs on the master channel and reset when INTTAUBnI occurs on the slave channel.	1	Synchronous Channel Operation Mode 2: TAUBnTTOUTm set when INTTAUBnIm occurs while the slave channel is counting down and reset when INTTAUBnIm occurs while the slave channel is counting up.
TOMm	TOCm	Description													
0	0	Toggle mode: TAUBnTTOUTm toggles when INTTAUBnIm occurs.													
	1	Set/reset mode: TAUBnTTOUTm set when INTTAUBnIm occurs upon count start and reset when INTTAUBnIm occurs due to detection of a match between TAUBnCNTm and TAUBnCDRm, or, in One-Shot Pulse Output Function when the counter is 0.													
1	0	Synchronous Channel Operation Mode 1: TAUBnTTOUTm set when INTTAUBnI occurs on the master channel and reset when INTTAUBnI occurs on the slave channel.													
	1	Synchronous Channel Operation Mode 2: TAUBnTTOUTm set when INTTAUBnIm occurs while the slave channel is counting down and reset when INTTAUBnIm occurs while the slave channel is counting up.													

(4) TAUBnTDE - TAUBn channel dead time output enable register

This register enables/disables dead time operation for each channel.

Access This register can be read/written in 16-bit units. It can only be written when the counter is stopped (TAUBnTE.TEm = 0).

Address <TAUBn_base> + 250_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
TDE	TDE	TDE	TDE	TDE	TDE	TDE	TDE	TDE	TDE	TDE	TDE	TDE	TDE	TDE	TDE
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 14-150 TAUBnTDE register contents

Bit position	Bit name	Function
15 to 0	TDEm	Enables/disables dead time control operation of channel m: 0: Disables dead time operation 1: Enables dead time operation The same settings must be set for the even and the odd slave channel that comprise a set. These bits only apply when: • TAUBnTOE.TOEm, TAUBnTOM.TOMm, and TAUBnTOC.TOCm = 1.

(5) TAUBnTDL - TAUBn channel dead time output level register

This register selects the phase period to which dead time is added.

Access This register can be read/written in 16-bit units.

Address <TAUBn_base> + 54_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
TDL	TDL	TDL	TDL	TDL	TDL	TDL	TDL	TDL	TDL	TDL	TDL	TDL	TDL	TDL	TDL
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 14-151 TAUBnTDL register contents

Bit position	Bit name	Function
15 to 0	TDLm	Selects the phase period to which dead time is added: 0: Positive phase period 1: Negative phase period These bits only apply when: • TAUBnTOE.TOEm, TAUBnTOM.TOMm, TAUBnTOC.TOCm, and TAUBnTDE.TDEm = 1.

14.22.5 TAUBn channel output level registers details

(1) TAUBnTO - TAUBn channel output register

This register specifies and reads the level of TAUBnTTOUTm.

Access This register can be read/written in 16-bit units.

Address <TAUBn_base> + 58_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
TO15	TO14	TO13	TO12	TO11	TO10	TO09	TO08	TO07	TO06	TO05	TO04	TO03	TO02	TO01	TO00
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 14-152 TAUBnTO register contents

Bit position	Bit name	Function
15 to 0	TOm	Specifies/reads the level of TAUBnTTOUTm: 0: Low 1: High Only TOm bits for which Independent Channel Output function is disabled (TAUBnTOEm = 0) can be written.

(2) TAUBnTOL - TAUBn channel output level register

This register specifies the output logic of the channel output bit (TAUBnTO.TOm).

Access This register can be read/written in 16-bit units.

Address <TAUBn_base> + 040_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
TOL	TOL	TOL	TOL	TOL	TOL	TOL	TOL	TOL	TOL	TOL	TOL	TOL	TOL	TOL	TOL
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 14-153 TAUBnTOL register contents

Bit position	Bit name	Function
15 to 0	TOLm	Specifies the output logic of the channel m output bit (TAUBnTO.TOm): 0: Positive logic (active high) 1: Inverted logic (active low) These bits apply in all channel output modes except Direct Channel Output Mode and channel output modes with real-time output.

14.22.6 TAUBn simultaneous rewrite register details

(1) TAUBnRDE - TAUBn channel reload data enable register

This register enables and disables simultaneous rewrite of the data register TAUBnCDRm. It also enables simultaneous rewrite of the data register TAUBnTOLm for the PWM output function and the triangle PWM output function.

Access This register can be read/written in 16-bit units. It can only be written when TAUBnTE.TEm = 0.

Address <TAUBn_base> + 260_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RDE	RDE	RDE	RDE	RDE	RDE	RDE	RDE	RDE	RDE	RDE	RDE	RDE	RDE	RDE	RDE
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 14-154 TAUBnRDE register contents

Bit position	Bit name	Function
15 to 0	RDEm	Enables/disables simultaneous rewrite of the data register of channel m: 0: Disables simultaneous rewrite 1: Enabled simultaneous rewrite

(2) TAUBnRDM - TAUBn channel reload data mode register

This register selects when the signal that controls simultaneous rewrite is loaded.

Access This register can be read/written in 16-bit units. It can only be written when TAUBnTE.TEm = 0.

Address <TAUBn_base> + 264_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RDM	RDM	RDM	RDM	RDM	RDM	RDM	RDM	RDM	RDM	RDM	RDM	RDM	RDM	RDM	RDM
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 14-155 TAUBnRDM register contents

Bit position	Bit name	Function
15 to 0	RDMm	Selects when the signal that triggers simultaneous is generated: 0: When the master channel counter starts counting 1: At the top of a triangle wave cycle These bits only apply when TAUBnRDE.RDEm = 1 and TAUBnRDS.RDSm = 0.

(3) TAUBnRDS - TAUBn channel reload data control channel select register

This register selects the control channel for simultaneous rewrite.

Access This register can be read/written in 16-bit or 1-bit units. It can only be written when TAUBnTE.TEm = 0.

Address <TAUBn_base> + 268_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RDS	RDS	RDS	RDS	RDS	RDS	RDE	RDE	RDE	RDE	RDE	RDE	RDE	RDE	RDE	RDE
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 14-156 TAUBnRDS register contents

Bit position	Bit name	Function
15 to 0	RDSm	Specifies which channel is monitored for the simultaneous rewrite trigger: 0: Master channel 1: Another upper channel

(4) TAUBnRDC - TAUBn channel reload data control register

This register specifies the channel that generates the INTTAUBnIm signal that triggers simultaneous rewrite.

Access This register can be read/written in 16-bit units. It can only be written when TAUBnTE.TEm = 0

Address <TAUBn_base> + 26C_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RDC	RDC	RDC	RDC	RDC	RDC	RDC	RDC	RDC	RDC	RDC	RDC	RDC	RDC	RDC	RDC
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 14-157 TAUBnRDC register contents

Bit position	Bit name	Function
15 to 0	RDCm	Specifies whether the channel is monitored for an INTTAUBnIm signal that is used as the simultaneous rewrite trigger: 0: Channel is not monitored 1: Channel is monitored These bits only apply when TAUBnRDS.RDSm = 1.

(5) TAUBnRDT - TAUBn channel reload data trigger register

This register triggers the simultaneous rewrite pending state.

Access This register can be written in 16-bit units. It is always read as 0000_H.

Address <TAUBn_base> + 044_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RDT 15	RDT 14	RDT 13	RDT 12	RDT 11	RDT 10	RDT 09	RDT 08	RDT 07	RDT 06	RDT 05	RDT 04	RDT 03	RDT 02	RDT 01	RDT 00
W	W	W	W	W	W	W	W	W	W	W	W	W	W	W	W

Table 14-158 TAUBnRDT register contents

Bit position	Bit name	Function
15 to 0	RDTm	Triggers the simultaneous rewrite pending state: 0: No function 1: Simultaneous rewrite pending state is triggered. The simultaneous rewrite pending flag (TAUBnRSFm) is set to 1. The system waits for the simultaneous rewrite trigger. TAUBnRDT.RDTm immediately returns to 0.

(6) TAUBnRSF - TAUBn channel reload status register

This flag register indicates that simultaneous rewrite is possible.

Access This register can be read in 16-bit units.

Address <TAUBn_base> + 048_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RSF 15	RSF 14	RSF 13	RSF 12	RSF 11	RSF 10	RSF 09	RSF 08	RSF 07	RSF 06	RSF 05	RSF 04	RSF 03	RSF 02	RSF 01	RSF 00
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Table 14-159 TAUBnRSF register contents

Bit position	Bit name	Function
15 to 0	RSFm	Indicates the simultaneous rewrite status: 0: Simultaneous rewrite disabled 1: Simultaneous rewrite enabled

14.22.7 TAUBn emulation register

(1) TAUBnEMU - TAUB emulation register

This register controls whether the TAUBn can be stopped during emulation, for instance upon a breakpoint hit.

Access This register can be read/written in 8-bit units only when TAUBnTE.TEm = 0.

Address <TAUBn_base> + 290_H

Initial Value 00_H

	7	6	5	4	3	2	1	0
TAUBn SVSDIS	0	0	0	0	0	0	0	0
	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 14-160 TAUBnEMU register contents

Bit position	Bit name	Function
7	TAUBn SVSDIS	Emulation control 0: TAUBn can be stopped during emulation 1: TAUBn continuous operating during emulation

Chapter 15 Timer Array Unit J (TAUJ)

This chapter contains a generic description of the Timer Array Unit J (TAUJ).

The first section describes all V850E2/Fx4-G specific properties, such as instances, register base addresses, input/output signal names, etc. The subsequent sections describe the features that apply to all implementations.

15.1 V850E2/Fx4-G TAUJ Features

Instances This microcontroller has following number of instances of the Timer Array Unit J.

Table 15-1 Instances of TAUJ

Timer Array Unit J	
Instance	1
Name	TAUJ0

Instances index n Throughout this chapter, the individual instances of a Timer Array Unit J is identified by the index “n” (n = 0), for example, TAUJnTOM for the TAUJn channel output mode register.

Channel index m The Timer Array Unit J has 4 channels. Throughout this chapter, the individual channels are identified by the index “m” (m = 0 to 3), thus a certain channel is denoted as CHm. The even numbered channels (m = 0, 2) are denoted as CHm_even. The odd numbered channels (m = 1, 3) are denoted as CHm_odd.

Register addresses All TAUJ n register addresses are given as address offsets to the individual base address <TAUJ n_base>. The <TAUJ n_base> address of each TAUJn are listed in the following table:

Table 15-2 Register base addresses <TAUJn_base>

TAUJn instance	<TAUJn_base> address
TAUJ 0	FF81 1000 _H

Clock supply All Timer Array Units J provide one clock input.

Table 15-3 TAUJn clock supply

TAUJn instance	TAUJn clock	Connected to
TAUJ0	PCLK	Clock Controller CKSCLK_A03




Figure 15-1 TAUJ clock supply

Interrupts and DMA The Time Array Unit J can generate the following interrupt and DMA requests:

Table 15-4 TAUJn interrupt and DMA requests

TAUJn signals	Function	Connected to
TAUJ0:		
INTTAUJ0I0	Channel 0 interrupt	Interrupt Controller INTTAUJ0I0 ^a DMA Controller trigger 44 Wake-up Sequencer INTTAUJ0I0
INTTAUJ0I1	Channel 1 interrupt	Interrupt Controller INTTAUJ0I1 ^a DMA Controller trigger 45 Wake-up Sequencer INTTAUJ0I1
INTTAUJ0I2	Channel 2 interrupt	Interrupt Controller INTTAUJ0I2 ^a DMA Controller trigger 46 Wake-up Sequencer INTTAUJ0I2
INTTAUJ0I3	Channel 3 interrupt	Interrupt Controller INTTAUJ0I3 ^{ab} DMA Controller trigger 47 TAUB0 TAUB0TTIN0, TAUB0TTIN15 ^c

a) These interrupts can be used as a wake-up source from any stand-by mode. Refer to the chapter “Stand-by Controller (STBC)” for details.

b) These signals can be used to as a trigger source to start the A/D Converter. Refer to the section “H/W Trigger Expansion” in the chapter “A/D Converter (ADAA)”.

c) Refer to section “TAUB Input Selections” in the “Timer Array Unit B (TAUB)” for details.

TAUJ H/W reset The Time Array Units J and their registers are initialized by the following reset signal:

Table 15-5 TAUJn reset signal

TAUJn	Reset signal
TAUJn	• Reset Controller SYSRES

I/O signals The I/O signals of the Timer Array Unit J are listed in the following table.

Table 15-6 TAUJn I/O signals

TAUJ signal	Function	Connected to
TAUJ0:		
TAUJ0TTIN0 to TAUJ0TTIN3	Channel 0 to 3 input	Port TAUJ0I0 ^a to TAUJ0I3 ^a
TAUJ0TTOUT0 to TAUJ0TTOUT3	Channel 0 to 3 output	Port TAUJ0O0 to TAUJ0O3

a) These input signals are passed through a noise filter, refer to the section “Port Filters” in the chapter “Port Functions”.

15.2 Functional Overview

Features summary The TAUJ has the following functions:

- 4 channels
- 32-bit counter and 32-bit data register per channel
- Independent channel operation
- Synchronous channel operation (master and slave operation)
- Generation of different types of output signal
- Counter can be triggered by external signal
- Interrupt generation

The following figure shows the main components of the TAUJ:




Figure 15-2 Block diagram of the TAUJ

The prefix “TAUJn” has been omitted from the register names for the sake of clarity in the above figure.

15.2.1 Terms

In this chapter, the following terms are used:

- **Independent / synchronous channel operation**

Independent or synchronous channel operation describes the dependency of channels on each other:

- If a channel operates independent of all other channels, this is called independent channel operation.
- If a channel operates depending on other channels, this is called synchronous channel operation.

- **Channel group**

In synchronous channel operation, all channels that depend on each other are referred to as a “channel group”.

A channel group has one master channel and one or more slave channels.

- **Operation mode**

An operation mode can be selected for every channel m . The operation mode defines the *basic* operation and features of a channel.

In synchronous channel operation, every channel in the channel group can operate in a different operation mode.

Examples are “Capture Mode”, and “Interval Timer Mode”.

- **Channel output mode**

The channel output mode defines the operation of $TAUJnTTOUTm$

- of a single channel (independent output operation) or
- of all channels in a channel group (synchronous output operation).

Example: “Independent Channel Output Mode 1”

- **Channel operation function**

The channel operation function defines the *complete* function and all features

- of a single channel (independent channel operation) or
- of all channels in a channel group (synchronous channel operation).

It defines the operation mode, start and capture trigger, count clock, and the channel output mode.

Examples are “Interval Timer Function”, “ $TINm$ Input Position Detection Function”, and “ $TINm$ Input Period Count Detection Function”

- **Upper / lower channel**

Depending on the channel number m , a neighboring channel can be referred to as “upper” or “lower” channel:

- Upper channel: Channel with a smaller channel number
- Lower channel: Channel with a higher channel number

Example:

For channel 2, channel 1 is an upper channel and channel 3 is a lower channel.

15.3 Functional Description

The Timer Array Unit J is used to perform various count or timer operations and to output a signal which depends on the result of the operation. It contains one prescaler block for count clock generation and 4 channels, each equipped with a 32-bit counter TAUJnCNTm and a 32-bit data register TAUJnCDRm to hold the start or compare value of the counter.

It also contains several control and status registers.

Independent and synchronous operation Every channel can operate in two operation modes, either independently or in combination with other channels (synchronously), i.e. multiple channels depend on each other with one master and one or more slave channels.

When a channel is operated independently, its operation mode and functions are not affected by those of other channels. When a channel is operated synchronously it is either a master or a slave. A master channel can have multiple slaves, and the state of one channel affects that of the other channels. For example, this means that one channel can control when another starts to count, is reset, etc.

The following describes the functional blocks:

Prescaler block The prescaler block provides up to 4 clock signals (CK0 to CK3) that can be used as count clocks for all channels.

Count clocks CK0 to CK2 are derived from PCLK by a configurable prescaler division factor of 2^0 to 2^{15} . The fourth count clock CK3 can be adjusted more precisely by an additional division factor that is not a power of 2.

Clock and count clock selection For every channel, the count clock selector selects which of the following is used as the clock source:

- One of the clocks CK0 to CK3 (selected by the clock selector)
- INTTAUJnIm from master channel
- Edge detected TAUJnTTINm input signal

Controller The controller controls the main operations of the counter:

- Operation mode (selected by bits TAUJnCMORm.MD[4:0])
- Counter start enable (TAUJnTS.TSm) and counter stop (TAUJnTT.TTm)

When counter start is enabled, status flag TAUJnTE.TEm is set.

Trigger selector Depending on the selected operation mode, the counter starts automatically when it is enabled (TAUJnTE.TEm = 1), or it waits for an external start trigger signal. Any of the following signals can be used as the start trigger:

- Synchronous channel start trigger input TAUJnTSSTm
- TAUJnTTINm input valid edge
- INTTAUJnIm from the master channel

- Simultaneous rewrite controller** Simultaneous rewrite control is a special function that can be used in synchronous operation modes. The data registers of all channels in a channel group can be rewritten at any time. The simultaneous rewrite controller ensures that new data register values of all channels become effective at the same time.
- TAUJnTO Controller** The output control of every channel enables the generation of various output signal forms such as PWM signals.
- Signals** The TAUJ has various input and output signals. A full list can be found in the first section of this chapter under the keyword "I/O signals".

15.4 General Operating Procedure

The following lists the general operation procedure for the TAUJn:

After reset release, the operation of each channel is stopped. Clock supply is started and writing to each register is enabled. All circuits and registers of all channels are initialized. The control register of TAUJnTTOUTm is also initialized and outputs a low level.

1. Set the TAUJnTPS and TAUJnBRS registers to specify the clock frequency of CK0 to CK3.
2. Configure the desired TAUJn function:
 - Set the operation mode
 - Set the channel output mode
 - Set any other control bits
3. Enable the counter by setting the TAUJnTS.TSm bit to 1.
The counter starts to count immediately, or when an appropriate trigger is detected, depending on the bit settings.
The function is in operation.
4. If desired, and if possible for the configured function, stop the counter or perform a forced restart operation.
5. Stop the function by setting the TAUJnTT.TTm bit to 0.

Note A detailed description of the required control bits and the operation of the individual functions is given in the following chapters:

15.14 “Independent Channel Interrupt Functions” on page 725

15.15 “Independent Channel Signal Measurement Functions” on page 739

15.16 “Other Independent Channel Functions” on page 770

15.17 “Synchronous PWM Signal Functions Triggered at Regular Intervals” on page 777

15.5 Operation Modes

The TAUJ contains 7 operation modes. These determine the basic behavior of a channel, for example whether a timer counts up or down, whether the data register TAUJnCDRm acts as a compare register or stores the initial value of the counter, etc.

One operation mode can be set for each channel. It is specified using the TAUJnCMORm.MD[4:0] bits.

When choosing a function, these settings cannot be specified individually, but are grouped under the term operation mode. If a function uses multiple channels, the operation mode of each channel must be set correctly for the function to work correctly.

Note For more information about the operation modes required by each function, refer to the required function in the following chapters:

15.14 “Independent Channel Interrupt Functions” on page 725

15.15 “Independent Channel Signal Measurement Functions” on page 739

15.16 “Other Independent Channel Functions” on page 770

15.17 “Synchronous PWM Signal Functions Triggered at Regular Intervals” on page 777

15.6 Concepts of Synchronous Channel Operation

In synchronous channel operation, multiple channels depend on each other, or are affected by changes in another channel. Therefore, several rules apply for the use of synchronous channel functions. These rules are detailed in 15.6.1 “Rules”.

Two special features for synchronous channel operation are detailed in the following subchapters:

- 15.6.2 “Simultaneous start and stop of synchronous channel counters” on page 705
- 15.7 “Simultaneous Rewrite” on page 706

15.6.1 Rules

- Number of masters and slaves**
- Only even channels (CH0, CH2) can be set as master channels. Any channel apart from CH0 can be set as a slave channel.
 - Only channels lower than the master channel can be set as slave channels, and several slave channels can be set for one master channel.
Example: If CH2 is a master channel, CH3 can be set as slave channel.
 - If two master channels are used, slave channels cannot cross the master channels.
Example: If CH0 and CH2 are master channels, CH1 can be set as slave channels for CH0, but CH3 cannot.
- Operation clock**
- The same operation clock must be set for the slave channel and the master channel. This is achieved using the TAUJnCMORm.CKS[1:0] bits of the slave and master channel.

The basic concepts of master/slave usage and operation clocks are illustrated in the following figure.




Figure 15-3 Grouping of the channels and assignment of operation clocks

INTTAUJnIm, start trigger, and count clock

- Master channels can transfer an interrupt request (INTTAUJnI), the start trigger, and the count clock to slave channels.
- Slave channels can use INTTAUJnI, the start trigger, and the count clock of the master channels but cannot transfer their INTTAUJnI, start trigger, or count clock to the lower channels.
- A master channel cannot use INTTAUJnI, the start trigger, or the count clock of the higher master channels.

15.6.2 Simultaneous start and stop of synchronous channel counters

Channels that are operated synchronously can be started and stopped simultaneously, both within a TAUJ unit, and between TAUJ units.

(1) Simultaneous start and stop within a TAUJ unit

- To simultaneously start synchronized channels, the TAUJnTS.TSm bits of the channels must be set at the same time.
- To simultaneously stop synchronized channels, the TAUJnTT.TTm bits of the channels must be set at the same time.

Writing to the TAUJnTS.TSm bits sets the corresponding TAUJnTE.TEm bits to 1, enabling counting. TAUJnTS.TSm = 1 only enables the corresponding counter to start; the exact time that it starts depends on the operation mode.

(2) Simultaneous start between TAUJ units

Counters in different TAUJ units can also be started simultaneously if the corresponding counters are enabled before receiving the simultaneous trigger signal. The simultaneous start trigger register is then sent to the TAUJnTSSTm input.

15.7 Simultaneous Rewrite

15.7.1 Introduction

Simultaneous rewrite describes the ability to change the compare/start value and the output logic of multiple channels at the same time.

The corresponding data and control registers (TAUJnCDRm and TAUJnTOLm) can nevertheless be written at any time. The new value does not affect the counter operation or the output signal until simultaneous rewrite is triggered.

Simultaneous rewrite can be triggered by the counter on the master channel reaching a certain value.

The following table shows the settings for simultaneous rewrite (TAUJnRDM.RDMm = 0).

Table 15-7 Simultaneous rewrite settings

Method	Simultaneous rewrite triggered when	TAUJnRDE.RDEm
-	No simultaneous rewrite	0
A	The master channel (re)starts counting	1

15.7.2 How to control simultaneous rewrite

The following figure shows the general procedure for simultaneous rewrite. The three main blocks (Initial settings, Start counter & count operation, and Simultaneous rewrite) are explained afterwards.




Figure 15-4 General procedure for simultaneous rewrite

(1) Initial settings

- To enable simultaneous rewrite in channel m, set `TAUJnRDE.RDEm = 1`
- To select simultaneous rewrite when the master channel starts counting, set `TAUJnRDM.RDMm = 0`

(2) Start counter and count operation

- To start all the `TAUJnCNTm` counters in the channel group, set the corresponding `TAUJnTS.TSm` bits to 1. `TAUJnTOL.TOLm` and the values in the data registers (`TAUJnCDRm`) are written to the corresponding TOLm buffer (`TAUJnTOL.TOLm` buf) and data buffer registers (`TAUJnCDRm` buf)

and the counters start.

- Setting the reload data trigger bit (TAUJnRDT.RDTm) to 1 sets the reload flag (TAUJnRSF.RSFm) to 1, enabling simultaneous rewrite. TAUJnRDT.RDTm then immediately returns to 0, but TAUJnRSF.RSFm remains at 1 until simultaneous rewrite has taken place.
- When the specified trigger for simultaneous rewrite is detected, the TAUJnRSF.RSFm bit is checked to see if simultaneous rewrite is enabled (TAUJnRSF.RSFm = 1). If it is, simultaneous rewrite is carried out. Otherwise the value of the TAUJnRSF.RSFm bit is re-evaluated the next time the trigger is detected.

(3) Simultaneous rewrite

- When the simultaneous rewrite trigger is detected and simultaneous rewrite is enabled (TAUJnRSF.RSFm = 1), the current values of the data registers are copied to their buffers. These values are then written to the corresponding counters and the values are applied the next time the counter starts or restarts.
- The TAUJnRSF.RSFm bit is set to 0, and the system awaits the next simultaneous rewrite trigger.

15.7.3 Other general rules of simultaneous rewrite

The following rules also apply:

- TAUJnRDE.RDEm and TAUJnRDM.RDMm cannot be changed while the counter is in operation (TAUJnTE.TEm = 1).
- TAUJnTOL.TOLm can only be rewritten during operation when in PWM output function. For all other output functions, TAUJnTOL.TOLm must be written before the counter starts. If it is rewritten in another function, TAUJnTOUTm outputs an invalid wave.

15.7.4 Simultaneous rewrite procedure

Simultaneous rewrite is executed, when the master channel (re) starts counting. The simultaneous rewrite procedure is described in the following figure.




Figure 15-5 Simultaneous rewrite when the master channel (re) starts counting

Setup:

- CH0 is the master channel, counting down, CH1 represents an arbitrary slave channel, and simultaneous rewrite is applied when the master channel starts counting.

Description:

1. When the counter starts, the value of TAUJnCDRm is copied to the TAUJnCDRm buffer and the value of TAUJnTOL.TOLm is copied to the TAUJnTOL.TOLm buffer. The TAUJnCDRm buffer value is written to the counter.
2. The TAUJnCDRm and TAUJnTOL.TOLm registers can be written at any time, but the values do not affect the counter as the counter reads the buffer values.
3. CH0 restarts counting, but simultaneous rewrite does not occur because it is disabled (TAUJnRSF.RSFm = 0).
4. The reload data trigger bit (TAUJnRDT.RDTm) is set to 1 which sets the status flag (TAUJnRSF.RSFm = 1), enabling simultaneous rewrite.
5. Simultaneous rewrite is triggered by counter TAUJnCNT0 starting to count down. The TAUJnCDRm value is written to the TAUJnCDRm buffer and the TAUJnTOL.TOLm value is written to the TAUJnTOL.TOLm buffer.
 - The counter starts to count down from the value in the TAUJnCDRm buffer and the TAUJnRSF.RSFm bit is reset to 0.
 - The output logic specified by TAUJnTOL.TOLm becomes effective.
6. The counters count down and await the next simultaneous rewrite trigger. The values of TAUJnCDRm and TAUJnTOL.TOLm can be changed again.

15.8 Channel Output Modes

The output of the TAUJnTTOUTm pin can be controlled in two ways, the latter of which can be further split into individual modes:

- By software (Direct Channel Output Mode, TAUJnTOE.TOEm = 0)

When controlled by software, the output register bit (TAUJnTO.TOm) can be written and the value of the bit is transferred to the output pin (TAUJnTTOUTm).

- By TAUJ signals (TAUJnTOE.TOEm = 1)

When operated by TAUJ signals, the output level of TAUJnTTOUTm is set or reset or toggled by internal signals. The value of TAUJnTO.TOm is updated accordingly to reflect the value of TAUJnTTOUTm.

- Independently (Independent Channel Output Mode, TAUJnTOM.TOMm = 0)

When operated independently, the output of the TAUJnTTOUTm pin is only affected by settings of channel m. Therefore, independent channel operation must be selected (TAUJnTOM.TOMm = 0).

- Synchronously (Synchronous Channel Output Mode, TAUJnTOM.TOMm = 1)

When operated synchronously, the output of the TAUJnTTOUTm pin is affected by settings of channel m and those of other channels. Therefore, synchronous channel operation must be selected for all participating channels (TAUJnTOM.TOMm = 1).

The TAUJnTO.TOm bit can always be read to determine the current value of TAUJnTTOUTm, regardless of whether the pin is controlled by software, operated independently, or operated synchronously.

Control bits The settings of the control bits required to select a specific channel output mode are listed in *Table 15-8 “Channel output modes” on page 712*.

The channel output modes are described in detail in

- *15.8.2 “Channel output modes controlled independently by TAUJn signals” on page 714 to*
- *15.8.3 “Channel output modes controlled synchronously by TAUJn signals” on page 715.*

Output logic Positive logic or inverted logic of the output is specified by control bit TAUJnTOL.TOLm.

The value of the TAUJnTOL.TOLm bit must be set before the counter is started. It can only be changed during operation in PWM output function. Otherwise, changes to TAUJnTOL.TOLm result in an invalid TAUJnTTOUTm signal.

Refer to *15.7 “Simultaneous Rewrite” on page 706*.

The channel output modes and the channel output control bits are listed in the following table (TAUJnTOC.TOCm = 0).

Table 15-8 Channel output modes

Channel output mode	TAUJnTOE. TOEm	TAUJnTOM. TOMm
By software		
Direct Channel Output Mode	0	x
By timer signals, independently (Independent Channel Output Mode)		
Independent Channel Output Mode 1	1	0
By timer signals, synchronously (Synchronous Channel Output Mode)		
Synchronous Channel Output Mode 1	1	1

- The combinations not listed in this table are forbidden.
- The bit marked with an x can be set to any value.

Note The following bits cannot be changed during count operation (TAUJnTE.TE = 1):

- TAUJnTOM.TOMm
- TAUJnTOC.TOCm

15.8.1 General procedure for specifying a channel output mode

The following steps describe the general procedure for specifying a TAUJnTTOUTm channel output mode. The prerequisite is that timer output operation is disabled (TAUJnTOE.TOEm = 0).

1. Set TAUJnTO.TOm to specify the initial level of the TAUJnTTOUTm output.
2. Set the channel output mode using *Table 15-8 “Channel output modes” on page 712* and the output logic using the TAUJnTOL.TOLm bit.
3. Start the counter (TAUJnTS.TSm = 1).




Figure 15-6 General procedure for specifying a TAUJnTTOUTm channel output mode

The following figure shows a general illustration of how the output changes when the counter is enabled:




Figure 15-7 General change of the TAUJnTTOUTm output

- TAUJnTO.TOm sets the initial value of TAUJnTTOUTm and can be changed while TAUJnTOE.TOEm = 0.
- TAUJnTOL.TOLm specifies whether the set signal sets TAUJnTO.TOm to high (TAUJnTOL.TOLm = 0) or low (inverted logic, TAUJnTOL.TOLm = 1).

15.8.2 Channel output modes controlled independently by TAUJn signals

This chapter lists the channel output modes that are controlled independently by TAUJn signals. The control bits used to specify a mode are listed in *Table 15-8 "Channel output modes" on page 712*.

(1) Independent Channel Output Mode 1

Set/reset conditions In this output mode, TAUJnTTOUTm toggles when INTTAUJnIm is detected. The value of TAUJnTOL.TOLm is ignored.

Prerequisites None, other than those in *Table 15-8 "Channel output modes" on page 712*.

15.8.3 Channel output modes controlled synchronously by TAUJn signals

This chapter lists the channel output modes that are controlled synchronously by TAUJn signals. The control bits used to specify a mode are listed in *Table 15-8 "Channel output modes" on page 712*.

(1) Synchronous Channel Output Mode 1

Set/reset conditions In this output mode, INTTAUJnIm of the master channel serves as the set signal and INTTAUJnIm of the slave channel as the reset signal. If INTTAUJnIm of the master channel and INTTAUJnIm of the slave channel are generated at the same time, INTTAUJnIm of the slave channel (reset signal) has priority over INTTAUJnIm (set signal) of the master channel, i.e. the master channel is ignored.

Prerequisites None, other than those in *Table 15-8 "Channel output modes" on page 712*.

15.9 Start Timing of Operating Modes

This chapter describes when the counters of the different operating modes start after the TAUJnTS.TSm bit is set to 1.

In all modes, the value of the data register and whether or not an interrupt is issued depends on the individual mode and corresponding register settings.

15.9.1 Interval Timer Mode, Capture Mode

The counter starts at the start of the next count clock cycle after TAUJnTS.TSm is set to 1. The value of data register is also loaded at the point the counter starts.




Figure 15-8 Start timing of Interval Timer Mode, Capture Mode

15.9.2 Other operating modes

In all other operating modes, the count clock cycles are ignored with regard to starting the counter. The counter is only triggered by detection of a valid TAUJnTTINm edge. The value of data register is also loaded at the point the counter starts. Nevertheless, the count clock cycles determine the frequency with which all operations take place.




Figure 15-9 Start timing of all other operating modes

15.10 TAUJnTTOUTm Output and INTTAUJnIm Generation when Counter Starts or Restarts

When the counter starts, it is possible to specify whether an INTTAUJnIm is generated using the TAUJnCMORm.MD0 bit. The effect of the bit depends on the selected mode, as shown in the following table. The effects of INTTAUJnIm on TAUJnTTOUTm depend on the selected channel operation function.

Table 15-9 Effect of CMORm.MD0 bit on generation of INTTAUJnIm when counter is triggered

Mode	TAUJnCMORm.MD0 bit	INTTAUJnIm generated when counter starts
Interval Timer Mode	0	No
Capture Mode	1	Yes
Count Capture Mode	1	Yes
Capture & One Count Mode	0	No
Capture & Gate Count Mode	0	No
One Count Mode	0/1	No, regardless of setting of TAUJnCMORm.MD0 bit.
Gate Count Mode	0/1	No, regardless of setting of TAUJnCMORm.MD0 bit.




Figure 15-10 INTTAUJnIm generated when counter starts




Figure 15-11 INTTAUJnIm not generated when counter starts

15.11 Interrupt Generation upon Overflow

Certain independent functions that count up, overflow without generating an interrupt when they reach $FFFF\ FFFF_H$. This section describes how it is possible to generate an interrupt, by combining a channel operating in one of these modes with a channel in a different operation mode which counts down.

The appropriate operation mode for the second channel depends on the operation mode of the first channel. Nevertheless, the principle is the same for all combinations:

- Find a operation mode for the second channel that counts down in such a manner, that it reaches $0000\ 0000_H$ at the same time as the first channel overflows ($TAUJnCNTm = FFFF\ FFFF_H$).
- Set $TAUJnCDRm$ of the second channel to $FFFF\ FFFF_H$
- The two channels must count at the same speed (i.e. they must have the same count clock)
- Both channels are triggered by the same $TAUJnTTINm$ input
- The trigger detection settings ($TAUJnCMORm.STS[2:0]$ and $TAUJnCMURm.TIS[1:0]$) must be identical for both channels
- This is only possible for TAUJ0 and TAUJ4 by using configurable "input selectors" (on system level)

Result: the down-counter of the second channel reaches $0000\ 0000_H$ at exactly the same time as the up-counter of the first channel overflows ($TAUJnCNTm = FFFF\ FFFF_H$). Thus the second channel generates the desired interrupt.

The following sections list the operating modes that count down that are required to match specific operating modes that count up, as well as example timing diagrams.

15.11.1 Capture Mode

- Applies to**
- TAUJnTTINm Input Pulse Interval Measurement Function
 - Real-Time Output Function Type 2
 - Simultaneous Rewrite Trigger Generation Function Type 2

Combine with Interval Timer Mode




Figure 15-12 Combination of Capture Mode and Interval Timer Mode

Timing diagram




Figure 15-13 Interrupt generation via combination of Capture Mode and Interval Timer Mode

15.11.2 Capture and One Count Mode

Applies to • TAUJnTTINm Input Signal Width Measurement Function
 Combine with One Count Mode




Figure 15-14 Combination of Capture and One Count Mode and One Count Mode

Timing diagram




Figure 15-15 Interrupt generation via combination of Capture and One Count Mode and One Count Mode

15.11.3 Count Capture Mode

- Applies to • TAUJnTTINm Input Position Detection Function
Combine with Interval Timer Mode




Figure 15-16 Combination of Count Capture Mode and Interval Timer Mode

Timing diagram




Figure 15-17 Interrupt generation via combination of Count Capture Mode and Interval Timer Mode

In the above timing diagram, TAUJnCSRm.OVF is set to 1 when TAUJnCNTm overflows. It is reset by a software command (TAUJnCSCm.CLOV = 1).

15.11.4 Capture and Gate Count Mode

- Applies to • TAUJnTTINm Input Period Count Detection Function
 Combine with Gate Count Mode




Figure 15-18 Combination of Capture and Gate Count Mode and Gate Count Mode

Timing diagram




Figure 15-19 Interrupt generation via combination of Capture and Gate Count Mode and Gate Count Mode

In the above timing diagram, TAUJnCSRm.OVF is set to 1 when TAUJnCNTm overflows. It is reset by a software command (TAUJnCSCm.CLOV = 1).

15.12 TAUJnTTINm Edge Detection

Edge detection is based on the operation clock. This means that an edge can only be detected at the next rising edge of the operation clock. This can lead to a maximum delay of one operation clock cycle.

The following figure shows when edge detection takes place.




Figure 15-20 Basic edge detection timing

15.13 Independent Channel Operation Functions

The following sections list the independent channel operation functions provided by the Timer Array Unit J. For a general overview of independent channel operation, see 15.3 “*Functional Description*” on page 699 .

15.14 Independent Channel Interrupt Functions

This chapter describes functions that generate interrupts at regular intervals.

- 15.14.1 “*Interval Timer Function*”
- 15.14.2 “*TAUJnTTINm Input Interval Timer Function*”

15.14.1 Interval Timer Function

(1) Overview

Summary This function is used as a reference timer for generating timer interrupts (INTTAUJnIm) at regular intervals. When an interrupt is generated, the TAUJnTTOUTm signal toggles, resulting in a square wave.

- Prerequisites**
- The operation mode must be set to Interval Timer Mode, refer to *Table 15-10 "TAUJnCMORm settings for Interval Timer Function" on page 728*
 - The channel output mode must be set to Independent Channel Output Mode 1, refer to *15.8 "Channel Output Modes" on page 711*

Description The counter is started by setting the channel trigger bit (TAUJnTS.TSm) to 1. This in turn sets TAUJnTE.TEm = 1, enabling count operation. The current value of TAUJnCDRm is written to TAUJnCNTm and the counter starts to count down from this value.

When the counter reaches 0000 0000_H, INTTAUJnIm is generated and the TAUJnTTOUTm signal toggles. TAUJnCNTm then reloads the TAUJnCDRm value and subsequently continues operation.

The value of TAUJnCDRm can be rewritten at any time, and the changed value of TAUJnCDRm is applied the next time the counter starts to count down.

The counter can be stopped by setting TAUJnTT.TTm to 1, which in turn sets TAUJnTE.TEm to 0. TAUJnCNTm and TAUJnTTOUTm stop but retain their values. The counter can be reset by setting TAUJnTS.TSm to 1. The counter can also be forcibly restarted (without stopping it first) by setting TAUJnTS.TSm to 1 during operation.

Conditions If the TAUJnCMORm.MD0 bit is set to 0, the first interrupt after a start or restart is not generated, and therefore TAUJnTTOUTm does not toggle. This results in an inverted TAUJnTTOUTm signal compared to when TAUJnCMORm.MD0 is set to 1. For details refer to *15.10 "TAUJnTTOUTm Output and INTTAUJnIm Generation when Counter Starts or Restarts" on page 718*.

(2) Equations

$\text{INTTAUJnIm cycle} = \text{count clock cycle} \times (\text{TAUJnCDRm} + 1)$

$\text{TAUJnTTOUTm square wave cycle} = \text{count clock cycle} \times (\text{TAUJnCDRm} + 1) \times 2$

(3) Block diagram and general timing diagram




Figure 15-21 Block diagram for Interval Timer Function

The following settings apply to the general timing diagram:

- INTTAUJnIm not generated at operation start (TAUJnCMORM.MD0 = 0)




Figure 15-22 General timing diagram for Interval Timer Function

(4) Register settings**(a) TAUJnCMORm**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]		CCS[1:0]		MAS	STS[2:0]		COS[1:0]		-	MD[4:1]				MD0	

Table 15-10 TAUJnCMORm settings for Interval Timer Function

Bit name	Setting
CKS[1:0]	00: Operation clock = CK0 01: Operation clock = CK1 10: Operation clock = CK2 11: Operation clock = CK3
CCS[1:0]	00: Operation clock is used as the count clock
MAS	0: Not used, so set to 0
STS[2:0]	000: Counter triggered by software trigger
COS[1:0]	00: Not used, so set to 00
MD[4:1]	0000: Interval Timer Mode
MD0	0: INTTAUJnIm not generated and TAUJnTTOUTm does not toggle at operation start or restart 1: Generates INTTAUJnIm and toggles TAUJnTTOUTm at operation start or restart

(b) TAUJnCMURm

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
														TIS[1:0]	

Table 15-11 TAUJnCMURm settings for Interval Timer Function

Bit name	Setting
TIS[1:0]	00: Not used, so set to 00

(c) Channel output mode**Table 15-12 Control bit settings for Independent Channel Output Mode 1**

Bit name	Setting
TOE.TOEm	1: Disables Direct Channel Output Mode
TOM.TOMm	0: Independent channel output
TOC.TOCm	0: Operation mode 1 (= Toggle mode if TAUJnTOM.TOMm = 0)
TOL.TOLm	0: Positive logic

Note The channel output mode can also be set to Direct Channel Output Mode by setting TAUJnTOE.TOEm = 0. TAUJnTTOUTm can then be controlled independently of the interrupts. For details refer to 15.8 “Channel Output Modes” on page 711 .

(d) Simultaneous rewrite

The simultaneous rewrite registers (TAUJnRDE and TAUJnRDM) cannot be used with the Interval Timer Function. Therefore, these registers must be set to 0.

Table 15-13 Simultaneous rewrite settings for Interval Timer Function


Bit name	Setting
RDE.RDEm	0: Disables simultaneous rewrite
RDM.RDMm	0: When simultaneous rewrite is disabled (TAUJnRDE.RDEm = 0), set these bits to 0

(5) Operating procedure for Interval Timer Function


Table 15-14 Operating procedure for Interval Timer Function

	Operation	Status of TAUJn
Restart ↓	Initial channel setting Set the TAUJnCMORm register and TAUJnCMURm registers as described in <i>Table 15-10 "TAUJnCMORm settings for Interval Timer Function" on page 728</i> and <i>Table 15-11 "TAUJnCMURm settings for Interval Timer Function" on page 728</i> Set the value of the TAUJnCDRm register Set the channel output mode by setting the control bits as described in <i>Table 15-12 "Control bit settings for Independent Channel Output Mode 1" on page 729</i>	Channel operation is stopped. (A clock is supplied, and a small amount of power is consumed.)
	Start operation Set TAUJnTS.TSm to 1. TAUJnTS.TSm is a trigger bit, so it is automatically cleared to 0.	TAUJnTE.TEm is set to 1 and the counter starts. TAUJnCnTm loads the TAUJnCDRm value. When TAUJnCMORm.MD0 = 1, INTTAUJnIm is generated and TAUJnTTOUTm toggles.
	During operation The TAUJnCDRm register value can be changed at any time. The TAUJnCnTm register can be read at all times.	TAUJnCnTm counts down. When the counter reaches 0000 0000 _H : <ul style="list-style-type: none"> • TAUJnCnTm reloads the TAUJnCDRm value and continues count operation • INTTAUJnIm is generated and TAUJnTTOUTm toggles.
	Stop operation Set TAUJnTT.TTm to 1. TAUJnTT.TTm is a trigger bit, so it is automatically cleared to 0.	TAUJnTE.TEm is cleared to 0 and the counter stops. TAUJnCnTm and TAUJnTTOUTm stop and retain their current values.

(6) Specific timing diagrams

(a) $\text{TAUJnCDRm} = 0000\ 0000_{\text{H}}$, count clock = $\text{PCLK}/2$ Figure 15-23 $\text{TAUJnCDRm} = 0000\ 0000_{\text{H}}$, count clock = $\text{PCLK}/2$

- If $\text{TAUJnCDRm} = 0000\ 0000_{\text{H}}$ and the count clock = $\text{PCLK}/2^1$, the TAUJnCDRm value is written to TAUJnCNTm every count clock, meaning that TAUJnCNTm is always $0000\ 0000_{\text{H}}$.
- INTTAUJnIm is generated every count clock, resulting in TAUJnTTOUTm toggling every count clock.

(b) $\text{TAUJnCDRm} = 0000\ 0000_{\text{H}}$, count clock = PCLK Figure 15-24 $\text{TAUJnCDRm} = 0000\ 0000_{\text{H}}$, count clock = PCLK

- If $\text{TAUJnCDRm} = 0000\ 0000_{\text{H}}$ and the count clock = PCLK , the TAUJnCDRm value is written to TAUJnCNTm every PCLK clock, meaning that TAUJnCNTm is always $0000\ 0000_{\text{H}}$.
- INTTAUJnIm is generated continuously, resulting in TAUJnTTOUTm toggling every PCLK clock.

(c) Operation stop and restart




Figure 15-25 Operation stop and restart, TAUJnCMORm.MD0 = 1

- The counter can be stopped by setting TAUJnTT.TTm to 1, which in turn sets TAUJnTE.TEm to 0.
- TAUJnCNTm and TAUJnTTOUTm stop but retain their values.
- The counter can be restarted by setting TAUJnTS.TSm to 1.

(d) Forced restart




Figure 15-26 Forced restart operation, TAUJnCMORm.MD0 = 1

- The counter can be forcibly restarted (without stopping it first) by setting TAUJnTS.TSm to 1 during operation.
- If the TAUJnCMORm.MD0 bit is set to 1, the first interrupt after a start or restart is generated.

15.14.2 TAUJnTTINm Input Interval Timer Function

(1) Overview

Summary This function is used as a reference timer for generating timer interrupts (INTTAUJnIm) at regular intervals or when a valid TAUJnTTINm input edge is detected. When an interrupt is generated, the TAUJnTTOUTm signal toggles, resulting in a square wave.

- Prerequisites**
- The operation mode must be set to Interval Timer Mode, refer to *Table 15-15 "TAUJnCMORm settings for TAUJnTTINm Input Interval Timer Function" on page 735*
 - The channel output mode must be set to Independent Channel Output Mode 1, refer to *15.8 "Channel Output Modes" on page 711*

Description This function operates in an identical manner to the Interval Timer Function (see *15.14.1 "Interval Timer Function" on page 726*), except that this function is restarted by a valid TAUJnTTINm input edge. The type of edge used as the trigger is specified using the TAUJnCMURm.TIS[1:0] bits. Either rising edge, falling edge, or rising and falling edge can be selected.

(2) Equations

$$\text{INTTAUJnIm cycle} = \text{count clock cycle} \times (\text{TAUJnCDRm} + 1)$$

$$\text{TAUJnTTOUTm square wave cycle} = \text{count clock cycle} \times (\text{TAUJnCDRm} + 1) \times 2$$

(3) Block diagram and general timing diagram




Figure 15-27 Block diagram for TAUJnTTINm Input Interval Timer Function

The following settings apply to the general timing diagram:

- INTTAUJnIm not generated at operation start (TAUJnCMORm.MD0 = 0)
- Rising edge detection (TAUJnCMURm.TIS[1:0] = 01_B)




Figure 15-28 General timing diagram for TAUJnTTINm Input Interval Timer Function

(4) Register settings**(a) TAUJnCMORm**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]		CCS[1:0]		MAS	STS[2:0]		COS[1:0]		-	MD[4:1]				MD0	

Table 15-15 TAUJnCMORm settings for TAUJnTTINm Input Interval Timer Function

Bit name	Setting
CKS[1:0]	00: Operation clock = CK0 01: Operation clock = CK1 10: Operation clock = CK2 11: Operation clock = CK3
CCS[1:0]	00: Operation clock is used as the count clock
MAS	0: Not used, so set to 0
STS[2:0]	001: Valid TAUJnTTINm input edge signal is used as the external start trigger
COS[1:0]	00: Not used, so set to 00
MD[4:1]	0000: Interval Timer Mode
MD0	0: INTTAUJnIm not generated and TAUJnTTOUtm does not toggle at operation start 1: Generates INTTAUJnIm and toggles TAUJnTTOUtm at operation start

(b) TAUJnCMURm

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
														TIS[1:0]	

Table 15-16 TAUJnCMURm settings for TAUJnTTINm Input Interval Timer Function

Bit name	Setting
TIS[1:0]	00: Falling edge detection 01: Rising edge detection 10: Rising and falling edge detection

(c) Channel output mode**Table 15-17 Control bit settings for Independent Channel Output Mode 1**

Bit name	Setting
TOE.TOEm	1: Disables Direct Channel Output Mode
TOM.TOMm	0: Independent channel output
TOC.TOCm	0: Operation mode 1 (= Toggle mode if TAUJnTOM.TOMm = 0)
TOL.TOLm	0: Positive logic

Note The channel output mode can also be set to Direct Channel Output Mode by setting TAUJnTOE.TOEm = 0. TAUJnTTOUTm can then be controlled independently of the interrupts. For details refer to 15.8 “Channel Output Modes” on page 711 .

(d) Simultaneous rewrite

The simultaneous rewrite registers (TAUJnRDE and TAUJnRDM) cannot be used with the TAUJnTTINm Input Interval Timer Function. Therefore, these registers must be set to 0.

Table 15-18 Simultaneous rewrite settings for TAUJnTTINm Input Interval Timer Function

Bit name	Setting
RDE.RDEm	0: Disables simultaneous rewrite
RDM.RDMm	0: When simultaneous rewrite is disabled (TAUJnRDE.RDEm = 0), set these bits to 0

(5) Operating procedure for TAUJnTTINm Input Interval Timer Function

Table 15-19 Operating procedure for TAUJnTTINm Input Interval Timer Function

	Operation	Status of TAUJn
Restart	Initial channel setting Set the TAUJnCMORm register and TAUJnCMURm registers as described in <i>Table 15-15 "TAUJnCMORm settings for TAUJnTTINm Input Interval Timer Function" on page 735</i> and <i>Table 15-16 "TAUJnCMURm settings for TAUJnTTINm Input Interval Timer Function" on page 735</i> Set the value of the TAUJnCDRm register Set the channel output mode by setting the control bits as described in <i>Table 15-17 "Control bit settings for Independent Channel Output Mode 1" on page 736</i>	Channel operation is stopped. (A clock is supplied, and a small amount of power is consumed.)
	Start operation Set TAUJnTS.TSm to 1. TAUJnTS.TSm is a trigger bit, so it is automatically cleared to 0.	TAUJnTE.TEm is set to 1 and the counter starts. TAUJnCnTm loads the TAUJnCDRm value. When TAUJnCMORm.MD0 = 1, INTTAUJnIm is generated and TAUJnTTOUTm toggles.
	During operation The values of the TAUJnCMURm.TIS[1:0] and TAUJnTO.TOm bits and the TAUJnCDRm register can be changed at any time. The TAUJnCnTm register can be read at all times. Detection of TAUJnTTINm edge	TAUJnCnTm counts down. When the counter reaches 0000 0000 _H : <ul style="list-style-type: none"> TAUJnCnTm reloads the TAUJnCDRm value and continues count operation INTTAUJnIm is generated and TAUJnTTOUTm toggles When a TAUJnTTINm input valid edge is detected during count operation, TAUJnCnTm reloads the TAUJnCDRm value and continues count operation. Afterwards, this procedure is repeated.
	Stop operation Set TAUJnTT.TTm to 1. TAUJnTT.TTm is a trigger bit, so it is automatically cleared to 0.	TAUJnTE.TEm is cleared to 0 and the counter stops. TAUJnCnTm and TAUJnTTOUTm stop and retain their current values.

(6) Specific timing diagrams

The timing diagrams in 15.14.1 “Interval Timer Function” on page 726 also apply, except for this function the counter can also be restarted by a valid TAUJnTTINm input edge.




Figure 15-29 Counter triggered by rising TAUJnTTINm input edge
(TAUJnCMURm.TIS[1:0] = 01_B), TAUJnCMORm.MD0 = 1

- If a valid TAUJnTTINm input edge is detected, an interrupt is generated which causes TAUJnTTOUTm to toggle. In this example, the valid edge is a rising edge (TAUJnCMURm.TIS[1:0] = 01_B).

15.15 Independent Channel Signal Measurement Functions

This chapter describes functions that measure the widths of an individual TAUJnTTINm pulse or the total width of successive TAUJnTTINm pulses. It also describes functions that measure the interval of the signal or that compare the width of a pulse with a reference value.

- 15.15.1 *“TAUJnTTINm Input Pulse Interval Measurement Function”*
- 15.15.2 *“TAUJnTTINm Input Signal Width Measurement Function”*
- 15.15.3 *“Overflow Interrupt Output Function (During TAUJnTTINm Width Measurement)”*
- 15.15.4 *“TAUJnTTINm Input Period Count Detection Function”*
- 15.15.5 *“Overflow Interrupt Output Function (During TAUJnTTINm Input Period Count Detection)”*

15.15.1 TAUJnTTINm Input Pulse Interval Measurement Function

(1) Overview

Summary This function captures the count value and uses this value and the overflow bit TAUJnCSRm.OVF to measure the interval of the TAUJnTTINm input signal.

- Prerequisites**
- The operation mode must be set to Capture Mode, refer to *Table 15-21 “TAUJnCMORm settings for TAUJnTTINm Input Pulse Interval Measurement Function”* on page 742
 - TAUJnTTOUTm is not used for this function

Description The counter is started by setting the channel trigger bit (TAUJnTS.TSm) to 1. This in turn sets TAUJnTE.TEm = 1, enabling count operation. The counter TAUJnCNTm starts counting up from 0000 0000_H. When a valid TAUJnTTINm edge is detected, the value of TAUJnCNTm is captured, transferred to TAUJnCDRm, and an interrupt INTTAUJnIm is generated. The counter resets to 0000 0000_H and subsequently continues operation.

If the counter reaches FFFF FFFF_H before a valid TAUJnTTINm edge is detected, it overflows to 0000 0000_H. The counter is reset to 0000 0000_H and subsequently continues operation. The values transferred to TAUJnCDRm and TAUJnCSRm.OVF respectively depend on the values of bits TAUJnCMORm.COS[1:0]:

Table 15-20 Effects of an overflow

TAUJnCMORm.COS[1:0]	When overflow occurs		When a valid TAUJnTTINm input is then detected	
	TAUJnCDRm	TAUJnCSRm.OVF	TAUJnCDRm and TAUJnCNTm	TAUJnCSRm.OVF
00	Unchanged	0	TAUJnCNTm written to TAUJnCDRm	1
01		1		
10	Set to FFFF FFFF _H	0	TAUJnCNTm set to 0, TAUJnCDRm unchanged	0
11		1		

If an overflow is set (TAUJnCSRm.OVF = 1), it can only be cleared by a CPU command that sets TAUJnCSCm.CLOV = 1.

The combination of the value of TAUJnCDRm and TAUJnCSRm.OVF can be used to deduce the interval of the TAUJnTTINm signal. However, if an overflow occurs multiple times before a valid TAUJnTTINm input is detected, the overflow bit TAUJnCSRm.OVF cannot indicate this.

The function can be stopped by setting TAUJnTT.TTm = 1, which in turn sets TAUJnTE.TEm = 0. TAUJnCNTm stops but retains its value. While the function is stopped, TAUJnTTINm input valid edge detection and TAUJnCNTm capture are not performed.

The function can be restarted by setting TAUJnTS.TSm = 1. The counter is reset to 0000 0000_H and subsequently continues operation. The counter can also be forcibly restarted (without stopping it first) by setting TAUJnTS.TSm = 1 during operation.

Conditions If the TAUJnCMORm.MD0 bit is set to 0, the first interrupt after a start or restart is not generated. For details refer to *15.10 “TAUJnTTOUTm Output and INTTAUJnIm Generation when Counter Starts or Restarts”* on page 718.

Note When $\text{TAUJnCMORm.COS}[1:0] = 11_{\text{B}}$, the value of TAUJnCNTm is *not* written to TAUJnCDRm when the first valid TAUJnTTINm input edge occurs after an overflow. However, an interrupt is generated.

(2) Equations

$$\text{TAUJnTTINm input pulse interval} = \text{count clock cycle} \times [(\text{TAUJnCSRm.OVF} \times (\text{FFFF FFFF}_{\text{H}} + 1)) + \text{TAUJnCDRm capture value} + 1]$$

(3) Block diagram and general timing diagram




Figure 15-30 Block diagram for TAUJnTTINm Input Pulse Interval Measurement Function

The following settings apply to the general timing diagram:

- INTTAUJnIm not generated at operation start ($\text{TAUJnCMORm.MD0} = 0$)
- Falling edge detection ($\text{TAUJnCMURm.TIS}[1:0] = 00_{\text{B}}$)
- When a valid TAUJnTTINm input is detected after an overflow TAUJnCDRm is changed and TAUJnCSRm.OVF is set to 1 ($\text{TAUJnCMORm.COS}[1:0] = 00_{\text{B}}$)




Figure 15-31 General timing diagram for TAUJnTTINm Input Pulse Interval Measurement Function

(4) Register settings**(a) TAUJnCMORm**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]		CCS[1:0]		MAS	STS[2:0]		COS[1:0]		-	MD[4:1]				MD0	

Table 15-21 TAUJnCMORm settings for TAUJnTTINm Input Pulse Interval Measurement Function

Bit name	Setting
CKS[1:0]	00: Operation clock = CK0 01: Operation clock = CK1 10: Operation clock = CK2 11: Operation clock = CK3
CCS[1:0]	00: Operation clock is used as the count clock
MAS	0: Not used, so set to 0
STS[2:0]	001: Valid edge of the TAUJnTTINm input signal is the external capture trigger
COS[1:0]	See Table 15-20 "Effects of an overflow" on page 740
MD[4:1]	0010: Capture Mode
MD0	0: INTTAUJnIm not generated at operation start 1: Generates INTTAUJnIm at operation start

(b) TAUJnCMURm

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
														TIS[1:0]	

Table 15-22 TAUJnCMURm settings for TAUJnTTINm Input Pulse Interval Measurement Function

Bit name	Setting
TIS[1:0]	00: Falling edge detection 01: Rising edge detection 10: Rising and falling edge detection (low width measurement) 11: Rising and falling edge detection (high width measurement)

(c) Channel output mode

The channel output mode is not used by this function. However, it can be used in Direct Channel Output Mode.

(d) Simultaneous rewrite

The simultaneous rewrite registers (TAUJnRDE and TAUJnRDM) cannot be used with the TAUJnTTINm Input Pulse Interval Measurement Function. Therefore, these registers must be set to 0.

Table 15-23 Simultaneous rewrite settings for TAUJnTTINm Input Pulse Interval Measurement Function

Bit name	Setting
RDE.RDEm	0: Disables simultaneous rewrite
RDM.RDMm	0: When simultaneous rewrite is disabled (TAUJnRDE.RDEm = 0), set these bits to 0

(5) Operating procedure for TAUJnTTINm Input Pulse Interval Measurement Function

Table 15-24 Operating procedure for TAUJnTTINm Input Pulse Interval Measurement Function

	Operation	Status of TAUJn
Initial channel setting	Set the TAUJnCMORm register and TAUJnCMURm registers as described in Table 15-21 "TAUJnCMORm settings for TAUJnTTINm Input Pulse Interval Measurement Function" on page 742 and Table 15-22 "TAUJnCMURm settings for TAUJnTTINm Input Pulse Interval Measurement Function" on page 742 Set the value of the TAUJnCDRm register	Channel operation is stopped. (A clock is supplied, and a small amount of power is consumed.)
Start operation	Set TAUJnTS.TSm to 1. TAUJnTS.TSm is a trigger bit, so it is automatically cleared to 0.	TAUJnTE.TEm is set to 1 and the counter starts. TAUJnCNTm is cleared to 0000 0000 _H . INTTAUJnIm is generated when TAUJnCMORm.MD0 is set to 1.
During operation	Detection of TAUJnTTINm edges. The TAUJnCMURm.TIS[1:0] bits can be changed at any time. The TAUJnCDRm and TAUJnCSRm registers can be read at any time.	TAUJnCNTm starts to count up from 0000 0000 _H . When a TAUJnTTINm valid edge is detected: <ul style="list-style-type: none"> • TAUJnCNTm transfers (captures) its value to TAUJnCDRm, and returns to 0000 0000_H • INTTAUJnIm is then generated. Afterwards, this procedure is repeated.
Stop operation	Set TAUJnTT.TTm to 1. TAUJnTT.TTm is a trigger bit, so it is automatically cleared to 0.	TAUJnTE.TEm is cleared to 0 and the counter stops. TAUJnCNTm stops and both it and TAUJnCSRm.OVF retain their current values.

Restart

(6) Specific timing diagrams: overflow behavior


(a) $\text{TAUJnCMORm.COS}[1:0] = 00_{\text{B}}$ 

Figure 15-32 $\text{TAUJnCMORm.COS}[1:0] = 00_{\text{B}}$, $\text{TAUJnCMORm.MD0} = 0$,
 $\text{TAUJnCMURm.TIS}[1:0] = 00_{\text{B}}$

- When an overflow occurs, the value of TAUJnCDRm remains unchanged and TAUJnCSRm.OVF remains = 0.
- Upon detection of the next valid TAUJnTTINm input edge, the value of TAUJnCNTm is written to TAUJnCDRm and TAUJnCSRm.OVF is set to 1.


(b) $\text{TAUJnCMORm.COS}[1:0] = 01_{\text{B}}$ 

Figure 15-33 $\text{TAUJnCMORm.COS}[1:0] = 01_{\text{B}}$, $\text{TAUJnCMORm.MD0} = 0$,
 $\text{TAUJnCMURm.TIS}[1:0] = 00_{\text{B}}$

- When an overflow occurs, the value of TAUJnCDRm remains unchanged and TAUJnCSRm.OVF is set to 1.
- Upon detection of the next valid TAUJnTTINm input edge, the value of TAUJnCNTm is written to TAUJnCDRm .
- TAUJnCSRm.OVF is only cleared by a CPU command.


(c) $\text{TAUJnCMORm.COS}[1:0] = 10_{\text{B}}$ 

Figure 15-34 $\text{TAUJnCMORm.COS}[1:0] = 10_{\text{B}}$, $\text{TAUJnCMORm.MD0} = 0$,
 $\text{TAUJnCMURm.TIS}[1:0] = 00_{\text{B}}$

- When an overflow occurs, TAUJnCDRm is set to $\text{FFFF FFFF}_{\text{H}}$ and TAUJnCSRm.OVF remains = 0.
- Upon detection of the next valid TAUJnTTINm input edge, TAUJnCNTm is reset to 0, but TAUJnCDRm and TAUJnCSRm.OVF remain unchanged.
- Thus, the next TAUJnTTINm input valid edge after the overflow is ignored.


(d) $\text{TAUJnCMORm.COS}[1:0] = 11_{\text{B}}$ 

Figure 15-35 $\text{TAUJnCMORm.COS}[1:0] = 11_{\text{B}}$, $\text{TAUJnCMORm.MD0} = 0$,
 $\text{TAUJnCMURm.TIS}[1:0] = 00_{\text{B}}$

- When an overflow occurs, TAUJnCDRm is set to $\text{FFFF FFFF}_{\text{H}}$, and TAUJnCSRm.OVF is set to 1.
- Upon detection of the next valid TAUJnTTINm input edge, TAUJnCNTm is reset to 0, but TAUJnCDRm and TAUJnCSRm.OVF remain unchanged.
- Thus, the next TAUJnTTINm input valid edge after the overflow is ignored.
- TAUJnCSRm.OVF is cleared by a CPU command.

15.15.2 TAUJnTTINm Input Signal Width Measurement Function

(1) Overview

Summary This function measures the width of a TAUJnTTINm input signal.

- Prerequisites**
- The operation mode must be set to Capture & One Count Mode, refer to Table 15-26 “TAUJnCMORm settings for TAUJnTTINm Input Signal Width Measurement Function” on page 749
 - TAUJnTTOUTm is not used for this function
 - TAUJnCMORm.MD0 must be set to 0

Description The counter is started by setting the channel trigger bit (TAUJnTS.TSm) to 1. This in turn sets TAUJnTE.TEm = 1, enabling count operation. When a valid TAUJnTTINm start edge is detected, the counter TAUJnCNTm starts counting up from 0000 0000_H. When a valid TAUJnTTINm stop edge is detected, the value of TAUJnCNTm is captured, transferred to TAUJnCDRm, and an interrupt INTTAUJnIm is generated. The counter retains its value and awaits the next valid TAUJnTTINm input start edge.

If the counter reaches FFFF FFFF_H before a valid TAUJnTTINm stop edge is detected, it overflows. The counter is reset to 0000 0000_H and subsequently continues operation. The values transferred to TAUJnCDRm and TAUJnCSRm.OVF respectively depend on the values of bits TAUJnCMORm.COS[1:0]:

Table 15-25 Effects of an overflow

TAUJnCMORm.COS[1:0]	When overflow occurs		When a valid TAUJnTTINm input stop edge is detected	
	TAUJnCDRm	TAUJnCSRm.OVF	TAUJnCDRm and TAUJnCNTm	TAUJnCSRm.OVF
00	Unchanged	0	TAUJnCNTm written to TAUJnCDRm	1
01		1		
10	Set to FFFF FFFF _H	0	TAUJnCNTm stops counting TAUJnCDRm unchanged	0
11		1		

If an overflow is set (TAUJnCSRm.OVF = 1), it can only be cleared by a CPU command that sets TAUJnCSCm.CLOV = 1.

The combination of the value of TAUJnCDRm and TAUJnCSRm.OVF can be used to deduce the width of the TAUJnTTINm signal. However, if an overflow occurs multiple times before a valid TAUJnTTINm input is detected, the overflow bit TAUJnCSRm.OVF cannot indicate this.

This function cannot be forcibly restarted.

Note When TAUJnCMORm.COS[1:0] = 11_B, the value of TAUJnCNTm is *not* written to TAUJnCDRm when the first valid TAUJnTTINm input edge occurs after an overflow. However, an interrupt is generated.

(2) Equations

TAUJnTTINm input signal width = count clock cycle x [(TAUJnCSRm.OVF x (FFFF FFFF_H + 1)) + TAUJnCDRm capture value + 1]

(3) Block diagram and general timing diagram




Figure 15-36 Block diagram for TAUJnTTINm Input Signal Width Measurement Function

The following settings apply to the general timing diagram:

- Rising and falling edge detection = high width measurement (TAUJnCMURm.TIS[1:0] = 11_B)
- When a valid TAUJnTTINm input is detected after an overflow TAUJnCDRm is changed and TAUJnCSRm.OVF is set to 1 (TAUJnCMORm.COS[1:0] = 00_B)




Figure 15-37 General timing diagram for TAUJnTTINm Input Signal Width Measurement Function

(4) Register settings**(a) TAUJnCMORm**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	CCS[1:0]	MAS	STS[2:0]		COS[1:0]		-	MD[4:1]				MD0			

Table 15-26 TAUJnCMORm settings for TAUJnTTINm Input Signal Width Measurement Function

Bit name	Setting
CKS[1:0]	00: Operation clock = CK0 01: Operation clock = CK1 10: Operation clock = CK2 11: Operation clock = CK3
CCS[1:0]	00: Operation clock is used as the count clock
MAS	0: Not used, so set to 0
STS[2:0]	010: Valid edge of the TAUJnTTINm input signal is the external start trigger and the reverse edge is the stop trigger
COS[1:0]	See Table 15-25 "Effects of an overflow" on page 747
MD[4:1]	0110: Capture & One Count Mode
MD0	0: INTTAUJnIm not generated at operation start

(b) TAUJnCMURm

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
-														TIS[1:0]	

Table 15-27 TAUJnCMURm settings for TAUJnTTINm Input Signal Width Measurement Function

Bit name	Setting
TIS[1:0]	10: Rising and falling edge detection (low width measurement) 11: Rising and falling edge detection (high width measurement)

(c) Channel output mode

The channel output mode is not used by this function. However, it can be used in Direct Channel Output Mode.

(d) Simultaneous rewrite

The simultaneous rewrite registers (TAUJnRDE and TAUJnRDM) cannot be used with the TAUJnTTINm Input Signal Width Measurement Function. Therefore, these registers must be set to 0.

Table 15-28 Simultaneous rewrite settings for TAUJnTTINm Input Signal Width Measurement Function

Bit name	Setting
RDE.RDEm	0: Disables simultaneous rewrite
RDM.RDMm	0: When simultaneous rewrite is disabled (TAUJnRDE.RDEm = 0), set these bits to 0

(5) Operating procedure for TAUJnTTINm Input Signal Width Measurement Function

Table 15-29 Operating procedure for TAUJnTTINm Input Signal Width Measurement Function

	Operation	Status of TAUJn
Initial channel setting	Set the TAUJnCMORm register and TAUJnCMURm registers as described in Table 15-21 "TAUJnCMORm settings for TAUJnTTINm Input Pulse Interval Measurement Function" on page 742 and Table 15-22 "TAUJnCMURm settings for TAUJnTTINm Input Pulse Interval Measurement Function" on page 742 Set the value of the TAUJnCDRm register	Channel operation is stopped. (A clock is supplied, and a small amount of power is consumed.)
Start operation	Set TAUJnTS.TSm to 1. TAUJnTS.TSm is a trigger bit, so it is automatically cleared to 0.	TAUJnTE.TEm is set to 1 and TAUJnCNTm waits for detection of the TAUJnTTINm start edge. When a TAUJnTTINm start is detected, TAUJnCNTm starts to count up.
During operation	Detection of TAUJnTTINm edges. The TAUJnCMURm.TIS[1:0] bits can be changed at any time. The TAUJnCDRm and TAUJnCSRm registers can be read at any time.	TAUJnCNTm starts to count up from 0000 0000 _H . When a TAUJnTTINm valid edge is detected: <ul style="list-style-type: none"> • TAUJnCNTm transfers (captures) its value to TAUJnCDRm, and retains its value • INTTAUJnIm is then generated. Afterwards, this procedure is repeated.
Stop operation	Set TAUJnTT.TTm to 1. TAUJnTT.TTm is a trigger bit, so it is automatically cleared to 0.	TAUJnTE.TEm is cleared to 0 and the counter stops. TAUJnCNTm stops and both it and TAUJnCSRm.OVF retain their current values.

Restart

(6) Specific timing diagrams: overflow behavior


(a) $\text{TAUJnCMORm.COS}[1:0] = 00_{\text{B}}$ 

Figure 15-38 $\text{TAUJnCMORm.COS}[1:0] = 00_{\text{B}}$, $\text{TAUJnCMORm.MD0} = 0$,
 $\text{TAUJnCMURm.TIS}[1:0] = 11_{\text{B}}$

- When an overflow occurs, the value of TAUJnCDRm remains unchanged and TAUJnCSRm.OVF remains = 0.
- Upon detection of the next valid TAUJnTTINm input edge, the value of TAUJnCNTm is written to TAUJnCDRm and TAUJnCSRm.OVF is set to 1.


(b) $\text{TAUJnCMORm.COS}[1:0] = 01_{\text{B}}$ 

Figure 15-39 $\text{TAUJnCMORm.COS}[1:0] = 01_{\text{B}}$, $\text{TAUJnCMORm.MD0} = 0$,
 $\text{TAUJnCMURm.TIS}[1:0] = 11_{\text{B}}$

- When an overflow occurs, the value of TAUJnCDRm remains unchanged and TAUJnCSRm.OVF is set to 1.
- Upon detection of the next valid TAUJnTTINm input edge, the value of TAUJnCNTm is written to TAUJnCDRm .
- TAUJnCSRm.OVF is only cleared by a CPU command.


(c) $\text{TAUJnCMORm.COS}[1:0] = 10_{\text{B}}$ 

Figure 15-40 $\text{TAUJnCMORm.COS}[1:0] = 10_{\text{B}}$, $\text{TAUJnCMORm.MD0} = 0$,
 $\text{TAUJnCMURm.TIS}[1:0] = 11_{\text{B}}$

- When an overflow occurs, TAUJnCDRm is set to $\text{FFFF FFFF}_{\text{H}}$ and TAUJnCSRm.OVF remains = 0.
- Upon detection of the next valid TAUJnTTINm input edge, TAUJnCNTm is reset to 0, but TAUJnCDRm and TAUJnCSRm.OVF remain unchanged.
- Thus, the next TAUJnTTINm input valid edge after the overflow is ignored.


(d) $\text{TAUJnCMORm.COS}[1:0] = 11_{\text{B}}$ 

Figure 15-41 $\text{TAUJnCMORm.COS}[1:0] = 11_{\text{B}}$, $\text{TAUJnCMORm.MD0} = 0$,
 $\text{TAUJnCMURm.TIS}[1:0] = 11_{\text{B}}$

- When an overflow occurs, TAUJnCDRm is set to $\text{FFFF FFFF}_{\text{H}}$, and TAUJnCSRm.OVF is set to 1.
- Upon detection of the next valid TAUJnTTINm input edge, TAUJnCNTm is reset to 0, but TAUJnCDRm and TAUJnCSRm.OVF remain unchanged.
- Thus, the next TAUJnTTINm input valid edge after the overflow is ignored.
- TAUJnCSRm.OVF is cleared by a CPU command.

15.15.3 Overflow Interrupt Output Function (During TAUJnTTINm Width Measurement)

(1) Overview

- Summary** This function measures the width of an individual TAUJnTTINm input signal. An interrupt is generated if the TAUJnTTINm input width is longer than FFFF FFFF_H.
- Prerequisites**
- The operation mode must be set to One Count Mode, refer to *Table 15-30 “TAUJnCMORm settings for Overflow Interrupt Output Function (During TAUJnTTINm Width Measurement)” on page 756*
 - TAUJnTTOUTm is not used for this function
 - The value of TAUJnCDRm must be set to FFFF FFFF_H.
- Description** The counter is enabled by setting the channel trigger bit (TAUJnTS.TSm) to 1. This in turn sets TAUJnTE.TEm = 1, enabling count operation.
- The counter starts when a valid TAUJnTTINm input start edge is detected. FFFF FFFF_H is written to TAUJnCNTm and the counter starts to count down.
- When a valid stop edge is detected, the counter stops and retains the current value.
- When the next TAUJnTTINm input start edge is detected, TAUJnCNTm reloads FFFF FFFF_H and starts to count down.
- If the counter reaches 0000 0000_H before a stop edge is detected, an interrupt is generated.
- Conditions** The valid start and stop edges are specified by the TAUJnCMURm.TIS[1:0] bits:
- If TAUJnCMURm.TIS[1:0] = 10_B, the TAUJnTTINm input low width is measured. The start trigger is a falling edge and the stop trigger is a rising edge.
 - If TAUJnCMURm.TIS[1:0] = 11_B, the TAUJnTTINm input high width is measured. The start trigger is a rising edge and the stop trigger is a falling edge.
- Note** The counter cannot be restarted during operation.

(2) Block diagram and general timing diagram




Figure 15-42 Block diagram for Overflow Interrupt Output Function (During TAUJnTTINm Width Measurement)

The following settings apply to the general timing diagram:

- Rising and falling edge detection = high width measurement (TAUJnCMURm.TIS[1:0] = 11_B)




Figure 15-43 General timing diagram for Overflow Interrupt Output Function (During TAUJnTTINm Width Measurement)

(3) Register settings**(a) TAUJnCMORm**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	CCS[1:0]	MAS	STS[2:0]		COS[1:0]		-	MD[4:1]				MD0			

Table 15-30 TAUJnCMORm settings for Overflow Interrupt Output Function (During TAUJnTTINm Width Measurement)

Bit name	Setting
CKS[1:0]	00: Operation clock = CK0 01: Operation clock = CK1 10: Operation clock = CK2 11: Operation clock = CK3
CCS[1:0]	00: Operation clock is used as the count clock
MAS	0: Not used, so set to 0
STS[2:0]	010: Valid edge of the TAUJnTTINm input signal is the external start trigger and the reverse edge is the stop trigger
COS[1:0]	00: Not used, so set to 00
MD[4:1]	0100: One Count Mode
MD0	0: INTTAUJnIm not generated at operation start

(b) TAUJnCMURm

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
-														TIS[1:0]	

Table 15-31 TAUJnCMURm settings Overflow Interrupt Output Function (During TAUJnTTINm Width Measurement)

Bit name	Setting
TIS[1:0]	10: Rising and falling edge detection (Low width measurement) 11: Rising and falling edge detection (High width measurement)

(c) Channel output mode

The channel output mode is not used by this function. However, it can be used in Direct Channel Output Mode.

(d) Simultaneous rewrite

The simultaneous rewrite registers (TAUJnRDE and TAUJnRDM) cannot be used with the Overflow Interrupt Output Function (During TAUJnTTINm Width Measurement). Therefore, these registers must be set to 0.

Table 15-32 Simultaneous rewrite settings for Overflow Interrupt Output Function (During TAUJnTTINm Width Measurement)

Bit name	Setting
RDE.RDEm	0: Disables simultaneous rewrite
RDM.RDMm	0: When simultaneous rewrite is disabled (TAUJnRDE.RDEm = 0), set these bits to 0

(4) Operating procedure for Overflow Interrupt Output Function
(During TAUJnTTINm Width Measurement)

Table 15-33 Operating procedure for Overflow Interrupt Output Function (During TAUJnTTINm Width Measurement)

	Operation	Status of TAUJn
Restart	Initial channel setting Set the TAUJnCMORm register and TAUJnCMURm registers as described in Table 15-30 "TAUJnCMORm settings for Overflow Interrupt Output Function (During TAUJnTTINm Width Measurement)" on page 756 and Table 15-31 "TAUJnCMURm settings Overflow Interrupt Output Function (During TAUJnTTINm Width Measurement)" on page 756 Set the value of the TAUJnCDRm register	Channel operation is stopped. (A clock is supplied, and a small amount of power is consumed.)
	Start operation Set TAUJnTS.TSm to 1. TAUJnTS.TSm is a trigger bit, so it is automatically cleared to 0. Detection of TAUJnTTINm start edge	TAUJnTE.TEm is set to 1 and TAUJnCNTm waits for detection of the start edge. When a start edge is detected, TAUJnCNTm loads the TAUJnCDRm value (FFFF FFFF _H).
	During operation The TAUJnCNTm register can be read at any time. Detection of TAUJnTTINm edges.	TAUJnCNTm counts down. When the counter reaches 0000 0000 _H : <ul style="list-style-type: none"> • INTTAUJnIm is generated • TAUJnCNTm stops counting at FFFF FFFF_H and waits for a trigger. When a reverse edge of TAUJnTTINm is detected during count operation: <ul style="list-style-type: none"> • TAUJnCNTm stops counting and waits for a trigger. Afterwards, this procedure is repeated.
	Stop operation Set TAUJnTT.TTm to 1. TAUJnTT.TTm is a trigger bit, so it is automatically cleared to 0.	TAUJnTE.TEm is cleared to 0 and the counter stops. TAUJnCNTm stops and retains its current value.

15.15.4 TAUJnTTINm Input Period Count Detection Function

(1) Overview

Summary This function measures the cumulative width of a TAUJnTTINm input signal.

- Prerequisites**
- The operation mode must be set to Capture & Gate Count Mode, refer to *Table 15-34 "TAUJnCMORm settings for TAUJnTTINm Input Period Count Detection Function" on page 761*
 - TAUJnTTOUm is not used for this function

Description The counter is enabled by setting the channel trigger bit (TAUJnTS.TSm) to 1. This in turn sets TAUJnTE.TEm = 1, enabling count operation. The counter awaits a valid TAUJnTTINm input edge.

When a valid TAUJnTTINm input start edge is detected, the counter starts to count from 0000 0000_H.

When a valid TAUJnTTINm input stop edge is detected, the current TAUJnCNTm value is written to TAUJnCDRm and an interrupt (INTTAUJnIm) is generated. The counter stops and retains its value until the next valid TAUJnTTINm input start edge is detected.

If the counter reaches FFFF FFFF_H the bit TAUJnCSRm.OVF is set to 1 and the counter restarts from 0000 0000_H. The value of TAUJnCSRm.OVF is reset by the CPU by setting TAUJnCSCm.CLOV = 1.

Note The input TAUJnTTINm is sampled at the frequency of the operation clock, specified by the TAUJnCMORm.CKS[1:0] bits. As a result, the output cycle of TAUJnTTOUm has an error of ± 1 operation clock cycle.

- Conditions** The valid start and stop edges are specified by the TAUJnCMURm.TIS[1:0] bits:
- If TAUJnCMURm.TIS[1:0] = 10_B, the TAUJnTTINm input low width is measured. The start trigger is a falling edge and the stop trigger is a rising edge.
 - If TAUJnCMURm.TIS[1:0] = 11_B, the TAUJnTTINm input high width is measured. The start trigger is a rising edge and the stop trigger is a falling edge.

(2) Equations

Cumulative TAUJnTTINm input width =
 count clock cycle × ((FFFF FFFF_H × TAUJnCSRm.OVF) + (TAUJnCDRm
 capture value + 1))

(3) Block diagram and general timing diagram




Figure 15-44 Block diagram for TAUJnTTINm Input Period Count Detection Function

The following settings apply to the general timing diagram:

- Rising and falling edge detection = high width measurement (TAUJnCMURm.TIS[1:0] = 11B)




Figure 15-45 General timing diagram for TAUJnTTINm Input Period Count Detection Function

(4) Register settings**(a) TAUJnCMORm**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]		CCS[1:0]		MAS	STS[2:0]		COS[1:0]		-	MD[4:1]				MDO	

Table 15-34 TAUJnCMORm settings for TAUJnTTINm Input Period Count Detection Function

Bit name	Setting
CKS[1:0]	00: Operation clock = CK0 01: Operation clock = CK1 10: Operation clock = CK2 11: Operation clock = CK3
CCS[1:0]	00: Operation clock is used as the count clock
MAS	0: Not used, so set to 0
STS[2:0]	010: Valid edge of the TAUJnTTINm input signal is the external start trigger and the reverse edge is the stop trigger
COS[1:0]	01: Overflow (TAUJnCSRm.OVF) set upon counter overflow and cleared by a CPU instruction
MD[4:1]	1101: Capture & Gate Count Mode
MDO	0: INTTAUJnIm not generated at operation start

(b) TAUJnCMURm

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
														TIS[1:0]	

Table 15-35 TAUJnCMURm settings for TAUJnTTINm Input Period Count Detection Function

Bit name	Setting
TIS[1:0]	10: Rising and falling edge detection (Low width measurement) 11: Rising and falling edge detection (High width measurement)

(c) Channel output mode

The channel output mode is not used by this function. However, it can be used in Direct Channel Output Mode.

(d) Simultaneous rewrite

The simultaneous rewrite registers (TAUJnRDE and TAUJnRDM) cannot be used with the TAUJnTTINm Input Period Count Detection Function. Therefore, these registers must be set to 0.

Table 15-36 Simultaneous rewrite settings for TAUJnTTINm Input Period Count Detection Function

Bit name	Setting
RDE.RDEm	0: Disables simultaneous rewrite
RDM.RDMm	0: When simultaneous rewrite is disabled (TAUJnRDE.RDEm = 0), set these bits to 0

(5) Operating procedure for TAUJnTTINm Input Period Count Detection Function

Table 15-37 Operating procedure for TAUJnTTINm Input Period Count Detection Function

	Operation	Status of TAUJn
Initial channel setting	Set the TAUJnCMORm register and TAUJnCMURm registers as described in Table 15-34 "TAUJnCMORm settings for TAUJnTTINm Input Period Count Detection Function" on page 761 and Table 15-35 "TAUJnCMURm settings for TAUJnTTINm Input Period Count Detection Function" on page 761	Channel operation is stopped. (A clock is supplied, and a small amount of power is consumed.)
	Set the value of the TAUJnCDRm register	
Start operation	Set TAUJnTS.TSm to 1. TAUJnTS.TSm is a trigger bit, so it is automatically cleared to 0.	TAUJnTE.TEm is set to 1 and TAUJnCNTm waits for detection of the TAUJnTTINm start edge.
	Detection of TAUJnTTINm start edge	When a start edge is detected, TAUJnCNTm is cleared to 0000 0000 _H and TAUJnCNTm starts to count up.
During operation	Detection of TAUJnTTINm edges. The TAUJnCDRm, TAUJnCNTm, and TAUJnCSRm registers can be read at any time. The TAUJnCSC.CLOV bit can be set to 1.	When a TAUJnTTINm start edge (rising edge for high width measurement, falling edge for low width measurement) is detected, TAUJnCNTm starts to count up from the stop value. When TAUJnCNTm detects a capture edge (falling edge for high width measurement, rising edge for low width measurement), it transfers the value to TAUJnCDRm and INTTAUJnIm is generated. Counting stops at the "value transferred to TAUJnCDRm + 1" value and TAUJnCNTm waits for detection of the TAUJnTTINm start edge. If the TAUJnCNTm reaches FFFF FFFF _H , the counter overflows and TAUJnCSR.OVF is set to 1. Afterwards, this procedure is repeated.
Stop operation	Set TAUJnTT.TTm to 1. TAUJnTT.TTm is a trigger bit, so it is automatically cleared to 0.	TAUJnTE.TEm is cleared to 0 and the counter stops. TAUJnCNTm stops and it and TAUJnCSRm.OVF retain their current values.

Restart

(6) Specific timing diagrams

(a) Operation stop and restart




Figure 15-46 Operation stop and restart, TAUJnCMURm.TIS[1:0] = 11_B

- The counter can be stopped by setting TAUJnTT.TTm to 1, which in turn sets TAUJnTE.TEm to 0.
- TAUJnCNTm stops and the current value is retained.
- If the counter is stopped, valid TAUJnTTINm input edges are ignored.
- The counter can be restarted by setting TAUJnTS.TSm to 1. TAUJnCNTm restarts to count from 0000 0000_H.

15.15.5 Overflow Interrupt Output Function (During TAUJnTTINm Input Period Count Detection)

(1) Overview

- Summary** This function measures the cumulative width of a TAUJnTTINm input signal. An interrupt is generated if the cumulative TAUJnTTINm input width is longer than FFFF FFFF_H.
- Prerequisites**
- The operation mode must be set to Gate Count Mode, refer to *Table 15-38 “TAUJnCMORm settings for Overflow Interrupt Output Function (During TAUJnTTINm Input Period Count Detection)” on page 767*
 - TAUJnTTOUTm is not used for this function
 - The value of TAUJnCDRm must be set to FFFF FFFF_H.
- Description** The counter is enabled by setting the channel trigger bit (TAUJnTS.TSm) to 1. This in turn sets TAUJnTE.TEm = 1, enabling count operation.
- The counter starts when a valid TAUJnTTINm input start edge is detected. FFFF FFFF_H is written to TAUJnCNTm and the counter starts to count down.
- When a valid stop edge is detected, the counter stops and retains the current value. The counter awaits the next TAUJnTTINm input start edge and then continues to count down from the current value.
- When the counter reaches 0000 0000_H an interrupt is generated. FFFF FFFF_H is written to TAUJnCNTm and the counter continues to count down until a TAUJnTTINm input stop edge is detected.
- Conditions** The valid start and stop edges are specified by the TAUJnCMURm.TIS[1:0] bits:
- If TAUJnCMURm.TIS[1:0] = 10_B, the TAUJnTTINm input low width is measured. The start trigger is a falling edge and the stop trigger is a rising edge.
 - If TAUJnCMURm.TIS[1:0] = 11_B, the TAUJnTTINm input high width is measured. The start trigger is a rising edge and the stop trigger is a falling edge.
- Note** The counter cannot be restarted during operation.

(2) Block diagram and general timing diagram




Figure 15-47 Block diagram for Overflow Interrupt Output Function (During TAUJnTTINm Input Period Count Detection)

The following settings apply to the general timing diagram:

- Rising and falling edge detection = high width measurement (TAUJnCMURm.TIS[1:0] = 11_B)




Figure 15-48 General timing diagram for Overflow Interrupt Output Function (During TAUJnTTINm Input Period Count Detection)

(3) Register settings**(a) TAUJnCMORm**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	CCS[1:0]	MAS	STS[2:0]		COS[1:0]		-	MD[4:1]				MD0			

Table 15-38 TAUJnCMORm settings for Overflow Interrupt Output Function (During TAUJnTTINm Input Period Count Detection)

Bit name	Setting
CKS[1:0]	00: Operation clock = CK0 01: Operation clock = CK1 10: Operation clock = CK2 11: Operation clock = CK3
CCS[1:0]	00: Operation clock is used as the count clock
MAS	0: Not used, so set to 0
STS[2:0]	010: Valid edge of the TAUJnTTINm input signal is the external start trigger and the reverse edge is the stop trigger
COS[1:0]	00: Not used, so set to 00
MD[4:1]	1100: Gate Count Mode
MD0	0: INTTAUJnIm not generated at operation start

(b) TAUJnCMURm

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
-														TIS[1:0]	

Table 15-39 TAUJnCMURm settings for Overflow Interrupt Output Function (During TAUJnTTINm Input Period Count Detection)

Bit name	Setting
TIS[1:0]	10: Rising and falling edge detection (Low width measurement) 11: Rising and falling edge detection (High width measurement)

(c) Channel output mode

The channel output mode is not used by this function. However, it can be used in Direct Channel Output Mode.

(d) Simultaneous rewrite

The simultaneous rewrite registers (TAUJnRDE and TAUJnRDM) cannot be used with the Overflow Interrupt Output Function (During TAUJnTTINm Input Period Count Detection). Therefore, these registers must be set to 0.

Table 15-40 Simultaneous rewrite settings for Overflow Interrupt Output Function (During TAUJnTTINm Input Period Count Detection)

Bit name	Setting
RDE.RDEm	0: Disables simultaneous rewrite
RDM.RDMm	0: When simultaneous rewrite is disabled (TAUJnRDE.RDEm = 0), set these bits to 0

(4) Operating procedure for Overflow Interrupt Output Function
(during TAUJnTTINm input period count detection)

Table 15-41 Operating procedure for Overflow Interrupt Output Function
(during TAUJnTTINm input period count detection)

	Operation	Status of TAUJn
Initial channel setting	Set the TAUJnCMORm register and TAUJnCMURm registers as described in Table 15-38 "TAUJnCMORm settings for Overflow Interrupt Output Function (During TAUJnTTINm Input Period Count Detection)" on page 767 and Table 15-39 "TAUJnCMURm settings for Overflow Interrupt Output Function (During TAUJnTTINm Input Period Count Detection)" on page 767 Set the value of the TAUJnCDRm register	Channel operation is stopped. (A clock is supplied, and a small amount of power is consumed.)
Start operation	Set TAUJnTS.TSm to 1. TAUJnTS.TSm is a trigger bit, so it is automatically cleared to 0. Detection of TAUJnTTINm start edge	TAUJnTE.TEm is set to 1 and TAUJnCNTm waits for detection of the start edge. When a start edge is detected, TAUJnCNTm loads the TAUJnCDRm value (FFFF FFFF _H).
During operation	The TAUJnCNTm register can be read at all times.	TAUJnCNTm counts down. When the counter reaches 0000 0000 _H : <ul style="list-style-type: none"> • INTTAUJnIm is generated • TAUJnCNTm loads the TAUJnCDRm value (FFFF FFFF_H) and continues to count down. When a reverse edge of TAUJnTTINm is detected during count operation: <ul style="list-style-type: none"> • TAUJnCNTm counts down from the stop value. Afterwards, this procedure is repeated.
Stop operation	Set TAUJnTT.TTm to 1. TAUJnTT.TTm is a trigger bit, so it is automatically cleared to 0.	TAUJnTE.TEm is cleared to 0 and the counter stops. TAUJnCNTm stops and retains its current value.

Restart

15.16 Other Independent Channel Functions

This chapter describes a function that generates an interrupt when a certain number of TAUJnTTINm pulses has occurred, a function that divides the frequency of TAUJnTTINm, and a function that measures the duration between the function start and a TAUJnTTINm input signal:

- 15.16.1 *“TAUJnTTINm Input Position Detection Function”*

15.16.1 TAUJnTTINm Input Position Detection Function

(1) Overview

Summary This function measures the duration between the function start and a TAUJnTTINm input signal.

- Prerequisites**
- The operation mode must be set to Count Capture Mode, refer to *Table 15-42 "TAUJnCMORm settings for TAUJnTTINm Input Position Detection Function" on page 773*
 - TAUJnTTOUm is not used for this function

Description The counter is enabled by setting the channel trigger bit (TAUJnTS.TSm) to 1. This in turn sets TAUJnTE.TEm = 1, enabling count operation. The counter starts to count from 0000 0000_H. When a valid TAUJnTTINm input stop edge is detected, the current TAUJnCNTm value is written to TAUJnCDRm and an interrupt (INTTAUJnIm) is generated. The counter continues to count from the current value until the next valid TAUJnTTINm input edge is detected.

When the counter reaches FFFF FFFF_H, the bit TAUJnCSRm.OVF is set to 1 and the counter restarts from 0000 0000_H. The value of TAUJnCSRm.OVF is reset by the CPU by TAUJnCSCm.CLOV = 1.

Note The input TAUJnTTINm is sampled at the frequency of the operation clock, specified by the TAUJnCMORm.CKS[1:0] bits. As a result, the output cycle of TAUJnTTOUm has an error of ± 1 operation clock cycle.

Conditions If the TAUJnCMORm.MD0 bit is set to 0, the first interrupt after a start or restart is not generated. For details refer to *15.10 "TAUJnTTOUm Output and INTTAUJnIm Generation when Counter Starts or Restarts" on page 718*.

(2) Equations

Function duration at a TAUJnTTINm input pulse =

count clock cycle × [(FFFF FFFF_H+1 × TAUJnCSRm.OVF) + (TAUJnCDRm capture value + 1)]

(3) Block diagram and general timing diagram




Figure 15-49 Block diagram for TAUJnTTINm Input Position Detection Function

The following settings apply to the general timing diagram:

- INTTAUJnIm not generated at operation start (TAUJnCMORm.MD0 = 0)
- Falling edge detection (TAUJnCMURm.TIS[1:0] = 00_B)




Figure 15-50 General timing diagram for TAUJnTTINm Input Position Detection Function

(4) Register settings**(a) TAUJnCMORm**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]		CCS[1:0]		MAS	STS[2:0]		COS[1:0]		-	MD[4:1]				MD0	

Table 15-42 TAUJnCMORm settings for TAUJnTTINm Input Position Detection Function

Bit name	Setting
CKS[1:0]	00: Operation clock = CK0 01: Operation clock = CK1 10: Operation clock = CK2 11: Operation clock = CK3
CCS[1:0]	00: Operation clock is used as the count clock
MAS	0: Not used, so set to 0
STS[2:0]	001: Valid TAUJnTTINm input edge signal is used as the external capture trigger
COS[1:0]	01: Overflow (TAUJnCSRm.OVF) set upon counter overflow and cleared by a CPU instruction
MD[4:1]	1011: Count Capture Mode
MD0	0: INTTAUJnIm not generated at operation start 1: Generates INTTAUJnIm at operation start

(b) TAUJnCMURm

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
														TIS[1:0]	

Table 15-43 TAUJnCMURm settings for TAUJnTTINm Input Position Detection Function

Bit name	Setting
TIS[1:0]	00: Falling edge detection 01: Rising edge detection 10: Rising and falling edge detection

(c) Channel output mode

The channel output mode is not used by this function. However, it can be used in Direct Channel Output Mode.

(d) Simultaneous rewrite

The simultaneous rewrite registers (TAUJnRDE and TAUJnRDM) cannot be used with the TAUJnTTINm Input Position Detection Function. Therefore, these registers must be set to 0.

Table 15-44 Simultaneous rewrite settings for TAUJnTTINm Input Position Detection Function

Bit name	Setting
RDE.RDEm	0: Disables simultaneous rewrite
RDM.RDMm	0: When simultaneous rewrite is disabled (TAUJnRDE.RDEm = 0), set these bits to 0

(5) Operating procedure for TAUJnTTINm Input Position Detection Function

Table 15-45 Operating procedure for TAUJnTTINm Input Position Detection Function

	Operation	Status of TAUJn
Restart	Initial channel setting Set the TAUJnCMORm register and TAUJnCMURm registers as described in <i>Table 15-42 "TAUJnCMORm settings for TAUJnTTINm Input Position Detection Function" on page 773</i> and <i>Table 15-43 "TAUJnCMURm settings for TAUJnTTINm Input Position Detection Function" on page 773</i> Set the value of the TAUJnCDRm register	Channel operation is stopped. (A clock is supplied, and a small amount of power is consumed.)
	Start operation Set TAUJnTS.TSm to 1. TAUJnTS.TSm is a trigger bit, so it is automatically cleared to 0.	TAUJnTE.TEm is set to 1 and the counter starts. INTTAUJnIm is generated when TAUJnCMORm.MD0 is set to 1.
	During operation The TAUJnCMURm.TIS[1:0] bits can be changed at any time. The TAUJnCDRm and TAUJnCSRm registers can be read at any time.	TAUJnCNTm starts to count up from 0000 0000 _H . When a TAUJnTTINm valid edge is detected: <ul style="list-style-type: none"> • TAUJnCNTm transfers (captures) its value to TAUJnCDRm • TAUJnTTINm is output. • The counter value is not cleared to 0000 0000_H and TAUJnCNTm continues count operation. Afterwards, this procedure is repeated.
	Stop operation Set TAUJnTT.TTm to 1. TAUJnTT.TTm is a trigger bit, so it is automatically cleared to 0.	TAUJnTE.TEm is cleared to 0 and the counter stops. TAUJnCNTm stops and both it and TAUJnCSRm.OVF retain their current values.

(6) Specific timing diagrams

(a) Operation stop and restart




Figure 15-51 Operation stop and restart, TAUJnCMORM.MD0 = 0, TAUJnCMURm.TIS[1:0] = 00

- The counter can be stopped by setting TAUJnTT.TTm to 1, which in turn sets TAUJnTE.TEm to 0.
- TAUJnCNTm stops and the current value is retained.
- If the counter is stopped, valid TAUJnTTINm input edges are ignored.
- The counter can be restarted by setting TAUJnTS.TSm to 1. TAUJnCNTm restarts to count from 0000 0000_H.

15.17 Synchronous PWM Signal Functions Triggered at Regular Intervals

This chapter describes a function that generates PWM signals at regular intervals. For a general overview of synchronous channel operation, see 15.3 “*Functional Description*” on page 699 .

- 15.17.1 “*PWM Output Function*”

15.17.1 PWM Output Function

(1) Overview

- Summary** This function generates multiple PWM outputs by using a master and multiple slave channels. It enables the pulse cycle (frequency) and the pulse width (duration) of the TAUJnTTOUTm to be set. The pulse cycle is set in the master channel. The pulse width is set in the slave channel.
- Prerequisites**
- Two channels
 - The operation mode of the master channel must be set to Interval Timer Mode, refer to *Table 15-46 “TAUJnCMORm settings for the master channel of the PWM Output Function” on page 781*
 - The operation mode of the slave channel(s) must be set to One Count Mode, refer to *Table 15-49 “TAUJnCMORm settings for the slave channel of the PWM Output Function” on page 783*
 - TAUJnTTOUTm is not used for the master channel of this function
 - The channel output mode of the slave channel(s) must be set to Synchronous Channel Output Mode 1 (*15.8 “Channel Output Modes” on page 711*)
- Description** The counters are started by setting the channel trigger bits (TAUJnTS.TSm) to 1. This in turn sets TAUJnTE.TEm = 1, enabling count operation. The current value of TAUJnCDRm is written to TAUJnCNTm and the counters start to count down from these values. INTTAUJnIm is generated on the master channel and TAUJnTTOUTm (slave) toggles.
- Master channel:

When the counter of the master channel reaches 0000 0000_H, pulse cycle time has elapsed and INTTAUJnIm is generated. The counter reloads the TAUJnCDRm value and counts down.
 - Slave channel(s)

The INTTAUJnIm of the master channel triggers the counter of the slave channel(s). The current value of TAUJnCDRm (slave) is written to TAUJnCNTm (slave) and the counter starts to count down from this value. The TAUJnTTOUTm signal is set.

When the counter reaches 0000 0000_H, i.e. duty time has elapsed, INTTAUJnIm is generated and the TAUJnTTOUTm signal is reset. The counter returns to FFFF FFFF_H and awaits the next INTTAUJnIm of the master channel, and thus the start of the next pulse cycle.

The counter can be stopped by setting TAUJnTT.TTm to 1 for the master and slave channel(s), which in turn sets TAUJnTE.TEm to 0. TAUJnCNTm and TAUJnTTOUTm of master and slave channel(s) stop but retain their values. The counters can be restarted by setting TAUJnTS.TSm to 1.
- Note** If a forced restart is executed during operation, TAUJnTTOUTm is not output as a PWM signal.
- Conditions** Simultaneous rewrite can be used with this function. Please refer to *15.7 “Simultaneous Rewrite” on page 706*

(2) Equations

Pulse cycle = (TAUJnCDRm (master) + 1) x count clock cycle

Duty cycle [%] = (TAUJnCDRm (slave) / (TAUJnCDRm (master) + 1)) x 100

– Duty cycle = 0 %

TAUJnCDRm (slave) = 0000 0000_H

– Duty cycle = 100 %

TAUJnCDRm (slave) ≥ TAUJnCDRm (master) + 1


(3) Block diagram and general timing diagram

Figure 15-52 Block diagram for PWM Output Function

The following settings apply to the general timing diagram:

- Slave channel: Positive logic (TAUJnTOL.TOLm = 0)




Figure 15-53 General timing diagram for PWM Output Function

Note The interval between the slave channel starting to count and an interrupt being generated is the value of corresponding TAUJnCDRm, whereas for the master channel the interval is the corresponding TAUJnCDRm + 1.

(4) Register settings for the master channel**(a) TAUJnCMORm for the master channel**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]		CCS[1:0]		MAS	STS[2:0]		COS[1:0]		-	MD[4:1]				MD0	

Table 15-46 TAUJnCMORm settings for the master channel of the PWM Output Function

Bit name	Setting
CKS[1:0]	00: Prescaler output CK0 01: Prescaler output CK1 10: Prescaler output CK2 11: Prescaler output CK3 The value of the CKS[1:0] bit of the master and slave channel(s) must be identical.
CCS[1:0]	00: Operation clock is used as the count clock
MAS	1: Channel is master channel
STS[2:0]	000: Counter triggered by software trigger
COS[1:0]	00: Not used, so set to 00
MD[4:1]	0000: Interval Timer Mode
MD0	1: Generates INTTAUJnIm at operation start

(b) TAUJnCMURm for the master channel

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
														TIS[1:0]	

Table 15-47 TAUJnCMURm settings for the master channel of the PWM Output Function

Bit name	Setting
TIS[1:0]	00: Not used so set to 00

(c) Channel output mode for the master channel

The channel output mode is not used by this function. However, it can be used by other functions or in Direct Channel Output Mode.

(d) Simultaneous rewrite for the master channel

The simultaneous rewrite settings of the master and slave channel must be identical.

Table 15-48 Simultaneous rewrite settings for the master channel of the PWM Output Function

Bit name	Setting
RDE.RDEm	1: Enables simultaneous rewrite
RDM.RDMm	0: The simultaneous rewrite trigger signal is generated when the master channel starts counting

(5) Register settings for the slave channel(s)**(a) TAUJnCMORm for the slave channel(s)**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]	CCS[1:0]	MAS	STS[2:0]		COS[1:0]		-	MD[4:1]				MD0			

Table 15-49 TAUJnCMORm settings for the slave channel of the PWM Output Function

Bit name	Setting
CKS[1:0]	00: Prescaler output CK0 01: Prescaler output CK1 10: Prescaler output CK2 11: Prescaler output CK3 The value of the CKS[1:0] bit of the master and slave channel(s) must be identical.
CCS[1:0]	00: Operation clock is used as the count clock
MAS	0: Channel is a slave channel
STS[2:0]	100: INTTAUJnIm of the master channel is the start trigger
COS[1:0]	00: Not used, so set to 00
MD[4:1]	0100: One Count Mode
MD0	1: Generates INTTAUJnIm and toggles TAUJnTTOUTm at operation start

(b) TAUJnCMURm for the slave channel(s)

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
-														TIS[1:0]	

Table 15-50 TAUJnCMURm settings for the slave channel of the PWM Output Function

Bit name	Setting
TIS[1:0]	00: Not used so set to 00

(c) Channel output mode for the slave channel(s)**Table 15-51 Control bit settings for Independent Channel Output Mode 1**

Bit name	Setting
TOEm	1: Disables Direct Channel Output Mode
TOMm	1: Synchronous channel operation
TOCm	0: Operation mode 1
TOLm	0: Positive logic 1: Inverted logic

(d) Simultaneous rewrite for the slave channel(s)

The simultaneous rewrite settings of the master and slave channel must be identical.

Table 15-52 Simultaneous rewrite settings for the slave channel of the PWM Output Function

Bit name	Setting
RDE.RDEm	1: Enables simultaneous rewrite
RDM.RDMm	0: The simultaneous rewrite trigger signal is generated when the master channel starts counting

(6) Operating procedure for PWM Output Function

Table 15-53 Operating procedure for PWM Output Function

	Operation	Status of TAUJn
Restart	Initial channel setting Master channel: set the TAUJnCMORm and TAUJnCMURm registers and the channel output mode as described in 4 "Register settings for the master channel" on page 781 Slave channel: set the TAUJnCMORm and TAUJnCMURm registers and the channel output mode as described in 5 "Register settings for the slave channel(s)" on page 783 Set the values of the TAUJnCDRm registers of all channels	Channel operation is stopped. (A clock is supplied, and a small amount of power is consumed.)
	Start operation Set TAUJnTS.TSm of the master and slave channels to 1 simultaneously. TAUJnTS.TSm is a trigger bit, so it is automatically cleared to 0.	TAUJnTE.TEm (master and slave channels) is set to 1 and the counters of the master and slave channels start. INTTAUJnIm is generated on the master channel and TAUJnTTOUTm (slave) is set.
	During operation TAUJnCDRm can be changed at any time. TAUJnCNTm and TAUJnRSF.RSFm can be read at any time. TAUJnRDT.RDTm can be changed during operation.	TAUJnCNTm of the master channel loads TAUJnCDRm and counts down. When the counter reaches 0000 0000 _H : <ul style="list-style-type: none"> INTTAUJnIm (master) is generated TAUJnCNTm (master) reloads the TAUJnCDRm value and continues count operation TAUJnCNTm (slave) reloads the TAUJnCDRm value and counts down TAUJnTTOUTm (slave) is set When TAUJnCNTm (slave) reaches 0000 0000 _H : <ul style="list-style-type: none"> INTTAUJnIm (slave) is generated TAUJnTTOUTm (slave) is reset
	Stop operation Set TAUJnTT.TTm of the master and slave channels to 1 simultaneously. TAUJnTT.TTm is a trigger bit, so it is automatically cleared to 0.	TAUJnTE.TEm is cleared to 0 and the counter stops. TAUJnCNTm and TAUJnTTOUTm stop and retain their current values. When TAUJnTOE.TOEm is 0, TAUJnTTOUTm output is initialized to the value set by TAUJnTO.TOm.

(7) Specific timing diagrams

(a) Duty cycle = 0 %




Figure 15-54 TAUJnCDRm (slave) = 0000 0000_H,
positive logic (TAUJnTOL.TOLm (slave) = 0)

- Every time the master channel generates an interrupt (INTTAUJnIm), 0000 0000_H is written to TAUJnCNTm (slave). Therefore, TAUJnCNTm (slave) cannot start to count and TAUJnTTOUTm remains at not active state.
- TAUJnCNTm (slave) generates an interrupt every time the value of TAUJnCDRm is reloaded. The slave and the master channel generate interrupts in the same cycle.

(b) Duty cycle = 100 %




Figure 15-55 $TAUJnCDRm (slave) \geq TAUJnCDRm (master) + 1$,
positive logic ($TAUJnTOL.TOLm (slave) = 0$)

- If the value $TAUJnCDRm (slave)$ is higher than the value $TAUJnCDRm (master)$, the counter of the slave channel cannot reach $0000\ 0000_H$ and cannot generate interrupts. The $TAUJnTTOUTm$ remains at active state.

(c) Stop and restart operation




Figure 15-56 Stop and restart operation,
positive logic (TAUJnTOL.TOLm (slave) = 0)

- The counter can be stopped by setting TAUJnTT.TTm of the master and slave channel(s) to 1, which in turn sets TAUJnTE.TEm to 0.
- TAUJnCNTm and TAUJnTTOUTm of all channels stop and the current values are retained. No interrupts are generated.
- The counter can be restarted by setting TAUJnTS.TSm of master and slave channel(s) to 1. TAUJnCNTm of master and slave channel reload the current values of TAUJnCDRm and start to count down from these values.

15.18 Registers

This section contains a description of all the registers of the 32-bit Timer Array Unit J.

15.18.1 TAUJn registers overview

The TAUJn is controlled and operated by the registers in the following table. Where there is one register per channel, this is indicated by an “m”, where m runs from 0 to 3.

Table 15-54 TAUJn registers overview

Register name	Shortcut	Address
TAUJn prescaler registers		
TAUJn prescaler clock select register	TAUJnTPS	<TAUJn_base> + 90 _H
TAUJn prescaler baud rate setting register	TAUJnBRS	<TAUJn_base> + 94 _H
TAUJn control registers		
TAUJn channel data register m	TAUJnCDRm	<TAUJn_base> + m x 4 _H
TAUJn channel counter register m	TAUJnCNTm	<TAUJn_base> + 10 _H + m x 4 _H
TAUJn channel mode OS register m	TAUJnCMORM	<TAUJn_base> + 80 _H + m x 4 _H
TAUJn channel mode user register m	TAUJnCMURm	<TAUJn_base> + 20 _H + m x 4 _H
TAUJn channel status register m	TAUJnCSRm	<TAUJn_base> + 30 _H + m x 4 _H
TAUJn channel status clear trigger register m	TAUJnCSCm	<TAUJn_base> + 40 _H + m x 4 _H
TAUJn channel start trigger register	TAUJnTS	<TAUJn_base> + 54 _H
TAUJn channel enable status register	TAUJnTE	<TAUJn_base> + 50 _H
TAUJn channel stop trigger register	TAUJnTT	<TAUJn_base> + 58 _H
TAUJn output registers		
TAUJn channel output enable register	TAUJnTOE	<TAUJn_base> + 60 _H
TAUJn channel output register	TAUJnTO	<TAUJn_base> + 5C _H
TAUJn channel output mode register	TAUJnTOM	<TAUJn_base> + 98 _H
TAUJn channel output configuration register	TAUJnTOC	<TAUJn_base> + 9C _H
TAUJn channel output active level register	TAUJnTOL	<TAUJn_base> + 64 _H
TAUJn reload data registers		
TAUJn channel reload data enable register	TAUJnRDE	<TAUJn_base> + A0 _H
TAUJn channel reload data mode register	TAUJnRDM	<TAUJn_base> + A4 _H
TAUJn channel reload data trigger register	TAUJnRDT	<TAUJn_base> + 68 _H
TAUJn channel reload status register	TAUJnRSF	<TAUJn_base> + 6C _H
TAUJn emulation register		
TAUJn emulation register	TAUJnEMU	<TAUJn_base> + A8 _H

<TAUJn_base> The <TAUJn_base> addresses of the registers are defined in the first section of this chapter under the keyword “Register addresses”.

15.18.2 TAUJn prescaler registers details

(1) TAUJnTPS - TAUJn prescaler clock select register

This register specifies the PCLK prescalers for clocks CK0, CK1, CK2, and CK3_PRE for all channels. CK3 is generated by dividing CK3_PRE by the factor specified in TAUJnBRS.

Access This register can be read/written in 16-bit units.

Address <TAUJn_base> + 90_H

Initial Value FFFF_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
PRS3[3:0]				PRS2[3:0]				PRS1[3:0]				PRS0[3:0]			
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 15-55 TAUJnTPS register contents (1/2)

Bit position	Bit name	Function																
15 to 12	PRS3[3:0]	<p>Specifies the CK3_PRE clock. Clock CK3_PRE is the input clock of the BRG unit. The BRG unit supplies the CK3 operation clock for all channels.</p> <table border="1"> <thead> <tr> <th>PRS3[3:0]</th><th>CK3_PRE clock</th></tr> </thead> <tbody> <tr><td>0000_B</td><td>PCLK/2⁰</td></tr> <tr><td>0001_B</td><td>PCLK/2¹</td></tr> <tr><td>0010_B</td><td>PCLK/2²</td></tr> <tr><td>0011_B</td><td>PCLK/2³</td></tr> <tr><td>...</td><td>...</td></tr> <tr><td>1110_B</td><td>PCLK/2¹⁴</td></tr> <tr><td>1111_B</td><td>PCLK/2¹⁵</td></tr> </tbody> </table> <p>These bits can only be rewritten when all counters using CK3 are stopped (TAUJnTE.TEm = 0).</p>	PRS3[3:0]	CK3_PRE clock	0000 _B	PCLK/2 ⁰	0001 _B	PCLK/2 ¹	0010 _B	PCLK/2 ²	0011 _B	PCLK/2 ³	1110 _B	PCLK/2 ¹⁴	1111 _B	PCLK/2 ¹⁵
PRS3[3:0]	CK3_PRE clock																	
0000 _B	PCLK/2 ⁰																	
0001 _B	PCLK/2 ¹																	
0010 _B	PCLK/2 ²																	
0011 _B	PCLK/2 ³																	
...	...																	
1110 _B	PCLK/2 ¹⁴																	
1111 _B	PCLK/2 ¹⁵																	
11 to 8	PRS2[3:0]	<p>Specifies the CK2 clock.</p> <table border="1"> <thead> <tr> <th>PRS2[3:0]</th><th>CK2 clock</th></tr> </thead> <tbody> <tr><td>0000_B</td><td>PCLK/2⁰</td></tr> <tr><td>0001_B</td><td>PCLK/2¹</td></tr> <tr><td>0010_B</td><td>PCLK/2²</td></tr> <tr><td>0011_B</td><td>PCLK/2³</td></tr> <tr><td>...</td><td>...</td></tr> <tr><td>1110_B</td><td>PCLK/2¹⁴</td></tr> <tr><td>1111_B</td><td>PCLK/2¹⁵</td></tr> </tbody> </table> <p>These bits can only be rewritten when all counters using CK2 are stopped (TAUJnTE.TEm = 0).</p>	PRS2[3:0]	CK2 clock	0000 _B	PCLK/2 ⁰	0001 _B	PCLK/2 ¹	0010 _B	PCLK/2 ²	0011 _B	PCLK/2 ³	1110 _B	PCLK/2 ¹⁴	1111 _B	PCLK/2 ¹⁵
PRS2[3:0]	CK2 clock																	
0000 _B	PCLK/2 ⁰																	
0001 _B	PCLK/2 ¹																	
0010 _B	PCLK/2 ²																	
0011 _B	PCLK/2 ³																	
...	...																	
1110 _B	PCLK/2 ¹⁴																	
1111 _B	PCLK/2 ¹⁵																	

Table 15-55 TAUJnTPS register contents (2/2)

Bit position	Bit name	Function																
7 to 4	PRS1[3:0]	Specifies the CK1 clock. <table border="1" data-bbox="552 331 1385 672"> <thead> <tr> <th>PRS1[3:0]</th> <th>CK1 clock</th> </tr> </thead> <tbody> <tr> <td>0000_B</td> <td>PCLK/2⁰</td> </tr> <tr> <td>0001_B</td> <td>PCLK/2¹</td> </tr> <tr> <td>0010_B</td> <td>PCLK/2²</td> </tr> <tr> <td>0011_B</td> <td>PCLK/2³</td> </tr> <tr> <td>...</td> <td>...</td> </tr> <tr> <td>1110_B</td> <td>PCLK/2¹⁴</td> </tr> <tr> <td>1111_B</td> <td>PCLK/2¹⁵</td> </tr> </tbody> </table> These bits can only be rewritten when all counters using CK1 are stopped (TAUJnTE.TEm = 0).	PRS1[3:0]	CK1 clock	0000 _B	PCLK/2 ⁰	0001 _B	PCLK/2 ¹	0010 _B	PCLK/2 ²	0011 _B	PCLK/2 ³	1110 _B	PCLK/2 ¹⁴	1111 _B	PCLK/2 ¹⁵
PRS1[3:0]	CK1 clock																	
0000 _B	PCLK/2 ⁰																	
0001 _B	PCLK/2 ¹																	
0010 _B	PCLK/2 ²																	
0011 _B	PCLK/2 ³																	
...	...																	
1110 _B	PCLK/2 ¹⁴																	
1111 _B	PCLK/2 ¹⁵																	
3 to 0	PRS0[3:0]	Specifies the CK0 clock. <table border="1" data-bbox="552 786 1385 1126"> <thead> <tr> <th>PRS0[3:0]</th> <th>CK0 clock</th> </tr> </thead> <tbody> <tr> <td>0000_B</td> <td>PCLK/2⁰</td> </tr> <tr> <td>0001_B</td> <td>PCLK/2¹</td> </tr> <tr> <td>0010_B</td> <td>PCLK/2²</td> </tr> <tr> <td>0011_B</td> <td>PCLK/2³</td> </tr> <tr> <td>...</td> <td>...</td> </tr> <tr> <td>1110_B</td> <td>PCLK/2¹⁴</td> </tr> <tr> <td>1111_B</td> <td>PCLK/2¹⁵</td> </tr> </tbody> </table> These bits can only be rewritten when all counters using CK0 are stopped (TAUJnTE.TEm = 0).	PRS0[3:0]	CK0 clock	0000 _B	PCLK/2 ⁰	0001 _B	PCLK/2 ¹	0010 _B	PCLK/2 ²	0011 _B	PCLK/2 ³	1110 _B	PCLK/2 ¹⁴	1111 _B	PCLK/2 ¹⁵
PRS0[3:0]	CK0 clock																	
0000 _B	PCLK/2 ⁰																	
0001 _B	PCLK/2 ¹																	
0010 _B	PCLK/2 ²																	
0011 _B	PCLK/2 ³																	
...	...																	
1110 _B	PCLK/2 ¹⁴																	
1111 _B	PCLK/2 ¹⁵																	

Note The TAUJn clock input PCLK is specified in the first section of this chapter under the keyword “Clock supply”.

(2) TAUJnBRS - TAUJn prescaler baud rate setting register

This register specifies the division factor of prescaler clock CK3.

CK3 is generated by dividing CK3_PRE by the factor specified in this register plus one. The PCLK prescaler for CK3_PRE is specified in TAUJnTPS.PRS3[3:0].

Access This register can be read/written in 8-bit units.

Address <TAUJn_base> + 94_H

Initial Value 00_H




Table 15-56 TAUJnBRS register contents

Bit position	Bit name	Function																
7 to 0	BRS[07:00]	Specifies the CK3_PRE clock division factor for generating CK3: <table border="1" style="margin-left: 20px; border-collapse: collapse; width: 80%;"> <thead> <tr style="background-color: #cccccc;"> <th style="text-align: center;">BRS[07:00]</th> <th style="text-align: center;">CK3 clock</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0000 0000_B</td> <td style="text-align: center;">CK3_PRE / 1</td> </tr> <tr> <td style="text-align: center;">0000 0001_B</td> <td style="text-align: center;">CK3_PRE / 2</td> </tr> <tr> <td style="text-align: center;">0000 0010_B</td> <td style="text-align: center;">CK3_PRE / 3</td> </tr> <tr> <td style="text-align: center;">0000 0011_B</td> <td style="text-align: center;">CK3_PRE / 4</td> </tr> <tr> <td style="text-align: center;">...</td> <td style="text-align: center;">...</td> </tr> <tr> <td style="text-align: center;">1111 1110_B</td> <td style="text-align: center;">CK3_PRE / 255</td> </tr> <tr> <td style="text-align: center;">1111 1111_B</td> <td style="text-align: center;">CK3_PRE / 256</td> </tr> </tbody> </table>	BRS[07:00]	CK3 clock	0000 0000 _B	CK3_PRE / 1	0000 0001 _B	CK3_PRE / 2	0000 0010 _B	CK3_PRE / 3	0000 0011 _B	CK3_PRE / 4	1111 1110 _B	CK3_PRE / 255	1111 1111 _B	CK3_PRE / 256
BRS[07:00]	CK3 clock																	
0000 0000 _B	CK3_PRE / 1																	
0000 0001 _B	CK3_PRE / 2																	
0000 0010 _B	CK3_PRE / 3																	
0000 0011 _B	CK3_PRE / 4																	
...	...																	
1111 1110 _B	CK3_PRE / 255																	
1111 1111 _B	CK3_PRE / 256																	

15.18.3 TAUJn control registers details

(1) TAUJnCDRm - TAUJn channel data register

This register functions either as a compare register or as a capture register, depending on the operation mode specified in TAUJnCMORm.MD[4:0].

Access This register can be read/written in 32-bit units.

- In capture mode, only reading is possible. Write operation is ignored.
- In compare mode, reading and writing is possible.

Address <TAUJn_base> + 0_H + m x 4_H

Initial Value 0000 0000_H

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
CDR[31:16]															
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CDR[15:0]															
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 15-57 TAUJnCDRm register contents

Bit position	Bit name	Function
31 to 0	CDR[31:0]	Data register for the capture/compare value.

(2) TAUJnCNTm - TAUJn channel counter register

This register is the channel m counter register.

Access This register can be read in 32-bit units.

Address <TAUJn_base> + 10_H + m × 4_H

Initial Value 0000 0000_H or FFFF FFFF_H The initial value depends on the operation mode, see Table 15-59 “TAUJnCNTm read values after the counter is re-enabled” on page 794

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
CNT[31:16]															
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CNT[15:0]															
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Table 15-58 TAUJnCNTm register contents

Bit position	Bit name	Function
31 to 0	CNT[31:0]	32-bit counter value.

The read value depends on the counter, the operation mode change, and the values of the TAUJnTS.TSm and TAUJnTT.TTm bits.

The *initial* counter read value depends on the operation mode and how the counter was stopped:

- by a reset
- by a counter stop trigger (TAUJnTT.TTm = 1)

The following table lists the initial counter read values after the counter has stopped (TAUJnTE.TEm= 0) and re-enabled (TAUJnTS.TSm = 1).

The table also contains the counter read value one count after the counter is enabled (TAUJnTS.TSm = 1) for modes where the counter waits for a start trigger.

Table 15-59 TAUJnCNTm read values after the counter is re-enabled

Mode name	Count method (up/down)	TAUJnCNTm value		
		After reset	After stop trigger	After one count
Interval Timer mode	Count down	FFFF FFFF _H	Stop value	-
Capture mode	Count up	0000 0000 _H	Stop value	-
One Count mode	Count down	FFFF FFFF _H	Stop value	FFFF FFFF _H
Capture & One Count mode	Count up	0000 0000 _H	Stop value	Captured value + 1 (TAUJnCDRm)
Count Capture Mode	Count up	0000 0000 _H	Stop value	-
Gate Count Mode	Count down	FFFF FFFF _H	Stop value	Stop value
Capture & Gate Count Mode	Count up	0000 0000 _H	Stop value	Stop value

Note If the operation mode is changed while the counter is stopped, the initial counter value after counter restart is undefined. The operation mode is changed by register TAUJnCMORm.MD[4:0].

(3) TAUJnCMORm - TAUJn channel mode OS register

This register controls channel m operation. It specifies, for example, the operation clock, count clock, and master/slave function.

Access This register can be read/written in 16-bit units. It can only be written when the counter is stopped (TAUJnTE.TEm = 0).

Address <TAUJn_base> + 80_H + m × 4_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CKS[1:0]		CCS[1:0]		MAS	STS[2:0]			COS[1:0]		-	MD[4:0]				
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R	R/W	R/W	R/W	R/W	R/W

Table 15-60 TAUJnCMORm register contents (1/3)

Bit position	Bit name	Function															
15,14	CKS[1:0]	<p>Selects the operation clock. The operation clock is used for the TAUJnTTINm input edge detection circuit. It can also be used as the count clock depending on bits TAUJnCMORm.CCS[1:0].</p> <table border="1"> <thead> <tr> <th>CKS1</th><th>CKS0</th><th>Selected operation clock</th></tr> </thead> <tbody> <tr> <td>0</td><td>0</td><td>CK0</td></tr> <tr> <td>0</td><td>1</td><td>CK1</td></tr> <tr> <td>1</td><td>0</td><td>CK2</td></tr> <tr> <td>1</td><td>1</td><td>CK3</td></tr> </tbody> </table>	CKS1	CKS0	Selected operation clock	0	0	CK0	0	1	CK1	1	0	CK2	1	1	CK3
CKS1	CKS0	Selected operation clock															
0	0	CK0															
0	1	CK1															
1	0	CK2															
1	1	CK3															
13,12	CCS[1:0]	<p>Selects the count clock for TAUJnCNTm counter:</p> <table border="1"> <thead> <tr> <th>CCS1</th><th>CCS0</th><th>Selected count clock</th></tr> </thead> <tbody> <tr> <td>0</td><td>0</td><td>Operation clock as specified by TAUJnCMORm.CKS[1:0].</td></tr> <tr> <td>0</td><td>1</td><td>Valid edge of TAUJnTTINm input signal</td></tr> <tr> <td>1</td><td>0</td><td>Setting prohibited</td></tr> <tr> <td>1</td><td>1</td><td>Setting prohibited</td></tr> </tbody> </table>	CCS1	CCS0	Selected count clock	0	0	Operation clock as specified by TAUJnCMORm.CKS[1:0].	0	1	Valid edge of TAUJnTTINm input signal	1	0	Setting prohibited	1	1	Setting prohibited
CCS1	CCS0	Selected count clock															
0	0	Operation clock as specified by TAUJnCMORm.CKS[1:0].															
0	1	Valid edge of TAUJnTTINm input signal															
1	0	Setting prohibited															
1	1	Setting prohibited															
11	MAS	<p>Specifies the channel as master or slave channel during synchronous channel operation: 0: Slave 1: Master This bit is only valid for even channels (CHm_even). For odd channels (CHm_odd), it is fixed to 0.</p>															

Table 15-60 TAUJnCMORm register contents (2/3)

Bit position	Bit name	Function																																				
10 to 8	STS[2:0]	<p>Selects the external start trigger:</p> <table border="1"> <thead> <tr> <th>STS2</th> <th>STS1</th> <th>STS0</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>0</td> <td>Software trigger.</td> </tr> <tr> <td>0</td> <td>0</td> <td>1</td> <td>Valid edge of the TAUJnTTINm input signal. TAUJnCMURm.TIS[1:0] specifies the valid edge.</td> </tr> <tr> <td>0</td> <td>1</td> <td>0</td> <td>Valid edge of the TAUJnTTINm input signal is the start trigger and the reverse edge is the stop (capture) trigger.</td> </tr> <tr> <td>0</td> <td>1</td> <td>1</td> <td>Setting prohibited</td> </tr> <tr> <td>1</td> <td>0</td> <td>0</td> <td>INTTAUJnI of the master channel.</td> </tr> <tr> <td>1</td> <td>0</td> <td>1</td> <td>Setting prohibited</td> </tr> <tr> <td>1</td> <td>1</td> <td>0</td> <td></td> </tr> <tr> <td>1</td> <td>1</td> <td>1</td> <td></td> </tr> </tbody> </table>	STS2	STS1	STS0	Description	0	0	0	Software trigger.	0	0	1	Valid edge of the TAUJnTTINm input signal. TAUJnCMURm.TIS[1:0] specifies the valid edge.	0	1	0	Valid edge of the TAUJnTTINm input signal is the start trigger and the reverse edge is the stop (capture) trigger.	0	1	1	Setting prohibited	1	0	0	INTTAUJnI of the master channel.	1	0	1	Setting prohibited	1	1	0		1	1	1	
STS2	STS1	STS0	Description																																			
0	0	0	Software trigger.																																			
0	0	1	Valid edge of the TAUJnTTINm input signal. TAUJnCMURm.TIS[1:0] specifies the valid edge.																																			
0	1	0	Valid edge of the TAUJnTTINm input signal is the start trigger and the reverse edge is the stop (capture) trigger.																																			
0	1	1	Setting prohibited																																			
1	0	0	INTTAUJnI of the master channel.																																			
1	0	1	Setting prohibited																																			
1	1	0																																				
1	1	1																																				
7, 6	COS[1:0]	<p>Specifies when the capture register TAUJnCDRm and the overflow flag TAUJnCSRm.OVF of channel m are updated. These bits are only valid if channel m is in capture mode.</p> <table border="1"> <thead> <tr> <th>COS1</th> <th>COS0</th> <th>Capture register</th> <th>TAUJnCSRm.OVF</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Updated upon detection of a TAUJnTTINm input valid edge.</td> <td>Updated (cleared or set) upon detection of a TAUJnTTINm input valid edge: <ul style="list-style-type: none"> If a counter overflow has occurred since the last valid edge detection, TAUJnCSRm.OVF is set. If no counter overflow has occurred since the last valid edge detection, TAUJnCSRm.OVF is cleared. </td> </tr> <tr> <td>0</td> <td>1</td> <td></td> <td>Set upon counter overflow and cleared by a CPU instruction.</td> </tr> <tr> <td>1</td> <td>0</td> <td>Updated upon detection of a TAUJnTTINm input valid edge and upon counter overflow:</td> <td>Not set.</td> </tr> <tr> <td>1</td> <td>1</td> <td> <ul style="list-style-type: none"> TAUJnTTINm input valid edge: Counter value is written to TAUJnCDRm. Overflow: FFFF FFFF_H is written to TAUJnCDRm. The next TAUJnTTINm input valid edge detection is ignored. </td> <td>Set upon counter overflow and cleared by a CPU instruction.</td> </tr> </tbody> </table>	COS1	COS0	Capture register	TAUJnCSRm.OVF	0	0	Updated upon detection of a TAUJnTTINm input valid edge.	Updated (cleared or set) upon detection of a TAUJnTTINm input valid edge: <ul style="list-style-type: none"> If a counter overflow has occurred since the last valid edge detection, TAUJnCSRm.OVF is set. If no counter overflow has occurred since the last valid edge detection, TAUJnCSRm.OVF is cleared. 	0	1		Set upon counter overflow and cleared by a CPU instruction.	1	0	Updated upon detection of a TAUJnTTINm input valid edge and upon counter overflow:	Not set.	1	1	<ul style="list-style-type: none"> TAUJnTTINm input valid edge: Counter value is written to TAUJnCDRm. Overflow: FFFF FFFF_H is written to TAUJnCDRm. The next TAUJnTTINm input valid edge detection is ignored. 	Set upon counter overflow and cleared by a CPU instruction.																
COS1	COS0	Capture register	TAUJnCSRm.OVF																																			
0	0	Updated upon detection of a TAUJnTTINm input valid edge.	Updated (cleared or set) upon detection of a TAUJnTTINm input valid edge: <ul style="list-style-type: none"> If a counter overflow has occurred since the last valid edge detection, TAUJnCSRm.OVF is set. If no counter overflow has occurred since the last valid edge detection, TAUJnCSRm.OVF is cleared. 																																			
0	1		Set upon counter overflow and cleared by a CPU instruction.																																			
1	0	Updated upon detection of a TAUJnTTINm input valid edge and upon counter overflow:	Not set.																																			
1	1	<ul style="list-style-type: none"> TAUJnTTINm input valid edge: Counter value is written to TAUJnCDRm. Overflow: FFFF FFFF_H is written to TAUJnCDRm. The next TAUJnTTINm input valid edge detection is ignored. 	Set upon counter overflow and cleared by a CPU instruction.																																			

Table 15-60 TAUJnCMORM register contents (3/3)

Bit position	Bit name	Function																																																																																										
4 to 0	MD[4:0]	Specifies the operation mode. <table border="1"> <thead> <tr> <th>MD4</th> <th>MD3</th> <th>MD2</th> <th>MD1</th> <th>MD0</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>1/0</td> <td>Interval Timer mode</td> </tr> <tr> <td>0</td> <td>0</td> <td>0</td> <td>1</td> <td>1/0</td> <td>Setting prohibited</td> </tr> <tr> <td>0</td> <td>0</td> <td>1</td> <td>0</td> <td>1/0</td> <td>Capture mode</td> </tr> <tr> <td>0</td> <td>0</td> <td>1</td> <td>1</td> <td>1/0</td> <td>Setting prohibited</td> </tr> <tr> <td>0</td> <td>1</td> <td>0</td> <td>0</td> <td>1/0</td> <td>One Count mode</td> </tr> <tr> <td>0</td> <td>1</td> <td>0</td> <td>1</td> <td>1/0</td> <td>Setting prohibited</td> </tr> <tr> <td>0</td> <td>1</td> <td>1</td> <td>0</td> <td>0</td> <td>Capture & One Count mode</td> </tr> <tr> <td>0</td> <td>1</td> <td>1</td> <td>1</td> <td>1/0</td> <td>Setting prohibited</td> </tr> <tr> <td>1</td> <td>0</td> <td>0</td> <td>0</td> <td></td> <td></td> </tr> <tr> <td>1</td> <td>0</td> <td>0</td> <td>1</td> <td></td> <td></td> </tr> <tr> <td>1</td> <td>0</td> <td>1</td> <td>0</td> <td></td> <td></td> </tr> <tr> <td>1</td> <td>0</td> <td>1</td> <td>1</td> <td>1/0</td> <td>Count Capture mode</td> </tr> <tr> <td>1</td> <td>1</td> <td>0</td> <td>0</td> <td>0</td> <td>Gate Count mode</td> </tr> <tr> <td>1</td> <td>1</td> <td>0</td> <td>1</td> <td>0</td> <td>Capture & Gate Count mode</td> </tr> </tbody> </table>	MD4	MD3	MD2	MD1	MD0	Description	0	0	0	0	1/0	Interval Timer mode	0	0	0	1	1/0	Setting prohibited	0	0	1	0	1/0	Capture mode	0	0	1	1	1/0	Setting prohibited	0	1	0	0	1/0	One Count mode	0	1	0	1	1/0	Setting prohibited	0	1	1	0	0	Capture & One Count mode	0	1	1	1	1/0	Setting prohibited	1	0	0	0			1	0	0	1			1	0	1	0			1	0	1	1	1/0	Count Capture mode	1	1	0	0	0	Gate Count mode	1	1	0	1	0	Capture & Gate Count mode
MD4	MD3	MD2	MD1	MD0	Description																																																																																							
0	0	0	0	1/0	Interval Timer mode																																																																																							
0	0	0	1	1/0	Setting prohibited																																																																																							
0	0	1	0	1/0	Capture mode																																																																																							
0	0	1	1	1/0	Setting prohibited																																																																																							
0	1	0	0	1/0	One Count mode																																																																																							
0	1	0	1	1/0	Setting prohibited																																																																																							
0	1	1	0	0	Capture & One Count mode																																																																																							
0	1	1	1	1/0	Setting prohibited																																																																																							
1	0	0	0																																																																																									
1	0	0	1																																																																																									
1	0	1	0																																																																																									
1	0	1	1	1/0	Count Capture mode																																																																																							
1	1	0	0	0	Gate Count mode																																																																																							
1	1	0	1	0	Capture & Gate Count mode																																																																																							
Mode	Role of the MD0 bit																																																																																											
Interval Timer mode Capture mode Count Capture mode	Specifies whether an INTTAUJnIm is generated when the counter is triggered: 0: No INTTAUJnIm generated 1: INTTAUJnIm generated																																																																																											
One Count mode Gate Count mode	Enables/disables start trigger detection during counting: 0: Disabled 1: Enabled INTTAUJnIm and TAUJnTTOUTm are not output when the counter is triggered.																																																																																											
Capture & One Count mode Capture & Gate Count mode	This bit must be set to 0: 0: No INTTAUJnIm generated when the counter is triggered. Start trigger is disabled during counting. 1: -																																																																																											

(4) TAUJnCMURm - TAUJn channel mode user register

This register specifies the type of valid edge detection used for the TAUJnTTINm input.

Access This register can be read/written in 8-bit units. It can only be written when the counter is enabled (TAUJnTE.TEm = 1).

Address <TAUJn_base> + 20_H + m × 4_H

Initial Value 00_H

7	6	5	4	3	2	1	0
-	-	-	-	-	-	TIS[1:0]	
R	R	R	R	R	R	R/W	R/W

Table 15-61 TAUJnCMURm register contents

Bit position	Bit name	Function															
1, 0	TIS[1:0]	<p>Specifies the valid edge of the TAUJnTTINm input:</p> <table border="1"> <thead> <tr> <th>TIS1</th> <th>TIS0</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td style="text-align: center;">0</td> <td>Falling edge</td> </tr> <tr> <td style="text-align: center;">0</td> <td style="text-align: center;">1</td> <td>Rising edge</td> </tr> <tr> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> <td>Rising and falling edges (low-width measurement selection). Start trigger: falling edge Stop trigger (capture): rising edge</td> </tr> <tr> <td style="text-align: center;">1</td> <td style="text-align: center;">1</td> <td>Rising and falling edges (high-width measurement selection). Start trigger: rising edge Stop trigger (capture): falling edge This setting is only valid if the start trigger selection is set to TAUJnCMORm.STS[2:0] = 010_B</td> </tr> </tbody> </table> <ul style="list-style-type: none"> To detect rising and falling edges when TAUJnCMORm.STS[2:0] is not set to 010_B, set TAUJnCMURm.TIS[1:0] = 10_B. Edge detection for TAUJnTTINm input signals is performed based on the operation clock selected by TAUJnCMORm.CKS[1:0]. 	TIS1	TIS0	Description	0	0	Falling edge	0	1	Rising edge	1	0	Rising and falling edges (low-width measurement selection). Start trigger: falling edge Stop trigger (capture): rising edge	1	1	Rising and falling edges (high-width measurement selection). Start trigger: rising edge Stop trigger (capture): falling edge This setting is only valid if the start trigger selection is set to TAUJnCMORm.STS[2:0] = 010 _B
TIS1	TIS0	Description															
0	0	Falling edge															
0	1	Rising edge															
1	0	Rising and falling edges (low-width measurement selection). Start trigger: falling edge Stop trigger (capture): rising edge															
1	1	Rising and falling edges (high-width measurement selection). Start trigger: rising edge Stop trigger (capture): falling edge This setting is only valid if the start trigger selection is set to TAUJnCMORm.STS[2:0] = 010 _B															

(5) TAUJnCSRm - TAUJn channel status register

This register indicates the overflow status of channel m's counter.

Access This register can be read in 8-bit units.

Address <TAUJn_base> + 30_H + m × 4_H

Initial Value 00_H

7	6	5	4	3	2	1	0
-	-	-	-	-	-	-	OVF
R	R	R	R	R	R	R	R

Table 15-62 TAUJnCSRm register contents

Bit position	Bit name	Function
0	OVF	<p>Indicates the counter overflow status: 0: No overflow occurred 1: Overflow occurred</p> <p>This bit is only used in the following modes:</p> <ul style="list-style-type: none"> • Capture mode • Capture & One Count mode • Count Capture mode • Capture & Gate Count mode <p>The function of this bit depends on the setting of control bits TAUJnCMORm.COS[1:0]. OVF is not be set when TAUJnCMORm.COS[1:0] = 10_B.</p>

(6) TAUJnCSCm - TAUJn channel status clear register

This register is a trigger register for clearing the overflow flag TAUJnCSRm.OVF of a channel m.

Access This register can be written in 8-bit units. It is always read as 0000_H.

Address <TAUJn_base> + 40_H + m × 4_H

Initial Value 00_H

7	6	5	4	3	2	1	0
-	-	-	-	-	-	0	CLOV
R	R	R	R	R	R	R	W

Table 15-63 TAUJnCSCm register contents

Bit position	Bit name	Function
0	CLOV	0: No function 1: Clears the overflow flag TAUJnCSRm.OVF

(7) TAUJnTS - TAUJn channel start trigger register

This register enables the counter for each channel.

Access This register can be written in 8-bit units. It is always read as 0000_H.

Address <TAUJn_base> + 54_H

Initial Value 00_H

7	6	5	4	3	2	1	0
-	-	-	-	TS 03	TS 02	TS 01	TS 00
W	W	W	W	W	W	W	W

Table 15-64 TAUJnTS register contents

Bit position	Bit name	Function
3 to 0	TSm	Enables the counter for channel m: 0: No function 1: Enables the counter and sets TAUJnTE.TEm = 1. When the counter is enabled, this bit immediately returns to 0. TAUJnTE.TEm = 1 only <i>enables</i> counter. Whether the counter <i>starts</i> depends on the selected operation mode.

(8) TAUJnTE - TAUJn channel enable status register

This register indicates whether counter is enabled or disabled.

Access This register can be read in 8-bit units.

Address <TAUJn_base> + 50_H

Initial Value 00_H

7	6	5	4	3	2	1	0
-	-	-	-	TE 03	TE 02	TE 01	TE 00
R	R	R	R	R	R	R	R

Table 15-65 TAUJnTE register contents

Bit position	Bit name	Function
3 to 0	TE _m	Indicates whether counter for channel m is enabled or disabled: 0: Counter disabled 1: Counter enabled Setting TAUJnTS.TS _m to 1 or trigger input detection TAUJnTSST _m = 1 sets this bit to 1. Setting TAUJnTT.TT _m to 1 resets this bit to 0.

(9) TAUJnTT - TAUJn channel stop trigger register

This register stops the counter for each channel.

Access This register can be written in 8-bit units. It is always read as 0000_H.

Address <TAUJn_base> + 58_H

Initial Value 00_H

7	6	5	4	3	2	1	0
-	-	-	-	TT 03	TT 02	TT 01	TT 00
W	W	W	W	W	W	W	W

Table 15-66 TAUJnTT register contents

Bit position	Bit name	Function
3 to 0	TT _m	Stops the counter of channel m: 0: No function 1: Stops the counter and sets TAUJnTE.TE _m = 0. When the counter has stopped, this bit immediately returns to 0. TAUJnCNT _m stops counting and TAUJnCNT _m , TAUJnTO.TO _m , and TAUJnTTOUT _m all retain the values they had before the counter was stopped.

15.18.4 TAUJn output registers details

(1) TAUJnTOE - TAUJn channel output enable register

This register enables and disables Direct Channel Output Mode.

Access This register can be read/written in 8-bit units.

Address <TAUJn_base> + 60_H

Initial Value 00_H

7	6	5	4	3	2	1	0
-	-	-	-	TOE 03	TOE 02	TOE 01	TOE 00
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 15-67 TAUJnTOE register contents

Bit position	Bit name	Function
3 to 0	TOEm	Enables/disables Direct Channel Output Mode: 0: Enables Direct Channel Output Mode (TAUJnTTOUT m output is controlled by the application software) 1: Disables Direct Channel Output Mode (TAUJnTTOUT m output is controlled by the timer)

(2) TAUJnTO - TAUJn channel output register

This register specifies and reads the level of TAUJnTTOUTm.

Access This register can be read/written in 8-bit units.

Address <TAUJn_base> + 5C_H

Initial Value 00_H

7	6	5	4	3	2	1	0
-	-	-	-	TO03	TO02	TO01	TO00
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 15-68 TAUJnTO register contents

Bit position	Bit name	Function
3 to 0	TOm	Specifies/reads the level of TAUJnTTOUTm: 0: Low 1: High Only TOm bits for which Independent Channel Output function is enabled (TAUJnTOEm = 0) can be written.

(3) TAUJnTOM - TAUJn channel output mode register

This register specifies the output mode of each channel.

Access This register can be read/written in 8-bit units. It can only be written when the counter is stopped (TAUJnTE.TEm = 0).

Address <TAUJn_base> + 98_H

Initial Value 00_H

7	6	5	4	3	2	1	0
-	-	-	-	TOM 03	TOM 02	TOM 01	TOM 00
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 15-69 TAUJnTOM register contents

Bit position	Bit name	Function
3 to 0	TOMm	Specifies the timer controlled channel output mode, if Direct Channel Output Mode is disabled (TAUJnTOE.TOEm = 1): 0: Independent Channel Output Mode 1: Synchronous Channel Output Mode The output mode depends on several channel output control bits, as can be seen in <i>Table 15-8 "Channel output modes" on page 712</i>

(4) TAUJnTOC - TAUJn channel output configuration register

This register specifies the output mode of each channel in combination with TAUJnTOMm.

Access This register can be read/written in 8-bit units. It can only be written when the counter is stopped (TAUJnTE.TEm = 0).

Address <TAUJn_base> + 9C_H

Initial Value 00_H

7	6	5	4	3	2	1	0
-	-	-	-	TOC 03	TOC 02	TOC 01	TOC 00
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 15-70 TAUJnTOC register contents

Bit position	Bit name	Function
3 to 0	TOCm	Specifies the output mode: 0: Operation mode 1 (= Toggle mode) 1: No function This bit must be set to 0 for all output modes except Direct Channel Output Mode.

(5) TAUJnTOL - TAUJn channel output level register

This register specifies the output logic of the channel output bit (TAUJnTO.TOm).

Access This register can be read/written in 8-bit units.

Address <TAUJn_base> + 64_H

Initial Value 00_H

7	6	5	4	3	2	1	0
-	-	-	-	TOL 03	TOL 02	TOL 01	TOL 00
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 15-71 TAUJnTOL register contents

Bit position	Bit name	Function
3 to 0	TOLm	Specifies the output logic of the channel m output bit (TAUJnTO.TOm): 0: Positive logic (active high) 1: Inverted logic (active low) These bits apply in all channel output modes except Direct Channel Output Mode.

15.18.5 TAUJn simultaneous rewrite register details

(1) TAUJnRDE - TAUJn channel reload data enable register

This register enables and disables simultaneous rewrite of the data register TAUJnCDRm. It also enables simultaneous rewrite of the data register TAUJnTOLm for the PWM output function and the triangle PWM output function.

Access This register can be read/written in 8-bit units. It can only be written when TAUJnTE.TEm = 0.

Address <TAUJn_base> + A0_H

Initial Value 00_H

7	6	5	4	3	2	1	0
-	-	-	-	RDE 03	RDE 02	RDE 01	RDE 00
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 15-72 TAUJnRDE register contents

Bit position	Bit name	Function
3 to 0	RDEm	Enables/disables simultaneous rewrite of the data register of channel m: 0: Disables simultaneous rewrite 1: Enabled simultaneous rewrite

(2) TAUJnRDM - TAUJn channel reload data mode register

This register selects when the signal that controls simultaneous rewrite is loaded.

Access This register can be read/written in 8-bit units. It can only be written when TAUJnTE.TEm = 0.

Address <TAUJn_base> + A4_H

Initial Value 00_H

7	6	5	4	3	2	1	0
				RDM 03	RDM 02	RDM 01	RDM 00
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 15-73 TAUJnRDM register contents

Bit position	Bit name	Function
3 to 0	RDMm	Specifies when the signal that triggers simultaneous rewrite is generated: 0: When the master channel counter starts counting 1: No function These bits only apply when TAUJnRDE.RDEm = 1.

(3) TAUJnRDT - TAUJn channel reload data trigger register

This register triggers the simultaneous rewrite pending state.

Access This register can be written in 8-bit units. It is always read as 0000_H.

Address <TAUJn_base> + 68_H

Initial Value 00_H

7	6	5	4	3	2	1	0
-	-	-	-	RDT 03	RDT 02	RDT 01	RDT 00
W	W	W	W	W	W	W	W

Table 15-74 TAUJnRDT register contents

Bit position	Bit name	Function
3 to 0	RDTm	Triggers the simultaneous rewrite pending state: 0: No function 1: Simultaneous rewrite pending state is triggered. The simultaneous rewrite pending flag (TAUJnRSFm) is set to 1. The system waits for the simultaneous rewrite trigger. TAUJnRDT.RDTm immediately returns to 0.

(4) TAUJnRSF - TAUJn channel reload status register

This flag register indicates that simultaneous rewrite is possible.

Access This register can be read in 8-bit units.

Address <TAUJn_base> + 6C_H

Initial Value 00_H

7	6	5	4	3	2	1	0
-	-	-	-	RSF 03	RSF 02	RSF 01	RSF 00
R	R	R	R	R	R	R	R

Table 15-75 TAUJnRSF register contents

Bit position	Bit name	Function
3 to 0	RSFm	Indicates the simultaneous rewrite status: 0: Simultaneous rewrite disabled 1: Simultaneous rewrite enabled

15.18.6 TAUJn emulation register

(1) TAUJnEMU - TAUJ emulation register

This register controls whether the TAUJn can be stopped during emulation, for instance upon a breakpoint hit.

Access This register can be read/written in 8-bit units.

Address <TAUJn_base> + A8_H

Initial Value 00_H

	7	6	5	4	3	2	1	0
TAUJn SVSDIS	0	0	0	0	0	0	0	0
	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 15-76 TAUJnEMU register contents

Bit position	Bit name	Function
7	TAUJn SVSDIS	Emulation control 0: TAUJn can be stopped during emulation 1: TAUJn continuous operating during emulation

Chapter 16 Asynchronous Serial Interface E (URTE)

This chapter contains a generic description of the Asynchronous Serial Interface E.

The first section describes all properties specific to the V850E2/Fx4-G, such as instances, register base addresses, input/output signal names, etc. The subsequent sections describe the features that apply to all implementations.

16.1 V850E2/Fx4-G URTE_n Features

Instances This microcontroller has the following number of instances of the Asynchronous Serial Interface E URTE_n.

Table 16-1 Instances of URTE

Asynchronous Serial Interface E	V850E2/FF4-G	V850E2/FG4-G
Instance	2	3
Name	URTE10, URTE11	URTE2, URTE10, URTE11

Instances index n Throughout this chapter, the instance of an Asynchronous Serial Interface E is identified by the index "n" (n = 2, 10, 11), for example, URTE_nCTL0 for the URTE_n control register 0.

Register addresses All URTE_n register addresses are given as address offsets to the individual base address <URTE_n_base>. The <URTE_n_base> address of each URTE_n are listed in the following table:

Table 16-2 Register base addresses <URTE_n_base>

URTE _n instance	<URTE _n _base> address
URTE2	FF5E 0000 _H
URTE10	FF66 0000 _H
URTE11	FF67 0000 _H

Clock supply All Asynchronous Serial Interface E provide one clock input.

Table 16-3 URTE_n clock supply

URTE _n instance	URTE _n clock	Connected to
URTE2	PCLK	Clock Controller CKSCLK_034
URTE10	PCLK	Clock Controller CKSCLK_011
URTE11	PCLK	Clock Controller CKSCLK_011




Figure 16-1 URTE clock supply

Interrupts The Asynchronous Serial Interface E can generate following interrupts requests, which are input to their respective LIN Master Controllers LMA_n:

Table 16-4 URTE_n interrupts requests

URTE _n signals	Function	Connected to
INTUAEnTIT	Transmission interrupt	LMA _n INTUAEnIT
INTUAEnTIR	Reception interrupt	LMA _n INTUAEnIR
INTUAEnTIS	Status interrupt	LMA _n INTUAEnIS

URTE H/W reset The Asynchronous Serial Interfaces E and their registers are initialized by the following reset signal:

Table 16-5 URTE_n reset signal

URTE _n	Reset signal
URTE _n	<ul style="list-style-type: none"> Reset Controller SYSRES Stand-by Controller DPSTPWU (wake-up from DEEPSTOP mode)

I/O signals The I/O signals of the Asynchronous Serial Interface E are listed in the table below.

Table 16-6 URTE_n I/O signals

URTE _n signals	Function	Connected to
URTE _n TTXD	Transmit data output	Port URTE _n TX
URTE _n TRXD	Receive data input	Port URTE _n RX ^a

^{a)} These input signals are passed through a noise filter, refer to the section "Port Filters" in the chapter "Port Functions".

Baudrate measurement Following URTE_n receive data signals can be internally connected to a capture input of the Timer Array Units B.

Table 16-7 URTE_n timer connections

URTE _n signals	Function	Connected to
URTE2:		
Port URTE2RX	Receive data input	TAUB0 TAUB0TTIN2
URTE10:		
Port URTE10RX	Receive data input	TAUB0 TAUB0TTIN0
URTE11:		
Port URTE11RX	Receive data input	TAUB0 TAUB0TTIN1

Refer to section "TAUB Input Selections" in the "Timer Array Unit B (TAUB)" for details.

16.2 Functional Overview

- Full-duplex communication:
 - Internal URTE_n receive data register n (URTE_nRX)
 - Internal URTE_n transmit data register n (URTE_nTX)
- 2-pin configuration:
 - URTE_nTTXD: Transmit data output pin
 - URTE_nTRXD: Receive data input pin
- Reception error and status output function
 - Parity error
 - Framing error
 - Overrun error
 - Data consistency error
 - BF receive error
- Interrupt sources: 3
 - Transmission interrupt INTUA_nTIT
 - Reception interrupt INTUA_nTIR
 - Status interrupt INTUA_nTIS
- Character length: 7, 8 bits
- Parity function: odd, even, 0, none
- Transmission stop bit: 1, 2 bits
- MSB-/LSB-first transfer selectable
- Transmit/receive data inverted input/output possible
- 13 to 20 bits selectable for the BF (Break Field) in the LIN (Local Interconnect Network) communication format
 - Recognition of 11 bits or more possible for BF reception in LIN communication format
 - BF reception flag provided
- BF reception can be detected during data communication
- Bus monitor function to keep data consistency of the transmit data

16.3 Configuration




Figure 16-2 Block diagram of Asynchronous Serial Interface URTE

16.4 URTE Registers

The URTE is controlled and operated by means of the following registers:

Table 16-8 URTE_n registers

Register function	Name	Address
Control register 0	URTE _n CTL0	<URTE _n _base> + 00 _H
Control register 1	URTE _n CTL1	<URTE _n _base> + 20 _H
Control register 2	URTE _n CTL2	<URTE _n _base> + 24 _H
Trigger register	URTE _n TRG	<URTE _n _base> + 04 _H
Status register 0	URTE _n STR0	<URTE _n _base> + 08 _H
Status register 1	URTE _n STR1	<URTE _n _base> + 0C _H
Status clear register	URTE _n STC	<URTE _n _base> + 10 _H
Receive data register	URTE _n RX	<URTE _n _base> + 14 _H
Transmit data register	URTE _n TX	<URTE _n _base> + 18 _H
Emulation register	URTE _n EMU	<URTE _n _base> + 34 _H

<URTE_n_base> The base addresses <URTE_n_base> of the URTE_n are defined in the first section of this chapter under the key word “Register addresses”.

Register access All registers are accessible in 32-bit width. Writing to non-existing register bits is ignored, reading of these bits return always 0.

(1) URTECTL0 - URTE control register 0

This register controls the URTE basic serial transfer operation.

Access This register can be read/written in 8-bit units.

Address <URTE_base> + 00_H

Initial Value 00_H

7	6	5	4	3	2	1	0
URTE PW	URTE TXE	URTE RXE	0	0	0	0	URTE SLDC
R/W	R/W	R/W	R	R	R	R	R/W

Table 16-9 URTECTL0 register contents

Bit position	Bit name	Function
7	URTE PW	URTE enable 0: Stop URTE operation 1: Enable URTE operation Changing this bit initializes all transmission and reception units.
6	URTE TXE	Transmission operation enable 0: Disable transmission operation 1: Enable transmission operation <ul style="list-style-type: none"> To start transmission, set URTEPW to 1 and then set URTETXE to 1. To stop transmission clear URTETXE to 0 and then URTEPW to 0. To initialize the transmission unit, clear URTETXE to 0, wait for two cycles of the base clock, and then set URTETXE to 1 again.
5	URTE RXE	Reception operation enable 0: Disable reception operation 1: Enable reception operation <ul style="list-style-type: none"> To enable reception, set URTEPW to 1 and then set URTERXE to 1. To disable reception clear URTERXE to 0 and then URTEPW to 0. To initialize the reception unit, clear URTERXE to 0, wait for two periods of the base clock, and then set URTERXE to 1 again. The reception is enabled after URTERXE is set to 1 and two cycles of base clock have passed. The rising edge detection of the RXDD pin is enabled after URTERXE is set to 1 and four cycles of the base clock have passed.
0	URTE SLDC	Data consistency check enable 0: Disable data consistency check 1: Enable data consistency check This bit selects the handling of data consistency error checks when transmitting data. When this bit is set to 1, the transmit data and receive data are compared, and if a mismatch is detected, URTESTR1.URTEDCE is set to 1 and a status interrupt request INTUAENTIS is issued. This bit is accessed only when starting a transmission. Consequently, if this bit value is changed later on during transmission processing, the transmission processing continues to use the value set at the start of processing.

- Cautions**
- In case URTE is in the status of
 - enabled reception and transmission (URTECTL0 bits URTEPW = 1 & URTERXE & URTETXE = 1) and
 - data consistency check is enabled (URTECTL0.URTESLDC = 1) and
 - transmission is ongoing or is completed

transmission shall be disabled, while keeping reception enabled, proceed as follows:

- check that no transmission is pending (URTESTR0 bits URTESSBT = URTESSST = 0) and
- check that no reception is ongoing (URTESTR0 bits URTESSBR = URTESSSR = 0) then
- disable transmission by URTECTL0.URTECTXE = 0.

The reason for this procedure is that the data consistency error flag URTESTR1.URTEDCE is cleared to 0 by URTECTL0.URTECTXE. Thus a potential data consistency error would not be reported, if transmission is disabled during a data transfer or after its completion.

2. In case URTE is in the status of

- enabled reception and transmission (URTECTL0 bits URTEPW = 1 & URTERXE & URTECTXE = 1) and
- data consistency check is enabled (URTECTL0.URTESLDC = 1) and
- transmission is ongoing or is completed

reception shall be disabled, while keeping transmission enabled, proceed as follows:

- check that no transmission is pending (URTESTR0 bits URTESSBT = URTESSST = 0) and
- check that no reception is ongoing (URTESTR0 bits URTESSBR = URTESSSR = 0) then
- disable reception by URTECTL0.URTERXE = 0.

The reason for this procedure is that the data consistency error flag URTESTR1.URTEDCE is invalid URTECTL0.URTECTXE is cleared. Thus a potential data consistency error of already transmitted data would not be reported.

3. Don't start any data transmission if

- data consistency check is enabled (URTECTL0.URTESLDC = 1) and
- BF reception is enabled (URTESTR0.URTESSBR = 1) and
- detection of a BF during reception is not active (URTECTL1.URTESLBM = 0)

A data consistency error will occur under above conditions when the BF reception is completed. The status interrupt INTUAEINTIS will be asserted and the BF reception completion will not be indicated (URTESTR1.URTEBSF remains 0). Consequently the BF reception completion will not be recognized.

(2) URTE_nCTL1 - URTE_n control register 1

This register defines the data frame properties of the URTE_n serial data transfers.

Access This register can be read/written in 16-bit units.

Address <URTE_n_base> + 20_H

Initial Value 5002_H

15	14	13	12	11	10	9	8
URTE _n SLBM	URTE _n BLG[2:0]			0	0	0	URTE _n CLG
R/W	R/W	R/W	R/W	R	R	R	R/W
7	6	5	4	3	2	1	0
URTE _n SLP[1:0]		URTE _n TDL	URTE _n RDL	0	URTE _n SLG	URTE _n SLD	URTE _n SLIT
R/W		R/W	R/W	R	R/W	R/W	R/W

Table 16-10 URTE_nCTL1 register contents (1/3)

Bit position	Bit name	Function																																				
15	URTE _n SLBM	BF receive mode selection 0: BF reception during data reception disabled. 1: BF reception during data reception enabled. <ul style="list-style-type: none"> When this bit is set to 1, data reception processing uses a character bit length of 8 bits and no parity bit, regardless of the values set to the URTE_nCLG and URTE_nSLP[1:0]. Changing this bit is only allowed, if reception is disabled (URTE_nCTL0.URTE_nPW = 0 or URTE_nCTL0.URTE_nRXE = 0). 																																				
14 to 12	URTE _n BLG[2:0]	BF bit length during transmission <table border="1"> <thead> <tr> <th>URTE_nBLG2</th><th>URTE_nBLG1</th><th>URTE_nBLG0</th><th>BF length</th></tr> </thead> <tbody> <tr><td>1</td><td>0</td><td>1</td><td>13 bits</td></tr> <tr><td>1</td><td>1</td><td>0</td><td>14 bits</td></tr> <tr><td>1</td><td>1</td><td>1</td><td>15 bits</td></tr> <tr><td>0</td><td>0</td><td>0</td><td>16 bits</td></tr> <tr><td>0</td><td>0</td><td>1</td><td>17 bits</td></tr> <tr><td>0</td><td>1</td><td>0</td><td>18 bits</td></tr> <tr><td>0</td><td>1</td><td>1</td><td>19 bits</td></tr> <tr><td>1</td><td>0</td><td>0</td><td>20 bits</td></tr> </tbody> </table> <p>Changing these bits is only allowed, if transmission is disabled (URTE_nCTL0.URTE_nPW = 0 or URTE_nCTL0.URTE_nTXE = 0).</p>	URTE _n BLG2	URTE _n BLG1	URTE _n BLG0	BF length	1	0	1	13 bits	1	1	0	14 bits	1	1	1	15 bits	0	0	0	16 bits	0	0	1	17 bits	0	1	0	18 bits	0	1	1	19 bits	1	0	0	20 bits
URTE _n BLG2	URTE _n BLG1	URTE _n BLG0	BF length																																			
1	0	1	13 bits																																			
1	1	0	14 bits																																			
1	1	1	15 bits																																			
0	0	0	16 bits																																			
0	0	1	17 bits																																			
0	1	0	18 bits																																			
0	1	1	19 bits																																			
1	0	0	20 bits																																			
8	URTE _n CLG	Receive/transmit data bit length 0: 7 bits 1: 8 bits <ul style="list-style-type: none"> When the transmission/reception is performed in the LIN format, set URTE_nCLG to 1. Changing this bit is only allowed, if reception and transmission is disabled (URTE_nCTL0.URTE_nPW = 0 or URTE_nCTL0.URTE_nRXE = URTE_nCTL0.URTE_nTXE = 0). 																																				

Table 16-10 URTECTL1 register contents (2/3)

Bit position	Bit name	Function																						
7 to 6	URTE _n SLP[1:0]	Parity bit selection <table border="1" data-bbox="552 331 1375 734"> <thead> <tr> <th rowspan="2">URTE_n SLP1</th> <th rowspan="2">URTE_n SLP0</th> <th colspan="2">Operation</th> </tr> <tr> <th>Transmission</th> <th>Reception</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Output without parity bit</td> <td>Received with no parity</td> </tr> <tr> <td>0</td> <td>1</td> <td>Output with space parity (0-fixed)</td> <td>No parity judgment</td> </tr> <tr> <td>1</td> <td>0</td> <td>Output with odd parity</td> <td>Judged as odd parity</td> </tr> <tr> <td>1</td> <td>1</td> <td>Output with even parity</td> <td>Judged as even parity</td> </tr> </tbody> </table> <ul style="list-style-type: none"> If "Reception with no parity judgment" is selected during reception, a parity check is not performed. Therefore, since the URTE_nSTR1.URTE_nPE bit is not set, no error interrupt is output. When the transmission/reception is performed in the LIN format, set URTE_nSLP[1:0] to 00_B. Changing these bits is only allowed, if reception and transmission is disabled (URTE_nCTL0.URTE_nPW = 0 or URTE_nCTL0.URTE_nRXE = URTE_nCTL0.URTE_nTXE = 0). 	URTE _n SLP1	URTE _n SLP0	Operation		Transmission	Reception	0	0	Output without parity bit	Received with no parity	0	1	Output with space parity (0-fixed)	No parity judgment	1	0	Output with odd parity	Judged as odd parity	1	1	Output with even parity	Judged as even parity
URTE _n SLP1	URTE _n SLP0	Operation																						
		Transmission	Reception																					
0	0	Output without parity bit	Received with no parity																					
0	1	Output with space parity (0-fixed)	No parity judgment																					
1	0	Output with odd parity	Judged as odd parity																					
1	1	Output with even parity	Judged as even parity																					
5	URTE _n TDL	Transmission data level control <ul style="list-style-type: none"> 0 No inverted output of transmit data 1 Inverted output of transmit data <ul style="list-style-type: none"> The output level of the URTE_nTTXD pin can be inverted using this bit. It inverts the URTE_nTTXD output level immediately, regardless of the values of URTE_nCTL0.URTE_nPW and URTE_nCTL0.URTE_nTXE. Therefore, if URTE_nTDL is set to 1 while the operation is disabled, the URTE_nTTXD outputs low level. Changing this bit is only allowed, if transmission is disabled (URTE_nCTL0.URTE_nPW = 0 or URTE_nCTL0.URTE_nTXE = 0). 																						
4	URTE _n RDL	Reception data level control <ul style="list-style-type: none"> 0 No inverted output of receive data 1 Inverted output of receive data <ul style="list-style-type: none"> The output level of the URTE_nTRXD pin can be inverted using this bit. It inverts the URTE_nTRXD input level immediately, regardless of the values of URTE_nCTL0.URTE_nPW and URTE_nCTL0.URTE_nRXE. Therefore, if URTE_nRDL is set to 1 while the operation is disabled, the URTE_nTRXD inputs low level. Changing this bit is only allowed, if reception is disabled (URTE_nCTL0.URTE_nPW = 0 or URTE_nCTL0.URTE_nRXE = 0). 																						

Table 16-10 URTEnCTL1 register contents (3/3)

Bit position	Bit name	Function
2	URTEnSLG	<p>Stop bit number selection for transmission data</p> <p>0 1 bit 1 2 bits</p> <ul style="list-style-type: none"> The stop bit length during data or BF reception is always handled as "1". Changing this bit is only allowed, if transmission is disabled (URTEnCTL0.URTEnPW = 0 or URTEnCTL0.URTEnTXE = 0).
1	URTEnSLD	<p>Transfer direction selection</p> <p>0 MSB-first transfer 1 LSB-first transfer</p> <ul style="list-style-type: none"> The stop bit length during data or BF reception is always handled as "1". When the transmission/reception is performed in the LIN format, set URTEnSLD to 1. Changing this bit is only allowed, if reception and transmission is disabled (URTEnCTL0.URTEnPW = 0 or URTEnCTL0.URTEnRXE = URTEnCTL0.URTEnTXE = 0).
0	URTEnSLIT	<p>Transmission interrupt request (INTUAEnTIT) timing selection</p> <p>0 INTUAEnTIT generated at the start of transmission, i.e. when the transmit data is stored to the transmission shift register 1 INTUAEnTIT generated at transmission completion</p> <ul style="list-style-type: none"> Changing this bit is only allowed, if transmission is disabled (URTEnCTL0.URTEnPW = 0 or URTEnCTL0.URTEnTXE = 0).

(3) URTE_nCTL2 - URTE_n control register 2

This register defines the baud rates of the URTE_n serial data transfers.

Access This register can be read/written in 16-bit units.

Address <URTE_n_base> + 24_H

Initial Value EFFF_H

15	14	13	12	11	10	9	8
URTE _n PRS[2:0]			0	URTE _n BRS[11:8]			
R/W	R/W	R/W	R	R/W	R/W	R/W	R/W
7	6	5	4	3	2	1	0
URTE _n BRS[7:0]							
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 16-11 URTE_nCTL2 register contents

Bit position	Bit name	Function																						
15 to 13	URTE _n PRS[2:0]	Prescaler clock (PRCLK) division value 0: PRCLK = PCLK / 2 ⁰ 1: PRCLK = PCLK / 2 ¹ 2: PRCLK = PCLK / 2 ² 3: PRCLK = PCLK / 2 ³ 4: PRCLK = PCLK / 2 ⁴ 5: PRCLK = PCLK / 2 ⁵ 6: PRCLK = PCLK / 2 ⁶ 7: PRCLK = PCLK / 2 ⁷																						
11 to 0	URTE _n BRS[11:0]	Baudrate clock (BRCLK) division value (PRCLK = PCLK / 2 ^{URTE_nPRS[2:0]}): <table border="1" data-bbox="550 1153 1372 1635"> <thead> <tr> <th>URTE_nBRS[11:0]</th><th>Transmit/receive BRCLK</th><th>BF receive clock</th></tr> </thead> <tbody> <tr> <td>000_H</td><td rowspan="5">PRCLK / (2 x 4)</td><td rowspan="5">PRCLK / 4</td></tr> <tr><td>001_H</td></tr> <tr><td>002_H</td></tr> <tr><td>003_H</td></tr> <tr><td>004_H</td></tr> <tr> <td>005_H</td><td>PRCLK / (2 x 5)</td><td>PRCLK / 5</td></tr> <tr> <td>...</td><td>PRCLK / (2 x URTE_nBRS[11:0])</td><td>PRCLK / URTE_nBRS[11:0]</td></tr> <tr> <td>FFE_H</td><td>PRCLK / (2 x 4094)</td><td>PRCLK / 4094</td></tr> <tr> <td>FFF_H</td><td>PRCLK / (2 x 4095)</td><td>PRCLK / 4095</td></tr> </tbody> </table>	URTE _n BRS[11:0]	Transmit/receive BRCLK	BF receive clock	000 _H	PRCLK / (2 x 4)	PRCLK / 4	001 _H	002 _H	003 _H	004 _H	005 _H	PRCLK / (2 x 5)	PRCLK / 5	...	PRCLK / (2 x URTE _n BRS[11:0])	PRCLK / URTE _n BRS[11:0]	FFE _H	PRCLK / (2 x 4094)	PRCLK / 4094	FFF _H	PRCLK / (2 x 4095)	PRCLK / 4095
URTE _n BRS[11:0]	Transmit/receive BRCLK	BF receive clock																						
000 _H	PRCLK / (2 x 4)	PRCLK / 4																						
001 _H																								
002 _H																								
003 _H																								
004 _H																								
005 _H	PRCLK / (2 x 5)	PRCLK / 5																						
...	PRCLK / (2 x URTE _n BRS[11:0])	PRCLK / URTE _n BRS[11:0]																						
FFE _H	PRCLK / (2 x 4094)	PRCLK / 4094																						
FFF _H	PRCLK / (2 x 4095)	PRCLK / 4095																						

Caution Writing to this register is only allowed if the operation of URTE_n is disabled (URTE_nCTL0.URTE_nPW = 0).

PCLK The value of the URTE_n input clock is defined in the first section of this chapter under the key word "Clock supply".

(4) URTE_nTRG - URTE_n trigger register

This register controls the URTE_n transmission/reception trigger of BF.

Access This register can be read/written in 8-bit units.

Address <URTE_n_base> + 04_H

Initial Value 0000_H

7	6	5	4	3	2	1	0
0	URTE _n BRT	URTE _n BTT	0	0	0	0	0
R	R/W	R/W	R	R	R	R	R

Table 16-12 URTE_nTRG register contents (1/2)

Bit position	Bit name	Function
6	URTE _n BRT	<p>BF reception trigger</p> <p>0: read value is always 0, writing 0 is ignored</p> <p>1: Enable BF reception</p> <ul style="list-style-type: none"> When reception is enabled, writing 1 to this bit enables BF reception (URTE_nSTR0.URTE_nSSBR = 1) and BF reception processing begins when the falling edge of the receive serial signal is detected. If 1 is written to this bit during reception processing, the current reception processing is terminated. Consequently, the received data is not stored, the framing, parity and overflow error bits are not updated based on the data that was being received and no interrupts are generated. Meanwhile, the BF counter value is continuously being used. After BF reception, the reception status is set according to the URTE_nCTL1.URTE_nSLBM setting. Setting this bit to 1 is only allowed, if reception is enabled (URTE_nCTL0.URTE_nPW = URTE_nCTL0.URTE_nRXE = 1). <p>After URTE_nBRT is set to 1, completion of BF reception is reported by either of the following two methods, based on the URTE_nCTL1.URTE_nSLBM setting:</p> <ul style="list-style-type: none"> if URTE_nCTL1.URTE_nSLBM = 0 When BF reception is complete, a reception interrupt request INTUAEnTIR is output. URTE_nCTL1.URTE_nSLBM When BF reception is complete, URTE_nSTR1.URTE_nBSF is set to 1 and a status interrupt request INTUAEnTIS is output.

Table 16-12 URTEnTRG register contents (2/2)

Bit position	Bit name	Function
5	URTEnBTT	<p>BF transmission trigger</p> <p>0: read value is always 0, writing 0 is ignored</p> <p>1: Triggers BF transmission</p> <ul style="list-style-type: none"> • When 1 is written to this bit while URTEnSTR0.URTEnSSBT = 0 and (URTETDCM = "H" or URTE0DCE = 0) transmission is enabled, a BF transmit request is set, and URTEnSSBT is set to 1. • When 1 is written to this bit during a data transmission, a BF is transmitted after the current transmission processing is completed. Even if 1 is written to this bit before the BF transmission is completed, a BF is transmitted only once. • When transmission is enabled (URTE0PW = URTE0TXE = 1), writing 1 to this bit clears all previously set data transmit requests (which have not been transmitted), leaving only BF transmit requests. If a write operation occurs in the URTE0TX7 to URTE0TX0 bits after writing 1 to this bit, data is transmitted after the BF is transmitted. • If both a BF transmit request and a data transmit request have been set when a transmission starts, the BF transmission takes priority. • When URTE0DCE = 1 and URTETDCM = "L", writing 1 to this bit is ignored. • When reception is enabled (URTEnCTL0.URTEnPW = URTEnCTL0.URTEnRXE = 1), writing 1 to this bit enables BF reception (URTEnSTR0.URTEnSSBR = 1) and BF reception processing begins when the falling edge of the receive serial signal is detected. • If 1 is written to this bit during reception processing, the current reception processing is terminated. Consequently, the received data is not stored, the framing, parity and overflow errors bits are not updated based on the data that was being received and no interrupts are generated. Meanwhile, the BF counter value is continuously being used. • After BF reception, the reception status is set according to the URTEnCTL1.URTEnSLBM setting. • When transmitting a BF while reception is enabled (URTEnCTL0 bits URTEnPW = URTEnRXE = 1) and BF shall not be detected during reception (URTEnCTL1.URTEnSLBM = 0), write 1 to URTEnBTT after 1 is written to URTEnBRT, then transmit the BF. If URTEnBTT is set to 1 first, a framing error may occur. • Setting this bit to 1 is only allowed, if transmission is enabled (URTEnCTL0.URTEnPW = URTEnCTL0.URTEnTXE = 1).

(5) URTE_nSTR0 - URTE_n status register 0

This register indicates the current status of serial data transmissions.

Access This register can be read in 8-bit units.
In case the URTE_n operation is disabled (URTE_nCTL0.URTE_nPW = 0), this register can also be written. If the URTE_n is enabled (URTE_nCTL0.URTE_nPW = 1), any written values are disregarded and the register takes on its initial value.

Address <URTE_n_base> + 08_H

Initial Value 0000_H. This register is initialized by any reset and when URTE_n operation is disabled by URTE_nCTL0.URTE_nPW = 0..

7	6	5	4	3	2	1	0
0	URTE _n SSBR ^a	URTE _n SSBT ^b	0	0	0	URTE _n SSR ^b	URTE _n SST ^b
R	R	R	R	R	R	R	R

- a) This bit is also initialized if reception is disabled by URTE_nCTL0.URTE_nRXE = 0.
b) These bits are also initialized if transmission is disabled by URTE_nCTL0.URTE_nTXE = 0.

Table 16-13 URTE_nSTR0 register contents

Bit position	Bit name	Function
6	URTE _n SSBR	BF reception enable status 0: BF reception disabled 1: BF reception has been enabled by setting URTE _n TRG.URTE _n BRT to 1 (BF reception standby mode or BF reception busy).
5	URTE _n SSBT	BF transmission enable status 0: BF transmission disabled 1: BF transmission has been enabled by setting URTE _n TRG.URTE _n BTT to 1 (BF transmission standby mode or BF transmission busy).
1	URTE _n SSR	Data reception status 0: no data reception ongoing 1: data reception ongoing (data reception busy)
0	URTE _n SST	Data transmission status 0: no transmission pending or ongoing 1: data in URTE _n TX[7:0] pending to be transmitted or transmission ongoing

(6) URTE_nSTR1 - URTE_n status register 1

This register indicates results of serial data transmissions.

Access This register can be read in 8-bit units.
In case the URTE_n operation is disabled (URTE_nCTL0.URTE_nPW = 0), this register can also be written. If the URTE_n is enabled (URTE_nCTL0.URTE_nPW = 1), any written values are disregarded and the register takes on its initial value.

Address <URTE_n_base> + 0C_H

Initial Value 0000_H. This register is initialized by any reset and when URTE_n operation is disabled by URTE_nCTL0.URTE_nPW = 0..

7	6	5	4	3	2	1	0
0	0	0	URTE _n BSF ^a	URTE _n DCE ^b	URTE _n PE ^a	URTE _n FE ^a	URTE _n OVE ^a
R	R	R	R	R	R	R	R

- a) These bits are also initialized if reception is disabled by URTE_nCTL0.URTE_nRXE = 0.
b) This bit is also initialized if transmission is disabled by URTE_nCTL0.URTE_nTXE = 0.

Table 16-14 URTE_nSTR1 register contents (1/2)

Bit position	Bit name	Function
4	URTE _n BSF	BF reception successful flag 0: no valid BF frame received 1: BF reception completed successfully When the BF receive mode selection bit is set in LIN communication mode, it is necessary to read this bit by the status interrupt processing and to confirm the beginning of a new frame slot. URTE _n BSF is cleared by <ul style="list-style-type: none"> • URTE_nCTL0.URTE_nPW = 1 • URTE_nCTL0.URTE_nRXE = 0 • URTE_nCTL1.URTE_nSLBM = 0 • URTE_nSTC.URTE_nCLBS = 1
3	URTE _n DCE	Data consistency error flag 0: no data consistency check error detected 1: data consistency check error detected URTE _n DCE is cleared by <ul style="list-style-type: none"> • URTE_nCTL0.URTE_nPW = 0 • URTE_nCTL0.URTE_nTXE = 0 • URTE_nCTL1.URTE_nSLDC = 0 • URTE_nSTC.URTE_nCLDC = 1
2	URTE _n PE	Parity error flag 0: no parity error in received data detected 1: parity error in received data detected The operation of URTE _n PE is controlled by the settings of the URTE _n .URTE _n SLP[1:0]. URTE _n PE is cleared by <ul style="list-style-type: none"> • URTE_nCTL0.URTE_nPW = 0 • URTE_nCTL0.URTE_nRXE = 0 • URTE_nSTC.URTE_nCLP = 1

Table 16-14 URTEnSTR1 register contents (2/2)

Bit position	Bit name	Function
1	URTEnFE	Framing error flag 0: cleared by - URTEnCTL0.URTEPW = 0 - URTEnCTL0.URTERXE = 0 - URTEnSTC.URTEnCLF = 1 1: framing error in received data detected
0	URTEnOVE	Overrun error flag 0: cleared by - URTEnCTL0.URTEPW = 0 - URTEnCTL0.URTERXE = 0 - URTEnSTC.URTEnCLOV = 1 1: overrun error in received data detected When an overrun error occurs, the data is discarded without the next receive data being written to the receive data register URTEnRX.

Note If the bits of these registers are set (1) and cleared (0) at the same time, setting takes priority over clearing.

For further information concerning error detections, refer to the sections “Transmission data consistency check” and “Reception errors”.

Caution In case reception and transmission is enabled and a data consistency check error occurs (URTEnSTR1.URTEnDCE = 1), follow the procedure below prior next data transmission:

- disable transmission by URTEnCTL0.URTEnTXE = 0
- initiate a transmission by URTEnTRG.URTEnBTT = 1 (BT transmission trigger) or writing any data to URTEnTX
- enable transmission by URTEnCTL0.URTEnTXE = 1

Afterwards new transmissions can be started.

(7) URTE_nSTC - URTE_n status clear register

This register is used to clear the status bits of the status register 1 URTE_nSTR1.

Access This register can be read/written in 8-bit units.
Reading this register returns always 00_H.

Address <URTE_n_base> +10_H

Initial Value 0000_H.

7	6	5	4	3	2	1	0
0	0	0	URTE _n CLBS	URTE _n CLDC	URTE _n CLP	URTE _n CLF	URTE _n CLOV
R	R	R	R/W	R/W	R/W	R/W	R/W

Table 16-15 URTE_nSTC register contents

Bit position	Bit name	Function
4	URTE _n CLBS	Clear BF reception successful flag 0: writing 0 is ignored 1: writing 1 clears URTE _n STR1.URTE _n BSF
3	URTE _n CLDC	Clear data consistency error flag 0: writing 0 is ignored 1: writing 1 clears URTE _n STR1.URTE _n DCE In case URTE _n DCE will be cleared by setting URTE _n CLDC = 1, any pending data or BF transmit requests will be ignored.
2	URTE _n CLP	Clear parity error flag 0: writing 0 is ignored 1: writing 1 clears URTE _n STR1.URTE _n PE
1	URTE _n CLF	Clear framing error flag 0: writing 0 is ignored 1: writing 1 clears URTE _n STR1.URTE _n FE
0	URTE _n CLOV	Clear overrun error flag 0: writing 0 is ignored 1: writing 1 clears URTE _n STR1.URTE _n OVE

(8) URTE_nRX - URTE_n receive data register

This register stores received data.

The data stored in the receive shift register is transferred to URTE_nRX upon completion of reception of 1 byte of data.

7-bit transfers If the data length has been specified as 7 bits (URTE_nCTL1.URTE_nCLG = 0) and

- LSB-first reception (URTE_nCTL1.URTE_nSLD = 1), the receive data is transferred to URTE_nRX[6:0] and the MSB URTE_nRX[7] always becomes 0.
- MSB-first reception (URTE_nCTL1.URTE_nSLD = 0), the receive data is transferred to URTE_nRX[7:1] and the LSB URTE_nRX[0] always becomes 0.

For further information on data formats, refer to the section “Data formats”.

Overflow error When an overflow error (URTE_nSTR1.URTE_nOVE = 1) occurs, the receive data at this time is not transferred to URTE_nRX and is discarded.

When reception processing ends and data reception is confirmed without any overflow errors, the received data is stored to URTE_nRX according to the specified storage format.

Access

This register can be read in 8-bit units.

In case the URTE_n operation is disabled (URTE_nCTL0.URTE_nPW = 0), this register can also be written. If the URTE_n is enabled (URTE_nCTL0.URTE_nPW = 1), any written values are disregarded and the register takes on its initial value.

Access This register can be read in 8-bit units.

Address <URTE_n_base> + 14_H

Initial Value FF_H. This register is initialized by any reset and when URTE_n operation is enabled by URTE_nCTL0.URTE_nPW = 1.




Table 16-16 URTE_nRx register contents

Bit position	Bit name	Function
7 to 0	URTE _n RX[7:0]	URTE _n receive data

(9) URTE_nTX - URTE_n transmit data register

This register is used to stores data to be transmitted.

Transmit data in URTE_nTX is stored to the transmission shift register URTE_nTXS according to the specified transmit data format.

7-bit transfers If the data length has been specified as 7 bits (URTE_nCTL1.URTE_nCLG = 0) and

- LSB-first transmission (URTE_nCTL1.URTE_nSLD = 1), URTE_nTX[6:0] with MSB URTE_nTX[7] always “0” is transferred to the shift register URTE_nTXS.
- MSB-first reception (URTE_nCTL1.URTE_nSLD = 0), URTE_nTX[7:1] with LSB URTE_nTX[0] always “0” is transferred to the shift register URTE_nTXS.

For further information on data formats, refer to the section “Data formats”.

Access This register can be read/written in 8-bit units.

Address <URTE_n_base> + 18_H

Initial Value FF_H




Table 16-17 URTE_nTx register contents

Bit position	Bit name	Function
7 to 0	URTE _n TX[7:0]	URTE _n transmit data

When transmission is enabled (URTE_nCTL0 bits URTE_nPW = URTE_nTXE = 1), a write to URTE_nTX triggers the start of the transmission.

Note If the the next data to URTE_nTX is written before the ongoing transmission is completed, the continuous transmission is enabled.

(10) URTE_nEMU - URTE_n emulation register

This register controls whether the URTE_n can be stopped during emulation, for instance upon a breakpoint hit.

Access This register can be read/written in 8-bit units.

Address <URTE_n_base> + 34_H

Initial Value 0000_H




Table 16-18 URTE_nEMU register contents

Bit position	Bit name	Function
7	URTE _n SVSDIS	Emulation control 0: URTE _n can be stopped during emulation 1: URTE _n continuous operating during emulation

16.5 Interrupt Request Signals

The following four interrupt request signals are generated by URTE_n.

- Transmission interrupt request INTUAEnTIT
- Reception interrupt request INTUAEnTIR
- Status interrupt request INTUAEnTIS

16.5.1 Transmission interrupt request INTUAEnTIT

If transmit data is transferred from the URTE_nTX register to transmit shift register with transmission enabled, the transmission interrupt request INTUAEnTIT is generated.

The condition for generation of a transmit interrupt request depends on the setting of the URTE_nCTL1.URTE_nSLIT:

- at start of transmission process: URTE_nCTL1.URTE_nSLIT = 0

A transmission interrupt request is issued when starting transmission of the first bit (this is the start bit for data transmission or the first BF bit for BF transmission). During data transmission, a transmission interrupt request is issued when transmit data in URTE_nTX is transferred to the transmission shift register.

- at end of transmission process: URTE_nCTL1.URTE_nSLIT = 1

A transmission interrupt request is issued after completing transmission of the last bit (the first bit of the stop bit when the stop bit length is 1, or the second bit of the stop bit when the stop bit length is 2).

Note If a data consistency error is detecting, this interrupt is not generated.

The following diagrams show the timing of the transmission interrupt request for both cases.




Figure 16-3 Transmission interrupt request timing for URTE_nCTL1.URTE_nSLIT = 0




Figure 16-4 Transmission interrupt request timing for URTE_nCTL1.URTE_nSLIT = 1

16.5.2 Reception interrupt request INTUAEnTIR

In case of erroneous reception, the status interrupt INTUAEnTIS is generated instead of INTUAEnTIR.

No reception interrupt request INTUAEnTIR is generated in the reception disabled status.

A reception interrupt request is issued when the first bit of the stop bit is sampled (at the end of reception processing).

The following diagrams show the timing of the reception interrupt request during data/BF reception.




Figure 16-5 Reception interrupt request timing

16.5.3 Status interrupt request INTUAEnTIS

A status interrupt request is generated if an error condition occurred during reception or transmission, as reflected in the status register 1 URTESTR1.

When the BF reception mode selection bit is set in LIN communication mode (URTECTL1.URTEenSLBM = 1), the status interrupt request signal is generated when a consecutive low level (BF) of 11 bits or more is received.

16.6 Operation

16.6.1 Data formats

Full-duplex serial data reception and transmission is performed.

As shown in the figures below, one data frame of transmit/receive data consists of a start bit, character bits, parity bit, and stop bit(s).


Several properties of a transmit/receive data frame can be specified by control bits of the URTECTL1 register:

Table 16-19 Data format specification


Item	Options	Control bits
Start bit	1 bit	fixed
Character bits	7 bits / 8 bits	URTECTL1.URTEenCLG
Parity	Even parity/odd parity/0	URTECTL1.URTEenSLP[1:0]
Stop bit	1 bit / 2 bits	URTECTL1.URTEenSLG
Data order	MSB first / LSB first	URTECTL1.URTEenSLD
Tx data level	inverted / not inverted	URTECTL1.URTEenSLG
Rx data level	inverted / not inverted	URTECTL1.URTEenRLG

(1) URTEen transmit/receive data format


(a) 8-bit data length, LSB first, even parity, 1 stop bit, transfer data: 55_H




- (b) 8-bit data length, MSB first, even parity, 1 stop bit, transfer data: 55_H




- (c) 8-bit data length, MSB first, even parity, 1 stop bit, transfer data: 55_H, URTE_nTTXD inversion



- (d) 7-bit data length, LSB first, odd parity, 2 stop bits, transfer data: 36_H



- (e) 8-bit data length, LSB first, no parity, 1 stop bit, transfer data: 87_H



16.6.2 BF transmission/reception format

The URTE_n has a BF (Break Field) transmission/reception control function to enable use of the LIN function.

About LIN LIN stands for Local Interconnect Network and is a low-speed (1 to 20 kbps) serial communication protocol intended to aid the cost reduction of an automotive network.

LIN communication is single-master communication, and up to 15 slaves can be connected to one master.

The LIN slaves are used to control the switches, actuators, and sensors, and these are connected to the LIN master via the LIN network.

Normally, the LIN master is connected to a network such as CAN (Controller Area Network).

In addition, the LIN bus uses a single-wire method and is connected to the nodes via a transceiver that complies with ISO9141.

In the LIN protocol, the master transmits a frame with baud rate information and the slave receives it and corrects the baud rate error. Therefore, communication is possible when the baud rate error in the slave is $\pm 14\%$ or less.

The *Figure 16-6 “LIN transmission outline”* and *Figure 16-7 “LIN reception outline”* below outline the transmission and reception manipulations of LIN.

(1) LIN transmission outline




Figure 16-6 LIN transmission outline

- Notes**
1. The interval between each field is controlled by software.
 2. BF output is performed by hardware. The output width is the bit length set by URTE_nCTL1.URTE_nBLG[2:0]. If even finer output width adjustments are required, such adjustments can be performed using URTE_nCTLn.URTE_nBRS[11:0].

3. 80_H transfer in the 8-bit mode is substituted for the wakeup signal frame.
4. A transmission enable interrupt INTUAEnTIT is generated at the start of each transmission. INTUAEnTIT is also generated at the start of each BF transmission.

(2) LIN reception outline




Figure 16-7 LIN reception outline

- Notes**
1. The wakeup signal is sent by the port edge detector, URTEEn is enabled, and the BF reception mode is set.
 2. Upon detection of the BF reception of 11 or more bits, normal BF reception end is judged.
Upon detection of BF reception of less than 11 bits, a BF reception error is judged, no interrupt is generated, and the mode returns to the BF reception mode.
 3. When BF reception ends normally and reception mode selection bit URTEEnCTL1.URTEEnSLBM
 - is set to "0"
the reception interrupt INTUAEnTIR is generated
 - is set to "1"
the status interrupt INTUAEnTIS is generated and the BF reception success flag URTEEnSTR1.URTEEnBSF is set.

If the BF reception trigger bit URTEEnTRG.URTEEnBRT = 1, the error detection for the overrun, parity, and framing is not performed during the BF reception. Moreover, the data transfer from the receive shift register URTEEnRXS to the receive data register URTEEnRX is not performed, either. At this time, the URTEEnRX holds the prior value.

4. In order to adjust the baud rate clock properly, the URTE_nTRXD signal needs to be connected to the capture input of a timer. By measuring the time between two URTE_nTRXD edges the transfer rate and the baud rate error can be calculated and the baud rate can be adjusted accordingly via the baud rate setting URTE_nCTL2.URTE_nBRS[11:0].
5. Check-sum field (CSF) distinctions are made by software. URTE_n is initialized following CSF reception, and the processing for setting the BF reception mode again is performed by software. When URTE_nCTL1.URTE_nSLBM = 1, BF reception can be performed automatically without setting to BF reception mode again.

16.6.3 BF transmission

When the URTE_nCTL0 bits URTE_nPW = URTE_nTXE = 1, the transmission enabled status is entered, and BF transmission is started by setting the BF transmission trigger URTE_nTRG.URTE_nBTT = 1.

Thereafter, URTE_nSTR0.URTE_nSSBT is set to "1" and a low level width of 13 to 20 bits, as specified by URTE_nCTL1.URTE_nBLG[2:0], is output. A transmission interrupt INTUA_nEnTIT is generated upon BF

- transmission start, if URTE_nCTL1.URTE_nSLIT = 0
- transmission end, if URTE_nCTL1.URTE_nSLIT = 1.

Following the end of BF transmission, URTE_nSTR0.URTE_nSSBT is automatically cleared. Thereafter, the URTE_n transmission mode is restored.

Transmission is suspended until the data to be transmitted next is written to the URTE_nTX register, or until the BF transmission trigger URTE_nTRG.URTE_nBTT is set to 1 and URTE_nSTR0.URTE_nSSBT changes to 1.




Figure 16-8 BF transmission

16.6.4 BF reception

The reception enabled status is achieved by setting the URTE_nCTL0.URTE_nCTL0.URTE_nPW bit to 1 and then setting the URTE_nCTL0.URTE_nRXE bit to 1.

The BF reception wait status is set by setting the BF reception trigger URTE_nTRG.URTE_nBRT = 1. URTE_nSTR0.URTE_nSSBR is set to 1.

In the BF reception wait status, similarly to the URTE_n reception wait status, the URTE_nTRXD pin is monitored and start bit detection is performed.

Following detection of the low level, reception is started and the internal counter counts up according to the set baud rate.

When a low level is received for minimum 11 bits (valid BF reception), while the BF receiving mode selection bit

- URTE_nCTL1.URTE_nSLBM = 0 (BF Rx during data Rx disabled), the reception interrupt INTUA_nEnTIR is generated.
- URTE_nCTL1.URTE_nSLBM = 1 (BF Rx during data Rx enabled), the status interrupt INTUA_nEnTIS is generated and BF reception success flag URTE_nSTR1.URTE_nBSF is set at the same time

The URTE_nSTR0.URTE_nSSBR bit is automatically cleared and BF reception ends.




Figure 16-9 Normal BF reception (stop bit after more than 10.5 “L” bits)

Error detection for the URTE_nSTR1 error flags URTE_nOVE, URTE_nPE, and URTE_nFE is suppressed and URTE_n communication error detection processing is not performed.

Moreover, the erroneous data is not stored in URTE_nRX, but the initial value FF_H is held.

If the BF width is 10 or fewer bits, reception is terminated as error processing without generating an interrupt, and the BF reception mode is returned. URTE_nSTR0.URTE_nSSBR is not cleared at this time.




Figure 16-10 BF reception error (stop bit within 10.5 “L” bits)

The BF mode can be selected between a single BF receive mode and an any time BF receive mode in by URTE nCTL1.URTE nSLBM. The status of a successful reception of the BF is shown URTE nSTR1.URTE nBSF.

Note URTE nSTR0.URTE nSSBR is set to “1”

- by setting URTE nTRG.URTE nBRT to “1”
- cleared by normal BF reception.

16.6.5 Transmission data consistency check

The URTE_n incorporates a data consistency check function to detect a mismatch between the transmit data written to transmit register URTE_nTX and the data on the bus when the device operates in master mode.

Data consistency check is enabled by URTE_nCTL0.URTE_nSLDC = 1.

The data consistency is checked by comparing the transmit data in the transmit register URTE_nTX and the receive data in the receive register URTE_nRX. In case of a mismatch the data consistency error flag URTE_nSTR1.URTE_nDCE is set and a status interrupt request INTUA_nEnTIS occurs.

The data consistency check of data is not done in reception mode.

The data consistency check of the send data and the input data terminal level is done even if the reception is disabled during sending. In that case also the reception completion interrupt request signal INTUA_nEnTIR, the URTE_nSTR1 status bits URTE_nBSF, URTE_nFE, URTE_nOVE and the status interrupt request signal INTUA_nEnTIS will not be generated as well. Receive data does not need to be read.

Refer to the description of the “URTE_nSTR1 - URTE_n status register 1” for details.




Figure 16-11 Timing example of data consistency error (no BF reception active, i.e. URTE_nSTR0.URTE_nSSBR = 0)

16.6.6 URTE_n transmission

- Transmission start** Set the transmission enabled status by performing the following procedures.
- Specify the baud rate by the URTE_n control register 2 URTE_nCTL2.
 - Specify the transmit parity, data character length, stop bit length, transmit data order, transmission interrupt request timing and output logic level by the URTE_n control register 1 URTE_nCTL1.
 - Enable URTE_n operation and transmission by URTE_nCTL0.URTE_nPW = URTE_nCTL0.URTE_nTXE = 1)

Write of the transmit data to the transmission buffer register URTE_nTX starts transmission. The data which is saved in the URTE_nTX register is transferred to the transmit shift register URTE_nTXS. Then, the start, parity and stop bits are added and the data frame is output serially via URTE_nTTXD.

- Transmission stop** When URTE_nCTL0.URTE_nPW or URTE_nCTL0.URTE_nTXE is set to 0, transmission operations are stopped immediately, even during transmission processing.

- Concurrent BF and data transmission** When a BF transmit request and a data transmit request have both been set, BF transmission takes priority.

- Data consistency check** When URTE_nTETDCM = "L", if a data consistency error is detected, the subsequent data is not transmitted until URTE_n0CLDC = 1, URTE_n0PW = 0, or URTE_n0TXE = 0 is written.

- INTUAEnTIT timing** The time to generate the transmission interrupt INTUAEnTIT depends on the setting of the URTE_nCTL1.URTE_nSLIT bit:

- URTE_nCTL1.URTE_nSLIT = 0
INTUAEnTIT is generated at the start of transmission, i.e. when the data from the data register URTE_nTX is transferred to the transmit shift register URTE_nTXS and transmission is started.
- URTE_nCTL1.URTE_nSLIT = 1
INTUAEnTIT is generated when the entire data transmission process is completed, i.e. when the last bit of the data frame has been transmitted.

Once INTUAEnTIT is generated, the next data can be written to URTE_nTX.




Figure 16-12 Transmission interrupt timing

16.6.7 Continuous transmission procedure

Continuous transmission is achieved by writing the next transmit data to the transmit data register URTEEnTX, while shifting out of the previous data from the transmission shift register URTEEnTXS is ongoing.

Note In order to maintain correct write timing, the transmission interrupt INTUAEiTIT must be generated at the start of each transmission (URTEEnCTL1.URTEEnSLIT = 0).

Caution If the value is written to the URTEEnTX register before the INTUAEiTIT is generated, the transmit data set before is overwritten by the new transmit data.

To initialize the transmission unit, confirm that no transmission is ongoing (URTEEnSTR0 bits URTEEnSSBT = URTEEnSST = 0). If the initialization is performed during an ongoing transmission, the transmission is aborted.




Figure 16-13 Continuous transmission processing flow




Figure 16-14 Continuous transmission operation timing - transmission start




Figure 16-15 Continuous transmission operation timing - transmission end

16.6.8 URTEn reception

Reception start Set the reception enabled status by the following procedure:

- Specify the baud rate by the URTEn control register 2 URTEnCTL2.
- Specify the receive parity, data character length, stop bit length, receive data order and output logic level by the URTEn control register 1 URTEnCTL1.
- Enable URTEn operation and reception by URTEnCTL0.URTEnPW = URTEnCTL0.URTEnRXE = 1).

When the sampling of the input level of the URTEnTRXD pin is performed and the falling edge is detected, the data sampling of the URTEnTRXD input is started. The start bit is recognized if the URTEnTRXD pin is low level after the time of a half bit is passed after the detection of the falling edge (shown in the figure below). After a start bit has been recognized, the receive operation starts, and serial data is stored in the receive shift register according to the set baud rate. When the reception interrupt INTUAEnTIR is asserted upon reception of the stop bit, the data stored in the receive shift register URTEnRXS is written to the receive data register URTEnRX.

Reception stop When URTEnCTL0.URTEnPW or URTEnCTL0.URTEnRXE is set to 0, reception operations are stopped immediately, even during reception processing.

Reception errors If an overrun error occurs (URTEnSTR1.URTEnOVE = 1), the receive data at this time is not transferred to the URTEnRX register and is discarded. Even if a parity error (URTEnSTR1.URTEnPE = 1) or a framing error (URTEnSTR1.URTEnFE = 1) occurs during reception, reception continues until the reception position of the first stop bit, and the reception data is transferred to the URTEnRX. In any case of the reception errors, the status interrupt INTUAEnTIS is

generated after the following reception completion, but not the reception interrupt INTUAEnTIR.

When the receive data order, parity, data character length, and the stop bit length are changed, clear the power bit (URTEEnCTL0.URTEEnPW = 0) or clear both the transmission enabled bit and the reception enabled bit (URTEEnTXE = 0, URTEEnRXE = 0), and then change the setting.




Figure 16-16 URTEEn reception

- Cautions**
1. Be sure to read the URTEEnRX register even when a reception error occurs. If the URTEEnRX register is not read, an overrun error occurs during reception of the next data.
 2. The operation during reception is performed assuming that there is only one stop bit. A second stop bit is ignored.
 3. When reception is completed, read the URTEEnRX register after the reception interrupt INTUAEnTIR has been generated, and clear the URTEEnCTL0.URTEEnPW or URTEEnCTL0.URTEEnRXE bit to 0. If the URTEEnCTL0.URTEEnPW or URTEEnCTL0.URTEEnRXE bit is cleared to 0 before the INTUAEnTIR is generated, the read value of the URTEEnRX register cannot be guaranteed.
 4. If receive completion processing (INTUAEnTIR interrupt generation) and the URTEEnCTL0.URTEEnPW bit = 0 or URTEEnCTL0.URTEEnRXE bit = 0 conflict, INTUAEnTIR may be generated in spite of these being no data stored in the URTEEnRX register.

- Notes**
1. If low level is always input to the URTEEnTRXD pin, it is not judged as the start bit.
 2. In continuous reception, immediately after the stop bit is detected at the first reception bit (when the reception interrupt is generated), the next start bit can be detected.

16.6.9 Reception errors

Errors during a receive operation are of three types: parity errors, framing errors, and overrun errors. Data reception result error flags are set in the URTEEnSTR1 register and a status interrupt request signal INTUAEnTIS is generated when an error occurs.

It is possible to ascertain which error occurred during reception by reading the contents of the URTEEnSTR1 register.

Clear a reception error flag by writing 1 to its associated bit in the status clear register URTEEnSTC.

Table 16-20 Reception error causes

Error flag in URTEEnSTR1	Reception error	Cause
URTEEnPE	Parity error	Received parity bit does not match the setting
URTEEnFE	Framing error	Stop bit not detected
URTEEnOVE	Overrun error	Reception of next data completed before data was read from receive buffer

Note Even in case of a parity or framing error, data is transferred from the receive shift register URTEEnRXS to the receive data register URTEEnRX. Consequently the data from URTEEnRX must be read. Otherwise an overrun error URTEEnSTR1.URTEEnOVE will occur at reception of the next data.

In case of an overrun error, the receive shift register data is not transferred to URTEEnRX, thus the previous data is not overwritten.

16.6.10 Parity types and operations

Caution When using the LIN function, fix the URTE_nCTL1.URTE_nSLP[1:0] to 00_B.

The parity bit is used to detect bit errors in the communication data. Normally the same parity is used on the transmission side and the reception side.

In the case of even parity and odd parity, it is possible to detect odd-count bit errors. In the case of 0 parity and no parity, errors cannot be detected.

(1) Even parity

- During transmission
The number of bits whose value is “1” among the transmit data, including the parity bit, is controlled so as to be an even number. The parity bit values are as follows:
 - Odd number of bits whose value is “1” among transmit data:1
 - Even number of bits whose value is “1” among transmit data:0
- During reception
The number of bits whose value is “1” among the reception data, including the parity bit, is counted, and if it is an odd number, a parity error is output.

(2) Odd parity

- During transmission
Opposite to even parity, the number of bits whose value is “1” among the transmit data, including the parity bit, is controlled so that it is an odd number. The parity bit values are as follows.
 - Odd number of bits whose value is “1” among transmit data: 0
 - Even number of bits whose value is “1” among transmit data: 1
- During reception
The number of bits whose value is “1” among the receive data, including the parity bit, is counted, and if it is an even number, a parity error is output.

(3) 0 parity

During transmission, the parity bit is always made 0, regardless of the transmit data.

During reception, parity bit check is not performed. Therefore, no parity error occurs, regardless of whether the parity bit is 0 or 1.

(4) No parity

No parity bit is added to the transmit data.

Reception is performed assuming that there is no parity bit. No parity error occurs since there is no parity bit.

16.6.11 Digital receive data noise filter

The receive data signal input URTE_nTRXD is equipped with a digital noise filter to eliminate noise and spikes.

This filter samples the URTE_nTRXD pin using the prescaler output clock PRSCLK.

When the same sampling value is read twice, the URTE_nTRXD signal is validated as the input data.

Therefore, data not exceeding the width of 2 prescaler output clocks is judged to be noise and thus eliminated.

The noise filter causes a delay of 4 prescaler output clock PRSCLK cycles when capturing the serial data URTE_nTRXD, until it is forwarded as valid.

16.7 Baud Rate Generator

The transmission and reception baudrate BRCLK are derived from the PBUS bus clock PCLK by use of a prescaler and a baudrate generator, as shown in the figure below.




Figure 16-17 Configuration of baud rate generator

The prescaler output clock PRSCLK is a fraction of PCLK, the divisor is set up by the value URTEnCTL2.URTEnPRS[2:0]:

$$\text{PRSCLK} = \text{PCLK} / 2^{\text{URTEnPRS}[2:0]}$$

PRSCLK is further divided by the baudrate generator by a value, determined by URTEnCTL2.URTEnBRS[11:0].

The baudrate generator distinguishes between the baudrate for data frames and BF receptions, as listed in the table below. The BF reception clock is the double of the baudrate clock BRCLK.

Table 16-21 Baudrate generator clocks output

URTEnCTL2. URTEnBRS[11:0]	Transmit/receive BRCLK	BF receive clock
000 _H	$\text{PCLK} / [2^{\text{URTEnPRS}[2:0]} \times (2 \times 4)]$	$\text{PCLK} / [2^{\text{URTEnPRS}[2:0]} \times 4]$
001 _H		
002 _H		
003 _H		
004 _H	$\text{PCLK} / [2^{\text{URTEnPRS}[2:0]} \times (2 \times 5)]$	$\text{PCLK} / [2^{\text{URTEnPRS}[2:0]} \times 5]$
005 _H		
...	$\text{PCLK} / [2^{\text{URTEnPRS}[2:0]} \times (2 \times \text{URTEnBRS}[11:0])]$	$\text{PCLK} / [2^{\text{URTEnPRS}[2:0]} \times \text{URTEnBRS}[11:0]]$
FFE _H	$\text{PCLK} / [2^{\text{URTEnPRS}[2:0]} \times (2 \times 4094)]$	$\text{PCLK} / [2^{\text{URTEnPRS}[2:0]} \times 4094]$
FFF _H	$\text{PCLK} / [2^{\text{URTEnPRS}[2:0]} \times (2 \times 4095)]$	$\text{PCLK} / [2^{\text{URTEnPRS}[2:0]} \times 4095]$

Chapter 17 LIN Master Controller (LMA)

This chapter contains a generic description of the LIN Master Controller.

The first section describes all properties specific to the V850E2/Fx4-G, such as instances, register base addresses, input/output signal names, etc. The subsequent sections describe the features that apply to all implementations.

17.1 V850E2/Fx4-G LMA Features

LMA_n instances This microcontroller has the following number of instances of the LIN Master Controller LMA_n.

Table 17-1 Instances of LMA

LIN Master Controller	V850E2/FF4-G	V850E2/FG4-G
Instance	2	3
Name	LMA10, LMA11	LMA2, LMA10, LMA11

LMA_n instances index n Throughout this chapter, the instance of a LIN Master Controller is identified by the index “n” (n = 2, 10, 11), for example, LMA_nCTLL for the LMA_n control register L.

CNTA_m instances This microcontroller has following number of instances of the LIN Master Scheduler Counters CNTA_m.

Table 17-2 Instances of LIN Master Scheduler Counters CNTA_m

LIN Master Scheduler Counter	V850E2/FF4-G	V850E2/FG4-G
Instance	1	2
Name	CNTA2	CNTA1, CNTA2

CNTA_m instances index m Throughout this chapter, the instance of a LIN Master Scheduler Counter is identified by the index “m” (m = 1, 2), for example, CNTA_mCTL for the CNTA_m control register.

LMA_n register addresses All LMA_n register addresses are given as address offsets to the individual base address <LMA_n_base>.

The <LMA_n_base> address of each LMA_n are listed in the following table:

Table 17-3 LMA_n register base addresses <LMA_n_base>

LMA _n instance	<LMA _n _base> address
LMA2	FF5E 0080 _H
LMA10	FF66 0080 _H
LMA11	FF67 0080 _H

CNTA_m register addresses All CNTA_m register addresses are given as address offsets to the individual base address <CNTA_m_base>.

The <CNTA_m_base> address of each CNTA_m are listed in the following table:

Table 17-4 CNTA_m register base addresses <CNTA_m_base>

CNTA _m instance	<CNTA _m _base> address
CNTA1	FF5D 4000 _H
CNTA2	FF5E 4000 _H

Clock supply All LIN Master Controller and LIN Master Scheduler Counters provide one clock input.

Table 17-5 LMA/CNTAm clock supply

LMA/CNTAm instance	LMA clock	Connected to
LMA2	PCLK	Clock Controller CKSCLK_034
CNTA1	PCLK	Clock Controller CKSCLK_034
LMA10	PCLK	Clock Controller CKSCLK_011
LMA11	PCLK	Clock Controller CKSCLK_011
CNTA2	PCLK	Clock Controller CKSCLK_011




Figure 17-1 LMA clock supply

Interrupts and DMA The LIN Master Controllers can generate following interrupt and DMA requests:

Table 17-6 LMA_n interrupt and DMA requests

LMA _n signals	Function	Connected to
LMA2:		
INTLMA2TIT	Transmission interrupt	Interrupt Controller INTLMA2IT DMA Controller trigger 52
INTLMA2TIR	Reception interrupt	Interrupt Controller INTLMA2IR
INTLMA2TIS	Status interrupt	Interrupt Controller INTLMA2IS
LMA10:		
INTLMA10TIT	Transmission interrupt	Interrupt Controller INTLMA10IT ^a DMA Controller trigger 59
INTLMA10TIR	Reception interrupt	Interrupt Controller INTLMA10IR ^a DMA Controller trigger 58
INTLMA10TIS	Status interrupt	Interrupt Controller INTLMA10IS ^a
LMA11:		
INTLMA11TIT	Transmission interrupt	Interrupt Controller INTLMA11IT ^a DMA Controller trigger 61
INTLMA11TIR	Reception interrupt	Interrupt Controller INTLMA11IR ^a DMA Controller trigger 60
INTLMA11TIS	Status interrupt	Interrupt Controller INTLMA11IS ^a

a) These interrupts can be used as a wake-up source from any stand-by mode. Refer to the chapter “Stand-by Controller (STBC)” for details.

LMA H/W reset The LIN Master Controllers and their registers are initialized by the following reset signal:

Table 17-7 LMA_n reset signal

LMA _n	Reset signal
LMA _n	<ul style="list-style-type: none"> Reset Controller SYSRES Stand-by Controller DPSTPWU (wake-up from DEEPSTOP mode)

Timer interrupt 0LIN Master Scheduler Counters Following table shows the assignment of the LIN Master Controllers to the LIN Master scheduler counters:

Table 17-8 CNTA_m to LMA_n assignment

CNTA _m instance	LMA _n instance
CNTA1	LMA2
CNTA2	LMA10 to LMA11

For a detailed description of the LIN Master Scheduler Counters CNTA_m refer to section 19.1 “LIN Master Scheduler Counters (CNTA)” on page 1.

17.2 LIN Master Scheduler Counters (CNTA)

The LIN master scheduler counter consists of a free-running 16-bit counter. The count clock is derived from the CNTA input clock PCLK, that is divided by a prescaler.




Figure 17-2 LIN master scheduler counter

CNTAm enable Before the LIN Master Controller is enabling the scheduler, the counter CNTAm must be enabled by CNTAmCTL.CNTAmPW = 1.

Prescaler division The division factor of the prescaler is determined by the value CNTAmCFG.CNTAmPRS[15:00]:

- CNTAmPRS[15:00] = FFFF_H: count clock = PCLK / 1
- else: count clock = PCLK / (CNTAmPRS[15:00]+2)

17.2.1 CNTAm registers

The CNTAm is controlled and operated by means of the following registers:

Table 17-9 CNTAm registers

Register function	Name	Address
Control register	CNTAmCTL	<CNTAm_base> + 00 _H
Configuration register	CNTAmCFG	<CNTAm_base> + 04 _H

<CNTAm_base> The base addresses <CNTAm_base> of the CNTAm are defined in the first section of this chapter under the key word “CNTAm register addresses”.

(1) CNTAmCTL - CNTAm control register

This register enables/disables the CNTAm operation.

Access This register can be read/written in 16-bit units.

Address <CNTAm_base> + 00_H

Initial Value 0000_H

	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CNTAm PW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 17-10 CNTAmCTL register contents

Bit position	Bit name	Function
15	CNTAm PW	CNTAm operation enable 0: CNTAm disabled 1: CNTAm enabled

(2) CNTAmCFG - CNTAm configuration register

This register sets the division factor for the clock prescaler.

Access This register can be read/written in 16-bit units.

Address <CNTAm_base> + 04_H

Initial Value 0000_H

	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	CNTAmPRS[15:00]															
	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 17-11 CNTAmCTL register contents

Bit position	Bit name	Function
15	CNTAm PRS[15:00]	CNTAm prescaler division ratio FFFF _H : PCLK/1 0000 _H : PCLK/2 0001 _H : PCLK/3 0002 _H : PCLK/4 ... FFFE _H : PCLK/65536

17.3 Functional Overview

The LMA module is connected to a UARTE module. This combination provides a LIN master interface, but can be used also as a buffered UARTE.

- UART through mode
- UART buffer mode, full-duplex operation
 - 12 byte Tx buffer
 - 12 byte Rx buffer
- LIN master mode
 - automatic checksum generation and check
 - automatic transmission of Break Field (BF), Sync Field (SF), and checksum
 - Scheduler and automatic frame start function

The block diagram shows the environment of the LIN Master Controller.




Figure 17-3 LIN Master Controller environment

The LIN Master Controller is tightly coupled to the UARTE and utilizes the UARTE as a asynchronous serial interface function with LIN capabilities.

In LIN master mode the UARTE is completely controlled by the LIN Master Controller, all data transfers between the Tx and Rx buffers are managed by the LIN Master Controller.

The UARTE interrupt signals INTUAEIT, INTUAEIR and INTUAEIS are handled by the LIN Master Controller, which generates the interrupt signals INTLMATIT, INTLMATIR and INTLMATIS towards the microcontroller's Interrupt Controller.

For a detailed description of the UARTE refer to the chapter "Asynchronous Serial Interface E (URTE)".

For using the scheduler and the automatic frame start function, a free-running counter is connected to the LIN Master Controller. Refer to the section "LIN Master Scheduler Counter" earlier in this chapter.

17.4 Functional Description

The LIN Master can be set up in three different basic modes by setting the LMA_nCTLL.LMA_nMD[1:0] bits:

- LMA_nCTLL.LMA_nMD[1:0] = 00_B: UART_{En} through mode
In this mode the LMA_n is bypassed and the connected UART_{En} is operated as without LMA_n connected.
- LMA_nCTLL.LMA_nMD[1:0] = 01_B: UART_{En} buffer mode
In this mode the LMA_n operates as a UART_{En} Rx and Tx buffer, each providing a storage capacity of 12 byte.
- LMA_nCTLL.LMA_nMD[1:0] = 1x_B: LIN master mode
In this mode the LMA_n operates in combination with the UART_{En} as a LIN master bus controller, providing Rx and Tx buffers of 12 bytes each in order to handle entire LIN frame transactions without any interaction by the CPU.

17.4.1 UART through mode

In UART through mode (LMA_nCTLL.LMA_nMD[1:0] = 00_B) the LMA_n is bypassed and the UART is used without any LMA_n functions.

As this is the default LMA_n mode, the UART_{En} can be controlled and operated without any LMA_n intervention.

Note In order to keep power consumption at a minimum, it is recommended to keep LMA_nCTLH.LMA_nPW = 0.

Interrupts All LMA_n interrupts request are identical to the UART interrupt requests:

- transmission interrupt request: INTLMA_nTIT = INTUA_{En}TIT
- reception interrupt request: INTLMA_nTIR = INTUA_{En}TIR
- status interrupt request: INTLMA_nTIS = INTUA_{En}TIS

Data transmission Data to be transmitted is written to the UART_{En} transmit data register URTE_nTX.

Data reception Received data is read from the UART_{En} receive data register URTE_nRX.

The UARTE status registers URTE_nSTR0 and URTE_nSTR1 provide information about data transaction status and error detections.

17.4.2 UART buffer mode

In this mode the UARTE_n - LMA_n combination acts a UARTE_n with Rx and Tx buffers of 12 byte size each. This mode is a full-duplex mode, thus receive and transmit transactions are separately controllable and are handled simultaneously.

(1) Initialization

UARTE settings The UARTE_n must be set up as follows:

- URTE_nCTL2
 - URTE_nPRS[2:0], URTE_nBRS[11:0]: baudrate setting
- URTE_nCTL1
 - URTE_nSLBM = 1: BF reception during data reception
- URTE_nCTL0
 - URTE_nPW = 1: UARTE_n enabled
 - URTE_nCTL0.URTE_nTXE = x: transmission enabled/disabled
 - URTE_nCTL0.URTE_nRXE = x: reception enabled/disabled
 - URTE_nCTL0.URTE_nSLDC = 0: no data consistency check
 - URTE_nSLIT = 0: transmission interrupt request at start of transmission

All other UARTE_n settings can be set as required.

LMA_n settings The LMA_n must be set up as follows:

- LMA_nCTLL
 - LMA_nMD[1:0] = 01_B: UART buffer mode
 - LMA_nACSE = 0: automatic checksum disabled
 - LMA_nSCHE = 0: scheduler disabled
 - LMA_nAFE = 0: automatic frame start function disabled
 - LMA_nITMK = 0: INTLMA_nTIT not masked
 - LMA_nIRMK = 0: INTLMA_nRIT not masked
- LMA_nCTLH
 - LMA_nPW = 1: LMA_n enabled

(2) Interrupts

INTLMA_nTIT The transmission interrupt request is generated if the number of data, set up in the Tx buffer and specified by LMA_nTCTLL.LMA_nTLG[3:0], have been transmitted.

INTLMA_nTIR The reception interrupt request is generated if the number of data, specified by LMA_nRCTLL.LMA_nRLG[3:0], have been stored in the Rx buffer. In case of continuous reception (LMA_nRCTLL.LMA_nRLG[3:0] = 0), INTLMA_nTIR is generated after storage of the 12th data, i.e. when the Rx buffer is full.

INTLMAnTIS The status interrupt request is generated under following conditions:

- UART has detected an error during data reception:
 - parity error: URTESTR1.URTEPE = 1
 - framing error: URTESTR1.URTEFE = 1
 - overrun error: URTESTR1.URTEOVE = 1

(3) Data transmission

For data transmission the data to be transmitted have to be written to the Tx buffer (via the LMA_nTX01 to LMA_nTXAB registers) and the number of bytes to be transmitted has to be specified in LMA_nTCTLL.LMA_nTLG[3:0] prior starting the transmission by setting the transmit request LMA_nTCTLL.LMA_nTRQ = 1.

The transmission interrupt request INTLMAnTIT indicates the transmission of the last data byte.

Following values are allowed for the transmit length:

- LMA_nTCTLL.LMA_nTLG[3:0] = 0: 12 data bytes are transmitted
- LMA_nTCTLL.LMA_nTLG[3:0] = 1 to 12: 1 to 12 data bytes are transmitted

Setting LMA_nTCTLL.LMA_nTLG[3:0] > 12 is prohibited.

The following diagram shows the principle transmission process.




Figure 17-4 Data transmission in UART buffer mode

Precondition LMA_n has been

- set into UART buffer mode (LMA_nCTLL.LMA_nMD[1:0] = 01_B)
- enabled (LMA_nCTLH.LMA_nPW = 1)
- Tx buffer empty flag LMA_nSTRH.LMA_nTXEF is cleared

- Procedure**
1. Write 12 bytes of data to the Tx buffer LMA_nTX01 to LMA_nTXAB and set the transmit request LMA_nTCTLL.LMA_nTRQ = 1. Data Tx starts afterwards.
The start of transmission is indicated by LMA_nSTRH.LMA_nSST = 1.
Since LMA_nTCTLL.LMA_nTLG[3:0] = 0, 12 byte will be transmitted.
 2. Upon Tx start of the last data byte Data11 the transmission interrupt request INTLMAnTIT is asserted and LMA_nSTRH.LMA_nTXEF = 1 to indicate Tx buffer empty. LMA_nSTRH.LMA_nSST is cleared to 0.

3. Clear the Tx buffer empty flag by $\text{LMA nSTCH.LMA nCLTXEF} = 1$.
4. The next Tx buffer is prepared to transmit m byte of data by writing m data byte to the Tx buffer and set $\text{LMA nTCTLL.LMA nTLG}[3:0] = 0\text{C}_\text{H}$.
5. Afterwards the next transmission is started by $\text{LMA nTCTLL.LMA nTRQ} = 1$.
6. Upon Tx start of the m^{th} data byte Data_m the transmission interrupt request INTLMA nTIT is asserted and $\text{LMA nSTRH.LMA nTXEF} = 1$ to indicate Tx buffer empty. $\text{LMA nSTRH.LMA nSST}$ is cleared to 0.

Note No errors are detected and indicated in case a transmit request is issued, though Tx buffer empty is indicated ($\text{LMA nSTRH.LMA nTXEF} = 1$) or the Tx length is set to incorrect values ($\text{LMA nTCTLL.LMA nTLG}[3:0] > 0\text{C}_\text{H}$).

Tx abort For stopping an ongoing data transmission, a Tx abort request must be issued by $\text{LMA nTCTLH.LMA nTAB} = 1$. No new data from the Tx buffer is sent to the UARTE and $\text{LMA nSTRH.LMA nSST}$ is cleared. The UARTE completes any ongoing data transmissions. The UARTE Tx completion can be confirmed by $\text{URTE nSTR0.URTE nSST} = 0$.

Caution After setting an Tx abort request $\text{LMA nTCTLH.LMA nTAB} = 1$, a transmit interrupt request may occur. Thus mask INTLMA nTIT in the Interrupt Controller before the Tx abort request.

(4) Data reception

For data reception the number of bytes to be received has to be specified in $\text{LMA nRCTLL.LMA nRLG}[3:0]$ prior starting the reception by setting the receive request $\text{LMA nRCTLL.LMA nRRQ} = 1$. The reception interrupt request INTLMA nTIR indicates the reception of the last data byte.

Following values are allowed for the transmit length:

- $\text{LMA nRCTLL.LMA nRLG}[3:0] = 0$: continuous Rx mode
In this mode received data are continuously stored to the Rx buffer without the need to set further receive requests ($\text{LMA nRCTLL.LMA nRRQ} = 1$). Each time 12 data bytes have been stored in the Rx buffer, a reception interrupt request INTLMA nTIR is asserted.
- $\text{LMA nRCTLL.LMA nRLG}[3:0] = 1$ to 12: 1 to 12 data bytes are stored in the Rx buffer

Setting $\text{LMA nRCTLL.LMA nTLG}[3:0] > 12$ is prohibited.

The following diagram shows the principle reception process.




Figure 17-5 Data reception in UART buffer mode

Precondition LMAAn has been

- set into UART buffer mode ($\text{LMAAnCTL.LMAAnMD}[1:0] = 01_B$)
- enabled ($\text{LMAAnCTLH.LMAAnPW} = 1$)
- Rx buffer full flag $\text{LMAAnSTRH.LMAAnRXFF}$ is cleared

- Procedure**
1. Set the receive request $\text{LMAAnRCTLL.LMAAnRRQ} = 1$. Data Rx starts afterwards.
The start of reception is indicated by $\text{LMAAnSTRH.LMAAnSSR} = 1$.
Since $\text{LMAAnRCTLL.LMAAnRLG}[3:0] = 0$, 12 byte will be received in continuous reception mode.
 2. Upon Rx of the last data byte 11 the reception interrupt request INTLMAAnTIR is asserted and $\text{LMAAnSTRH.LMAAnRXFF} = 1$ to indicate Rx buffer full.
Because of continuous reception mode, Data1 is received without a new receive request.
 3. The Rx buffer needs to be read via the LMAAnRX00 to LMAAnRXAB registers and the Rx buffer full flag is cleared by $\text{LMAAnSTCH.LMAAnCLRXXFF} = 1$.
 4. After reception of the next 12 data byte, only m data bytes shall be received and reception shall be stopped. Therefore Rx buffer length is set to $\text{LMAAnRCTLL.LMAAnRLG}[3:0] = m$ and the Rx buffer full flag is cleared by $\text{LMAAnSTCH.LMAAnCLRXXFF} = 1$.
 5. If the m data bytes have been stored in the Rx buffer, reception is stopped ($\text{LMAAnSTRH.LMAAnSSR} = 0$).

Rx abort For stopping an ongoing data reception, a Rx abort request must be issued by $\text{LMAAnRCTLH.LMAAnRAB} = 1$. No new data is stored to the TR buffer, and $\text{LMAAnSTRH.LMAAnSSr}$ is cleared.

The UARTE completes any ongoing data reception, but the finally received data is not stored in the Rx buffer. The UARTE Rx completion can be confirmed by $\text{URTEEnSTR0.URTEEnSSR} = 0$.

Caution After setting an Rx abort request `LMAAnRCTLH.LMAAnRAB = 1`, a receive interrupt request may occur. Thus mask `INTLMAAnTIR` in the Interrupt Controller before the Rx abort request.

(5) UARTE Rx errors

Error detections during data reception can be initiated by the UARTE as well as by the LMAAn.

UARTEn errors If the UARTE detects a parity, framing or overrun error during data reception, the received data is stored to the Rx buffer and the assigned Rx data error flag `LMAAnSTRL.LMAAnRXBE[11:00]` is set. The number of `RXBE[11:00]` is associated to the data byte in the Rx buffer:

- `LMAAnSTRL.LMAAnRXBE[00] = 1` for `LMAAnRX01.LMAAnRX00B[7:0]` error
- ...
- `LMAAnSTRL.LMAAnRXBE[11] = 1` for `LMAAnRXAB.LMAAnRX11B[7:0]` error

If the specified number of data bytes (`LMAAnRCTLL.LMAAnRLG[3:0]`) have been stored in the Rx buffer, the status interrupt request `INTLMAAnTIS` is asserted and reception stops (`LMAAnSTRH.LMAAnSSR = 0`), even if operating in continuous reception mode (`LMAAnRCTLL.LMAAnRLG[3:0] = 0`).

Note that in this case no receive interrupt request `INTLMAAnTIR` is generated.

The Rx error flags `LMAAnSTRL.LMAAnRXBE[11:00]` are cumulative, i.e. each reception error, that is detected until the specified number of bytes are received, set its error flag. Upon the end of reception, indicated by `INTLMAAnTIS`, `LMAAnSTRL.LMAAnRXBE[11:00]` can be read in order to identify all Rx buffer data, that have causes error flag settings.

The following diagram shows an example in continuous reception mode (`LMAAnRCTLL.LMAAnRLG[3:0] = 0`).




Figure 17-6 Data reception in UART buffer mode with UART reception errors

Precondition LMAAn has been

- set into UART buffer mode (LMAAnCTL.LMAAnMD[1:0] = 01_B)
- enabled (LMAAnCTLH.LMAAnPW = 1)
- Rx buffer full flag LMAAnSTRH.LMAAnRXFF is cleared
- Rx error flags LMAAnSTRLL.LMAAnRXBE[11:00] has been cleared

Procedure

1. Rx is started by LMAAnRCTL.LMAAnRRQ = 1.
2. During reception of Data3 the UARTE has detected an error. Data3 is stored to the Rx buffer LMAAnRX23.LMAAnRX03B[7:0] and the associated error flag LMAAnSTRLL.LMAAnRXBE[03] is set, thus LMAAnSTRLL.LMAAnRXBE[11:00] = 008_H.
3. During reception of Data5 the UARTE has detected another error. Data5 is stored to the Rx buffer LMAAnRX45.LMAAnRX05B[7:0] and the associated error flag LMAAnSTRLL.LMAAnRXBE[05] is set, thus LMAAnSTRLL.LMAAnRXBE[11:00] = 028_H.
4. After reception of the last data Data11, the status interrupt INTLMAAnTIS is generated (instead of INTLMAAnTIR) and the Rx process is stopped (LMAAnSTRH.LMAAnSSR = 0).

LMAAn Rx buffer overflow error

If the Rx buffer full flag LMAAnSTRH.LMAAnRXFF is set while new data has been received,

- the Rx buffer overflow flag LMAAnSTRH.LMAAnROVE is set
- the status interrupt request INTLMAAnTIS is asserted
- the received data is not stored in the Rx buffer
- Rx process is stopped (LMAAnSTRH.LMAAnSSR = 0).

Since the received data, that is not stored in the Rx buffer, remains in the UARTE's receive register URTEEnRX, it is possible to read from there. However if a next data is received, this data is lost since the UARTE discards this data, i.e. it does not overwrite the URTEEnRX register, but sets its overrun error flag URTEEmSTR1.URTEEnOVE = 1.

17.4.3 LIN master modes

In this mode the LMA in combination with the UARTE provides a LIN master interface with automatic LIN master Tx and Rx frame transactions, including sending of Break and Sync Fields (BF and SF) to initiate a LIN master frame transaction, automatic checksum functions, scheduler and automatic frame start facilities. The separate 12-byte Tx and Rx buffers allow complete LIN frame transactions without any intervention from the CPU side.

Principle of operation A LIN master frame transaction is initiated by sending the frame header (BF and SF). This is done automatically when the transaction is started.

In either LIN master Tx or Rx mode the PID is written to the Tx buffer.

In *Tx mode* the data to be transmitted (maximum 8 data bytes) has to be written to the Tx buffer and the length of the Tx frame has to be specified in LMA_nTCTLL.LMA_nTLG[3:0].

If *automatic checksum* is enabled, the checksum is automatically calculated and appended to the Tx data bytes in the Tx buffer. In case automatic checksum is disabled, the CPU needs to calculate the checksum and to write it to the Tx buffer.

After start of the frame transmission by setting the transmit request LMA_nTCTLL.LMA_nTRQ = 1 transmission starts sending "BF - SF - PID - TxData bytes - Tx Checksum".

Simultaneously the sent data is received and stored in the Rx buffer for performing the *data consistency check*, which is executed during transmission of the entire LIN frame.

If automatic checksum calculation is enabled, the checksum of the received data is automatically calculated and checked against the received checksum in the Rx buffer. In case of mismatch a checksum error is reported. If automatic checksum calculation is disabled, the checksum over the received data needs to be calculated and checked against the received checksum by the CPU.

In *Rx mode* the frame length to be received (maximum 8 data bytes) has to be specified in LMA_nTCTLL.LMA_nTLG[3:0].

Frame reception is also started by setting the transmit request LMA_nTCTLL.LMA_nTRQ = 1. The LIN master starts sending "BF - SF - PID" and then waits to receive the number of specified data bytes and finally the checksum from the LIN slave.

If *automatic checksum* calculation is enabled, the checksum of the received data is automatically calculated and checked against the received checksum in the Rx buffer. In case of mismatch a checksum error is reported. If automatic checksum calculation is disabled, the checksum over the received data needs to be calculated and checked against the received checksum by the CPU.

Note In either LIN master Tx or Rx mode the frame transaction control is done via the Tx control register LMA_nTCT.

If the *scheduler* is enabled, status interrupts are generated in defined periods to ensure a minimum LIN interframe space (which is the time between two LIN frames). This minimum interframe space may be required by some slaves. For that purpose the length of the LIN frame slot length FRSL, which spans the LIN frame plus the interframe space, is to be specified in the Tx buffer prior starting the LIN frame transaction.

If the scheduler and the *automatic frame start function* is enabled, a new LIN frame transaction is automatically started after the LIN frame slot length FRSL.

LIN frame header errors	<p>Two modes are provided to react on errors during the LIN frame header (BF: Break Field, SF: Sync Field) transmission:</p> <ul style="list-style-type: none"> • LMA_nCTLL.LMA_nMD[1:0] = 10_B: LIN master mode without break in header Data transfers are carried on after error detections during header transmission. • LMA_nCTLL.LMA_nMD[1:0] = 11_B: LIN master mode with break in header Data transfers are stopped after error detections during header transmission.
Enhanced checksum	<p>Automatic checksum calculation can be performed in two ways:</p> <ul style="list-style-type: none"> • LMA_nTCTLL.LMA_nSLEC = 0: only the data bytes are used to calculate the checksum (classic checksum) • LMA_nTCTLL.LMA_nSLEC = 1: the PID and the data bytes are used to calculate the checksum (enhanced checksum)
LIN frame length	<p>The number of bytes to be transferred, i.e. the length of the LIN frame, needs to be specified in LMA_nTCTLL.LMA_nTLG[3:0]. The LMA_nTCTLL.LMA_nTLG[3:0] value includes the number of data bytes (maximum 8), the PID and the checksum. Thus</p> $\text{LMA}_{n}\text{TCTLL.LMA}_{n}\text{TLG}[3:0] = 2 \text{ to } 10$ <p>All other values are prohibited.</p>
Tx/Rx abort	<p>For stopping an ongoing data transaction, a Tx abort request must be issued by LMA_nTCTLLH.LMA_nTAB = 1. No new data from the Tx buffer is sent to the UARTE respectively received from the UARTE and stored in the Rx buffer.LMA_nSTRH.LMA_nSST is cleared. The UARTE completes any ongoing data transmissions. The UARTE data transmission/reception completion can be confirmed by URTE_nSTR0.URTE_nSST =URTE_nSTR0.URTE_nSST = 0.</p>
Caution	<hr/> <p>After setting an Tx abort request LMA_nTCTLLH.LMA_nTAB = 1, a transmit, reception or status interrupt request may occur. Thus mask INTLMA_nTIT, INTLMA_nTIR, and INTLMA_nTIS in the Interrupt Controller before the Tx abort request.</p> <hr/>

(1) Initialization

CNTAn settings If the scheduler is to be used, the scheduler counter must be set up as follows:

- CNTAmCTL
 - CNTAmPW = 1: counter enabled
- CNTAmCFG
 - CNTAmPRS[15:00]: division ratio

UARTE settings The UARTEn must be set up as follows:

- URTEnCTL2
 - URTEnPRS[2:0], URTEnBRS[11:0]: baudrate setting
- URTEnCTL1
 - URTEnSLBM = 0: no BF reception during data reception
 - URTEnBLG[2:0] = 0: BF bit length
 - URTEnCLG = 1: 8-bit data
 - URTEnSLP[1:0] = 00_B: no parity
 - URTEnTDL = 0: no Tx data inversion
 - URTEnRDL = 0: no Rx data inversion
 - URTEnSLG = 0: 1 stop bit
 - URTEnSLD = 1: LSB first
 - URTEnSLIT = 0: transmission interrupt request at start of transmission
- URTEnCTL0
 - URTEnPW = 1: UARTEn enabled
 - URTEnCTL0.URTEnTXE = 1: transmission enabled
 - URTEnCTL0.URTEnRXE = 1: reception enabled
 - URTEnCTL0.URTEnSLDC = 1: data consistency check enabled

LMAAn settings The LMAAn must be set up as follows:

- LMAAnCTLL
 - LMAAnMD[1:0] = 1x_B: LIN master mode
 - LMAAnACSE = x: automatic checksum enabled/disabled
 - LMAAnSCHE = x: scheduler enabled/disabled
 - LMAAnAFE = x: automatic frame start function enabled/disabled
 - LMAAnITMK = x: INTLMAAnTIT masked/not masked
 - LMAAnIRMK = x: INTLMAAnRIT masked/not masked
- LMAAnCTLH
 - LMAAnPW = 1: LMAAn enabled

(2) Interrupts

Since both transmission and reception are involved during a LIN master frame transaction, transmit (INTLMAntIT) and receive (INTLMAntRIT) interrupts are generated in Tx as well as in Rx mode.

Note Both interrupt requests can be separately suppressed:

- LMAntCTLL.ITMK = 1: INTLMAntIT is masked and will not be generated
- LMAntCTLL.IRMK = 1: INTLMAntRIT is masked and will not be generated

- INTLMAntIT**
- in Tx mode (LMAntCTLL.LMAntSLRT = 0)
INTLMAntIT is generated if the number of data, specified by LMAntCTLL.LMAntTLG[3:0], have been transmitted.
 - in Rx mode (LMAntCTLL.LMAntSLRT = 1)
if SF has been transmitted
- INTLMAntTIR**
- in Tx mode (LMAntCTLL.LMAntSLRT = 0)
Generation of INTLMAntTIR depends also on the auto-checksum function. If the checksum has been received for checksum control and
 - auto-checksum function is disabled (LMAntCTL.LMAntACSE = 0), INTLMAntTIR is always asserted.
 - auto-checksum function is enabled (LMAntCTL.LMAntACSE = 1), INTLMAntTIR is asserted, if the received checksum matches the automatically calculated checksum. In case of a mismatch a checksum error is indicated (LMAntSTRH.LMAntFCSE = 1) and the status interrupt request INTLMAntTIS is generated instead.
 - in Rx mode (LMAntCTLL.LMAntSLRT = 1)
INTLMAntTIR is generated if the number of data, specified by LMAntCTLL.LMAntTLG[3:0], have been stored in the Rx buffer.
- INTLMAntIS** The status interrupt request is generated under various conditions:
- UARTE has detected a framing error.
 - UARTE has detected an overrun error.
 - UARTE has detected a data consistency error.
 - UARTE has detected a BF transmission error.
 - UARTE has detected a SF transmission error.
 - LMAnt has detected an auto-checksum error.
 - LMAnt has detected a buffer preparation error.
 - LMAnt scheduler ready event occurred.

(3) Data transmission

The LIN master Tx mode is selected by LMAntCTLL.LMAntMD[1:0] = 1x_B and LMAntCTLL.LMAntSLRT = 0.

For transmission of a LIN master frame the Tx buffer has to be prepared in the following format prior starting the frame transmission:

Table 17-12 Tx buffer preparation in LIN master Tx mode

Tx buffer register		Tx buffer for 8 data byte	Tx buffer for 5 data byte
LMA _n TXAB.	LMA _n TX11B[7:0]	FRSLH ^a	FRSLH ^a
	LMA _n TX10B[7:0]	FRSLL ^a	FRSLL ^a
LMA _n TX89.	LMA _n TX9B[7:0]	Tx checksum ^b	–
	LMA _n TX8B[7:0]	TxData7	–
LMA _n TX67.	LMA _n TX7B[7:0]	TxData6	–
	LMA _n TX6B[7:0]	TxData5	Tx checksum ^b
LMA _n TX45.	LMA _n TX5B[7:0]	TxData4	TxData4
	LMA _n TX4B[7:0]	TxData3	TxData3
LMA _n TX23.	LMA _n TX3B[7:0]	TxData2	TxData2
	LMA _n TX2B[7:0]	TxData1	TxData1
LMA _n TX01.	LMA _n TX1B[7:0]	TxData0	TxData0
	LMA _n TX0B[7:0]	PID	PID

a) The frame slot length FRSLH/FRSLL is only effective if the scheduler is enabled (LMA_nCTLL.LMA_nSCHE = 1).

b) The Tx checksum is automatically stored, if automatic checksum is enabled (LMA_nCTLL.LMA_nACSE = 1). Otherwise the checksum needs to be calculated and stored by software.

After starting the LIN frame transmission the sent data is stored in the Rx buffer for checksum confirmation. When the entire frame has been transmitted, the Rx buffer looks as follows:

Table 17-13 Rx buffer after LIN frame transmission

Rx buffer register		Rx buffer for 8 data byte	Rx buffer for 5 data byte
LMA _n RxAB.	LMA _n Rx11B[7:0]	–	–
	LMA _n Rx10B[7:0]	–	–
LMA _n Rx89.	LMA _n Rx9B[7:0]	Rx checksum	–
	LMA _n Rx8B[7:0]	RxData7	–
LMA _n Rx67.	LMA _n Rx7B[7:0]	RxData6	–
	LMA _n Rx6B[7:0]	RxData5	Rx checksum
LMA _n Rx45.	LMA _n Rx5B[7:0]	RxData4	RxData4
	LMA _n Rx4B[7:0]	RxData3	RxData3
LMA _n Rx23.	LMA _n Rx3B[7:0]	RxData2	RxData2
	LMA _n Rx2B[7:0]	RxData1	RxData1
LMA _n Rx01.	LMA _n Rx1B[7:0]	RxData0	RxData0
	LMA _n Rx0B[7:0]	PID	PID

If automatic checksum is enabled (LMA_nCTLL.LMA_nACSE = 1), the checksum (as selected by LMA_nTCTLL.LMA_nSLEC) is calculated and compared with the received checksum. Otherwise the checksum needs to be calculated and compared by software.

The following diagram shows the principle LIN frame transmission process with the maximum of 8 data byte.




Figure 17-7 LIN frame transmission in LIN master mode

Precondition LMA_n has been

- set into LIN master Tx mode (LMA_nCTLL.LMA_nMD[1:0] = 1x_B, LMA_nTCTLL.LMA_nSLRT = 0)
- neither scheduler and, thus, nor automatic frame start function used (LMA_nSCHE and LMA_nAFE of LMA_nCTLL register both cleared)
- enabled (LMA_nCTLH.LMA_nPW = 1)
- Tx buffer empty flag LMA_nSTRH.LMA_nTXEF is cleared
- Rx buffer full flag LMA_nSTRH.LMA_nRXFF is cleared

- Procedure**
1. Write the PID to Tx buffer LMA_nTX01.LMA_nTX00B[7:0] and 8 bytes of data to the Tx buffer LMA_nTX01.LMA_n01B[7:0] to LMA_nTX89.LMA_n08B[7:0]. If automatic checksum is disabled (LMA_nCTLL.LMA_nACSE = 0), calculate the checksum CSF (over the bytes including respectively excluding PID, depending on LMA_nTCTLL.LMA_nSLEC) and store it to LMA_nTX89.LMA_n09B[7:0]. Otherwise CSF will be calculated and added automatically.
Set the frame length LMA_nTCTLL.LMA_nTLG[3:0] = A_H (10 = PID + 8 data bytes + CSF).
Start frame transmission by LMA_nTCTLL.LMA_nTRQ = 1, and transmission start is indicated by LMA_nSTRH.LMA_nSST = 1.
 2. Upon start of the Checksum Field (CSF) transmission, Tx buffer empty is indicated by LMA_nSTRH.LMA_nTXEF = 1 and the transmit interrupt request INTLMA_nTIT is asserted.
 3. After the checksum field CSF has been transmitted, the Rx buffer full flag LMA_nSTRH.LMA_nRXFF is set and checksum control is performed,

provided automatic checksum calculation is enabled
(LMA_nCTLL.LMA_nACSE = 1.

If the checksum is correct, the receive interrupt request INTLMA_nTIR is asserted.

If the checksum is incorrect, the status INTLMA_nTIS instead of the receive interrupt request is asserted.

(4) Data reception

The LIN master Rx mode is selected by LMA_nCTLL.LMA_nMD[1:0] = 1x_B and LMA_nTCTLL.LMA_nSLRT = 1.

For data reception in LIN master mode the Tx buffer has to be prepared in the following format prior starting the frame reception:

Table 17-14 Tx buffer preparation in LIN master Rx mode

Tx buffer register		Tx buffer
LMA _n TXAB.	LMA _n TX11B[7:0]	FRSLH ^a
	LMA _n TX10B[7:0]	FRSLL ^a
LMA _n TX89.	LMA _n TX9B[7:0]	–
	LMA _n TX8B[7:0]	–
LMA _n TX67.	LMA _n TX7B[7:0]	–
	LMA _n TX6B[7:0]	–
LMA _n TX45.	LMA _n TX5B[7:0]	–
	LMA _n TX4B[7:0]	–
LMA _n TX23.	LMA _n TX3B[7:0]	–
	LMA _n TX2B[7:0]	–
LMA _n TX01.	LMA _n TX1B[7:0]	–
	LMA _n TX0B[7:0]	PID

a) The frame slot length FRSLH/FRSLL is only effective if the scheduler is enabled (LMA_nCTLL.LMA_nSCHE = 1).

After starting the LIN frame reception the LIN master frame header (BF, SF, PID) is transmitted to the slaves and the data, received from the slave afterwards, is stored in the Rx buffer. When the entire frame has been transmitted, the Rx buffer looks as follows:

Table 17-15 LIN master Rx buffer after LIN frame reception (1/2)

Rx buffer register		Rx buffer for 8 data byte	Rx buffer for 5 data byte
LMA _n RxAB.	LMA _n Rx11B[7:0]	–	–
	LMA _n Rx10B[7:0]	–	–
LMA _n Rx89.	LMA _n Rx9B[7:0]	Rx checksum	–
	LMA _n Rx8B[7:0]	RxData7	–
LMA _n Rx67.	LMA _n Rx7B[7:0]	RxData6	–
	LMA _n Rx6B[7:0]	RxData5	Rx checksum
LMA _n Rx45.	LMA _n Rx5B[7:0]	RxData4	RxData4
	LMA _n Rx4B[7:0]	RxData3	RxData3

Table 17-15 LIN master Rx buffer after LIN frame reception (2/2)

Rx buffer register		Rx buffer for 8 data byte	Rx buffer for 5 data byte
LMA _n Rx23.	LMA _n Rx3B[7:0]	RxData2	RxData2
	LMA _n Rx2B[7:0]	RxData1	RxData1
LMA _n Rx01.	LMA _n Rx1B[7:0]	RxData0	RxData0
	LMA _n Rx0B[7:0]	PID	PID

If automatic checksum is enabled (LMA_nCTLL.LMA_nACSE = 1), the checksum (as selected by LMA_nTCTLL.LMA_nSLEC) is calculated and compared with the received checksum. Otherwise the checksum needs to be calculated and compared by software.

The following diagram shows the principle LIN frame reception process with the maximum of 8 data byte.




Figure 17-8 LIN frame reception in LIN master mode

Precondition LMA_n has been

- set into LIN master Rx mode (LMA_nCTLL.LMA_nMD[1:0] = 1x_B, LMA_nTCTLL.LMA_nSLRT = 1)
- neither scheduler and, thus, nor automatic frame start function used (LMA_nSCHE and LMA_nAFE of LMA_nCTLL register both cleared)
- enabled (LMA_nCTLH.LMA_nPW = 1)
- Tx buffer empty flag LMA_nSTRH.LMA_nTXEF is cleared
- Rx buffer full flag LMA_nSTRH.LMA_nRXFF is cleared

- Procedure**
1. Write the PID to Tx buffer LMA_nTX01.LMA_nTX00B[7:0].
The number of data
Start frame reception by LMA_nTCTLL.LMA_nTRQ = 1, and transmission start of the frame header is indicated by LMA_nSTRH.LMA_nSST = 1.
 2. Upon start of the PID transmission, Tx buffer empty is indicated by LMA_nSTRH.LMA_nTXEF = 1 and the transmit interrupt request INTLMA_nTIT is asserted.
 3. After the checksum field CSF has been transmitted, the Rx buffer full flag LMA_nSTRH.LMA_nRXFF is set and checksum control is performed, provided automatic checksum calculation is enabled (LMA_nCTLL.LMA_nACSE = 1.
If the checksum is correct, the receive interrupt request INTLMA_nTIR is asserted.
If the checksum is incorrect, the status INTLMA_nTIS instead of the receive interrupt request is asserted.

(5) LIN master mode transaction errors

During LIN master mode transactions the UARTEn as well as the LMAAn can detect and indicate various transaction errors.

Table 17-16 LIN master mode transaction errors

Detection module	Error	Indicator	Error cause
UARTE	Framing error	URTEEnSTR1.URTEEnFE = 1	No stop bit was detected after reception of the 8th bit of the SF, PID, data, or CSF (checksum) byte. A framing error generates also a data consistency error.
	Overrun error	URTEEnSTR1.URTEEnOVE = 1	New data received, while the UARTE receive register URTEEnRX holds data, that has not been stored in the Rx buffer.
	Data consistency error	URTEEnSTR1.URTEEnDCE = 1	Data sent during transmission is erroneous. A data consistency error during BF transmission is indicated as a BF transmission error. A data consistency error during SF transmission is indicated as a SF transmission error. Note that any framing error generates also a data consistency error.
	BF transmission error	URTEEnSTR1.URTEEnBSF = 0 LMAAnSTRH.LMANBFE = 1	Data consistency occurs during BF Tx
	SF transmission error	URTEEnSTR1.URTEEnDCE = 1 LMAAnSTRH.LMANSFE = 1	Data consistency error occurred during SF transmission.
LMAAn	Auto-checksum error	LMAAnSTRH.LMANFCSE = 1	Calculated checksum does not match the received checksum after completion of a LIN frame transaction. provided the auto-checksum function is enabled by LMAAnCTLL.LMANACSE = 1.
	Rx/Tx buffer preparation error	LMAAnSTRH.LMANPIE = 1	LIN frame transaction is started (by LMAAnTCTLL.TRQ = 1 or in auto frame start mode), while the Tx and Rx buffer are not set up correctly, i.e. <ul style="list-style-type: none"> Tx buffer empty (LMAAnSTRH.LMANTXEF = 1) Rx buffer full (LMAAnSTRH.LMANRXFF = 1) transmit length incorrect (LMAAnTCTLL.LMANTLG[3:0] = 0, 1, 11 to 15)

The procedure taking place upon an UARTE error detection depends on the mode the LMAAn is operating in and the type of erroneous data.

The main difference between LIN master mode with and without break in header refers to the different behaviour, when a data consistency check error is detected in the LIN frame header (BF/SF) in Rx mode: "with break in header" stops any further transactions, while "without break in header" continuous transactions.

- LIN master mode with break in header

If a *data consistency check error* was detected in any type of data, further transactions are stopped, the associated Rx buffer error flag LMA_nSTRL.LMA_nRXBE is set and a status interrupt request INTLMA_nTIS is generated.

In case of *framing/overrun error* detections during transmission of the BF/SF transactions are continued.

If PID/data/checksum are received with framing/overrun errors in Rx mode, further transactions are stopped, the associated Rx buffer error flag LMA_nSTRL.LMA_nRXBE is set and a status interrupt request INTLMA_nTIS is generated.

- LIN master mode without break in header

If a *data consistency check error* was detected in PID/data/checksum, or during transmission of BF/SF, further transactions are stopped, the associated Rx buffer error flag LMA_nSTRL.LMA_nRXBE is set and a status interrupt request INTLMA_nTIS is generated. If data inconsistency during BF/SF in Rx mode, transactions continue, the associated Rx buffer error flag LMA_nSTRL.LMA_nRXBE is set and a status interrupt request INTLMA_nTIS is generated.

In case of *framing/overrun error* detections during transmission of the BF or SF transactions are continued.

If PID/data/Checksum are received with framing/overrun errors in Rx mode, further transactions are stopped, the associated Rx buffer error flag LMA_nSTRL.LMA_nRXBE is set and a status interrupt request INTLMA_nTIS is generated.

The following table summarizes these procedures.

Figure 17-9 UARTE errors in LIN master mode

Rx/Tx mode	Framing error ^a /overrun error in		Data consistency check error in	
	BF/SF ^b	PID/data/CSF	BF / SF	PID / Data / CSF
LIN master mode with break in header (LMA nCTLL.LMA nMD[1:0] = 11_B)				
Tx mode (LMA nTCTLL. LMA nSLRT = 0)	Transaction continued		<ul style="list-style-type: none"> Transaction stopped at STOP bit of erroneous field LMA nSTRL.LMA nRXBE[i] = 1 	
Rx mode (LMA nTCTLL. LMA nSLRT = 1)	Transaction continued	<ul style="list-style-type: none"> Transaction stopped at STOP bit of erroneous field LMA nSTRL.LMA nRXBE[i] = 1 INTLMA nTIS asserted 	<ul style="list-style-type: none"> INTLMA nTIS asserted 	
LIN master mode without break in header (LMA nCTLL.LMA nMD[1:0] = 10_B)				
Tx mode (LMA nTCTLL. LMA nSLRT = 0)	Transaction continued		<ul style="list-style-type: none"> Transaction stopped after PID transmitted LMA nSTRL.LMA nRXBE[i] = 1 INTLMA nTIS asserted after PID transmitted 	<ul style="list-style-type: none"> Transaction stopped at STOP bit of erroneous field LMA nSTRL.LMA nRXBE[i] = 1 INTLMA nTIS asserted
Rx mode (LMA nTCTLL. LMA nSLRT = 1)	Transaction continued	<ul style="list-style-type: none"> Transaction stopped at STOP bit of erroneous field LMA nSTRL.LMA nRXBE[i] = 1 INTLMA nTIS asserted 	<ul style="list-style-type: none"> Transaction continued LMA nSTRL.LMA nRXBE[i] = 1 INTLMA nTIS asserted after CSF reception completed 	

- a) A framing error during transmission of any type of data a data consistency error is detected simultaneously (in Tx mode: BF/SF/PID/data/CSF are transmitted, in Rx mode: BF/SF/PID/ are transmitted).
- b) Any error detection in BF or SF sets the respective error flag LMA nSTRH.LMA nBFE respectively LMA nSTRH.LMA nSFE.

Note During data reception in LIN Master mode, the LMA cannot distinguish between missing responses from LIN slaves and incomplete responses from LIN slaves. In both cases, the data reception will not finish and needs to be aborted by software. There is no indication, how many data bytes have been received up to the abortion.

17.4.4 Automatic checksum function

The automatic checksum function allows to automatically generate respectively control checksums.

The automatic checksum function is control by:

- LMA_nCTLL.LMA_nACSE = 0: automatic checksum function disabled
- LMA_nCTLL.LMA_nACSE = 1: automatic checksum function enabled

In LMA_nCTLL.LMA_nACSE = 0: automatic checksum function is enabled, the automatic checksum function performs the following:

Tx mode In Tx mode (LMA_nTCTLL.LMA_nSLRT = 0), the checksum is automatically calculated and appended to the transmit data in the Tx buffer upon LIN frame transaction start.

After transmission completion the checksum the same procedure takes place as in Rx mode (see below).

Rx mode After reception completion the checksum is calculated from the received data and automatically compared to the received checksum, stored in the Rx buffer. In case both match, the receive interrupt request INTLMA_nTIR is generated. If they don't match, the status interrupt request INTLMA_nTIS is generated and the checksum error flag LMA_nSTRH.LMA_nFCSE is set.

Checksum format The data incorporated in the calculation of the checksum in automatic checksum mode can be chosen:

- LMA_nTCTLL.LMA_nSLEC = 0: classic checksum
Only the data bytes, stored in the Tx or Rx buffer, are used to calculate the checksum.
- LMA_nTCTLL.LMA_nSLEC = 1: enhanced checksum
The data bytes and the PID, stored in the Tx or Rx buffer, are used to calculate the checksum.

17.4.5 Scheduler

The scheduler allows to generate status interrupts INTLMAntIS in defined time distances. INTLMAntIS can be used to initiate the next LIN master frame transaction.

By this a minimum LIN interframe space (which is the time between two LIN frames) can be ensured. This minimum interframe space may be required by some slaves.

For that purpose the LIN frame slot length FRSL, which spans the LIN frame plus the interframe space, is to be specified in the Tx buffer prior starting the LIN frame transaction.

Scheduler counter The scheduler makes use of a scheduler counter CNTAm. CNTAm is a free-running counter. Its count clock can be selected by the prescaler CNTAmCFG.CNTAmPS[15:0]. A detailed description of the scheduler counter CNTAm is given in the first section of this chapter in “Scheduler Counter A”.

(1) Scheduler operation

Note Before any LIN master frame transaction is started with scheduler, the employed scheduler counter CNTAm has to be enabled (CNTAmCTL.CNTAmPWR = 1) and its prescaler has to be set up (CNTAmCFG.CNTAmPS[15:0]). CNTAmCFG.CNTAmPS[15:0] determines the scheduler count clock SCHECLK. The scheduler clocks are counting up the scheduler counters count value CNTAmCNT.

The scheduler needs to be enabled by LMAntCTL.LMAntSCHE = 1.

Before starting a LIN master frame transaction (LMAntCTL.LMAntTRQ = 1) with scheduler function, the length of the 16-bit LIN frame slot length FRSL[15:0] has to be written to the Tx buffer:

- LMAntTXAB.LMAntTX10B[7:0] = FRSL[7:0]
- LMAntTXAB.LMAntTX11B[7:0] = FRSL[15:8]

FRSL[15:0] defines the number of scheduler clocks SCHECLK for the frame slot length.

If the LIN master frame transaction is started, the current value of the scheduler counter CNTAmCNT[15:0] is added to the defined frame slot length FRSL[15:0] and stored to the compare register LMAntCMPL.LMAntCMP[15:0].

The scheduler counter value CNTAmCNT[15:0] is continuously compared with the compare register LMAntCMP[15:0]. If both match, the status interrupt request INTLMAntIS is generated and the scheduler ready flag LMAntSTRH.LMAntSRF is set.




Figure 17-10 Scheduler functional overview

Interrupt handling Upon occurrence of the status interrupt INTLMAAnTIS transaction of a next LIN master frame can be started immediately, provided the frame slot length FRSL includes also a minimum interframe space. Thus the receive and transmit interrupts may not be necessary to be processed and could be suppressed by masking LMAAnCTLL.LMAAnITMK = LMAAnCTLL.LMAAnIRMK = 1.

The diagram below shows the principle timing of a LIN frame transmission with use of the scheduler.




Figure 17-11 LIN frame transaction with scheduler

Precondition The scheduler counter is operating and scheduler clock frequency has been set up.
LMAAn has been

- set into LIN master mode (LMA_nCTLL.LMA_nMD[1:0] = 1x_B)
- scheduler is enabled (LMA_nCTLL.LMA_nSCHE = 1)
- automatic frame start function is disabled (LMA_nCTLL.LMA_nAFE = 0)
- enabled (LMA_nCTLH.LMA_nPW = 1)
- Tx buffer empty flag LMA_nSTRH.LMA_nTXEF and Rx buffer full flag LMA_nSTRH.LMA_nRXFF are cleared
- Tx buffer has been set up correctly with frame slot length FRSL₀

- Procedure**
1. Start frame transmission by LMA_nTCTLL.LMA_nTRQ = 1, and transmission start is indicated by LMA_nSTRH.LMA_nSST = 1. Sum of the current schedule counter value CNTAmCNT[15:0] and the frame slot length FRSL₀ is stored to LMA_nCMP.CMP[15:0].
 2. After transmission of the checksum field CSF, i.e. after the frame length, the Tx buffer is indicated as empty (LMA_nSTRH.LMA_nTXEF = 1) and the Rx buffer as full (LMA_nSTRH.LMA_nRXFF = 1).
 3. Upon match of the scheduler counter CNTAmCNT[15:0] and LMA_nCMP.LMA_nCMP[15:0] the status interrupt request INTLMA_nTIS indicates the end of the frame slot length and the scheduler ready flag LMA_nSTRH.LMA_nSRF is set.
If a sufficient interframe space was regarded, when defining the frame slot length FRSL₀, the next frame transaction could already be started at this point in time.
 4. The buffer status flags and the scheduler ready flag are cleared (LMA_nCLTXEF = LMA_nCLRXFF = LMA_nCLSRF of LMA_nSTCH register set to 1).
The Tx buffer and its control register LMA_nTCTLL are prepared for the next frame transaction, with the next frame slot length FRSL₁.
 5. Next frame transaction is started by LMA_nTCTLL.LMA_nTRQ = 1, and transmission start is indicated by LMA_nSTRH.LMA_nSST = 1. Sum of the current schedule counter value CNTAmCNT[15:0] and the frame slot length FRSL₁ is stored to LMA_nCMP.CMP[15:0].

(2) Scheduler operation with automatic frame start function

The automatic start function, in combination with the scheduler, allows to eliminate unnecessary gaps on the LIN bus by enabling the CPU to make all preparations within the interframe space. The next LIN frame transaction is started automatically after the interframe space, thus maintaining a maximum data transmission performance on the bus.

The automatic frame start function needs to be enabled by LMA_nCTLL.LMA_nAFE = 1.

Note that the scheduler has to be enabled as well by LMA_nCTLL.LMA_nSCHE = 1.

In order to start LIN frame transactions with automatic frame start function the first Tx request bit LMA_nTCTLL.LMA_nFRQ has to be set to 1 in addition to the first Tx request LMA_nTCTLL.LMA_nTRQ. After LMA_nTRQ has returned to 0, it can be set again to 1, although the frame transfer is ongoing (LMA_nSTRH.LMA_nSST = 1). Thus the next frame transaction is started immediately after the next interframe space has passed.

During the interframe space all preparations (Rx/Tx buffer setup, etc.) have to be finished for the next frame transaction. These preparations can be triggered by the reception interrupt request INTLMAntIR.

Caution The reception interrupt request INTLMAntIR must be used to initiate frame preparations in Tx as well as in Rx mode.

The diagram below shows the principle timing of a LIN frame transmission with use of the scheduler and automatic frame start function.




Figure 17-12 LIN frame transmission with scheduler and automatic frame start function

Precondition The scheduler counter is operating and scheduler clock frequency has been set up.

LMAnt has been

- set into LIN master mode (LMAntCTLL.LMAntMD[1:0] = 1xB)
- scheduler is enabled (LMAntCTLL.LMAntSCHE = 1)
- automatic frame start function is enabled (LMAntCTLL.LMAntAFE = 1)
- enabled (LMAntCTLL.LMAntPW = 1)
- Tx buffer empty flag LMAntSTRH.LMAntXEF and Rx buffer full flag LMAntSTRH.LMAntRXFF are cleared
- Tx buffer has been set up correctly with frame slot length FRSL

Procedure

1. Start first transmission with automatic frame start function by LMAntCTLL.LMAntRQ = 1 and LMAntCTLL.LMAntFRQ = 1. Transmission start is indicated by LMAntSTRH.LMAntSST = 1. Sum of the current schedule counter value CNTAmCNT[15:0] and the frame slot length FRSL is stored to LMAntCmp.CMP[15:0].

After LMA_nTCTLL.LMA_nTRQ has returned to 0, the next transmission request can be set. At the latest it needs to be set before the interframe space has ended, i.e. in the gray area.

However in the diagram LMA_nTRQ is set in the interframe space.

2. After transmission of the checksum field CSF, i.e. after the frame length, the Tx buffer is indicated as empty (LMA_nSTRH.LMA_nTXEF = 1) and the Rx buffer as full (LMA_nSTRH.LMA_nRXFF = 1). The reception interrupt request INTLMA_nTIR is asserted.
3. All preparations are performed for the next frame transmission. The buffer status flags and the scheduler ready flag are cleared (LMA_nCLTXEF = LMA_nCLR_XFF = LMA_nCLSRF of LMA_nSTCH register set to 1). The next Tx request is set (LMA_nTCTLL.LMA_nTRQ = 1).
4. Upon match of the scheduler counter CNTAmCNT[15:0] and LMA_nCMP.LMA_nCMP[15:0], next frame transmission is started.

Preparation error If the next frame is not completely and correctly prepared,

- LMA_nTCTLL.LMA_nTRQ and LMA_nSTRH.LMA_nSST are cleared and frame transaction is not started
- LMA_nCMP.LMA_nCMP[15:0] is loaded with CNATmCNT[15:0] + FRSL
- the preparation incomplete error flag LMA_nSTRH.LMA_nPIE is set
- the status interrupt request LMA_nTIS is asserted

If frame preparation is completed with start of the next frame, i.e. if CNATmCNT[15:0] = LMA_nCMP.LMA_nCMP[15:0], frame transmission starts. Otherwise the next LMA_nTIS interrupt request is asserted to indicate another preparation incomplete error.

17.5 LMA Registers

This section contains a description of all registers of the LIN Master A.

17.5.1 LMA registers overview

The LMA is controlled and operated by means of the registers, listed in the table below.

One set of 16-bit and one set of 32-bit registers are provided, at which the bits of two 16-bit registers can be accessed via one 32-bit register. Note that the offset addresses for both sets are different.

Throughout this document all descriptions refer to the 16-bit register set. However the described functions of 16-bit registers bits apply also to bits with the same name in their associated 32-bit register.

Table 17-17 LMA registers

Register function	16-bit access registers		32-bit access registers	
	Name	Address	Name	Address
Control and status register:				
Control register	LMA nCTLL	<LMA n_base> + 80 _H	LMA nCTL0W	<LMA n_base> + 180 _H
	LMA nCTLH	<LMA n_base> + 84 _H		
Status register	LMA nSTRL	<LMA n_base> + 88 _H	LMA nSTROW	<LMA n_base> + 188 _H
	LMA nSTRH	<LMA n_base> + 8C _H		
Status clear register	LMA nSTCL	<LMA n_base> + 90 _H	LMA nSTC0W	<LMA n_base> + 190 _H
	LMA nSTCH	<LMA n_base> + 94 _H		
Compare register	LMA nCMPL	<LMA n_base> + 98 _H	LMA nCMP0W	<LMA n_base> + 198 _H
	LMA nCMPH	<LMA n_base> + 9C _H		
Tx control register	LMA nTCTLL	<LMA n_base> + D8 _H	LMA nTCTL0W	<LMA n_base> + 1D8 _H
	LMA nTCTLH	<LMA n_base> + DC _H		
Rx control register	LMA nRCTLL	<LMA n_base> + F8 _H	LMA nRCTL0W	<LMA n_base> + 1F8 _H
	LMA nRCTLH	<LMA n_base> + FC _H		
Tx buffer register:				
Tx buffer register 01	LMA nTX01	<LMA n_base> + C0 _H	LMA nTX00W	<LMA n_base> + 1C0 _H
Tx buffer register 23	LMA nTX23	<LMA n_base> + C4 _H		
Tx buffer register 45	LMA nTX45	<LMA n_base> + C8 _H	LMA nTX04W	<LMA n_base> + 1C8 _H
Tx buffer register 67	LMA nTX67	<LMA n_base> + CC _H		
Tx buffer register 89	LMA nTX89	<LMA n_base> + D0 _H	LMA nTX08W	<LMA n_base> + 1D0 _H
Tx buffer register AB	LMA nTXAB	<LMA n_base> + D4 _H		
Rx buffer register:				
Rx buffer register 01	LMA nRX01	<LMA n_base> + E0 _H	LMA nRX00W	<LMA n_base> + 1E0 _H
Rx buffer register 23	LMA nRX23	<LMA n_base> + E4 _H		
Rx buffer register 45	LMA nRX45	<LMA n_base> + E8 _H	LMA nRX04W	<LMA n_base> + 1E8 _H
Rx buffer register 67	LMA nRX67	<LMA n_base> + EC _H		
Rx buffer register 89	LMA nRX89	<LMA n_base> + F0 _H	LMA nRX08W	<LMA n_base> + 1F0 _H
Rx buffer register AB	LMA nRXAB	<LMA n_base> + F4 _H		

- <LMA_n_base>** The base addresses <LMA_n_base> of the LMA_n are defined in the first section of this chapter under the key word "Register addresses".
- Register access** All registers are accessible in 16-bit width.
Writing to non-existing register bits is ignored, reading of these bits return always 0.

17.5.2 LMA registers details

(1) LMACTL - LMA control register L

This register selects the LMA operation modes.

Note This register can only be changed when the LMA module is disabled (LMACTLH.LMAPW = 0).

Access This register can be read/written in 16-bit units.

Address <LMA_base> + 80_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	0	LMA MD[1:0]	LMA ACSE	LMA SCHE	LMA AFE	LMA ITMK	LMA IRMK	
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 17-18 LMACTL register contents (1/2)

Bit position	Bit name	Function										
6 to 5	LMA MD[1:0]	LMA operation mode selection <table border="1"> <thead> <tr> <th>MD[1:0]</th><th>Operation mode</th></tr> </thead> <tbody> <tr> <td>00_B</td><td>UART through mode The LMA is bypassed and the connected UART is used as a normal UART.</td></tr> <tr> <td>01_B</td><td>UART buffer mode The connected UART is used UART with buffer.</td></tr> <tr> <td>10_B</td><td>LIN master mode without break in header The connected UART is used as LIN master. Data transmission is continued even if data consistency errors within the LIN header (BF, SF) are detected. However, in case of an data consistency error in the PID data transmission is stopped.</td></tr> <tr> <td>11_B</td><td>LIN master mode with break in header The connected UART is used as LIN master. Data transmission is stopped if data consistency errors within the LIN header (BF, SF) are detected. In this case the status interrupt signal INTLMA_{TIS} is generated. Afterwards a new frame transaction with BF can be started.</td></tr> </tbody> </table>	MD[1:0]	Operation mode	00 _B	UART through mode The LMA is bypassed and the connected UART is used as a normal UART.	01 _B	UART buffer mode The connected UART is used UART with buffer.	10 _B	LIN master mode without break in header The connected UART is used as LIN master. Data transmission is continued even if data consistency errors within the LIN header (BF, SF) are detected. However, in case of an data consistency error in the PID data transmission is stopped.	11 _B	LIN master mode with break in header The connected UART is used as LIN master. Data transmission is stopped if data consistency errors within the LIN header (BF, SF) are detected. In this case the status interrupt signal INTLMA _{TIS} is generated. Afterwards a new frame transaction with BF can be started.
MD[1:0]	Operation mode											
00 _B	UART through mode The LMA is bypassed and the connected UART is used as a normal UART.											
01 _B	UART buffer mode The connected UART is used UART with buffer.											
10 _B	LIN master mode without break in header The connected UART is used as LIN master. Data transmission is continued even if data consistency errors within the LIN header (BF, SF) are detected. However, in case of an data consistency error in the PID data transmission is stopped.											
11 _B	LIN master mode with break in header The connected UART is used as LIN master. Data transmission is stopped if data consistency errors within the LIN header (BF, SF) are detected. In this case the status interrupt signal INTLMA _{TIS} is generated. Afterwards a new frame transaction with BF can be started.											

Table 17-18 LMA_nCTLL register contents (2/2)

Bit position	Bit name	Function
4	LMA _n ACSE	<p>Automatic checksum calculation enable 0: automatic checksum calculation disabled 1: automatic checksum calculation enabled In UART through or UART buffer mode (LMA_nMD[1:0] = 0x_B) this bit must be set to 0.</p> <p>If automatic checksum calculation is disabled, the</p> <ul style="list-style-type: none"> Rx checksum needs to be calculated by software and compared with the received checksum. Tx checksum need to be calculated by software and to be set to the TX buffer prior starting data transmission. <p>If automatic checksum calculation is enabled, the</p> <ul style="list-style-type: none"> Rx checksum is automatically calculated from the received data and compared with the received checksum. Tx checksum is automatically calculated and set to the TX buffer upon start of a data transmission.
3	LMA _n SCHE	<p>Scheduler enable 0: scheduler disabled 1: scheduler enabled In UART through or UART buffer mode (LMA_nMD[1:0] = 0x_B) this bit must be set to 0. Before the scheduler is enabled, the scheduler counter, that is connected to LMA_n, needs to be started.</p>
2	LMA _n AFE	<p>Automatic frame start function enable 0: automatic frame start function disabled 1: automatic frame start function enabled In UART through or UART buffer mode (LMA_nMD[1:0] = 0x_B) this bit must be set to 0. If the automatic frame start function is disabled, a frame transmission is started by software, when LMA_nTCTLL.LMA_nTRQ is set to 1. If the automatic frame start function is enabled, a frame transmission is automatically started by the scheduler immediately after the interframe space, if LMA_nTCTLL.LMA_nTRQ = 1.</p>
1	LMA _n ITMK	<p>Transmission interrupt request (INTLMA_nTIT) mask 0: INTLMA_nTIT not masked (INTLMA_nTIT generated) 1: INTLMA_nTIT masked (INTLMA_nTIT is not generated) In UART through or UART buffer mode (LMA_nMD[1:0] = 0x_B) this bit must be set to 0.</p>
0	LMA _n IRMK	<p>Reception interrupt request (INTLMA_nTIR) mask 0: INTLMA_nTIR not masked (INTLMA_nTIR generated) 1: INTLMA_nTIR masked (INTLMA_nTIR is not generated) In UART through or UART buffer mode (LMA_nMD[1:0] = 0x_B) this bit must be set to 0.</p>

(2) LMA_nCTLH - LMA_n control register H

This register enables/disables the LMA_n operation.

Access This register can be read/written in 16-bit units.

Address <LMA_n_base> + 84_H

Initial Value 0000_H

	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
LMA _n PW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 17-19 LMA_nCTLH register contents

Bit position	Bit name	Function
15	LMA _n PW	LMA _n enable 0: LMA _n disabled (internal clock stopped) 1: LMA _n enabled (internal clock operating) When LMA _n PW is set to 0, all operations are stopped and LMA _n is reset.

(3) LMA_nSTRL - LMA_n status register L

This register provides Rx process status indications.

Access This register can be read in 16-bit units.

Address <LMA_n_base> + 88_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
LMA _n SSB[2:0]			0	LMA _n RXBE[11:00]											
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Table 17-20 LMA_nSTRL register contents

Bit position	Bit name	Function								
15 to 13	LMA _n SSB[2:0]	Rx buffer mode status flags <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>SSB[2:0]</th><th>Rx buffer mode</th></tr> </thead> <tbody> <tr> <td>0_H</td><td>Idle state (no data was received)</td></tr> <tr> <td>5_H</td><td>Data has been received, but the Rx data length has not been reached. An Rx abort is necessary by LMA_nRCTLH.LMA_nRAB = 1.</td></tr> <tr> <td>other</td><td>Abnormal operation has occurred. An Rx abort is necessary by LMA_nRCTLH.LMA_nRAB = 1.</td></tr> </tbody> </table> LMA _n SSB[2:0] can be read for diagnostic purposes when a Rx process stalls.	SSB[2:0]	Rx buffer mode	0 _H	Idle state (no data was received)	5 _H	Data has been received, but the Rx data length has not been reached. An Rx abort is necessary by LMA _n RCTLH.LMA _n RAB = 1.	other	Abnormal operation has occurred. An Rx abort is necessary by LMA _n RCTLH.LMA _n RAB = 1.
SSB[2:0]	Rx buffer mode									
0 _H	Idle state (no data was received)									
5 _H	Data has been received, but the Rx data length has not been reached. An Rx abort is necessary by LMA _n RCTLH.LMA _n RAB = 1.									
other	Abnormal operation has occurred. An Rx abort is necessary by LMA _n RCTLH.LMA _n RAB = 1.									
11 to 0	LMA _n RXBE[11:00]	Rx buffer error flag <p>0: no UART error detections of data in the Rx buffer 11 to 00 1: UART has detected an error of data in the Rx buffer 11 to 00</p> The bit number [11:00] corresponds to the Rx buffer number: 0: Rx byte 0 (LMA _n RX01.LMA _n RX00B[7:0]) caused an error ... 11: Rx byte (LMA _n RXAB.LMA _n RX11B[7:0]) caused an error								
		Each bit remains at 1 until it is cleared by LMA _n STCL.LMA _n CLRRXBE[11:00] = 1.								

(4) LMA_nSTRH - LMA_n status register H

This register provides Rx process status indications.

Access This register can be read in 16-bit units.

Address <LMA_n_base> + 8C_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
LMA _n SST	LMA _n SSR	LMA _n TXEF	LMA _n RXFF	LMA _n ROVE	LMA _n FCSE	LMA _n SRF	LMA _n PIE	LMA _n BFE	LMA _n SFE	LMA _n SSL[5:0]					
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Table 17-21 LMA_nSTRH register contents (1/3)

Bit position	Bit name	Function
15	LMA _n SST	<p>Tx status flag 0: no Tx request issued 1: Tx request issued</p> <p>LMA_nSST is automatically set if a Tx request was set by LMA_nTCTLL.LMA_nTRQ = 1. If automatic frame start function in LIN mode is used (LMA_nCTLH.LMA_nAFE = 1), is automatically set upon automatic start of a new frame.</p> <p>This flag is not set in UART through mode.</p> <p>It is cleared by</p> <ul style="list-style-type: none"> • LMA_nCTLH.LMA_nPW = 0 • Tx process completion (frame transmission completed in LIN master mode)
14	LMA _n SSR	<p>Rx status flag 0: no Rx request issued 1: Rx request issued</p> <p>LMA_nSSR is automatically set if a Rx request was set by LMA_nRCTLL.LMA_nRRQ = 1.</p> <p>This flag is not set in UART through or LIN master mode.</p> <p>It is cleared by</p> <ul style="list-style-type: none"> • LMA_nCTLH.LMA_nPW = 0 • Rx process completion
13	LMA _n TXEF ^a	<p>Tx buffer empty flag 0: data remaining in Tx buffer to be transmitted 1: Tx buffer empty: last Tx data transmitted</p> <p>This flag is not set in UART through mode.</p> <p>It is cleared by</p> <ul style="list-style-type: none"> • LMA_nCTLH.LMA_nPW = 0 • LMA_nSTCH.LMA_nCLTXEF = 1

Table 17-21 LMASTRH register contents (2/3)

Bit position	Bit name	Function
12	LMA RXFF ^a	<p>Rx buffer full flag 0: data remaining to be received and to be stored in Rx buffer 1: Rx buffer full: last Rx data received</p> <p>This flag is not set in UART through mode.</p> <p>It is cleared by</p> <ul style="list-style-type: none"> • LMACTLH.LMAPW = 0 • LMASTCH.LMACLRXFF = 1
11	LMA ROVE ^a	<p>Rx buffer overflow flag 0: no Rx buffer overflow occurred 1: Rx buffer overflow occurred</p> <p>When an overflow occurs during data reception, the new data is not stored but discarded.</p> <p>This flag is not set in UART through or LIN master mode.</p> <p>It is cleared by</p> <ul style="list-style-type: none"> • LMACTLH.LMAPW = 0 • LMASTCH.LMACLROVE = 1
10	LMA FCSE ^a	<p>Checksum error flag 0: no checksum error occurred 1: checksum error occurred</p> <p>LMAFCSE indicates the result of the checksum control during a LIN frame reception. An error is indicated, if the checksum, calculated from the received data, does not match the received checksum.</p> <p>This flag is only effective in LIN master mode with automatic checksum function enabled (LMACTLL.LMACSE = 1).</p> <p>It is cleared by</p> <ul style="list-style-type: none"> • LMACTLH.LMAPW = 0 • LMASTCH.LMACLFCSE = 1
9	LMA SRF ^a	<p>Scheduler ready flag 0: no scheduler ready event occurred 1: scheduler ready event occurred</p> <p>A scheduler ready event occurs, when the value of the compare register LMACMPL.LMACMP[15:0] matches the value of the scheduler counter. In that case a status interrupt request INTLMAITIS is also asserted.</p> <p>This flag is only effective in LIN master mode with scheduler function enabled (LMACTLL.LMACSCHE = 1), while automatic frame start function remains disabled (LMACTLL.LMACAFE = 0).</p> <p>It is cleared by</p> <ul style="list-style-type: none"> • LMACTLH.LMAPW = 0 • LMASTCH.LMACLSRF = 1

Table 17-21 LMA nSTRH register contents (3/3)

Bit position	Bit name	Function								
8	LMA nPIE ^a	<p>Preparation incomplete error flag 0: Rx/Tx buffer preparation correct 1: Rx/Tx buffer preparation incorrect</p> <p>LMA nPIE is set, if a LIN master frame transfer is started, though the Rx respectively Tx buffer has not been prepared correctly. An incorrect buffer preparation is detected upon any of the following conditions:</p> <ul style="list-style-type: none"> • LMA nTXEF = 1 (Tx buffer empty) • LMA nSTRH.LMA nRXFF = 1 (Rx buffer full) • LMA nSTRH.LMA nTCTLL.LMA nTLG[3:0] holds incorrect value <p>This flag is only effective in LIN master mode.</p> <p>It is cleared by</p> <ul style="list-style-type: none"> • LMA nCTLH.LMA nPW = 0 • LMA nSTCH.LMA nCLPIE = 1 								
7	LMA nBFE ^a	<p>BF (Break Field) error flag 0: BF transmission successful 1: BF transmission failed</p> <p>LMA nBFE is set, if a framing, overrun or data consistency check error was detected during BF transmission at start of a LIN frame transmission. In case of an error detection the status interrupt request INTLMA nTIS is asserted.</p> <p>This flag is only effective in LIN master mode.</p> <p>It is cleared by</p> <ul style="list-style-type: none"> • LMA nCTLH.LMA nPW = 0 • LMA nSTCH.LMA nCLBFE = 1 								
6	LMA nSFE ^a	<p>SF (Sync Field) error flag 0: SF transmission successful 1: SF transmission failed</p> <p>LMA nSFE is set, if a framing, overrun or data consistency check error was detected during SF transmission at start of a LIN frame transmission. In case of an error detection the status interrupt request INTLMA nTIS is asserted.</p> <p>This flag is only effective in LIN master mode.</p> <p>It is cleared by</p> <ul style="list-style-type: none"> • LMA nCTLH.LMA nPW = 0 • LMA nSTCH.LMA nCLSFE = 1 								
5 to 0	LMA nSSL[5:0]	<p>LIN master mode status flag</p> <table border="1"> <thead> <tr> <th>LMA nSSL[5:0]</th> <th>LIN master mode status</th> </tr> </thead> <tbody> <tr> <td>0_H</td> <td>Idle state (no operation)</td> </tr> <tr> <td>19_H</td> <td>No response from slave. An Tx abort is necessary by LMA nTCTLH.LMA nTAB = 1.</td> </tr> <tr> <td>other</td> <td>Abnormal operation has occurred. An Tx abort is necessary by LMA nTCTLH.LMA nTAB = 1.</td> </tr> </tbody> </table> <p>LMA nSSL[2:0] can be read for diagnostic purposes when a LIN master transmission process stalls.</p>	LMA nSSL[5:0]	LIN master mode status	0 _H	Idle state (no operation)	19 _H	No response from slave. An Tx abort is necessary by LMA nTCTLH.LMA nTAB = 1.	other	Abnormal operation has occurred. An Tx abort is necessary by LMA nTCTLH.LMA nTAB = 1.
LMA nSSL[5:0]	LIN master mode status									
0 _H	Idle state (no operation)									
19 _H	No response from slave. An Tx abort is necessary by LMA nTCTLH.LMA nTAB = 1.									
other	Abnormal operation has occurred. An Tx abort is necessary by LMA nTCTLH.LMA nTAB = 1.									

a) Before starting a data transmission process, these flags should be cleared by setting the corresponding status clear bit in LMA nSTC register to 1.

(5) LMA_nSTCL - LMA_n status clear register L

This register is used to clear the status and error bits of the LMA_n status register L LMA_nSTRL.

Access This register can be written in 16-bit units.
Reading this register returns an undefined value.

Address <LMA_n_base> + 90_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	LMA _n CLR _X BE[11:00]											
W	W	W	W	W	W	W	W	W	W	W	W	W	W	W	W

Table 17-22 LMA_nSTCL register contents

Bit position	Bit name	Function
11 to 0	LMA _n CLR _X BE [11:00]	Clear Rx buffer error flags 0: writing 0 is ignored 1: writing 1 clears LMA _n RXBE[11:00]

(6) LMA_nSTCH - LMA_n status clear register H

This register is used to clear the status and error bits of the LMA_n status register L LMA_nSTRH.

Access This register can be written in 16-bit units.
Reading this register returns an undefined value.

Address <LMA_n_base> + 94_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	LMA _n CL TXEF	LMA _n CL RXFF	LMA _n CL ROVE	LMA _n CL FCSE	LMA _n CL SRF	LMA _n CL PIE	LMA _n CL BFE	LMA _n CL SFE	0	0	0	0	0	0
W	W	W	W	W	W	W	W	W	W	W	W	W	W	W	W

Table 17-23 LMA_nSTCH register contents

Bit position	Bit name	Function
13	LMA _n CL TXEF	Tx buffer empty flag 0: writing 0 is ignored 1: writing 1 clears LMA _n TXEF
12	LMA _n CL RXFF	Rx buffer full flag 0: writing 0 is ignored 1: writing 1 clears LMA _n RXFF
11	LMA _n CL ROVE	Rx buffer overflow flag 0: writing 0 is ignored 1: writing 1 clears LMA _n ROVE
10	LMA _n CL FCSE	Checksum error flag 0: writing 0 is ignored 1: writing 1 clears LMA _n FCSE
9	LMA _n CL SRF	Scheduler ready flag 0: writing 0 is ignored 1: writing 1 clears LMA _n SRF
8	LMA _n CL PIE	Preparation incomplete error flag 0: writing 0 is ignored 1: writing 1 clears LMA _n PIE
7	LMA _n CL BFE	BF (Break Field) error flag 0: writing 0 is ignored 1: writing 1 clears LMA _n BFE
6	LMA _n CL SFE	SF (Sync Field) error flag 0: writing 0 is ignored 1: writing 1 clears LMA _n SFE

(7) LMA_nCMPL - LMA_n compare register L

This register holds the lower 16 bit of scheduler comparison value.

Access This register can be read in 16-bit units.

Address <LMA_n_base> + 98_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
LMA _n CMP[15:0]															
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Table 17-24 LMA_nCMPL register contents

Bit position	Bit name	Function
15 to 0	LMA _n CMP[15:0]	Current scheduler comparison value LMA _n CMP[15:0] is loaded with the sum of the current free-running counter value CNATmCNT[15:0] and the frame slot length FRSL upon start of a LIN master frame.

(8) LMA_nCMPH - LMA_n compare register H

This register holds the upper 16 bit of scheduler comparison value.
These bits are always 0000_H.

Access This register can be read in 16-bit units.

Address <LMA_n_base> + 9C_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
LMA _n CMP[31:16]															
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Table 17-25 LMA_nCMPH register contents

Bit position	Bit name	Function
15 to 0	LMA _n CMP[31:16]	Current scheduler comparison value LMA _n CMP[31:16] are always 0000 _H .

(9) LMA_nTCTLL - LMA_n Tx control register L

This register controls the LMA_n Tx buffer.

Access This register can be read/written in 16-bit units.

Address <LMA_n_base> + D8_H

Initial Value 0000_H. This register is initialized by any reset and by LMA_nCTLH.LMA_nPW = 0.

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	LMA _n SLEC	LMA _n SLRT	LMA _n FRQ	LMA _n TRQ	LMA _n TLG[3:0]			
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 17-26 LMA_nTCTLL register contents (1/2)

Bit position	Bit name	Function
7	LMA _n SLEC	Enhanced checksum control 0: classic checksum Only the data bytes are used for checksum calculation. 1: enhanced checksum Checksum is calculated from the data and the PID. LMA _n SLEC is only effective, if automatic checksum calculation is enabled (LMA _n TCTLL.LMA _n ACSE = 1).
6	LMA _n SLRT	LIN master mode operation control 0: Tx mode 1: Rx mode LMA _n SLRT is only effective in LIN master mode.
5	LMA _n FRQ	First Tx request control 0: LIN frame transaction starts with the scheduler ready event 1: LIN frame transaction starts immediately by requesting transmission (LMA _n TRQ = 1), in case no Tx operation has been requested (LMA _n STRH.LMA _n SST = 0). In case LMA _n FRQ is set to 1 while LMA _n STRH.LMA _n SST = 1, LIN frame transaction starts with the next scheduler event, and thus behaves as with LMA _n FRQ = 0. Set LMA _n FRQ = 1 together with LMA _n TRQ = 1. LMA _n FRQ is only effective in LIN master mode with using the scheduler (LMA _n TCTLL/LMA _n SCHE = 1) and auto frame start enabled (LMA _n TCTLL.LMA _n AFE = 1). In all other modes, LMA _n FRQ shall be set to 0.
4	LMA _n TRQ	Tx request control 0: Tx operation has started or has not been requested. 1: Tx operation request In LIN master mode LMA _n TRQ = 1 triggers LIN frame transaction also in LIN master Rx mode (LMA _n SLRT = 1). After setting LMA _n TRQ = 1, LMA _n TRQ returns automatically to 0 when transmission has started. Writing 0 to LMA _n TRQ has no effect. In UART through (LMA _n MD[1:0] = 00 _B) this bit must be set to 0. Caution: It is prohibited to set LMA _n TRQ = 1 during a pending transmission request (LMA _n STRH.LMA _n SST = 1), except LMA _n is operating in LIN master mode with scheduler and auto frame start (LMA _n TCTLL register bits LMA _n SCHE = LMA _n AFE = 1).

Table 17-26 LMAntCTLL register contents (2/2)

Bit position	Bit name	Function																
3 to 0	LMAntTLG[3:0]	<p>Tx buffer length specification LMAntTLG[3:0] are only effective in UART buffer and LIN master mode.</p> <ul style="list-style-type: none"> in UART buffer mode <table border="1"> <thead> <tr> <th>LMAntTLG[3:0]</th> <th>Tx buffer length</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>12 byte transmission</td> </tr> <tr> <td>1 to 12</td> <td>1 to 12 byte transmission in UART buffer mode</td> </tr> <tr> <td>13 to 15</td> <td>prohibited</td> </tr> </tbody> </table> in LIN master mode <table border="1"> <thead> <tr> <th>LMAntTLG[3:0]</th> <th>Tx buffer length</th> </tr> </thead> <tbody> <tr> <td>0 to 1</td> <td>prohibited</td> </tr> <tr> <td>2 to 10</td> <td>2 to 10 byte transmission in LIN master mode</td> </tr> <tr> <td>11 to 15</td> <td>prohibited</td> </tr> </tbody> </table> <p>The value set to LMAntTLG[3:0] includes the PID and checksum bytes, thus a maximum of 8 data byte can be transmitted. If any of the prohibited values are set to LMAntTLG[3:0], a preparation incomplete error is detected and indicated by LMAntSTRH.LMAntPIE = 1.</p>	LMAntTLG[3:0]	Tx buffer length	0	12 byte transmission	1 to 12	1 to 12 byte transmission in UART buffer mode	13 to 15	prohibited	LMAntTLG[3:0]	Tx buffer length	0 to 1	prohibited	2 to 10	2 to 10 byte transmission in LIN master mode	11 to 15	prohibited
LMAntTLG[3:0]	Tx buffer length																	
0	12 byte transmission																	
1 to 12	1 to 12 byte transmission in UART buffer mode																	
13 to 15	prohibited																	
LMAntTLG[3:0]	Tx buffer length																	
0 to 1	prohibited																	
2 to 10	2 to 10 byte transmission in LIN master mode																	
11 to 15	prohibited																	

(10) LMA_nTCTLH - LMA_n Tx control register H

This register controls the Tx abort process.

Access This register can be read/written in 16-bit units.

Address <LMA_n_base> + DC_H

Initial Value 0000_H. This register is initialized by any reset and by LMA_nCTLH.LMA_nPW = 0.

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	LMA _n TAB
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 17-27 LMA_nTCTLH register contents

Bit position	Bit name	Function
0	LMA _n TAB	<p>Tx abort request</p> <p>0: reading returns always 0, writing 0 has no effect</p> <p>1: writing 1 requests Tx abort</p> <p>If LMA_nTAB is set to 1, Tx operation is stopped accordingly and the Tx status flag LMA_nSTRH.LMA_nSST is cleared.</p> <p>This bit has no effect in UART through mode.</p> <p>This bit is also effective during Rx process in LIN master mode.</p>

Note If Tx is aborted by LMA_nTAB = 1, the LMA_n stops to send any further data to the UART. However ongoing transmissions are completed by the UART. The complete stop of transmissions can be confirmed by URTE_nSTR0.URTE_nSST = 0.

(11) LMA_nRCTL - LMA_n Rx control register L

This register controls the LMA_n Rx buffer.

Access This register can be read/written in 16-bit units.

Address <LMA_n_base> + F8_H

Initial Value 0000_H. This register is initialized by any reset and by LMA_nCTLH.LMA_nPW = 0.

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	0	0	0	LMA _n RRQ	LMA _n RLG[3:0]			
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 17-28 LMA_nRCTL register contents

Bit position	Bit name	Function								
4	LMA _n RRQ	<p>Rx request control</p> <p>0: Rx operation has started or has not been requested.</p> <p>1: Rx operation request</p> <p>After setting LMA_nRRQ = 1, LMA_nRRQ returns automatically to 0 when reception data storage to the Rx buffer has started.</p> <p>Writing 0 to LMA_nRRQ has no effect.</p> <p>This bit is only effective in UART buffer mode. In all other modes this bit must not be set to 1.</p>								
3 to 0	LMA _n RLG[3:0]	<p>Rx buffer length specification</p> <p>LMA_nRLG[3:0] are only effective in UART buffer mode.</p> <table border="1"> <thead> <tr> <th>LMA_nRLG[3:0]</th><th>Rx buffer length</th></tr> </thead> <tbody> <tr> <td>0</td><td>continuous data reception</td></tr> <tr> <td>1 to 12</td><td>1 to 12 byte reception to Rx buffer</td></tr> <tr> <td>13 to 15</td><td>prohibited</td></tr> </tbody> </table> <p>In continuous data reception (LMA_nRLG[3:0] = 0) received data is stored to the Rx buffer continuously. After each 12 byte storage a reception interrupt INTLMA_nTIR or status interrupt INTLMA_nTIS request is generated. To stop continuous storage set LMA_nRLG[3:0] to 1 to 12.</p>	LMA _n RLG[3:0]	Rx buffer length	0	continuous data reception	1 to 12	1 to 12 byte reception to Rx buffer	13 to 15	prohibited
LMA _n RLG[3:0]	Rx buffer length									
0	continuous data reception									
1 to 12	1 to 12 byte reception to Rx buffer									
13 to 15	prohibited									

(12) LMA_nRCTLH - LMA_n Rx control register H

This register controls the Rx abort process.

Access This register can be read/written in 16-bit units.

Address <LMA_n_base> + FC_H

Initial Value 0000_H. This register is initialized by any reset and by LMA_nCTLH.LMA_nPW = 0.

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	LMA _n RAB
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 17-29 LMA_nRCTLH register contents

Bit position	Bit name	Function
0	LMA _n RAB	<p>Rx abort request</p> <p>0: reading returns always 0, writing 0 has no effect</p> <p>1: writing 1 requests Rx abort</p> <p>If LMA_nRAB is set to 1, Rx operation is stopped accordingly and the Rx status flag LMA_nSTRH.LMA_nSSR is cleared.</p> <p>This bit is only effective in UART buffer mode. In all other modes this bit must not be set to 1.</p> <p>This bit is also effective during Rx process in LIN master mode.</p>

Note If Rx is aborted by LMA_nRAB = 1, the LMA_n stops to store any data in the Rx buffer. However ongoing reception by the UART will be completed. The complete stop of reception can be confirmed by URTE_nSTR0.URTE_nSSR = 0.

Chapter 18 CAN Controller (FCN)

The microcontroller features on-chip CAN (Controller Area Network) controllers that complies with the CAN protocol as standardized in ISO 11898.

This chapter contains a generic description of the CAN Controller (FCN).

The first section describes all V850E2/Fx4-G specific properties, such as instances, register base addresses, input/output signal names, etc.

The subsequent sections describe the features that apply to all implementations.

18.1 V850E2/Fx4-G FCN Features

Instances This microcontroller has following number of instances of the CAN Controller.

Table 18-1 Instances of FCN

CAN Controller	V850E2/FF4-G (μPD70F4177) V850E2/FG4-G (μPD70F4179)	V850E2/FF4-G (μPD70F4178) V850E2/FG4-G (μPD70F4180)
Instance	3	6
Name	FCN0 to FCN2	FCN0 to FCN5

Instances index n Throughout this chapter, the instance of a CAN Controller is identified by the index “n” (n = 0 to 5), for example, FCNnGMCLCTL for the FCNn control register.

Message buffers index m Throughout this chapter, the FCN message buffer registers are identified by “m” (for m refer to the table below), for example FCNnMmDAT4B for FCN instance n, message data byte 4 of message buffer register m. The number of message buffers for each instance of FCN is given in the following table:

Table 18-2 Message buffers of FCNn

FCNn instance	Number m of message buffers
FCN0	32
FCN1	32
FCN2	32
FCN3	32
FCN4	32
FCN5	32

Register addresses All CAN Controller register addresses are given as address offsets to the individual base address <FCNn_base>. The <FCNn_base> address of each FCNn is given in the following table:

Table 18-3 Register base addresses <FCNn_base>

FCNn instance	<FCNn_base> address
FCN0	FF48 0000 _H
FCN1	FF4A 0000 _H
FCN2	FF4C 0000 _H
FCN3	FF4E 0000 _H
FCN4	FF50 0000 _H
FCN5	FF52 0000 _H

Clock supply All CAN Controllers provide one clock input:

Table 18-4 FCNn clock supply

FCNn instance	FCNn clock	Connected to
FCN0	PCLK (CANCLK f_{CAN})	Clock Controller CKSCLK_033
FCN1	PCLK (CANCLK f_{CAN})	Clock Controller CKSCLK_033
FCN2	PCLK (CANCLK f_{CAN})	Clock Controller CKSCLK_033
FCN3	PCLK (CANCLK f_{CAN})	Clock Controller CKSCLK_033
FCN4	PCLK (CANCLK f_{CAN})	Clock Controller CKSCLK_033
FCN5	PCLK (CANCLK f_{CAN})	Clock Controller CKSCLK_033




Figure 18-1 FCN clock supply

Interrupts and DMA The CAN Controllers can generate the following interrupt and DMA requests:

Table 18-5 FCNn interrupt and DMA requests (1/2)

FCNn signals	Function	Connected to
FCN0:		
INTC0ERR	Error indication	Interrupt Controller INTFCN0ERR
INTC0REC	Reception completion	Interrupt Controller INTFCN0REC ^a
INTC0TRX	Transmission completion	Interrupt Controller INTFCN0TRX DMA Controller trigger 28
INTC0WUP	Sleep wake-up / transmission abortion	Interrupt Controller INTFCNWUP ^b
FCN1:		
INTC1ERR	Error indication	Interrupt Controller INTFCN1ERR
INTC1REC	Reception completion	Interrupt Controller INTFCN1REC ^a
INTC1TRX	Transmission completion	Interrupt Controller INTFCN1TRX DMA Controller trigger 29
INTC1WUP	Sleep wake-up / transmission abortion	Interrupt Controller INTFCNWUP ^b
FCN2:		
INTC2ERR	Error indication	Interrupt Controller INTFCN2ERR
INTC2REC	Reception completion	Interrupt Controller INTFCN2REC ^a
INTC2TRX	Transmission completion	Interrupt Controller INTFCN2TRX DMA Controller trigger 30
INTC2WUP	Sleep wake-up / transmission abortion	Interrupt Controller INTFCNWUP ^b
FCN3:		
INTC3ERR	Error indication	Interrupt Controller INTFCN3ERR
INTC3REC	Reception completion	Interrupt Controller INTFCN3REC ^a
INTC3TRX	Transmission completion	Interrupt Controller INTFCN3TRX DMA Controller trigger 31
INTC3WUP	Sleep wake-up / transmission abortion	Interrupt Controller INTFCNWUP ^b
FCN4:		
INTC4ERR	Error indication	Interrupt Controller INTFCN4ERR
INTC4REC	Reception completion	Interrupt Controller INTFCN4REC ^a
INTC4TRX	Transmission completion	Interrupt Controller INTFCN4TRX DMA Controller trigger 32
INTC4WUP	Sleep wake-up / transmission abortion	Interrupt Controller INTFCNWUP ^b

Table 18-5 FCNn interrupt and DMA requests (2/2)

FCNn signals	Function	Connected to
FCN5:		
INTC5ERR	Error indication	Interrupt Controller INTFCN5ERR
INTC5REC	Reception completion	Interrupt Controller INTFCN5REC ^a
INTC5TRX	Transmission completion	Interrupt Controller INTFCN5TRX DMA Controller trigger 33
INTC5WUP	Sleep wake-up / transmission abortion	Interrupt Controller INTFCNWUP ^b

- a) These interrupts can be used as a wake-up source from any stand-by mode. Refer to the chapter “*Stand-by Controller (STBC)*” for details.
- b) The Interrupt Controller input INTFCNWUP is a combination of the wake-up interrupts of the CAN Controllers FCN0 to FCN5. Thus any of these wake-up interrupts asserts the interrupt request INTFCNWUP.

FCN H/W reset The CAN Controllers and their registers are initialized by the following reset signal:

Table 18-6 FCNn reset signal

FCNn	Reset signal
FCNn	<ul style="list-style-type: none"> Reset Controller SYSRES Stand-by Controller DPSTPWU (wake-up from DEEPSTOP mode)

I/O signals The I/O signals of the CAN Controllers are listed in the table below.

Table 18-7 CAN Controllers I/O signals

FCNn signals	Function	Connected to
FCN0:		
CRXD0	CAN bus receive input	Port FCN0RX ^a or FCN1RX ^b
CTXD0	CAN bus transmit output	Port FCN0TX
FCN1:		
CRXD1	CAN bus receive input	Port FCN1RX ^a
CTXD1	CAN bus transmit output	Port FCN1TX
FCN2:		
CRXD2	CAN bus receive input	Port FCN2RX ^a
CTXD2	CAN bus transmit output	Port FCN2TX
FCN3:		
CRXD3	CAN bus receive input	Port FCN3RX ^a
CTXD3	CAN bus transmit output	Port FCN3TX
FCN4:		
CRXD4	CAN bus receive input	Port FCN4RX ^a
CTXD4	CAN bus transmit output	Port FCN4TX
FCN5:		
CRXD5	CAN bus receive input	Port FCN5RX ^a
CTXD5	CAN bus transmit output	Port FCN5TX

- a) These signals can be used as a wake-up source from any stand-by mode. Refer to the chapter “Stand-by Controller (STBC)” for details.
- b) Refer to 17.7 “FCN0 and FCN1 connection” on page 1 for details.

Time stamp Following FCNn time stamp output signals can be internally connected to a capture input of the Timer Array Units B.

Table 18-8 FCNn time stamp signals

FCNn signals	Function	Connected to
FCN0:		
TSOUT	CAN time stamp output	TAUB0 TAUB0TTIN0, TAUB0TTIN10
FCN1:		
TSOUT	CAN time stamp output	TAUB0 TAUB0TTIN1, TAUB0TTIN11
FCN2:		
TSOUT	CAN time stamp output	TAUB0 TAUB0TTIN2, TAUB0TTIN12
FCN3:		
TSOUT	CAN time stamp output	TAUB0 TAUB0TTIN3, TAUB0TTIN13
FCN4:		
TSOUT	CAN time stamp output	TAUB0 TAUB0TTIN4, TAUB0TTIN14
FCN5:		
TSOUT	CAN time stamp output	TAUB0 TAUB0TTIN5, TAUB0TTIN15

Refer to section “*TAUB Input Selections*” in the “*Timer Array Unit B (TAUB)*” for details.

18.2 FCN0 and FCN1 connection

The FCN0 and FCN1 CAN Controllers have the option to be connected to the same CAN bus signals. This allow to operate the two CAN Controllers on the same CAN bus (FCN1 signals) thus allowing twice the number of message buffer support on this bus.

The following figure depicts the FCN0 and FCN1 connection scheme:




Figure 18-2 FCN0 and FCN1 connection scheme

(1) ITGSLFC0 - FCN0 signal connection selection register

This register selects the signals of FCN0.

Access This register can be read/written in 8-bit units.

Address FF77 2008_H

Initial Value 00_H

7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	ITGSL FC00
R	R	R	R	R	R	R	R/W

Table 18-9 ITGSLFC0 register contents

Bit position	Bit name	Function
0	ITGSLFC00	FCN0 signal selection 0: use FCN0 bus signals (FCN0RX, FCN0TX) 1: use FCN1 bus signals (FCN1RX, FCN1TX) - combined operation

18.3 CAN baudrate and time quanta

When configuring the CAN Controller (FCN) one of the following combinations for

- the CAN Controller clock f_{CAN} ,
- the CAN baudrate and
- the number of time quantas (TQ) per data bit time (DBT)

must be used:

Table 18-10 CAN baudrate settings

CAN baudrate [kbps]	CAN Controller clock f_{CAN} [MHz]	TQs per DBT
1000	16	8
	24	8
	32	8
	40	8, 10
	48	8, 12, 16
500	8	8, 16
	16	8, 16
	20	10
	24	8, 12
	32	8, 16
	40	8, 10, 20
	48	8, 12, 16, 24
250/125	8	8, 16
	16	8, 16
	20	10, 20
	24	8, 12, 24
	32	8, 16
	40	8, 10, 20
	48	8, 12, 16, 24

Thus make sure to set the

- global clock selection register FCNnGMCSPRE
- module bit rate prescaler register FCNnCMBRPRS
- module bit rate register FCNnCMBTCTL

accordingly.

Note The table describes common combinations. For other combinations please contact your local Renesas engineering representative.

18.4 Features

- Compliant with ISO 11898 and tested according to ISO/DIS 16845 (CAN conformance test)
- Standard frame and extended frame transmission/reception enabled
- Transfer rate: 1 Mbps max. (if CAN Controller clock input \geq 16 MHz, for 64 or more message buffers)
- 32, 64 or 128 message buffers per channel
For the number of available message buffers for each CAN Controller refer to the key word "Message buffers index m" in the first section of this chapter.
- Receive/transmit history list function, with enable flag for each message buffer individually
- Automatic block transmission function
- Multi-buffer receive block function
- Mask setting of 8 patterns is possible for each channel, applicable for data and remote frames
- Data bit time, communication baudrate and sample point can be controlled by CAN channel bit-rate prescaler register (FCNnCMBRPRS) and bit rate register (FCNnCMBTCTL)
 - As an example the following sample-point configurations can be configured:
 - 66.7%, 70.0%, 75.0%, 80.0%, 81.3%, 85.0%, 87.5%
 - Baudrates in the range of 10 kbps up to 1000 kbps can be configured
- Enhanced features:
 - Each message buffer can be configured to operate as a transmit or a receive message buffer
 - A transmission request can be aborted by clearing the dedicated Transmit-Request flag of the concerned message buffer. Supported by Transmission Abort Interrupt, on successful abortion.
 - Automatic block transmission operation mode (ABT)
 - Time stamp function in collaboration with timers capture channels
 - Centralized data new flag register, collecting all data new flags to be read from one location

18.4.1 Overview of functions

Table 18-11 "Overview of functions" presents an overview of the CAN Controller functions.

Table 18-11 Overview of functions

Function	Details
Protocol	CAN protocol ISO 11898 (standard and extended frame transmission/reception)
Baudrate	Maximum 1 Mbps (minimum CAN Controller clock input = 16 MHz)
Data storage	Storing messages in the CAN RAM
Number of messages	<ul style="list-style-type: none"> • 32, 64 or 128 message buffers per channel • For the number of available message buffers for each CAN Controller refer to the key word "Message buffers index m" in the first section of this chapter. • Each message buffer can be set to be either a transmit message buffer or a receive message buffer.
Message reception	<ul style="list-style-type: none"> • Unique ID can be set to each message buffer. • Mask setting of 8 patterns is possible for each channel, applicable for data and remote frames • A receive completion interrupt is generated each time a message is received and stored in a message buffer. • Two or more receive message buffers can be used as a FIFO receive buffer (multi-buffer receive block function). • Receive history list function, with enable flag for each message buffer individually • Centralized Data New Flag register
Message transmission	<ul style="list-style-type: none"> • Unique ID can be set to each message buffer. • Transmit completion interrupt for each message buffer • Transmit Abort interrupt and -flag for each message buffer (only one transmission of any buffer can be aborted at a time) • Message buffer number 0 to 7 ($m = 32$) / 15 ($m = 64$) / 31 ($m = 128$) specified as the transmit message buffer can be set for automatic block transfer. Message transmission interval is programmable (automatic block transmission function (hereafter referred to as "ABT")). • Transmission history list function, with enable flag for each message buffer individually
Remote frame processing	<ul style="list-style-type: none"> • Remote frame processing by transmit message buffer • Remote frame processing by receive message buffer, when applying one of the 8 masks
Time stamp function	<ul style="list-style-type: none"> • The time stamp function can be set for a message reception when a 16-bit timer is used in combination. • Time stamp capture trigger can be selected (SOF or EOF in a CAN message frame can be detected.).
Diagnostic function	<ul style="list-style-type: none"> • Readable error counters • "Valid protocol operation flag" for verification of bus connections • Receive-only mode • Single-shot mode • CAN protocol error type decoding • Self-test mode
Release from bus-off state	<ul style="list-style-type: none"> • Forced release from bus-off (by ignoring timing constraint) possible by software. • No automatic release from bus-off (software must re-enable).
Power save mode	<ul style="list-style-type: none"> • Sleep mode (can be woken up by CAN bus) • Stop mode (cannot be woken up by CAN bus)

18.4.2 Configuration

The CAN Controller is composed of the following four blocks.

- **PBUS interface**
This functional block provides an PBUS interface and means of transmitting and receiving messages between the CAN Controller and the host CPU.
- **MAC (Memory Access Controller)**
This functional block controls access to the CAN protocol layer and to the CAN RAM within the CAN Controller.
- **CAN protocol layer**
This functional block is involved in the operation of the CAN protocol and its related settings.
- **CAN RAM**
The CAN RAM is used to store message IDs, message data, etc.




Figure 18-3 Block diagram of the CAN Controller

Note For the number m of available message buffers for each CAN Controller refer to the key word “Message buffers index m ” in the first section of this chapter.

CAN RAM The CAN RAM is equipped with a memory checking module. If a CAN RAM error occurs during a software reset, the message buffer RAM read error detection bit FCNnGMCLCTL.FCNnGMCLECCF is set. Check the CAN Controller functionality in such case.

18.5 Internal Registers of CAN Controller

18.5.1 CAN Controller configuration

Table 18-12 List of CAN Controller registers (1/2)

Item	Register Name
CAN Controller global registers	FCNn global control register (FCNnGMCLCTL)
	FCNn global clock selection register (FCNnGMCSPRE)
	FCNn global automatic block transmission control register (FCNnGMABCTL)
	FCNn global automatic block transmission delay setting register (FCNnGMADCTL)
	FCNn global Data New bit monitor registers (FCNnDNBMRX0 - FCNnDNBMRX3)
CAN channel registers	FCNn channel mask 1 registers (FCNnCMMKCTL01H, FCNnCMMKCTL02H, FCNnCMMKCTL01W)
	FCNn channel mask 2 registers (FCNnCMMKCTL03H, FCNnCMMKCTL04H, FCNnCMMKCTL03W)
	FCNn channel mask3 registers (FCNnCMMKCTL05H, FCNnCMMKCTL06H, FCNnCMMKCTL05W)
	FCNn channel mask 4 registers (FCNnCMMKCTL07H, FCNnCMMKCTL08H, FCNnCMMKCTL07W)
	FCNn channel mask 5 registers (FCNnCMMKCTL09H, FCNnCMMKCTL10H, FCNnCMMKCTL09W)
	FCNn channel mask 6 registers (FCNnCMMKCTL11H, FCNnCMMKCTL12H, FCNnCMMKCTL11W)
	FCNn channel mask registers (FCNnCMMKCTL13H, FCNnCMMKCTL14H, FCNnCMMKCTL13W)
	FCNn channel mask 8 registers (FCNnCMMKCTL15H, FCNnCMMKCTL16H, FCNnCMMKCTL15W)
	FCNn channel control register (FCNnCMCLCTL)
	FCNn channel last error information register (FCNnCMLCSTR)
	FCNn channel information register (FCNnCMLCSTR)
	FCNn channel error counter register (FCNnCMERCNT)
	FCNn channel last error code register (FCNnCMLCSTR)
	FCNn channel interrupt enable register (FCNnCMIECTL)
	FCNn channel interrupt status register (FCNnCMISCTL)
	FCNn channel bit rate prescaler and clock selector register (FCNnCMBRPRS)
	FCNn channel bit rate register (FCNnCMBTCTL)
	FCNn channel last in-pointer register (FCNnCMLISTR)
	FCNn channel receive history list register (FCNnCMRGRX)
	FCNn channel last out-pointer register (FCNnCMLOSTR)
	FCNn channel transmit history list register (FCNnCMTGTX)
	FCNn channel time stamp register (FCNnCMTSCTL)
	FCNn Controller message data byte 0 to 3 registers m (FCNnMmDAT0W, FCNnMmDAT0H, FCNnMmDAT2H, FCNnMmDAT0B, FCNnMmDAT1B, FCNnMmDAT2B, FCNnMmDAT3B)

Table 18-12 List of CAN Controller registers (2/2)

Item	Register Name
CAN Controller message buffer registers	FCNn message data byte 4 to 7 registers m (FCNnMmDAT4W, FCNnMmDAT4H, FCNnMmDAT6H, FCNnMmDAT4B, FCNnMmDAT5B, FCNnMmDAT6B, FCNnMmDAT7B)
	FCNn message data length register m (FCNnMmDTLGB)
	FCNn message configuration register m (FCNnMmSTRB)
	FCNn message ID registers m (FCNnMmMID0H, FCNnMmMID1H, FCNnMmMID0W)
	FCNn message control register m (FCNnMmCTL)

18.5.2 CAN Controller Registers Overview

Address offset All register addresses are given as offsets to the base address <FCNn_base>. The <FCNn_base> addresses of the registers are defined in the first section of this chapter under the keyword “Register addresses”.

(1) CAN Controller global and channel registers

Table 18-13 CAN Controller global and channel registers (1/2)

Address offset	Register name	Symbol	R/W	Access bit	After reset
0 0008 _H	FCNn global clock selection register	FCNnGMCSPRE	R/W	8	0F _H
0 0020 _H	FCNn global automatic block transmission delay register	FCNnGMADCTL	R/W	8	00 _H
0 8000 _H	FCNn global control register	FCNnGMCLCTL	R/W	16	00x0 _H ^a
0 8018 _H	FCNn global automatic block transmission register	FCNnGMABCTL	R/W	16	0000 _H
1 00C0 _H	FCNn global data new bit monitor register 0	FCNnDNBMRX0	R	32	0000 0000 _H
1 00D0 _H	FCNn global data new bit monitor register 1	FCNnDNBMRX1	R	32	0000 0000 _H
1 00E0 _H	FCNn global data new bit monitor register 2	FCNnDNBMRX2	R	32	0000 0000 _H
1 00F0 _H	FCNn global data new bit monitor register 3	FCNnDNBMRX3	R	32	0000 0000 _H
0 8300 _H	FCNn channel mask 1 register	FCNnCMMKCTL01H	R/W	16	0000 _H
0 8308 _H		FCNnCMMKCTL02H			
1 0300 _H		FCNnCMMKCTL01W		32	
0 8310 _H	FCNn channel mask 2 register	FCNnCMMKCTL03H	R/W	16	0000 _H
0 8318 _H		FCNnCMMKCTL04H			
1 0310 _H		FCNnCMMKCTL03W		32	
0 8320 _H	FCNn channel mask 3 register	FCNnCMMKCTL05H	R/W	16	0000 _H
0 8328 _H		FCNnCMMKCTL06H			
1 0320 _H		FCNnCMMKCTL05W		32	
0 8330 _H	FCNn channel mask 4 register	FCNnCMMKCTL07H	R/W	16	0000 _H
0 8338 _H		FCNnCMMKCTL08H			
1 0330 _H		FCNnCMMKCTL07W		32	
0 8340 _H	FCNn channel mask 5 register	FCNnCMMKCTL09H	R/W	16	0000 _H
0 8348 _H		FCNnCMMKCTL10H			
1 0340 _H		FCNnCMMKCTL09W		32	
0 8350 _H	FCNn channel mask 6 register	FCNnCMMKCTL11H	R/W	16	0000 _H
0 8358 _H		FCNnCMMKCTL12H			
1 0350 _H		FCNnCMMKCTL11W		32	

Table 18-13 CAN Controller global and channel registers (2/2)

Address offset	Register name	Symbol	R/W	Access bit	After reset
0 8360 _H	FCNn channel mask 7 register	FCNnCMMKCTL13H	R/W	16	0000 _H
0 8368 _H		FCNnCMMKCTL14H			
1 0360 _H		FCNnCMMKCTL13W		32	0000 0000 _H
0 8370 _H	FCNn channel mask 8 register	FCNnCMMKCTL15H	R/W	16	0000 _H
0 8378 _H		FCNnCMMKCTL16H			
1 0370 _H		FCNnCMMKCTL15W		32	0000 0000 _H
0 0248 _H	FCNn channel last error code register	FCNnCMLCSTR	R/W	8	00 _H
0 024C _H	FCNn channel information register	FCNnCMINSTR	R	8	00 _H
0 0268 _H	FCNn channel bit-rate prescaler and clock selector register	FCNnCMBRPRS	R/W	8	FF _H
0 0278 _H	FCNn channel last in-pointer register	FCNnCMLISTR	R	8	Undefined
0 0288 _H	FCNn channel last out-pointer register	FCNnCMLOSTR	R	8	Undefined
0 8240 _H	FCNn channel control register	FCNnCMCLCTL	R/W	16	0000 _H
0 8250 _H	FCNn channel error counter register	FCNnCMERCNT	R	16	0000 _H
0 8258 _H	FCNn channel interrupt enable register	FCNnCMIECTL	R/W	16	0000 _H
0 8260 _H	FCNn channel interrupt status register	FCNnCMISCTL	R/W	16	0000 _H
0 8270 _H	FCNn channel bit-rate register	FCNnCMBTCTL	R/W	16	370F _H
0 8280 _H	FCNn channel receive history list register	FCNnCMRGRX	R/W	16	xx02 _H
0 8290 _H	FCNn channel transmit history list register	FCNnCMTGTX	R/W	16	xx02 _H
0 8298 _H	FCNn channel time stamp register	FCNnCMTSCTL	R/W	16	0000 _H

a) Initial value depends on FCNnGMCLCTL.FCNnGMCLECCF, which indicates error detections when reading from message buffer RAM. Refer to the detailed description of the FCNnGMCLCTL register.

18.5.3 Register bit configuration

Table 18-14 CAN Controller global register bit configuration

Address offset	Symbol	Bit 7/ 15/23/ 31	Bit 6/ 14/22/ 30	Bit 5/ 13/21/ 29	Bit 4/ 12/20/ 28	Bit 3/ 11/19/ 27	Bit 2/ 10/18/ 26	Bit 1/ 9/17/ 25	Bit 0/ 8/16/ 24
0 8000 _H	FCNnGMCLCTL (W)	0	0	FCNnGM CLCLMB		0	0	0	FCNnGMC LCLOM
		0	0	0	FCNnGM CLSESR	0	0	FCNnGM CLSESD	FCNnGMC LSEOM
	FCNnGMCLCTL (R)	0	0	FCNnGM CLECCF	FCNnGM CLSORF	0	0	FCNnGM CLESDE	FCNnGMC LPWOM
		FCNnGM CLSSMO	0	0	0	0	0	0	0
0 0008 _H	FCNnGMCSPRE	0	0	0	0	FCNnGMCSPRSC[3:0]			
0 8018 _H	FCNnGMABCTL (W)	0	0	0	0	0	0	0	FCNnGMA BCLAT
		0	0	0	0	0	0	FCNnGM ABSEAC	FCNnGMA BSEAT
	FCNnGMABCTL (R)	0	0	0	0	0	0	FCNnGM ABCLRF	FCNnGMA BABTT
		0	0	0	0	0	0	0	0
0 0020 _H	FCNnGMADCTL	0	0	0	0	FCNnGMADSSAD[3:0]			
1 00C0 _H	FCNnDNBMRX0 (R)	FCNnDNBMSSDN[7:0]							
		FCNnDNBMSSDN[15:8]							
		FCNnDNBMSSDN[23:16]							
		FCNnDNBMSSDN[31:24]							
1 00D0 _H	FCNnDNBMRX1 (R) ^a	FCNnDNBMSSDN[39:32]							
		FCNnDNBMSSDN[47:40]							
		FCNnDNBMSSDN[55:48]							
		FCNnDNBMSSDN[63:56]							
1 00E0 _H	FCNnDNBMRX2 (R) ^b	FCNnDNBMSSDN[71:64]							
		FCNnDNBMSSDN[79:72]							
		FCNnDNBMSSDN[87:80]							
		FCNnDNBMSSDN[95:88]							
1 00F0 _H	FCNnDNBMRX3 (R) ^b	FCNnDNBMSSDN[103:96]							
		FCNnDNBMSSDN[111:104]							
		FCNnDNBMSSDN[119:112]							
		FCNnDNBMSSDN[127:120]							

a) Only available with 64 (m = 0 to 63) and 128 message buffers (m = 0 to 127)

b) Only available with 128 message buffers (m = 0 to 127)

Table 18-15 CAN channel mask control 16-bit registers bit configuration

Address offset	Symbol	Bit 15	Bit 14	Bit 13	Bit 12 to 0
0 8300 _H	FCNnCMMK CTL01H	FCNnCMMKSSID[15:0]			
0 8308 _H	FCNnCMMK CTL02H	0	0	0	FCNnCMMKSSID[28:16]
0 8310 _H	FCNnCMMK CTL03H	FCNnCMMKSSID[15:0]			
0 8318 _H	FCNnCMMK CTL04H	0	0	0	FCNnCMMKSSID[28:16]
0 8320 _H	FCNnCMMK CTL05H	FCNnCMMKSSID[15:0]			
0 8328 _H	FCNnCMMK CTL06H	0	0	0	FCNnCMMKSSID[28:16]
0 8330 _H	FCNnCMMK CTL07H	FCNnCMMKSSID[15:0]			
0 8338 _H	FCNnCMMK CTL08H	0	0	0	FCNnCMMKSSID[28:16]
0 8340 _H	FCNnCMMK CTL09H	FCNnCMMKSSID[15:0]			
0 8348 _H	FCNnCMMK CTL10H	0	0	0	FCNnCMMKSSID[28:16]
0 8350 _H	FCNnCMMK CTL11H	FCNnCMMKSSID[15:0]			
0 8358 _H	FCNnCMMK CTL12H	0	0	0	FCNnCMMKSSID[28:16]
0 8360 _H	FCNnCMMK CTL13H	FCNnCMMKSSID[15:0]			
0 8368 _H	FCNnCMMK CTL14H	0	0	0	FCNnCMMKSSID[28:16]
0 8370 _H	FCNnCMMK CTL15H	FCNnCMMKSSID[15:0]			
0 8378 _H	FCNnCMMK CTL16H	0	0	0	FCNnCMMKSSID[28:16]

Table 18-16 CAN channel mask control 32-bit registers bit configuration (1/2)

Address offset	Symbol	Bit 31	Bit 30	Bit 29	Bit 28 to 0
1 0300 _H	FCNnCMMK CTL01W	0	0	0	FCNnCMMKSSID[28:0]
1 0310 _H	FCNnCMMK CTL03W	0	0	0	FCNnCMMKSSID[28:0]
1 0320 _H	FCNnCMMK CTL05W	0	0	0	FCNnCMMKSSID[28:0]
1 0330 _H	FCNnCMMK CTL07W	0	0	0	FCNnCMMKSSID[28:0]
1 0340 _H	FCNnCMMK CTL09W	0	0	0	FCNnCMMKSSID[28:0]

Table 18-16 CAN channel mask control 32-bit registers bit configuration (2/2)

Address offset	Symbol	Bit 31	Bit 30	Bit 29	Bit 28 to 0
1 0350 _H	FCNnCMMK CTL11W	0	0	0	FCNnCMMKSSID[28:0]
1 0360 _H	FCNnCMMK CTL13W	0	0	0	FCNnCMMKSSID[28:0]
1 0370 _H	FCNnCMMK CTL15W	0	0	0	FCNnCMMKSSID[28:0]

Table 18-17 CAN channel register bit configuration (1/2)

Address offset	Symbol	Bit 7/15	Bit 6/14	Bit 5/13	Bit 4/12	Bit 3/11	Bit 2/10	Bit 1/9	Bit 0/8
0 8240 _H	FCNnCM CLCTL (W)	0	FCNnCM CLCLAL	FCNnCM CLCLVL	FCNnCMCLCLPS[1:0]		FCNnCMCLCLOP[2:0]		
		FCNnCM CLSERC	FCNnCM CLCSEAL	0	FCNnCMSESEPS[1:0]		FCNnCMCSELOP[2:0]		
	FCNnCM CLCTL (R)	FCNnCM CLERCF	FCNnCM CLALBF	FCNnCM CLVALF	FCNnCMCLMDPF[1:0]		FCNnCMCLMDOF[2:0]		
		0	0	0	0	0	0	FCNnCMC LSSRS	FCNnCMC LSSTS
0 00248 _H	FCNnCM LCSTR (W)	0	0	0	0	0	0	0	0
	FCNnCM LCSTR (R)	0	0	0	0	0	FCNnCMCLCSSL[2:0]		
0 024CH	FCNnCM INSTR	0	0	0	FCNnCM NBOFF	FCNnCMINSSTE[1:0]		FCNnCMINSSRE[1:0]	
0 8250 _H	FCNnCM ERCNT	FCNnCMERTECF[7:0]							
		FCNnCM ERRPSF	FCNnCMERRECF[6:0]						
0 8258 _H	FCNnCM IECTL (W)	0	FCNnCMIECLIE[6:0]						
		0	FCNnCMIESEIE[6:0]						
	FCNnCM IECTL (R)	0	FCNnCMIEINTF[6:0]						
		0	0	0	0	0	0	0	0
0 8260 _H	FCNnCM ISCTL (W)	0	FCNnCMISCLTS[6:0]						
		0	0	0	0	0	0	0	0
	FCNnCM ISCTL (R)	0	FCNnCMISITSF[6:0]						
		0	0	0	0	0	0	0	0
0 0268 _H	FCNnCM BRPRS	FCNnCMBRPRS[7:0]							
0 8270 _H	FCNnCM BTCTL	0	0	0	0	FCNnCMBTS1LG[3:0]			
		0	0	FCNnCMBTJWLG[1:0]		0	FCNnCMBTS2LG[2:0]		
0 0278 _H	FCNnCM LISTR	FCNnCMLISSLR[7:0]							

Table 18-17 CAN channel register bit configuration (2/2)

Address offset	Symbol	Bit 7/15	Bit 6/14	Bit 5/13	Bit 4/12	Bit 3/11	Bit 2/10	Bit 1/9	Bit 0/8
0 8280 _H	FCNnCM RGRX (W)	0	0	0	0	0	0	0	FCNnCMR GCLR
		0	0	0	0	0	0	0	0
	FCNnCM RGRX (R)	0	0	0	0	0	0	FCNnCMR GSSPM	FCNnCMR GRVFF
		FCNnCMRGSSPT[7:0]							
0 0288 _H	FCNnCM LOSTR	FCNnCMLOSTRSSLT[7:0]							
0 8290 _H	FCNnCM TGTX (W)	0	0	0	0	0	0	0	FCNnCMT GCLTV
		0	0	0	0	0	0	0	0
	FCNnCM TGTX (R)	0	0	0	0	0	0	FCNnCMT GSSPM	FCNnCMT GTVFF
		FCNnCMTGSSPT[7:0]							
0 8298 _H	FCNnCM TSCTL (W)	0	0	0	0	0	FCNnCMT SCLK	FCNnCMT SCLSL	FCNnCMT SCLTS
		0	0	0	0	0	FCNnCMT SSELK	FCNnCMT SSEL	FCNnCMT SSETS
	FCNnCM TSCTL (R)	0	0	0	0	0	FCNnCMT SLOKE	FCNnCMT SLE	FCNnCMT STSGE
		0	0	0	0	0	0	0	0

Table 18-18 Message buffer register bit configuration (1/2)

Address offset	Symbol	Bit 7/15/ 23/31	Bit 6/14/ 22/30	Bit 5/13/ 21/29	Bit 4/12/ 20/28	Bit 3/11/ 19/27	Bit 2/10/ 18/26	Bit 1/9/ 17/25	Bit 0/8/ 16/24
1 1000 _H + m × 40 _H	FCNnMm DAT0W	FCNnMmSSD0[7:0]							
		FCNnMmSSD1[7:0]							
		FCNnMmSSD2[7:0]							
		FCNnMmSSD3[7:0]							
0 9000 _H + m × 40 _H	FCNnMm DAT0H	FCNnMmSSD0[7:0]							
		FCNnMmSSD1[7:0]							
0 1000 _H + m × 40 _H	FCNnMm DAT0B	FCNnMmSSD0[7:0]							
0 1004 _H + m × 40 _H	FCNnMm DAT1B	FCNnMmSSD1[7:0]							
		FCNnMmSSD2[7:0]							
0 9008 _H + m × 40 _H	FCNnMm DAT2H	FCNnMmSSD2[7:0]							
		FCNnMmSSD3[7:0]							
0 1008 _H + m × 40 _H	FCNnMm DAT2B	FCNnMmSSD2[7:0]							
0 100C _H + m × 40 _H	FCNnMm DAT3B	FCNnMmSSD3[7:0]							

Table 18-18 Message buffer register bit configuration (2/2)

Address offset	Symbol	Bit 7/15/ 23/31	Bit 6/14/ 22/30	Bit 5/13/ 21/29	Bit 4/12/ 20/28	Bit 3/11/ 19/27	Bit 2/10/ 18/26	Bit 1/9/ 17/25	Bit 0/8/ 16/24	
1 1010 _H + m × 40 _H	FCNnMm DAT4W	FCNnMmSS4[7:0]								
		FCNnMmSSD5[7:0]								
		FCNnMmSSD6[7:0]								
		FCNnMmSSD7[7:0]								
0 9010 _H + m × 40 _H	FCNnMm DAT4H	FCNnMmSSD4[7:0]								
		FCNnMmSSD5[7:0]								
0 1010 _H + m × 40 _H	FCNnMm DAT4B	FCNnMmSSD4[7:0]								
0 1014 _H + m × 40 _H	FCNnMm DAT5B	FCNnMmSSD5[7:0]								
0 9018 _H + m × 40 _H	FCNnMm DAT6H	FCNnMmSSD6[7:0]								
		FCNnMmSSD7[7:0]								
0 1018 _H + m × 40 _H	FCNnMm DAT6B	FCNnMmSSD6[7:0]								
0 101C _H + m × 40 _H	FCNnMm DAT7B	FCNnMmSSD7[7:0]								
0 1020 _H + m × 40 _H	FCNnMm DTLGB	0				FCNnMmDTLG[3:0]				
0 1024 _H + m × 40 _H	FCNnMm STRB	FCNnMm SSOW	FCNnMmSSMT[3:0]				FCNnMm SSRT	0	FCNnMm SSAM	
0 9028 _H + m × 40 _H	FCNnMm MID0H	FCNnMmSSID[7:0]								
		FCNnMmSSID[15:8]								
0 9030 _H + m × 40 _H	FCNnMm MID1H	FCNnMmSSID[23:16]								
		FCNnMm SSIE	0	0	FCNnMmSSID[28:24]					
1 1028 _H + m × 40 _H	FCNnMm MID0W	FCNnMmSSID[7:0]								
		FCNnMmSSID[15:8]								
		FCNnMmSSID[23:16]								
		FCNnMm SSIE	0	0	FCNnMmSSID[28:24]					
0 9038 _H + m × 40 _H	FCNnMmCTL (W)	0	FCNnMm CLNH	0	FCNnMm CLMW	FCNnMm CLIE	FCNnMm CLDN	FCNnMm CLTR	FCNnMm CLRY	
		0	FCNnMm SENH	0	0	FCNnMm SEIE	0	FCNnMm CSETR	FCNnMm SERY	
	FCNnMmCTL (R)	0	FCNnMm NHMF	0	FCNnMm MOWF	FCNnMm IENF	FCNnMm DTNF	FCNnMm TRQF	FCNnMm RDYF	
		0	0	FCNnMm MUCF	0	0	0	FCNnMm TCPF	0	

18.6 Bit Set/Clear Function

The CAN Controller control registers include registers whose bits can be set or cleared via the CPU and via the CAN Controller. These register bits can not be changed directly by the CPU by any bit manipulation instructions, such as SET1, CLR1, and NOT1. Instead a special bit-set/bit-clear mechanism is used.

All registers where bit manipulation operations are prohibited are organised in such a way that all bits allowed for changing by the CPU are located in the lower byte (RWx in the register layout below), while in the upper byte either no or read-only information is located (ROx in the register layout below).

The registers can be read in the usual way getting all 16 data bits in their current setting and as described in the register description.

For setting or clearing any of the lower 8 bits the following mechanism is implemented:

When writing 16-bit data to the register address

- Bit clear**
- each of the lower 8 data bits (CLx in the register layout below) indicates whether the corresponding register bit RWx should be
 - cleared, i.e. set to 0: if CLx = 1, the corresponding RWx is cleared to 0
 - remain unchanged: if CLx = 0, the corresponding RWx does not change
- Bit set**
- each of the upper 8 data bits (SEx in the register layout below) indicate whether the corresponding register bit should be
 - set, i.e. set to 1: if SEx = 1, the corresponding RWx is set to 1
 - remain unchanged: if SEx = 0, the corresponding RWx does not change

Register layout for read access:

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RO7	RO6	RO5	RO4	RO3	RO2	RO1	RO0	RW7	RW6	RW5	RW4	RW3	RW2	RW1	RW0
changing by the CPU not possible								bits for CPU manipulation via SE7-SE0 and CL7-CL0							

Register layout for write access:

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
SE7	SE6	SE5	SE4	SE3	SE2	SE1	SE0	CL7	CL6	CL5	CL4	CL3	CL2	CL1	CL0
SEx = 1 sets the corresponding RW7-RW0								CLx = 1 clears the corresponding RW7-RW0							

The following table denotes the operations applied to the RWx bits:

Table 18-19 Bit set/clear operation

CLx	SEx	Operation on RWx
0	0	no change of RWx
0	1	RWx set to 1
1	0	RWx cleared to 0
1	1	no change of RWx

Example Following an example.

The register with the content 1883_H shall be changed so, that

- bit 3 shall be set to 1: SE3 = 1

- bit 1 shall be cleared to 0: CL1 = 1

Register read before bit manipulations:

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	1	1	0	0	0	1	0	0	0	0	0	1	1
may hold any value, here 18 _H								RW7-RW0: 83 _H							

Register write access:

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	1	0	0	0	0	0	0	0	0	0	1	0
SE3 = 1: 08 _H								CL1 = 1: 02 _H							

Register read after bit manipulations:

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	1	1	0	0	0	1	0	0	0	1	0	0	1
may hold any value, here 18 _H								RW7-RW0: 89 _H							

18.7 Control Registers

18.7.1 CAN Controller global registers

(1) FCNnGMCLCTL - FCNn global control register

This register is used to control the operation of the CAN Controller.

Access This register can be read/written in 16-bit units.

Address <FCNn_base> + 0 8000_H

Initial Value The initial value depends on the occurrence of errors in relation to a software reset:

- no CAN RAM error detection after CAN S/W reset: 0000_H
- no CAN RAM error detection while CAN S/W reset is ongoing: 0010_H
- CAN RAM error detection after CAN S/W reset: 0020_H
- CAN RAM error detection while CAN S/W reset is ongoing: 0030_H

(a) FCNnGMCLCTL read

	15	14	13	12	11	10	9	8
FCNnGM CLSSMO	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
0	0	FCNnGM CLECCF	FCNnGM CLSORF	0	0	FCNnGM CLEUDE	FCNnGM CLPWOM	

FCNnGMCLSSMO	Bit enabling access to message buffer register, transmit/receive history registers
0	Write access and read access to the message buffer register and the transmit/receive history list registers is disabled.
1	Write access and read access to the message buffer register and the transmit/receive history list registers is enabled.

- Cautions**
1. While the FCNnGMCLCTL.FCNnGMCLSSMO is cleared (to 0), software access to all message buffers and message buffer registers (i.e. all registers with name prefix FCNnMm...), or registers related to transmit history or receive history (FCNnCMLOSTR, FCNnCMTGTX, FCNnCMLISTR, and FCNnCMRGRX) is disabled.
 2. FCNnGMCLCTL.FCNnGMCLSSMO is read-only. Even if 1 is written while it is 0, its value does not change, and access to the message buffer registers, or registers related to transmit history or receive history remains disabled.

- Note** FCNnGMCLCTL.FCNnGMCLSSMO is cleared to 0 when the CAN Controller enters sleep/stop, or when the FCNnGMCLCTL.FCNnGMCLPWOM is cleared to 0.
FCNnGMCLSSMO is set to 1 when the CAN Controller sleep/stop mode is released, or when the FCNnGMCLCTL.FCNnGMCLPWOM is set to 1.

FCNnGMCLECCF	Message buffer RAM read error detect bit
0	Not detect error for reading from message buffer RAM.
1	Detect error for reading from message buffer RAM.

- Notes**
1. FCNnGMCLCTL.FCNnGMCLECCF is set (1) in case of detecting a memory error when reading from the message buffer RAM during the soft reset process. Once FCNnGMCLECCF is set (1), it keeps the level until it is cleared (0).
 2. Although reading from message buffer RAM happens, when
 - reading a message buffer register,
 - reading a register that is related to receive and transmit history lists,
 - sending (transmitting) a message or
 - receiving a message,
 FCNnGMCLECCF is only evaluated during soft reset is ongoing. During any other operation, FCNnGMCLECCF is not updated.
 3. It is impossible to clear FCNnGMCLECCF (0) during FCNnGMCLCTL.FCNnGMCLSORF is set (1) (soft reset is ongoing).

FCNnGMCLSORF	Soft reset execution status bit
0	No soft reset
1	Soft reset is ongoing

- Notes**
1. While a soft reset is ongoing (FCNnGMCLCTL.FCNnGMCLSORF is set (1)), it is impossible to set FCNnGMCLCTL.FCNnGMCLPWOM and FCNnGMCLCTL.FCNnGMCLESEDE.
It is possible to set start a software reset by FCNnGMCLCTL.FCNnGMCLSESR = 1 during FCNnGMCLCTL.FCNnGMCLPWOM bit is clear (0).
 2. When FCNnGMCLCTL.FCNnGMCLSORF is set (1), the initialization of message buffer RAM starts. It is possible to detect error during initializing message buffer RAM, if FCNnGMCLCTL.FCNnGMCLECCF is cleared before setting FCNnGMCLSORF.
 3. When FCNnGMCLCTL.FCNnGMCLSORF is set (1) again in the condition that is already set (1), the soft reset procedure does not restart, but continues.
 4. After release of the H/W reset FCNnGMCLCTL.FCNnGMCLSORF is set (1) automatically and initialization of message buffer RAM starts.
 5. It is impossible that clearing FCNnGMCLCTL.FCNnGMCLPWOM (0) and setting FCNnGMCLCTL.FCNnGMCLSORF (1) are done at the same time.

6. If a hardware RESET occurs during FCNnGMCLCTL.FCNnGMCLSORF = 1, then the soft reset procedure is stopped (aborted), and the hardware RESET starts.

FCNnGMCLESEDE	Bit enabling forced shut down
0	Forced shut down disabled.
1	Forced shut down of FCNnGMCLCTL.FCNnGMCLPWOM bit = 0 enabled.

Caution To request a forced shut down, FCNnGMCLCTL.FCNnGMCLPWOM must be cleared to 0 in a subsequent, immediately following access after FCNnGMCLCTL.FCNnGMCLESEDE has been set to 1. If any access to another register (including reading the FCNnGMCLCTL register) is executed without clearing FCNnGMCLPWOM immediately after FCNnGMCLESEDE has been set to 1, FCNnGMCLESEDE is forcibly cleared to 0, and the forced shut down request is invalid.

FCNnGMCLPWOM	Global operation mode bit
0	CAN Controller is disabled.
1	CAN Controller is enabled to operate.

Caution FCNnGMCLCTL.FCNnGMCLPWOM can be cleared only in the initialization mode or immediately after FCNnGMCLCTL.FCNnGMCLESEDE is set (forced shutdown).

(b) FCNnGMCLCTL write

15	14	13	12	11	10	9	8
0	0	0	FCNnGM CLSESR	0	0	FCNnGM CLSESD	FCNnGM CLSEOM
7	6	5	4	3	2	1	0
0	0	FCNnGM CLCLMB	0	0	0	0	FCNnGM CLCLOM

FCNnGMCLSESR	Software reset start
0	No changes.
1	Start soft reset.

FCNnGMCLSESD	FCNnGMCLSESD bit setting
0	No change in FCNnGMCLSESD bit.
1	FCNnGMCLSEDE bit set to 1.

FCNnGMCLSEOM	FCNnGMCLCLOM	FCNnGMCLPWOM bit setting
0	1	FCNnGMCLCTL.FCNnGMCLPWOM bit cleared to 0.
1	0	FCNnGMCLCTL.FCNnGMCLPWOM bit set to 1.
Other than above		No change of FCNnGMCLCTL.FCNnGMCLPWOM bit.

Caution Set FCNnGMCLCTL.FCNnGMCLPWOM and FCNnGMCLCTL.FCNnGMCLSEDE bit always separately.

FCNnGMCLCLMB	FCNnGMCLCTL.FCNnGMCLSECCF bit clear
0	No change in FCNnGMCLCTL.FCNnGMCLSECCF bit.
1	FCNnGMCLCTL.FCNnGMCLSECCF bit cleared to 0.

(2) FCNnGMCSPRE - FCNn global clock selection register

This register is used to select the CAN channel clock.

Access This register can be read/written in 8-bit units.

Address <FCNn_base> + 0008_H

Initial Value 0F_H

7	6	5	4	3	2	1	0
0	0	0	0	FCNnGMCSPRE[3:0]			

FCNnGMCSPRE[3:0]	CAN channel clock (f_{CANCHN})
0000 _B	$f_{CAN}/1$
0001 _B	$f_{CAN}/2$
0010 _B	$f_{CAN}/3$
0011 _B	$f_{CAN}/4$
0100 _B	$f_{CAN}/5$
0101 _B	$f_{CAN}/6$
0110 _B	$f_{CAN}/7$
0111 _B	$f_{CAN}/8$
1000 _B	$f_{CAN}/9$
1001 _B	$f_{CAN}/10$
1010 _B	$f_{CAN}/11$
1011 _B	$f_{CAN}/12$
1100 _B	$f_{CAN}/13$
1101 _B	$f_{CAN}/14$
1110 _B	$f_{CAN}/15$
1111 _B	$f_{CAN}/16$ (default value)

Note f_{CAN} = clock supplied to CAN Controller.

Caution Setting of the channel clock, CAN baudrate and time quantas (TQs) per data bit time (DBT) is allowed only in certain combinations. Refer to the section “CAN baudrate and time quanta” above in this chapter.

(3) FCNnGMABCTL - FCNn global automatic block transmission control register

This register is used to control the automatic block transmission (ABT) operation.

Access This register can be read/written in 16-bit units.

Address <FCNn_base> + 0 8018_H

Initial Value 0000_H

(a) FCNnGMABCTL read

15	14	13	12	11	10	9	8
0	0	0	0	0	0	0	0
7	6	5	4	3	2	1	0
0	0	0	0	0	0	FCNnGM ABCLRF	FCNnGM ABABTT

FCNnGMABCLRF	Automatic block transmission engine clear status bit
0	Clearing the automatic transmission engine is completed.
1	The automatic transmission engine is being cleared.

- Notes**
1. Start automatic transmission engine clearance by
FCNnGMABCTL.FCNnGMABCLAT = 1 while
FCNnGMABCTL.FCNnGMABCLRF = 0.
The operation is not guaranteed if FCNnGMABCLRF is set to 1 while
FCNnGMABCLRF = 1.

FCNnGMABABTT	Automatic block transmission status bit
0	Automatic block transmission is stopped.
1	Automatic block transmission is under execution.

(b) FCNnGMABCTL write

15	14	13	12	11	10	9	8
0	0	0	0	0	0	FCNnGM ABSEAC	FCNnGM ABSEAT
7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	FCNnGM ABCLAT

Note When the automatic block transmission engine is cleared by setting FCNnGMABCTL.FCNnGMABSEAC to 1, FCNnGMABCLR is automatically set, and cleared to 0 as soon as the requested clearing processing is completed.

- Cautions**
1. Before changing the normal operation mode with ABT to the initialization mode, be sure to set the FCNnGMABCTL register to the default value (0000_H) and confirm the FCNnGMABCTL register is surely initialized to the default value (0000_H).
 2. Do not start automatic block transmission in the initialization mode. If automatic block transmission is started in the initialization mode, the operation is not guaranteed after the CAN Controller has entered the normal operation mode with ABT.
 3. Do not start automatic block transmission while FCNnCMCLCTL.FCNnCMCLSSTS is set to 1 (transmission in progress). Confirm FCNnCMCLSSTS = 0 directly in advance before starting automatic block transmission.

FCNnGMABSEAC	Automatic block transmission engine clear request bit
0	The automatic block transmission engine is in idle status or under operation.
1	Request to clear the automatic block transmission engine. After the automatic block transmission engine has been cleared, automatic block transmission is started from message buffer 0 by setting the FCNnGMABCTL.FCNnGMABABTT = 1.

FCNnGMABSEAT	FCNnGMABCLAT	Automatic block transmission start bit
0	1	Request to stop automatic block transmission.
1	0	Request to start automatic block transmission.
Other than above		No change of FCNnGMABCTL.FCNnGMABABTT.

(4) FCNnGMADCTL - FCNn global automatic block transmission delay register

This register is used to set the interval at which the data of the message buffer assigned to ABT is to be transmitted in the normal operation mode with ABT.

Access This register can be read/written in 8-bit units.

Address <FCNn_base> + 0020_H

Initial Value 00_H

7	6	5	4	3	2	1	0
0	0	0	0	FCNnGMADSSAD[3:0]			

FCNnGMADSSAD[3:0]	Data frame interval during automatic block transmission in DBT ^a
0000 _B	0 DBT (default value)
0001 _B	2 ⁵ DBT
0010 _B	2 ⁶ DBT
0011 _B	2 ⁷ DBT
0100 _B	2 ⁸ DBT
0101 _B	2 ⁹ DBT
0110 _B	2 ¹⁰ DBT
0111 _B	2 ¹¹ DBT
1000 _B	2 ¹² DBT
Other than above	Setting prohibited

a) Unit: Data bit time (DBT)

- Cautions**
1. Do not change the contents of the FCNnGMADCTL register while FCNnGMABCTL.FCNnGMABCLRF = 1 (clearing of ABT in progress).
 2. The timing at which the ABT message is actually transmitted onto the CAN bus differs depending on the status of transmission from the other station or how a request to transmit a message other than an ABT message is made.

(5) FCNnDNBMRXk - FCNn data new bit monitor registers (k = 0 to 3)


These registers are used to read Data New Flags globally for several message buffers at a time.

Access These registers can be read in 32-bit units.


Address FCNnDNBMRX0: <FCNn_base> + 1 00C0_H
 Following register is available only with m = 64 or 128 message buffers
 FCNnDNBMRX1: <FCNn_base> + 1 00D0_H
 Following registers are available only with m = 128 message buffers:
 FCNnDNBMRX2: <FCNn_base> + 1 00E0_H
 FCNnDNBMRX3: <FCNn_base> + 1 00F0_H

Initial Value 0000 0000_H


FCNnDNBMRX0:




FCNnDNBMRX1 (for m = 64 or 128 message buffers only):



FCNnDNBMRX2 (for m = 128 message buffers only):



FCNnDNBMRX3 (for m = 128 message buffers only):



FCNnDNBMSSDN[31:0]	Message buffer data new bit
0	No remote or data frame has been stored into the message buffer.
1	A remote or data frame has been stored into the message buffer.

18.7.2 CAN channel registers

(1) FCNnCMMKCTLaH - FCNn channel mask control register

These registers are used to extend the number of receivable messages into the same message buffer by masking part of the identifier (ID) comparison of a message and invalidating the ID of the masked part.



Two 16-bit registers FCNnCMMKCTLaH (a = 01 to 16) can also be accessed via a single 32-bit access to the registers FCNnCMMKCTLaW (a = 01, 03, 05, 07, 09, 11, 13, 15).

Access The FCNnCMMKCTLaH registers can be read/written in 16-bit units.
The FCNnCMMKCTLaW registers can be read/written in 32-bit units.

Address FCnCMMKCTL01H: <FCNn_base> + 0 8300_H
 FCnCMMKCTL02H: <FCNn_base> + 0 8308_H
 FCnCMMKCTL03H: <FCNn_base> + 0 8310_H
 FCnCMMKCTL04H: <FCNn_base> + 0 8318_H
 FCnCMMKCTL05H: <FCNn_base> + 0 8320_H
 FCnCMMKCTL06H: <FCNn_base> + 0 8328_H
 FCnCMMKCTL07H: <FCNn_base> + 0 8330_H
 FCnCMMKCTL08H: <FCNn_base> + 0 8338_H
 FCnCMMKCTL09H: <FCNn_base> + 0 8340_H
 FCnCMMKCTL10H: <FCNn_base> + 0 8348_H
 FCnCMMKCTL11H: <FCNn_base> + 0 8350_H
 FCnCMMKCTL12H: <FCNn_base> + 0 8358_H
 FCnCMMKCTL13H: <FCNn_base> + 0 8360_H
 FCnCMMKCTL14H: <FCNn_base> + 0 8368_H
 FCnCMMKCTL15H: <FCNn_base> + 0 8370_H
 FCnCMMKCTL16H: <FCNn_base> + 0 8378_H

FCnCMMKCTL01W: <FCNn_base> + 1 0300_H
 FCnCMMKCTL03W: <FCNn_base> + 1 0310_H
 FCnCMMKCTL05W: <FCNn_base> + 1 0320_H
 FCnCMMKCTL07W: <FCNn_base> + 1 0330_H
 FCnCMMKCTL09W: <FCNn_base> + 1 0340_H
 FCnCMMKCTL11W: <FCNn_base> + 1 0350_H
 FCnCMMKCTL13W: <FCNn_base> + 1 0360_H
 FCnCMMKCTL15W: <FCNn_base> + 1 0370_H

Initial Value 0000_H

(a) FCNnCMMKCTLaH (a = 01, 03, 05, 07, 09, 11, 13, 15)**(b) FCNnCMMKCTLaH (a = 02, 04, 06, 08, 10, 12, 14, 16)****(c) FCNnCMMKCTLaW (a = 01, 03, 05, 07, 09, 11, 13, 15)**

FCNnCMMKSSID[i] ^a	Mask pattern setting of ID bit
0	The ID bit <i>i</i> of the message buffer <i>m</i> set by FCNnMmSSID[<i>i</i>] are compared with the ID bits of the received message frame.
1	The ID bit <i>i</i> of the message buffer <i>m</i> set by FCNnMmSSID[<i>i</i>] are not compared with the ID bits of the received message frame (they are masked).

^{a)} $i = [28:0]$

Note Masking is always defined by an ID length of 29 bits. If a mask is assigned to a message with a standard ID, FCNnCMMKSSID[17:0] are ignored. Therefore, only FCNnCMMKSSID[28:18] of the received ID are masked. The same mask can be used for both the standard and extended IDs.

(2) FCNnCMCLCTL - FCNn channel control register

This register is used to control the operation mode of the CAN Controller.

Access This register can be read/written in 16-bit units.

Address <FCNn_base> + 0 8240_H

Initial Value 0000_H

(a) FCNnCMCLCTL read

15	14	13	12	11	10	9	8
0	0	0	0	0	0	FCNnCM CLSSRS	FCNnCM CLSSTS
7	6	5	4	3	2	1	0
FCNnCM CLERCF	FCNnCM CLALBF	FCNnCM CLVALF	FCNnCM CLMDPF[1:0]		FCNnCM CLMDOF[2:0]		

FCNnCMCLSSRS	Reception status bit
0	Reception is stopped.
1	Reception is in progress.

- Notes**
1. FCNnCMCLSSRS is set to 1 under the following conditions (timing)
 - The SOF bit of a receive frame is detected
 - On occurrence of arbitration loss during a transmit frame
 2. FCNnCMCLSSRS is cleared to 0 under the following conditions (timing)
 - When a recessive level is detected at the second bit of the interframe space
 - On transition to the initialization mode at the first bit of the interframe space

FCNnCMCLSSTS	Transmission status bit
0	Transmission is stopped.
1	Transmission is in progress.

- Notes**
1. FCNnCMCLSSTS is set to 1 under the following conditions (timing)
 - The SOF bit of a transmit frame is detected
 2. FCNnCMCLSSTS is cleared to 0 under the following conditions (timing)
 - During transition to bus-off state
 - On occurrence of arbitration loss in transmit frame
 - On detection of recessive level at the second bit of the interframe space
 - On transition to the initialization mode at the first bit of the interframe space

FCNnCMCLERCF	Error counter clear bit
0	The FCNnCMERCNT and FCNnMCLCSTR registers are not cleared in the initialization mode.
1	The FCNnCMERCNT and FCNnMCLCSTR registers are cleared in the initialization mode.

Caution The error counter register FCNnCMERCNT and the information register FCNnCMINSTR are cleared by FCNnCMCLERCF bit only following conditions:

- During Bus-Off state, while in initialization mode.
- After starting the CAN Controller (FCNnGMCLPWOM is set at FCNnGMCLPWOM=0), while in initialization mode.
- After aborting all transmit request according to *Figure 18-27 “Transmission abort processing (except normal operation mode with ABT)” on page 1011* or *Figure 18-28 “Transmission abort processing (normal operation mode with ABT) - Repeat option for aborted message” on page 1012*, while in initialization mode.

- Notes**
1. When the FCNnCMERCNT and FCNnMCLCSTR registers have been cleared, FCNnCMCLERCF is also cleared to 0 automatically.
 2. FCNnCMCLERCF can be set to 1 at the same time as a request to change the initialization mode to an operation mode is made.
 3. FCNnCMCLERCF is read-only in the CAN Controller sleep or stop mode.
 4. The error counters can also be cleared by shut down or forced shut down of the CAN controller.

FCNnCMCLALBF	Bit to set operation in case of arbitration loss
0	Re-transmission is not executed in case of an arbitration loss in the single-shot mode.
1	Re-transmission is executed in case of an arbitration loss in the single-shot mode.

Note FCNnCMCLALBF is valid only in the single-shot mode.

FCNnCMCLVALF	Valid receive message frame detection bit
0	A valid message frame has not been received since FCNnCMCLVALF was last cleared to 0.
1	A valid message frame has been received since FCNnCMCLVALF was last cleared to 0.

- Notes**
1. Detection of a valid receive message frame is not dependent upon storage in the receive message buffer (data frame) or transmit message buffer (remote frame).
 2. Clear FCNnCMCLVALF (0) before changing the initialization mode to an operation mode.

3. If only two CAN nodes are connected to the CAN bus with one transmitting a message frame in the normal mode and the other in the receive-only mode, FCNnCMCLVALF is not set to 1 before the transmitting node enters the error passive state, because in receive-only mode no acknowledge is generated.
4. To clear FCNnCMCLVALF, set FCNnCMCLLVL to 1 first and confirm that FCNnCMCLVALF is cleared. If it is not cleared, perform clearing processing again.

FCNnCMCLMDPF[1:0]	Power save mode
00 _B	No power save mode is selected.
01 _B	CAN Controller sleep mode
10 _B	Setting prohibited
11 _B	CAN Controller stop mode

- Cautions**
1. Transition to and from the CAN Controller stop mode must be made via sleep mode. A request for direct transition to and from the stop mode is ignored.
 2. The FCNnGMCLSSMO flag of FCNnGMCLCTL must be checked after releasing a power save mode, prior to access the message buffers again.
 3. CAN Controller sleep mode requests are kept pending, until cancelled by software or entered on appropriate bus condition (bus idle). Software can check the actual status by reading FCNnCMCLMDPF[1:0].

Note In case that the CAN bus is blocked on dominant level, so that the CAN Controller could not synchronize since initialization mode was left, the sleep mode can be reached nevertheless. In this case however, the wake up from sleep mode will happen after the first recessive to dominant edge, after a synchronization was successful. Waking up by software is possible in any case.

FCNnCMCLMDOF[2:0]	Operation mode
000 _B	No operation mode is selected (CAN Controller is in the initialization mode).
001 _B	Normal operation mode
010 _B	Normal operation mode with automatic block transmission function (normal operation mode with ABT)
011 _B	Receive-only mode
100 _B	Single-shot mode
101 _B	Self-test mode
Other than above	Setting prohibited

Caution Transit to initialization mode or power saving modes may take some time. Be sure to verify the success of mode change by reading the values, before proceeding.

Note FCNnCMCLMDOF[2:0] are read-only in the CAN Controller sleep or stop mode.

(b) FCNnCMCLCTL write

	15	14	13	12	11	10	9	8
FCNnCM CLSERC	FCNnCM CLSEAL	0	FCNnCM SESEPS[1:0]		FCNnCM CLSEOP[2:0]			
	7	6	5	4	3	2	1	0
0	FCNnCM CLCLAL	FCNnCM CLCLVL	FCNnCM SECLPS[1:0]		FCNnCM CLCLOP[2:0]			

FCNnCMCLSERC	Setting of FCNnCMCLERCF bit
1	FCNnCMCLERCF is set to 1.
Other than above	FCNnCMCLERCF is not changed.

FCNnCMCLSEAL	FCNnCMCLCLAL	Setting of FCNnCMCLALBF bit
0	1	FCNnCMCLALBF is cleared to 0.
1	0	FCNnCMCLALBF is set to 1.
Other than above		FCNnCMCLALBF is not changed.

FCNnCMCLCLVL	Setting of FCNnCMCLVALF bit
0	FCNnCMCLVALF is not changed.
1	FCNnCMCLVALF is cleared to 0.

FCNnCMSESEPS0	FCNnCMSECLPS0	Setting of FCNnCMCLMDPF0 bit
0	1	FCNnCMCLMDPF0 is cleared to 0.
1	0	FCNnCMCLMDPF0 is set to 1.
Other than above		FCNnCMCLMDPF0 is not changed.

FCNnCMSESEPS1	FCNnCMSECLPS1	Setting of FCNnCMCLMDPF1 bit
0	1	FCNnCMCLMDPF1 is cleared to 0.
1	0	FCNnCMCLMDPF1 is set to 1.
Other than above		FCNnCMCLMDPF1 is not changed.

FCNnCMCLSEOP0	FCNnCMCLCLOP0	Setting of FCNnCMCLMDOF0 bit
0	1	FCNnCMCLMDOF0 is cleared to 0.
1	0	FCNnCMCLMDOF0 is set to 1.
Other than above		FCNnCMCLMDOF0 is not changed.

FCNnCMCLSEOP1	FCNnCMCLCLOP1	Setting of FCNnCMCLMDOF1 bit
0	1	FCNnCMCLMDOF1 is cleared to 0.
1	0	FCNnCMCLMDOF1 is set to 1.
Other than above		FCNnCMCLMDOF1 is not changed.

FCNnCMCLSEOP2	FCNnCMCLCLOP2	Setting of FCNnCMCLMDOF2 bit
0	1	FCNnCMCLMDOF2 is cleared to 0.
1	0	FCNnCMCLMDOF2 is set to 1.
Other than above		FCNnCMCLMDOF2 is not changed.

Caution When setting initialization mode while reception is ongoing in an operation mode, a last reception may occur, which sets the data new flag of a message box. However, the transition back to an operation mode also clears the Receive History List. Therefore, reaching the initialization mode must be confirmed by software by reading back the operation mode. Before restarting an operation mode, all set data new flags of all active receive message boxes must be cleared, before activating an operation mode again.

(3) FCNnCMLCSTR - FCNn channel last error information register

This register provides the error information of the CAN protocol.

Access This register can be read/written in 8-bit units.

Address <FCNn_base> + 0 0248_H

Initial Value 00_H

7	6	5	4	3	2	1	0
0	0	0	0	0	FCN0CMLCSSL[2:0]		

- Notes**
1. The contents of the FCNnCMLCSTR register are not cleared when the CAN Controller changes from an operation mode to the initialization mode.
 2. If an attempt is made to write a value other than 00_H to the FCNnCMLCSTR register by software, the access is ignored.

FCN0CMLCSSL[2:0]	Last CAN protocol error information
000 _B	No error
001 _B	Stuff error
010 _B	Form error
011 _B	ACK error
100 _B	Bit error. (The CAN Controller tried to transmit a recessive-level bit as part of a transmit message (except the arbitration field), but the value on the CAN bus is a dominant-level bit.)
101 _B	Bit error. (The CAN Controller tried to transmit a dominant-level bit as part of a transmit message, ACK bit, error frame, or overload frame, but the value on the CAN bus is a recessive-level bit.)
110 _B	CRC error
111 _B	Undefined

(4) FCNnCMINSTR - FCNn channel information register

This register indicates the status of the CAN Controller.

Access This register is read-only in 8-bit units.

Address <FCNn_base> + 0 024C_H

Initial Value 00_H

7	6	5	4	3	2	1	0
0	0	0	FCNnCM INBOFF	FCNnCM INSSTE[1:0]	FCNnCM INSSRE[1:0]	FCNnCM INSSRE[1:0]	FCNnCM INSSRE[1:0]

FCNnCMINBOFF	Bus-off state bit
0	Not bus-off state (transmit error counter ≤ 255). (The value of the transmit counter is less than 256.)
1	Bus-off state (transmit error counter > 255). (The value of the transmit counter is 256 or more.)

FCNnCMINSSTE[1:0]	Transmission error counter status bit
00 _B	The value of the transmission error counter is less than that of the warning level (< 96).
01 _B	The value of the transmission error counter is in the range of the warning level (96 to 127).
10 _B	Undefined
11 _B	The value of the transmission error counter is in the range of the error passive or bus-off status (≥ 128).

FCNnCMINSSRE[1:0]	Reception error counter status bit
00 _B	The value of the reception error counter is less than that of the warning level (< 96).
01 _B	The value of the reception error counter is in the range of the warning level (96 to 127).
10 _B	Undefined
11 _B	The value of the reception error counter is in the error passive range (≥ 128).


(5) FCNnCMERCNT - FCNn channel error counter register

This register indicates the count value of the transmission/reception error counter.

Access This register is read-only in 16-bit units.

Address <FCNn_base> + 0 8250_H

Initial Value 0000_H



FCNnCMERRPSF	Reception error passive status bit
0	The reception error counter is not in the error passive range (< 128)
1	The reception error counter is in the error passive range (≥ 128)

FCNnCMERRECF[6:0]	Reception error counter bit
0 to 127	Number of reception errors. These bits reflect the status of the reception error counter. The number of errors is defined by the CAN protocol.

Note FCNnCMERRECF[6:0] are invalid in the reception error passive state (FCNnCMINSTR.FCNnCMINSSRE[1:0] = 11_B).

FCNnCMERTECF[7:0]	Transmission error counter bit
0 to 255	Number of transmission errors. These bits reflect the status of the transmission error counter. The number of errors is defined by the CAN protocol.

Note FCNnCMERTECF[7:0] are invalid in the bus-off state (FCNnCMINSTR.FCNnCMINBOFF = 1).

(6) FCNnCMIECTL - FCNn channel interrupt enable register

This register is used to enable or disable the interrupts of the CAN Controller.

Access This register can be read/written in 16-bit units.

Address <FCNn_base> + 0 8258_H

Initial Value 0000_H

(a) FCNnCMIECTL read

15	14	13	12	11	10	9	8
0	0	0	0	0	0	0	0
7	6	5	4	3	2	1	0
0	FCNnCMIEINTF[6:0]						

FCNnCMIEINTF[6:0]	CAN Controller interrupt enable bit
0	Output of the interrupt corresponding to interrupt status register FCNnCMISCTL is disabled.
1	Output of the interrupt corresponding to interrupt status register FCNnCMISCTL is enabled.

(b) FCNnCMIECTL write

15	14	13	12	11	10	9	8
0	FCNnCMIESEIE[6:0]						
7	6	5	4	3	2	1	0
0	FCNnCMIECLIE[6:0]						

FCNnCMIESEIE[6:0]	FCNnCMIECLIE[6:0]	Setting of FCNnCMIEINTF[6:0] bit
0	1	FCNnCMIEINTF[6:0] bit is cleared to 0.
1	0	FCNnCMIEINTF[6:0] bit is set to 1.
Other than above		FCNnCMIEINTF[6:0] bit is not changed.

(7) FCNnCMISCTL - FCNn channel interrupt status register

This register indicates the interrupt status of the CAN Controller.

Access This register can be read/written in 16-bit units.

Address <FCNn_base> + 0 8260_H

Initial Value 0000_H

(a) FCNnCMISCTL read

15	14	13	12	11	10	9	8
0	0	0	0	0	0	0	0
7	6	5	4	3	2	1	0
0	FCNnCMISITSF[6:0]						

FCNnCMISITSF[6:0]	CAN Controller interrupt status bit
0	No related interrupt source event is pending
1	A related interrupt source event is pending

Interrupt status bit	Related interrupt source event
FCNnCMISITSF6	CAN Controller transmission abort interrupt status bit
FCNnCMISITSF5	Wakeup interrupt from CAN Controller sleep mode ^a
FCNnCMISITSF4	Arbitration loss interrupt
FCNnCMISITSF3	CAN protocol error interrupt
FCNnCMISITSF2	CAN error status interrupt
FCNnCMISITSF1	Interrupt on completion of reception of valid message frame to message buffer m
FCNnCMISITSF0	Interrupt on normal completion of transmission of message frame from message buffer m

a) FCNnCMISITSF5 is set only when the CAN Controller is woken up from the CAN Controller sleep mode by a CAN bus operation. It is not set when the sleep mode has been released by software.

(b) FCNnCMISCTL write

15	14	13	12	11	10	9	8
0	0	0	0	0	0	0	0
7	6	5	4	3	2	1	0
0	FCNnCMISITSF[6:0]						

FCNnCMISITSF[6:0]	Clearing of FCNnCMISITSF[6:0]
0	FCNnCMISITSF[6:0] bits are not changed
1	FCNnCMISITSF[6:0] bits are cleared to 0

Caution Clear the status bit of this register by software, when the confirmation of each status is necessary in the interrupt processing, because these bits are not cleared automatically.

(8) FCNnCMBRPRS - FCNn channel bit rate prescaler register

This register is used to select the CAN protocol layer clock (f_{TQ}). The communication baudrate is set to the FCNnCMBTCTL register.

Access This register can be read/written in 8-bit units.

Address <FCNn_base> + 0 0268_H

Initial Value FF_H



FCNnCMBRPRS	CAN protocol layer clock (f_{TQ})
0	$f_{CANCHN}/1$
1	$f_{CANCHN}/2$
n	$f_{CANCHN}/(n+1)$
:	:
255	$f_{CANCHN}/256$ (default value)




Figure 18-4 CAN Controller clocks

Note

- f_{CAN} : clock supplied to CAN Controller
- f_{CANCHN} : CAN channel clock
- f_{TQ} : CAN protocol layer clock

- Cautions**
1. FCNnCMBRPRS can be write-accessed only in the initialization mode.
 2. Setting of the channel clock, CAN baudrate and time quantas (TQs) per data bit time (DBT) is allowed only in certain combinations. Refer to the section "CAN baudrate and time quanta" above in this chapter.

(9) FCNnCMBTCTL - FCNn channel bit rate register

This register is used to control the data bit time of the communication baudrate.

Access This register can be read/written in 16-bit units.

Address <FCNn_base> + 0 8270_H

Initial Value 0370F_H

15	14	13	12	11	10	9	8
0	0	FCNnCM BTJWLG[1:0]		0	FCNnCM BTS2LG[2:0]		
7	6	5	4	3	2	1	0
0	0	0	0	FCNnCMBTS1LG[3:0]			




Figure 18-5 Data bit time

FCNnCMBTJWLG[1:0]	Length of synchronization jump width (SJW)
00 _B	1T _Q
01 _B	2T _Q
10 _B	3T _Q
11 _B	4T _Q (default value)

FCNnCMBTS2LG[2:0]	Length of time segment 2 (TSEG2)
000 _B	1T _Q
001 _B	2T _Q
010 _B	3T _Q
011 _B	4T _Q
100 _B	5T _Q
101 _B	6T _Q
110 _B	7T _Q
111 _B	8T _Q (default value)

FCNnCMBTS1LG[3:0]	Length of time segment 1(TSEG1)
0000 _B	Setting prohibited
0001 _B	2 T _Q ^a
0010 _B	3 T _Q ^a
0011 _B	4 T _Q
0100 _B	5 T _Q
0101 _B	6 T _Q
0110 _B	7 T _Q
0111 _B	8 T _Q
1000 _B	9 T _Q
1001 _B	10 T _Q
1010 _B	11 T _Q
1011 _B	12 T _Q
1100 _B	13 T _Q
1101 _B	14 T _Q
110 _B	15 T _Q
1111 _B	16 T _Q (default value)

a) This setting must not be made when the FCNnCMBRPRS register = 00_H

Note T_Q = 1/f_{TQ} (f_{TQ}: CAN protocol layer clock)

Caution Setting of the CAN channel clock, CAN baudrate and time quantas (TQs) per data bit time (DBT) is allowed only in certain combinations. Refer to the section “CAN baudrate and time quanta” above in this chapter.


(10) FCNnCMLISTR - FCNn channel last in-pointer register

This register indicates the number of the message buffer in which a data frame or a remote frame was last stored.

Access This register is read-only in 8-bit units.

Address <FCNn_base> + 0 0278_H

Initial Value Undefined.



FCNnCMLISLT[7:0]	Last in-pointer register
0 to 31 ^a	When the FCNnCMLISTR register is read, the contents of the element indexed by the last in-pointer (FCNnCMLISLT[7:0]) of the receive history list are read. These contents indicate the number of the message buffer in which a data frame or a remote frame was last stored.
0 to 63 ^b	
0 to 127 ^c	

- a) On 32 message buffer CAN Controller.
 b) On 64 message buffer CAN Controller.
 c) On 128 message buffer CAN Controller.

Note The read value of FCNnCMLISTR is undefined if a data frame or a remote frame has never been stored in the message buffer. If FCNnCMRGRX.FCNnCMRGSSPM is set to 1 after the CAN Controller has changed from the initialization mode to an operation mode, therefore, the read value of FCNnCMLISTR is undefined.


(11) FCNnCMRGRX - FCNn channel receive history list register

This register is used to read the receive history list (RHL).

Access This register can be read/written in 16-bit units.

Address <FCNn_base> + 0 8280_H

Initial Value xx02_H

(a) FCNnCMRGRX read

FCNnCMRGSSPT[7:0]	Receive history list read pointer
0 to 31 ^a 0 to 63 ^b 0 to 127 ^c	When FCNnCMRGRX is read, the contents of the element indexed by the receive history list get pointer (FCNnCMRGRX.FCNnCMRGSSPT) of the receive history list are read. These contents indicate the number of the message buffer in which a data frame or a remote frame has been stored.

- a) On 32 message buffer CAN Controller.
b) On 64 message buffer CAN Controller.
c) On 128 message buffer CAN Controller.

FCNnCMRGSSPM ^a	Receive history list pointer match
0	The receive history list has at least one message buffer number that has not been read.
1	The receive history list has no message buffer numbers that have not been read.

- a) The read value of FCNnCMRGSSPT[7:0] is invalid when FCNnCMRGSSPM = 1.

FCNnCMRGRVFF ^a	Receive history list overflow bit ^b
0	All the message buffer numbers that have not been read are preserved. All the numbers of the message buffers in which a new data frame or remote frame has been received and stored are recorded to the receive history list (the receive history list has a vacant element).
1	At least (i) entries have been stored since the host processor has serviced the RHL last time (i.e. read FCNnCMRGRX). The first (i-1) entries are sequentially stored while the last entry can have been overwritten whenever newly received message is stored, because all buffer numbers are stored at position (i), when FCNnCMRGRVFF is set. Thus the sequence of receptions can not be recovered completely now.

- a) If FCNnCMRGRVFF is set, FCNnCMRGSSPM is no longer cleared on message storage, but FCNnCMRGSSPM is still set, if all entries of FCNnCMRGRX have been read by software.
b) i = 23 on 32 message buffer CAN Controller;
i = 47 on 64 message buffer CAN Controller;
i = 95 on 128 message buffer CAN Controller.

(b) FCNnCMRGRX write

15	14	13	12	11	10	9	8	
0	0	0	0	0	0	0	0	
7	6	5	4	3	2	1	0	
0	0	0	0	0	0	0	0	FCNnCMRGCLRV

FCNnCMRGCLRV	Clearing of FCNnCMRGRVFF bit
0	FCNnCMRGRVFF bit is not changed.
1	FCNnCMRGRVFF bit is cleared to 0.


(12) FCNnCMLOSTR - FCNn channel last out-pointer register

This register indicates the number of the message buffer, from which a data frame or a remote frame was transmitted last.

Access This register is read-only in 8-bit units.

Address <FCNn_base> + 0 0288_H

Initial Value Undefined



FCNnCMLOSTR[7:0]	Last out-pointer of transmit history list
0 to 31 ^a	When the FCNnCMLOSTR register is read, the contents of the element indexed by the last out-pointer (FCNnCMLOSTR[7:0]) of the receive history list are read. These contents indicate the number of the message buffer to which a data frame or a remote frame was transmitted last.
0 to 63 ^b	
0 to 127 ^c	

- a) On 32 message buffer CAN Controller.
- b) On 64 message buffer CAN Controller.
- c) On 128 message buffer CAN Controller.

Note The value read from the FCNnCMLOSTR register is undefined if a data frame or remote frame has never been transmitted from a message buffer. If FCNnCMTGTX.FCNnCMTGSSPM is set to 1 after the CAN Controller has changed from the initialization mode to an operation mode, therefore, the read value of the FCNnCMLOSTR register is undefined.

(13) FCNnCMTGTX - FCNn channel transmit history list register

This register is used to read the transmit history list (THL).

Access This register can be read/written in 16-bit units.

Address <FCNn_base> + 0 8290_H

Initial Value xx02_H

(a) FCNnCMTGTX read

15	14	13	12	11	10	9	8
FCNnCMTGSSPT[7:0]							
7	6	5	4	3	2	1	0
0	0	0	0	0	0	FCNnCM TGSSPM	FCNnCM TGTVFF

FCNnCMTGSSPT[7:0]	Transmit history list read pointer
0 to 31 ^a 0 to 63 ^b 0 to 127 ^c	When the FCNnCMTGTX register is read, the contents of the element indexed by the read pointer (FCNnCMTGSSPT[7:0]) of the transmit history list are read. These contents indicate the number of the message buffer to which a data frame or a remote frame was transmitted last.

- a) On 32 message buffer CAN Controller.
 b) On 64 message buffer CAN Controller.
 c) On 128 message buffer CAN Controller.

FCNnCMTGSSPM ^a	Transmit history pointer match
0	The transmit history list has at least one message buffer number that has not been read.
1	The transmit history list has no message buffer numbers that have not been read.

- a) The read value of FCNnCMTGSSPT[7:0] is invalid when the FCNnCMTGSSPM = 1.

FCNnCMTGTVFF ^a	Transmit history list overflow bit ^b
0	All the message buffer numbers that have not been read are preserved. All the numbers of the message buffers to which a new data frame or remote frame has been transmitted are recorded to the transmit history list (the transmit history list has a vacant element).
1	At least (i) entries have been stored since the host processor has serviced the THL last time (i.e. read FCNnCMTGTX). The first (i-1) entries are sequentially stored while the last entry can have been overwritten whenever newly received message is stored, because all buffer numbers are stored at position (i) , when FCNnCMTGTVFF is set. Thus the sequence of receptions can not be recovered completely now.

a) If FCNnCMTGTVFF is set, FCNnCMTGSSPM is no longer cleared on message transmission, but FCNnCMTGSSPM is still set, if all entries of FCNnCMTGTX are read by software.

b) i = 7 on 32 message buffer CAN Controller
 i = 15 on 64 message buffer CAN Controller;
 i = 31 on 128 message buffer CAN Controller.

Note Transmission from message buffers ...

- 0 to 8 (for 32 message buffer CAN Controller)
- 0 to 16 (for 64 message buffer CAN Controller)
- 0 to 32 (for 128 message buffer CAN Controller)

... is not recorded to the transmit history list in the normal operation mode with ABT.

(b) FCNnCMTGTX write

15	14	13	12	11	10	9	8
0	0	0	0	0	0	0	0
7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	FCNnCM TGCLTV

FCNnCMTGCLTV	Setting of FCNnCMTGTVFF bit
0	FCNnCMTGTVFF bit is not changed
1	FCNnCMTGTVFF bit is cleared to 0

(14) FCNnCMTSCTL - FCNn channel time stamp register

This register is used to control the time stamp function.

Access This register can be read/written in 16-bit units.

Address <FCNn_base> + 0 8298_H

Initial Value 0000_H

(a) FCNnCMTSCTL read

15	14	13	12	11	10	9	8
0	0	0	0	0	0	0	0
7	6	5	4	3	2	1	0
0	0	0	0	0	FCNnCM TSLOKE	FCNnCM TSSELE	FCNnCM TSTSGE

Note The lock function of the time stamp function must not be used when the CAN Controller is in the normal operation mode with ABT.

FCNnCMTSLOKE	Time stamp lock function enable bit
0	Time stamp lock function stopped. The TSOUT signal is toggled each time the selected time stamp capture event occurs.
1	Time stamp lock function enabled. The TSOUT signal is toggled each time the selected time stamp capture event occurs. However, the TSOUT output signal is locked when a data frame has been correctly received to message buffer 0 ^a .

a) FCNnCMTTSTSGE is automatically cleared to 0.

FCNnCMTSSELE	Time stamp capture event selection bit
0	The time capture event is SOF.
1	The time stamp capture event is the last bit of EOF.

FCNnCMTTSTSGE	TSOUT operation setting bit
0	TSOUT toggle operation is disabled.
1	TSOUT toggle operation is enabled.

(b) FCNnCMTSCTL write

15	14	13	12	11	10	9	8
0	0	0	0	0	FCNnCM TSSELK	FCNnCM TSSES	FCNnCM TSSETS
7	6	5	4	3	2	1	0
0	0	0	0	0	FCNnCM TSCLK	FCNnCM TSCLSL	FCNnCM TSCLTS

FCNnCMTSSELK	FCNnCMTSCLK	Setting of FCNnCMTSLOKE bit
0	1	FCNnCMTSLOKE is cleared to 0.
1	0	FCNnCMTSLOKE is set to 1.
Other than above		FCNnCMTSLOKE is not changed.

FCNnCMTSSES	FCNnCMTSCLSL	Setting of FCNnCMTSSELE bit
0	1	FCNnCMTSSELE is cleared to 0.
1	0	FCNnCMTSSELE is set to 1.
Other than above		FCNnCMTSSELE is not changed.

FCNnCMTSSETS	FCNnCMTSCLTS	Setting of FCNnCMTSTSGE bit
0	1	FCNnCMTSTSGE is cleared to 0.
1	0	FCNnCMTSTSGE is set to 1.
Other than above		FCNnCMTSTSGE is not changed.

18.7.3 Message buffer registers

(1) FCNnMmDATxB/H/W, FCNn message data byte registers

These registers are used to store the data of a transmit/receive message.

Access The FCNnMmDATxW registers can be read/written in 32-bit units.
The FCNnMmDATxH registers can be read/written in 16-bit units.
The FCNnMmDATxB registers can be read/written in 8-bit units.

Address FCNnMmDAT0B: $\langle \text{FCNn_base} \rangle + 0\ 1000_{\text{H}} + m \times 40_{\text{H}}$
FCNnMmDAT1B: $\langle \text{FCNn_base} \rangle + 0\ 1004_{\text{H}} + m \times 40_{\text{H}}$
FCNnMmDAT2B: $\langle \text{FCNn_base} \rangle + 0\ 1008_{\text{H}} + m \times 40_{\text{H}}$
FCNnMmDAT3B: $\langle \text{FCNn_base} \rangle + 0\ 100\text{C}_{\text{H}} + m \times 40_{\text{H}}$
FCNnMmDAT4B: $\langle \text{FCNn_base} \rangle + 0\ 1010_{\text{H}} + m \times 40_{\text{H}}$
FCNnMmDAT5B: $\langle \text{FCNn_base} \rangle + 0\ 1014_{\text{H}} + m \times 40_{\text{H}}$
FCNnMmDAT6B: $\langle \text{FCNn_base} \rangle + 0\ 1018_{\text{H}} + m \times 40_{\text{H}}$
FCNnMmDAT7B: $\langle \text{FCNn_base} \rangle + 0\ 101\text{C}_{\text{H}} + m \times 40_{\text{H}}$

FCNnMmDAT0H: $\langle \text{FCNn_base} \rangle + 0\ 9000_{\text{H}} + m \times 40_{\text{H}}$
FCNnMmDAT2H: $\langle \text{FCNn_base} \rangle + 0\ 9008_{\text{H}} + m \times 40_{\text{H}}$
FCNnMmDAT4H: $\langle \text{FCNn_base} \rangle + 0\ 9010_{\text{H}} + m \times 40_{\text{H}}$
FCNnMmDAT6H: $\langle \text{FCNn_base} \rangle + 0\ 9018_{\text{H}} + m \times 40_{\text{H}}$

FCNnMmDAT0W: $\langle \text{FCNn_base} \rangle + 1\ 1000_{\text{H}} + m \times 40_{\text{H}}$
FCNnMmDAT4W: $\langle \text{FCNn_base} \rangle + 1\ 1010_{\text{H}} + m \times 40_{\text{H}}$

Initial Value Undefined.

(a) FCNnCMmDATxB (x = 0 to 7)

7	6	5	4	3	2	1	0
FCNnMmSSD0[7:0], FCNnMmSSD1[7:0], FCNnMmSSD2[7:0], FCNnMmSSD3[7:0], FCNnMmSSD4[7:0], FCNnMmSSD5[7:0], FCNnMmSSD6[7:0], FCNnMmSSD7[7:0]							

(b) FCNnCMmDATyH (y = 0, 2, 4, 6)

15	14	13	12	11	10	9	8
FCNnMmSSD0[7:0], FCNnMmSSD2[7:0], FCNnMmSSD4[7:0], FCNnMmSSD6[7:0]							

7	6	5	4	3	2	1	0
FCNnMmSSD1[7:0], FCNnMmSSD3[7:0], FCNnMmSSD5[7:0], FCNnMmSSD7[7:0]							

(c) FCNnCMmDATzW (z = 0, 4)

31	30	29	28	27	26	25	24
FCNnMmSSD0[7:0], FCNnMmSSD4[7:0]							

23	22	21	20	19	18	17	16
FCNnMmSSD1[7:0], FCNnMmSSD5[7:0]							

15	14	13	12	11	10	9	8
FCNnMmSSD2[7:0], FCNnMmSSD6[7:0]							

7	6	5	4	3	2	1	0
FCNnMmSSD3[7:0], FCNnMmSSD7[7:0]							

(2) FCNnMmDTLGB - FCNn message data length register m

This register is used to set the number of bytes of the data field of a message buffer.

Access This register can be read/written in 8-bit units.

Address <FCNn_base> + 0 1020_H + m × 40_H

Initial Value Undefined.

7	6	5	4	3	2	1	0
0	0	0	0	FCNnMmDTLG[3:0]			

FCNnMmDTLG[3:0]	Data length of transmit/receive message
0000 _B	0 bytes
0001 _B	1 byte
0010 _B	2 bytes
0001 _B	3 bytes
0100 _B	4 bytes
0101 _B	5 bytes
0110 _B	6 bytes
0111 _B	7 bytes
1000 _B	8 bytes
1001 _B	Setting prohibited (If these bits are set during transmission, 8-byte data is transmitted regardless of the set DLC value when a data frame is transmitted. However, the DLC actually transmitted to the CAN bus is the DLC value set to this register.) ^{Note}
1010 _B	
1001 _B	
1100 _B	
1101 _B	
1110 _B	
1111 _B	

Note The data and DLC value actually transmitted to CAN bus are as follows.

Type of transmit frame	Length of transmit data	DLC transmitted
Data frame	Number of bytes specified by DLC (However, 8 bytes if DLC ≥ 8)	FCNnMmDTLGB.FC NnMmDTLG[3:0] bits
Remote frame	0 bytes	

- Cautions**
1. Be sure to set bits 7 to 4 to 0000_B.
 2. Receive data is stored in as many FCNnMmDATxB register as the number of bytes (however, the upper limit is 8) corresponding to DLC of the received frame. The FCNnMmDATxB register in which no data is stored is undefined.
 3. On reception, FCNnMmDTLGB is updated according to the received frame.

(3) FCNnMmSTRB - FCNn message configuration register m

This register is used to specify the type of the message buffer and to set a mask.

Access This register can be read/written in 8-bit units.

Address <FCNn_base> + 0 1024_H + m × 40_H

Initial Value 00_H

7	6	5	4	3	2	1	0
FCNnMm SSOW	FCNnMm SSMT[3:0]			FCNnMm SSRT	0	FCNnMm SSAM	

FCNnMmSSOW	Overwrite control bit
0	The message buffer that has already received a data frame ^a is not overwritten by a newly received data frame. The newly received data frame is discarded.
1	The message buffer that has already received a data frame ^a is overwritten by a newly received data frame.

a) The “message buffer that has already received a data frame” is a receive message buffer whose FCNnMmCTL.FCNnMmDTNF bit has been set to 1.

Note A remote frame is received and stored, regardless of the setting of FCNnMmCTL.FCNnMmSSOW and FCNnMmCTL.FCNnMmDTNF. A remote frame that satisfies the other conditions

- either:
ID matches exactly, FCNnMmSTRB.FCNnMmSSRT = 0,
FCNnMmCTL.FCNnMmTRQF = 0, FCNnMmSSMT = 0000_B
- or:
ID matches with or without mask, FCNnMmSTRB.FCNnMmSSRT = 1,
FCNnMmSSMT <> 0000_B

is always received and stored in the corresponding message buffer (interrupt generated, FCNnMmDTNF flag set, FCNnMmDTLGB.FCNnMmDTLG[3:0] updated, and recorded to the receive history list).

FCNnMmSSRT	Remote frame request bit
0	Transmit / receive a data frame.
1	Transmit / receive a remote frame.

FCNnMmSTRB.FCNnMmSSRT specifies the type of message frame that is transmitted or received from/to a message buffer.

- Notes**
1. If the message buffer is defined as a transmit message buffer, and a remote frame shall be received into it, the FCNnMmSSRT bit must be cleared.
 2. Even if a valid remote frame has been received in a transmit message buffer, the FCNnMmSSRT bit of the transmit message buffer that has received the frame remains cleared to 0.

3. Even if a remote frame whose ID matches has been received from the CAN bus, if the FCNnMmSSRT bit of a transmit message buffer is set to 1 (to transmit a remote frame), that remote frame is not stored in this transmit message buffer.
4. If the message buffer is defined as a receive message buffer, the FCNnMmSSRT bit must be set, in order to receive remote frames instead of data frames.

FCNnMmSSMT[3:0]	Message buffer type setting bit
0000 _B	Transmit message buffer
0001 _B	Receive message buffer (no mask setting)
0010 _B	Receive message buffer (mask 1 set)
0011 _B	Receive message buffer (mask 2 set)
0100 _B	Receive message buffer (mask 3 set)
0101 _B	Receive message buffer (mask 4 set)
0110 _B	Receive message buffer (mask 5 set)
0111 _B	Receive message buffer (mask 6 set)
1000 _B	Receive message buffer (mask 7 set)
1001 _B	Receive message buffer (mask 8 set)
Other than above	Setting prohibited

Note The setting of FCNnMmSSMT is also valid to select masks in conjunction with remote frame reception. To receive remote frames in receive message buffers, the flag FCNnMmSSRT of the message buffer must be set.

FCNnMmSSAM	Message buffer assignment bit
0	Message buffer not used.
1	Message buffer used.

Caution Be sure to write 0 to bits 2 and 1.

(4) FCNnMmMID0H, FCNnMmMID1H, FCNnMmMID0W - FCNn message ID register m

These registers are used to set an identifier (ID).

Access FCNnMmMID0H, FCNnMmMID1H can be read/written in 16-bit units.
FCNnMmMID0W can be read/written in 32-bit units.

Address FCNnMmMID0H: $\langle \text{FCNn_base} \rangle + 0\ 9028_{\text{H}} + m \times 40_{\text{H}}$
FCNnMmMID1H: $\langle \text{FCNn_base} \rangle + 0\ 9030_{\text{H}} + m \times 40_{\text{H}}$

FCNnMmMID0W: $\langle \text{FCNn_base} \rangle + 1\ 1028_{\text{H}} + m \times 40_{\text{H}}$

Initial Value Undefined.

(a) FCNnMmMID0H

15	14	13	12	11	10	9	8
FCNnMmSSID[15:8]							
7	6	5	4	3	2	1	0
FCNnMmSSID[7:0]							

(b) FCNnMmMID1H

15	14	13	12	11	10	9	8	
FCNnMmSSIE	0	0	FCNnMmSSID[28:24]					
7	6	5	4	3	2	1	0	
FCNnMmSSID[23:16]								

(c) FCNnCMmMID0W

31	30	29	28	27	26	25	24	
FCNnMmSSIE	0	0	FCNnMmSSID[28:24]					
23	22	21	20	19	18	17	16	
FCNnMmSSID[23:16]								
15	14	13	12	11	10	9	8	
FCNnMmSSID[15:8]								
7	6	5	4	3	2	1	0	
FCNnMmSSID[7:0]								

FCNnMmSSIE	Format mode specification bit
0	Standard format mode (FCNnMmSSID[28:18]: 11 bits, FCNnMmSSID[17:0] are not used)
1	Extended format mode (FCNnMmSSID[28:0]: 29 bits)

FCNnMmSSID[28:0]	Message ID
FCNnMmSSID[28:18]	Standard ID value of 11 bits (when FCNnMmSSIE = 0)
FCNnMmSSID[28:0]	Extended ID value of 29 bits (when FCNnMmSSIE = 1)

-
- Cautions**
1. Be sure to write 0 to bits 14 and 13 of FCNnMmMID1H, respectively bits 30 and 29 of FCNnMmMID0W register.
 2. Be sure to align the ID value according to the given bit positions into this registers. Note that for standard ID, the ID value must be shifted to fit into FCNnMmSSID[28:18] bit positions.
-

(5) FCNnMmCTL - FCNn message control register m

This register is used to control the operation of the message buffer.

Access This register can be read/written in 16-bit units.

Address <FCNn_base> + 0 9038_H + m × 40_H

Initial Value 0000_H

(a) FCNnMmCTL read

15	14	13	12	11	10	9	8
0	0	FCNnMm MUCF	0	0	0	FCNnMm TCPF	0
7	6	5	4	3	2	1	0
0	FCNnMm NHMF	0	FCNnMm MOWF	FCNnMm IENF	FCNnMm DTNF	FCNnMm TRQF	FCNnMm RDYF

FCNnMmNHMF	History Mask flag ^a
0	Updates of receive/transmit history list registers FCNnCMRGRX/FCNnCMRGTX are not masked.
1	Updates of receive/transmit history list registers FCNnCMRGRX/FCNnCMRGTX are masked.

a) When masked, the history lists are not updated upon reception or transmission completion activity on this message buffer.

FCNnMmMUCF ^a	Bit indicating that message buffer data is being updated
0	The CAN Controller is not updating the message buffer (reception and storage).
1	The CAN Controller is updating the message buffer (reception and storage).

a) FCNnMmMUCF is undefined until the first reception and storage is performed.

FCNnMmTCPF ^a	Transmission completely finished flag
0	Transmission failed. ^{b c}
1	Transmission (including ABT) completely finished.

a) FCNnMmTCPF is cleared if FCNnMmRDYF is changed or FCNnMmTRQF is set.

b) This indicates a successful transmission abort, if this was requested by the application by clearing the FCNnMmTRQF flag.

c) FCNnMmTCPF is not cleared, if FCNnMmTRQF is set by the ABT operation.

FCNnMmMOWF	Message buffer overwrite status bit
0	The message buffer is not overwritten by a newly received data or remote frame.
1	The message buffer is overwritten by a newly received data or remote frame.

FCNnMmIENF	Message buffer interrupt request enable bit
0	Receive message buffer: Valid message reception completion interrupt disabled. Transmit message buffer: Normal message transmission completion interrupt disabled.
1	Receive message buffer: Valid message reception completion interrupt enabled. Transmit message buffer: Normal message transmission completion interrupt enabled.

FCNnMmDTNF	Message buffer data update bit
0	No new data frame or remote frame has been stored in the message buffer.
1	A new data frame or remote frame has been stored in the message buffer.

FCNnMmTRQF	Message buffer transmission request bit
0	No message frame transmitting request that is pending or being transmitted is in the message buffer.
1	The message buffer is holding transmission of a message frame pending or is transmitting a message frame.

FCNnMmRDYF	Message buffer ready bit
0	The message buffer can be written by software. The CAN Controller cannot write to the message buffer.
1	Writing the message buffer by software is ignored (except a write access to the FCNnMmRDYF, FCNnMmTRQF, FCNnMmDTNF, and FCNnMmMOWF). The CAN Controller can write to the message buffer.

(b) FCNnMmCTL write

15	14	13	12	11	10	9	8
0	FCNnMm SENH	0	0	FCNnMm SEIE	FCNnMm SEDN	FCNnMm SETR	FCNnMm SERY
7	6	5	4	3	2	1	0
0	FCNnMm CLNH	0	FCNnMm CLMW	FCNnMm CLIE	FCNnMm CLDN	FCNnMm CLTR	FCNnMm CLRY

FCNnMmSENH	FCNnMmCLNH	Setting of FCNnMmNHMF bit
0	1	FCNnMmNHMF is cleared to 0.
1	0	FCNnMmNHMF is set to 1.
Other than above		FCNnMmNHMF is not changed.

FCNnMmCLMW	Setting of FCNnMmMOWF bit
0	FCNnMmMOWF is not changed.
1	FCNnMmMOWF is cleared to 0.

FCNnMmSEIE	FCNnMmCLIE	Setting of FCNnMmIENF bit
0	1	IE is cleared to 0.
1	0	IE is set to 1.
Other than above		IE is not changed.

FCNnMmSEDN	FCNnMmCLDN	Setting of FCNnMmDTNF bit
0	1	FCNnMmDTNF is cleared to 0.
1	0	FCNnMmDTNF is set to 1.
Other than above		FCNnMmDTNF is not changed.

Note If FCNnMmDTNF is cleared by the finish of ID field receiving, the message buffer participates in the search to store the receiving frame.

FCNnMmSETR	FCNnMmCLTR	Setting of FCNnMmTRQF bit
0	1	FCNnMmTRQF is cleared to 0.
1	0	FCNnMmTRQF is set to 1.
Other than above		FCNnMmTRQF is not changed.

FCNnMmSERY	FCNnMmCLRY	Setting of FCNnMmRDYF bit
0	1	FCNnMmRDYF is cleared to 0.
1	0	FCNnMmRDYF is set to 1.
Other than above		FCNnMmRDYF is not changed.

- Cautions**
1. Set FCNnMmIENF and FCNnMmRDYF always separately.
 2. Do not set FCNnMmDTNF to 1 by software. Be sure to write 0 to bit 10.
 3. Do not set FCNnMmTRQF and FCNnMmRDYF to 1 at the same time. Set FCNnMmRDYF = 1 before setting FCNnMmTRQF = 1.
 4. Do not clear FCNnMmRDYF to "0" during message transmission. Follow the transmission abort process about clearing FCNnMmRDYF for redefinition of the message buffer.
 5. Clearing of FCNnMmRDYF may take some time, depending on activity of the CAN Controller. Repeat the clearing access, until reading of FCNnMmRDYF confirms that the bit is cleared.
 6. Be sure that FCNnMmRDYF is cleared before writing to the other message buffer registers, by checking the status of FCNnMmRDYF.

18.8 CAN Controller Initialization

18.8.1 Initialization of CAN Controller

Before the CAN Controller operation is enabled, the CAN channel clock T_{CANCH} needs to be determined by setting FCNnGMCSPRE.FCNnGMCSPRSC[3:0] by software. Do not change the setting of the CAN channel clock T_{CANCH} after CAN Controller operation is enabled.

The CAN Controller is enabled by setting FCNnGMCLCTL.FCNnGMCLPWOM.

For the procedure of initializing the CAN Controller, refer to 18.16 "Operation of the CAN Controller" on page 999.

18.8.2 Initialization of message buffer

After the CAN Controller is enabled, the message buffers contain undefined values. A minimum initialization for all the message buffers, even for those not used in the application, is necessary before switching the CAN Controller from the initialization mode to one of the operation modes.

- Clear FCNnMmRDYF, FCNnMmTRQF, and FCNnMmDTNF of the FCNnMmCTL registers to 0.
- Clear all FCNnMmSTRB.FCNnMmSSAM to 0.

18.8.3 Redefinition of message buffer

Redefining a message buffer means changing the ID and control information of the message buffer while a message is being received or transmitted, without affecting other transmission/reception operations.

(1) To redefine message buffer in initialization mode

Place the CAN Controller in the initialization mode once and then change the ID and control information of the message buffer in the initialization mode. After changing the ID and control information, set the CAN Controller to an operation mode.

(2) To redefine message buffer during reception

Perform redefinition as shown in *Figure 18-20 "Message buffer redefinition during reception"*.

(3) To redefine message buffer during transmission

To rewrite the contents of a transmit message buffer to which a transmission request has been set, perform transmission abort processing (see and 2 "Transmission abort process except for ABT transmission in normal operation mode with automatic block transmission (ABT)" on page 980). Confirm that transmission has been aborted or completed, and then redefine the message buffer. After redefining the transmit message buffer, set a transmission request using the procedure described below. When setting a transmission request to a message buffer that has been redefined without aborting the transmission in progress, however, the 1-bit wait time is not necessary.




Figure 18-6 Setting transmission request (FCNnMmCTL.FCNnMmTRQF) to transmit message buffer after redefinition

- Cautions**
1. When a message is received, reception filtering is performed in accordance with the ID and mask set to each receive message buffer. If the procedure in *Figure 18-20 “Message buffer redefinition during reception” on page 1003* is not observed, the contents of the message buffer after it has been redefined may contradict the result of reception (result of reception filtering). If this happens, check that the ID and IDE received first and stored in the message buffer following redefinition are those stored after the message buffer has been redefined. If no ID and IDE are stored after redefinition, redefine the message buffer again.
 2. When a message is transmitted, the transmission priority is checked in accordance with the ID, IDE, and FCNnMmSTRB.FCNnMmSSRT set to each transmit message buffer to which a transmission request was set. The transmit message buffer having the highest priority is selected for transmission. If the procedure in *Figure 18-6 “Setting transmission request (FCNnMmCTL.FCNnMmTRQF) to transmit message buffer after redefinition” on page 963* is not observed, a message with an ID not having the highest priority may be transmitted after redefinition.

18.8.4 Transition from initialization mode to operation mode

The CAN Controller can be switched to the following operation modes.

- Normal operation mode
- Normal operation mode with ABT
- Receive-only mode
- Single-shot mode
- Self-test mode




Figure 18-7 Transition to operation modes

Note In the figure above following abbreviations are used:

- MDOF = FCNnCMCLCTL.FCNnCMCLMDOF[2:0]
- PWOM = FCNnGMCLCTL.FCNnGMCLPWOM
- SESD = FCNnGMCLCTL.FCNnGMCLSESD

The transition from the initialization mode to an operation mode is controlled by the bit string FCNnCM.FCNnCMCLMDOF[2:0].

Changing from one operation mode into another requires shifting to the initialization mode in between. Do not change one operation mode to another directly; otherwise the operation will not be guaranteed.

Requests for transition from an operation mode to the initialization mode are held pending when the CAN bus is not in the interframe space (i.e., frame reception or transmission is in progress), and the CAN Controller enters the initialization mode at the first bit in the interframe space (the values of the FCNnCMCLCTL.FCNnCMCLMDOF[2:0] are changed to 000_B). After issuing a request to change the mode to the initialization mode, read FCNnCMCLCTL.FCNnCMCLMDOF[2:0] until their value becomes 000_B to confirm that the channel has entered the initialization mode (see Figure 18-17 “Re-initialization without Software Reset function” on page 1000).

18.9 Message Reception

18.9.1 Message reception

In all the operation modes, the complete message buffer area is analyzed to find a suitable buffer to store a newly received message. All message buffers satisfying the following conditions are included in that evaluation (RX-search process).

- Used as a message buffer
(FCNnMmSTRB.FCNnMmSSAM = 1.)
- Set as a receive message buffer
(FCNnMmSTRB.FCNnMmSSMT[3:0] = 0001_B to 1001_B.)
- Ready for reception
(FCNnMmCTL.FCNnMmRDYF = 1.)

When two or more message buffers of the CAN Controller are found to be able to receive a message, the message is stored according to the priority explained below. The message is always stored in the message buffer with the highest priority, not in a message buffer with a low priority. For example, when an unmasked receive message buffer and a receive message buffer linked to mask 1 have the same ID, the received message is not stored in the message buffer linked to mask 1, even if that message buffer has not received a message and a message has already been received in the unmasked receive message buffer. In other words, when a condition has been set in two or more message buffers with different priorities, the message buffer with the highest priority always stores the message; the message is not stored in message buffers with a lower priority. This also applies when the message buffer with the highest priority is unable to store a message (i.e., when FCNnMmCTL.FCNnMmDTNF = 1 indicating that a message has already been received, but rewriting is disabled because FCNnMmSTRB.FCNnMmSSOW = 0). In this case, the message is not actually stored in the candidate message buffer with the highest priority, but neither is it stored in a message buffer with a lower priority.

Table 18-20 MBRB priorities

Priority	Storing condition if same ID is set	
1 (high)	Unmasked message buffer	FCNnMmDTNF = 0
		FCNnMmDTNF = 1 and FCNnMmSSOW = 1
2	Message buffer linked to mask 1	FCNnMmDTNF = 0
		FCNnMmDTNF = 1 and FCNnMmSSOW = 1
3	Message buffer linked to mask 2	FCNnMmDTNF = 0
		FCNnMmDTNF = 1 and FCNnMmSSOW = 1
...	...	
9 (low)	Message buffer linked to mask 8	FCNnMmDTNF = 0
		FCNnMmDTNF = 1 and FCNnMmSSOWt = 1

18.9.2 Receive data read

To keep data consistency when reading CAN Controller message buffers, perform the data reading according to Figure 18-34 “Reception via interrupt (using FCNnCMLISTR register)” on page 1019 to Figure 18-37 “Reception via software polling” on page 1023.

During message reception, the CAN Controller sets FCNnMmCTL.FCNnMmDTNF two times: at the beginning of the storage process of data to the message buffer, and again at the end of this storage process. During this storage process, FCNnMmCTL.FCNnMmMUCF of the message buffer is set (refer to Figure 18-8 “FCNnMmCTL.FCNnMmDTNF and FCNnMmCTL.FCNnMmMUCF bit setting period (for standard ID format)”).

The receive history list is also updated just before the storage process. In addition, during storage process (FCNnMmCTL.FCNnMmMUCF = 1), FCNnMmCTL.FCNnMmRDYF of the message buffer is locked to avoid any coincidental data write by CPU. Note that the storage process may be disturbed (delayed) when the CPU accesses the message buffer.




Figure 18-8 FCNnMmCTL.FCNnMmDTNF and FCNnMmCTL.FCNnMmMUCF bit setting period (for standard ID format)

Note If a message shall be stored in a message buffer, the FCNnMmDTNF bit of this buffer must be cleared before the Message Search Process is started, i.e., right after the ID of the frame is on the bus. In worst case, this happens 15 CAN bits after EOF of the previous frame. Consider to use more than one Message Buffer for reception of a frame, if CAN frames are appearing back-to-back on the bus and none shall be lost.

18.9.3 Receive history list function

The receive history list (RHL) function records in the receive history list the number of the receive message buffer in which each data frame or remote frame was received and stored. The RHL consists of storage elements equivalent to up to 23 messages (on 32 message buffer CAN Controller), 47 messages (on 64 message buffer CAN Controller) or up to 95 messages (on 128 message buffer CAN Controller), the last in-message pointer FCNnCMLISLR[7:0] with the corresponding FCNnCMLISTR register and the receive history list get pointer FCNnCMRGSSPT with the corresponding FCNnCMRGRX register.

The RHL is undefined immediately after the transition of the CAN Controller from the initialization mode to one of the operation modes.

The FCNnCMLISTR register holds the contents of the RHL element indicated by the value of the FCNnCMLISTR.FCNnCMLISLR[7:0] pointer minus 1. By reading the FCNnCMLISTR register, therefore, the number of the message buffer that received and stored a data frame or remote frame first can be checked. The FCNnCMLISLR[7:0] pointer is utilized as a write pointer that indicates to what part of the RHL a message buffer number is recorded. Any time a data frame or remote frame is received and stored, the corresponding message buffer number is recorded to the RHL element indicated by the FCNnCMLISLR[7:0] pointer. Each time recording to the RHL has been completed, the FCNnCMLISLR[7:0] pointer is automatically incremented. In this way, the number of the message buffer that has received and stored a frame will be recorded chronologically.

For message buffers, where the flag FCNnMmCTL.FCNnMmNHMF is set, no entry in the history lists is recorded.

The FCNnCMRGRX.FCNnCMRGSSPT pointer is utilized as a read pointer that reads a recorded message buffer number from the RHL. This pointer indicates the first RHL element that the CPU has not read yet. By reading the FCNnCMRGRX register by software, the number of a message buffer that has received and stored a data frame or remote frame can be read. Each time a message buffer number is read from the FCNnCMRGRX register, the FCNnCMRGSSPT pointer is automatically incremented.

If the value of the FCNnCMRGRX.FCNnCMRGSSPT pointer matches the value of the FCNnCMLISTR.FCNnCMLISLR[7:0] pointer, FCNnCMRGRX.FCNnCMRGSSPM (receive history list pointer match) is set to 1. This indicates that no message buffer number that has not been read remains in the RHL. If a new message buffer number is recorded, the FCNnCMLISLR[7:0] pointer is incremented and because its value no longer matches the value of the FCNnCMRGSSPT pointer, FCNnCMRGSSPM is cleared. In other words, the numbers of the unread message buffers exist in the RHL.

If the FCNnCMLISTR.FCNnCMLISLR[7:0] pointer is incremented and matches the value of the FCNnCMRGRX.FCNnCMRGSSPT pointer minus 1, FCNnCMRGRX.FCNnCMRGRVFF (receive history list overflow) is set to 1. This indicates that the RHL is full of numbers of message buffers that have not been read. When further message reception and storing occur, the last recorded message buffer number is overwritten by the number of the message buffer that received and stored the newly received message. In this case, after FCNnCMRGRVFF has been set (1), the recorded message buffer numbers in the RHL do not completely reflect the chronological order. However messages itself are not lost and can be located by CPU search in message buffer memory with the help of FCNnMmCTL.FCNnMmDTNF, or by reading the global registers FCNnDNBMRX[3:0].

Caution If the history list is in the overflow condition (FCNnCMRGRX.FCNnCMRGRVFF is set), reading the history list contents is still possible, until the history list is empty (indicated by FCNnCMRGRX.FCNnCMRGSSPM flag set). Nevertheless, the history list remains in the overflow condition, until FCNnCMRGRVFF is cleared by software. If FCNnCMRGRVFF is not cleared, the FCNnCMRGSSPM flag will also not be updated (cleared) upon a message storage of newly received frame. This may lead to the situation, that FCNnCMRGSSPM indicates an empty history list, although a reception has taken place, while the history list is in the overflow state (FCNnCMRGRVFF and FCNnCMRGSSPM are set).

As long as the RHL still has free entries, the sequence of occurrence is maintained. If more receptions occur without reading the RHL by the host processor, complete sequence of receptions can not be recovered.




Figure 18-9 Receive history list

18.9.4 Mask function

For any message buffer, which is used for reception, the assignment to one of eight global reception masks (or no mask) can be selected.

By using the mask function, the message ID comparison can be reduced by masked bits, herewith allowing the reception of several different IDs into one buffer.

While the mask function is in effect, an identifier bit that is defined to be 1 by a mask in the received message is not compared with the corresponding identifier bit in the message buffer.

However, this comparison is performed for any bit whose value is defined as 0 by the mask.

For example, let us assume that all messages that have a standard-format ID, in which bits ID27 to ID25 are 0 and bits ID24 and ID22 are 1, are to be stored in message buffer 14. The procedure for this example is shown below.

(1) Identifier to be stored in message buffer

ID28	ID27	ID26	ID25	ID24	ID23	ID22	ID21	ID20	ID19	ID18
x	0	0	0	1	x	1	x	x	x	x
ID17	ID16	ID15	ID14	ID13	ID12	ID11	ID10	ID9	ID8	ID7
x	x	x	x	x	x	x	x	x	x	x
ID6	ID5	ID4	ID3	ID2	ID1	ID0				
x	x	x	x	x	x	x				

(2) Identifier to be configured in message buffer 14 (example) (using FCNnCM14MID0W register)

ID28	ID27	ID26	ID25	ID24	ID23	ID22	ID21	ID20	ID19	ID18
x	0	0	0	1	x	1	x	x	x	x
ID17	ID16	ID15	ID14	ID13	ID12	ID11	ID10	ID9	ID8	ID7
x	x	x	x	x	x	x	x	x	x	x
ID6	ID5	ID4	ID3	ID2	ID1	ID0				
x	x	x	x	x	x	x				

- Notes**
1. ID with the ID27 to ID25 bits cleared to 0 and the ID24 and ID22 bits set to 1 is registered (initialized) to message buffer 14. Other bits of ID can be set to any value (x), because they are going to be masked.
 2. Message buffer 14 is set as a standard format identifier that is linked to mask 1 (FCNnMmSTRB.FCNnMmSSMT[3:0] = 0010_B).

Mask setting for CAN Controller 1 (mask 1) (example)
(using CAN1 address mask 1 register FCNnCMMKCTL01W)

FCNnCMMKSSID[..]										
ID28	ID27	ID26	ID25	ID24	ID23	ID22	ID21	ID20	ID19	ID18
1	0	0	0	0	1	0	1	1	1	1
ID17	ID16	ID15	ID14	ID13	ID12	ID11	ID10	ID9	ID8	ID7
1	1	1	1	1	1	1	1	1	1	1
ID6	ID5	ID4	ID3	ID2	ID1	ID0				
1	1	1	1	1	1	1				

1: Not compared (masked)

0: Compared

FCNnCMMKSSID[27:24] and FCNnCMMKSSID[22] are cleared to 0, and FCNnCMMKSSID[28], FCNnCMMKSSID[23], and FCNnCMMKSSID[21:0] are set to 1.

18.9.5 Multi buffer receive block function

The multi buffer receive block (MBRB) function is used to store a block of data in two or more message buffers sequentially with no CPU interaction, by setting the same ID to two or more message buffers with the same message buffer type. These message buffers can be allocated anywhere in the message buffer memory, they do not even have to follow each other adjacently.

Suppose, for example, the same message buffer type is set to 10 message buffers, message buffers 10 to 19, and the same ID is set to each message buffer. If the first message whose ID matches an ID of the message buffers is received, it is stored in message buffer 10. At this point, FCNnMmCTL.FCNnMmDTNF of message buffer 10 is set, prohibiting overwriting the message buffer when subsequent messages are received.

When the next message with a matching ID is received, it is received and stored in message buffer 11. Each time a message with a matching ID is received, it is sequentially (in the ascending order) stored in message buffers 12, 13, and so on. Even when a data block consisting of multiple messages is received, the messages can be stored and received without overwriting the previously received matching-ID data.

Whether a data block has been received and stored can be checked by setting FCNnMmCTL.FCNnMmIENF of each message buffer. For example, if a data block consists of k messages, k message buffers are initialized for reception of the data block. FCNnMmIENF in message buffers 0 to $(k-2)$ is cleared to 0 (interrupts disabled), and FCNnMmIENF in message buffer $k-1$ is set to 1 (interrupts enabled). In this case, a reception completion interrupt occurs when a message has been received and stored in message buffer $k-1$, indicating that MBRB has become full. Alternatively, by clearing FCNnMmIENF of message buffers 0 to $(k-3)$ and setting FCNnMmIENF of message buffer $k-2$, a warning that MBRB is about to overflow can be issued.

The basic conditions of storing receive data in each message buffer for the MBRB are the same as the conditions of storing data in a single message buffer.

-
- Cautions**
1. MBRB can be configured for each of the same message buffer types. Therefore, even if a message buffer of another MBRB whose ID matches but whose message buffer type is different has a vacancy, the received message is not stored in that message buffer, but instead discarded.
 2. MBRB does not have a ring buffer structure. Therefore, after a message is stored in the message buffer having the highest number in the MBRB configuration, a newly received message will not be stored in the message buffer having the lowest message buffer number.
 3. MBRB operates based on the reception and storage conditions; there are no settings dedicated to MBRB, such as function enable bits. By setting the same message buffer type and ID to two or more message buffers, MBRB is automatically configured.
 4. With MBRB, “matching ID” means “matching ID after mask”. Even if the ID set to each message buffer is not the same, if the ID that is masked by the mask register matches, it is considered a matching ID and the buffer that has this ID is treated as the storage destination of a message.
 5. The priority between MBRBs is mentioned in the table *Table 18-20 “MBRB priorities”*.
-

18.9.6 Remote frame reception

In all the operation modes, when a remote frame is received, the message buffer that is to store the remote frame is searched from all the message buffers satisfying the following conditions (1 and 2, condition 1 has priority on reception acceptance). If condition 1 is not fulfilled, the remaining message buffers are scanned, whether condition 2 could be fulfilled.

- Condition 1:
Set as a transmit message buffer
(FCNnMmSTRB.FCNnMmSSMT[3:0] = 0000_B)
 - Used as a message buffer
(FCNnMmSTRB.FCNnMmSSAM = 1.)
 - Ready for reception
(FCNnMmCTL.FCNnMmRDYF = 1.)
 - Set to data frame message type
(FCNnMmSTRB.FCNnMmSSRT = 0.)
 - Transmission request is not set.
(FCNnMmCTL.FCNnMmTRQF = 0.)
- Condition 2:
Set as a receive message buffer
(FCNnMmSTRB.FCNnMmSSMT[3:0] = 0001_B ... 1001_B)
 - Used as a message buffer
(FCNnMmSTRB.FCNnMmSSAM = 1.)
 - Ready for reception
(FCNnMmCTL.FCNnMmRDYF = 1.)
 - Set to remote frame message type
(FCNnMmSTRB.FCNnMmSSRT = 1.)
 - Buffer is ready to store a message
(FCNnMmCTL.FCNnMmDTNF = 0, or FCNnMmSTRB.FCNnMmSSOW = 1 with FCNnMmCTL.FCNnMmDTNF = 1).

Upon acceptance of a remote frame, the following actions are executed if the ID of the received remote frame matches the ID of a message buffer that satisfies the above conditions.

- The FCNnMmDTLG[3:0] bit string in the FCNnMmDTLGB register store the received DLC value.
- The FCNnMmDAT0B to FCNnMmDAT7B registers in the data area are not updated (data before reception is saved).
- FCNnMmCTL.FCNnMmDTNF is set to 1.
- FCNnCMISCTL.FCNnCMISITSF1 is set to 1 (if FCNnMmCTL.FCNnMmIENF of the message buffer that receives and stores the frame is set to 1).
- The receive completion interrupt (INTCnREC) is output (if FCNnMmCTL.FCNnMmIENF of the message buffer that receives and stores the frame is set to 1 and if FCNnCMIECTL.FCNnCMIESEIE1 is set to 1).
- The message buffer number is recorded in the receive history list, if the flag FCNnMmCTL.FCNnMmNHMF is not set.

Caution When a transmit message buffer is found for receiving and storing a remote frame, overwrite control by FCNnMmSTRB.FCNnMmSSOW of the message buffer and FCNnMmCTL.FCNnMmDTNF are not checked. The setting of FCNnMmSSOW is ignored, and FCNnMmDTNF is set in any case.

- Notes**
1. If more than one transmit message buffer has the same ID and the ID of the received remote frame matches that ID, the remote frame is stored in the transmit message buffer with the lowest message buffer number.
 2. If transmit and receive message buffers are found, which could receive a remote frame matching with its ID, either masked or unmasked, the remote frame is stored in the transmit message buffer.
 3. If several receive message buffers would match for reception for a remote frame, the reception priority is identical as for a data frame.
 4. If a receive message buffer is found to match for a remote frame reception, and selected for storage, but this receive message buffer does not allow the storage, because FCNnMmDTNF is set, and FCNnMmSSOW is not set, the remote frame is not stored at all.

18.10 Message Transmission

18.10.1 Message transmission

A message buffer with its FCNnMmCTL.FCNnMmTRQF bit set to 1 participates in the search for the most high-prioritized message when the following conditions are fulfilled. This behavior is valid for all operational modes.

- Used as a message buffer
(FCNnMmSTRB.FCNnMmSSAM = 1.)
- Set as a transmit message buffer
(FCNnMmSTRB.FCNnMmSSMT[3:0] = 0000_B.)
- Ready for transmission
(FCNnMmCTL.FCNnMmRDYF = 1.)

The CAN bus is a multi-master communication system. In a system like this, the priority of message transmission is determined based on message identifiers (IDs). To facilitate transmission processing by software when there are several messages awaiting transmission, the CAN Controller uses hardware to check the ID of the message with the highest priority and automatically identifies that message. This eliminates the need for software-based priority control.

Transmission priority is controlled by the identifier (ID).




Figure 18-10 Message processing example

After the transmit message search, the transmit message with the highest priority of the transmit message buffers that have a pending transmission request (message buffers with the FCNnMmCTL.FCNnMmTRQF bit set to 1 in advance) is transmitted.

If a new transmission request is set, the transmit message buffer with the new transmission request is compared with the transmit message buffer with a pending transmission request. If the new transmission request has a higher priority, it is transmitted, unless transmission of a message with a low priority has already started. If transmission of a message with a low priority has already started, however, the new transmission request is transmitted later. To solve this priority inversion effect, the software can perform a transmission abort request for the lower priority message. The highest priority is determined according to the following rules.

Priority	Conditions	Description
1 (high)	Value of first 11 bits of ID [ID28 to ID18]:	The message frame with the lowest value represented by the first 11 bits of the ID is transmitted first. If the value of an 11-bit standard ID is equal to or smaller than the first 11 bits of a 29-bit extended ID, the 11-bit standard ID has a higher priority than a message frame with a 29-bit extended ID.
2	Frame type	A data frame with an 11-bit standard ID (FCNnMmSTRB.FCNnMmSSRT cleared to 0) has a higher priority than a remote frame with a standard ID and a message frame with an extended ID.
3	ID type	A message frame with a standard ID (message buffer identifier register FCNnMmMID... bit FCNnMmSSIE is cleared to 0) has a higher priority than a message frame with an extended ID.
4	Value of lower 18 bits of ID [ID17 to ID0]:	If one or more transmission-pending extended ID message frame has equal values in the first 11 bits of the ID and the same frame type (equal FCNnMmSTRB.FCNnMmSSRT bit values), the message frame with the lowest value in the lower 18 bits of its extended ID is transmitted first.
5 (low)	Message buffer number	If two or more message buffers request transmission of message frames with the same ID, the message from the message buffer with the lowest message buffer number is transmitted first.

- Notes**
- If the automatic block transmission request bit FCNnGMABCTL.FCNnGMABABTT is set to 1 in the normal operation mode with ABT, FCNnMmCTL.FCNnMmTRQF is set to 1 only for one message buffer in the ABT message buffer group.

If the ABT mode was triggered by FCNnGMABCTL.FCNnGMABSEAT = 1, one FCNnMmCTL.FCNnMmTRQF is set to 1 in the ABT area (buffer 0 through 7). Beyond this transmit request, the application can request transmissions (set FCNnMmTRQF to 1) for other TX-message buffers that do not belong to the ABT area. In that case an interval arbitration process (TX-search) evaluates all TX-message buffers with FCNnMmTRQF set to 1 and chooses the message buffer that contains the highest prioritized identifier for the next transmission. If there are 2 or more identifiers that have the highest priority (i.e. identical identifiers), the message located at the lowest message buffer number is transmitted at first.

Upon successful transmission of a message frame, the following operations are performed.

- The FCNnMmCTL.FCNnMmTRQF flag of the corresponding transmit message buffer is automatically cleared to 0.
 - The transmission completion status bit FCNnCMISCTL.FCNnCMISITSF0 is set to 1 (if the interrupt enable bit FCNnMmIENF of the corresponding transmit message buffer is set to 1).
 - An interrupt request signal INTCnTRX is output (if FCNnCMIECTL.FCNnCMIESEIE0 is set to 1 and if the interrupt enable bit FCNnMmIENF of the corresponding transmit message buffer is set to 1).
- When changing the contents of a transmit buffer, the FCNnMmCTL.FCNnMmRDYF flag of this buffer must be cleared before updating the buffer contents. As during internal transfer actions, the FCNnMmRDYF flag may be locked temporarily, the status of FCNnMmRDYF must be checked by software, after changing it.

18.10.2 Transmit history list function

The transmit history list (THL) function records in the transmit history list the number of the transmit message buffer from which data or remote frames have been sent. The THL consists of storage elements equivalent to up to 7 messages (on 32 message buffer CAN Controller), 15 messages (on 64 message buffer CAN Controller) or up to 31 messages (on 128 message buffer CAN Controller), the last out-message pointer FCNnCMLOSTR[7:0] with the corresponding FCNnCMLOSTR register, and the transmit history list get pointer FCNnCMTGSSPT[7:0] with the corresponding FCNnCMTGTX register.

The THL is undefined immediately after the transition of the CAN Controller from the initialization mode to one of the operation modes.

The FCNnCMLOSTR register holds the contents of the THL element indicated by the value of the FCNnCMLOSTR.FCNnCMLOSTR[7:0] pointer minus 1. By reading the FCNnCMLOSTR register, therefore, the number of the message buffer that transmitted a data frame or remote frame first can be checked. The FCNnCMLOSTR[7:0] pointer is utilized as a write pointer that indicates to what part of the THL a message buffer number is recorded. Any time a data frame or remote frame is transmitted, the corresponding message buffer number is recorded to the THL element indicated by the FCNnCMLOSTR[7:0] pointer. Each time recording to the THL has been completed, the FCNnCMLOSTR[7:0] pointer is automatically incremented. In this way, the number of the message buffer that has received and stored a frame will be recorded chronologically.

For message buffers, where the flag FCNnMmCTL.FCNnMmNHMF is set, no entry in the history lists is recorded.

The FCNnCMTGTX.FCNnCMTGSSPT[7:0] pointer is utilized as a read pointer that reads a recorded message buffer number from the THL. This pointer indicates the first THL element that the CPU has not yet read. By reading the FCNnCMTGTX register by software, the number of a message buffer that has completed transmission can be read. Each time a message buffer number is read from the FCNnCMTGTX register, the FCNnCMTGSSPT[7:0] pointer is automatically incremented.

If the value of the FCNnCMTGTX.FCNnCMTGSSPT[7:0] pointer matches the value of the FCNnCMLOSTR.FCNnCMLOSTR[7:0] pointer, FCNnCMTGTX.FCNnCMTGSSPM (transmit history list pointer match) is set to 1. This indicates that no message buffer numbers that have not been read remain in the THL. If a new message buffer number is recorded, the FCNnCMLOSTR[7:0] pointer is incremented and because its value no longer matches the value of the FCNnCMTGSSPT[7:0] pointer, FCNnCMTGSSPM is cleared. In other words, the numbers of the unread message buffers exist in the THL.

If the FCNnCMLOSTR.FCNnCMLOSTR[7:0] pointer is incremented and matches the value of the FCNnCMTGTX.FCNnCMTGSSPT[7:0] pointer minus 1, FCNnCMTGTX.FCNnCMTGTVFF (transmit history list overflow) is set to 1. This indicates that the THL is full of message buffer numbers that have not been read. If a new message is received and stored, the message buffer number recorded last is overwritten by the message buffer number that transmitted its message afterwards. In this case, after FCNnCMTGTVFF has been set (1), therefore, the recorded message buffer numbers in the THL do not completely reflect the chronological order. However the other transmitted messages can be found by a CPU search applied to all transmit message buffers unless the CPU has not overwritten a transmit object in one of these buffers beforehand. In total up to six transmission completions can occur without overflowing the THL.

Caution If the history list is in the overflow condition (FCNnCMTGTGX.FCNnCMTGTVFF is set), reading the history list contents is still possible, until the history list is empty (indicated by FCNnCMTGTGX.FCNnCMTGSSPM flag set). Nevertheless, the history list remains in the overflow condition, until FCNnCMTGTVFF is cleared by software. If FCNnCMTGTVFF is not cleared, the FCNnCMTGTGX.FCNnCMTGSSPM flag will also not be updated (cleared) upon successful transmission of a new message. This may lead to the situation, that FCNnCMTGSSPM indicates an empty history list, although a successful transmission has taken place, while the history list is in the overflow state (FCNnCMTGTVFF and FCNnCMTGSSPM are set).




Figure 18-11 Transmit history list

18.10.3 Automatic block transmission (ABT)

The automatic block transmission (ABT) function is used to transmit two or more data frames successively with no CPU interaction. The maximum number of transmit message buffers assigned to the ABT function is 8 (for 32 message buffer CAN Controller), 16 (for 64 message buffer CAN Controller) or 32 (for 128 message buffer CAN Controller), always located in the lowest message buffers.

By setting FCNnCM.FCNnCMCLMDOF[2:0] to 010_B, “normal operation mode with automatic block transmission function” (hereafter referred to as ABT mode) can be selected.

To issue an ABT transmission request, define the message buffers by software first. Set FCNnMmSTRB.FCNnMmSSAM = 1 in all the message buffers used for ABT, and define all the buffers as transmit message buffers by setting the FCNnMmSTRB.FCNnMmSSMT[3:0] bits to 0000_B. Be sure to set the same ID for the message buffers for ABT even when that ID is being used for all the message buffers. To use two or more IDs, set the ID of each message buffer by using the FCNnMmMID0H and FCNnMmMID1H or FCNnMmMID0W registers. Set the CAN Controller message buffer data bytes registers before issuing a transmission request for the ABT function.

After initialization of message buffers for ABT is finished, FCNnMmCTL.FCNnMmRDYF needs to be set to 1. In the ABT mode, FCNnMmCTL.FCNnMmTRQF does not have to be manipulated by software.

After the data for the ABT message buffers has been prepared, set FCNnGMABCTL.FCNnGMABSEAT = 1. Automatic block transmission is then started. When ABT is started, FCNnMmCTL.FCNnMmTRQF in the first message buffer (message buffer 0) is automatically set to 1. After transmission of the data of message buffer 0 is finished, the FCNnMmTRQF of the next message buffer, message buffer 1, is set automatically. In this way, transmission is executed successively.

A delay time can be inserted by program in the interval in which the transmission request FCNnMmCTL.FCNnMmTRQF is automatically set while successive transmission is being executed. The delay time to be inserted is defined by the FCNnGMADCTL register. The unit of the delay time is DBT (data bit time). DBT depends on the setting of the FCNnCMBRPRS and FCNnCMBTCTL registers.

Among transmit objects within the ABT-area, the priority of the transmission ID is not evaluated. The data of message buffers 0 to 7 are sequentially transmitted. When transmission of the data frame from message buffer 7 has been completed, FCNnGMABCTL.FCNnGMABABTT is automatically cleared to 0 and the ABT operation is finished.

If FCNnMmCTL.FCNnMmRDYF of an ABT message buffer is cleared during ABT, no data frame is transmitted from that buffer, ABT is stopped, and FCNnGMABCTL.FCNnGMABABTT is cleared. After that, transmission can be resumed from the message buffer where ABT stopped, by setting FCNnMmRDYF and FCNnGMABABTT to 1 by software. To not resume transmission from the message buffer where ABT stopped, the internal ABT engine can be reset by setting the FCNnGMABCTL.FCNnGMABCLRFB bit to 1 while ABT mode is stopped and FCNnGMABABTT is cleared to 0. In this case, transmission is started from message buffer 0 if FCNnGMABCTL.FCNnGMABSEAC is cleared to 0 and then FCNnGMABABTT is set to 1.

An interrupt can be used to check if data frames have been transmitted from all the message buffers for ABT. To do so, FCNnMmCTL.FCNnMmIENF of each message buffer except the last message buffer needs to be cleared (0).

If a transmit message buffer other than those used by the ABT function is assigned to a transmit message buffer, the message to be transmitted next is determined by the priority of the transmission ID of the ABT message buffer whose transmission is currently held pending and the transmission ID of the message buffers other than those used by the ABT function.

Transmission of a data frame from an ABT message buffer is not recorded in the transmit history list (THL).

Cautions

1. Set FCNnGMABCTL.FCNnGMABSEAC = 1 while FCNnGMABCTL.FCNnGMABABTT is cleared to 0 in order to resume ABT operation at buffer No. 0. If FCNnGMABSEAC is set to 1 while FCNnGMABABTT is set to 1, the subsequent operation is not guaranteed.
 2. If the automatic block transmission engine is cleared by setting FCNnGMABCTL.FCNnGMABSEAC = 1, FCNnGMABSEAC is automatically cleared immediately after the processing of the clearing request is completed.
 3. Do not trigger automatic block transmission in the initialization mode. If FCNnGMABCTL.FCNnGMABSEAC is set in the initialization mode, the proper operation is not guaranteed after the mode is changed from the initialization mode to the ABT mode.
 4. Do not set FCNnMmCTL.FCNnMmTRQF of the ABT message buffers to 1 by software in the normal operation mode with ABT. Otherwise, the operation is not guaranteed.
 5. The FCNnGMADCTL register is used to set the delay time that is inserted in the period from completion of the preceding ABT message to setting of FCNnMmCTL.FCNnMmTRQF for the next ABT message when the transmission requests are set in the order of message numbers for each message for ABT that is successively transmitted in the ABT mode. The timing at which the messages are actually transmitted onto the CAN bus varies depending on the status of transmission from other stations and the status of the setting of the transmission request for messages other than the ABT messages.
 6. If a transmission request is made for a message other than an ABT message and if no delay time is inserted in the interval in which transmission requests for ABT are automatically set (FCNnGMADCTL = 00_H), messages other than ABT messages may be transmitted not depending on their priority compared to the priority of the ABT message.
 7. Do not clear FCNnMmCTL.FCNnMmRDYF to 0 when FCNnGMABCTL.FCNnGMABABTT = 1.
 8. If a message is received from another node while normal operation mode with ABT is active, the TX-message from the ABT-area may be transmitted with delay of one frame although FCNnGMADCTL register was set up with 00_H.
-

18.10.4 Transmission abort process

(1) Transmission abort process except for in normal operation mode with automatic block transmission (ABT)

The user can clear FCNnMmCTL.FCNnMmTRQF to 0 to abort a transmission request. FCNnMmTRQF will be cleared immediately if the abort was successful. Whether the transmission was successfully aborted or not can be checked using FCNnCMCLCTL.FCNnCMCLSSTS and the FCNnCMGTGX register, or the FCNnMmCTL.FCNnMmTCPF flag, which indicate the transmission status on the CAN bus (for details, refer to the processing in *Figure 18-27 "Transmission abort processing (except normal operation mode with ABT)" on page 1011*).

(2) Transmission abort process except for ABT transmission in normal operation mode with automatic block transmission (ABT)

The user can clear FCNnGMABCTL.FCNnGMABABTT to 0 to abort a transmission request. After checking FCNnGMABABTT = 0, clear FCNnMmCTL.FCNnMmTRQF to 0. FCNnMmTRQF will be cleared immediately if the abort was successful. Whether the transmission was successfully aborted or not can be checked using FCNnCMCLCTL.FCNnCMCLSSTS and the FCNnCMGTGX register, or the FCNnMmCTL.FCNnMmTCPF flag, which indicate the transmission status on the CAN bus (for details, refer to the processing in *Figure 18-28 "Transmission abort processing (normal operation mode with ABT) - Repeat option for aborted message" on page 1012*).

(3) Transmission abort process for ABT transmission in normal operation mode with automatic block transmission (ABT)

To abort ABT that is already started, clear FCNnGMABCTL.FCNnGMABCLAT to 0. In this case, FCNnGMABCTL.FCNnGMABABTT remains 1 if an ABT message is currently being transmitted and until the transmission is completed (successfully or not), and is cleared to 0 as soon as transmission is finished. This aborts ABT.

If the last transmission (before ABT) was successful, the normal operation mode with ABT is left with the internal ABT pointer pointing to the next message buffer to be transmitted.

In the case of an erroneous transmission, the position of the internal ABT pointer depends on the status of FCNnMmCTL.FCNnMmTRQF in the last transmitted message buffer. If FCNnMmTRQF is set to 1 when clearing FCNnGMABCTL.FCNnGMABABTT is requested, the internal ABT pointer points to the last transmitted message buffer (for details, refer to the process in *Figure 18-29 "Transmission abort processing (normal operation mode with ABT) - No repetition option for aborted message" on page 1013*). If FCNnMmTRQF is cleared to 0 when clearing FCNnGMABABTT is requested, the internal ABT pointer is incremented (+1) and points to the next message buffer in the ABT area (for details, refer to the process in *Figure 18-30 "ABT transmission request abort processing (normal operation mode with ABT)" on page 1014*).

Caution Be sure to abort ABT by clearing FCNnGMABCTL.FCNnGMABCLAT to 0. The operation is not guaranteed if aborting transmission is requested by clearing FCNnMmCTL.FCNnMmRDYF.

When the normal operation mode with ABT is resumed after ABT has been aborted and FCNnGMABCTL.FCNnGMABSEAT is set to 1, the next ABT message buffer to be transmitted can be determined from the following table.

Status of FCNnMmCTL. FCNnMmTRQF of ABT message buffer	Abort after successful transmission	Abort after erroneous transmission
Set (1)	Next message buffer in the ABT area ^a	Same message buffer in the ABT area
Cleared (0)	Next message buffer in the ABT area ^a	Next message buffer in the ABT area ^a

- a) The above resumption operation can be performed only if a message buffer ready for ABT exists in the ABT area. For example, an abort request that is issued while ABT of highest ABT message buffer is in progress is regarded as completion of ABT, rather than abort, if transmission of this message buffer has been successfully completed, even if FCNnGMABCTL.FCNnGMABABTT is cleared to 0. If FCNnMmCTL.FCNnMmRDYF in the next message buffer in the ABT area is cleared to 0, the internal ABT pointer is retained, but the resumption operation is not performed even if FCNnGMABABTT is set to 1, and ABT ends immediately.

18.10.5 Remote frame transmission

Remote frames can be transmitted only from transmit message buffers. Set whether a data frame or remote frame is transmitted via FCNnMmSTRB.FCNnMmSSRT. Setting FCNnMmSSRT = 1 sets remote frame transmission.

18.11 Power Saving Modes

18.11.1 CAN Controller sleep mode

The CAN Controller sleep mode can be used to set the CAN Controller to stand-by mode in order to reduce power consumption. The CAN Controller can enter the sleep mode from all operation modes. Release of the sleep mode returns the CAN Controller to exactly the same operation mode from which the sleep mode was entered.

In the sleep mode, the CAN Controller does not transmit messages, even when transmission requests are issued or pending.

(1) Entering CAN Controller sleep mode

The CPU issues a CAN Controller sleep mode transition request by setting $\text{FCNnCMCLCTL.FCNnCMCLMDPF}[1:0] = 01_{\text{B}}$.

This transition request is acknowledged only under the following conditions.

1. The CAN Controller is already in one of the following operation modes
 - Normal operation mode
 - Normal operation mode with ABT
 - Receive-only mode
 - Single-shot mode
 - Self-test mode
 - CAN Controller stop mode in all the above operation modes
2. The CAN bus state is bus idle (the 4th bit in the interframe space is recessive).
If the CAN bus is fixed to dominant, the request for transition to the sleep mode is held pending. Also the transition from stop mode to sleep mode is independent of the CAN bus state.
3. No transmission request is pending.

Note If a sleep mode request is pending, and at the same time a message is received in a message box, the sleep mode request is not cancelled, but is executed right after message storage has been finished. This may result in CAN Controller being in sleep mode, while the CPU would execute the RX interrupt routine. Therefore, the interrupt routine must check the access to the message buffers as well as reception history list registers by using the FCNnGMCLSSMO flag, if sleep mode is used.

If any one of the conditions mentioned above is not met, the CAN Controller will operate as follows.

- If the sleep mode is requested from the initialization mode, the sleep mode transition request is ignored and the CAN Controller remains in the initialization mode.
- If the CAN bus state is not bus idle (i.e., the CAN bus state is either transmitting or receiving) when the sleep mode is requested in one of the operation modes, immediate transition to the sleep mode is not possible. In this case, the sleep mode transition request is held pending until the CAN bus state becomes bus idle (the 4th bit in the interframe space is recessive). In the time from the sleep mode request to successful transition, $\text{FCNnCMCLCTL.FCNnCMCLMDPF}[1:0]$ remain 00_{B} . When the channel has entered the sleep mode, the $\text{FCNnCMCLMDPF}[1:0]$ bits are set to 01_{B} .

- If a request for transition to the initialization mode and a request for transition to the sleep mode are made at the same time while the CAN Controller is in one of the operation modes, the request for the initialization mode is enabled. The CAN Controller enters the initialization mode at a predetermined timing. At this time, the sleep mode request is not held pending and is ignored.
- Even when initialization mode and sleep mode are not requested simultaneously (i.e the first request has not been granted while the second request is made), the request for initialization has priority over the sleep mode request. The sleep mode request is cancelled when the initialization mode is requested. When a pending request for initialization mode is present, a subsequent request for Sleep mode request is cancelled right at the point in time where it was submitted.

(2) Status in CAN Controller sleep mode

The CAN Controller is in the following state after it enters the sleep mode:

- The CAN channel clock T_{CANCH} is stopped and the power consumption is minimized.
- The function to detect the falling edge of the CAN Controller reception pin (CRXDn) remains in effect to wake up the CAN Controller from the CAN bus.
- To wake up the CAN Controller from the CPU, data can be set to FCNnCMCLCTL.FCNnCMCLMDPF[1:0], but nothing can be written to other CAN Controller registers or bits.
- The CAN Controller registers can be read, except for the FCNnCMLISTR, FCNnCMRGRX, FCNnCMLOSTR, and FCNnCMTGTX registers.
- The CAN Controller message buffer registers cannot be written or read.
- FCNnGMCLCTL.FCNnGMCLSSMO is cleared.
- The registers FCNnDNBMRX cannot be read.
- A request for transition to the initialization mode is not acknowledged and is ignored.

(3) Releasing CAN Controller sleep mode

The CAN Controller sleep mode is released by the following events:

- When the CPU sets 00_B to FCNnCMCLCTL.FCNnCMCLMDPF[1:0]
- A falling edge at the CAN Controller reception pin CRXDn (i.e. the CAN bus level shifts from recessive to dominant)

Caution Even if the falling edge belongs to the SOF of a receive message, this message will not be received and stored. If the CPU has turned off the clock supply to the CAN Controller while the CAN Controller was in sleep mode, even subsequently the sleep mode will not be released and FCNnCMCLMDPF[1:0] will remain 01_B unless the clock to the CAN Controller is supplied again. In addition to this, the receive message will not be received after that.

After releasing the sleep mode, the CAN Controller returns to the operation mode from which the sleep mode was requested and FCNnCMCLCTL.FCNnCMCLCTL[1:0] must be reset by software to 00_B. If the CAN Controller sleep mode is released by a change in the CAN bus state, FCNnCMISCTL.FCNnCMISITSF5 is set to 1, regardless of FCNnCMIECTL.FCNnCMIEINTF[6:0]. After the CAN Controller is released from the sleep mode, it participates in the CAN bus again by automatically detecting 11 consecutive recessive-level bits on the CAN bus. The user application has to wait until FCNnGMCLCTL.FCNnGMCLSSMO = 1, before accessing message buffers again.

When a request for transition to the initialization mode is made while the CAN Controller is in the sleep mode, that request is ignored; the CAN Controller has to be released from sleep mode by software first before entering the initialization mode.

-
- Cautions**
1. Be aware that the release of sleep mode by CAN bus event, and thus the wake up interrupt may happen at any time, even right after requesting sleep mode, if a CAN bus event occurs.
 2. Always reset the FCNnCMCLCTL.FCNnCMCLMDPF[1:0] bits to 00_B, when waking up from sleep mode, before accessing any other registers of the CAN Controller.
 3. Always clear the interrupt flag FCNnCMISCTL.FCNnCMISITSF5, when waking up from sleep mode.
-

18.11.2 CAN Controller stop mode

The CAN Controller stop mode can be used to set the CAN Controller to stand-by mode to reduce power consumption. The CAN Controller can enter the stop mode only from the sleep mode. Release of the stop mode puts the CAN Controller in the sleep mode.

The stop mode can only be released (entering sleep mode) by setting 01_B to FCNnCMCLCTL.FCNnCMCLMDPF[1:0] and not by a change in the CAN bus state. No message is transmitted even when transmission requests are issued or pending.

(1) Entering CAN Controller stop mode

A stop mode transition request is issued by setting 11_B to FCNnCMCLCTL.FCNnCMCLMDPF[1:0].

A stop mode request is only acknowledged when the CAN Controller is in the sleep mode. In all other modes, the request is ignored.

Caution To set the CAN Controller to the stop mode, it must be in the sleep mode first. To confirm that the CAN Controller is in the sleep mode, check that the FCNnCMCLCTL.FCNnCMCLMDPF[1:0] = 01_B, and then request the stop mode. If a bus change occurs at the CAN Controller reception pin CRXDn while this process is being performed, the sleep mode is automatically released. In this case, the stop mode transition request cannot be acknowledged.

(2) Status in CAN Controller stop mode

The CAN Controller is in the following state after it enters the stop mode.

- The CAN channel clock T_{CANCH} is stopped and the power consumption is minimized.
- To wake up the CAN Controller from the CPU, data can be set to FCNnCMCLCTL.FCNnCMCLMDPF[1:0], but nothing can be written to other CAN Controller registers or bits.
- The CAN Controller registers can be read, except for the FCNnCMCLISTR, FCNnCMRGRX, FCNnCMLOSTR, and FCNnCMTGTX registers.
- The CAN Controller message buffer registers cannot be written or read.
- FCNnGMCLCTL.FCNnGMCLSSMO is cleared.
- The registers FCNnDNBMRX cannot be read.
- An initialization mode transition request is not acknowledged and is ignored.

(3) Releasing CAN Controller stop mode

The stop mode can only be released by writing 01_B to FCNnCMCLCTL.FCNnCMCLMDPF[1:0]. After releasing the stop mode, the CAN Controller enters the sleep mode.

When the initialization mode is requested while the CAN Controller is in the stop mode, that request is ignored; the CPU has to release the stop mode and subsequently sleep mode before entering the initialization mode. It is impossible to enter the other operation mode directly from the stop mode not entering the sleep mode, that request is ignored.

18.11.3 Example of using power saving modes

In some application systems, it may be necessary to place the CPU in a power saving mode to reduce the power consumption. By using the power saving mode specific to the CAN Controller and the power saving mode specific to the CPU in combination, the CPU can be woken up from the power saving status by the CAN bus.

Here is an example for using the power saving modes.

- First, put the CAN Controller in the sleep mode (FCNnCMCLCTL.FCNnCMCLMDPF[1:0] = 01_B).
After successfully confirming this state by reading back the sleep mode status, put the CPU in the power saving mode. Disable interrupts for the CPU, while processing additional tasks after the CAN Controller is in sleep mode, to avoid that the CAN Controller wakeup interrupt is acknowledged. If an edge transition from recessive to dominant is detected at the CAN Controller reception pin CRXDn in this status, FCNnCMISCTL.FCNnCMISITSF5 in the CAN Controller is set to 1. If FCNnCNIECTL.FCNnCMIEINT5 is set to 1, a wakeup interrupt (INTCnWUP) is generated.
The CAN Controller is automatically released from sleep mode (FCNnCMCLMDPF[1:0] = 00_B) and returns to normal operation mode.
- The CPU, in response to INTCnWUP, can release its own power saving mode and return to normal operation mode.
To further reduce the power consumption of the CPU, the internal clock - including that of the CAN Controller - may be stopped. In this case, the operating clock supplied to the CAN Controller is stopped after the CAN Controller has been put in sleep mode. Then the CPU enters a power saving mode in which the clock supplied to the CPU is stopped.
- If an edge transition from recessive to dominant is detected at the CAN Controller reception pin CRXDn in this status, the CAN Controller can set FCNnCMISCTL.FCNnCMISITSF5 to 1 and generate the wakeup interrupt INTCnWUP even if it is not supplied with the clock.
- The other functions, however, do not operate, because clock supply to the CAN Controller is stopped, which remains in sleep mode.
- The CPU, in response to INTCnWUP,
 - releases its power saving mode,
 - resumes supply of the internal clocks - including the clock to the CAN Controller - after the oscillation stabilization time has elapsed, and
 - starts instruction execution.
- The CAN Controller is immediately released from the sleep mode when clock supply is resumed, and returns to the normal operation mode (FCNnCMCLCTL.FCNnCMCLMDPF[1:0] = 00_B).

18.12 Interrupt Function

The CAN Controller provides 6 different interrupt sources.

The occurrence of these interrupt sources is stored in interrupt status registers. Four separate interrupt request signals are generated from the six interrupt sources. When an interrupt request signal that corresponds to two or more interrupt sources is generated, the interrupt sources can be identified by using an interrupt status register. After an interrupt source has occurred, the corresponding interrupt status bit must be cleared to 0 by software.

Table 18-21 List of CAN Controller interrupt sources

No.	Interrupt status bit FCNnCMISCTL.	Interrupt enable bit FCNnCMIESEIE ^a	Interrupt request signal	Interrupt source description
1	FCNnCMISITSF0	FCNnCMIESEIE0	INTCnTRX	Message frame successfully transmitted from message buffer m
2	FCNnCMISITSF1	FCNnCMIESEIE1	INTCnREC	Valid message frame reception in message buffer m
3	FCNnCMISITSF2	FCNnCMIESEIE2	INTCnERR	CAN Controller error state interrupt <ul style="list-style-type: none"> This interrupt is generated when the transmission/reception error counter is at the warning level, or in the error passive or bus-off state.
4	FCNnCMISITSF3	FCNnCMIESEIE3		CAN Controller protocol error interrupt <ul style="list-style-type: none"> This interrupt is generated when a stuff error, form error, ACK error, bit error, or CRC error occurs.
5	FCNnCMISITSF4	FCNnCMIESEIE4		CAN Controller arbitration loss interrupt
6	FCNnCMISITSF5	FCNnCMIESEIE5	INTCnWUP	CAN Controller wakeup interrupt from CAN Controller sleep mode <ul style="list-style-type: none"> This interrupt is generated when the CAN Controller is woken up from the sleep mode because a falling edge is detected at the CAN Controller reception pin (CAN bus transition from recessive to dominant).
7	FCNnCMISITSF6	FCNnCMIESEIE6		CAN Controller transmit abort interrupt status <ul style="list-style-type: none"> This interrupt is generated when the abortion of a transmission was successful (aborted message was not sent).

^{a)} The message buffer interrupt enable bit FCNnMmCTL.FCNnMmIENF of the corresponding message buffer has to be set to 1 for that message buffer to participate in the interrupt generation process.

18.13 Diagnosis Functions and Special Operational Modes

The CAN Controller provides a receive-only mode, single-shot mode, and self-test mode to support CAN bus diagnosis functions or the operation of special CAN communication methods.

18.13.1 Receive-only mode

The receive-only mode is used to monitor receive messages without causing any interference on the CAN bus and can be used for CAN bus analysis nodes.

For example, this mode can be used for automatic baud-rate detection. The baudrate in the CAN Controller is changed until “valid reception” is detected, so that the baudrates are matching (“valid reception” means a message frame has been received in the CAN protocol layer without occurrence of an error and with an appropriate ACK between nodes connected to the CAN bus). A valid reception does not require message frames to be stored in a receive message buffer (data frames) or transmit message buffer (remote frames). The event of valid reception is indicated by setting $FCNnCMCLCTL.FCNnCMCLVALF = 1$.




Figure 18-12 CAN Controller terminal connection in receive-only mode

In the receive-only mode, no message frames can be transmitted from the CAN Controller to the CAN bus. Transmit requests issued for message buffers defined as transmit message buffers are held pending.

In the receive-only mode, the CAN Controller transmission pin CTXDn in the CAN Controller is fixed to the recessive level. Therefore, no active error flag can be transmitted from the CAN Controller to the CAN bus even when a CAN bus error is detected while receiving a message frame. Since no transmission can be issued from the CAN Controller, the transmission error counter the $FCNnCMERCNT.TEC7$ to $FCNnCMERCNT.TEC0$ bits are never updated. Therefore, a CAN Controller in the receive-only mode does not enter the bus-off state.

Furthermore, in the receive-only mode ACK is not returned to the CAN bus in this mode upon the valid reception of a message frame. Internally, the local node recognizes that it has transmitted ACK. An overload frame cannot be transmitted to the CAN bus.

Caution If only two CAN nodes are connected to the CAN bus and one of them is operating in the receive-only mode, there is no ACK on the CAN bus. Due to the missing ACK, the transmitting node will transmit an active error flag, and repeat transmitting a message frame. The transmitting node becomes error passive after transmitting the message frame 16 times (assuming that the error counter was 0 in the beginning and no other errors have occurred). After the message frame for the 17th time is transmitted, the transmitting node generates a passive error flag. The receiving node in the receive-only mode detects the first valid message frame at this point, and the FCNnCMCLCTL.FCNnCMCLVALF bit is set to 1 for the first time.

18.13.2 Single-shot mode

In the single-shot mode, automatic re-transmission as defined in the CAN protocol is switched off. (According to the CAN protocol, a message frame transmission that has been aborted by either arbitration loss or error occurrence has to be repeated without control by software.) All other behavior of single shot mode is identical to normal operation mode. Features of single shot mode can not be used in combination with normal mode with ABT.

The single-shot mode disables the re-transmission of an aborted message frame transmission according to the setting of FCNnCMCLCTL.FCNnCMCLALBF. When FCNnCMCLALBF is cleared to 0, re-transmission upon arbitration loss and upon error occurrence is disabled. If FCNnCMCLALBF is set to 1, re-transmission upon error occurrence is disabled, but re-transmission upon arbitration loss is enabled. As a consequence, FCNnMmCTL.FCNnMmTRQF in a message buffer defined as a transmit message buffer is cleared to 0 by the following events:

- Successful transmission of the message frame
- Arbitration loss while sending the message frame
- Error occurrence while sending the message frame

The events arbitration loss and error occurrence can be distinguished by checking FCNnCMISCTL.FCNnCMISITSF4 and FCNnCMISCTL.FCNnCMISITSF3 respectively, and the type of the error can be identified by reading FCNnCMLCSTR.FCN0CMLCSSLC[2:0].

Upon successful transmission of the message frame, the transmit completion interrupt bit FCNnCMISCTL.FCNnCMISITSF0 is set to 1. If FCNnCMIECTL.FCNnCMIEINTF0 is set to 1 at this time, an interrupt request signal is output.

The single-shot mode can be used when emulating time-triggered communication methods (e.g., TTCAN level 1).

Caution FCNnCMCLCTL.FCNnCMCLALBF is only valid in single-shot mode. It does not influence the operation of re-transmission upon arbitration loss in the other operation modes.

18.13.3 Self-test mode

In the self-test mode, message frame transmission and message frame reception can be tested without connecting the CAN node to the CAN bus or without affecting the CAN bus.

In the self-test mode, the CAN Controller is completely disconnected from the CAN bus, but transmission and reception are internally looped back. The CAN Controller transmission pin CTXDn is fixed to the recessive level.

If the falling edge on the CAN Controller reception pin CRXDn is detected after the CAN Controller has entered the CAN Controller sleep mode from the self-test mode, however, the CAN Controller is released from sleep mode in the same manner as the other operation modes. To keep the CAN Controller in the sleep mode, use the CAN Controller reception pin CRXDn as a port pin.




Figure 18-13 CAN Controller terminal connection in self-test mode

18.13.4 Receive/transmit operation in each operation mode

The following table shows outline of the receive/transmit operation in each operation mode.

Table 18-22 Outline of the receive/transmit in each operation mode

Operation mode	Transmission of data/remote frame	Transmission of ACK	Transmission of error/overload frame	Transmission on retry	Automatic block transmission (ABT)	Set of FCNnCM CLVALF bit	Store data to message buffer
Initialization mode	No	No	No	No	No	No	No
Normal operation mode	Yes	Yes	Yes	Yes	No	Yes	Yes
Normal operation mode with ABT	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Receive only mode	No	No	No	No	No	Yes	Yes
Single-shot mode	Yes	Yes	Yes	No ^a	No	Yes	Yes
Self-test mode	Yes ^b	Yes ^b	Yes ^b	Yes ^b	No	Yes ^b	Yes ^b

^{a)} When the arbitration lost occurs, control of re-transmission is possible by FCNnCMCLCTL.FCNnCMCLALBF.

^{b)} Each signals are not generated to outside, but generated into the CAN Controller.

18.14 Time Stamp Function

CAN is an asynchronous, serial protocol. All nodes connected to the CAN bus have a local, autonomous clock. As a consequence, the clocks of the nodes have no relation (i.e., the clocks are asynchronous and may have different frequencies).

In some applications, however, a common time base over the network (= global time base) is needed. In order to build up a global time base, a time stamp function is used. The essential mechanism of a time stamp function is the capture of timer values triggered by signals on the CAN bus.

18.14.1 Time stamp function

The CAN Controller supports the capturing of timer values triggered by a specific frame. An on-chip 16-bit capture timer unit of the microcontroller is used in addition to the CAN Controller. The 16-bit capture timer unit captures the timer value according to a trigger signal (TSOUT) for capturing that is output when a data frame is received from the CAN Controller. The CPU can retrieve the time of occurrence of the capture event, i.e., the time stamp of the message received from the CAN bus, by reading the captured value. The TSOUT signal can be selected from the following two event sources and is specified by FCNnCMTSCTL.FCNnCMTSSELE.

- SOF event (start of frame)
(FCNnCMTSCTL.FCNnCMTSSELE = 0)
- EOF event (last bit of end of frame)
(FCNnCMTSCTL.FCNnCMTSSELE = 1)

The TSOUT signal is enabled by setting FCNnCMTSCTL.FCNnCMTSTSGE = 1.




Figure 18-14 Timing diagram of capture signal TSOUT

The TSOUT signal toggles its level upon occurrence of the selected event during data frame reception (in Figure 18-14 “Timing diagram of capture signal TSOUT”, the SOF is used as the trigger event source). To capture a timer value by using the TSOUT signal, the capture timer unit must detect the capture signal at both the rising edge and falling edge.

This time stamp function is controlled by the FCNnCMTSLOKE bit of the FCNnCMTSCTL register. When FCNnCMTSLOKE is cleared to 0, the TSOUT signal toggles upon occurrence of the selected event. If FCNnCMTSLOKE is set to 1, the TSOUT signal toggles upon occurrence of the selected event, but the toggle is stopped as FCNnCMTSCTL.FCNnCMTSTSGE is automatically cleared to 0 as soon as the message storing to the message buffer 0 starts. This suppresses the subsequent toggle occurrence by the TSOUT signal, so

that the time stamp value toggled last (= captured last) can be saved as the time stamp value of the time at which the data frame was received in message buffer 0.

Caution The time stamp function using the FCNnCMTSLOKE bit stops toggle of the TSOUT signal by receiving a data frame in message buffer 0. Toggle of the TSOUT signal does not stop when a data frame is received in a message buffer other than message buffer 0.
A data frame cannot be received in message buffer 0 when the CAN Controller is in the normal operation mode with ABT, because message buffer 0 must be set as a transmit message buffer.
In this operation mode, therefore, the function to stop toggle of the TSOUT signal by the FCNnCMTSLOKE bit cannot be used.

18.15 Baudrate Settings

18.15.1 Baudrate setting conditions

Make sure that the settings are within the range of limit values for ensuring correct operation of the CAN Controller, as follows.

- $5 TQ \leq SPT$ (sampling point) $\leq 17 TQ$
 $SPT = TSEG1 + 1$
- $8 TQ \leq DBT$ (data bit time) $\leq 25 TQ$
 $DBT = TSEG1 + TSEG2 + 1 TQ = TSEG2 + SPT$
- $1 TQ \leq SJW$ (synchronization jump width) $\leq 4 TQ$
 $SJW \leq DBT - SPT$
- $4 \leq TSEG1 \leq 16$
- $1 \leq TSEG2 \leq 8$

- Notes**
1. $TQ = 1/f_{TQ}$ (f_{TQ} : CAN protocol layer clock)
 2. The values TSEG1, TSEG2 and SJW are defined by following register bits:
 $TSEG1 = FCNnCMBTCTL.FCNnCMBTS1LG[3:0] + 1$
 $TSEG2 = FCNnCMBTCTL.FCNnCMBTS2LG[2:0] + 1$
 $SJW = FCNnCMBTCTL.FCNnCMBTJWLG[1:0] + 1$

Table 18-23 “Settable bit rate combinations” shows the combinations of bit rates that satisfy the above conditions.

Table 18-23 Settable bit rate combinations (1/3)

Valid bit rate setting					FCNnCMBTCTL register setting value		Sampling point (unit %)
DBT length	SYNC SEGMENT	PROP SEGMENT	PHASE SEGMENT1	PHASE SEGMENT2	FCNnCMBT S1LG[3:0]	FCNnCMBT S2LG[2:0]	
25	1	8	8	8	1111	111	68.0
24	1	7	8	8	1110	111	66.7
24	1	9	7	7	1111	110	70.8
23	1	6	8	8	1101	111	65.2
23	1	8	7	7	1110	110	69.6
23	1	10	6	6	1111	101	73.9
22	1	5	8	8	1100	111	63.6
22	1	7	7	7	1101	110	68.2
22	1	9	6	6	1110	101	72.7
22	1	11	5	5	1111	100	77.3
21	1	4	8	8	1011	111	61.9
21	1	6	7	7	1100	110	66.7
21	1	8	6	6	1101	101	71.4
21	1	10	5	5	1110	100	76.2
21	1	12	4	4	1111	011	81.0
20	1	3	8	8	1010	111	60.0
20	1	5	7	7	1011	110	65.0
20	1	7	6	6	1100	101	70.0
20	1	9	5	5	1101	100	75.0
20	1	11	4	4	1110	011	80.0
20	1	13	3	3	1111	010	85.0
19	1	2	8	8	1001	111	57.9
19	1	4	7	7	1010	110	63.2
19	1	6	6	6	1011	101	68.4
19	1	8	5	5	1100	100	73.7
19	1	10	4	4	1101	011	78.9
19	1	12	3	3	1110	010	84.2
19	1	14	2	2	1111	001	89.5
18	1	1	8	8	1000	111	55.6
18	1	3	7	7	1001	110	61.1
18	1	5	6	6	1010	101	66.7
18	1	7	5	5	1011	100	72.2
18	1	9	4	4	1100	011	77.8
18	1	11	3	3	1101	010	83.3
18	1	13	2	2	1110	001	88.9
18	1	15	1	1	1111	000	94.4
17	1	2	7	7	1000	110	58.8

Table 18-23 Settable bit rate combinations (2/3)

Valid bit rate setting					FCNnCMBTCTL register setting value		Sampling point (unit %)
DBT length	SYNC SEGMENT	PROP SEGMENT	PHASE SEGMENT1	PHASE SEGMENT2	FCNnCMBT S1LG[3:0]	FCNnCMBT S2LG[2:0]	
17	1	4	6	6	1001	101	64.7
17	1	6	5	5	1010	100	70.6
17	1	8	4	4	1011	011	76.5
17	1	10	3	3	1100	010	82.4
17	1	12	2	2	1101	001	88.2
17	1	14	1	1	1110	000	94.1
16	1	1	7	7	0111	110	56.3
16	1	3	6	6	1000	101	62.5
16	1	5	5	5	1001	100	68.8
16	1	7	4	4	1010	011	75.0
16	1	9	3	3	1011	010	81.3
16	1	11	2	2	1100	001	87.5
16	1	13	1	1	1101	000	93.8
15	1	2	6	6	0111	101	60.0
15	1	4	5	5	1000	100	66.7
15	1	6	4	4	1001	011	73.3
15	1	8	3	3	1010	010	80.0
15	1	10	2	2	1011	001	86.7
15	1	12	1	1	1100	000	93.3
14	1	1	6	6	0110	101	57.1
14	1	3	5	5	0111	100	64.3
14	1	5	4	4	1000	011	71.4
14	1	7	3	3	1001	010	78.6
14	1	9	2	2	1010	001	85.7
14	1	11	1	1	1011	000	92.9
13	1	2	5	5	0110	100	61.5
13	1	4	4	4	0111	011	69.2
13	1	6	3	3	1000	010	76.9
13	1	8	2	2	1001	001	84.6
13	1	10	1	1	1010	000	92.3
12	1	1	5	5	0101	100	58.3
12	1	3	4	4	0110	011	66.7
12	1	5	3	3	0111	010	75.0

Table 18-23 Settable bit rate combinations (3/3)

Valid bit rate setting					FCNnCMBTCTL register setting value		Sampling point (unit %)
DBT length	SYNC SEGMENT	PROP SEGMENT	PHASE SEGMENT1	PHASE SEGMENT2	FCNnCMBT S1LG[3:0]	FCNnCMBT S2LG[2:0]	
12	1	7	2	2	1000	001	83.3
12	1	9	1	1	1001	000	91.7
11	1	2	4	4	0101	011	63.6
11	1	4	3	3	0110	010	72.7
11	1	6	2	2	0111	001	81.8
11	1	8	1	1	1000	000	90.9
10	1	1	4	4	0100	011	60.0
10	1	3	3	3	0101	010	70.0
10	1	5	2	2	0110	001	80.0
10	1	7	1	1	0111	000	90.0
9	1	2	3	3	0100	010	66.7
9	1	4	2	2	0101	001	77.8
9	1	6	1	1	0110	000	88.9
8	1	1	3	3	0011	010	62.5
8	1	3	2	2	0100	001	75.0
8	1	5	1	1	0101	000	87.5
7 ^a	1	2	2	2	0011	001	71.4
7 ^a	1	4	1	1	0100	000	85.7
6 ^a	1	1	2	2	0010	001	66.7
6 ^a	1	3	1	1	0011	000	83.3
5 ^a	1	2	1	1	0010	000	80.0
4 ^a	1	1	1	1	0001	000	75.0

a) Setting with a DBT value of 7 or less is valid only when the value of the FCNnCMBRPRS register is other than 00_H.

Caution The values in *Table 18-23 “Settable bit rate combinations”* do not guarantee the operation of the network. Thoroughly check the effect on the network, taking into consideration oscillation errors and delays of the CAN bus and CAN transceiver.

18.15.2 Clock prescaler and baudrate generator settings

In order to achieve the desired baudrate, time quanta, respectively data bit rate, combinations, described in the section above, the clock prescaler and the baudrate generator must be set up properly.

The diagram belows shows the clocks and how they are generated.




Figure 18-15 CAN Controller clocks

The setting of the global clock selection register bits $FCNnGMCSRSC.FCNnCSRSC[3:0]$ for the desired CAN channel clock f_{CANCHN} is calculated as follows:

$$FCNnGMCSRSC = \frac{f_{CAN}}{f_{CANCHN}} - 1$$

f_{CAN} : clock supplied to CAN Controller (unit: Hz)

f_{CANCHN} : CAN channel clock (unit: Hz)

Following conditions must be met:

- $0 \leq FCNnCSRSC \leq 15$
- $FCNnCSRSC$ defines an integer value with no remainder.

The setting of the channel bit rate prescaler register $FCNnCMBRPRS$ for the desired data bit time DBT and the baudrate is calculated as follows:

$$FCNnCMBRPRS = \frac{f_{CANCHN}}{DBT \cdot BRT} - 1$$

f_{CANCHN} : CAN channel clock (unit: Hz)

DBT : Data bit time (unit: 1/bit)

BRT : Baudrate (unit: bit/s)

If the baudrate is given, f_{CANCHN} and DBT must be selected such, that following conditions are met:

- $0 \leq \text{FCNnCMBRPRS} \leq 15$
- FCNnCMBRPRS defines an integer value with no remainder.
- $8 \leq \text{DBT} \leq 25$
- The restrictions in *Table 18-23 "Settable bit rate combinations"* on page 994 have to be obeyed.
- Restrictions of DBT selection and baudrate depending on clock f_{CAN} have to be obeyed. Refer to the section "*CAN baudrate and time quanta*" above in this chapter.

18.16 Operation of the CAN Controller

The processing procedure for showing in this chapter is recommended processing procedure to operate CAN Controller.

Develop the program referring to recommended processing procedure in this chapter.

18.16.1 Initialization




Figure 18-16 Initialization




Figure 18-17 Re-initialization without Software Reset function

Caution When clearing the error counter in Re-initialization, set FCNnCMCLERCF bit only following conditions:

- After starting the CAN Controller (FCNnGMCLPWOM is set at FCNnGMCLPWOM=0), while in initialization mode.
- After aborting all transmit request according to *Figure 18-27 “Transmission abort processing (except normal operation mode with ABT)” on page 1011* or *Figure 18-28 “Transmission abort processing (normal operation mode with ABT) - Repeat option for aborted message” on page 1012*, while in initialization mode.




Figure 18-18 Re-initialization with Software Reset function




Figure 18-19 Message buffer initialization

- Cautions**
1. Before a message buffer is initialized, FCNnMmCTL.FCNnMmRDYF must be cleared.
 2. Make the following settings for message buffers not used by the application.
 - Clear FCNnMmRDYF, FCNnMmTRQF, and FCNnMmDTNF bits of the FCNnMmCTL register to 0.
 - Clear FCNnMmSTRB.FCNnMmSSAM to 0.

Figure 18-20 “Message buffer redefinition during reception” shows the processing for a receive message buffer (FCNnMmSTRB.FCNnMmSSMT[3:0] = 0001_B to 1000_B).




Figure 18-20 Message buffer redefinition during reception

Figure 18-21 “Message buffer redefinition during transmission” shows the processing for a transmit message buffer during transmission (FCNnMmSTRB.FCNnMmSSMT[3:0] = 0000_B).




Figure 18-21 Message buffer redefinition during transmission

18.16.2 Message transmission

Figure 18-22 "Message transmit processing" shows the processing for a transmit message buffer (FCNnMmSTRB.FCNnMmSSMT[3:0] = 0000_B).




Figure 18-22 Message transmit processing

- Cautions**
1. FCNnMmCTL.FCNnMmTRQF should be set after FCNnMmCTL.FCNnMmRDYF is set.
 2. FCNnMmCTL.FCNnMmRDYF and FCNnMmCTL.FCNnMmTRQF should not be set at the same time.

Figure 18-23 “ABT message transmit processing” shows the processing for a transmit message buffer (FCNnMmSTRB.FCNnMmSSMT[3:0] = 0000_B)




Figure 18-23 ABT message transmit processing

Note This processing (normal operation mode with ABT) can only be applied to message buffers usable with ABT mode. For message buffers other than the ABT message buffers, see Figure 18-22 “Message transmit processing” on page 1005.

Caution FCNnGMABCTL.FCNnGMABSEAT should be set to 1 after FCNnCMCLCTL.FCNnCMCLSSTS is cleared to 0. Checking FCNnCMCLCTL.FCNnCMCLSSTS and setting FCNnGMABCTL.FCNnGMABSEAT = 1 must be processed consecutively.




Figure 18-24 Transmission via interrupt (using FCNnCMLOSTR register)

- Cautions**
1. FCNnMmCTL.FCNnMmTRQF should be set after FCNnMmCTL.FCNnMmRDYF is set.
 2. FCNnMmCTL.FCNnMmRDYF and FCNnMmCTL.FCNnMmTRQF should not be set at the same time.

Note Also check the FCNnGMCLSSMO flag at the beginning and at the end of the interrupt routine, in order to check the access to the message buffers as well as TX history list registers, in case a pending sleep mode had been executed. If FCNnGMCLSSMO is detected to be cleared at any check, the actions and results of the processing have to be discarded and processed again, after FCNnGMCLSSMO is set again. It is recommended to cancel any sleep mode requests, before processing TX interrupts.




Figure 18-25 Transmission via interrupt (using FCNnCMTGTX register)

Cautions 1. FCNnMmCTL.FCNnMmTRQF should be set after

FCNnMmCTL.FCNnMmRDYF is set.

2. FCNnMmCTL.FCNnMmRDYF and FCNnMmCTL.FCNnMmTRQF should not be set at the same time.
-

- Notes**
1. Also check the FCNnGMCLSSMO flag at the beginning and at the end of the interrupt routine, in order to check the access to the message buffers as well as TX history list registers, in case a pending sleep mode had been executed. If FCNnGMCLSSMO is detected to be cleared at any check, the actions and results of the processing have to be discarded and processed again, after FCNnGMCLSSMO is set again.
It is recommended to cancel any sleep mode requests, before processing TX interrupts.
 2. If FCNnCMTGTX.FCNnCMTGTVFF was set once, the transmit history list is inconsistent. Consider to scan all configured transmit buffers for completed transmissions.




Figure 18-26 Transmission via software polling

- Cautions**
1. FCnMmCTL.FCnMmTRQF should be set after FCnMmCTL.FCnMmRDYF is set.
 2. FCnMmCTL.FCnMmRDYF and FCnMmCTL.FCnMmTRQF should not be set at the same time.

- Notes**
1. Also check the FCNnGMCLSSMO flag at the beginning and at the end of the polling routine, in order to check the access to the message buffers as well as TX history list registers, in case a pending sleep mode had been executed. If FCNnGMCLSSMO is detected to be cleared at any check, the actions and results of the processing have to be discarded and processed again, after FCNnGMCLSSMO is set again.
 2. If FCNnCMTGTX.FCNnCMTGTVFF was set once, the transmit history list is inconsistent. Consider to scan all configured transmit buffers for completed transmissions.




Figure 18-27 Transmission abort processing (except normal operation mode with ABT)

Note There is a possibility of starting the transmission without being aborted even if FCNnMmCTL.FCNnMmTRQF is cleared, because the transmission request to protocol layer might already been accepted between 11 bits, total of interframe space (3 bits) and suspend transmission (8 bits).

- Cautions**
1. Clear FCNnMmCTL.FCNnMmTRQF for aborting transmission request, not FCNnMmCTL.FCNnMmRDYF.
 2. Before making a sleep mode transition request, confirm that there is no transmission request left using this processing.
 3. FCNnCMCLCTL.FCNnCMCLSSTS can be periodically checked by a user application or can be checked after the transmit completion interrupt.

- Do not execute any new transmission request including in the other message buffers while transmission abort processing is in progress.




Figure 18-28 Transmission abort processing (normal operation mode with ABT) - Repeat option for aborted message

- Cautions**
- Clear FCNnMmCTL.FCNnMmTRQF for aborting transmission request, not FCNnMmCTL.FCNnMmRDYF.
 - Before making a sleep mode transition request, confirm that there is no transmission request left using this processing.
 - FCNnCMCLCTL.FCNnCMCLSSTS can be periodically checked by a user application or can be checked after the transmit completion interrupt.
 - Do not execute any new transmission request including in the other message buffers while transmission abort processing is in progress.

Figure 18-29 “Transmission abort processing (normal operation mode with ABT) - No repetition option for aborted message” shows the processing to skip resumption of transmitting a message that was stopped when transmission of an ABT message buffer was aborted.




Figure 18-29 Transmission abort processing (normal operation mode with ABT) - No repetition option for aborted message

- Cautions**
1. Do not set any transmission requests while ABT transmission abort processing is in progress.
 2. Make a CAN Controller sleep/stop mode transition request after FCNnGMABCTL.FCNnGMABABTT is cleared (after ABT mode is aborted) following the procedure shown in Figure 18-29 “Transmission abort processing (normal operation mode with ABT) - No repetition option for aborted message” or Figure 18-30 “ABT transmission request abort processing (normal operation mode with ABT)”. When clearing a transmission request in an area other than the ABT area, follow the procedure shown in Figure 18-27 “Transmission abort processing (except normal operation mode with ABT)” on page 1011 .

Figure 18-30 “ABT transmission request abort processing (normal operation mode with ABT)” shows the processing to not skip resumption of transmitting a message that was stopped when transmission of an ABT message buffer was aborted.




Figure 18-30 ABT transmission request abort processing (normal operation mode with ABT)

- Cautions**
1. Do not set any transmission requests while ABT transmission abort processing is in progress.
 2. Make a CAN Controller sleep/stop mode request after FCNnGMABCTL.FCNnGMABABTT is cleared (after ABT mode is stopped) following the procedure shown in Figure 18-29 “Transmission abort processing (normal operation mode with ABT) - No repetition option for aborted message” or Figure 18-30 “ABT transmission request abort processing (normal operation mode with ABT)”. When clearing a transmission request in an area other than the ABT area, follow the procedure shown in Figure 18-27 “Transmission abort processing (except normal operation mode with ABT)” on page 1011 .

Figure 18-31 “ABT transmission request abort processing (normal operation mode with ABT) with transmit abort interrupt flag” shows the processing on ABT mode, when using the Transmit Abort functionality (Transmit Abort Flag). The box “Transmission Abort Success” represents the checking of the transmission abort success by checking the FCNnMmTCPF flag within the ABT message buffers.




Figure 18-31 ABT transmission request abort processing (normal operation mode with ABT) with transmit abort interrupt flag

- Cautions**
1. Do not set any transmission requests while ABT transmission abort processing is in progress.
 2. Issue a CAN sleep mode/CAN stop mode request only, after ABTTRG is cleared (and after ABT mode has stopped) following the procedure shown above. When clearing a transmission request in an area other than the ABT area, follow the procedures shown in flowcharts of aborting transmit requests in operation modes except ABT mode.

Note There is the case that all ABT is transmitted completely even if transmission abort interrupt is occurred. Then it is possible to know which message is finished transmission.

Figure 18-32 “Transmission request abort processing (except normal operation mode with ABT) with transmit abort interrupt and transmission completely finished flag” shows the processing when using the Transmit Abort functionality (Transmit Abort Interrupt).




Figure 18-32 Transmission request abort processing (except normal operation mode with ABT) with transmit abort interrupt and transmission completely finished flag

Note Check FCNnMmCTL.FCNnMmMUCF and FCNnMmCTL.FCNnMmDTNF bits using one read access.

- Cautions**
1. Execute transmission request abort processing by clearing the TRQ bit, not the RDY bit.
 2. Before making a sleep mode transition request, confirm that there is no transmission request left using this processing.
 3. Do not execute another new transmission request in this or the other message buffers, while transmission abort processing is in progress.

4. It is prohibited to clear the transmit request flags of other messages, while transmission abort is in progress.
 5. If a new transmission request is executed for a message buffer within 400 clocks of the CAN Controller, after transmission abort process and before IFS (Inter-Frame Space), that message might be transmitted in the next following transmission, although its ID priority was low.
-

Note Even if the TRQ bit is cleared, there is the possibility that the transmission still starts in the following 11 bits of interframe space (3bit) and suspend transmission (8bit), because the transmission request has already been received by protocol layer.

Figure 18-33 “Transmission request abort processing (except normal operation mode with ABT) with transmission completely finished flag” shows the processing when using the Transmit Abort functionality (Transmission Completely Finished Flag FCNnMmTCPF).




Figure 18-33 Transmission request abort processing (except normal operation mode with ABT) with transmission completely finished flag

- Cautions**
1. Execute transmission request abort processing by clearing the TRQ bit, not the RDY bit.
 2. Before making a sleep mode transition request, confirm that there is no transmission request left using this processing.
 3. Do not execute another new transmission request in this or the other message buffers, while transmission abort processing is in progress.
 4. It is prohibited to clear the transmit request flags of other messages, while transmission abort is in progress.
 5. If a new transmission request is executed for a message buffer within 400 T_{CANCH} of the CAN Controller, after transmission abort process and before IFS (Inter-Frame Space), that message might be transmitted in the next following transmission, although its ID priority was low.

Note Even if the TRQ bit is cleared, there is the possibility that the transmission still starts in the following 11 bits of interframe space (3bit) and suspend transmission (8bit), because the transmission request has already been received by protocol layer.

18.16.3 Message reception




Figure 18-34 Reception via interrupt (using FCNnCMLISTR register)

- Notes**
1. Check FCNnMmCTL.FCNnMmMUCF and FCNnMmCTL.FCNnMmDTNF bits using one read access.
 2. Also check the FCNnGMCLSSMO flag at the beginning and at the end of the interrupt routine, in order to check the access to the message buffers as well as reception history list registers, in case a pending sleep mode had been executed. If FCNnGMCLSSMO is detected to be cleared at any check, the actions and results of the processing have to be discarded and processed again, after FCNnGMCLSSMO is set again. It is recommended to cancel any sleep mode requests, before processing RX interrupts.




Figure 18-35 Reception via interrupt (using FCNnCMRGRX register)

- Notes**
1. Check FCNnMmCTL.FCNnMmMUCF and FCNnMmCTL.FCNnMmDTNF bits using one read access.
 2. Depending of the processing target of the application, two ways are possible:
 - Way A: The message is not processed within this pass, but with the next pass, depending on the timing this can happen latest with the next Receive Interrupt. Other messages will be processed earlier.
 - Way B: The message is processed within this pass, the loop waits on this message. Other messages will be processed later.

3. Also check the FCNnGMCLSSMO flag at the beginning and at the end of the interrupt routine, in order to check the access to the message buffers as well as reception history list registers, in case a pending sleep mode had been executed. If FCNnGMCLSSMO is detected to be cleared at any check, the actions and results of the processing have to be discarded and processed again, after FCNnGMCLSSMO is set again.
It is recommended to cancel any sleep mode requests, before processing RX interrupts.
4. If FCNnCMRGRX.FCNnCMRGRVFF was set once, the receive history list is inconsistent. Consider to scan all configured receive buffers for receptions.




Figure 18-36 Reception via interrupt (using FCNnCMRGRX register), alternative way

- Notes**
1. Also check the FCNnGMCLSSMO flag at the beginning and at the end of the interrupt routine, in order to check the access to the message buffers as well as reception history list registers, in case a pending sleep mode had been executed. If FCNnGMCLSSMO is detected to be cleared at any check, the actions and results of the processing have to be discarded and processed again, after FCNnGMCLSSMO is set again. It is recommended to cancel any sleep mode requests, before processing RX interrupts.
 2. If FCNnCMRGRX.FCNnCMRGRVFF was set once, the receive history list is inconsistent. Consider to scan all configured receive buffers for receptions.
 3. This flow will not provide most recently received data for the application. However, due to less effort on processing, it reduces interrupt load.
 4. The overwrite function (FCNnMmSTRB.FCNnMmSSOW=1) must not be used with this flow - data inconsistency could occur.
 5. It can be used alternatively to *Figure 18-35 "Reception via interrupt (using FCNnCMRGRX register)"* on page 1020 .




Figure 18-37 Reception via software polling

- Notes**
1. Check FCNnMmCTL.FCNnMmMUCF and FCNnMmCTL.FCNnMmDTNF bits using one read access.
 2. Also check the FCNnGMCLSSMO flag at the beginning and at the end of the polling routine, in order to check the access to the message buffers as well as reception history list registers, in case a pending sleep mode had been executed. If FCNnGMCLSSMO is detected to be cleared at any check, the actions and results of the processing have to be discarded and processed again, after FCNnGMCLSSMO is set again.
 3. If FCNnCMRGRX.FCNnCMRGRVFF was set once, the receive history list is inconsistent. Consider to scan all configured receive buffers for receptions.

18.16.4 Power save modes




Figure 18-38 Setting CAN Controller sleep mode/stop mode

Caution To abort transmission before making a request for the CAN Controller sleep mode, perform processing according to previously given flowcharts.




Figure 18-39 Clear CAN Controller sleep/stop mode




Figure 18-40 Bus-off recovery (except normal operation mode with ABT)

Caution When the transmission from the initialization mode to any operation modes is requested to execute bus-off recovery sequence again in the bus-off recovery sequence, reception error counter is cleared. Therefore it is necessary to detect 11 consecutive recessive-level bits 128 times on the bus again.

Note Operation mode: Normal operation mode, normal operation mode with ABT, receive-only mode, singleshot mode, self-test mode.




Figure 18-41 Normal shutdown process




Figure 18-42 Forced shutdown process

Caution Do not read- or write-access any registers by software between setting the FCNnGMCLSEDE bit and clearing the FCNnGMCLPWOM bit.




Figure 18-43 Error handling




Figure 18-44 Setting CPU stand-by (from CAN Controller sleep mode)

- Notes**
1. Before the CPU is set in the CPU standby mode, please check if the CAN Controller sleep mode has been reached. However, after check of the sleep mode, until the CPU is set in the CPU standby mode, the sleep mode may be cancelled by wakeup from CAN bus.
 2. There is a possibility, that between the check of $FCNnGMCLSSMO = 0$ and setting of the CPU standby mode a wake up condition on the CAN bus occurs. In that case the CAN Controller releases the SLEEP mode, the $FCNnCMISITSF5$ bit is set and if enabled the wake up interrupt will be generated.




Figure 18-45 Setting CPU stand-by (from CAN Controller stop mode)

Caution The CAN Controller stop mode can only be released by setting 01_B to FCNnCMCLCTL.FCNnCMCLMDPF[1:0] and not by a change in the CAN Controller bus state.

Chapter 19 Clocked Serial Interface G (CSIG)

This chapter contains a generic description of the Clocked Serial Interface G (CSIG).

The first section describes all V850E2/Fx4-G specific properties, such as instances, register base addresses, input/output signal names, etc. The subsequent sections describe the features that apply to all implementations.

19.1 V850E2/Fx4-G CSIG Features

Instances This microcontroller has following number of instances of the Clocked Serial Interface G.

Table 19-1 Instances of CSIG

Clocked Serial Interface G	V850E2/FF4-G	V850E2/FG4-G
Instance	2	3
Name	CSIG0, CSIG4	CSIG0, CSIG4, CSIG7

Instances index n Throughout this chapter, the individual instances of a Clocked Serial Interface G is identified by the index "n" (n = 0, 4, 7), for example, CSIGnCTL0 for the CSIGn control register 0.

Register addresses All CSIGn register addresses are given as address offsets to the individual base address <CSIGn_base>. The base address <CSIGn_base> of each CSIGn is listed in the following table:

Table 19-2 Register base addresses <CSIGn_base>

CSIGn instance	<CSIGn_base> address
CSIG0	FF70 0000 _H
CSIG4	FF74 0000 _H
CSIG7	FF69 0000 _H

Clock supply All Clocked Serial Interface G provide one clock input:

Table 19-3 CSIGn clock supply

CSIGn instance	CSIGn clock	Connected to
CSIG0	PCLK	Clock Controller CKSCLK_028
CSIG4	PCLK	Clock Controller CKSCLK_011
CSIG7	PCLK	Clock Controller CKSCLK_029




Figure 19-1 CSIG clock supply

Interrupts and DMA The Clocked Serial Interface G can generate the following interrupt and DMA requests:

Table 19-4 CSIGn interrupt and DMA requests

CSIGn signals	Function	Connected to
CSIG0:		
CSIGTIC	Communication status interrupt	Interrupt Controller INTCSIG0IC DMA Controller trigger 35
CSIGTIR	Reception status interrupt	Interrupt Controller INTCSIG0IR DMA Controller trigger 34
CSIGTIRE	Reception error interrupt	Interrupt Controller INTCSIG0IRE
CSIG4:		
CSIGTIC	Communication status interrupt	Interrupt Controller INTCSIG4IC ^a DMA Controller trigger 49
CSIGTIR	Reception status interrupt	Interrupt Controller INTCSIG4IR ^a DMA Controller trigger 48
CSIGTIRE	Reception error interrupt	Interrupt Controller INTCSIG4IRE ^a
CSIG7:		
CSIGTIC	Communication status interrupt	Interrupt Controller INTCSIG7IC DMA Controller trigger 57
CSIGTIR	Reception status interrupt	Interrupt Controller INTCSIG7IR DMA Controller trigger 56
CSIGTIRE	Reception error interrupt	Interrupt Controller INTCSIG7IRE

^{a)} These interrupts can be used as a wake-up source from any stand-by mode. Refer to the chapter “Stand-by Controller (STBC)” for details.

CSIG H/W reset The Clocked Serial Interfaces G and their registers are initialized by the following reset signal:

Table 19-5 CSIGn reset signal

CSIGn	Reset signal
CSIGn	<ul style="list-style-type: none"> Reset Controller SYSRES Stand-by Controller DPSTPWU (wake-up from DEEPSTOP mode)

Internal signals The internal signal connections of the Clocked Serial Interface G are listed in the following table.

Table 19-6 CSIGn internal signal connections

CSIGn signal	Function	Connected to
CSIG0:		
CSIGTSSO	CSIGTSSO output buffer control	Port CSIG0SO output buffer control
CSIG4:		
CSIGTSSO	CSIGTSSO output buffer control	Port CSIG4SO output buffer control
CSIG7:		
CSIGTSSO	CSIGTSSO output buffer control	Port CSIG7SO output buffer control

Handshake function The CSIGn handshake function uses the CSIGn module's handshake signal CSITSHSG, which is connected to the port signals CSIGnRY. If the CSIGn module operates in master mode, CSIGnRY is an input and in slave mode an output signal. The same CSIGnRY can not be used as alternative input and output port function. The following table summarizes the usage options of the different CSIGnRY signals.

Table 19-7 CSIGn handshake signal ports

CSIGn I/O port signal	Port	Alternative function	CSIGnRY usage
CSIG0:			
CSIG0RY	P3_4	ALT_IN4 ALT_OUT4	in CSIG0 master or slave mode
	P4_9	ALT_OUT2	only in CSIG0 slave mode
CSIG4:			
CSIG4RY	P4_10	ALT_IN2	only in CSIG4 master mode
CSIG7:			
CSIG7RY	P1_5	ALT_IN4 ALT_OUT4	in CSIG7 master or slave mode

19.1.1 Data consistency check

The following table shows the CSIGNSO ports and their capability to use them for data consistency checks. Refer to “*Error detection*” in the section “*Functional Description*” below for details about data consistency checks.

Table 19-8 CSIGN data consistency check ports

CSIGN I/O port signal	Port	Alternative function	Data consistency check
CSIG0:			
CSIG0SO	P0_14	ALT_OUT4	possible
	P3_6	ALT_OUT4	possible
	P4_4	ALT_OUT2	not possible
CSIG4:			
CSIG4SO	P0_1	ALT_OUT2	possible
	P4_7	ALT_OUT2	not possible
CSIG7:			
CSIG7SO	P1_3	ALT_OUT4	possible

Port configuration Input/output control of the CSIGNSO port is done by the CSIGN module, thus set PIPCn.PIPCn_m = 1.
All other necessary configuration is done automatically, when the data consistency check is enabled.

19.2 Functional Overview

- Features summary**
- Three-wire serial synchronous data transfer
 - Master mode and slave mode
 - Slave select input signal ($\overline{\text{CSIGTSSI}}$)
 - Built-in baud rate generator
 - Adjustable baud rate; in slave mode it is determined by the input clock
 - Maximum transmission speed:
 - in master mode: PCLK/4
 - in slave mode: PCLK/6
 - Adjustable clock phase and data phase
 - Data transfer with MSB or LSB first
 - Transfer data length selectable from 7 to 16 bits in 1-bit units
 - EDL (Extended Data Length) function for transferring data with more than 16 bits
 - Three selectable transfer modes:
 - transmit-only mode
 - receive-only mode
 - transmit/receive mode
 - Built-in handshake function
 - Separate transmit and receive buffers (two 16-bit registers)
 - Error detection (data consistency check, parity, overrun)
 - Three different interrupt request signals (CSIGTIC, CSIGTIR, CSIGTIRE)
 - Various conditions for interrupt generation
 - LBM (Loop Back Mode) function for self test

The block diagram shows the main components of the CSIG.




Figure 19-2 CSIG block diagram

In master mode, the transmission clock CSIGTSCK is generated by the built-in baud rate generator (BRG). In slave mode, the transmission clock is received from an external source.

19.3 Functional Description

The Clocked Serial Interface G uses three signals for communication:

- Transmission clock CSIGT \overline{SCK} (output in master mode, in slave mode input)
- Data output signal CSIGT \overline{SO}
- Data input signal CSIGT \overline{SI}

If the CSIGn is operated in slave mode, the additional input signal $\overline{CSIGTSSI}$ acts as a chip select signal, that selects the CSIG to take part in data transfers.

Data transmission is bit-wise and serial and synchronous to the transmission clock.

The most important registers for setting up the CSIG are:

Register	Function
CSIGnCTL0	Enables/disables transmission clock, data transmission, and data reception
CSIGnCTL1	Controls options like interrupt timing, extended data length, data consistency check, loop-back mode, handshake, etc.
CSIGnCTL2	Selects master/slave mode and – effective in master mode – the baud rate of the internal generator
CSIGnCFG0	Configures the communication protocol

19.3.1 Master/slave mode

The master or slave mode primarily determines the source of the transmission clock.

(1) Master mode

In master mode, the serial communication clock is generated by the internal baud rate generator (BRG) and provided by signal CSIGT \overline{SCK} .

Master mode is enabled by setting CSIGnCTL2.CSIGnPRS[2:0] to anything but 111_B. In master mode, the frequency setting of the BRG becomes effective.

The initial level of CSIGT \overline{SCK} depends on the clock phase selection bit: it is high when CSIGnCTL1.CSIGnCKR = 0, and is low when CSIGnCTL1.CSIGnCKR = 1.

The example below shows the communication in master mode for 8 data bits, CSIGnCTL1.CSIGnCKR = 0, CSIGnCFG0.CSIGnDAP = 0, and MSB first:




Figure 19-3 Transmit/receive in master mode

(2) Slave mode

In slave mode, another device is the communication master. The external clock is received by signal CSIGTSCK. Send/receive operation starts as soon as a clock signal is detected.

Slave mode is selected by setting CSIGnCTL2.CSIGnPRS[2:0] to 111_B.

Note When using slave mode, disable the baud rate generator (BRG) by clearing bits CSIGnCTL2.CSIGnBRS[11:0]. When the BRG is disabled, CSIGTSCK stays on the level specified by CSIGnCTL1.CSIGnCKR.

The example below shows the communication in slave mode for 8 data bits, CSIGnCTL1.CSIGnCKR = 0, CSIGnCFG0.CSIGnDAP = 0, and MSB first:




Figure 19-4 Transmit/receive in slave mode

19.3.2 Master/slave connections

(1) One master and one slave

The following figure illustrates the connections between one master and one slave.




Figure 19-5 Simple master/slave connection

(2) One master and multiple slaves

The following figure illustrates the connections between one master and multiple slaves. In this case, the master must provide one slave select (SS) signal to each of the slaves. This signal is connected to the slave select input $\overline{\text{CSIGTSSI}}$ of the slave.

The recognition of the $\overline{\text{CSIGTSSI}}$ signal can be enabled/disabled by bit CSIGNCTL1.CSIGNSSE.




Figure 19-6 Master to multiple slaves connection

A slave is selected (enabled) when its $\overline{\text{CSIGTSSI}}$ signal is low.

If it is not selected, the slave will neither receive nor transmit data. In addition, the CSIGTSO output buffer is disabled order to avoid interference with the output of another slave which was selected.

CSIGTSO buffer control

The CSIG provides the signal CSIGTSSO to control the port output buffer of the serial output signal CSIGTSO. By use of this signal the CSIGTSO output buffer can be disabled under following conditions:

- The CSIG is enabled (CSIGNCTL0.CSIGNPWR = 1)
- The CSIG is operated in transmit-only or transmit/receive mode (CSIGNCTL0.CSIGNTXE = 1)
- The CSIG is operated with slave select enabled (CSIGNCTL1.CSIGNSSE = 1).
- The slave mode selection signal $\overline{\text{CSIGTSSI}}$ is inactive, i.e. on high level.

By this signal congestions on the external CSIGTSO signal line are avoided.

19.3.3 Transmission clock selection

In master mode, the transmission baud rate is selectable using the CSIGNPRRS[2:0] and CSIGNBRS[11:0] bits in the CSIGNCTL2 register. The baud rate generator (BRG) counts up at every rising edge of PCLK.

The following figure shows a block diagram of the BRG.




Figure 19-7 BRG block diagram

Clearing CSIGNCTL2.CSIGNBRS[11:0] disables the BRG.

Baud rate calculation

The baud rate is calculated as: $PCLK / (2^m \times k \times 2)$, where

$$m = CSIGNCTL2.CSIGNPRRS[2:0] = 0 \text{ to } 6$$

$$k = CSIGNCTL2.CSIGNBRS[11:0] = 1 \text{ to } 4095$$

Baud rate limits

When setting the baud rate, please note:

- Maximum acceptable baud rate in master mode is $PCLK / 4$.
- Maximum acceptable baud rate in slave mode is $PCLK / 6$ and must be ensured by the external master.
- Minimum baud rate in both modes is $PCLK / 524160$.

19.3.4 Data transfer modes

(1) Transmit-only mode

Setting CSIGNCTL0.CSIGNTXE = 1 and CSIGNCTL0.CSIGNRXE = 0 puts the CSIG in transmit-only mode. Transmission starts when transmit data is written in the CSIGNTX0W or CSIGNTX0H register.

Caution In case transmit-only mode has been entered after any reception mode, the data in the CSIGNRX0 buffer becomes undefined after completion of the first transmission.
Consequently the reception register CSIDnRX0 has to be read before changing to transmit-only mode.

(2) Receive-only mode

Setting CSIGNCTL0.CSIGNTXE = 0 and CSIGNCTL0.CSIGNRXE = 1 puts the CSIG in receive-only mode.

In master mode, reception starts when dummy data is written to the CSIGNTX0W or CSIGNTX0H register.

All following receptions are triggered by a read from the receive data register CSIGNRX0, as long as CSIGNBCTL0.CSIGNSCE = 1.

In slave mode, reception starts when the communication clock CSIGTSCK from the master is received. In this case, it is not necessary to write data to the CSIGNTX0W or CSIGNTX0H register of the slave.

Note In receive-only mode, any previously received data must be read from the reception register CSIGNRX0 in order to avoid any overwrite situation.
Moreover the communication start bit CSIGNBCTL0.CSIGNSCE has to be set to 1 and has to set back to 0 before reading the last received data from CSIGNRX0.

The recommended procedure is:

1. Set CSIGNBCTL0.CSIGNSCE = 1.
2. Before starting the first receive operation, read CSIGNRX0 (dummy data).
3. Wait for the reception interrupt CSIGTIR.
4. Read CSIGNRX0 (received data).
In case of further data receptions continue at 4. until all data has been received.
Before reading the last received data from CSIGNRX0, set CSIGNBCTL0.CSIGNSCE = 0.

(3) Transmit / receive mode

Setting CSIGNCTL0.CSIGNTXE = 1 and CSIGNCTL0.CSIGNRXE = 1 puts the CSIG in transmit/receive mode.

Data transfer (transmission and reception) starts when transmit data is written to the CSIGNTX0W or CSIGNTX0H register.

19.3.5 Data length selection

(1) Data length selection without extended length

Transmission data length is selectable from 7 to 16 bits using the CSIGNDLS[3:0] bits in the CSIGNCFG0 register. The examples below show the communication with MSB first (CSIGNCFG0.CSIGNDIR = 0):




Figure 19-8 Data length select function

(2) Data length selection with extended data length

If the data to be sent/received exceeds 16 bits, the extended data length (EDL) feature can be used.

The EDL function is enabled by setting bit CSIGNCTL1.CSIGNEDLE to 1.

The EDL function works as follows:

- The data has to be broken into 16-bit blocks plus remainder. For example, a string of 42 bits would be broken into two 16-bit blocks plus 10 bits.
- The remainder defines the “data length” that has to be specified in CSIGNCFG0.CSIGNDLS[3:0].
- CSIGNTX0W.CSIGNEDL must be set to 1. In this case, the data written to CSIGNTX0W is sent as a 16-bit data length regardless of the CSIGNCFG0.CSIGNDLS[3:0] bits.
- The transfer is complete after the data with the specified data length (the remainder with CSIGNTX0W.CSIGNEDL = 0) has been sent.

Example Example for sending 40-bit data, for example the string 123456789A_H:

40 bits are split into 2 × 16 bits plus 8 bits.

- Initialize CSIGnCFG0.CSIGnDLS[3:0] = 8.
- To send the string 123456789A_H with MSB first, write the following sequence to CSIGnTX0W:
 - 2000 1234_H (CSIGnTX0W.CSIGnEDL = 1)
 - 2000 5678_H (CSIGnTX0W.CSIGnEDL = 1)
 - 0000 009A_H (CSIGnTX0W.CSIGnEDL = 0)

The following figure illustrates the timing.




Figure 19-9 EDL timing diagram

- Notes**
1. It is not possible to send two consecutive data with a data length of less than 7 bits.
 2. If parity is enabled, the parity bit is added after the last bit.
 3. To consider the data direction, pay attention to the following example: (example data to be sent 123456_H)
 - CSIGnCFG0.CSIGnDIR = 1: LSB first
 - CSIGnTX0 = 2000 3456_H (EDL bit = 1)
 - CSIGnTX0 = 0000 0012_H (EDL bit = 0)
 - CSIGnCFG0.CSIGnDIR = 0: MSB first
 - CSIGnTX0 = 2000 1234_H (EDL bit = 1)
 - CSIGnTX0 = 0000 0056_H (EDL bit = 0)

19.3.6 Serial data direction select function

The serial data direction is selectable using the CSIGNDIR bit in the CSIGNCFG0 register. The examples below show the communication for 8-bit data (CSIGNCFG0.CSIGNDLS[3:0] = 1000_B):




Figure 19-10 Serial data direction select function - MSB first (CSIGNDIR = 0)




Figure 19-11 Serial data direction select function - LSB first (CSIGNDIR = 1)

19.3.7 Communication in slave mode

The following figure illustrates the communication signals and timings in slave mode.




Figure 19-12 Rx/Tx communication timing in slave mode

1. CSIG is put into slave mode by setting $\text{CSIGnCTL2.CSIGnPRS}[2:0] = 111_{\text{B}}$. $\text{CSIGnCTL1.CSIGnCKR}$ and $\text{CSIGnCFG0.CSIGnDAP}$ are 0.
2. Data length is 8 bits ($\text{CSIGnCFG0.CSIGnDLS}[3:0] = 1000_{\text{B}}$). Data direction is MSB first ($\text{CSIGnCFG0.CSIGnDIR} = 0$).
3. CSIG is set to transmit/receive operation ($\text{CSIGnCTL0.CSIGnTXE} = 1$, $\text{CSIGnCTL0.CSIGnRXE} = 1$). Communication start is enabled.
4. The “transmission in progress” flag $\text{CSIGnSTR0.CSIGnTSF}$ is automatically set when transfer data is written to the transmission register CSIGnTX0H .
5. As long as signal $\overline{\text{CSIGTSSI}}$ is high, transmission/reception is not started, even if an external transmission clock is applied to clock input signal CSIGTSCI . Input at CSIGTSI is ignored.
6. As soon as $\overline{\text{CSIGTSSI}}$ falls to low level, signal CSIGTSSO goes high, indicating that CSIGTSD is enabled and ready for transmission.
7. Now, as soon as the external clock signal appears at CSIGTSCK , the slave transmits data to CSIGTSD and simultaneously captures data from CSIGTSI .
8. Interrupt CSIGTIR indicates when the reception is complete. The register CSIGnRX0 can be read.

19.3.8 CSIG interrupts

CSIG can generate the following interrupts:

- CSIGTIC
- CSIGTIR
- CSIGTIRE

Interrupt delay In master mode, all interrupts generated by the master can be delayed by one half period of the transmission clock CSIGTSCK. This is not possible in slave mode.

The delay is specified by setting bit CSIGNCTL1.CSIGNSIT = 1.

The following example illustrates the interrupt delay function, assuming a setting of CSIGNCTL1.CSIGNSIT = 1 (interrupt delay enabled), CSIGNCTL1.CSIGNCKR = 0, CSIGNCFG0.CSIGNDAP = 0 (normal clock and data phase), and CSIGNCFG0.CSIGNDLS[3:0] = 1000_B (data length 8 bits).




Figure 19-13 Interrupt delay function (CSIGNCTL1.CSIGNSIT = 1)

(1) CSIGTIC communication interrupt

This interrupt is normally generated after every data transfer. It can be used to trigger a DMA for writing new transmission data to register CSIGNTX0W or CSIGNTX0H.

The following example assumes master mode and a setting of CSIGNCTL1.CSIGNSIT = 0 (no interrupt delay), CSIGNCTL1.CSIGNCKR = 0, CSIGNCFG0.CSIGNDAP = 0 (normal clock and data phase), CSIGNCFG0.CSIGNDLS[3:0] = 1000_B (data length 8 bits), and CSIGNCTL1.CSIGNSLIT = 0 (normal interrupt timing).




Figure 19-14 Generation of CSIGTIC after communication (CSIGNCTL1.CSIGNSLIT = 0)

However, CSIGTIC can also be set up to occur when the CSIGNTX0 register is free for the next data. This is specified by setting CSIGNCTL1.CSIGNSLIT = 1.

This mode allows more efficient data transfers.

The effect is illustrated in the figure below.




Figure 19-15 Generation of CSIGTIC at the beginning of communication

(2) CSIGTIR reception interrupt

This interrupt is generated in receive-only and transmit/receive mode after data has been received and is available in the reception register. It can be used to trigger a DMA for reading the received data from register CSIGNRX0.

The following example assumes master mode and a setting of CSIGNCTL1.CSIGNSLIT = 0 (no interrupt delay), CSIGNCTL1.CSIGNCKR = 0, CSIGNCFG0.CSIGNDAP = 0 (normal clock and data phase), and CSIGNCFG0.CSIGNDLS[3:0] = 1000_B (data length 8 bits).




Figure 19-16 Generation of CSIGTIR

(3) CSIGTIRE reception error interrupt

This interrupt is generated whenever an error is detected.

Table 19-9 Data error types

Error type	Communication status after error interrupt
Parity error	Interrupt is generated and communication continues
Data consistency error	Interrupt is generated and communication continues
Overrun error	Interrupt is generated and communication is stopped

The type of error that caused the generation of CSIGTIRE is indicated in register CSIGNSTR0.

For details about the various error types refer to 19.3.11 “Error detection” on page 1053.

19.3.9 Handshake function


CSIG features a handshake function to synchronize the master and the slave devices. This function can be enabled/disabled by bit CSIGNCTL1.CSIGNHSE. For handshake, the signal CSIGTSHSG is used.

The timing depends on the data phase selection bit CSIGNCFG0.CSIGNDAP.

(1) Slave mode

When CSIGNCTL1.CSIGNHSE = 1, the slave outputs CSITSHSG = 0 when it is busy. This happens when previous receive data is still in the CSIGNRX0 register, and new data cannot be copied from the shift register to CSIGNRX0 (CSIGNRX0 full condition).

The following examples assume a data length of 8 bits.

**Figure 19-17 Ready/busy signal from slave (CSIGNCFG0.CSIGNDAP = 0)**

As long as the slave is busy, the master has to wait (i.e. suspend the transmission clock). The slave sets CSIGTSHSG to high (“ready”) as soon as the reception register CSIGNRX0 has been read.




Figure 19-18 Ready/busy signal from slave (CSIGnCFG0.CSIGnDAP = 1)

(2) Master mode

When the master detects CSIGTSHSG = 0, the following transfer is put on hold, and the master goes into wait status. It suspends the clock at CSIGTSCK.

The CSIGTSHSG level is checked at each half clock cycle of CSIGTSCK.




Figure 19-19 Master's reaction to CSIGTSHSG (CSIGnCFG0.CSIGnDAP = 0)

If the CSIGTSHSG low signal comes from the slave while data transfer is in progress, the serial clock is suspended after the transfer is complete.

The master resumes the communication as soon as CSIGTSHSG becomes high (slave is "ready").




Figure 19-20 Master's reaction to CSIGTSHSG (CSIGNCFG0.CSIGNDAP = 1)

Caution If multiple slaves are connected, the master must only detect the CSIGTSHSG signal of the slave it has selected for communication.

CSIGTSHSG must be pulled down by the external slave before the next transfer starts. Even if the signal is pulled down by the slave during the transfer, the transfer will be finished.

19.3.10 Loop-back mode

Loop-back mode is a special mode for self-test. This feature is only available in master mode.

When this mode is active, the transmit and receive signals are internally connected, as shown in the figures below. The signals CSIGTSCK, CSIGTSO, and CSIGTSI are disconnected from the ports. In addition, the CSIGTSO output level is fixed to low, and CSIGTSCK is set to the inactive state, as defined by CSIGNCTL1.CSIGNCKR. The rest of CSIG works as in normal operation.

In order to test the CSIG, enable loop-back mode and carry out normal transfer operations. Then check that the received data is the same as the transmitted data.




Figure 19-21 Normal operation




Figure 19-22 Operation in loop-back mode

19.3.11 Error detection

CSIG can detect three error types:

- Data consistency error (transmission data)
- Parity error (received data)
- Overrun error

Error check can be individually enabled/disabled for each type.

If one of these errors is detected, the interrupt CSIGTIRE is generated.

(1) Data consistency check

The purpose of the data consistency check is to ensure that the data physically sent to the output pin is identical to the original data that was copied to the shift register.

The data consistency check can be enabled/disabled by bit CSIGnCTL1.CSIGnDCS. It is not active if data transmission is disabled (CSIGnCTL0.CSIGnTXE = 0).

When the data consistency check is active, the data transferred from CSIGnTX0 to the shift register is copied to a separate register. In addition, the physical levels at CSIGTSO is read back via the CSIGTDCS signal into an own shift register.

After completion of the transmission, the data sent is compared with the original transmission data.

Mismatch is considered as a data consistency error:

- Interrupt CSIGTIRE is generated.
- Bit CSIGnSTR0.CSIGnDCE is set.

The function is illustrated in the following block diagram.




Figure 19-23 Functional block diagram of the data consistency check

(2) Parity check

Parity is a common mean to detect a single bit failure during data transmission. CSIG can append a parity bit to the last data bit (even if extended data length is used).

The use and type of parity is specified in CSIGNCFG0.CSIGNPS[1:0].

Parity check is enabled if CSIGNCFG0.CSIGNPS[1] = 1.

The parity bit is checked after reception is complete. If a parity error occurs:

- Interrupt CSIGTIRE is generated
- Bit CSIGNSTR0.CSIGNPE is set

The following figure shows an example.

Data length is 8 bits. The data transmitted is 05_H and 35_H. Parity type is odd.




Figure 19-24 Parity check example

For the first 8 bits, the parity bit is 1. There is no parity error, because the total number of ones (including the parity bit) is odd.

For the second 8 bits, the parity bit is 0. This is detected as a parity error, because the total number of ones (including the parity bit) is even.

(3) Overrun error

This error occurs when previously received data still resides in the reception register CSIGNRX0, because it wasn't read, and new data is received.

The overrun error is not generated if data reception is disabled (CSIGNCTL0.CSIGNRXE = 0).

If overrun occurs:

- Interrupt CSIGTIRE is generated
- Bit CSIGNSTR0.CSIGNOVE is set
- Communication is stopped

The following figure illustrates the function.




Figure 19-25 Overrun error detection

The following figure illustrates an example where:

- Rx data 3 was not read
- Rx data 4 was received, but cannot be stored

Thus an overrun error occurs.




Figure 19-26 Overrun error detection - example

- Notes**
1. An Rx data overrun error can be avoided in slave mode by using the handshake.
When handshake is used in slave mode, the receiver (slave) signals to the transmitter (master) that it is busy. The transmitter then waits until the receiver has read its reception register and is ready again.
For details see 19.3.9 "Handshake function" on page 1049 .
 2. In master mode no overrun error can occur, since the data clock CSIGTCK is stopped, until the data in the CSIGNRX0 register is read.

19.4 CSIG Control Registers

The CSIGn is controlled and operated by means of the following registers:

Table 19-10 CSIGn register overview

Register name	Shortcut	Address
Control register 0	CSIGnCTL0	<CSIGn_base>
Control register 1	CSIGnCTL1	<CSIGn_base> + 10 _H
Control register 2	CSIGnCTL2	<CSIGn_base> + 14 _H
Status register 0	CSIGnSTR0	<CSIGn_base> + 04 _H
Status clear register 0	CSIGnSTCR0	<CSIGn_base> + 08 _H
Rx-only mode control register 0	CSIGnBCTL0	<CSIGn_base> + 1000 _H
Configuration register 0	CSIGnCFG0	<CSIGn_base> + 1010 _H
Transmit data register 0 for word access	CSIGnTX0W	<CSIGn_base> + 1004 _H
Transmit data register 0 for half word access	CSIGnTX0H	<CSIGn_base> + 1008 _H
Receive data register 0	CSIGnRX0	<CSIGn_base> + 100C _H
Emulation register	CSIGnEMU	<CSIGn_base> + 0018 _H

<CSIGn_base> The base addresses <CSIGn_base> of the CSIGn is defined in the first section of this chapter under the key word "Register addresses".

(1) CSIGNCTL0 - CSIG control register 0

This register controls the operation clock and enables/disables transmission/reception.

Access This register can be read/written in 8-bit units.

Address <CSIGN_base> + 00_H

Initial Value 00_H

7	6	5	4	3	2	1	0
CSIGN PWR	CSIGN TXE	CSIGN RXE	0	0	0	0	0 ^a
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

a) The default value “0” of bit 0 of CSIGNCTL0 must be changed to “1” before the CSIGN is used.

Caution The default value “0” of bit 0 of CSIGNCTL0 must be changed to “1” before the CSIGN is used.

Table 19-11 CSIGNCTL0 register contents

Bit position	Bit name	Function
7	CSIGNPWR	Controls operation clock: 0: Stop operation clock 1: Provide operation clock Clearing CSIGNPWR to 0 resets the internal circuits, stops operation, and sets the CSIG to standby state. No clock is provided to internal circuits. If CSIGNPWR is cleared during communication, ongoing communication is aborted. A restart of the communication is then required.
6	CSIGNTXE	Enables/disables transmission: 0: Transmission disabled 1: Transmission enabled
5	CSIGNRXE	Enables/disables reception: 0: Receive disabled 1: Receive enabled
0	Bit 0	Caution The default value “0” of this must be changed to “1” before the CSIGN is used.

- Cautions**
1. Do not modify CSIGNRXE or CSIGNTXE while CSIGNPWR = 0. However both bits can be modified in the same write operation when setting CSIGNPWR = 1.
 2. Do not modify CSIGNRXE or CSIGNTXE while a data transmission is pending or ongoing, i.e. if CSIGNSTR0.CSIGNTSF = 1.

(2) CSIGNCTL1 - CSIG control register 1

This register specifies the interrupt timing and the interrupt delay mode. It enables/disables extended data length control, data consistency check, loop-back mode, handshake function, and slave select function.

Access This register can be read/written in 32-bit units.

Address <CSIGN_base> + 10_H

Initial Value 0000 0000H

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0	0	0	0	0	0	0	CSIGNCKR	CSIGNSLIT
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	CSIGNEDLE	0	CSIGNDCS	0	CSIGNLBM	CSIGNSIT	CSIGNHSE	CSIGNSSE
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Caution Changing the contents of this register is only permitted when CSIGNCTL0.CSIGNPWR = 0.

Table 19-12 CSIGNCTL1 register contents (1/2)

Bit position	Bit name	Function
17	CSIGNCKR	Selects the initial level of the data clock CSIGTSCK 0: Initial level of CSIGTSCK is high 1: Initial level of CSIGTSCK is low For the relation between CSIGTSCK, CSIGTSO and the sample point, refer to the description of the CSIGNCFG0.CSIGNDAP bit.
16	CSIGNSLIT	Selects the timing of interrupt CSIGTIC: 0: Normal interrupt timing (interrupt is generated after the transfer) 1: Interrupt generation when CSIGNTX0 is free for next data. For details refer to 1 "CSIGTIC communication interrupt" on page 1047.
7	CSIGNEDLE	Enables/disables extended data length (EDL) mode: 0: Extended data length mode disabled 1: Extended data length mode enabled For details refer to 2 "Data length selection with extended data length" on page 1043.
5	CSIGNDCS	Enables/disables data consistency check: 0: Data consistency check disabled 1: Data consistency check enabled For details refer to 1 "Data consistency check" on page 1053.
3	CSIGNLBM	Controls loop-back mode (LBM): 0: Loop-back mode deactivated 1: Loop-back mode activated For details refer to 19.3.10 "Loop-back mode" on page 1052.

Table 19-12 CSIGNCTL1 register contents (2/2)

Bit position	Bit name	Function
2	CSIGNSIT	Selects interrupt delay mode: 0: No delay 1: Half clock delay for all interrupts This bit is only valid in master mode. In slave mode, no delay is generated. For details refer to 19.3.8 "CSIG interrupts" on page 1047.
1	CSIGNHSE	Enables/disables handshake mode: 0: Handshake function disabled 1: Handshake function enabled For details refer to 19.3.9 "Handshake function" on page 1049.
0	CSIGNSSE	Enables/disables slave select function: 0: Input signal $\overline{\text{CSIGTSSI}}$ is ignored 1: Input signal $\overline{\text{CSIGTSSI}}$ is enabled If the slave select function is not used, this bit must be set to 0 (see also 19.3.2 "Master/slave connections" on page 1039).

Details about CSIGNCTL1.CSIGNSSE:

Table 19-13 Operation of the slave select function during reception

CSIGNCTL0. CSIGNRXE	CSIGNCTL1. CSIGNSSE	$\overline{\text{CSIGTSSI}}$	Receive operation
0	-	-	Reception disabled
1	0	-	Possible
1	1	0	Possible
1	1	1	Impossible

Table 19-14 Operation of the slave select function during transmission

CSIGNCTL0. CSIGNTXE	CSIGNCTL1. CSIGNSSE	$\overline{\text{CSIGTSSI}}$	Transmit operation
0	-	-	Transmission disabled
1	0	-	Possible
1	1	0	Possible
1	1	1	Impossible

(3) CSIGNCTL2 - CSIG control register 2

This register selects the communication clock.

Access This register can be read/written in 16-bit units.

Address <CSIGN_base> + 14_H

Initial Value E000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CSIGN PRS[2:0]			0	CSIGN BRS[11:0]											
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Caution Changing the contents of this register is only permitted when CSIGNCTL0.CSIGNPWR = 0.

Table 19-15 CSIGNCTL2 register contents

Bit position	Bit name	Function																																				
15 to 13	CSIGNPRS [2:0]	Selects the value m of the prescaler: <table border="1" data-bbox="549 972 1385 1388"> <thead> <tr> <th>CSIGN PRS2</th><th>CSIGN PRS1</th><th>CSIGN PRS0</th><th>Prescaler output (PRSOUT)</th></tr> </thead> <tbody> <tr><td>0</td><td>0</td><td>0</td><td>PCLK (master mode)</td></tr> <tr><td>0</td><td>0</td><td>1</td><td>PCLK / 2 (master mode)</td></tr> <tr><td>0</td><td>1</td><td>0</td><td>PCLK / 4 (master mode)</td></tr> <tr><td>0</td><td>1</td><td>1</td><td>PCLK / 8 (master mode)</td></tr> <tr><td>1</td><td>0</td><td>0</td><td>PCLK / 16 (master mode)</td></tr> <tr><td>1</td><td>0</td><td>1</td><td>PCLK / 32 (master mode)</td></tr> <tr><td>1</td><td>1</td><td>0</td><td>PCLK / 64 (master mode)</td></tr> <tr><td>1</td><td>1</td><td>1</td><td>External clock via CSIGTSCI (slave mode)</td></tr> </tbody> </table>	CSIGN PRS2	CSIGN PRS1	CSIGN PRS0	Prescaler output (PRSOUT)	0	0	0	PCLK (master mode)	0	0	1	PCLK / 2 (master mode)	0	1	0	PCLK / 4 (master mode)	0	1	1	PCLK / 8 (master mode)	1	0	0	PCLK / 16 (master mode)	1	0	1	PCLK / 32 (master mode)	1	1	0	PCLK / 64 (master mode)	1	1	1	External clock via CSIGTSCI (slave mode)
CSIGN PRS2	CSIGN PRS1	CSIGN PRS0	Prescaler output (PRSOUT)																																			
0	0	0	PCLK (master mode)																																			
0	0	1	PCLK / 2 (master mode)																																			
0	1	0	PCLK / 4 (master mode)																																			
0	1	1	PCLK / 8 (master mode)																																			
1	0	0	PCLK / 16 (master mode)																																			
1	0	1	PCLK / 32 (master mode)																																			
1	1	0	PCLK / 64 (master mode)																																			
1	1	1	External clock via CSIGTSCI (slave mode)																																			
11 to 0	CSIGNBRS [11:0]	Selects the baud rate (m = CSIGNPRS[2:0]): <table border="1" data-bbox="549 1469 1385 1814"> <thead> <tr> <th>CSIGNBRS[11:0]</th><th>Baud rate at CSIGTSCK</th></tr> </thead> <tbody> <tr><td>0</td><td>BRG is stopped</td></tr> <tr><td>1</td><td>PCLK / (2^m × 1 × 2)</td></tr> <tr><td>2</td><td>PCLK / (2^m × 2 × 2)</td></tr> <tr><td>3</td><td>PCLK / (2^m × 3 × 2)</td></tr> <tr><td>4</td><td>PCLK / (2^m × 4 × 2)</td></tr> <tr><td>...</td><td>...</td></tr> <tr><td>4095</td><td>PCLK / (2^m × 4095 × 2)</td></tr> </tbody> </table>	CSIGNBRS[11:0]	Baud rate at CSIGTSCK	0	BRG is stopped	1	PCLK / (2 ^m × 1 × 2)	2	PCLK / (2 ^m × 2 × 2)	3	PCLK / (2 ^m × 3 × 2)	4	PCLK / (2 ^m × 4 × 2)	4095	PCLK / (2 ^m × 4095 × 2)																				
CSIGNBRS[11:0]	Baud rate at CSIGTSCK																																					
0	BRG is stopped																																					
1	PCLK / (2 ^m × 1 × 2)																																					
2	PCLK / (2 ^m × 2 × 2)																																					
3	PCLK / (2 ^m × 3 × 2)																																					
4	PCLK / (2 ^m × 4 × 2)																																					
...	...																																					
4095	PCLK / (2 ^m × 4095 × 2)																																					

(4) CSIGNSTR0 - CSIG status register 0

This register indicates the status of the CSIG.

Access This register can be read in 32-bit units.

Address <CSIGN_base> + 04_H

Initial Value 0000 0010_H

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	CSIGN TSF	0	0	1	CSIGN DCE	0	CSIGN PE	CSIGN OVE
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Table 19-16 CSIGNSTR0 register contents

Bit position	Bit name	Function																					
7	CSIGNTSF	Transfer status flag: 0: Idle state 1: Transmission is in progress or being prepared Setting and clearing of this bit is as follows: <table border="1" style="margin: 10px 0;"> <thead> <tr> <th>Master mode</th><th>Set by</th><th>Cleared by</th></tr> </thead> <tbody> <tr> <td>Tx only mode</td><td rowspan="3">Writing to transmit register</td><td>Rising edge of CSIGTIC</td></tr> <tr> <td>Tx / Rx mode</td><td>Rising edge of CSIGTIR</td></tr> <tr> <td>Rx only mode</td><td></td></tr> </tbody> </table> <table border="1" style="margin: 10px 0;"> <thead> <tr> <th>Slave mode</th><th>Set by</th><th>Cleared by</th></tr> </thead> <tbody> <tr> <td>Tx only mode</td><td rowspan="2">Writing to transmit register</td><td>Rising edge of CSIGTIC</td></tr> <tr> <td>Tx / Rx mode</td><td>Rising edge of CSIGTIR</td></tr> <tr> <td>Rx only mode</td><td>CSIGTSCK</td><td></td></tr> </tbody> </table>	Master mode	Set by	Cleared by	Tx only mode	Writing to transmit register	Rising edge of CSIGTIC	Tx / Rx mode	Rising edge of CSIGTIR	Rx only mode		Slave mode	Set by	Cleared by	Tx only mode	Writing to transmit register	Rising edge of CSIGTIC	Tx / Rx mode	Rising edge of CSIGTIR	Rx only mode	CSIGTSCK	
Master mode	Set by	Cleared by																					
Tx only mode	Writing to transmit register	Rising edge of CSIGTIC																					
Tx / Rx mode		Rising edge of CSIGTIR																					
Rx only mode																							
Slave mode	Set by	Cleared by																					
Tx only mode	Writing to transmit register	Rising edge of CSIGTIC																					
Tx / Rx mode		Rising edge of CSIGTIR																					
Rx only mode	CSIGTSCK																						
3	CSIGNDCE	Data consistency check error flag: 0: No data consistency error detected 1: Data consistency error detected This bit is cleared by writing 1 to CSIGNSTCR0.CSIGNDCEC. This bit is initialized when CSIGNCTL0.CSIGNPWR changes from 0 to 1 or from 1 to 0.																					
1	CSIGNPE	Parity error flag: 0: No parity error detected 1: Parity error detected This bit is cleared by writing 1 to CSIGNSTCR0.CSIGNPEC. This bit is initialized when CSIGNCTL0.CSIGNPWR changes from 0 to 1 or from 1 to 0.																					
0	CSIGNOVE	Overrun error flag: 0: No overrun error detected 1: Overrun error detected This bit is cleared by writing 1 to CSIGNSTCR0.CSIGNOVEC. This bit is initialized when CSIGNCTL0.CSIGNPWR changes from 0 to 1 or from 1 to 0.																					

(5) CSIGNSTCR0 - CSIG status clear register 0

This register clears the status flags of the CSIGNSTR0 status register.

Access This register can be read/written in 16-bit units.

Address <CSIGN_base> + 08_H

Initial Value Reading this register returns always 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	0	0	0	0	CSIGN DCEC	0	CSIGN PEC	CSIGN OVEC
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 19-17 CSIGNSTCR0 register contents

Bit position	Bit name	Function
3	CSIGNDCEC	0: No operation. Read value is always 0. 1: Clear data consistency error flag (CSIGNSTR0.CSIGNDCE)
1	CSIGNPEC	0: No operation. Read value is always 0. 1: Clear parity error flag (CSIGNSTR0.CSIGNPE)
0	CSIGNOVEC	0: No operation. Read value is always 0. 1: Clear overrun error flag (CSIGNSTR0.CSIGNOVE)

(6) CSIGNBCTL0 - CSIG Rx-only mode control register 0

This register enables/disables the data transfer in Rx-only mode.

Access This register can be read/written in 8-bit units.

Address <CSIGN_base> + 1000_H

Initial Value 01_H

7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	CSIGNSCE
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 19-18 CSIGNBCTL0 register contents

Bit position	Bit name	Function
0	CSIGNSCE	Disables/enables next data reception start by reading CSIGNRX0: 0: Next reception disabled 1: Next reception enabled For details refer to 2 "Receive-only mode" on page 1042 and 19.3.7 "Communication in slave mode" on page 1046 .

Caution CSIGNSCE must be set to 0 if transmit mode is enabled (CSIGNCTL0.CSIGNTXE = 1).

(7) CSIGNCFG0 - CSIG configuration register 0

This register configures the communication protocol – data length, parity, transfer direction, clock phase, and data phase.

Access This register can be read/written in 32-bit units.

Address <CSIGN_base> + 1010_H

Initial Value 0000 0000_H

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	CSIGN PS[1:0]		CSIGN DLS[3:0]				0	0	0	0	0	CSIGN DIR	0	CSIGN DAP
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Caution Changing the contents of this register is only permitted when CSIGNCTL0.CSIGNPWR = 0.

Table 19-19 CSIGNCFG0 register contents (1/2)

Bit position	Bit name	Function																				
29 to 28	CSIGNPS [1:0]	Specifies parity: <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>CSIGN PS1</th><th>CSIGN PS0</th><th>Transmission</th><th>Reception</th></tr> </thead> <tbody> <tr> <td>0</td><td>0</td><td>No parity transmitted</td><td>No parity expected</td></tr> <tr> <td>0</td><td>1</td><td>Add parity bit fixed at 0</td><td>Parity bit is expected but not judged</td></tr> <tr> <td>1</td><td>0</td><td>Add odd parity</td><td>Odd parity bit is expected</td></tr> <tr> <td>1</td><td>1</td><td>Add even parity</td><td>Even parity bit is expected</td></tr> </tbody> </table>	CSIGN PS1	CSIGN PS0	Transmission	Reception	0	0	No parity transmitted	No parity expected	0	1	Add parity bit fixed at 0	Parity bit is expected but not judged	1	0	Add odd parity	Odd parity bit is expected	1	1	Add even parity	Even parity bit is expected
CSIGN PS1	CSIGN PS0	Transmission	Reception																			
0	0	No parity transmitted	No parity expected																			
0	1	Add parity bit fixed at 0	Parity bit is expected but not judged																			
1	0	Add odd parity	Odd parity bit is expected																			
1	1	Add even parity	Even parity bit is expected																			
27 to 24	CSIGNDLS [3:0]	Specifies data length: 0: Data length is 16 bits 1: Data length is 1 bit 2: Data length is 2 bits ... 15: Data length is 15 bits Caution Data lengths of less than 7 bits is only allowed in combination with the extended data length function. It is forbidden to transmit two consecutive data with a data length of less than 7 bits.																				
18	CSIGNDIR	Selects the serial data direction: 0: Data is sent/received with MSB first 1: Data is sent/received with LSB first																				

Table 19-19 CSIGNCFG0 register contents (2/2)

Bit position	Bit name	Function															
16	CSIGNDAP	<p>Data phase selection bit</p> <p>The control bits CSIGNDAP and CSIGNCTL1.CSIGNCKR determine the CSIGTSCK clock edge</p> <ul style="list-style-type: none"> to shift serial data out via CSIGTSO to sample serial input data at CSIGTSI. <p>The following diagram shows the relation between CSIGTSCK, CSIGTSO and the sample point of CSIGTSI, depending on CSIGNCTL1.CSIGNCKR and CSIGNDAP:</p> <table border="1"> <thead> <tr> <th>CSIGNCKR</th> <th>CSIGNDAP</th> <th>Clock and data phase selection</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td> </td> </tr> <tr> <td>0</td> <td>1</td> <td> </td> </tr> <tr> <td>1</td> <td>0</td> <td> </td> </tr> <tr> <td>1</td> <td>1</td> <td> </td> </tr> </tbody> </table>	CSIGNCKR	CSIGNDAP	Clock and data phase selection	0	0		0	1		1	0		1	1	
CSIGNCKR	CSIGNDAP	Clock and data phase selection															
0	0																
0	1																
1	0																
1	1																

(8) CSIGNTX0W - CSIG transmission register 0 for word access

This register stores the transmission data. It has to be used when the extended data length function is enabled (CSIGNCTL1.CSIGNEDLE = 1).

Access This register can be read/written in 32-bit units.

Address <CSIGN_base> + 1004_H

Initial Value 0000 0000_H

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	CSIGN EDL	0	0	0	0	0	0	0	0	0	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CSIGNTX[15:0]															
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 19-20 CSIGNTX0W register contents

Bit position	Bit name	Function
29	CSIGNEDL	Specifies the extended data length configuration: 0: Normal operation 1: Extended data length activated The associated data is transmitted as 16-bit data. This bit can only be set if CSIGNCTL1.CSIGNEDLE = 1. It is automatically cleared if CSIGNCTL1.CSIGNEDLE is cleared.
15 to 0	CSIGN TX[15:0]	Data to be transmitted

(9) CSIGNTX0H - CSIG transmission register 0 for half word access

This register stores the transmission data. It can be used when the Extended Data Length function is disabled (CSIGNCTL1.CSIGNEDLE = 0).

Access This register can be read/written in 16-bit units.

Address <CSIGN_base> + 1008_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CSIGNTX[15:0]															
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 19-21 CSIGNTX0H register contents

Bit position	Bit name	Function
15 to 0	CSIGN TX[15:0]	Data to be transmitted

(10) CSIGNRX0 - CSIG reception register 0

This register stores the received data.

Access This register can be read in 16-bit units.

Address <CSIGN_base> + 100C_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CSIGN RX[15:0]															
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Table 19-22 CSIGNRX0 register contents

Bit position	Bit name	Function
15 to 0	CSIGN RX[15:0]	Received data This register is initialized when CSIGNCTL0.CSIGNPWR changes from 0 to 1 or from 1 to 0.

(11) CSIGNEMU - CSIG emulation register

This register controls whether the CSIGN can be stopped during emulation, for instance upon a breakpoint hit.

Access This register can be read/written in 8-bit units.

Address <CSIGN_base> + 18_H

Initial Value 00_H

	7	6	5	4	3	2	1	0
CSIGN SVSDIS	0	0	0	0	0	0	0	0
	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 19-23 CSIGNEMU register contents

Bit position	Bit name	Function
7	CSIGN SVSDIS	Emulation control 0: CSIGN can be stopped during emulation 1: CSIGN continuous operating during emulation

19.5 Operating Procedure Example

In the following a transmit/receive example in master mode in combination with a DMA is described.

The following instructions are based on the assumption that:

- Transmission data length is 8 bits (CSIGnCFG0.CSIGnDLS[3:0] = 1000_B)
- MSB is transmitted first (CSIGnCFG0.CSIGnDIR = 0)
- CSIGTIC interrupt at the end of the transfer (CSIGnCTL1.CSIGnSLIT = 0)
- Normal clock and data phase (CSIGnCTL1.CSIGnCKR = 0, CSIGnCFG0.CSIGnDAP = 0)
- The number of data packets is 10 (0 to 9)




Figure 19-27 Communication in master mode

Procedure:

1. Configure the communication protocol in register CSIGnCFG0.
2. In the CSIGnCTL0 register, set bits CSIGnPWR = 1 (enable the clock), CSIGnTXE = 1 (enable transmission), CSIGnRXE = 1 (enable reception). The data output CSIGTSO is enabled.
3. Write the first data packet to be sent to the transmission register CSIGnTX0H. Transmission starts automatically when the first data is available.
4. Write the second data to CSIGnTX0H. Writing the second packet immediately after the first one avoids unnecessary delays between the packets.
5. After every packet that has been transmitted, the interrupts CSIGTIC and CSIGTIR are generated. CSIGTIC indicates that the next packet can be

written to CSIGNTX0H. CSIGTIR indicates that the reception register CSIGNRX0 must be read.

In this example, CPU write and DMA write are equivalent.

6. No more write action is required after completion of packet 8. Packet 9 (the last packet) has been written in advance. However, the reception register CSIGNRX0 must be read after completion of packets 8 and 9.
7. To finally disable the transmit/receive operation, clear CSIGNCTL0.CSIGNTXE and CSIGNCTL0.CSIGNRXE.

Chapter 20 I²C Interface (IICB)

This chapter contains a generic description of the I²C Interface (IICB).

The first section describes all properties specific to the V850E2/Fx4-G, such as instances, register base addresses, input/output signal names, etc.

The subsequent sections describe the features that apply to all implementations.

20.1 V850E2/Fx4-G IICB Features

Instances This microcontroller has following number of instances of the I²C Interface.

Table 20-1 Instances of IICB

I ² C Interface	
Instances	1
Names	IICB0

Instances index n Throughout this chapter, the individual instances of a I²C Interface are identified by the index “n” (n = 0), for example, IICBnCTL0 for the IICBn control register 0.

Register addresses All IICBn register addresses are given as address offsets from the individual base address <IICBn_base>. The base address <IICBn_base> of each IICBn is listed in the following table:

Table 20-2 Register base addresses <IICBn_base>

IICBn instance	<IICBn_base> address
IICB0	FF82 0000 _H

Clock supply All I²C Interfaces provide one clock input:

Table 20-3 IICB clock supply

IICBn instance	Clock	Connected to
IICB0	PCLK	Clock Controller CKSCLK_028




Figure 20-1 IICB clock supply

Interrupts and DMA The I²C Interfaces can generate following interrupt and DMA requests:

Table 20-4 IICB interrupt and DMA requests

IICBn signals	Function	Connected to
IICB0:		
IICBTIA	Data transmission/reception interrupt	Interrupt Controller INTIICB0IA DMA Controller trigger 43

IICB H/W reset The I²C Interfaces and their registers are initialized by the following reset signal:

Table 20-5 IICBn reset signal

IICBn	Reset signal
IICBn	<ul style="list-style-type: none"> Reset Controller SYSRES Stand-by Controller DPSTPWU (wake-up from DEEPSTOP mode)

I/O signals The I/O signals of the I²C Interfaces are listed in the following table:

Table 20-6 IICB I/O signals

IICBn signals	Function	Connected to
IICB0:		
SCL	IICB0 clock signal	Port IICB0SCL
SDA	IICB0 data/address signal	Port IICB0SDA

20.2 I²C Interface Port Settings

The I²C interface function requires to define the ports for the IICBnSCL and IICBnSDA signals as input and open drain output pins simultaneously.

In the following table the port configuration register bits are listed to be set up properly for port m of the port group n, if it shall be used for I²C interface signals IICBnSCL or IICBnSDA.

The bold printed values in grey cells differ from the initial register values after reset release and thus have to be changed.

Table 20-7 I²C Interface port settings

Register	Value to set	Initial value	Function
Port function configuration registers:			
PMCn_m	= 1	0	alternative mode
PIPCn_m	= 0	0	S/W I/O control
PMn_m	= 0	1	output mode
PIBCn_m	= x	0	overruled by PMCn_m = 1
PFCn_m, PFCEn_m	= 1 or 0	0	select correct alternative function
Port data input/output registers:			
PBDCn_m	= 1	0	bi-directional I/O
Configuration of electrical characteristics registers:			
PUn_m	= x	0	no pull-up resistor, overruled by PMn_m = 0
PDn_m	= x	0	no pull-down resistor, overruled by PMn_m = 0
PODCn_m	= 1	0	open drain output
PISn_m, PISEn_m	= 1 or 0	0	input characteristic can be selected based on application signal quality

20.3 Functional Overview

Operating mode	Standard mode (SCL clock frequency: 100 kHz max.) Fast mode (SCL clock frequency: 400 kHz max.)
Transfer mode	Single transfer mode
Pin configuration	SCLn: Serial clock pin SDAn: Serial transmit/receive data pin
Interrupt request signal	Data transmit/receive interrupt request signal (IICBTIA _n)
Communication data length	8 bits
Multimaster support	Multiple masters can control the bus simultaneously.
SCLn level width	The high-level width and low-level width of the serial clock signal (SCLn) can be changed.
Automatic detection	The start and stop conditions can be detected automatically.




Figure 20-2 Block diagram of IICBn

20.4 I²C Bus Mode Functions

20.4.1 Pin configuration

The serial clock pin (SCLn) and serial data bus pin (SDAn) are configured as follows.

SCLn... This pin is used for serial clock input and output.
This pin is an N-ch open-drain output for both master and slave devices. Input is Schmitt input.

SDAn... This pin is used for serial data input and output.
This pin is an N-ch open-drain output for both master and slave devices. Input is Schmitt input.

Because the outputs of the serial clock line and serial data bus line are N-ch open-drain outputs, an external pull-up resistor must be connected to these lines.




Figure 20-3 Pin configuration diagram

20.5 I²C Bus Definition

This section describes the I²C bus's serial data communication format and the signals used by the I²C bus.

Figure 20-4 "I²C bus serial data transfer timing" shows the transfer timing for the "start condition", "address", "transfer direction specification", "data", and "stop condition", which are output onto the I²C bus's serial data bus.




Figure 20-4 I²C bus serial data transfer timing

The start condition, slave address, and stop condition are output by the master device.

$\overline{\text{ACK}}$ can be output by either the master or slave device. (Normally, it is output by the device that receives 8-bit data.)

The serial clock signal (SCLn) is continuously output by the master device. In the slave device, the low-level period of the SCLn signal can be extended to insert a wait.

20.5.1 Start Condition

The start condition is met if the SDA_n signal level changes from high to low while the SCL_n signal is high. The start condition is output when the master device starts serial data transfer to a slave device. When the IICB_n is in the slave mode, it detects the start condition.




Figure 20-5 Start condition

20.5.2 Addresses

The 7 bits of data following the start condition are defined as an address.

An address is a 7-bit data segment that is output in order to select one of the slave devices that are connected to the master device via the bus lines. Therefore, each slave device connected via the bus lines must have a unique address.

The slave device checks whether the 7-bit data matches its own address. If they match, that slave device is selected as the communication destination and communicates with the master device until the master device outputs another start condition or a stop condition.




Figure 20-6 Addresses

20.5.3 Extension code

When the higher 4 bits of the address are 0000 or 1111, these bits are called extension code. Table 20-8 "Extension code bit definitions" lists the bit definitions of extension code.

Table 20-8 Extension code bit definitions

Slave address	R/W bit	Description
0000 000	0	General call address
0000 000	1	Start byte
0000 001	x	CBUS address
0000 010	x	Address reserved for different bus format
0000 011	x	Reserved for future use
0000 1xx	x	HS mode master code ^a
1111 0xx	x	10-bit slave address specification
1111 1xx	x	Reserved for future use

a) The HS mode cannot be used with this IICB module.

20.5.4 Transfer direction specification

After the 7-bit address data, the master device transmits 1 bit that specifies the transfer direction.

If this transfer direction specification bit is 0, it indicates that the master device transmits data to a slave device. If this bit is 1, it indicates that the master device receives data from a slave device.




Figure 20-7 Transfer direction specification

20.5.5 Acknowledge ($\overline{\text{ACK}}$)

The 1-bit data after the transfer direction bit ($\overline{\text{R/W}}$) and the 1-bit data after the 8-bit data during address transfer are defined as an acknowledge signal ($\overline{\text{ACK}}$). $\overline{\text{ACK}}$ is used to check the serial data status of the transmitting and receiving devices.

The receiving device returns $\overline{\text{ACK}}$ after receiving 8-bit data.

The transmitting device normally receives $\overline{\text{ACK}}$ after transmitting 8-bit data. If the transmitting device receives $\overline{\text{ACK}}$ from the receiving device, it continues processing assuming that the transmitted data is normally received.

If the master device is the receiving device and receives the final data, it does not return $\overline{\text{ACK}}$ and outputs a stop condition. If the slave device is the receiving device and does not return $\overline{\text{ACK}}$, the master device outputs either a stop condition or a restart condition and then stops the current transmission. Failure to return $\overline{\text{ACK}}$ may be caused by the following factors:

- The transmitted data has not been received normally.
- The final data has been received.
- The receiving device (slave) does not exist for the specified address.

$\overline{\text{ACK}}$ is output when the SDA_n line of the receiving device changes to low level at the 9th clock (normal reception).




Figure 20-8 Acknowledge ($\overline{\text{ACK}}$)

20.5.6 Data

Except for a 9-bit data string (consisting of a 7-bit address, 1-bit $\overline{R/W}$, and 1-bit ACK) transferred after the start condition, the bits other than ACK are defined as data.

If a 10-bit address is specified using an extension code, the 8-bit data that is transferred after the address is used as the second address.

20.5.7 Stop condition

A stop condition is met if the SDA_n signal level changes from low to high while the SCL_n signal is high.

The stop condition is output when serial data transfer from the master device to the slave device has been completed.




Figure 20-9 Stop condition

20.5.8 Wait state

A wait state is used to report to the communication destination that the IICBn (master or slave) is preparing to transmit or receive data.

The wait state is reported to the communication destination by setting the SCLn signal to low. The next data transfer cannot start until both the master and slave devices exit the wait state.

(a) When a wait at the 9th clock is specified for the master and a wait at the 8th clock for the slave (master: transmission, slave: reception)




Figure 20-10 Wait state (1/2)

(b) When a wait at the 9th clock is specified for both the master and slave
(master: transmission, slave: reception)




Figure 20-10 Wait state (2/2)

20.5.9 Arbitration

When several master devices simultaneously output a start condition, communication with the master devices continues until the data differs, while adjusting the clocks. An example where two masters simultaneously output a start condition and arbitration is conducted is described below.

This example assumes that one master outputs the SDA_n line high (master 1) and the other master outputs the SDA_n line low (master 2) while the SCL_n line is low.

In this case, the communication with master 2 is prioritized, and communication is not authorized for master 1.

This kind of operation is called arbitration, and the state in which communication is not authorized is called arbitration loss. The master that lost arbitration releases the bus by setting both the SCL_n and SDA_n line to high impedance.




Figure 20-11 Arbitration timing example

20.6 Registers

Caution In this section, the operation when an extension code is received is omitted. For details about the extension code, refer to 20.7.4 “Extension code”.

(1) IICBnDAT – IICBn data register

This register is used to transmit and receive transfer data.

Access This register can be read/written in 8-bit units.

Address <IICBn_base> + 0000_H

Initial Value 0000_H. This register is also initialized by changing the value of the IICBnCTL0.IICBnIICE bit from 1 to 0 or from 0 to 1.

- Cautions**
1. When the IICBn becomes a master in the single transfer mode, after the IICBnTRG.IICBnSTT bit has been set to 1, writing to the IICBnDAT register is allowed only once to transfer the address and communication direction.
 2. When transferring data in the single transfer mode, writing to the IICBnDAT register in communication state other than the wait state is prohibited.
 3. When transferring data in the continuous transfer mode, writing to the IICBnDAT register in response to an INTIICBTIA interrupt request signal is only allowed once.
 4. When executing transmission operations in the continuous transfer mode, do not read the IICBnDAT register. Similarly, when performing reception operations in the continuous transfer mode, do not write to the IICBnDAT register.

7	6	5	4	3	2	1	0
IICBnDAT7	IICBnDAT6	IICBnDAT5	IICBnDAT4	IICBnDAT3	IICBnDAT2	IICBnDAT1	IICBnDAT0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 20-9 IICBnDAT register contents

Bit position	Bit name	Function
7 to 0	IICBnDAT[7:0]	<p>During reception, these bits hold the received data. During transmission, these bits write the transmit data.</p> <p>The prescribed procedure must be followed during access (read, write) to the IICBnDAT register. For the setting sequence, refer to 20.10 “Setting Sequence”. The IICBn exits the wait state by performing access to the IICBnDAT register.</p> <ul style="list-style-type: none"> • In single transfer mode <ul style="list-style-type: none"> - When write access to the IICBnDAT register is performed • In continuous transfer mode <ul style="list-style-type: none"> - When write access to the IICBnDAT register is performed - When read access to the IICBnDAT register is performed during a wait state for data transfer that is not triggered by NACK signal reception

(2) IICBnSVA – IICBn slave address register

This register stores the slave address of the I²C bus.

Access This register can be read/written in 8-bit units.

Address <IICBn_base> + 0004_H

Initial Value 0000_H

Caution Write access to the IICBnSVA register is prohibited when the value of the IICBnCTL0.IICBnIICE bit is 1.

7	6	5	4	3	2	1	0
IICBnSVA7	IICBnSVA6	IICBnSVA5	IICBnSVA4	IICBnSVA3	IICBnSVA2	IICBnSVA1	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R

Table 20-10 IICBnSVA register contents

Bit position	Bit name	Function
7 to 1	IICBnSVA[7:1]	<p>Store the slave address of the I²C bus.</p> <p>Address match/address mismatch is judged by comparing the received address and the IICBnSVA register.</p> <p>If the received address matches the IICBnSVA register, the IICBnSTR0.IICBnSSCO bit is set to 1.</p>

(3) IICBnCTL0 – IICBn control register 0

This register is used to control the operations of the IICBn.

Access This register can be read/written in 8-bit units.

Address <IICBn_base> + 0008_H

Initial Value 0000_H

	7	6	5	4	3	2	1	0
IICBn IICE	0	0	0	0	0	0	IICBn SLWT	IICBn SLAC
R/W	R	R	R	R	R	R	R/W	R/W

Table 20-11 IICBnCTL0 register contents (1/2)

Bit position	Bit name	Function
7	IICBnIICE	<p>Enables/disables operation of the IICBn.</p> <p>0: Disables operation of IICBn. 1: Enables operation of IICBn.</p> <p>Synchronous reset of the following registers is executed when the value of the IICBnIICE bit changes from 1 to 0, or the value of the IICBnIICE bit changes from 0 to 1.</p> <ul style="list-style-type: none"> IICBnDAT and IICBnSTR0 registers <p>When IICBnIICE is 0, the SCLn and SDA_n pins go into the high impedance state.</p>
1	IICBnSLWT	<p>Controls a wait and interrupt request output timing.</p> <p>0: The IICBn enters the wait state and an interrupt request is output at the falling edge of the 8th clock during single transfer. 1: The IICBn enters the wait state and an interrupt request is output at the falling edge of the 9th clock during single transfer.</p> <p>The IICBnSLWT bit controls wait state transition and interrupt request output at the following timing.</p> <ul style="list-style-type: none"> 8th and 9th clocks during data transfer <p>For the conditions for transition to the wait state, refer to 20.7.3 “Entering and exiting wait state”.</p> <p>During address transfer, the conditions for transiting to the wait state and for interrupt request output are as follows, regardless of the setting of the IICBnSLWT bit.</p> <ul style="list-style-type: none"> Master mode: A data transmit/receive interrupt request signal (INTIICBTIA_n) is output and the IICBn enters the wait state upon detection of the falling edge of the 9th clock. Slave mode: During an address match, the INTIICBTIA_n signal is output and the IICBn enters the wait state upon detection of the falling edge of the 9th clock. During address mis-match, the INTIICBTIA_n signal is not output and the IICBn does not enter the wait state. <p>Caution During data transmission, rewriting the IICBnSLWT bit is prohibited.</p>

Table 20-11 IICBnCTL0 register contents (2/2)

Bit position	Bit name	Function
0	IICBnSLAC	<p>Controls acknowledge signal output.</p> <p>0: Disables acknowledge signal output. Master: The acknowledge signal is not output during data reception (SDAn = "H"). Slave: The acknowledge signal is not output during data transfer when an address match occurs (SDAn = "H").</p> <p>1: Enables acknowledge signal output. Master: The acknowledge signal is output during data reception (SDAn = "L"). Slave: The acknowledge signal is output during data transfer when an address match occurs (SDAn = "L").</p> <p>When the IICBn is operating as a slave, in the case of an address match, an acknowledge signal is output during address transfer regardless of the value of the IICBnSLAC bit (SDAn = "L"). also, no acknowledge signal is output (SDAn = "H") while the IICBn is transmitting data or when it does not participate in communications.</p>

(4) IICBnCTL1 – IICBn control register 1

This register controls the operation of the IICBn.

Access This register can be read/written in 8-bit units.

Address <IICBn_base> + 0020_H

Initial Value 0000_H

Caution Write access to the IICBnCTL1 register is prohibited when the value of the IICBnCTL0.IICBnIICE is 1.

7	6	5	4	3	2	1	0
IICBn MDSC	IICBn LGDF2	IICBn LGDF1	IICBn LGDF0	0	0	IICBn SLSE	0
R/W	R/W	R/W	R/W	R	R	R/W	R

Table 20-12 IICBnCTL1 register contents (1/2)

Bit position	Bit name	Function														
7	IICBnMDSC	Specifies the operation mode for the IICBn. 0: Standard mode (SCL clock frequency: 100 kbps max.) 1: Fast mode (SCL clock frequency: 400 kbps max.)														
6 to 4	IICBnLGDF[2:0]	Specify the digital filter sampling frequency. Note that the digital filter can be used only in the fast mode. 000: Does not use digital filter. SCLn and SDAn are used without passing through the digital filter in the IICBn. The digital filter circuit operations are stopped. Other than above: Uses digital filter. SCLn and SDAn are used passing through the digital filter in the IICBn. When using a digital filter, set bits IICBnLGDF2 to IICBnLGDF0 as follows.														
		<table border="1"> <thead> <tr> <th>IICBnLGDF2 to IICBnLGDF0 bits</th> <th>Frequency</th> </tr> </thead> <tbody> <tr> <td>001</td> <td>Minimum frequency ^{a)} ≤ PCLK ≤ 20 MHz</td> </tr> <tr> <td>010</td> <td>20 MHz < PCLK ≤ 40 MHz</td> </tr> <tr> <td>011</td> <td>40 MHz < PCLK ≤ 60 MHz</td> </tr> <tr> <td>100</td> <td>60 MHz < PCLK ≤ 80 MHz</td> </tr> <tr> <td>101</td> <td>80 MHz < PCLK ≤ 100 MHz</td> </tr> <tr> <td>110, 111</td> <td>Setting prohibited</td> </tr> </tbody> </table>	IICBnLGDF2 to IICBnLGDF0 bits	Frequency	001	Minimum frequency ^{a)} ≤ PCLK ≤ 20 MHz	010	20 MHz < PCLK ≤ 40 MHz	011	40 MHz < PCLK ≤ 60 MHz	100	60 MHz < PCLK ≤ 80 MHz	101	80 MHz < PCLK ≤ 100 MHz	110, 111	Setting prohibited
IICBnLGDF2 to IICBnLGDF0 bits	Frequency															
001	Minimum frequency ^{a)} ≤ PCLK ≤ 20 MHz															
010	20 MHz < PCLK ≤ 40 MHz															
011	40 MHz < PCLK ≤ 60 MHz															
100	60 MHz < PCLK ≤ 80 MHz															
101	80 MHz < PCLK ≤ 100 MHz															
110, 111	Setting prohibited															
		^{a)} A list of the minimum frequencies by setting is shown below.														
		<table border="1"> <thead> <tr> <th>Operation mode (IICBnMDSC)</th> <th>When digital filter used (IICBnLGDF bits = 000)</th> <th>When digital filter used (IICBnLGDF bits ≠ 000)</th> </tr> </thead> <tbody> <tr> <td>Standard mode (0)</td> <td>1.0 MHz</td> <td>Use prohibited</td> </tr> <tr> <td>Fast mode (1)</td> <td>3.5 MHz</td> <td>4.0 MHz</td> </tr> </tbody> </table>	Operation mode (IICBnMDSC)	When digital filter used (IICBnLGDF bits = 000)	When digital filter used (IICBnLGDF bits ≠ 000)	Standard mode (0)	1.0 MHz	Use prohibited	Fast mode (1)	3.5 MHz	4.0 MHz					
Operation mode (IICBnMDSC)	When digital filter used (IICBnLGDF bits = 000)	When digital filter used (IICBnLGDF bits ≠ 000)														
Standard mode (0)	1.0 MHz	Use prohibited														
Fast mode (1)	3.5 MHz	4.0 MHz														

Table 20-12 IICBnCTL1 register contents (2/2)

Bit position	Bit name	Function
1	IICBnSLSE	<p>Enables/disables start condition output in the initial communication state.</p> <p>0: Disables start condition output in the initial communication state. 1: Enables start condition output in the initial communication state.</p> <p>If the IICBnSLSE bit is set to 1, a start condition can be output by setting the IICBnTRG.IICBnSTT bit to 1 in the initial communication state (from when the IICBnCTL0.IICBnIICE bit is set to 1 until detection of a stop condition). The IICBnSLSE bit is automatically cleared to 0 upon detection of a start condition (even without a 0 write operation).</p> <p>Caution Clear the IICBnSLSE bit to 0 when participating in communications after other communications have started. When other communications are being performed, if the IICBnSTT has been set to 1 with the IICBnSLSE bit set to 1, the other communications may be damaged.</p>

(5) IICBnWL – IICBn low level width setting register

This register is used to set the low level width of the serial clock register (SCLn).

Access This register can be read/written in 16-bit units.

Address <IICBn_base> + 0024_H

Initial Value 03FF_H

Caution Write access to the IICBnWL register is prohibited when the value of the IICBnCTL0.IICBnIICE bit is 1.

15	14	13	12	11	10	9	8
0	0	0	0	0	0	IICBnWL9	IICBnWL8
R	R	R	R	R	R	R/W	R/W
7	6	5	4	3	2	1	0
IICBnWL7	IICBnWL6	IICBnWL5	IICBnWL4	IICBnWL3	IICBnWL2	IICBnWL1	IICBnWL0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 20-13 IICBnWL register contents

Bit position	Bit name	Function
9 to 0	IICBnWL[9:0]	Specify the t_{LOW} period (low level width of the SCLn clock) of the I ² C bus specification. The value of the IICBnWL register is used to determine the serial output timing of other I ² C bus specifications. For the serial output timing setting conditions, refer to a "Setting transfer clock by using IICBnWL and IICBnWH registers" on page 1091 .

(a) Setting transfer clock by using IICBnWL and IICBnWH registers

The various timings in compliance with the I²C bus specifications can be set by setting the IICBnWL register and IICBnWH register.

- Setting transfer clock on master side

$$\text{Transfer clock (Hz)} = \frac{\text{PCLK}}{\text{IICBnWL} + \text{IICBnWH} + \text{PCLK} (t_R + t_F)}$$

At this time, the optimal setting values of IICBnWL and IICBnWH are as follows.

(The fractional parts of all setting values are rounded up.)

- When the fast mode

$$\text{IICBnWL} = \frac{0.52}{\text{Transfer clock}} \times \text{PCLK}$$

$$\text{IICBnWH} = \left(\frac{0.48}{\text{Transfer clock}} - t_R - t_F \right) \times \text{PCLK}$$

- When the normal mode

$$\text{IICBnWL} = \frac{0.47}{\text{Transfer clock}} \times \text{PCLK}$$

$$\text{IICBnWH} = \left(\frac{0.53}{\text{Transfer clock}} - t_R - t_F \right) \times \text{PCLK}$$

Caution The data hold time must be 0.9 μs or less in the fast mode and 3.45 μs or less in the standard mode.

Note The data hold time is determined by the IICBWL register setting as follows:

$$\text{Data hold time} = \text{IICBnWL.IICBnWL}[9:2] / \text{PCLK}$$

- Setting IICBnWL and IICBnWH on slave side
(The fractional parts of all setting values are rounded up.)
 - When the fast mode
$$\text{IICBnWL} = 1.3 \mu\text{s} \times \text{PCLK}$$
$$\text{IICBnWH} = (1.2 \mu\text{s} - t_R - t_F) \times \text{PCLK}$$
 - When the normal mode
$$\text{IICBnWL} = 4.7 \mu\text{s} \times \text{PCLK}$$
$$\text{IICBnWH} = (5.3 \mu\text{s} - t_R - t_F) \times \text{PCLK}$$

Note IICBnWL: IICBn low-level width setting register
IICBnWH: IICBn high-level width setting register
t_F: SDA_n and SCL_n signal falling times
t_R: SDA_n and SCL_n signal rising times
PCLK: Frequency of the clock supplied to the IICBn
f_{CLK}: SCL clock frequency

(6) IICBnWH – IICBn high-level width setting register

This register is used to set the high level width of the serial clock signal (SCLn).

Access This register can be read/written in 16-bit units.

Address <IICBn_base> + 0028_H

Initial Value 03FF_H

Caution Write access to the IICBnWH register is prohibited when the value of the IICBnCTL0.IICBnIICE bit is 1.

15	14	13	12	11	10	9	8
0	0	0	0	0	0	IICBnWH9	IICBnWH8
R	R	R	R	R	R	R/W	R/W
7	6	5	4	3	2	1	0
IICBnWH7	IICBnWH6	IICBnWH5	IICBnWH4	IICBnWH3	IICBnWH2	IICBnWH1	IICBnWH0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 20-14 IICBnWH register contents

Bit position	Bit name	Function
9 to 0	IICBnWH[9:0]	Specify the t_{HIGH} period (high level width of the SCLn clock) of the I ² C bus specification. The value of the IICBnWH register is used to determine the serial output timing of other I ² C bus specifications. For the serial output timing setting conditions, refer to a "Setting transfer clock by using IICBnWL and IICBnWH registers" on page 1091 .

(7) IICBnTRG – IICBn trigger register

This register is used to set the IICBn trigger.

Access This register can be read/written in 8-bit units.

Address <IICBn_base> + 000C_H

Initial Value 0000_H

7	6	5	4	3	2	1	0
0	0	0	0	IICBn LRET	IICBn WRET	IICBn STT	IICBn SPT
R	R	R	R	R/W	R/W	R/W	R/W

Table 20-15 IICBnTRG register contents (1/3)

Bit position	Bit name	Function
3	IICBnLRET	<p>Communication exit trigger bit</p> <p>0: Normal operation</p> <p>1: The IICBn exits the current communication and enters the wait state. This bit is automatically cleared to 0 following execution.</p> <p>The following occurs when IICBnLRET is 1.</p> <ul style="list-style-type: none"> - SCLn and SDAn each go into high impedance (communication wait state). - Bits IICBnSSMS, IICBnSSDR, IICBnSSWT, IICBnSSEX, IICBnSSC0, IICBnSSTR, IICBnSSAC, and IICBnSSST of the IICBnSTR0 register are cleared to 0. - When IICBnSTT = 1 (start condition output preparation) or IICBnSPT = 1 (stop condition output preparation) has been set, output of a start condition or stop condition is stopped. <p>Caution If IICBnLRET is set to 1 during master operation (IICBnSTR0.IICBnSSMS = 1), the bus is released. Since serial clock output stops, problems occur during communication on the slave side.</p>
2	IICBnWRET	<p>This is the trigger bit for exiting the wait state.</p> <p>0: Does not exit the wait state.</p> <p>1: Exits the wait state and resumes communication. This bit is automatically cleared following execution.</p> <p>If the IICBn have exited the wait state by setting the IICBnWRET bit to 1 during the wait state triggered by the falling edge of the 9th clock, the IICBnSTR0.IICBnSSTR bit is cleared to 0 and SDAn goes into high impedance (this enables the external master to output a stop condition or start condition.)</p> <p>If the IICBn is not in the wait state (IICBnSTR0.IICBnSSWT = 0), setting this bit to 1 has no meaning.</p> <p>There are other conditions for exiting the wait state in addition to the setting of this bit. For details, refer to 20.7.3 “Entering and exiting wait state”.</p>

Table 20-15 IICBnTRG register contents (2/3)

Bit position	Bit name	Function
1	IICBnSTT	<p>Start condition trigger bit</p> <p>0: Does not output a start condition. 1: Outputs a start condition (This bit is automatically cleared to 0 after it has been set to 1.)</p> <p>The IICBnSTT bit can be set to 1 under the following conditions:</p> <p>[1] IICBnSTR0.IICBnSSMS bit = Master state (1)</p> <ul style="list-style-type: none"> • During wait state triggered by the falling edge of the 9th clock (both address transfer and data transfer) • During data reception, only after clearing the ACKEn bit to 0 to report the end of reception to the slave <p>After exiting the wait state that was triggered by the falling edge of the 9th clock, and upon detection of the falling edge of the 9th clock in all other cases, SDAn and SCLn are set to high level after the t_{LOW} (low-level width of SCLn clock) period, and when SDAn is set to the low level after waiting for $t_{SU:STA}$ of the I²C bus specification (setup time of start/restart condition), a start condition is output. Then, SCLn is set to low level after the $t_{HD:STA}$ time (hold time) of the I²C bus specification has elapsed.</p> <p>[2] Slave state or communication wait state (IICBnSTR0.IICBnSSMS = 0)</p> <ul style="list-style-type: none"> • IICBnSTR0.IICBnSSBS bit = 0 (bus release state) Outputs a start condition. Following verification of the t_{BUF} (bus free time (between stop/start conditions) of the I²C specification (if this time has not elapsed, following lapse, and if this time has elapsed, immediately), a start condition is output when SDAn is changed from high level to low level while SCLn is high level. (At this time, SCLn outputs a high level.) Then, SCLn is set to low level after the $t_{HD:STA}$ time of the I²C bus specification has elapsed. • IICBnSSBS bit = 1 (bus communication state) This status indicates that communication is performed on the bus while the IICBn is not operating as a master. The IICBnSTR0.IICBnSTCF bit is set to 1 and a start condition is not output. <p>Caution [2] shows the operations according to the value of the IICBnSSBS bit when the IICBnSTT bit is 0. Even if the IICBnSTT bit is set to 1 after checking the value of the IICBnSSBS bit through register read, the value of IICBnSSBS may differ from its value when it was checked.</p>

Table 20-15 IICBnTRG register contents (3/3)

Bit position	Bit name	Function
1	IICBnSTT	<p>The output processing of the start condition is started by setting the IICBnSTT bit to 1, but upon detection of the following states, output processing of the start condition is stopped and the start condition is not output.</p> <ul style="list-style-type: none"> - When 0 is written to the IICBnCTL0.IICBnIICE bit - When 1 is written to the IICBnLRET bit - Upon detection of arbitration loss <p>Caution When start in the initial communication state is enabled (IICBnCTL1.IICB0SLSE bit = 1), the start condition is output regardless of the bus status when the IICBnSTT bit is set to 1. If other communications are performed at that time, they may be damaged.</p> <p>Note Setting the IICBnSTT bit at the same time as the IICBnSPT bit is prohibited.</p>
0	IICBnSPT	<p>Stop condition trigger bit</p> <p>0: Does not output a stop condition. 1: Outputs a stop condition (This bit is automatically cleared after it has been set to 1).</p> <p>The IICBnSPT bit can be set to 1 under the following conditions while the IICBn is performing communication as a master.</p> <ul style="list-style-type: none"> • Wait state triggered by the falling edge of the 9th clock (both address transfer and data transfer) • During data reception, only after clearing the ACKEn bit to 0 to report the end of reception to the slave <p>A stop condition can be output with the following procedure. (If the IICBn is in the wait state, after exiting the wait state) SCLn is released when SDAn has output a low level, and SCLn = high level, SDAn is low level are waited for. Then, following the lapse of the $t_{SU:STO}$ time, a stop condition is output by setting SDAn to high level.</p> <p>The output processing of the stop condition is started by setting the IICBnSPT bit to 1, but upon detection of the following states, output processing of the stop condition is stopped and the stop condition is not output.</p> <ul style="list-style-type: none"> - When 0 is written to the IICBnIICE bit - When 1 is written to the IICBnLRET bit - Upon detection of a stop condition - Upon detection of arbitration loss <p>Caution Setting the IICBnSPT bit to 1 is prohibited during slave operation (IICBnSTR0.IICBnSSMS bit = 0)</p> <p>Note Setting the IICBnSPT bit to 1 at the same time as the IICBnSTT bit is prohibited.</p>

(8) IICBnSTR0 – IICBn status register 0

This register indicates the statuses of the IICBn and the bus.

Access This register can be read only in 16-bit units. However, when IICBnIICE is 0, this register can also be write accessed.

Address <IICBn_base> + 0010_H

Initial Value 0000_H. This register is also initialized by changing the value of the IICBnCTL0.IICBnIICE bit from 1 to 0 or from 0 to 1.

15	14	13	12	11	10	9	8
IICBn SSMS	0	IICBn SSDR	IICBn SSWT	IICBn SSEX	IICBn SSCO	IICBn SSTR	IICBn SSAC
R	R	R	R	R	R	R	R
7	6	5	4	3	2	1	0
0 ^a	IICBn SSBS	IICBn SSST	IICBn SSSP	0	0	IICBn STCF	IICBn ALDF
R	R	R	R	R	R	R	R

a) Bit 7 may change to 1, but has no particular meaning.

Table 20-16 IICBnSTR0 register contents (1/5)

Bit position	Bit name	Function
15	IICBnSSMS	<p>Master state check flag: Indicates that the IICBn is operating as a master. 1: Indicates that the IICBn is operating as a master.</p> <p>Setting condition: Upon detection of a start condition after 1 is written to the IICBnTRG.IICBnSTT bit</p> <p>Clearing conditions: • When 1 is written to the IICBnTRG.IICBnLRET bit • Upon detection of a stop condition • Upon detection of arbitration loss</p> <p>If a setting condition coincides with a clearing condition, the clearing condition takes priority.</p>
13	IICBnSSDR	<p>IICBnDAT register status flag 1: Indicates that data in the IICBnDAT register remains unprocessed. During reception operation: Received data remains unread in the IICBnDAT register. During transmission operation: Data written to the IICBnDAT register has not been transferred to the IICBnDAT register.</p> <p>Setting condition:</p> <ul style="list-style-type: none"> When the IICBnDAT register is written during address transfer and data transfer while the IICBnSSWT bit is 0 (Note that the IICBnSSDR bit is not set to 1 if address data is written to the IICBnDAT register while the IICBn is operating as a master, because the address data is directly transferred to the IICBnDAT register in this event.) At the falling edge of the 9th clock after an address match with a slave When IICBnCTL0.IICBnSLWT = 0, at the falling edge of the 8th clock during data reception When IICBnCTL0.IICBnSLWT = 1, at the falling edge of the 9th clock during data reception

Table 20-16 IICBnSTR0 register contents (2/5)

Bit position	Bit name	Function
13	IICBnSSDR	<p>Clearing conditions:</p> <ul style="list-style-type: none"> • Clearing conditions given priority over setting conditions <ul style="list-style-type: none"> - When 1 is written to the IICBnLRET bit - Upon detection of arbitration loss - At the falling edge of the 9th clock during address transfer while the IICBn is operating as a master - When IICBnCTL0.IICBnSLWT = 0, at the falling edge of the 8th clock during data transmission - When IICBnCTL0.IICBnSLWT = 1, at the falling edge of the 9th clock during data transmission • Clearing condition for which setting conditions are given priority <ul style="list-style-type: none"> - When the IICBnDAT register is read while the IICBnDAT register does not have any received data that must be transferred to the IICBnDAT register
12	IICBnSSWT	<p>Wait state flag 1: Indicates that the IICBn is in the wait state.</p> <p>Setting condition: <Common to master/slave></p> <ul style="list-style-type: none"> • During data transfer, upon detection of the falling edge of the 8th clock with IICBnSLWT = 0 • During data transfer, upon detection of the falling edge of the 9th clock with IICBnSLWT = 1 <p><Master></p> <ul style="list-style-type: none"> • When the IICBn becomes a master (IICBnSSMS = 1) after 1 is written to the IICBnSTT bit, and the falling edge of the first SCLn is detected without the IICBnDAT register being written • Upon detection of the falling edge of the 9th clock during address transfer <p><Slave></p> <ul style="list-style-type: none"> • Upon detection of the falling edge of the 9th clock during address transfer when an address match occurred <p>During address transfer period, operating as master></p> <ul style="list-style-type: none"> - When the IICBn becomes a master (IICBnSSMS = 1) after 1 is written to the IICBnSTT bit, and the first falling edge is detected without the IICBnDAT register being written - Upon NACK detection (However, only if 1 has not been written to IICBnTRG.IICBnSTT or IICBnTRG.IICBnSPT) <p><During address transfer period, operating as slave></p> <ul style="list-style-type: none"> - Upon detection of the falling edge of the 9th clock while IICBnSSTR bit is 0 during address transfer when an address match occurred - Upon NACK detection

Table 20-16 IICBnSTR0 register contents (3/5)

Bit position	Bit name	Function
12	IICBnSSWT	<p>Clearing conditions:</p> <ul style="list-style-type: none"> • Clearing conditions given priority over setting conditions <ul style="list-style-type: none"> - When 1 is written to the IICBnLRET bit - When 1 is written to the IICBnSPT bit while the IICBn is operating as a master in the continuous transfer mode - When the IICBnDAT register is written while the IICBn is performing transmission in the continuous transfer mode - During the wait state triggered by the falling edge of the 8th clock, when the IICBnDAT register is read while reception is performed in the continuous transfer mode - During the wait state triggered by the falling edge of the 9th clock, when the IICBnDAT register is read while the IICBn is performing reception in the continuous transfer mode and an acknowledge signal (ACK) has been received • Clearing condition for which setting conditions are given priority <ul style="list-style-type: none"> - When 1 is written to the IICBnTRG.IICBnWRET bit - When 1 is written to the IICBnSTT bit while the IICBn is operating as a master in the single transfer mode - When 1 is written to the IICBnSPT bit while the IICBn is operating as a master in the single transfer mode - When the IICBnDAT register is written while the IICBn is performing reception in the single transfer mode <p>Caution If the IICBn exits the wait state that was triggered by the falling edge of the 9th clock by writing 1 to the IICBnWRET bit, the IICBnSSTR bit is cleared to 0 and the bus is released (both SCLn and SDAn go into high impedance).</p>
11	IICBnSSEX	<p>Expansion code reception detection flag 1: Indicates that an expansion code has been received.</p> <p>Setting condition: Upon detection of the falling edge of the 8th clock while transferring received address data whose higher 4 bits are either 0000 or 1111</p> <p>Clearing conditions: <ul style="list-style-type: none"> • When 1 is written to the IICBnLRET bit • Upon detection of a stop condition • Upon detection of a start condition </p> <p>Caution When the expansion codes match, the processing after the interrupt differs according to the ensuing data, and therefore is dependent on software processing.</p>
10	IICBnSSCO	<p>Address match detection flag 1: Indicates that an address that matches the IICBnSVA register has been detected.</p> <p>Setting condition: Upon detection of the falling edge of the 8th clock while transferring a received address that matches the IICBnSVA register</p> <p>Clearing conditions: <ul style="list-style-type: none"> • When 1 is written to the IICBnLRET bit • Upon detection of a stop condition • Upon detection of a start condition </p>

Table 20-16 IICBnSTR0 register contents (4/5)

Bit position	Bit name	Function
9	IICBnSSTR	<p>Transmission status detection flag 1: Indicates that data is being transmitted to the serial data bus.</p> <p>Setting condition: <Master> - Upon detection of a start condition after 1 is written to the IICBnSTT bit <Slave> - Upon detection of the falling edge of the 8th clock following reception of 1 to R/W bit during address transfer when an address match occurred</p> <p>Clearing conditions: <Common to master/slave> - When 1 is written to the IICBnLRET bit - Upon detection of a stop condition - When 1 is written to the IICBnWRET bit during the wait state triggered by the falling edge of the 9th clock <Master> - Upon detection of the falling edge of the 8th clock following reception of 1 to R/W bit during address transfer - Upon detection of arbitration loss <Slave> - Upon detection of a start condition</p>
8	IICBnSSAC	<p>Acknowledge ($\overline{\text{ACK}}$) detection flag 1: Indicates that an acknowledge signal has been detected.</p> <p>Setting condition: Upon detection of the falling edge of SCLn when a low level has been received at the ACK bit during participation in communications</p> <p>Clearing conditions: • When 1 is written to the IICBnLRET bit • Upon detection of the rising edge of SCLn</p> <p>Caution The value of the IICBnSSAC bit changes regardless of whether or not an interrupt has occurred.</p>
6	IICBnSSBS	<p>IICBn bus status flag 0: Bus released state (initial communication state when IICBnCTL1.IICBnSLSE = 1) 1: Bus communication state (initial communication state when IICBnCTL1.IICBnSLSE = 0)</p> <p>Setting condition: • Upon detection of a start condition • When 1 is written to the IICBnCTL0.IICBnIICE bit when IICBnSLSE = 0</p> <p>Clearing conditions: Upon detection of a stop condition</p> <p>Note The IICBnSSBS bit operates whether or not the IICBn is participating in communications.</p>
5	IICBnSSST	<p>Start condition detection flag 1: Indicates that a start condition has been detected.</p> <p>Setting condition: Upon detection of a start condition</p> <p>Clearing conditions: • When 1 is written to the IICBnLRET bit • Upon detection of a stop condition • Upon detection of the rising edge of SCLn following the end of address transfer</p> <p>Note The IICBnSSST bit operates whether or not the IICBn is participating in communications.</p>

Table 20-16 IICBnSTR0 register contents (5/5)

Bit position	Bit name	Function
4	IICBnSSSP	<p>Stop condition detection flag 1: Indicates that a stop condition has been detected.</p> <p>Setting condition: Upon detection of a stop condition Clearing conditions: Upon detection of the falling edge of the first SCLn following start condition detection</p> <p>Note The IICBnSSSP bit operates whether or not the IICBn is participating in communications.</p>
1	IICBnSTCF	<p>IICBnSTT bit clear flag 1: Indicates that the IICBnSTT bit has been cleared because start condition output failed.</p> <p>Setting condition: When 1 is written to the IICBnSTT bit during bus communication when the IICBn is not operating as a master</p> <p>Caution Even if the bus is released in the external bus state, this bit is set to 1 when 1 is written to the IICBnSTT bit, unless the IICBn recognizes the bus release state (IICBnSSBS = 1).</p> <p>Clearing condition: When 1 is written to the IICBnSTRC.IICBnCLSF bit</p>
0	IICBnALDF	<p>Arbitration loss detection flag 1: Indicates that an arbitration loss has been detected.</p> <p>Setting condition: Upon detection of arbitration loss Clearing condition: When 1 is written to the IICBnSTRC.IICBnCLAF bit</p> <p>If a setting condition coincides with a clearing condition, the setting condition takes priority. Upon detection of arbitration loss, the IICBnSSMS and IICBnSSTR bits are cleared to 0. (SCLn and SDAn become high level and the bus is released.)</p> <p>Caution When the IICBnALDF bit is set to 1 due to arbitration loss, the INTIICBTIA interrupt request signal may be output. After confirming that the IICBnALDF bit has been set to 1 with an interrupt request signal, clear the IICBnALDF bit with the IICBnSTRC.IICBnCLAF bit.</p>

(9) IICBnSTR1 – IICBn status register 1

This register indicates the status of the serial bus.

Access This register is read-only, in 8-bit units.

Address <IICBn_base> + 0014_H

Initial Value 0000_H

7	6	5	4	3	2	1	0
0	0	0	0	0	0	IICBn SSCL	IICBn SSDA
R	R	R	R	R	R	R	R

Table 20-17 IICBnSTR1 register contents

Bit position	Bit name	Function
1	IICBnSSCL	Indicates the level of the SCLn pin (input). 0: Low level 1: High level
0	IICBnSSDA	Indicates the level of the SDAn pin (input). 0: Low level 1: High level

(10) IICBnSTRC – IICBn status clear register

This register clears the IICBnSTCF and IICBnALDF bits of the IICBnSTR0 register.

Access This register can be read/written in 8-bit units.

Address <IICBn_base> + 0018_H

Initial Value 0000_H

7	6	5	4	3	2	1	0
0	0	0	0	0	0	IICBnCLS F	IICBnCLAF
R	R	R	R	R	R	R/W	R/W

Table 20-18 IICBnSTRC register contents

Bit position	Bit name	Function
1	IICBnCLS F	<p>Clears the IICBnSTR0.IICBnSTCF bit. 1: Clears the IICBnSTCF bit.</p> <p>Note If the IICBnCLS F bit is read after setting data, 0 is returned.</p>
0	IICBnCLAF	<p>Clears the IICBnSTR0.IICBnALDF bit. 1: Clears the IICBnALDF bit.</p> <p>Caution If writing 1 to the IICBnCLAF bit and the setting condition of the IICBnALDF bit occur at the same time, the setting condition of the IICBnALDF takes priority.</p> <p>Note If the IICBnCLAF bit is read after data setting, 0 is returned.</p>

(11) IICBnEMU - IICBn emulation register

This register controls whether the IICBn can be stopped during emulation, for instance upon a breakpoint hit.

Access This register can be read/written in 8-bit units.

Address <IICBn_base> + 34_H

Initial Value 0000_H

	7	6	5	4	3	2	1	0
IICBn SVSDIS	0	0	0	0	0	0	0	0
	R/W	R	R	R	R	R	R	R

Table 20-19 IICBnEMU register contents

Bit position	Bit name	Function
7	IICBn SVSDIS	Emulation control 0: IICBn can be stopped during emulation 1: IICBn continuous operating during emulation


20.7 Operation

20.7.1 Single transfer mode

In the single transfer mode, a data transmit/receive interrupt request signal is output at the timing specified using the IICBnCTL0.IICBnSLW bit to make the IICBn enter the wait state, and transmit/receive data processing is performed during this wait state.


The various processing operations are described below.

(1) Example of communication in single transfer mode (master reception)




- <1> Start condition output
Set the IICBnTRG.IICBnSTT bit (to 1).
- <2> Address and transfer direction specification output
Set the address of the slave device and the transfer direction as 8 bits into the IICBnDAT register.
- <3> Acknowledge result check
Check the acknowledge result by reading the IICBnSTR0.IICBnSSAC bit using the IICBTIA interrupt.
- <4> Wait timing setting
During data reception, clear the IICBnCTL0.IICBnSLWT bit (to 0) so that the IICBn enters the wait state at the falling edge of the 8th clock.
- <5> Data reception
Exit the wait state by setting the IICBnTRG.IICBnWRET bit (to 1) to start reception.
- <6> Receive data load
Read the receive data from the IICBnDAT register using the IICBTIA interrupt.
- <7> Data reception completion processing
- Set the IICBnCTL0.IICBnSLWT bit to 1 and the IICBnSLAC bit to 0.
 - Next, exit the wait state by setting the IICBnTRG.IICBnWRET bit (to 1). The end of the data is notified to the transmitting device without outputting ACK.
- <8> Stop condition output
Set the IICBnTRG.IICBnSPT bit (to 1).

(2) Example of communication in single transfer mode (master transmission)




Note During data transmission, set the IICBnCTL0.IICBnSLWT bit (to 1) so that the IICBn enters the wait state at the falling edge of the 9th clock.

- <1> Start condition output
Set the IICBnTRG.IICBnSTT bit (to 1).
- <2> Address and transfer direction specification output
Set the address of the slave device and the transfer direction as 8 bits into the IICBnDAT register.
- <3> Acknowledge result check
Check the acknowledge result by reading the IICBnSTR0.IICBnSSAC bit using the IICBTIAN interrupt.
- <4> Data transmission
Exit the wait state by setting the transmit data into the IICBnDAT register to start transmission.
- <5> Stop condition output
Set the IICBnTRG.IICBnSPT bit (to 1).

(3) Example of communication in single transfer mode (slave reception)

(4) Example of communication in single transfer mode (slave transmission)



Note During data transmission, set the IICBnCTL0.IICBnSLWT bit (to 1) so that the IICBn enters the wait state at the falling edge of the 9th clock.

<1> Operation mode check in slave mode

- Check the operation mode using the IICBTIAN interrupt.
- Check the address transfer, address match, and reception operation with the IICBnSTR0.IICBnSSST, IICBnSSCO, and IICBnSSTR bits.
- Read the IICBnDAT register (empty read).

<2> Data transmission

Exit the wait state by setting the transmit data into the IICBnDAT register to start transmission.

<3> Acknowledge result check

Check the acknowledge result by reading the IICBnSTR0.IICBnSSAC bit using the IICBTIAN interrupt.

If ACK is not output, the transmission is judged to have been completed, and the IICBn exits the wait state by setting the IICBnTRG.IICBnWRET bit (to 1).

<4> Stop condition detection.

20.7.2 Arbitration

When the IICBn operates as the master device and loses arbitration, it enters the slave standby state by setting both SCLn and SDAn to high level upon detection of the arbitration loss, and then the IICBnSTR0.IICBnALDF bit is set (to 1).

(1) Status upon occurrence of arbitration

The statuses upon occurrence of arbitration during master device operation (IICBnSTR0.IICBnSSMS bit = 1) are listed below.

- [8] Address transmission
- [9] R/W bit transmission of address transfer
- [10] Extension code transmission
- [11] R/W bit transmission of extension code transfer
- [12] Data transmission
- [13] $\overline{\text{ACK}}$ bit transmission after data reception
- [14] Start condition detection during address transfer or data transfer
- [15] Stop condition detection during address transfer or data transfer
- [16] The SDAn signal is low when the IICBn is attempting to output a restart condition
- [17] The SDAn signal is low when the IICBn is attempting to output a stop condition
- [18] The falling edge of the SCLn signal is detected when the IICBn is attempting to output a restart condition

20.7.3 Entering and exiting wait state

The IICBn enters the wait state at the following timings.

Table 20-20 Wait state transit timings

ST	AD6-AD0	R/W	ACK	D7-D0	ACK	SP
	$\Delta 0$			$\Delta 1$	$\Delta 2$	$\Delta 3$

Timing	Description	Refer to:
$\Delta 0$	Upon detection of the first falling edge of the SCLn, following detection of start condition as the master device	1 "Wait state at falling edge of first SCLn after IICBn became master" on page 1112
$\Delta 1$	Upon detection of the falling edge of the 9th SCLn during address transfer after the start condition	2 "Wait state upon detection of the falling edge of the 9th SCLn during address transfer after the start condition" on page 1113
$\Delta 2$	Upon detection of the falling edge of the 8th SCLn during data transfer	3 "Wait state upon detection of the falling edge of the 8th SCLn during data transfer" on page 1113
$\Delta 3$	Upon detection of the falling edge of the 9th SCLn during data transfer	4 "Wait state upon detection of the falling edge of the 9th SCLn during data transfer" on page 1114

Note

ST: Start condition
 AD6 to AD0: Address
 R/W: Transfer direction specification
 ACK: Acknowledge
 D7 to D0: Data
 SP: Stop condition

The method to exit the wait state differs according to the wait state.

Exit the wait state by applying the appropriate method for each of the four wait states as described below.

(1) Wait state at falling edge of first SCLn after IICBn became master

$\Delta 0$ indicates the wait state when the data to be transferred has not been written (to the IICBnDAT register) when the falling edge of the first SCLn after the IICBn became the master is detected, after 1 was written to the IICBnTRG.IICBnSTT bit.

(a) Wait state transit condition

The IICBn enters the wait state if data is not written to the IICBnDAT register in the period from when the IICBnSTT bit becomes 1 until the $\Delta 0$ timing, upon detection of the first falling edge of SCLn after the IICBn became master, after 1 was written to the IICBnSTT bit.

The valid times to write to the IICBnDAT register for each of these cases are shown in *Figure 20-12 "Valid times to write to IICBnDAT register"*.




Figure 20-12 Valid times to write to IICBnDAT register

Caution The communication reservation function is disabled (<2> in the above figure) while the IICBnSTR0.IICBnSTCF bit is 0. When the IICBnSTCF bit becomes 1, setting from IICBnSTCF bit = 1 write is required again.

(b) Wait state exit conditions

Exit the wait state by writing to the IICBnDAT register.

(2) Wait state upon detection of the falling edge of the 9th SCLn during address transfer after the start condition

$\Delta 1$ indicates the wait state entered upon completion of address transfer.

(a) Wait state transit condition

In the single transfer mode, the IICBn always enters the wait state while it operates as the master.

While the IICBn operates as a slave, it enters the wait state upon an address match, or upon extension code detection while the IICBnSLWT bit is 1.

(b) Wait state exit conditions

Exit the wait state by writing to the IICBnDAT register during transmission, or by writing 1 to the IICBnWRET bit during reception. When the IICBn operates as the master and the IICBnSTR0.IICBnSSAC bit is 0 or the IICBn is at the transmission side, the wait state can be exited by writing 1 to the IICBnTRG.IICBnSTT or the IICBnTRG.IICBnSPT bit.

(3) Wait state upon detection of the falling edge of the 8th SCLn during data transfer

$\Delta 2$ indicates the wait state entered upon detection of the falling edge of the 8th SCLn during data transfer.

(a) Wait state transit condition

When the IICBn participates in communications and the IICBnCTL0.IICBnSLWT bit is 0, the IICBn enters the wait state if the falling edge of the 8th SCLn is detected.

(b) Wait state exit conditions

Exit the wait state by writing to the IICBnDAT register during transmission, or by writing 1 to the IICBnTRG.IICBnWRET bit during reception.

(4) Wait state upon detection of the falling edge of the 9th SCLn during data transfer

$\Delta 3$ indicates the wait state entered upon detection of the falling edge of the 9th SCLn during data transfer.

(a) Wait state transit condition

When the IICBn participates in communications and the IICBnCTL0.IICBnSLWT bit is 1, the IICBn enters the wait state if the falling edge of the 9th SCLn is detected.

(b) Wait state exit conditions

The wait state exit conditions are listed for each transfer mode in *Table 20-21* "Wait state exit conditions".

Table 20-21 Wait state exit conditions

Master/ slave	Transfer mode	Transfer direction	IICBnSTR0. IICBnSSAC bit	Exit conditions
Master	Single transfer mode	Reception	0	IICBnTRG.IICBnSTT bit = 1 or IICBnTRG.IICBnSPT bit = 1
			1	IICBnTRG.IICBnLRET bit = 1
		Transmission	0	IICBnSTT bit = 1 or IICBnSPT bit = 1
			1	Write to IICBnDAT register or IICBnSTT bit = 1 or IICBnSPT bit = 1
Slave	Single transfer mode	Reception	-	IICBnWRET bit = 1
		Transmission	0	IICBnWRET bit = 1
			1	Write to IICBnDAT register ^a

^{a)} Condition for exiting the wait state that was entered when no transmit data has been written to the data register.

20.7.4 Extension code

The processing when the extension code is received differs according to the data after the extension code and thus must be executed through the user's software.

Therefore, the operation differs from that during normal slave address reception. These differences are described below.

- (1) When the upper 4 bits of the received address are 0000 or 1111, the extension code reception flag (IICBnSTR0.IICBnSSEX bit) is set to 1 to indicate that an extension code has been received. The IICBn enters the wait state (IICBnTRG.IICBnSSWT = 1). The IICBnSTR0.IICBnSSDR bit is then set (to 1).
- (2) During address transfer, the acknowledge output can be controlled by setting the IICBnCTL0.IICBnLAC bit. (Note that an acknowledge is always output upon an address match, regardless of the setting of this bit, during address transfer for normal slave address reception.)
- (3) During transmission while the IICBnCTL0.IICBnSLWT bit is 0, exit the wait state by writing to the IICBnDAT register. During transmission while the IICBnSLWT bit is 1, or during reception, exit the wait state by writing 1 to the IICBnTRG.IICBnWRET bit.
- (4) At the falling edge of the 9th clock, if the IICBnSLWT bit is 1, the interrupt request signal (IICBTIA_n) is output and the IICBn enters the wait state (IICBnTRG.IICBnSSWT = 1). If the IICBnCTL0.IICBnSLWT bit is 0, the interrupt request signal (IICBTIA_n) is not output and the IICBn does not enter the wait state.
- (5) If the IICBn receives an extension code, it participates in communications even if the addresses do not match.

For example, to avoid operating the IICBn as a slave device after receiving an extension code, set the IICBnTRG.IICBnLRET bit to 1. The IICBn enters the standby state for the next communication.

20.8 Interrupt Request Signals

Caution In this section, the operation when an extension code is received is omitted. For details about the extension code, refer to 20.7.4 “*Extension code*”.


The IICBn has the data transmit/receive interrupt request signal (IICBTIA_n), which is a pulse of one PCLK clock width. The interrupt request signal is explained below.

20.8.1 Single transfer mode

The interrupt request signal timing in the single transfer mode is described below.

During the single transfer mode, for the IICBTIA_n interrupt request signal, whether to output an interrupt is judged based on the IICB_n state when the falling edge of SCL_n is detected during the bus cycle. Note, however, that whether to output an interrupt is judged based on the IICB_n state when a stop condition is detected at the $\Delta 4$ timing.

Table 20-22 Interrupt request signal output timing (single transfer mode)



Output timing	Description	Refer to:
$\Delta 1$	Upon detection of the falling edge of the 9th SCL _n during address transfer	1 "Interrupt request signal output conditions and output interrupt request signal during address transfer" on page 1118
$\Delta 2$	Upon detection of the falling edge of the 8th SCL _n during data transfer	2 "Interrupt request signal output conditions and interrupt request signals output during data transfer" on page 1119
$\Delta 3$	Upon detection of the falling edge of the 9th SCL _n during data transfer	2 "Interrupt request signal output conditions and interrupt request signals output during data transfer" on page 1119

Note

ST: Start condition
 AD6 to AD0: Address
 R/W: Transfer direction specification
 $\overline{\text{ACK}}$: Acknowledge
 D7 to D0: Data
 SP: Stop condition

(1) **Interrupt request signal output conditions and output interrupt request signal during address transfer**

$\Delta 1$ in Table 20-22 "Interrupt request signal output timing (single transfer mode)" indicates the interrupt request signal output timing during address transfer. Table 20-23 "Interrupt request signal output conditions and interrupt request signal output during address transfer (single transfer mode)" lists the interrupt request signal output conditions and the interrupt request signal output (IICBTIA_n) at the $\Delta 1$ timing.

Table 20-23 Interrupt request signal output conditions and interrupt request signal output during address transfer (single transfer mode)

IICB _n SSMS	IICB _n ALDF	IICB _n SLWT	IICB _n SSCO	$\Delta 1$		Remark
				Interrupt	Wait	
1	0	x	x	IICBTIA _n	Wait	-
1	1	x	x	This state does not exist.		-
0	0	x	1	IICBTIA _n	Wait	-
0	1	x	0	-	-	After arbitration loss, non-participation in communications
0	1	x	1	IICBTIA _n	Wait	-

Note x: don't care

(2) **Interrupt request signal output conditions and interrupt request signals output during data transfer**

$\Delta 2$ and $\Delta 3$ in Table 20-22 “Interrupt request signal output timing (single transfer mode)” indicate the interrupt request signal output timings during data transfer. The interrupt request signal output timing at $\Delta 2$ or $\Delta 3$ is determined by the setting of the IICBnCTL0.IICBnSLWT bit. Table 20-24 “Interrupt request signal output conditions and interrupt request signals output during address transfer (single transfer mode)” lists the interrupt request signal output conditions and the interrupt request signal (IICBTIA_n) output at the $\Delta 2$ and $\Delta 3$ timings.

Table 20-24 Interrupt request signal output conditions and interrupt request signals output during address transfer (single transfer mode)

IICBn SSMS	IICBn ALDF	IICBn SLWT	IICBn SSCO	$\Delta 2$		$\Delta 3$		Remark
				Interrupt	Wait	Interrupt	Wait	
1	0	0	x	IICBTIA _n	Wait	-	-	-
1	0	1	x	-	-	IICBTIA _n	Wait	-
1	1	x	x	This state does not exist.				-
0	0	x	0	-	-	-	-	Non-participation in communications
0	0	0	1	IICBTIA _n	Wait	-	-	-
0	0	1	1	-	-	IICBTIA _n	Wait	-
0	1	0	0	-	-	-	-	Non-participation in communications after arbitration loss
0	1	1	0	-	-	-	-	Non-participation in communications after arbitration loss
0	1	0	1	IICBTIA _n	Wait	-	-	-
0	1	1	1	-	-	IICBTIA _n	Wait	-

Note x: don't care

20.9 Interrupt Outputs and Statuses

This section describes the statuses of the IICBnSTR0 register during interrupt output by communication flow.


The meanings of the symbols used in the figures are as follows.

ST:	Start condition
AD6-AD0:	Address
R, \overline{W} , R/ \overline{W} :	Transfer direction specification
\overline{ACK} :	Acknowledge
NACK:	Not acknowledge
D7-D0:	Data
SP:	Stop condition

20.9.1 Single transfer mode (master device operation)

(1) Start ~ Address ~ Data ~ Data ~ Stop (normal transmission/reception)

<1> When IICBnCTL0.IICBnSLWT bit is 0



▲1: IICBnSTR0 register = 1-0100X1 0110--00B

▲2: IICBnSTR0 register = 1-0100X0 0100--00B


▲3: IICBnSTR0 register = 1-0100X0 0100--00B (IICBnSLWT bit = 1)

▲4: IICBnSTR0 register = 1-0100XX 0100--00B (IICBnTRG.IICBnSPT bit = 1)

Δ5: IICBnSTR0 register = 0-000000 0001--00B

Note ▲ Always output
 - Undefined
 X don't care

<2> When IICBnSLWT bit is 1



▲1: IICBnSTR0 register = 1-0100X1 0110--00B

▲2: IICBnSTR0 register = 1-0100X0 0100--00B


▲3: IICBnSTR0 register = 1-0100XX 0100--00B (IICBnSPT bit = 1)

Δ4: IICBnSTR0 register = 0-000000 0001--00B

Note ▲ Always output
 - Undefined
 X don't care

(2) Start ~ Address ~ Data ~ Start ~ Address ~ Data ~ Stop (restart)

<1> When IICBnSLWT bit is 0



▲1: IICBnSTR0 register = 1-0100X1 0110--00B

▲2: IICBnSTR0 register = 1-0100X0 0100--00B (IICBnSLWT bit = 1)

▲3: IICBnSTR0 register = 1-0100XX 0100--00B (IICBnTRG.IICBnSTT bit = 1, IICBnSLWT bit = 0)

▲4: IICBnSTR0 register = 1-0100X1 0110--00B


▲5: IICBnSTR0 register = 1-0100X0 0100--00B (IICBnSLWT bit = 1)

▲6: IICBnSTR0 register = 1-0100XX 0100--00B (IICBnSPT bit = 1)

△7: IICBnSTR0 register = 0-000000 0001--00B

Note ▲ Always output
 - Undefined
 X don't care

<2> When IICBnSLWT bit is 1



▲1: IICBnSTR0 register = 1-0100X1 0110--00B

▲2: IICBnSTR0 register = 1-0100XX 0100--00B (IICBnSTT bit = 1)

▲3: IICBnSTR0 register = 1-0100X1 0110--00B


▲4: IICBnSTR0 register = 1-0100XX 0100--00B (IICBnSPT bit = 1)

△5: IICBnSTR0 register = 0-000000 0001--00B

Note ▲ Always output
 - Undefined
 X don't care

(3) Start ~ ExCode ~ Data ~ Data ~ Stop (extension code transmission)

<1> When IICBnSLWT bit is 0



▲1: IICBnSTR0 register = 1-0110X1 0110--00B

▲2: IICBnSTR0 register = 1-0110X0 0100--00B


▲3: IICBnSTR0 register = 1-0110X0 0100--00B (IICBnSLWT bit = 1)

▲4: IICBnSTR0 register = 1-0110XX 0100--00B (IICBnSPT bit = 1)

Δ5: IICBnSTR0 register = 0-000000 0001--00B

Note ▲ Always output
 - Undefined
 X don't care

<2> When IICBnSLWT bit is 1



▲1: IICBnSTR0 register = 1-0110X1 0110--00B

▲2: IICBnSTR0 register = 1-0110X1 0100--00B

▲3: IICBnSTR0 register = 1-0110XX 0100--00B (IICBnSPT bit = 1)


Δ4: IICBnSTR0 register = 0-000000 0001--00B

Note ▲ Always output
 - Undefined
 X don't care

20.9.2 Single transfer mode (slave device operation: during slave address reception (IICBnSTR0.IICBnSSC0 bit = 1))

(1) Start ~ Address ~ Data ~ Data ~ Stop

<1> When IICBnCTL0.IICBnSLWT bit is 0



▲1: IICBnSTR0 register = 0-0101X1 0110--00B


▲2: IICBnSTR0 register = 0-0101X0 0100--00B

▲3: IICBnSTR0 register = 0-0101X0 0100--00B

△4: IICBnSTR0 register = 0-000000 0001--00B

Note ▲ Always output
 - Undefined
 X don't care

<2> When IICBnSLWT bit is 1



▲1: IICBnSTR0 register = 0-0101X1 0110--00B

▲2: IICBnSTR0 register = 0-0101X1 0100--00B

▲3: IICBnSTR0 register = 0-0101XX 0100--00B

△4: IICBnSTR0 register = 0-000000 0001--00B


Note ▲ Always output
 - Undefined
 X don't care

20.9.3 Single transfer mode (slave device operation: during extension code reception (IICBnSTR0.IICBnSSEX bit = 1))

The IICBn always participates in communications when it receives an extension code.

(1) Start ~ Code ~ Data ~ Data ~ Stop

<1> When IICBnCTL0.IICBnSLWT bit is 0



▲1: IICBnSTR0 register = 0-0110X0 0110--00B


▲2: IICBnSTR0 register = 0-0110X0 0100--00B

▲3: IICBnSTR0 register = 0-0110X0 0100--00B

Δ4: IICBnSTR0 register = 0-000000 0001--00B

Note ▲ Always output
 - Undefined
 X don't care

<2> When IICBnSLWT bit is 1



▲1: IICBnSTR0 register = 0-0110X0 0110--00B

▲2: IICBnSTR0 register = 0-0110X1 0110--00B

▲3: IICBnSTR0 register = 0-0110X0 0100--00B


▲4: IICBnSTR0 register = 0-0110XX 0100--00B

Δ5: IICBnSTR0 register = 0-000000 0001--00B

Note ▲ Always output
 - Undefined
 X don't care

20.9.4 Single transfer mode (non-participation in communications)

(1) Start ~ Code ~ Data ~ Data ~ Stop




20.9.5 Single transfer mode (arbitration loss operation (IICBnSTR0.IICBnALDF bit = 1): operation as slave after arbitration loss)

When the IICBn operates as a master in a multi-master system, read the IICSn.MSTSn bit to check the arbitration result each time the INTIICn interrupt is output.

(1) Address match after arbitration loss

<1> When IICBnCTL0.IICBnSLWT bit is 0



▲1: IICBnSTR0 register = 0-0101X1 0110--01B (IICBnSTRC.IICBnCLAF bit = 1)


▲2: IICBnSTR0 register = 0-0101X0 0100--00B

▲3: IICBnSTR0 register = 0-0101X0 0100--00B

△4: IICBnSTR0 register = 0-000000 0001--00B

Note ▲ Always output
- Undefined
X don't care

<2> When IICBnSLWT bit is 1



▲1: IICBnSTR0 register = 0-0101X1 0110--01B (IICBnCLAF bit = 1)

▲2: IICBnSTR0 register = 0-0101X1 0100--00B


▲3: IICBnSTR0 register = 0-0101XX 0100--00B

△4: IICBnSTR0 register = 0-000000 0001--00B

Note ▲ Always output
- Undefined
X don't care

(2) Upon extension code detection after arbitration loss

<1> When IICBnCTL0.IICBnSLWT bit is 0



▲1: IICBnSTR0 register = 0-0110X0 0110--01B (IICBnCLAF bit = 1)

▲2: IICBnSTR0 register = 0-0110X0 0100--00B


▲3: IICBnSTR0 register = 0-0110X0 0100--00B

△4: IICBnSTR0 register = 0-000000 0001--00B

Notes 1. ▲ Always output
- Undefined
X don't care

2.n = 0 to 5

<2> When IICBnSLWT bit is 1



▲1: IICBnSTR0 register = 0-0110X0 0110--01B (IICBnCLAF bit = 1)

▲2: IICBnSTR0 register = 0-0110X1 0110--00B

▲3: IICBnSTR0 register = 0-0110X0 0100--00B

▲4: IICBnSTR0 register = 0-0110XX 0100--00B


△5: IICBnSTR0 register = 0-000000 0001--00B

Note ▲ Always output
- Undefined
X don't care

20.9.6 Single transfer mode (arbitration loss operation (IICBnSTR0.IICBnALDF bit = 1): non-participation in communications after arbitration loss)


When the IICBn is used as a master in a multi-master system, read the IICSn.MSTSn bit to check the arbitration result each time the INTIICn interrupt is output.

(1) Arbitration loss during transmission of slave address



(2) Arbitration loss during data transfer

<1> When IICBnSLWT bit is 0




▲1: IICBnSTR0 register = 1-1000X1 0110--00B

▲2: IICBnSTR0 register = 0-0000X0 0100--01B (IICBnCLAF bit = 1)

△3: IICBnSTR0 register = 0-000000 0001--00B

Note ▲ Always output
 - Undefined
 X don't care

<2> When IICBnSLWT bit is 1



▲1: IICBnSTR0 register = 1-1000X1 0110--00B


▲2: IICBnSTR0 register = 0-0000X0 0100--01B (IICBnCLAF bit = 1)

△3: IICBnSTR0 register = 0-000000 0001--00B

Note ▲ Always output
 - Undefined
 X don't care

(3) Arbitration loss for the restart condition during data transfer

<1> When IICBnSLWT bit is 1 (extension code mismatch, address mismatch)




▲1: IICBnSTR0 register = 1-1000X1 0110--00B

▲2: IICBnSTR0 register = 0-0000X0 0100--01B (IICBnCLAF bit = 1)

▲3: IICBnSTR0 register = 0-000000 0001--00B

Note ▲ Always output
 - Undefined
 X don't care

(4) Arbitration loss for the stop condition during data transfer


▲1: IICBnSTR0 register = 1-1000X1 0110--00B

▲2: IICBnSTR0 register = 0-000000 0001--00B

Note ▲ Always output
 - Undefined
 X don't care

(5) Arbitration loss because the SDA_n signal is low level when attempting to output restart condition

<1> When IICBnSLWT bit is 0



▲1: IICBnSTR0 register = 1-1000X1 0110--00B

▲2: IICBnSTR0 register = 1-1000X0 0100--00B (IICBnSLWT bit = 1)


▲3: IICBnSTR0 register = 1-1000XX 0100--00B (IICBnSLWT bit = 0, IICBnTRG.IICBnSTT bit = 1)

▲4: IICBnSTR0 register = 0-0000X0 0100--01B (IICBnCLAF bit = 1)

△5: IICBnSTR0 register = 0-000000 0001--00B

Note ▲ Always output
 - Undefined
 X don't care

<2> When IICBnSLWT bit is 1



▲1: IICBnSTR0 register = 1-1000X1 0110--00B

▲2: IICBnSTR0 register = 1-1000XX 0100--00B (IICBnSLWT bit = 0, IICBnSTT bit = 1)


▲3: IICBnSTR0 register = 0-0000X0 0100--01B (IICBnCLAF bit = 1)

△4: IICBnSTR0 register = 0-000000 0001--00B

Note ▲ Always output
 - Undefined
 X don't care

(6) Arbitration loss for the stop condition when attempting to output restart condition

<1> When IICBnSLWT bit is 0



▲1: IICBnSTR0 register = 1-1000X1 0110--00B


▲2: IICBnSTR0 register = 1-1000X0 0100--00B (IICBnSLWT bit = 0)

▲3: IICBnSTR0 register = 1-0000XX 0100--00B (IICBnSTT bit = 1)

△4: IICBnSTR0 register = 0-000000 0001--01B

Note ▲ Always output
 - Undefined
 X don't care

<2> When IICBnSLWT bit is 1



▲1: IICBnSTR0 register = 1-1000X1 0110--00B


▲2: IICBnSTR0 register = 1-0000XX 0100--00B (IICBnSTT bit = 1)

△3: IICBnSTR0 register = 0-000000 0001--01B

Note ▲ Always output
 - Undefined
 X don't care

(7) Arbitration loss because the SDA_n signal is low level when attempting to output stop condition

<1> When IICBnSLWT bit is 0



▲1: IICBnSTR0 register = 1-1000X1 0110--00B

▲2: IICBnSTR0 register = 1-1000X0 0100--00B (IICBnSLWT bit = 1)


▲3: IICBnSTR0 register = 1-1000XX 0100--00B (IICBnSLWT bit = 0, IICBnTRG.IICBnSPT bit = 1)

▲4: IICBnSTR0 register = 0-0000XX 0100--01B (IICBnCLAF bit = 1)

△5: IICBnSTR0 register = 0-000000 0001--01B

Note ▲ Always output
 - Undefined
 X don't care

<2> When IICBnSLWT bit is 1



▲1: IICBnSTR0 register = 1-1000X1 0110--00B

▲2: IICBnSTR0 register = 1-1000XX 0100--00B (IICBnSPT bit = 1)

▲3: IICBnSTR0 register = 0-0000XX 0100--01B (IICBnCLAF bit = 1)


△4: IICBnSTR0 register = 0-000000 0001--01B

Note ▲ Always output
 - Undefined
 X don't care

20.9.7 Single transfer mode (arbitration loss operation (IICBnSTR0.IICBnALDF bit = 1): non-participation in communications after arbitration loss (during extension code transfer))

When the IICBn is used as a master in a multi-master system, read the IICSn.MSTSn bit to check the arbitration result each time the INTIICn interrupt is output.

(1) Arbitration loss during extension code transfer




▲1: IICBnSTR0 register = 0-1100X0 0110--01B (IICBnSTRC.IICBnCLAF bit = 1, IICBnTRG.IICBnLRET bit = 1)

△2: IICBnSTR0 register = 0-000000 0001--01B

Note ▲ Always output
 - Undefined
 X don't care

(2) Arbitration loss for the restart condition during data transfer (extension code match)



▲1: IICBnSTR0 register = 1-1000X1 0110--00B

▲2: IICBnSTR0 register = 0-1100X0 0100--01B (IICBnCLAF bit = 1, IICBnLRET bit = 1)

△3: IICBnSTR0 register = 0-000000 0001--01B

Note ▲ Always output
 - Undefined
 X don't care

20.10 Setting Sequence

20.10.1 Single master environment

(1) Master operate setting sequence during single transfer mode




Figure 20-13 Master operate setting sequence during single transfer mode (single master environment)

(2) Slave operate setting sequence during single transfer mode




Figure 20-14 Slave operate setting sequence during single transfer mode (single master environment)

Chapter 21 Key Return Function (KR)

This chapter contains a generic description of the Key Return Function.

The first section describes all properties specific to the V850E2/Fx4-G, such as instances, register base addresses, input/output signal names, etc. The subsequent sections describe the features that apply to all implementations.

21.1 V850E2/Fx4-G KR Features

Instances This microcontroller has following number of instances of the Key Return Function.

Table 21-1 Instances of KR

Key Return Function	
Instance	1
Name	KR0

Instances index n Throughout this chapter, the individual instances of a Key Return Function is identified by the index “n” (n = 0), for example KRnM for the Key Return mode register.

Register addresses All KRn register addresses are given as address offsets to the individual base address <KRn_base>. The base address <KRn_base> of each KRn is listed in the following table:

Table 21-2 Register base addresses <KRn_base>

KRn instance	<KRn_base> address
KR0	FF82 B000 _H

Clock supply All Key Return Functions provide one clock input:

Table 21-3 KRn clock supply

KRn instance	KRn clock	Connected to
KR0	PCLK	Clock Controller CKSCLK_A02




Figure 21-1 KR clock supply

Interrupts The Key Return Function can generate the following interrupt requests:

Table 21-4 KRn interrupt requests

KRn signals	Function	Connected to
KR0TIKR	Communication status interrupt	Interrupt Controller INTKR0 ^a

^{a)} This interrupt can be used as a wake-up source from any stand-by mode. Refer to the chapter “Stand-by Controller (STBC)” for details.

KRH/W reset The Key Return Function and their registers are initialized by the following reset signal:

Table 21-5 KRn reset signal

KRn	Reset signal
KR0	• Reset Controller SYSRES

I/O signals The I/O signals of the Key Return Function are listed in the following table.

Table 21-6 KRn I/O signals

KRn signal	Function	Connected to
KR0TPKR7 to KR0TPKR0	Key input signals	Ports KR0 ^a to KR7 ^a

^{a)} These input signals are passed through a noise filter, refer to the section “Port Filters” in the chapter “Port Functions”.

21.2 Functional Overview

Features summary The Key Return Function has the following feature:

A key interrupt request signal (KRnTIKR) can be generated by inputting a low level to any of the eight key input pins (KRnTPKR0 to KRnTPKR7).




Figure 21-2 Block diagram of the Key Return Function

21.3 Functional Description

21.3.1 Interrupt request KRnTIKR

The interrupt request KRnTIKR is generated when a low level is input to key input pin KRnTPKR[7:0] while input to pin KRnTPKR[7:0] is enabled (KR08nM.KR08nKRM[7:0] = 1).

The following figure shows the interrupt request generation:




Figure 21-3 Interrupt request generation

- Cautions**
1. If a low level is input to any key input KRnTPKR[7:0], KRnTIKR is not generated again, even if another key input changes from high to low level.
 2. An unintended key interrupt request KRnTIKR may occur under the following conditions:
 - KR08nM.KR08nKRM[7:0] = 1 and the key input KRnTPKR[7:0] level changes from high to low.
 - The key input KRnTPKR[7:0] level is low and KR08nM.KR08nKRM[7:0] is changed from 0 to 1.

Thus mask (i.e. disable) KRnTIKR in the Interrupt Controller before changing KR08nM.KR08nKRM[7:0] from 0 to 1 or vice versa.

21.4 Registers

This section contains a description of all registers of the Key Return Function.

21.4.1 Key Return Function registers overview

The Key Return Function is controlled and operated by the following registers:

Table 21-7 Key Return Function registers overview

Register name	Shortcut	Address
Key return mode register	KR08nM	<KRn_base>

<KRn_base> <KRn_base> of the KRn are defined in the first section of this chapter under the key word “Register addresses”.

21.4.2 Key Return Function registers details

(1) KR08nM - Key return mode register

This register enables/disables the key input signal detection.

Access This register can be read/written in 8-bit units.

Address <KRn_base>

Initial Value 00_H. This register is cleared by any reset.

7	6	5	4	3	2	1	0
KR08n KRM7	KR08n KRM6	KR08n KRM5	KR08n KRM4	KR08n KRM3	KR08n KRM2	KR08n KRM1	KR08n KRM0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 21-8 KR08nM register contents

Bit position	Bit name	Function
7 to 0	KR08n KRMm	Enables/disables the key input signal detection 0: Disabled 1: Enabled

Chapter 22 A/D Converter (ADAA)

This chapter contains a generic description of the A/D Converter.

The first section describes all properties specific to the V850E2/Fx4-G, such as instances, register base addresses, input/output signal names, etc. The subsequent sections describe the features that apply to all implementations.

22.1 V850E2/Fx4-G ADAA Features

Instances This microcontroller has following number of instances of the A/D Converter.

Table 22-1 Instances of ADAA

A/D Converter	
Instance	1
Name	ADAA0

Instances index n Throughout this chapter, the individual instances of the ADAA are identified by “n” (n = 0), for example ADAAn, or ADAAnCTL0 for the control register 0 of ADAAn.

Channel group index i The A/D Converter has 3 A/D conversion channel groups, abbreviated with CG. Throughout this chapter, the individual channel group is identified by the index “i” (i = 0 to 2), for example, ADAAnLOCi for the CGi interrupt controller register.

Channel index m Each A/D Converter has several A/D conversion channels. Throughout this chapter, the individual channels of each ADAA are identified by the index “m”, for example, ADAAnCmCR for the channel m conversion result register.

Table 22-2 ADAAn channel select indices m

ADAAn instance	V850E2/FF4-G	V850E2/FG4-G
ADAA0	m = 3 to 13	m = 0 to 15

Register addresses All ADAA register addresses are given as address offsets to the individual base address <ADAAn_base>. The base address <ADAAn_base> of each ADAAn is listed in the following table:

Table 22-3 Register base addresses <ADAAn_base>

ADAAn instance	<ADAAn_base> address
ADAA0	FF81 D000 _H

Clock supply All A/D Converters provide one clock input:

Table 22-4 ADAA_n clock supply

ADAA _n instance	ADAA _n clock	Connected to
ADAA0	PCLK	Clock Controller CKSCLK_012

Interrupts and DMA The A/D Converters can generate the following interrupt and DMA requests:

Table 22-5 ADAA_n interrupt and DMA requests

ADAA _n signals	Function	Connected to
ADAA0:		
INTADAA0T0	End of conversion CG0	Interrupt Controller INTADAA0I0 DMA Controller trigger 30
INTADAA0T1	End of conversion CG1	Interrupt Controller INTADAA0I1 DMA Controller trigger 31
INTADAA0T2	End of conversion CG2	Interrupt Controller INTADAA0I2 DMA Controller trigger 32
INTADAA0LLT	Last conversion	Interrupt Controller INTADAA0LLT ^a DMA Controller trigger 33
INTADAA0ERR	Error interrupt	Interrupt Controller INTADAA0ERR ^a

a) These interrupts can be used as a wake-up source from any stand-by mode. Refer to the chapter “Stand-by Controller (STBC)” for details.

ADAA H/W reset The A/D Converters and their registers are initialized by the following reset signal:

Table 22-6 ADAA_n reset signal

ADAA _n	Reset signal
ADAA0	<ul style="list-style-type: none"> Reset Controller SYSRES Stand-by Controller DPSTPWU (wake-up from DEEPSTOP mode)

I/O signals The I/O signals of the A/D Converters are listed in the following table.

Table 22-7 ADAAAn I/O signals

ADAAAn signal	Function	Connected to
ADAA0:		
ADAA0I0 to ADAA0I15	Analog input channels 0 to 15	Pins ADAA0I0 to ADAA0I15
ADAA0TTRGi	H/W trigger for CGi	H/W trigger expansion i, refer to the section " <i>H/W Trigger Expansion</i> " below
AVREFP	Positive reference voltage	Power supply A0VDD
AVREFM	Negative reference voltage	Power supply A0VSS

ADAA ports If the ports used as ADAAAn inputs shall be used as port inputs, set

- ADAA0CTL1.ADAA0GPS = 1 to use port groups P10 in port mode

22.2 H/W Trigger Expansion

All A/D Converter H/W trigger inputs ADAAnTTRGi are equipped with a H/W trigger expansion module that enables up to 16 signals ADAAnTTINi[15:00] to trigger an A/D conversion process.




Figure 22-1 H/W trigger expansion module

22.2.1 ADAAn H/W trigger selection

The selection of active H/W triggers is made via the ADAAn register ADAAnTSELi.ADAAnTiSEL[15:0] bits.

Caution It is only allowed to select a single H/W trigger for each ADAAn H/W trigger input ADAAnTTRGi. Thus do not set more than one bit of each ADAAnTSELi register to “1” at the same time.

22.2.2 ADAAn H/W trigger edge selection

The A/D conversion process of channel group *i* is started with the rising edge of the H/W triggers ADAAnTTRGi.

The rising edge has to be selection via the ADAAnCTL1 register:

- ADAAnCTL1.ADAAnTiETS0 = 0: no edge is selected, thus ADAAnTTRGi does not trigger an A/D conversion
- ADAAnCTL1.ADAAnTiETS0 = 1: rising edge is selected, thus rising edge of ADAAnTTRGi triggers an A/D conversion

(1) External A/D converter H/W triggers

ADAAnTRG[2:0] The rising edge of the external ADAAn H/W trigger signals ADAAnTRG[2:0] can start and A/D conversion, provided ADAAnCTL1.ADAAnTiETS0 = 1.

INTPx In case an external interrupt signal INTPx is used to start an A/D conversion, the edge of INTPx to trigger A/D conversion can be selected by the port filters:

Table 22-8 ADAAn H/W trigger edge selection for external interrupts INTPx

Control setup	Rising edge	Falling edge	Both edges
ADAAnCTL1.ADAAnTiETS0 =	1		
FCLAnCTLm.FCLAnINTLm =	0		
FCLAnCTLm.FCLAnINTFm =	0	1	1
FCLAnCTLm.FCLAnINTRm =	1	0	1

Note The index “x” stands for the number of the external interrupt signal. The index “m” denotes the number of the port control register, assigned to INTPx.

For further details about the port filters refer to the “*Port filters*” section in the chapter “Port Functions”.

22.2.3 ADAAn H/W trigger tables

The available ADAAn H/W triggers comprises

- external H/W triggers
- external interrupts
- output signals of Timer Array Units B
- output signals of Timer Array Units J

Table 22-9 ADAA0 H/W trigger signals (1/2)

ADAA0 channel group	Trigger input signals			ADAA0 trigger signal
	Name	Control bit	Connected to	
CG0	ADAA0TTIN000	ADAA0TSEL0.ADAA0T0SEL[00]	Port ADAA0TRG0 ^a	ADAA0TTRG0
	ADAA0TTIN001	ADAA0TSEL0.ADAA0T0SEL[01]	Port INTP2	
	ADAA0TTIN002	ADAA0TSEL0.ADAA0T0SEL[02]	Port INTP5	
	ADAA0TTIN003	ADAA0TSEL0.ADAA0T0SEL[03]	TAUB0 INTTAUB0I15	
	ADAA0TTIN004	ADAA0TSEL0.ADAA0T0SEL[04]	not connected	
	ADAA0TTIN005	ADAA0TSEL0.ADAA0T0SEL[05]	not connected	
	ADAA0TTIN006	ADAA0TSEL0.ADAA0T0SEL[06]	not connected	
	ADAA0TTIN007	ADAA0TSEL0.ADAA0T0SEL[07]	not connected	
	ADAA0TTIN008	ADAA0TSEL0.ADAA0T0SEL[08]	TAUJ0 INTTAUJ0I3	
	ADAA0TTIN009	ADAA0TSEL0.ADAA0T0SEL[09]	not connected	
	ADAA0TTIN010	ADAA0TSEL0.ADAA0T0SEL[10]	not connected	
	ADAA0TTIN011	ADAA0TSEL0.ADAA0T0SEL[11]	not connected	
	ADAA0TTIN012	ADAA0TSEL0.ADAA0T0SEL[12]	not connected	
	ADAA0TTIN013	ADAA0TSEL0.ADAA0T0SEL[13]	not connected	
	ADAA0TTIN014	ADAA0TSEL0.ADAA0T0SEL[14]	not connected	
	ADAA0TTIN015	ADAA0TSEL0.ADAA0T0SEL[15]	not connected	
CG1	ADAA0TTIN100	ADAA0TSEL1.ADAA0T1SEL[00]	Port ADAA0TRG1 ^a	ADAA0TTRG1
	ADAA0TTIN101	ADAA0TSEL1.ADAA0T1SEL[01]	Port INTP1	
	ADAA0TTIN102	ADAA0TSEL1.ADAA0T1SEL[02]	Port INTP4	
	ADAA0TTIN103	ADAA0TSEL1.ADAA0T1SEL[03]	TAUB0 INTTAUB0I15	
	ADAA0TTIN104	ADAA0TSEL1.ADAA0T1SEL[04]	not connected	
	ADAA0TTIN105	ADAA0TSEL1.ADAA0T1SEL[05]	not connected	
	ADAA0TTIN106	ADAA0TSEL1.ADAA0T1SEL[06]	not connected	
	ADAA0TTIN107	ADAA0TSEL1.ADAA0T1SEL[07]	not connected	
	ADAA0TTIN108	ADAA0TSEL1.ADAA0T1SEL[08]	TAUJ0 INTTAUJ0I3	
	ADAA0TTIN109	ADAA0TSEL1.ADAA0T1SEL[09]	not connected	
	ADAA0TTIN110	ADAA0TSEL1.ADAA0T1SEL[10]	not connected	
	ADAA0TTIN111	ADAA0TSEL1.ADAA0T1SEL[11]	not connected	
	ADAA0TTIN112	ADAA0TSEL1.ADAA0T1SEL[12]	not connected	
	ADAA0TTIN113	ADAA0TSEL1.ADAA0T1SEL[13]	not connected	
	ADAA0TTIN114	ADAA0TSEL1.ADAA0T1SEL[14]	not connected	
	ADAA0TTIN115	ADAA0TSEL1.ADAA0T1SEL[15]	not connected	

Table 22-9 ADAA0 H/W trigger signals (2/2)

ADAA0 channel group	Trigger input signals			ADAA0 trigger signal
	Name	Control bit	Connected to	
CG2	ADAA0TTIN200	ADAA0TSEL2.ADAA0T2SEL[00]	Port ADAA0TRG2 ^a	ADAA0TTRG2
	ADAA0TTIN201	ADAA0TSEL2.ADAA0T2SEL[01]	Port INTP0	
	ADAA0TTIN202	ADAA0TSEL2.ADAA0T2SEL[02]	Port INTP3	
	ADAA0TTIN203	ADAA0TSEL2.ADAA0T2SEL[03]	TAUB0 INTTAUB0I15	
	ADAA0TTIN204	ADAA0TSEL2.ADAA0T2SEL[04]	not connected	
	ADAA0TTIN205	ADAA0TSEL2.ADAA0T2SEL[05]	not connected	
	ADAA0TTIN206	ADAA0TSEL2.ADAA0T2SEL[06]	not connected	
	ADAA0TTIN207	ADAA0TSEL2.ADAA0T2SEL[07]	not connected	
	ADAA0TTIN208	ADAA0TSEL2.ADAA0T2SEL[08]	TAUJ0 INTTAUJ0I3	
	ADAA0TTIN209	ADAA0TSEL2.ADAA0T2SEL[09]	not connected	
	ADAA0TTIN210	ADAA0TSEL2.ADAA0T2SEL[10]	not connected	
	ADAA0TTIN211	ADAA0TSEL2.ADAA0T2SEL[11]	not connected	
	ADAA0TTIN212	ADAA0TSEL2.ADAA0T2SEL[12]	not connected	
	ADAA0TTIN213	ADAA0TSEL2.ADAA0T2SEL[13]	not connected	
	ADAA0TTIN214	ADAA0TSEL2.ADAA0T2SEL[14]	not connected	
	ADAA0TTIN215	ADAA0TSEL2.ADAA0T2SEL[15]	not connected	

^{a)} These input signals are passed through a noise filter, refer to the section "Port Filters" in the chapter "Port Functions".

22.3 Functional Overview

The A/D Converter (ADAA) converts analog input signals into digital values.

Features summary The ADAA has the following features:

- A/D conversion with 10-bit resolution
- A/D conversion based on successive approximation method
- A/D conversion of up to 16 analog input signals
The number of channels supported by this microcontroller is specified in the first section of this chapter under the key word "*Channel index m*".
- A/D conversion of up to 3 differently-prioritized groups of channels
- one-shot and continuous A/D conversion modes (continuous conversion mode for channel group CG0 only)
- channel repeat function (repeats conversion of each channel in a channel group 1 to 4 times)
- software and hardware start trigger modes
The hardware trigger source can be selected from multiple input signals.
- configurable terms for generation of end interrupts
- three types of result check functions
- discharge function for discharging the capacitor prior to executing conversion with a new sampling value
- self-diagnosis function to check correct ADAA operation

The following figure shows the main components of the ADAA.




Figure 22-2 Block diagram of the ADAA

22.4 Cautions

Caution Make sure that the voltages input to ADAAnIm do not exceed the rated values. If a voltage higher than AVDD or lower than AVSS is input to a channel, the conversion value of the channel is saturated, and the electrical characteristics of the other channels may also be affected.

For further information concerning the electrical characteristics refer to the Data Sheet.

22.5 Functional Description

A/D Converter resolution The A/D Converter A (ADAA) converts up to 16 analog input signals into digital values with a resolution of 10-bit.

Channels and channel groups Each of the input channels can be assigned to one of three channel groups CGi (i = 0 to 2). The list of the input channels assigned to each CG is called a scan list (including diagnostic A/D conversion of CG0). The scan lists can be set up easily with one register. The scan lists can also be changed during operation. All the A/D conversions for a scan list are called scan list conversion.

The ADAA supports up to 3 differently-prioritized channel groups and 2 conversion modes:

- Continuous conversion mode:
repeats conversion of all input channels of the channel group 0 (CG0) scan list.
- One-shot conversion:
executes conversion of all input channels of the channel group i (CGi) scan list conversion only once. In one-shot conversion mode, conversion of each channel in the scan list is repeated a selectable number of times (1 to 4 times).

A/D conversion The A/D conversion can be started using either software or hardware as the start trigger.

A multiplexer selects the channel to be converted and the Sample & Hold circuit holds the voltage input.

The A/D Converter uses the successive approximation method.

The successive approximation register (SAR) stores the D/A converter output voltage to be compared with the analog input voltage as a 10-bit digital value.

After each successful conversion the INTADAAnLLT signal is generated.

A/D conversion result registers	<p>When the A/D conversion is complete, the contents of the SAR register is stored in three registers allowing the conversion result</p> <ul style="list-style-type: none">• of all channels• of the last converted channel• of the last of a certain channel group <p>to be read continuously.</p> <p>Depending on the configuration, the ADAA generates a conversion end interrupt after the A/D conversion of certain channels and/or at the end of the A/D conversion of all channels of a channel group.</p>
Optional result check	<p>The results of A/D conversions can be checked with the following functions:</p> <ul style="list-style-type: none">• conversion result overwrite check function• conversion result upper/lower limit compare function
Optional discharge function	<p>If required, the internal capacitor of the Sample & Hold circuit can be discharged prior to every conversion.</p>
Self-diagnosis function	<p>By means of the A/D conversion circuit self-diagnosis function correct function of the ADAA can be checked.</p>
Configurable stabilization time	<p>By setting an arbitrary value to the stabilization counter, the optimum stabilization time can be secured after the power is switched on.</p>

22.5.1 Basic Operation

This section describes the basic procedure for an analog to digital conversion. More detailed descriptions are given in the following sections.

1. To optimize the startup time after power on and after standby mode is released, adjust the stabilization time by specifying the stabilization counter ADAAnCNT register.
2. Switch the power of the ADAA on by setting ADAAnCTL1.ADAAnGPS to 1.
3. Before you enable the A/D converter (ADAA must be disabled by ADAAnCTL0.ADAAnCE = 0), configure the ADAA clock, trigger mode, conversion mode, interrupt generation, channel groups, etc. in the following registers:
 - ADAAnCTL1
 - ADAAnCGi
 - ADAAnLOCi
 - ADAAnTSELi
4. If you want to check that the A/D conversion results are within a certain value range, enable the conversion result upper/lower limit compare function for the desired channels (ADAAnCTL2.ADAAnRCKm) and specify the lower and upper limits for the ADAAnLL and ADAAnUL registers.
5. If you want the capacitor of the Sample & Hold circuit to be discharged before sampling a new value, enable the discharge function by writing ADAAnCTL1.ADAAnDISC = 1.
6. Enable the A/D converter by setting ADAAnCTL0.ADAAnCE to 1. The A/D converter is ready for A/D conversion after the stabilization time has elapsed after power on or stand-by mode release.
7. Depending on the configured trigger mode, A/D conversion is started by a channel group related start trigger:
 - by a software trigger (ADAAnTRGi.ADAAnSTTi = 1), or
 - by a hardware trigger (input signal ADAAnTTRGi)If the A/D conversion starts for multiple CGs, the order of A/D conversion depends on the priority of the CGs.
8. The A/D conversion end interrupt INTADAAnTi is generated when the conversion of the channel set in the ADAAnLOCi register ends.
9. Read the results from the A/D conversion result registers ADAAnLCR, ADAAnDBiCR, and ADAAnCmCR.
10. Monitor the following registers:
 - ADAAnSTR1: To check whether the A/D conversion results have been overwritten before being read.
 - ADAAnSTR0: To check whether the A/D conversion results are within the configured range (only if the conversion result upper/lower limit compare function is enabled).
11. Disable the A/D converter if you want to reconfigure it. To do so, set ADAAnCTL0.ADAAnCE to 0.

22.5.2 Clock usage

The ADAA system clock ADAATCLK is the PCLK clock. Sampling and conversion times are selected via ADAAnCTL1.ADAAnFR[3:0].

22.5.3 Channels and channel groups

The input channels are configured as channel groups (CG). A scan list can be created for each CG through register settings, and also can be changed during operation. The conversion settings for a CG are applied to all the channels within that group.

The ADAA supports up to three channel groups (CG_i, where $i = 0$ to 2). The channels, i.e. the scan list, of each CG_i are specified with the ADAAnCG_i register.

Note The conversion of a single channel can be performed by assigning only one input channel to a CG.

(1) Order of A/D conversion

Upon occurrence of the start trigger for a CG, the channels set to its scan list are converted in ascending order, starting from CH00.

If A/D conversion requests for multiple CGs are pending, the CGs are converted in the following hierarchical order:

CG2 (highest priority) > CG1 > CG0 (lowest priority)

If the start trigger for a CG with a higher priority, or the trigger for ADCHALT mode is set, the current A/D conversion is halted.

One of the following two methods can be selected for halting A/D conversion, according to the setting of ADAAnCTL1.ADAAnTRMi.

- ADAAnCTL1.ADAAnTRMi = 0:
The A/D conversion of CG is interrupted immediately.
The A/D conversion of the interrupted channel is repeated after all pending A/D conversions of higher priority CGs have been finished.
- ADAAnCTL1.ADAAnTRMi = 1
The A/D conversion of the current channel is completed before the higher priority CG is converted.

When the A/D conversions of *all* higher priority CGs have been finished, the interrupted A/D conversion is continued from the next channel.

ADAAnSTR2.ADAAnST[2:0] indicates the current conversion status.

Examples The following figures illustrate the different types of conversion interruption; CH3, CH9, and CH12 are assigned to CG0, CH5 and CH9 are assigned to CG2.




Figure 22-3 Immediate interruption of A/D conversion of CG0 (ADAAAnCTL1.ADAAnTRM0 = 0)




Figure 22-4 Wait until A/D conversion of current channel has been completed (ADAAAnCTL1.ADAAnTRM0 = 1)

22.5.4 A/D conversion modes

The A/D converter provides the following A/D conversion modes.

Mode	Operation	Channel group
One-shot conversion mode (ADAAAnCTL1.ADAAnMD0 = 0)	Executes CGi scan list conversion only once. The channel of a scan list can be repeatedly converted a specified number of times (1 to 4 times, according to the setting of ADAAAnCTL0.SCTi[1:0]).	CG0, CG1, CG2
Continuous conversion mode (ADAAAnCTL1.ADAAnMD0 = 1)	Executes scan list conversion repeatedly.	CG0

- Notes**
1. A running A/D conversion is interrupted by an A/D conversion request for a higher priority CG and then is automatically continued when all requests of higher priority CGs have been finished (see 1 “Order of A/D conversion” on page 1155).
 2. CG1 and CG2 operate in one-shot conversion mode regardless of the conversion mode setting in ADAAAnCTL1.ADAAnMD0.

(1) One-shot conversion mode

In one-shot conversion mode, CGi scan list conversion is executed upon a start trigger. The number of times each channel of a scan list is repeatedly converted, can be specified for each CG from 1 to 4, by specifying ADAAAnCTL0.ADAAnSCTi[1:0].




Figure 22-5 2 times repetition of channel conversion in one-shot conversion mode

(a) Start Trigger for the same CG before end of conversion

The A/D converter can hold one trigger for starting another conversion prior to the end of conversion of the same CG. Therefore, A/D conversion is performed continuously if one or more subsequent start triggers are input (the second and subsequent start triggers are ignored) before the A/D conversion for the CG_i started by the first start trigger ends.




Figure 22-6 Start Trigger for the same CG before end of conversion

(b) Start Trigger for a different CG before end of conversion

Start triggers for lower priority CGs during conversion of a higher priority CG are ignored, i.e.

- CG0 start trigger is ignored during CG1 or CG2 conversion
- CG1 start trigger is ignored during CG2 conversion

Reversely, a start trigger for a higher priority CG during conversion of a lower priority CG is held.

A start trigger for a lower priority CG that was input before the start of conversion of a high priority CG is held. When no start trigger is generated, a start-before-conversion-end trigger is accepted even during the conversion of a high priority CG.

- CG2 start trigger is held during CG0 or CG1 conversion
- CG1 start trigger is held during CG0 conversion

During conversion, start triggers before end of conversion for a lower priority CG are ignored.

Reversely, a start trigger before end of conversion for a lower priority CG that was input before the start of conversion of a high priority CG is held. When no start trigger is generated, a start-before-conversion-end trigger is accepted even during the conversion of a high priority CG.

Depending on the ADAAnCTL1.ADAAnTRM0 setting, conversion of the higher priority CG is launched immediately ((ADAAnTRM0 = 0) or after completion of the lower priority CG conversion (ADAAnTRM0 = 1).

Refer also to 22.5.3 "Channels and channel groups" on page 1155 .




Figure 22-7 Start Trigger for a different CG before end of conversion (ADAAAnCTL1.ADAAnTRM0 = 0)

(2) Continuous conversion mode

Continuous conversion mode can be used only for CG0 (ADAAAnCTL1.ADAAnMD0 = 1).

In continuous conversion mode, a start trigger causes the channels of CG0 to be sampled and converted repeatedly until a stop trigger is generated or another stop condition occurs (refer to 22.5.6 “Stopping A/D conversion” on page 1162).




Figure 22-8 Continuous conversion mode

Caution After a stop trigger, the state becomes idle and sampling/conversion cannot be performed.

Note Additional start triggers for CG0 are ignored in continuous conversion mode.

22.5.5 Starting A/D conversion (start trigger modes)

A/D conversion can be started by a software or a hardware trigger, as specified by ADAAnCTL1.ADAAnMD1.

If A/D conversion is started for multiple CGs, the conversion order depends on the priority of the CGs (refer to 1 “Order of A/D conversion” on page 1155).

- Notes**
1. If no channels are assigned to the CGi scan list (ADAAnCGi = 0000 0000_H), start triggers for that CGi are ignored.
 2. In one-shot conversion mode, the A/D converter can hold only one start trigger. Additional start triggers are ignored (refer to Figure 22-6 “Start Trigger for the same CG before end of conversion” on page 1158).
 3. In continuous conversion mode, additional start triggers before a stop trigger has been generated, are ignored.

(1) Software start trigger

The A/D conversion of CGi is started by setting ADAAnTRGi.ADAAnSTTi = 1, provided that the A/D converter is enabled (ADAAnCTL0.ADAAnCE = 1).

Timing example of software start trigger

The following figure shows the timing of a software start trigger.




Figure 22-9 Software start trigger timing example

1. Software trigger for CGi is written.
2. A/D conversion starts at the next falling edge of ADAATCLK. The status bit ADAAnSTR2.ADAAnSTi is set, indicating that A/D conversion of CGi is running.

(2) Hardware start trigger

The A/D conversion of CGi is started upon detection of the valid edge of the ADAAnTTRGi signal, provided that the A/D converter is enabled (ADAAnCTL0.ADAAnCE = 1) and hardware trigger mode is set (ADAAnCTL1.ADAAnMD1 = 1).

The valid edge is specified in ADAAnCTL1.ADAAnTiETS[1:0] for every CG individually.

H/W trigger expansion If this microcontroller supports a hardware trigger expansion, up to 16 hardware trigger sources can be specified for each ADAAnTTRGi signal input. ADAAnTSELi specifies the input signals to be used as the ADAAnTTRGi signal.

Note For details about the hardware start trigger function expansion refer to “H/W trigger expansion” in the second section of this chapter.

Timing of hardware start trigger The A/D converter starts A/D conversion upon detection of the valid edge of the ADAAnTTRGi signal.

The following figure shows the timing of a hardware start trigger with the following condition:

- Valid edge of ADAAnTTRGi is rising edge (ADAAnCTL1.ADAAnTiETS[1:0] = 01_B)




Figure 22-10 Hardware start trigger timing

- Input signal ADAAnTTRGi rises.
- A/D conversion starts at the next falling edge of ADAATCLK.

22.5.6 Stopping A/D conversion

(1) Stop trigger

Setting the stop trigger bit for CGi to 1 ($ADAAnTRG4+i.ADAAnSPi = 1$) stops the A/D conversion for the CGi.

If the stop trigger is generated before the A/D conversion ends, the A/D conversion end interrupt signal $INTADAAnTi$ is not generated and the A/D conversion result register is not updated.

If the start trigger is generated again after the A/D conversion is stopped by a stop trigger, scan list conversion is executed from the beginning.

Follow the stop trigger procedure below when using the hardware start trigger.

1. Stop hardware start trigger generation.
2. Set the stop trigger bit ($ADAAnTRG4+i.ADAAnSPi = 1$).
3. Check the status of $ADAAnSTR2.ADAAnSTi$.

If the above procedure is not followed, the hardware start trigger and the stop trigger may conflict with each other and A/D conversion may not stop.

Timing of stop trigger

1. Stop trigger for CGi is written.
2. A/D conversion of CGi stops at the next falling edge of $ADAATCLK$. The status bit $ADAAnSTR2.ADAAnSTi$ is cleared, indicating that A/D conversion of CGi is stopped. If the digital value of $ADAAnIm$ is already available, the operation is as follows:
 - All A/D conversion result registers are updated.
 - The conversion end interrupt $INTADAAnTi$ is generated as configured in $ADAAnIOCi$ (refer to 22.5.10 "Interrupt generation" on page 1166).
 - If configured in $ADAAnCTL2$, the A/D conversion result is checked to see whether it is in the specified value range (refer to 22.5.12 "Result check functions" on page 1169).

The A/D converter proceeds with pending A/D conversion requests of other CGs - if there are any.

The following figures show the timing of a stop trigger with the following condition:

- The A/D conversion end interrupt $INTADAAnTi$ is generated at the end of the A/D conversion of CGi ($ADAAnIOCi = 0000\ 0000_H$)




Figure 22-11 Stop trigger timing, if generated before A/D conversion end

1. The stop trigger (ADAAnTRG4+i.ADAAnSPi) is set to 1.
2. The status bit (ADAAnSTR2.ADAAnSTi) is cleared.
The A/D conversion end interrupt (INTADAAnTi) is not generated and the A/D conversion result register is not updated.




Figure 22-12 Stop trigger timing, if generated after A/D conversion end

1. The stop trigger (ADAAnTRG4+i.ADAAnSPi) is set to 1.
2. The status bit (ADAAnSTR2.ADAAnSTi) is cleared.
The A/D conversion end interrupt (INTADAAnTi) is generated and the A/D conversion result register is updated.

(2) Other stop conditions

In addition to the software stop trigger, A/D conversion is stopped when the A/D converter is disabled (ADAAAnCTL0.ADAAnCE = 0).

With ADAAAnCTL0.ADAAnCE = 0 conversions are stopped immediately and no A/D conversion results are stored in the conversion result registers.

22.5.7 Stand-by mode

Stand-by mode is entered, when the related system stand-by mode becomes active.

The A/D converter is automatically disabled (ADAAAnCTL1.ADAAnCE = 0).

To leave stand-by mode:

1. Release related system stand-by mode.
2. Enable the A/D converter by setting ADAAAnCTL1.ADAAnCE to 1.

Note After stand-by mode is released, a start trigger is accepted but conversion does not start until the stabilization time elapses (stabilization counter ADAAAnCNT = 00_H).

Refer to 22.5.15 "Stabilization control" on page 1173 for details.

22.5.8 Pausing and resuming A/D conversion (ADCHALT mode)

The A/D Converter allows the A/D conversion (of all CGs) to be paused/halted. The halted A/D conversion can be continued with a resume trigger.

Procedure:

1. Set ADAAAnTRG3 = 1 to go into ADCHALT mode (refer to 1 "Order of A/D conversion" on page 1155 for details about the halt operation).
 - Start triggers are ignored in ADCHALT mode.
 - The internal circuits are stopped and the power consumption is reduced.
 - The analog input pins ADAAnIm can be used for other functions in ADCHALT mode.
2. Set ADAAAnTRG7.ADAAnSP3 = 1 to release ADCHALT mode and start A/D conversion.

Note ADCHALT has the highest priority and overrules all CGi conversions.

22.5.9 Resolution, sampling and conversion times

The total conversion time comprises sampling time and A/D conversion time.




Figure 22-13 Total conversion time

The sampling time is the time of connecting an analog input voltage to the Sample & Hold circuit. The A/D conversion time is the time required to obtain one digital value out of an analog input voltage.

While the A/D conversion time takes 25 PCLK clock cycles, the sampling time - and thus the total conversion time - depends on the setting of ADAAnCTL1.ADAAnFR[3:0]:

Table 22-10 Sampling and conversion times (discharge function disabled)

ADAAnCTL1.ADAAnFR[3:0]	A/D conversion time [PCLK clocks]	Sampling time [PCLK clocks]	Total conversion time [PCLK clocks]
0000 _B	25	13	38
0001 _B	25	20	45
0020 _B	25	26	51
0011 _B	25	33	58
0100 _B	25	39	64
0110 _B	25	52	77
1000 _B	25	65	90
1010 _B	25	78	103
1100 _B	25	91	116
1110 _B	25	104	129

Discharge function Using the discharge function (ADAAnCTL1.ADAAnDISC = 1) increases the total conversion time by 7 PCLK cycle. Refer to 22.5.14 “Discharge function” on page 1173 for details.

22.5.10 Interrupt generation

(1) A/D conversion end interrupt INTADAAAnTi

The INTADAAAnTi interrupt indicates that the new A/D conversion result is saved to the conversion result register.

An A/D conversion end interrupt is generated upon completion of the A/D conversion for any channel of CGi specified in the ADAAnIOCi register.

If nothing else is configured (ADAAnIOCi = 0000 0000_H), INTADAAAnTi is generated at the end of the A/D conversion of CGi.




Figure 22-14 Generation of A/D conversion end interrupt INTADAAAnTi

- Notes**
1. ADAAnIOCi can be written at any time even when the A/D converter is enabled (ADAAnCTL0.ADAAnCE = 1). The new value takes effect after the current A/D conversion of CGi has been completed.
 2. ADAAnIOCi is associated with ADAAnCGi and their buffer registers should be updated simultaneously. As the update time depends on writing ADAAnCGi, always write ADAAnIOCi before ADAAnCGi if you want to change the interrupt generation for a CG.

(2) Error interrupt INTADAAAnERR

The interrupt INTADAAAnERR is generated in the following cases:

- The result of the A/D conversion of a specified channel is out of the specified range, when the conversion result upper/lower limit compare function is enabled.
- An A/D conversion result in ADAAnLcR, ADAAnDBiCR, or ADAAnCmCR has been overwritten before it was read.
The generation of the INTADAAAnERR error interrupt upon register overwrite can be controlled for each register by setting ADAAnCTL0.ADAAnOEM[4:0].

Refer to 22.5.12 "Result check functions" on page 1169 for details.

(3) Last conversion interrupt INTADAAAnLLT

The interrupt INTADAAAnLLT is generated after each successful conversion.

22.5.11 Storage of A/D conversion result

(1) A/D conversion result registers

The A/D conversion result is stored in the following registers:

- ADAAnLCR register
This register stores the latest A/D conversion result.
- ADAAnDBiCR register
This register stores the latest A/D conversion result for CGi.
- ADAAnCmCR register
This register stores the latest A/D conversion results for channel m.

Each register also stores status flags of the A/D conversion result (see 22.5.12 “Result check functions” on page 1169).




Figure 22-15 Storage of A/D conversion result

(2) Configuration related to A/D conversion result storage

Bit position	ADAAAnCTL1.ADAAnCRAC specifies whether the 10-bit A/D conversion result is right aligned (ADAAAnCRAC = 0) or left aligned (ADAAAnCRAC = 1).
Read & clear function	ADAAAnCTL1.ADAAnRCL specifies whether the A/D conversion result ADAAAnCmCR is retained after reading it or cleared by reading it.

(3) Relationship between analog input voltage and A/D conversion result

The relationship between the analog input voltage input to the analog input pin (ADAAAnIm) and the A/D conversion results (the values ADAAAnLCR[15:00], ADAAAnCmCR[15:00], and ADAAAnDBiCR[15:00]) is expressed as follows:

$$\text{A/D conversion result value} = \text{INT}\left(\frac{V_{\text{IAN}} - AV_{\text{REFM}}}{AV_{\text{REFP}} - AV_{\text{REFM}}} \times 2^k + 0.5\right)$$

or

$$(\text{A/D conversion result} - 0.5) \times \frac{AV_{\text{REFP}} - AV_{\text{REFM}}}{2^k} \leq V_{\text{IAN}} - AV_{\text{REFM}} < (\text{A/D conversion result} + 0.5) \times \frac{AV_{\text{REFP}} - AV_{\text{REFM}}}{2^k}$$

INT():	Function that returns the integer part of the value in parentheses
V_{IAN} :	Analog input voltage
AV_{REFP} :	AVREFP pin voltage
AV_{REFM} :	AVREFM pin voltage
A/D conversion result:	Values of the ADAAAnLCR[15:00], ADAAAnCmCR[15:00], and ADAAAnDBiCR[15:00] bits
$k = 10$:	Resolution: 10 bit

The figure below shows the relationship between the analog input voltage and A/D conversion result.




Figure 22-16 Conversion characteristics of 10-bit A/D converter (ADAAAnCTL1.ADAAnCTYP = 1)

22.5.12 Result check functions

ADAA allows checking of the A/D conversion result with the following functions:

- Conversion result overwrite check function
- Conversion result read flag function
- Conversion result upper/lower limit compare function

(1) Conversion result overwrite check function

The ADAA allows to check if an A/D conversion result has been overwritten before it was read.

Error flags The A/D conversion result registers have the following overwrite error flags:

- ADAAnLCR.ADAAnLER1
- ADAAnDBiCR.ADAAnDBiER1
- ADAAnCmCR.ADAAnCmER1

Setting of the overwrite error flag indicates, that the conversion result stored in the respective register was overwritten before it is read.

The overwrite flag ADAAnCmCR.ADAAnCmER1 is reflected in ADAAnSTR1.ADAAnOWEm, which holds overwrite flags for all channels.

Error interrupt If the A/D conversion results in the ADAAnLCR, ADAAnDBiCR, and ADAAnCmCR registers are overwritten before they were read, an error interrupt INTADAAnERR is generated.

Generation of an INTADAAnERR interrupt can be masked separately for each for each conversion result register type, so that the interrupt does not become effective:

Table 22-11 Overwrite error interrupt masking

Result register	Mask bit in ADAAnCTL0
ADAAnLCR	ADAAnOEM4
ADAAnDB2CR	ADAAnOME3
ADAAnDB1CR	ADAAnOEM2
ADAAnDB0CR	ADAAnOEM1
ADAAnCmCR	ADAAnOEM0

If a mask bit is set to 1, the interrupt is not effective.

Note Interrupt generation for conversion result registers that are not to be read shall be masked by setting the appropriate ADAAnCTL0.ADAAnOEM[4:0] = 1.

(2) Conversion result read flag function

An update status flag indicates whether the A/D conversion result in the conversion result register has already been read or is a new one.

Status flags The update status flags are provided in the A/D conversion result registers:

- ADAAnLCR.ADAAnLUR
- ADAAnDBiCR.ADAAnDBiUR
- ADAAnCmCR.ADAAnCmUR

If an update status flag is set to 1, the A/D conversion result is new.

The update status flags are cleared after they are read.

(3) Conversion result upper/lower limit compare function

The ADAA can check whether an A/D conversion results lies within a configurable value range.

The result check function can be enabled for every channel individually in ADAAnCTL2.

When enabled, the A/D conversion result ADAAnCmCR is compared with the specified lower limit (ADAAnLL) and upper limit (ADAAnUL), each time the channel results is converted respectively updated.

Error flags If the A/D conversion result of a specified channel is either lower than the lower limit value ADAAnLL or higher than the upper limit value ADAAnUL, the ADAAnSTR0.ADAAnRCE[15:00] error flag corresponding to that channel is set.

ADAAnSTR0 indicates the error status of the latest A/D conversion upper/lower limit check for every channel. By use of this register it is possible to evaluating which A/D conversion results are outside the specified range.

The result check error flag is also mirrored by the A/D conversion result registers ADAAnLCR, ADAAnDBiCR, and ADAAnCmCR.

The result check error flags ADAAnSTR0.ADAAnRCE[15:00] are reflected in ADAAnCmCR.ADAAnCmER0 of the respective channel.

Error interrupt If the A/D conversion result for the specified channel is out of the setting range, the INTADAAAnERR error interrupt is generated.

22.5.13 Self-diagnosis function

The self-diagnosis function can be used to verify that the ADAA works properly.

The diagnosis of the A/D conversion circuit can be performed during normal A/D conversion. Following the end of A/D conversion of CG0, the reference voltage signal ADDIAGOUT is converted. If this diagnosis A/D conversion result differs greatly from the expected value, a hardware anomaly or a malfunction may occur.

The diagnostic A/D conversion is enabled by $ADAAAnCG0.ADAAnDIAG = 1$.

Note The A/D conversion circuit diagnosis is available for CG0 only.

The diagnostic A/D conversion is started after the A/D conversion of the last channel of CG0 has been completed:

- The A/D conversion results of CG0 are stored in the “normal” A/D conversion result registers (refer to *1 “A/D conversion result registers” on page 1167*).
- The result of the diagnostic A/D conversion is stored in ADAAnDGCR.

Diagnosis procedure

1. Switch the power of the ADAA on by setting $ADAAAnCTL1.ADAAnGPS = 1$.
2. Configure CG0 and the A/D conversion as follows:
 - Ensure that $ADAAAnCG0.ADAAnDIAG$ is set to 1 to enable the diagnostic A/D conversion of the reference voltage.
For example, write $8000\ 0007_H$ to first convert the analog input voltages of CH0, CH1, and CH2, and then the reference voltage ADDIAGOUT for diagnostic purposes.
 - Set $ADAAAnI0C0.ADAAnCG0IDG = 1$ to generate the A/D conversion end interrupt INTADAAAnT0 on finishing the diagnostic A/D conversion.
3. Specify the reference voltage signal ADDIAGOUT via $ADAAAnDGCTL0.ADAAnPSEL$.
For example, set $ADAAAnDGCTL0.ADAAnPSEL = 1$ to apply AVDD as the reference voltage ADDIAGOUT.
4. Enable the ADAA by setting $ADAAAnCTL0.ADAAnCE = 1$.
5. Generate software or hardware start triggers to start the A/D conversion.
6. When the A/D conversion end interrupt INTADAAAnT0 is generated, read the A/D conversion results of the diagnostic A/D conversion in ADAAnDGCR.

ADDIAGOUT change $ADAAAnDGCTL0.ADAAnPSEL$ can be written - and thus the reference voltage can be changed - even during A/D conversion, as shown in the diagram below.




Figure 22-17 ADDIAGOUT change during A/D conversion

The value set with ADAAAnDGCTL0.ADAAnPSEL is applied upon completion of the conversion of the current channel. Therefore, set the reference voltage of the next diagnosis A/D conversion before that diagnosis A/D conversion starts.

22.5.14 Discharge function

If required, the internal capacitor of the common Sample & Hold circuit can be discharged prior to every conversion. This ensures that the capacitor is always empty before the new sample value is stored.

Note Using the discharge function increases the total conversion time by 7 PCLK clock cycles (see 22.5.9 “Resolution, sampling and conversion times” on page 1165).

Configuration The discharge function is enabled by setting ADAAnCTL1.ADAAnDISC to 1.




Figure 22-18 Timing when discharge function is enabled

22.5.15 Stabilization control

The A/D converter needs time for stabilization purposes in the following cases:

- The A/D converter has been switched on (ADAAnCTL1.ADAAnGPS = 1)
- The stand-by mode has been terminated.

A start trigger is accepted during the stabilization time, but the conversion does not start before the stabilization time has elapsed.

In order to secure the minimum stabilization time, the stabilization time counter ADAAnCNT must be set (refer to the Data Sheet).

22.6 Registers

This section contains a description of all the registers of the ADAA.

22.6.1 ADAA registers overview

The ADAA is controlled and operated by the registers in the following table.

- Where there is one register per channel, this is indicated by an “m”. The number “m” of available channels are specified in the first section of this chapter under the key word “Channel index m”.
- Where there is one register per CG, this is indicated by an “i” (i = 0 to 2).

Table 22-12 ADAA registers overview (1/2)

Register name	Shortcut	Address
Control registers		
A/D converter mode control register 0	ADAAAnCTL0	<ADAAAn_base> + 100 _H
A/D converter mode control register 1	ADAAAnCTL1	<ADAAAn_base> + 104 _H
A/D converter CG register i	ADAAAnCGi	<ADAAAn_base> + i × 4 _H
A/D converter interrupt control register i	ADAAAnIOCi	<ADAAAn_base> + C _H + i × 4 _H
A/D converter trigger select control register i	ADAAAnTSELi	<ADAAAn_base> + 108 _H + i × 4 _H
A/D converter stabilization counter	ADAAAnCNT	<ADAAAn_base> + 114 _H
Conversion status registers		
A/D converter overwrite error flag register	ADAAAnSTR1	<ADAAAn_base> + 28 _H
ADAAAnSTR1 flag clear register	ADAAAnSTC1	<ADAAAn_base> + 34 _H
A/D converter status flag register 2	ADAAAnSTR2	<ADAAAn_base> + 2C _H
ADAAAnSTR2 flag clear register	ADAAAnSTC2	<ADAAAn_base> + 38 _H
S/W trigger registers		
A/D converter S/W trigger register i	ADAAAnTRGi	<ADAAAn_base> + A4 _H + i × 4 _H
A/D converter S/W trigger register 3	ADAAAnTRG3	<ADAAAn_base> + B0 _H
A/D converter S/W trigger register 4+i	ADAAAnTRG4 + i	<ADAAAn_base> + B4 _H + i × 4 _H
A/D converter S/W trigger register 7	ADAAAnTRG7	<ADAAAn_base> + C0 _H
A/D conversion result registers		
A/D converter latest conversion result register	ADAAAnLCR	<ADAAAn_base> + A0 _H
A/D converter conversion result register m	ADAAAnCmCR	<ADAAAn_base> + 3C _H + m × 4 _H
A/D converter CGi buffer register i	ADAAAnDBiCR	<ADAAAn_base> + C4 _H + i × 4 _H
A/D converter CGi buffer result register i	ADAAAnDBiCRL	<ADAAAn_base> + D0 _H + i × 4 _H
Diagnostic conversion result register	ADAAAnDGCR	<ADAAAn_base> + 9C _H
A/D conversion result upper/lower limit comparison registers		
A/D converter result check register	ADAAAnCTL2	<ADAAAn_base> + 18 _H
A/D converter result check (upper limit)	ADAAAnUL	<ADAAAn_base> + 1C _H
A/D converter result check (lower limit)	ADAAAnLL	<ADAAAn_base> + 20 _H
A/D converter result check error flag	ADAAAnSTR0	<ADAAAn_base> + 24 _H
ADAAAnSTR0 flag clear register	ADAAAnSTC0	<ADAAAn_base> + 30 _H

Table 22-12 ADAA registers overview (2/2)

Register name	Shortcut	Address
Diagnose functions control registers		
Self-diagnosis function control register 0	ADAAAnDGCTL0	<ADAAAn_base> + DC _H
Emulation register		
Emulation register	ADAAAnEMU	<ADAAAn_base> + 128 _H

<ADAAAn_base> The base addresses <ADAAAn_base> of the ADAAAn is defined in the first section of this chapter under the key word "Register addresses".

22.6.2 Control registers details

(1) ADAAnCTL0 – A/D converter mode control register 0

This register enables/disables the A/D converter. Additionally, it specifies the number of repetitions for one-shot conversion mode, and also whether to generate an error interrupt request if the A/D conversion result is overwritten before it is read.

Access This register can be read/written in 16-bit units.

Address <ADAAn_base> + 100_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	ADAAn OEM4	ADAAn OEM3	ADAAn OEM2	ADAAn OEM1	ADAAn OEM0	ADAAn CE	0	ADAAn SCT2[1:0]	ADAAn SCT1[1:0]	ADAAn SCT0[1:0]			
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 22-13 ADAAnCTL0 register contents (1/2)

Bit position	Bit name	Function
12	ADAAn OEM4	Specifies whether to generate the INTADAAnERR error interrupt when an A/D conversion result is overwritten in ADAAnLCR before it was read. 0: generate INTADAAnERR if the A/D conversion result is overwritten 1: do not generate INTADAAnERR Refer to 22.5.12 "Result check functions" on page 1169 for details.
11	ADAAn OEM3	Specifies whether to generate the INTADAAnERR error interrupt when an A/D conversion result is overwritten in ADAAnDB2CR before it was read. 0: generate INTADAAnERR if the A/D conversion result is overwritten 1: do not generate INTADAAnERR Refer to 22.5.12 "Result check functions" on page 1169 for details.
10	ADAAn OEM2	Specifies whether to generate the INTADAAnERR error interrupt when an A/D conversion result is overwritten in ADAAnDB1CR before it was read. 0: generate INTADAAnERR if the A/D conversion result is overwritten 1: do not generate INTADAAnERR Refer to 22.5.12 "Result check functions" on page 1169 for details.
9	ADAAn OEM1	Specifies whether to generate the INTADAAnERR error interrupt when an A/D conversion result is overwritten in ADAAnDB0CR before it was read. 0: generate INTADAAnERR if the A/D conversion result is overwritten 1: do not generate INTADAAnERR Refer to 22.5.12 "Result check functions" on page 1169 for details.
8	ADAAn OEM0	Specifies whether to generate the INTADAAnERR error interrupt when an A/D conversion result is overwritten in ADAAnCmCR before it was read. 0: generate INTADAAnERR if the A/D conversion result is overwritten 1: do not generate INTADAAnERR Refer to 22.5.12 "Result check functions" on page 1169 for details.
7	ADAAn CE	This bit enables/disables the A/D converter. 0: disable A/D converter 1: enable A/D converter Note that A/D conversion only starts on hardware trigger or software trigger, when ADAAnCTL0.ADAAnCE = 1. Note also that the A/D converter needs time to stabilize after it has been enabled. A start trigger is accepted even immediately after power-on. After the values of the stabilization counter ADAAnCNT changes to 00 _H , the A/D conversion starts.

Table 22-13 ADAA_nCTL0 register contents (2/2)

Bit position	Bit name	Function															
5 to 4	ADAA _n SCT2[1:0]	Number of conversion repetitions of each channel of CG2 in one-shot conversion mode. <table border="1"> <thead> <tr> <th>ADAA_n SCT21</th> <th>ADAA_n SCT20</th> <th>Number of conversion repetitions of each channel of CG2</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>1</td> </tr> <tr> <td>0</td> <td>1</td> <td>2</td> </tr> <tr> <td>1</td> <td>0</td> <td>3</td> </tr> <tr> <td>1</td> <td>1</td> <td>4</td> </tr> </tbody> </table>	ADAA _n SCT21	ADAA _n SCT20	Number of conversion repetitions of each channel of CG2	0	0	1	0	1	2	1	0	3	1	1	4
ADAA _n SCT21	ADAA _n SCT20	Number of conversion repetitions of each channel of CG2															
0	0	1															
0	1	2															
1	0	3															
1	1	4															
3 to 2	ADAA _n SCT1[1:0]	Number of conversion repetitions of each channel of CG1 in one-shot conversion mode. <table border="1"> <thead> <tr> <th>ADAA_n SCT11</th> <th>ADAA_n SCT10</th> <th>Number of conversion repetitions of each channel of CG1</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>1</td> </tr> <tr> <td>0</td> <td>1</td> <td>2</td> </tr> <tr> <td>1</td> <td>0</td> <td>3</td> </tr> <tr> <td>1</td> <td>1</td> <td>4</td> </tr> </tbody> </table>	ADAA _n SCT11	ADAA _n SCT10	Number of conversion repetitions of each channel of CG1	0	0	1	0	1	2	1	0	3	1	1	4
ADAA _n SCT11	ADAA _n SCT10	Number of conversion repetitions of each channel of CG1															
0	0	1															
0	1	2															
1	0	3															
1	1	4															
1 to 0	ADAA _n SCT0[1:0]	Number of conversion repetitions of each channel of CG0 in one-shot conversion mode. <table border="1"> <thead> <tr> <th>ADAA_n SCT01</th> <th>ADAA_n SCT00</th> <th>Number of conversion repetitions of each channel of CG0</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>1</td> </tr> <tr> <td>0</td> <td>1</td> <td>2</td> </tr> <tr> <td>1</td> <td>0</td> <td>3</td> </tr> <tr> <td>1</td> <td>1</td> <td>4</td> </tr> </tbody> </table>	ADAA _n SCT01	ADAA _n SCT00	Number of conversion repetitions of each channel of CG0	0	0	1	0	1	2	1	0	3	1	1	4
ADAA _n SCT01	ADAA _n SCT00	Number of conversion repetitions of each channel of CG0															
0	0	1															
0	1	2															
1	0	3															
1	1	4															

(2) ADAAnCTL1 – A/D converter mode control register 1

This register specifies the conversion mode and controls the conversion operations.

Access This register can be read/written in 32-bit units.

Address <ADAAn_base> + 104_H

Initial Value 0100 0000_H

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	ADAAn T2ETS0	0	ADAAn T1ETS0	0	ADAAn T0ETS0	0	ADAAn CRAC	0	0	ADAAn MD1	ADAAn MD0	0	0	ADAAn DISC	ADAAn RCL
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0		ADAAn FR[3:0]		0	ADAAn TRM2	ADAAn TRM1	ADAAn TRM0	0	0	0	ADAAn GPS	
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 22-14 ADAAnCTL1 register contents (1/3)

Bit position	Bit name	Function
31	ADAAn T2ETS0	Specifies the valid edge of the H/W trigger ADAAnTTRGi. 0: no edge selected (no trigger accepted) 1: rising edge selected For further information refer to the section “H/W trigger expansion” in this chapter.
29	ADAAn T1ETS0	
27	ADAAn T0ETS0	
24	ADAAn CRAC	Specifies the alignment of the A/D and diagnosis conversion result: 0: right-aligned 1: left-aligned
21	ADAAn MD1	Specifies the A/D conversion start trigger for all CGs. 0: software trigger 1: hardware trigger and software trigger This configuration is valid for all CGs. The A/D converter only detects triggers when the A/D converter is enabled. Refer to 22.5.5 “Starting A/D conversion (start trigger modes)” on page 1160 for details.
20	ADAAn MD0	Specifies the A/D conversion mode for CG0: 0: one-shot conversion mode Number of repetitions of scan list conversion is configured in ADAAnCTL0.ADAAnSCTi[1:0] for each CG individually. 1: continuous conversion mode This configuration applies to the A/D conversion of CG0 only. CG1 and CG2 are always operated in one-shot conversion mode. Refer to 22.5.4 “A/D conversion modes” on page 1157 for details.
17	ADAAn DISC	Enables/disables the discharge function: 0: disable 1: enable Refer to 22.5.14 “Discharge function” on page 1173 for details.
16	ADAAn RCL	Specifies whether the A/D conversion results ADAAnCmCR and ADAAnDBiCR are retained after they are read. 0: A/D conversion results are retained until they are overwritten by the next A/D conversion results 1: A/D conversion results are cleared after they are read

Table 22-14 ADAAnCTL1 register contents (2/3)

Bit position	Bit name	Function																								
11 to 8	ADAAnFR[3:0]	<p>Specifies the ADAA total conversion time. Refer to the section 22.5.9 “Resolution, sampling and conversion times” for details.</p> <table border="1"> <thead> <tr> <th>ADAAnFR[3:0]</th> <th>Total conversion time [PCLK clocks] (discharge disabled)</th> </tr> </thead> <tbody> <tr> <td>0000_B</td> <td>38</td> </tr> <tr> <td>0001_B</td> <td>45</td> </tr> <tr> <td>0010_B</td> <td>51</td> </tr> <tr> <td>0011_B</td> <td>58</td> </tr> <tr> <td>0100_B</td> <td>64</td> </tr> <tr> <td>0110_B</td> <td>77</td> </tr> <tr> <td>1000_B</td> <td>90</td> </tr> <tr> <td>1010_B</td> <td>103</td> </tr> <tr> <td>1100_B</td> <td>116</td> </tr> <tr> <td>1110_B</td> <td>129</td> </tr> <tr> <td>all others</td> <td>setting prohibited</td> </tr> </tbody> </table> <p>Note: Enabling the discharge function adds 7 PCLK clock cycles to the total conversion time.</p>	ADAAnFR[3:0]	Total conversion time [PCLK clocks] (discharge disabled)	0000 _B	38	0001 _B	45	0010 _B	51	0011 _B	58	0100 _B	64	0110 _B	77	1000 _B	90	1010 _B	103	1100 _B	116	1110 _B	129	all others	setting prohibited
ADAAnFR[3:0]	Total conversion time [PCLK clocks] (discharge disabled)																									
0000 _B	38																									
0001 _B	45																									
0010 _B	51																									
0011 _B	58																									
0100 _B	64																									
0110 _B	77																									
1000 _B	90																									
1010 _B	103																									
1100 _B	116																									
1110 _B	129																									
all others	setting prohibited																									
6	ADAAnTRM2	<p>Specifies the behaviour of CG2 conversion when transition to ADCHALT mode is requested.^a</p> <p>0: Halt the current A/D conversion of CG2 immediately, and enter ADCHALT mode.</p> <p>1: Finish conversion of the currently converted channel of CG2, halt A/D conversion of CG2, and enter ADCHALT mode.</p> <p>A/D conversion of CG2 is continued as soon as ADCHALT mode has been terminated.</p>																								

Table 22-14 ADAAnCTL1 register contents (3/3)

Bit position	Bit name	Function
5	ADAAn TRM1	Specifies the behaviour of CG1 conversion when a start trigger for a CG2 A/D conversion occurs or when transition to ADCHALT mode is requested. ^a 0: Halt the current A/D conversion of CG1 immediately, and start the A/D conversion of CG2 or enter ADCHALT mode respectively. 1: Finish conversion of the currently converted channel of CG1, halt A/D conversion of CG1, and start the A/D conversion of CG2 or enter ADCHALT mode respectively. A/D conversion of CG1 is continued as soon as all pending A/D conversions of CG2 have been completed or the ADCHALT mode has been terminated.
4	ADAAn TRM0	Specifies the behaviour of CG0 conversion when a start trigger for a CG1 or CG2 A/D conversion occurs or when transition to ADCHALT mode is requested. ^a 0: Halt the current A/D conversion of CG0 immediately, and start the A/D conversion of CG2 or CG1 or enter ADCHALT mode respectively. 1: Finish conversion of the currently converted channel of CG0, halt A/D conversion of CG0, and start the A/D conversion of CG2 or CG1 or enter ADCHALT mode respectively. A/D conversion of CG0 is continued as soon as all pending A/D conversions of CG2 or CG1 have been completed or the ADCHALT mode has been terminated.
0	ADAAn GPS	Switches the power of the ADAA off/on: 0: power off 1: power on The A/D converter needs a stabilization time after A/D power on (see 22.5.15 “Stabilization control” on page 1173).

^{a)} The behaviour follows the priority scheme: ADCHALT > CG2 > CG1 > CG0. Refer to 1 “Order of A/D conversion” on page 7 for details.

(3) ADAAnCGi – A/D converter channel group register i

This register creates the scan list for each CG. The channels set to the scan list of CGi are converted in ascending order, i.e. starting from the lowest channel number.

For details, refer to 22.5.3 “Channels and channel groups” on page 1155 .

Diagnosis conversion Additionally the diagnosis A/D conversion channel can be added to the CG0 scan list via the ADAAnCG0 register.
For details, refer to 22.5.13 “Self-diagnosis function” on page 1171 .

Access This register can be read/written in 32-bit units.
It can be written at any time even when the A/D converter is enabled (ADAAnCTL0.ADAAnCE = 1). The new value takes effect after the current A/D conversion of CGi has been completed.

- When CGi is not currently undergoing A/D conversion, the new value becomes effective immediately.
- When CGi is currently undergoing A/D conversion, the new value becomes effective upon completion of the scan list conversion of CGi currently being executed.
- When the stop trigger bit (ADAAnTRG4+i.ADAAnSPi) of CGi is set, the new value becomes effective when A/D conversion is stopped.

Address <ADAAn_base> + i x 4_H

Initial Value 0000 0000_H

ADAAnCG0:

	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
ADAAn DIAG	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	ADAAnCG0S[15:00]															
	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

ADAAnCG1:

	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	ADAAnCG1S[15:00]															
	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

ADAAAnCG2:

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
ADAAAnCG2S[15:00]															
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 22-15 ADAAAnCGi register contents

Bit position	Bit name	Function
31	ADAAAn DIAG	Enables/disables the diagnostic A/D conversion of the reference voltage ADDIAGOUT at the end of the A/D conversion of CG0: 0: disable A/D conversion of ADDIAGOUT 1: convert ADDIAGOUT This bit is only available in ADAAAnCG0. Refer to 22.5.13 "Self-diagnosis function" on page 1171 for details.
15 to 00	ADAAAn CGiS[15:00]	Specifies the analog inputs to be converted for CGi: 0: do not convert analog input ADAAAnIm 1: convert analog input ADAAAnIm

Note It is possible to assign a channel to multiple channel groups.

(4) ADAAnIOCi – A/D converter interrupt control register i

The A/D conversion end interrupt INTADAAnTi can be generated when the A/D conversion of a certain channel has been completed.

This register specifies the channel in each CGi scan list, for which INTADAAnTi is generated on A/D conversion completion.

If ADAAnIOCi = 0000 0000_H, INTADAAnTi is automatically generated at the completion of A/D conversion of CGi scan list.

Access This register can be read/written in 32-bit units.
The new value takes effect after the current A/D conversion of CGi has been completed.

Address <ADAAn_base> + 0C_H + i × 4_H

Initial Value 0000 0000_H

ADAAnIOC0:

	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
ADAAn CG0 IDG	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
ADAAnCG0I[15:00]																
	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

ADAAnIOC1:

	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
ADAAnCG1I[15:00]																
	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

ADAAnIOC2:

	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
ADAAnCG2I[15:00]																
	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 22-16 ADAAnIOCi register contents

Bit position	Bit name	Function
31	ADAAnCG0IDG	Specifies whether INTADAAnT0 is generated on completion of the A/D conversion of the reference voltage when the diagnostic mode is enabled for CG0 (ADAAnCG0.ADAAnDIAG = 1): 0: do not generate INTADAAnT0 1: generate INTADAAnT0 This bit is only available in ADAAnIOC0. Refer to 22.5.13 "Self-diagnosis function" on page 1171 for details.
15 to 00	ADAAnCGiI[15:00]	Specifies whether the interrupt INTADAAnTi is generated on A/D conversion completion of channel m: 0: Do not generate INTADAAnTi 1: Generate INTADAAnTi Note: ADAAnCGiI bits, which are assigned to not available channels, must be set to 0.

Note As the ADAAnIOCi register is associated with the ADAAnCGi register, their buffer registers must be updated simultaneously. As the update time depends on writing ADAAnCGi, always write ADAAnIOCi before ADAAnCGi if you want to change the interrupt generation for a CG.

(5) ADAAnCNT – A/D converter stabilization counter

This register specifies the stabilization time.

Access This register can be read/written in 8-bit units.

Address <ADAAn_base> + 114_H

Initial Value 00_H




Table 22-17 ADAAnCNT register contents

Bit position	Bit name	Function
7 to 0	ADAAnCNT[7:0]	Specifies the stabilization counter: Stabilization time = ADAAnCNT[7:0] * PCLK clock cycles

(6) ADAAnTSELi – A/D converter trigger select control register i

This register specifies the input signals to be used in combination with hardware start trigger signals ADAAnTTRGi.

Access This register can be read/written in 16-bit units.
It can only be written when the A/D converter is disabled
(ADAAnCTL0.ADAAnCE = 0).

Address <ADAAn_base> + 108_H + i × 4_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
ADAAnTiSEL[15:00]															
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 22-18 ADAAnTSELi register contents

Bit position	Bit name	Function
15 to 0	ADAAnTiSEL[15:00]	Specifies whether the corresponding input signal is to be used as hardware start trigger 0: do not use as hardware start trigger 1: use as hardware start trigger

Note For details about the hardware start trigger function expansion refer to “H/W trigger expansion” in the first section of this chapter.

22.6.3 Conversion status registers

(1) ADAAnSTR1 – A/D converter overwrite error flag register

This register indicates for every channel whether the latest A/D conversion result has been overwritten before it was read.

Access This register can be read in 32-bit units.

Address <ADAAn_base> + 28_H

Initial Value 0000 0000_H

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
ADAAnOWE[15:00]															
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Table 22-19 ADAAnSTR1 register contents

Bit position	Bit name	Function
15 to 0	ADAAnOWE[15:00]	Indicates whether the A/D conversion result of channel m has been overwritten before it was read: 0: not overwritten 1: overwritten This error flag is cleared by setting ADAAnSTR1.ADAAnOWECm to 1. All flags are also cleared by enabling and disabling the ADAA (ADAAn.ADAAnCE= 0 and then ADAAn.ADAAnCE= 1).

Note ADAAnSTR1.ADAAnOWEm is mirrored by the following overwrite error flags:

- Error flag in register with the latest A/D conversion result of CHm (ADAAnCmCR.ADAAnCmER1)

(2) ADAAnSTC1 – ADAAnSTR1 flag clear register

This register is the clear control register of ADAAnSTR1.

Access This register can be written in 32-bit units.

Address <ADAAn_base> + 34_H

Initial Value Reading this register returns always 0000 0000_H.

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
W	W	W	W	W	W	W	W	W	W	W	W	W	W	W	W
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
ADAAnOWEC[15:00]															
W	W	W	W	W	W	W	W	W	W	W	W	W	W	W	W

Table 22-20 ADAAnSTC1 register contents

Bit position	Bit name	Function
15 to 0	ADAAnOWEC[15:00]	Clear overwrite error flags in ADAAnSTR1: 0: no function 1: clears the corresponding ADAAnSTR1.ADAAnOWEm

(3) ADAAnSTR2 – A/D converter status flag register 2

This register indicates the current conversion status.

Access This register can be read in 16-bit units.

Address <ADAAn_base> + 2C_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	ADAAn RQT3	ADAAn RQ2	ADAAn RQ1	ADAAn RQ0	0	0	0	0	ADAAn ST3	ADAAn ST2	ADAAn ST1	ADAAn ST0
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Table 22-21 ADAAnSTR2 register contents

Bit position	Bit name	Function
11	ADAAn RQ3	Indicates whether a ADCHALT request is pending: 0: ADCHALT request is not pending 1: ADCHALT request is pending
10	ADAAn RQ2	Indicates whether A/D conversion request for CG2 is pending: 0: A/D conversion request for CG2 is not pending 1: A/D conversion request for CG2 is pending
9	ADAAn RQ1	Indicates whether A/D conversion request for CG1 is pending: 0: A/D conversion request for CG1 is not pending 1: A/D conversion request for CG1 is pending
8	ADAAn RQ0	Indicates whether A/D conversion request for CG0 is pending: 0: A/D conversion request for CG0 is not pending 1: A/D conversion request for CG0 is pending
3	ADAAn ST3	Indicates whether the A/D conversion is currently in the ADCHALT state due to a software trigger (ADAAnTRG3.ADAAnSTT3). 0: not in ADCHALT state 1: in ADCHALT state This bit is cleared when the A/D converter is disabled (ADAAnCTL0.ADAAnCE = 0).
2	ADAAn ST2	Indicates whether A/D conversion of CG2 is currently performed: 0: A/D conversion is not currently performed 1: A/D conversion is currently performed This bit is cleared when the A/D converter is disabled (ADAAnCTL0.ADAAnCE = 0).
1	ADAAn ST1	Indicates whether A/D conversion of CG1 is currently performed: 0: A/D conversion is not currently performed (including halt caused by A/D conversion of CG with higher priority) 1: A/D conversion is currently performed This bit is cleared when the A/D converter is disabled (ADAAnCTL0.ADAAnCE = 0).
0	ADAAn ST0	Indicates whether A/D conversion of CG0 is currently performed: 0: A/D conversion is not currently performed (including halt caused by A/D conversion of CG with higher priority) 1: A/D conversion is currently performed This bit is cleared when the A/D converter is disabled (ADAAnCTL0.ADAAnCE = 0).

(4) ADAAnSTC2 – A/D converter status flag clear register 2

This register is used to clear the overwrite and result check status flags of ADAAnLCR and ADAAnDBiCR.

Access This register can be written in 8-bit units.

Address <ADAAn_base> + 38_H

Initial Value Reading this register returns always 00_H.

7	6	5	4	3	2	1	0
ADAAn LERC1	ADAAn LERC0	ADAAn DB2ERC1	ADAAn DB2ERC0	ADAAn DB1ERC1	ADAAn DB1ERC0	ADAAn DB0ERC1	ADAAn DB0ERC0
W	W	W	W	W	W	W	W

Table 22-22 ADAAnSTC2 register contents

Bit position	Bit name	Function
7	ADAAn LERC1	Clears the overwrite flag ADAAnLCR.ADAAnLER1: 0: no function 1: ADAAnLCR.ADAAnLER1 is cleared
6	ADAAn LERC0	Clears the result check error flag ADAAnLCR.ADAAnLER0: 0: no function 1: ADAAnLCR.ADAAnLER0 is cleared
5, 3, 1	ADAAn DBiERC1	Clears the overwrite flag ADAAnDBiCR.ADAAnDBiER1: 0: no function 1: ADAAnDBiCR.ADAAnDBiER1 is cleared
4, 2, 0	ADAAn DBiERC0	Clears the result check error flag ADAAnDBiCR.ADAAnDBiER0: 0: no function 1: ADAAnDBiCR.ADAAnDBiER0 is cleared

22.6.4 S/W trigger registers details

(1) ADAAnTRGi – A/D converter software trigger register i

This register is the trigger register to *start* the A/D conversion of CGi.

Access This register can be written in 8-bit units.

Address <ADAAn_base> + A4_H + i × 4_H

Initial Value Reading this register returns always 00_H.

7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	ADAAn STTi
W	W	W	W	W	W	W	W

Table 22-23 ADAAnTRGi register contents

Bit position	Bit name	Function
0	ADAAn STTi	Starts the A/D conversion of CGi: 0: no function 1: starts A/D conversion of CGi

Refer to 22.5.5 “Starting A/D conversion (start trigger modes)” on page 1160 for details.

(2) ADAAnTRG3 – A/D converter software trigger register 3

This register is the trigger register for transition to ADCHALT mode.

Access This register can be written in 8-bit units.

Address <ADAAn_base> + B0_H

Initial Value Reading this register returns always 00_H.

7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	ADAAn STT3
W	W	W	W	W	W	W	W

Table 22-24 ADAAnTRG3 register contents

Bit position	Bit name	Function
0	ADAAn STT3	0: no function 1: transition to ADCHALT mode

Refer to 22.5.8 “Pausing and resuming A/D conversion (ADCHALT mode)” on page 1164 for details.

(3) ADAAnTRG4+i – A/D converter S/W trigger register 4+i

This register is the software trigger register to *stop* the A/D conversion of CGi.

Access This register can be written in 8-bit units.

Address <ADAAn_base> + B4_H + i × 4_H

Initial Value Reading this register returns always 00_H.

7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	ADAAn SPi
W	W	W	W	W	W	W	W

Table 22-25 ADAAnTRG4 + i register contents

Bit position	Bit name	Function
0	ADAAn SPi	0: no function 1: stops the A/D conversion of CGi

Refer to 22.5.6 “Stopping A/D conversion” on page 1162 for details.

Note If a H/W start trigger for CGi occurs simultaneously with a CGI A/D conversion stop by ADAAnTRG4+i, the H/W start trigger has higher priority.

(4) ADAAnTRG7 – A/D converter S/W trigger register 7

This register is the S/W trigger register to resume the A/D conversion after a ADCHALT.

Access This register can be written in 8-bit units.

Address <ADAAn_base> + C0_H

Initial Value Reading this register returns always 00_H.

7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	ADAAn SP3
W	W	W	W	W	W	W	W

Table 22-26 ADAAnTRG7 register contents

Bit position	Bit name	Function
0	ADAAn SP3	0: no function 1: resume A/D conversion

Refer to 22.5.8 “Pausing and resuming A/D conversion (ADCHALT mode)” on page 1164 for details.

22.6.5 ADAA conversion result registers details

(1) ADAAnLCR – A/D converter latest conversion result register

This register stores the result and the status of the latest A/D conversion.

Access This register can be read in 32-bit units.

- The upper 16 bits store the A/D conversion result status.
- The lower 16 bits store the A/D conversion result.

Address <ADAAn_base> + A0_H

Initial Value 0000 0000_H

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	ADAAn LCG[1:0]	ADAAn LER1	ADAAn LER0	ADAAn LUR	ADAAn LCN[4:0]					
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
ADAAnLCR[15:00]															
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Table 22-27 ADAAnLCR register contents (1/2)

Bit position	Bit name	Function															
25 to 24	ADAAn LCG[1:0]	Indicates the CG to which the result in ADAAnLCR[15:00] belongs. <table border="1"> <thead> <tr> <th>ADAAn LCG1</th><th>ADAAn LCG0</th><th>Channel group</th></tr> </thead> <tbody> <tr> <td>0</td><td>0</td><td>CG0</td></tr> <tr> <td>0</td><td>1</td><td>CG1</td></tr> <tr> <td>1</td><td>0</td><td>CG2</td></tr> <tr> <td>1</td><td>1</td><td>None</td></tr> </tbody> </table>	ADAAn LCG1	ADAAn LCG0	Channel group	0	0	CG0	0	1	CG1	1	0	CG2	1	1	None
ADAAn LCG1	ADAAn LCG0	Channel group															
0	0	CG0															
0	1	CG1															
1	0	CG2															
1	1	None															
23	ADAAn LER1	Indicates the overwrite error status. 0: not overwritten 1: overwritten This error flag is cleared when ADAAnSTC2.ADAAnLERC1 is set to 1.															
22	ADAAn LER0	Indicates the A/D conversion result upper/lower limit comparison status. 0: The conversion result is within the setting range. 1: The conversion result is out of the setting range. This error flag is cleared when ADAAnSTC2.ADAAnLERC0 is set to 1.															
21	ADAAn LUR	Indicates the update status of the A/D conversion result. 0: The A/D conversion result has been read from the ADAAnLCR register. 1: 1: The A/D conversion result is new and has not been read from ADAAnLCR yet. This bit is cleared after the read operation.															
20 to 16	ADAAn LCN[4:0]	Indicates the channel number corresponding to the conversion result stored in the ADAAnLCR[15:00]. 00000 = CH0 00001 = CH1 ... = ... 01111 = CH15															

Table 22-27 ADAAnLCR register contents (2/2)

Bit position	Bit name	Function									
15 to 0	ADAAnLCR[15:00]	Result of the A/D conversion. The alignment is determined by ADAAnCTL1.ADAAnCRAC, as follows. <table border="1" data-bbox="555 360 1385 533"> <thead> <tr> <th>ADAAnCRAC</th> <th>Alignment</th> <th>Bit positions of A/D conversion result</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>right-aligned</td> <td>ADAAnLCR[09:00]</td> </tr> <tr> <td>1</td> <td>left-aligned</td> <td>ADAAnLCR[15:06]</td> </tr> </tbody> </table>	ADAAnCRAC	Alignment	Bit positions of A/D conversion result	0	right-aligned	ADAAnLCR[09:00]	1	left-aligned	ADAAnLCR[15:06]
ADAAnCRAC	Alignment	Bit positions of A/D conversion result									
0	right-aligned	ADAAnLCR[09:00]									
1	left-aligned	ADAAnLCR[15:06]									

Note If A/D conversion is performed using the internal reference voltage, the A/D conversion result is stored in ADAAnDGCR, not in the ADAAnLCR, ADAAnCmCR, and ADAAnDBiCR.

(2) ADAAnCmCR – A/D converter conversion result register for channel m

This register stores the result and the status of the latest A/D conversion of channel m.

Access This register can be read in 32-bit units.

- The upper 16 bits store the A/D conversion result status.
- The lower 16 bits store the A/D conversion result.

Address <ADAAn_base> + 3C_H + m × 4_H

Initial Value 0300 0000_H + m × 0001 0000_H

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	ADAAn CmCG[1:0]	ADAAn CmER1	ADAAn CmER0	ADAAn CmUR	ADAAn CmCN[4:0]					
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
ADAAnCmCR[15:00]															
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

- Notes**
1. The functions of the individual bits are identical to those of the ADAAnLCR register, except that each of the m registers hold the latest result for the specific channel m rather than the latest A/D conversion result for any channel.
 2. If ADAAnCTL1.ADAAnRCL = 0, the A/D conversion result in ADAAnCmCR[15:00] is kept until it is overwritten by the next A/D conversion result.
If ADAAnCTL1.ADAAnRCL = 1, ADAAnCmCR[15:00] is cleared by reading it.

Table 22-28 ADAAnCmCR register contents (1/2)

Bit position	Bit name	Function															
25 to 24	ADAAn CmCG[1:0]	Indicates the CG to which the result in ADAAnCmCR[15:00] belongs. <table border="1"> <thead> <tr> <th>ADAAn CmCG1</th><th>ADAAn CmCG0</th><th>Channel group</th></tr> </thead> <tbody> <tr> <td>0</td><td>0</td><td>CG0</td></tr> <tr> <td>0</td><td>1</td><td>CG1</td></tr> <tr> <td>1</td><td>0</td><td>CG2</td></tr> <tr> <td>1</td><td>1</td><td>None</td></tr> </tbody> </table>	ADAAn CmCG1	ADAAn CmCG0	Channel group	0	0	CG0	0	1	CG1	1	0	CG2	1	1	None
ADAAn CmCG1	ADAAn CmCG0	Channel group															
0	0	CG0															
0	1	CG1															
1	0	CG2															
1	1	None															
23	ADAAn CmER1	Indicates the overwrite error status. 0: not overwritten 1: overwritten This error flag reflects the value of ADAAnSTR1.ADAAnOWEm. It is cleared when ADAAnSTC1.ADAAnQWECm is set to 1.															
22	ADAAn CmER0	Indicates the A/D conversion result upper/lower limit comparison status. 0: The conversion result is within the setting range. 1: The conversion result is out of the setting range. This error flag reflects the value of ADAAnSTR0.ADAAnRCEm. It is cleared when ADAAnSTC0.ADAAnRCEcm is set to 1.															

Table 22-28 ADAAnCmCR register contents (2/2)

Bit position	Bit name	Function									
21	ADAAnCmUR	Indicates the update status of the A/D conversion result. 0: The A/D conversion result has been read from the ADAAnCmCR register. 1: 1: The A/D conversion result is new and has not been read from ADAAnCmCR yet. This bit is cleared after the read operation.									
20 to 16	ADAAnCmCN[4:0]	Indicates the channel number corresponding to the conversion result stored in the ADAAnCmCR[15:00]. 00000 = CH0 00001 = CH1 ... = ... 01111 = CH15									
15 to 0	ADAAnCmCR[15:00]	Result of the A/D conversion. The alignment is determined by ADAAnCTL1.ADAAnCRAC, as follows. <table border="1" data-bbox="555 707 1385 882"> <thead> <tr> <th>ADAAnCRAC</th> <th>Alignment</th> <th>Bit positions of A/D conversion result</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>right-aligned</td> <td>ADAAnCmCR[09:00]</td> </tr> <tr> <td>1</td> <td>left-aligned</td> <td>ADAAnCmCR[15:06]</td> </tr> </tbody> </table>	ADAAnCRAC	Alignment	Bit positions of A/D conversion result	0	right-aligned	ADAAnCmCR[09:00]	1	left-aligned	ADAAnCmCR[15:06]
ADAAnCRAC	Alignment	Bit positions of A/D conversion result									
0	right-aligned	ADAAnCmCR[09:00]									
1	left-aligned	ADAAnCmCR[15:06]									

Note If A/D conversion is performed using the internal reference voltage, the A/D conversion result is stored in ADAAnDGCR, not in the ADAAnLCR, ADAAnCmCR, and ADAAnDBiCR.

(3) ADAAnDBiCR – A/D converter CGI buffer register

This register stores the result and the status of the latest A/D conversion of CGI. It allows the A/D conversion results for all channels of CGI to be read continuously.

Access This register can be read in 32-bit units.

- The upper 16 bits store the A/D conversion result status.
- The lower 16 bits store the A/D conversion result.

The conversion result can also be read via the ADAAnDBiCRL register.

Address <ADAAn_base> + C4_H + i × 4_H

Initial Value 0000 0000_H + i × 0100 0000_H

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	ADAAn DBiCG[1:0]	ADAAn DBiER1	ADAAn DBiER0	ADAAn DBiUR	ADAAn DBiCN[4:0]					
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
ADAAnDBiCR[15:00]															
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Note The functions of the individual bits are identical to those of the ADAAnLCR register, except that each of the i registers hold the latest result for the specific channel group i rather than the latest A/D conversion result for any channel.

Table 22-29 ADAAnDBiCR register contents (1/2)

Bit position	Bit name	Function															
25 to 24	ADAAn DBiCG[1:0]	Indicates the CG to which the result in ADAAnDBiCR[15:00] belongs. <table border="1" data-bbox="555 1249 1385 1527"> <thead> <tr> <th>ADAAn DBiCG1</th><th>ADAAn DBiCG0</th><th>Channel group</th></tr> </thead> <tbody> <tr> <td>0</td><td>0</td><td>CG0</td></tr> <tr> <td>0</td><td>1</td><td>CG1</td></tr> <tr> <td>1</td><td>0</td><td>CG2</td></tr> <tr> <td>1</td><td>1</td><td>None</td></tr> </tbody> </table>	ADAAn DBiCG1	ADAAn DBiCG0	Channel group	0	0	CG0	0	1	CG1	1	0	CG2	1	1	None
ADAAn DBiCG1	ADAAn DBiCG0	Channel group															
0	0	CG0															
0	1	CG1															
1	0	CG2															
1	1	None															
23	ADAAn DBiER1	Indicates the overwrite error status. 0: not overwritten 1: overwritten This error flag is cleared when ADAAnSTC2.ADAAnDBiERC1 is set to 1.															
22	ADAAn DBiER0	Indicates the A/D conversion result upper/lower limit comparison status. 0: The conversion result is within the setting range. 1: The conversion result is out of the setting range. This error flag is cleared when ADAAnSTC2.ADAAnDBiERC0 is set to 1.															
21	ADAAn DBiUR	Indicates the update status of the A/D conversion result. 0: The A/D conversion result has been read from the ADAAnDBiCR register. 1: 1: The A/D conversion result is new and has not been read from ADAAnDBiCR yet. This bit is cleared after the read operation.															

Table 22-29 ADAAnDBiCR register contents (2/2)

Bit position	Bit name	Function									
20 to 16	ADAAnDBiCN[4:0]	Indicates the channel number corresponding to the conversion result stored in the ADAAnDBiCR[15:00]. 00000 = CH0 00001 = CH1 ... = ... 01111 = CH15									
15 to 0	ADAAnDBiCR[15:00]	Result of the A/D conversion. The alignment is determined by ADAAnCTL1.ADAAnCRAC, as follows. <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>ADAAnCRAC</th> <th>Alignment</th> <th>Bit positions of A/D conversion result</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>right-aligned</td> <td>ADAAnDBiCR[09:00]</td> </tr> <tr> <td>1</td> <td>left-aligned</td> <td>ADAAnDBiCR[15:06]</td> </tr> </tbody> </table>	ADAAnCRAC	Alignment	Bit positions of A/D conversion result	0	right-aligned	ADAAnDBiCR[09:00]	1	left-aligned	ADAAnDBiCR[15:06]
ADAAnCRAC	Alignment	Bit positions of A/D conversion result									
0	right-aligned	ADAAnDBiCR[09:00]									
1	left-aligned	ADAAnDBiCR[15:06]									

Note If A/D conversion is performed using the internal reference voltage, the A/D conversion result is stored in ADAAnDGCR, not in the ADAAnLCR, ADAAnCmCR, and ADAAnDBiCR.

(4) ADAAnDBiCRL – A/D converter CGI buffer result register

This register stores the result of the latest A/D conversion of CGi.

The content of this register is identical to the lower 16 bit of the ADAAnDBiCR register (ADAAnDBiCR[15:00]).

Access This register can be read in 16-bit units.

Address <ADAAn_base> + D0_H + i × 4_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
ADAAnDBiCR[15:00]															
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

(5) ADAAnDGCR – Diagnostic conversion result register

This register stores the A/D conversion result of the reference voltage ADDIAGOUT signal (when ADAAnCG0.ADAAnDIAG = 1).

The diagnosis conversion starts after the A/D conversion of the last channel of CG0 has been completed.

Access This register can be read in 16-bit units.

Address <ADAAn_base> + 9C_H

Initial Value 0000_H




Table 22-30 ADAAnDGCR register contents

Bit position	Bit name	Function									
15 to 0	ADAAnDGCR[15:00]	Result of the diagnostic A/D conversion. The alignment is determined by ADAAnCTL1.ADAAnCRAC, as follows. <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>ADAAnCRAC</th> <th>Alignment</th> <th>Bit positions of A/D conversion result</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>right-aligned</td> <td>ADAAnDBiCR[09:00]</td> </tr> <tr> <td>1</td> <td>left-aligned</td> <td>ADAAnDBiCR[15:06]</td> </tr> </tbody> </table>	ADAAnCRAC	Alignment	Bit positions of A/D conversion result	0	right-aligned	ADAAnDBiCR[09:00]	1	left-aligned	ADAAnDBiCR[15:06]
ADAAnCRAC	Alignment	Bit positions of A/D conversion result									
0	right-aligned	ADAAnDBiCR[09:00]									
1	left-aligned	ADAAnDBiCR[15:06]									

22.6.6 A/D conversion result upper/lower limit comparison registers details

(1) ADAAnCTL2 – A/D converter result check register

This register can enable/disable the conversion result upper/lower limit comparison function for each channel.

Refer to 22.5.12 “Result check functions” on page 1169 for details.

Access This register can be read/written in 32-bit units.
It can only be written when the A/D converter is disabled (ADAAnCTL0.ADAAnCE = 0).

Address <ADAAn_base> + 18_H

Initial Value 0000 0000_H

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
ADAAnRCK[15:00]															
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 22-31 ADAAnCTL2 register contents

Bit position	Bit name	Function
15 to 00	ADAAnRCK[15:00]	Enables/disables result upper/lower limit comparison for CH _m . 0: do not perform upper/lower limit comparison for A/D conversion of CH _m 1: perform upper/lower limit comparison for A/D conversion of CH _m

Note The settings are valid for A/D conversions of every CG.

(2) ADAAnUL – A/D converter result check upper limit register

This register specifies the upper limit of the A/D conversion result.

Refer to 22.5.12 “Result check functions” on page 1169 for details.

Access This register can be read/written in 16-bit units.
It can only be written when the A/D converter is disabled
(ADAAnCTL0.ADAAnCE = 0).

Address <ADAAn_base> + 1C_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
ADAAnUL[09:00]										0	0	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 22-32 ADAAnUL register contents

Bit position	Bit name	Function
15 to	ADAAnUL[09:00]	Specifies the upper limit of the A/D conversion result.

(3) ADAAnLL – A/D converter result lower limit register

This register specifies the lower limit of the A/D conversion result.

Refer to 22.5.12 “Result check functions” on page 1169 for details.

Access This register can be read/written in 16-bit units.
It can only be written when the A/D converter is disabled
(ADAAnCTL0.ADAAnCE = 0).

Address <ADAAn_base> + 20_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
ADAAnLL[09:00]										0	0	0	0	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 22-33 ADAAnLL register contents

Bit position	Bit name	Function
15 to 6	ADAAnLL[09:00]	Specifies the lower limit of the A/D conversion result.

(4) ADAAnSTR0 – A/D converter result check error flag register

This register indicates the error status of the latest A/D conversion result upper/lower limit comparison for the channel set in the ADAAnCTL2 register. By evaluating this register it is possible to deduce which A/D conversion results are outside the specified range.

Refer to 22.5.12 “Result check functions” on page 1169 for details.

Access This register can be read in 32-bit units.

Address <ADAAn_base> + 24_H

Initial Value 0000 0000_H

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
ADAAnRCE[15:00]															
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Table 22-34 ADAAnSTR0 register contents

Bit position	Bit name	Function
15 to 0	ADAAnRCE[15:00]	Indicates whether the A/D conversion result is within the specified value range: 0: conversion results within the specified range 1: at least one Conversion result out of the specified range This error flag is cleared by setting ADAAnSTC0.ADAAnRCECm to 1. All flags are also cleared by enabling and disabling the ADAA (ADAAn.ADAAnCE= 0 and then ADAAn.ADAAnCE= 1).

Note ADAAnSTR0.ADAAnRCEm is mirrored by the following A/D conversion result error flag:

- Error flag in A/D converter conversion result register for channel m (ADAAnCmCR.ADAAnCmER0)

(5) ADAAnSTC0 – ADAAnSTR0 flag clear register

This register is the clear control register of ADAAnSTR0.

Access This register can be written in 32-bit units.

Address <ADAAn_base> + 30_H

Initial Value Reading this register always returns 0000 0000_H.

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
W	W	W	W	W	W	W	W	W	W	W	W	W	W	W	W
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
ADAAnRCEC[15:00]															
W	W	W	W	W	W	W	W	W	W	W	W	W	W	W	W

Table 22-35 ADAAnSTC0 register contents

Bit position	Bit name	Function
15 to 0	ADAAnRCEC[15:00]	0: no function 1: clears the corresponding ADAAnSTR0.ADAAnRCEm

22.6.7 Diagnose functions registers

(1) ADAAnDGCTL0 – Self-diagnosis function control register 0

This register specifies the reference voltage to be applied to diagnose the A/D conversion circuit operation.

Access This register can be read/written in 16-bit units.

Address <ADAAn_base> + DC_H

Initial Value 0000_H

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	0	0	0	0	0	ADAAn PSEL	0	0
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 22-36 ADAAnDGCTL0 register contents

Bit position	Bit name	Function
2	ADAAn PSEL	Specifies the reference voltage ADDIAGOUT: 0: ADDIAGOUT = AVSS 1: ADDIAGOUT = AVDD

Refer to 22.5.13 “Self-diagnosis function” on page 1171 for details.

22.6.8 Emulation register

(1) ADAAnEMU - Emulation register

This register controls whether the A/D Converter can be stopped during emulation, for instance upon a breakpoint hit.

Access This register can be read/written in 8-bit units.

Address <ADAAn_base> + 128_H

Initial Value 00_H

7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	ADAAn SVSDIS
R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

Table 22-37 ADAAnEMU register contents

Bit position	Bit name	Function
0	ADAAn SVSDIS	Emulation control 0: ADAAn can be stopped during emulation 1: ADAAn continuous operating during emulation

Chapter 23 On-chip Debug Unit (OCD)

This microcontroller has a debug function on-chip. By using the on-chip debug emulator, programs can be debugged with the microcontroller mounted in the target system.

The debug functions incorporated in this microcontroller conform to IEEE-ISTO 5001TM-2003 Class 1, a Nexus debug interface standard.

Caution The debug functions described in this chapter are supported by the microcontroller but whether they are usable depends on the debugger. For details of debugging, see the user's manual of the debugger.

23.1 V850E2/Fx4-G On-chip Debug Features

23.1.1 Modules behaviour during emulation break

This section specifies, which modules

- are always stopped (unconditional emulation break)
- can optionally be stopped (emulation break function)
- continue operation,

if the debugger stops the microcontroller's operation in case of an emulation break.

Emulation break An emulation break refers to a

- breakpoint hit
- manual break

during a debug session.

(1) Modules with unconditional emulation break

Following list shows all modules which are always stopped upon a emulation break:

Table 23-1 Modules with unconditional emulation break

Module
Window Watchdog Timer A (WDTA)

(2) Modules with optional emulation break

Modules with optional emulation break provide a control bit, that allows the application software to make the module stop or continue upon emulation break.

These modules support the emulation stop function.

Following list shows all modules which can optionally be stopped or continue upon an emulation break:

Table 23-2 Modules with optional emulation break

Module	Control register bit
OS Timer (OSTM)	OSTMnEMU.OSTMnSVSDIS: 0: stop during break 1: continue during break
Timer Array Unit B (TAUB)	TAUBnEMU.TAUBnSVSDIS: 0: stop during break 1: continue during break
Timer Array Unit J (TAUJ)	TAUJnEMU.TAUJnSVSDIS: 0: stop during break 1: continue during break
Clocked Serial Interface G (CSIG)	CSIGnEMU.CSIGnSVSDIS: 0: stop during break 1: continue during break
Asynchronous Serial Interface E (URTE)	URTEnEMU.URTEnSVSDIS: 0: stop during break 1: continue during break
I ² C Interface (IICB)	IICBnEMU.IICBnSVSDIS: 0: stop during break 1: continue during break
A/D Converter (ADAA)	ADAAAnEMU.ADAAAnSVSDIS: 0: stop during break 1: continue during break

(3) Modules continuing operation at emulation break

Following list shows all modules continuing operation upon an emulation break:

Table 23-3 Modules continuing operation at emulation break

Module
CAN Controller (FCN)
Key Return Function (KR)

23.1.2 Signal masking

Following V850E2/Fx4-G external signals can be masked, so that they don't have any effect, while the microcontroller is controlled by the On-chip Debug Unit:

- $\overline{\text{RESET}}$
- NMI

23.2 Functional Overview

The On-Chip Debug functions are outlined below.

(1) Debug interface

This interface is used to communicate with the host by using the $\overline{\text{DCUTRST}}$, DCUTCK, DCUTMS, DCUTDI, DCUTDO, and DCUTRDY signals via the on-chip debug emulator.

(2) Debug monitoring function

The basic debug functions below can be used by running a monitoring program in a memory space for debugging while execution of the user-created program is paused.

- downloading the user-created program
- reading and writing the memory and registers
- running the user-created program starting at any address

(3) Hardware break function

Up to four breakpoints can be specified for instructions and data. If a breakpoint is specified for an instruction, execution can be interrupted at the specified address. If a breakpoint is specified for an address, execution can be interrupted when data at the specified address is accessed.

In addition, break conditions can be combined by using a sequence of up to two levels.

(4) Software break function

Execution of the user-created program stored in the RAM can be interrupted at the specified address.

(5) Forced break function

Execution of the user-created program can be interrupted forcibly.

(6) Forced reset function

The microcontroller can be reset forcibly.

(7) Real-time RAM monitoring (RRM)

The memory can be read during program execution. Because this read access uses debug-dedicated DMA, it has minimal effect on program execution.

(8) Dynamic memory modification (DMM)

The memory can be written during program execution. Because this write access uses debug-dedicated DMA, it has minimal effect on program execution.

(9) Timer function

Using a 32-bit counter, the time for running the user-created program can be measured based on the clock obtained by dividing the DCUTCK signal frequency by 2.

(10) Mask function

Some dedicated external signals can be masked, so that they don't have any effect, while the microcontroller is controlled by the On-Chip Debug Unit.

These signals are listed in the section "*Signal masking*" above in this chapter.

(11) Modules run/stop selection during a break

Upon a breakpoint hit the microcontroller's modules behave as follows:

- module always stops operation during break
- behaviour of the module during break is an user's option and can be specified by use of the module's emulation register.
This emulation break function needs to be generally enabled, refer to 23.3 "*Emulation Break Control*" on page 1209 for details.
- module always stays in operation during break

The behaviour of the modules of this microcontroller is described in the section "*Modules behaviour during emulation break*" above in this chapter.

(12) Hot attach function

The On-Chip Debug emulator can be connected and start debugging without resetting the CPU while it is running.

(13) Security function

To prevent the contents of the flash memory from being read by an unauthorized person, a 96-bit ID code can be written to the microcontroller. If the code the user inputs when starting a debugger does not match the ID code written to the microcontroller, the flash memory cannot be accessed. If the OCDID[95] bit of the On-Chip Debug ID register OCDIDH is set to 0, the flash memory cannot be accessed even if the ID code matches.

For details of how to set the ID code, see the user's manual of the used software tools and refer to section "*On-Chip Debug Interface Protection*" in the chapter "*Code Protection and Security*" in this manual.

(14) On-Chip Debug and Stand-by modes

Setting the device in STOP or DEEPSTOP mode is not possible, if the microcontroller is operated under control of an On-Chip Debugger.

23.3 Emulation Break Control

The emulation break function generates a stop request to the modules of the microcontroller, if the debugger is taking over the control of the microcontroller, for instance upon a breakpoint hit.

Those modules stop their operation during emulation break, if

- the module supports the emulation break function (for a list of these modules refer to “*Modules behaviour during emulation break*” in the first section of this chapter)
- emulation break is enabled in the module (by setting the module’s emulation register).

Debugger support In general the debugger provides an option to enable the emulation break function. In this case the application program does not need to take care for that.

23.4 Connection with On-Chip Debug Emulator

Following signals are used to connect the debugger with the microcontroller:

Table 23-4 Signals used to connect On-Chip Debug emulator

Pin name	Description
VDD	Signal used to detect power supply to the target system, or the power supply for the buffers in the On-Chip Debug emulator
DCUTRST	Signal to asynchronously reset the debug functions of the microcontroller
DCUTCK	Clock signal used for debugging
DCUTMS	Signal to select the transfer mode for data communication
DCUTDI	Data signal input to the microcontroller
DCUTDO	Data signal output from the microcontroller
DCUTRDY	Synchronization signal for data communication
FLMDO	Mode signal used to rewrite the flash memory in the microcontroller

Refer to the section “*Operation Modes*” in chapter “*CPU System Functions*” for details.

23.5 Cautions on using On-Chip Debugging

(1) Handling of device that was used for debugging

Do not mount a device that was used for debugging on a mass-produced product, because the flash memory was rewritten during debugging and thus the number of flash memory rewrites cannot be guaranteed.

Chapter 24 Power Supply

The V850E2/Fx4-G devices provide separate power supply pins for the digital and analog circuits of the functional modules on the different power domains and for several groups of port I/O buffers.

24.1 Power supply pins naming

In this section some general information is given about the naming of the power supply pins.

In general the name of a power supply pin is composed of up to four fields with the following meaning:

Supply type	Prefix	Kind of supply	Suffix
Symbol, representing the purpose of the supply	Consecutive number for separate supplies ^a	VDD or VSS	Consecutive number for different pins for same supply ^a

^{a)} Prefix and suffix number may be omitted, if only a single supply pin is used.

The different supply types are defined in the following table.

Table 24-1 Supply types symbols

Symbol	Explanation
A	Analog circuits supply (e.g. analog parts of the A/D Converter)
B	Standard I/O buffer supply
E	Standard I/O buffer supply
OSC	Oscillator supply
REG	Internal voltage regulator input voltage

Examples:

- E0VDD: supply for standard I/O buffers group “0” via single pin
- B1VDD2: supply for standard I/O buffers group “1” via several pins (this is the second pin)
- REG0VSS: input voltage for on-chip voltage regulator REG0

24.2 Power supply schemes

The following sections show the power supply schemes, i.e. the power supply pins and the modules they supply.

Information about the voltage ranges of the power supply pins and all conditions related to them are provided in the Data Sheet. The Data Sheet provides also details about the electrical properties of the port pins.

24.2.1 V850E2/FF4-G power supply scheme

The following table and diagram shows the power supply scheme of the V850E2/FF4-G devices.

Table 24-2 V850E2/FF4-G power supply pins

Pin	Modules	Ports buffers
REG0VDD/REG0VSS/ REG0C	Internal voltage regulator REG0 V_{REG0} supplies digital circuits of Always-On-Area modules	–
REG1VDD/REG1VSS/ REG1C	Internal voltage regulator REG1 V_{REG1} supplies digital circuits of Isolated-Area-0 modules	–
E0VDD/E0VSS	–	JP0, P0
E1VDD/E1VSS	–	P1, P3, P4
OSCVDD/OSCVSS	MainOsc supply	–
A0VDD/A0VSS	Analog circuits of A/D Converter ADAA0	P10
I0VDD/VSS	Flash memory	–




Figure 24-1 V850E2/FF4-G power supply scheme

Note Refer to the Data Sheet for information about the capacitance to be connected to REG0C and REG1C.

24.2.2 V850E2/FG4-G power supply scheme

The following table and diagram shows the power supply scheme of the V850E2/FG4-G devices.

Table 24-3 V850E2/FG4-G power supply pins

Pin	Modules	Ports buffers
REG0VDD/REG0VSS/ REG0C	Internal voltage regulator REG0 V_{REG0} supplies digital circuits of Always-On-Area modules	–
REG1VDD/REG1VSS/ REG1C	Internal voltage regulator REG1 V_{REG1} supplies digital circuits of Isolated-Area-0 modules	–
E0VDD/E0VSS	–	JP0, P0
E1VDD/E1VSS	–	P1, P3, P4, P27
OSCVDD/OSCVSS	MainOsc supply	–
A0VDD/A0VSS	Analog circuits of A/D Converter ADAA0	P10
I0VDD/VSS	Flash memory	–




Figure 24-2 V850E2/FG4-G power supply scheme

Note Refer to the Data Sheet for information about the capacitance to be connected to REG0C and REG1C.

24.3 Power supply control

This section describes the power supply control.

Caution All figures are only for explanatory purposes without any relevance to the real hardware implementation.

For detailed information about voltage levels, time and frequency values refer to the Data Sheet.

The following figure outlines the power supply control.




Figure 24-3 Power supply control scheme

AWO supply The supply voltage V_{REG0} of the Always-On-Area is generated by the on-chip voltage regulator REG0 from the input voltage REG0VDD. REG0VDD is observed by the Power-On-Clear circuit POC, that keeps the Always-On-Area in reset state (POCRES) as long as REG0VDD voltage is below the POC level V_{POC} .

Isolated-Area-0 supply The Isolated-Area-0 supply is generated by the on-chip voltage regulator REG1 from its input voltage REG1VDD.

Power-up and -down of the Isolated-Area-0 is necessary in two situations:

- initial power-up and final power-down
The entire microcontroller is powered up respectively down, including the Always-On-Area.

- DEEPSTOP mode entry and wake-up
In DEEPSTOP mode only the supply of the Isolated-Area-0 ISO0VDD is switched off, while the power supply of the Always-On-Area remains active. DEEPSTOP mode entry and wake-up is signalled via the DPSTPREQ signal, which are asserted by the Stand-by Controller.

Isolated-Area-0 supply during reset Any reset switches off the power supply of the Isolated-Area-0. Thus after a reset the Isolated-Area-0 has the same status as after initial power-up or after wake-up from DEEPSTOP mode, i.e. it has to be completely re-initialized.

Note Be aware that also after any reset the internal CPU RAM content is undefined.

Power Sequencer The Power Sequencer controls the correct power-up and -down of the Isolated-Area-0.

For that purpose it is located on the Always-On-Area and starts operation if the AWO power supply V_{REG0} is stable and AWO reset AWORES is released.

For controlling the Isolated-Area-0 the Power Sequencer

- switches on the Isolated-Area-0 power supply ISO0VDD if the Isolated-Area-0 supplies V_{REG1} are stable, respectively switches off ISO0VDD when V_{REG1} are not stable
- controls the Isolated-Area-0 reset ISO0RES in order to avoid operation of the Isolated-Area-0, if its power supply is not stable

The Power Sequencer ensures that the Isolated-Area-0 voltage supply ISO0VDD is switched on and ISO0RES is released when V_{REG1} is stable.

Revision History

The table below gives an overview about the revision history of this document.

Revision history overview

Rev.	Date	Summary
1.00	Feb 28, 2013	1st edition

Index

Numerics

75% interrupt output (WDTA) 447

A

A/D Converter

see A/D Converter (ADAA)

A/D Converter (ADAA) 1143

<ADAA_n_base> 1143

ADAA_nSTR0 flag clear register
(ADAA_nSTC0) 1202

ADAA_nSTR1 flag clear register
(ADAA_nSTC1) 1187

ADCHALT mode 1164

Base addresses 1143

CG_i buffer register (ADAA_nDBiCR) 1196

CG_i buffer result register
(ADAA_nDBiCRL) 1197

Channel and channel groups (CG) 1155

Channel group index *i* 1143

Channel group register *i* (ADAA_nAG_i
) 1181

Channel index *m* 1143

Clock supply 1144

Continuous conversion mode 1159

Conversion end interrupt
INTADAA_nT_i 1166

Conversion modes 1157

Conversion result register for channel *m*
(ADAA_nCmCR) 1194

Conversion time 1165

Diagnostic conversion result register
(ADAA_nDGCR) 1198

Discharge function 1173

Emulation register (ADAA_nEMU) 1204

Error interrupt INTADAA_nERR 1166

Functional Description 1152

I/O signals 1145

Instances 1143

Instances index *n* 1143

Interrupt control register *i* (ADAA_nIO_i
) 1183

Interrupts 1166

Interrupts and DMA 1144

Last conversion interrupt
INTADAA_nLLT 1166

Latest conversion result register
(ADAA_nLCR) 1192

Mode control register 0
(ADAA_nCTL0) 1176

Mode control register 1

(ADAA_nCTL1) 1178

One-shot conversion mode 1157

Overwrite check function 1169

Overwrite error flag register
(ADAA_nSTR1) 1186

Registers 1174

Reset 1144

Resolution 1165

Result check error flag register
(ADAA_nSTR0) 1201

Result check functions 1169

Result check register
(ADAA_nCTL2) 1199

Result lower limit register
(ADAA_nLL) 1200

Result read flag function 1170

Result registers 1167

Result upper limit register
(ADAA_nUL) 1200

Result upper/lower limit compare
function 1170

Sampling time 1165

Self-diagnosis function control register 0
(ADAA_nDGCTL0) 1203

Self-diagnosis functions 1171

Stabilization control 1173

Stabilization counter (ADAA_nANT) 1184

Stand-by mode 1164

Start triggers 1160

Status flag clear register 2
(ADAA_nSTC2) 1189

Status flag register 2 (ADAA_nSTR2) 1188

Stop triggers 1162

SW trigger register 3
(ADAA_nTRG3) 1190

SW trigger register 4+*i* (ADAA_nTRG4+*i*
) 1191

SW trigger register 7
(ADAA_nTRG7) 1191

SW trigger register *i* (ADAA_nTRG_i) 1190

Trigger select control register *i*
(ADAA_nTSELi) 1185

A/D Converter (ADC) 398

ADAA

see A/D Converter (ADAA)

ADAA_nCG_i 1181

ADAA_nCmCR 1194

ADAA_nCNT 1184

ADAA_nCTL0 1176

ADAA_nCTL1 1178

-
- ADAAAnCTL2 1199
 - ADAAAnDBiCR 1196
 - ADAAAnDBiCRL 1197
 - ADAAAnDGCR 1198
 - ADAAAnDGCTL0 1203
 - ADAAAnEMU 1204
 - ADAAAnIOCi 1183
 - ADAAAnLCR 1192
 - ADAAAnLL 1200
 - ADAAAnSTC0 1202
 - ADAAAnSTC1 1187
 - ADAAAnSTC2 1189
 - ADAAAnSTR0 1201
 - ADAAAnSTR1 1186
 - ADAAAnSTR2 1188
 - ADAAAnTRG3 1190
 - ADAAAnTRG4+i 1191
 - ADAAAnTRG7 1191
 - ADAAAnTRGi 1190
 - ADAAAnTSELi 1185
 - ADAAAnUL 1200
 - ADC 398
 - ADDIAGOUT 1171
 - Address maps 129
 - Address space 127
 - CPU 127
 - Physical 127
 - Alphabetic pin function list 82
 - Analog filter type A 89
 - Analog filter type B 90
 - Analog filter type C 90
 - Analog filters 95
 - Control registers 95
 - Filter characteristic 95
 - Stand-by mode 96
 - Type A 96
 - Type B 97
 - Asynchronous Serial Interface E (URTE) 809
 - <URTE_n_base> 809
 - Baud rate generator 848
 - Baudrate measurement 811
 - BF reception 837
 - BF transmission 836
 - BF transmission/reception format 834
 - Clock supply 810
 - Configuration 813
 - Continuous transmission procedure 841
 - Control register 0 (URTE_nCTL0) 815
 - Control register 1 (URTE_nCTL1) 817
 - Control register 2 (URTE_nCTL2) 820
 - Data formats 832
 - Emulation register(URTE_nEMU) 829
 - Functional Overview 812
 - I/O signals 811
 - Instances 809
 - Instances index n 809
 - Interrupt requests 830
 - Interrupts 810
 - Operation 832
 - Parity types and operations 846
 - Receive data noise filter 847
 - Receive data register(URTE_nRX) 827
 - Reception 843
 - Reception errors 845
 - Reception interrupt (INTUA_nTIR) 831
 - Registers 814
 - Reset 811
 - Status clear register(URTE_nSTC) 826
 - Status interrupt (INTUA_nTIS) 832
 - Status register 0(URTE_nSTR0) 823
 - Status register 1(URTE_nSTR1) 824
 - Transmission 840
 - Transmission interrupt (INTUA_nTIT) 830
 - Transmit data register(URTE_nTX) 828
 - Trigger register(URTE_nTRG) 821
- B**
- Back-up RAM (BURAM) 132
 - Access 132
 - Access error clear register (BURAEC) 134
 - Access error register (BURAE) 134
 - Address 132
 - Clock supply 132
 - Control register (BURC) 133
 - Write permission 132
 - Write protection 133
 - BURAE 134
 - BURAEC 134
 - BURAM
 - see Back-up RAM (BURAM)
 - BURC 133
- C**
- CAN (Controller area network) 899
 - CAN Controller (FCN) 899
 - <FCN_n_base> 900
 - Base addresses 900
 - Baudrate settings 993
 - Bit set/clear function 920
 - CAN RAM 910
-

- Channel bit rate prescaler register (FCNnCMBRPRS) 943
- Channel bit rate register (FCNnCMBTCTL) 944
- Channel control register (FCNnCMCLCTL) 933
- Channel data byte register (FCNnMm-DATxB/H/W) 953
- Channel data length register m (FCNnMmDTLGB) 954
- Channel error counter register (FCNnCMERCNT) 940
- Channel information register (FCNnCMINSTR) 939
- Channel interrupt enable register (FCNnCMIECTL) 941
- Channel interrupt status register (FCNnCMISCTL) 942
- Channel last error information register (FCNnCMLCSTR) 938
- Channel last-in-pointer register (FCNnCMLISTR) 946
- Channel last-out-pointer register (FCNnCMLOSTR) 948
- Channel mask control register (FCNnCMMKCTLaH) 931
- Channel receive history list register (FCNnCMRGRX) 946
- Channel time stamp register (FCNnCMTSCTL) 951
- Channel transmit history list register (FCNnCMTGTGX) 949
- Clock supply 900
- Configuration 910
- Control registers 922
- Data new bit monitor registers (FCNnDNBMRXk) 930
- Diagnosis functions 988
- FCN0 signal connection selection register (ITGSLFC0) 906
- FCN0/FCN1 connection 905
- Global automatic block transmission control register (FCNnGMABCTL) 927
- Global automatic block transmission delay register (FCNnGMADCTL) 929
- Global clock selection register (FCNnGMCSPRE) 926
- Global control register (FCNnGMCLCTL) 922
- I/O signals 903
- Initialization 962
- Instances 899
- Instances index n 899
- Internal registers 911
- Interrupt function 987
- Interrupts and DMA 901
- Message buffers index m 899
- Message configuration register m (FCNnMmSTRB) 955
- Message control register m (FCNnMmCTL) 959
- Message ID register m (FCNnMmMIDxH/W) 957
- Message reception 965
- Message transmission 974
- Operation 999
- Overview of functions 908
- Power saving modes 982
- Register bit configuration 915
- Reset 902
- Special operational modes 988
- Time stamp 904
- Time stamp function 992
- Transition from initialization mode to operation mode 964
- CDEDADR 157
- CECCER 155
- CECCERC 155
- CG (ADAA) 1155
- CKSC_mn 319
- CLMA 289
 - Start-up options 292
- CLMA_n protection command register (CLMA_nPCMD) 143
- CLMA_n protection status register (CLMA_nPS) 143
- CLMA_nCMPH 303
- CLMA_nCMPL 302
- CLMA_nCTL0 300
- CLMA_nCTL1 301
- CLMA_nEMU0 304
- CLMA_nPCMD 143, 304
- CLMA_nPS 143
- CLMA_nRES) 410
- Clock Controller 254
 - Clock selector control registers (CKSC_mn) 319
 - Clock selector status registers (CSCSTAT_mn) 320
 - Clock switching 274
 - High Speed Internal Oscillator (High Speed IntOsc) 267
 - High Speed IntOsc enable register (ROSCE) 312

- High Speed IntOsc status register (ROSCS) 314
- Illegal ID 274
- Low Speed Internal Oscillator (Low Speed IntOsc) 266
- Main Oscillator (MainOsc) 263
- MainOsc control register (MOSC) 309
- MainOsc enable register (MOSCE) 307
- MainOsc stabilization time register (MOSCST) 310
- MainOsc status register (MOSCS) 308
- Phase-Locked Loop generators (PLL) 270
- PLL0 control registers (PLLC0) 317
- PLL0 enable register (PLLE0) 315
- PLL0 stabilization time register (PLLST0) 318
- PLL0 status registers (PLLS0) 316
- Register write protection 305
- Registers 305
- Clock Domain Figures 284
- Clock domain index n 254
- Clock Monitor A
 - <CLMA_n_base> 289
 - Base addresses 289
 - Clock supply 290
 - Instances 289
 - Instances index n 289
 - Interrupts and reset outputs 291
- Clock Monitor A (CLMA) 289
 - CLMA_nPCMD 143
 - CLMA_nPS 143
 - Comparison register H (CLMA_nCMPH) 303
 - Comparison register L (CLMA_nCMPL) 302
 - Control register 0 (CLMA_nCTL0) 300
 - Control register 1 (CLMA_nCTL1) 301
 - Emulation register 0 (CLMA_nEMU0) 304
 - Enable/disable 297
 - Protection command register (CLMA_nPCMD) 304
 - Register write protection 299
 - Registers 299
 - Reset 291
 - Suspend/resume 298
- Clock Monitors reset (CLMA_nRES) 410
- Clock switching 274
- Clocked Serial Interface (CSIG)
 - EDL 1043
- Clocked Serial Interface G (CSIG) 1031
- <CSIG_n_base> 1031
- Base addresses 1031
- Clock supply 1032
- Communication in slave mode 1046
- Configuration register 0 (CSIG_nCFG0) 1064
- Control register 0 (CSIG_nCTL0) 1057
- Control register 1 (CSIG_nCTL1) 1058
- Control register 2 (CSIG_nCTL2) 1060
- Data consistency check 1035, 1053
- Data length select function 1043
- Data transfer modes 1042
- Emulation register (CSIG_nEMU) 1067
- Error detection 1053
- Extended data length 1043
- Functional description 1038
- Functional overview 1036
- Hand-shake function 1049
- Instances 1031
- Instances index n 1031
- Internal signals 1034
- Interrupts 1047
- Interrupts and DMA 1033
- Loop-back mode 1052
- Master/slave connections 1039
- Master/slave mode 1038
- Overrun error 1055
- Parity check 1054
- Reception register 0 (CSIG_nRX0) 1067
- Registers 1056
- Reset 1033
- Rx-only mode control register 0 (CSIG_nBCTL0) 1063
- Serial data direction select function 1045
- Status clear register 0 (CSIG_nSTCR0) 1062
- Status register 0 (CSIG_nSTR0) 1061
- Transmission clock selection 1041
- Transmission register 0 for half word access (CSIG_nTX0H) 1066
- Transmission register 0 for word access (CSIG_nTX0W) 1066
- CNTAm 853, 854
 - Configuration register (CNTAm) 854
 - Control register (CNTAm) 854
 - Registers 853
- Code flash error correction 154
 - Double-bit error detection address register (CDEDADR) 157
 - Error flag clear register (CECCERC) 155
 - Error flag register (CECCER) 155

- Single-bit error correction address register (CSECADR) 156
 - Code Protection and Security 391
 - CPU
 - Address space 127
 - CPU Access Bus Structures and Latencies 108
 - CPU Subsystem
 - Reset 115
 - CPU Subsystem modules access 108
 - CPU System Function 106
 - CSCSTAT_mn 320
 - CSECADR 156
 - CSIG
 - see Clocked Serial Interface (CSIG)
 - CSIGNBCTL0 1063
 - CSIGNCFG0 1064
 - CSIGNCTL0 1057
 - CSIGNCTL1 1058
 - CSIGNCTL2 1060
 - CSIGNEMU 1067
 - CSIGNRX0 1067
 - CSIGNSTCR0 1062
 - CSIGNSTR0 1061
 - CSIGNTX0H 1066
 - CSIGNTX0W 1066
- D**
- Data consistency check (CSIG) 1035
 - Data flash wait cycles 120
 - Data space 127
 - DBRES 410
 - DDAnH 210
 - DDAnL 208
 - DDMA Controller (DMAC)
 - Transfer count register (DTCn) 211
 - Debug interface 65
 - Debugger reset (DBRES) 410
 - Digital filter type D 91
 - Digital filters 98
 - Control registers 100
 - Filter characteristic 98
 - Filter groups 99
 - Stand-by mode 100
 - Type D 101
 - DMA
 - see DMA Controller (DMAC)
 - DMA address map 129
 - DMA Controller
 - DMA trigger factors 197
 - DMA Controller (DMAC) 196
 - Channel index n 196
 - Clock supply 196
 - Destination address register H (DDAnH) 210
 - Destination address register L (DDAnL) 208
 - DMA address map 196
 - DMA channels 196
 - DMA request check register (DRQSTR) 226
 - DMA request clear register (DRQCLR) 225
 - Reset 196
 - Source address register H (DSAnH) 207
 - Source address register L (DSAnL) 205
 - Transfer control register (DTCTn) 212
 - Transfer request control register (DTRC) 204
 - Transfer status register (DTSn) 214
 - Trigger factor register (DTFRn) 224
 - DMA data transfer unit (DMAT) 198
 - DMA trigger factors 197
 - DMAC (DMA Controller)
 - see DMA Controller (DMAC)
 - DMAT 198
 - DNFAnCTL 104
 - DNFAnEN 105
 - DPSTPREQ 326
 - DPSTPWU 326
 - DRQCLR 225
 - DRQSTR 226
 - DSAnH 207
 - DSAnL 205
 - DTCn 211
 - DTCTn 212
 - DTFRn 224
 - DTRC 204
 - DTSn 214
- E**
- Edge detection configuration 169
 - Emulation break 1205
 - Emulation break control 1209
 - Error detection (WDTA) 445
 - Exception handler address switching function 195
 - Exceptions 149
- F**
- FCLAnCTLm 103
 - FCN

- see CAN Controller (FCN)
 - FCNnCMBRPRS 943
 - FCNnCMBTCTL 944
 - FCNnCMCLCTL 933
 - FCNnCMERCNT 940
 - FCNnCMIECTL 941
 - FCNnCMINSTR 939
 - FCNnCMISCTL 942
 - FCNnCMLCSTR 938
 - FCNnCMLISTR 946
 - FCNnCMLOSTR 948
 - FCNnCMMKCTLaH 931
 - FCNnCMRGRX 946
 - FCNnCMTGTX 949
 - FCNnCMTSCTL 951
 - FCNnDNBMRXk 930
 - FCNnGMABCTL 927
 - FCNnGMADCTL 929
 - FCNnGMCLCTL 922
 - FCNnGMCSPRE 926
 - FCNnMmCTL 959
 - FCNnMmDATxB/H/W 953
 - FCNnMmDTLGB 954
 - FCNnMmMIDxH/W 957
 - FCNnMmSTRB 955
 - FENMIF 167
 - FENMIFC 168
 - FIC 180
 - Flash configuration options 252
 - Flash configuration option register 0 (OPBT0) 253
 - Flash Memory 227
 - FLMD protection command register (FLMDPCMD) 145
 - FLMD protection error status register (FLMDPS) 145
 - Flash memory
 - Configuration area 230
 - Self-Programming 230, 244
 - Serial-Programming 230
 - Flash programmer
 - Communication mode 235
 - Pin connection 236
 - Flash Programmer and Self-Programming Protection 392
 - Flash programmer interface 65
 - Flash programming
 - Mode 121
 - FLMD control register (FLMDCNT) 245
 - FLMDCNT 245
 - FLMDPCMD 145
 - FLMDPS 145
 - FNC 179
- ## H
- High Speed IntOsc 267
- ## I
- I²C Interface (IICB) 1070
 - <IICBn_base> 1070
 - Base addresses 1070
 - Clock supply 1071
 - Control register 0 (IICBnCTL0) 1086
 - Control register 1 (IICBnCTL1) 1088
 - Data register (IICBnDAT) 1084
 - Emulation register (IICBnEMU) 1104
 - High-level width setting register (IICBnWH) 1093
 - I/O signals 1071
 - Instances 1070
 - Instances index n 1070
 - Interrupts and DMA 1071
 - Low level width setting register (IICBnWL) 1090
 - Port Settings 1072
 - Reset 1071
 - Slave address register (IICBnSVA) 1085
 - Status clear register (IICBnSTRC) 1103
 - Status register 0 (IICBnSTR0) 1097
 - Status register 1 (IICBnSTR1) 1102
 - Trigger register (IICBnTRG) 1094
 - IcN 171
 - ICSR 178
 - IDMODI 397
 - IICB
 - see I²C Interface (IICB)
 - IICBnCTL0 1086
 - IICBnCTL1 1088
 - IICBnDAT 1084
 - IICBnEMU 1104
 - IICBnSTR0 1097
 - IICBnSTR1 1102
 - IICBnSTRC 1103
 - IICBnSVA 1085
 - IICBnTRG 1094
 - IICBnWH 1093
 - IICBnWL 1090
 - Illegal ID 274
 - IMRm 173
 - INTADAA_nERR 1166
 - INTADAA_nLLT 1166
 - INTADAA_nTi 1166

- Interrupt Controller
 - Control registers 171
- Interrupt functions 147
 - Acknowledgement 148
 - Acknowledgement condition 148
 - Edge detection configuration 169
 - EI level interrupt control registers (ICn) 171
 - EI level interrupt mask registers (IMRm) 173
 - EI level maskable interrupts 159
 - Exception handler address switching function 195
 - Exceptions 149
 - Exceptions and Interrupts 147
 - FE level INT status register (FIC) 180
 - FE level NMI status register (FNC) 179
 - FE level non-maskable interrupt sharing 167
 - FE level non-maskable interrupts 158
 - FENMI factor clear register (FENMIFC) 168
 - FENMI factor register (FENMIF) 167
 - In-service priority clear function 195
 - In-service priority clear register (ISPC) 176
 - Interrupt acknowledgment and restoring 181
 - Interrupt controller status register (ICSR) 178
 - Interrupt operation 188
 - Interrupt priority level judgment 188
 - Interrupt Request Sources 158
 - Interrupt types 158
 - Mask function of EI level maskable interrupt 188
 - Memory error exceptions MEP 149
 - Pending interrupt report function 194
 - Priority mask function 194
 - Priority mask register (PMR) 175
 - Priority order 148
 - Request 148
 - Restore 148
 - Resume 148
 - Select channel hold register (SCR) 177
 - System error control register (SEG_CONT) 152
 - System error exceptions SYSERR 150
 - System error flag register (SEG_FLAG) 153
- Interrupt operation 188
- Interrupt Request Sources 158
- INTUAEnTIR (URTE) 831
- INTUAEnTIS (URTE) 832
- INTUAEnTIT (URTE) 830
- ISPC 176
- ITGSLFC0 906
- J**
 - JP0 56
 - JPBDC0 54
 - JPDO 60
 - JPFC0 52
 - JPIBC0 51
 - JPIS0 62
 - JPISE0 63
 - JPM0 49
 - JPMC0 46
 - JPMCSR0 47
 - JPMSR0 50
 - JPNOT0 57
 - JPODC0 61
 - JPPR0 55
 - JPSR0 58
 - JPU0 59
 - JTAG ports 38
- K**
 - Key Interrupt Function 1140
 - Key Return Function
 - Functional Description 1141
 - Key Return Function (KR) 1138
 - <KRn_base> 1138
 - Base addresses 1138
 - Clock supply 1139
 - I/O signals 1139
 - Instances 1138
 - Instances index n 1138
 - Interrupts 1139
 - Reset 1139
 - Key Return Function (KR08) 1140
 - Key return mode register
 - KR08nKRM 1142
 - Key return mode register (KR08nKRM) 1142
 - KR
 - see Key Return Function (KR)
 - KR08nKRM 1142
- L**
 - LIN Master Controller (LMA) 849
 - <LMA_n_base> 850
 - Base addresses 850
 - Clock supply 851

- CNTA instances 849
- CNTA instances index m 849
- CNTAm base addresses
 - <CNTAm_base> 850
- Compare register H (LMAncMPH) 893
- Compare register L (LMAncMPL) 893
- Control register H (LMAncTLH) 886
- Control register L (LMAncTLL) 884
- Instances 849
- Instances index n 849
- Interrupts and DMA 852
- Registers 882
- Reset 852
- Rx control register H (LMAncRCTLH) 898
- Rx control register L (LMAncRCTLL) 897
- Status clear register H (LMAncSTCH) 892
- Status clear register L (LMAncSTCL) 891
- Status register H (LMAncSTRH) 888
- Status register L (LMAncSTRL) 887
- Tx control register H (LMAncTCTLH) 896
- Tx control register L (LMAncTCTLL) 894
- LIN Master Scheduler Counter (CNTA) 853
- LMA
 - see LIN Master Controller (LMA)
- LMAnc
 - Control register L (LMAncTLL) 854
- LMAncMPH 893
- LMAncMPL 893
- LMAncTLH 886
- LMAncTLL 854, 884
- LMAncRCTLH 898
- LMAncRCTLL 897
- LMAncSTCH 892
- LMAncSTCL 891
- LMAncSTRH 888
- LMAncSTRL 887
- LMAncTCTLH 896
- LMAncTCTLL 894
- Low Speed IntOsc 266
- Low-Voltage Indicator (LVI) 404
- LVI 404
- LVICNT 416
- M**
- MainOsc 263
- Memory Protection Unit (MPU) 107
- MEP (Memory error exceptions) 149
- Mode pins 65
- MOSC 309
- MOSCE 307
- MOSCS 308
- MOSCST 310
- MPU
 - see Memory Protection Unit (MPU)
- N**
- Noise elimination 89
- Normal operation mode 121
- O**
- OCD 1205
- OCD protection command register (PROTOPCMD) 146
- OCD protection error status register (PROTOPS) 146
- OCDIDL/M/H 396
- On-Chip Debug Interface Protection 393
 - Control register (IDMODI) 397
 - Control registers 395
 - Enable flag 393
 - ID code 394
 - ID registers (OCDIDL/M/H) 396
 - Protection levels summary 394
- On-Chip Debug Unit (OCD) 1205
 - Debug interface 1207
 - Debug monitoring function 1207
 - Debugger connection 1210
 - Dynamic memory modification (DMM) 1207
 - Emulation break control 1209
 - Forced break function 1207
 - Forced reset function 1207
 - Hardware break function 1207
 - Hot attach function 1208
 - Mask function 1208
 - Modules run/stop selection during a break 1208
 - Real-time RAM monitoring (RRM) 1207
 - Security function 1208
 - Software break function 1207
 - Timer function 1207
- OPBT0 253
- Operation modes 121
 - Normal operation mode 121
 - Serial flash programming mode 121
- Ordering information 35
- OS Timer (OSTM) 418
 - <OSTMn_base> 418
 - Base addresses 418
 - Clock supply 419
 - Compare register (OSTMnCMP) 429

- Control register (OSTMnCTL) 432
 - Count enable status register (OSTMnTE) 431
 - Count start trigger register (OSTMnTS) 431
 - Count stop trigger register (OSTMnTT) 432
 - Counter register (OSTMnCNT) 430
 - Emulation register (OSTMnEMU) 433
 - Functional Description 420
 - Instances 418
 - Instances index n 418
 - Interrupts 419
 - Registers 428
 - Reset 419
 - OSCWUFMSK 332, 354
 - OSTM
 - see OS Timer (OSTM)
 - OSTMnCMP 429
 - OSTMnCNT 430
 - OSTMnCTL 432
 - OSTMnEMU 433
 - OSTMnTE 431
 - OSTMnTS 431
 - OSTMnTT 432
- P**
- PBDCn 54
 - PBUS modules access 109
 - PBUS Synchronizer 112
 - PDn 60
 - PFCEn 53
 - PFCn 52
 - Physical address space 127
 - PIBCn 51
 - PIPCn 48
 - PISEn 63
 - PISn 62
 - PLL 270
 - PLLC0 317
 - PLLE0 315
 - PLLS0 316
 - PLLST0 318
 - PMcN 46
 - PMCSRn 47
 - PMn 49
 - PMR 175
 - PMSRn 50
 - Pn 56
 - PNOTn 57
 - POC 403
 - PODCn 61
 - Port bi-direction control register (PBDCn, JPBDc0) 54
 - Port filters 89
 - Analog filter type A 89
 - Analog filter type B 90
 - Analog filter type C 90
 - Analog filters 95
 - Clock supply 93
 - Control registers 102
 - Digital filter type D 91
 - Digital filters 98
 - Digital noise elimination control register (DNFAnCTL) 104
 - Digital noise elimination enable register (DNFAnEN) 105
 - Filter control register (FCLAnCTLm) 103
 - Filters assignment 89
 - Reset 94
 - Port filters assignment 89
 - Port function
 - PBDCn, JPBDc0 54
 - PDn, JPD0 60
 - PFCEn 53
 - PFCn, JPFC0 52
 - PIBCn, JPIBC0 51
 - PIPCn 48
 - PISEn, JPISE0 63
 - PISn, JPIS0 62
 - PMcN, JPMc0 46
 - PMCSRn, JPMCSR0 47
 - PMn, JPM0 49
 - PMSRn, JPMSR0 50
 - Pn, JP0 56
 - PNOTn, JPNOT0 57
 - PODCn, JPODC0 61
 - PPCMDn 144
 - PPRn, JPPR0 55
 - PPROTSn 144
 - PSRn, JPSR0 58
 - PUn, JPU0 59
 - Register write protection 44
 - Port function control expansion register (PFCEn) 53
 - Port function control register (PFCn, JPFC0) 52
 - Port Functions
 - Port groups 36
 - Port functions 36
 - <JPORT0_base> 36
 - <PORTn_base> 36
 - Base addresses 36

Debug interface 65
 Direct I/O control (PIPC) 67
 Flash programmer interface 65
 Functions during and after reset 86
 Functions in stand-by mode 86
 Mode pins 65
 Permanent inputs 66
 Port groups index n 36
 Port group configuration 64
 Alphabetic pin function list 82
 Port input buffer control register (PIBCn, JPIBC0) 51
 Port input selection expansion register (PISEn, JPISE0) 63
 Port input selection register (PISn, JPIS0) 62
 Port IP control register (PIPCn) 48
 Port mode control register (PMcN, JPMC0) 46
 Port mode control set reset register (PMCSRn, JPMCSR0) 47
 Port mode register (PMn, JPM0) 49
 Port mode set reset register (PMSRn, JPMSR0) 50
 Port NOT register (PNOTn, JPNOT0) 57
 Port open drain control register (PODCn, JPODC0) 61
 Port pin read register (PPRn, JPPR0) 55
 Port protection command register (PPCMDn) 144
 Port protection status register (PPROTSn) 144
 Port register (Pn, JP0) 56
 Port register protection 44
 Port set reset register (PSRn, JPSR0) 58
 Power domain index m 254
 Power supply control 1215
 Power Supply Scheme 1211
 Power-On Clear (POC) 403
 PPCMDn 144
 PPRn 55
 PPROTSn 144
 Program space 127
 PROT0PCMD 146
 PROT0PS 146
 PROTCMDm 141
 PROTSm 142
 PSC0 348
 PSRn 58
 Pull-down option register (PDn, JPD0) 60
 Pull-up option register (PUn, JPU0) 59
 PUn 59
 PURES 400
 PWS0 350

R

Related documents 34
 $\overline{\text{RESET}}$ 408
 Reset Controller
 Clock Monitors reset (CLMAnRES) 410
 Debugger reset (DBRES) 410
 External $\overline{\text{RESET}}$ 408
 Low-Voltage Indicator (LVI) 404
 LVI control register (LVICNT) 416
 Power-On Clear (POC) 403
 Power-up reset (PURES) 400
 Register write protection 411
 Registers 411
 Reset factor clear register (RESFC) 414
 Reset factor register (RESF) 412
 Reset flags 402
 Software reset (SWRES) 410
 Software reset register (SWRESA) 415
 System reset (SYSRES) 400
 Very-Low-Voltage flag clear register (VLVFC) 417
 Very-Low-Voltage flag register (VLVF) 417
 Very-Low-Voltage Indicator (VLVI) 406
 Watchdog Timers reset (WDTAnRES) 410
 Reset flags 402
 RESF 412
 RESFC 414
 ROSCE 312
 ROSCS 314
S
 SCR 177
 SEG_CONT 152
 SEG_FLAG 153
 Self-Programming library (SPL) 244
 SEQ
 see Wake-up Sequencer (SEQ)
 SEQnDPINSR 377
 SEQnEFR 379
 SEQnSCR 380
 SEQnSCTLR 378
 Software reset (SWRES) 410
 SPL (Self-Programming library) 244
 SRP
 see System Register Protection (SRP)
 Stand-by Controller (STBC) 322
 CAN FCNnRX wake-up 330
 Clock generators in stand-by 329
 DEEPSTOP mode flow 341

-
- DPSTPREQ 326
 - DPSTPWU 326
 - External interrupts INTPm wake-up 330
 - Functional modules interrupt wake-up 330
 - HALT mode wake-up 330
 - MainOsc wake-up 332
 - Mode transitions 336
 - On-Chip Debug wake-up 331
 - Oscillator wake-up mask register (OSCWUFMSK) 354
 - Power save control register 0 (PSC0) 348
 - Power status register 0 (PWS0) 350
 - Register write protection 347
 - Reset 322
 - Signal connections 326
 - Stand-by mode transitions 336
 - Stand-by modes control 327
 - Stand-by modes flows 337
 - Stand-by modes overview 328
 - Stand-by status 328
 - STOP mode flow 338
 - STPREQ 326
 - Wake-up 330
 - Wake-up control 331
 - Wake-up events 330
 - Wake-up factor clear registers (WUFC) 353
 - Wake-up factor mask registers (WUFMSK) 352
 - Wake-up factor registers (WUF) 351
 - Wake-up factors 322
 - WUOSCSTA 326
 - Stand-by modes flows 337
 - DEEPSTOP mode 341
 - STOP mode 338
 - STPREQ 326
 - SWRES 410
 - SWRESA 415
 - SYSERR (System error exceptions) 150
 - SYSRES 400
 - System Register Protection (SRP) 107
- T**
- TAUB
 - see Timer Array Unit B (TAUB)
 - TAUB input selections 461
 - TAUBnCDRm 675
 - TAUBnCMORm 678
 - TAUBnCMURm 681
 - TAUBnCNTm 676
 - TAUBnCSCm 683
 - TAUBnCSRm 682
 - TAUBnEMU 692
 - TAUBnRDC 690
 - TAUBnRDE 689
 - TAUBnRDM 689
 - TAUBnRDS 690
 - TAUBnRDT 691
 - TAUBnRSF 691
 - TAUBnTDE 687
 - TAUBnTDL 687
 - TAUBnTDM 687
 - TAUBnTE 684
 - TAUBnTO 688
 - TAUBnTOC 686
 - TAUBnTOE 685
 - TAUBnTOL 688
 - TAUBnTOM 685
 - TAUBnTPS 673
 - TAUBnTS 683
 - TAUBnTT 684
 - TAUJ
 - see Timer Array Unit J (TAUJ)
 - TAUJnBRS 792
 - TAUJnCDRm 793
 - TAUJnCMORm 796
 - TAUJnCMURm 799
 - TAUJnCNTm 794
 - TAUJnCSCm 801
 - TAUJnCSRm 800
 - TAUJnEMU 808
 - TAUJnRDE 806
 - TAUJnRDM 806
 - TAUJnRDT 807
 - TAUJnTE 802
 - TAUJnTO 803
 - TAUJnTOC 805
 - TAUJnTOE 803
 - TAUJnTOL 805
 - TAUJnTOM 804
 - TAUJnTPS 790
 - TAUJnTS 801
 - TAUJnTT 802
 - Timer Array Unit B (TAUB) 457
 - <TAUBn_base> 457
 - Assigning DMA Window Addresses 500
 - Base addresses 457
 - Channel counter register (TAUBnCNTm) 676
 - Channel data register
-

- (TAUBnCDRm) 675
- Channel dead time output enable register (TAUBnTDE) 687
- Channel dead time output level register (TAUBnTDL) 687
- Channel dead time output mode register (TAUBnTDM) 687
- Channel enable status register (TAUBnTE) 684
- Channel index m 457
- Channel mode OS register (TAUBnCMORm) 678
- Channel mode user register (TAUBnCMURm) 681
- Channel output configuration register (TAUBnTOC) 686
- Channel output enable register (TAUBnTOE) 685
- Channel output level register (TAUBnTOL) 688
- Channel output mode register (TAUBnTOM) 685
- Channel Output Modes 489
- Channel output register (TAUBnTO) 688
- Channel reload data control channel select register (TAUBnRDS) 690
- Channel reload data control register (TAUBnRDC) 690
- Channel reload data enable register (TAUBnRDE) 689
- Channel reload data mode register (TAUBnRDM) 689
- Channel reload data trigger register (TAUBnRDT) 691
- Channel reload status register (TAUBnRSF) 691
- Channel start trigger register (TAUBnTS) 683
- Channel status clear register (TAUBnCSCm) 683
- Channel status register (TAUBnCSRm) 682
- Channel stop trigger register (TAUBnTT) 684
- Clock supply 458
- Concepts of Synchronous Channel Operation 476
- Emulation register (TAUBnEMU) 692
- Functional Description 472
- Functional Overview 469
- General Operating Procedure 474
- I/O signals 460
- Independent functions 501
- Instances 457
- Instances index n 457
- Interrupt Generation upon Overflow 499
- Interrupts and DMA 458
- Operation Modes 475
- Prescaler clock select register (TAUBnTPS) 673
- Registers 672
- Reset 459
- Simultaneous rewrite 479
- Start Timing of Operating Modes 496
- Synchronous functions 592
- TAUB0 input selection register (TSOSLTA0) 467, 468
- TAUB0 odd input selection register (TISLTA0) 465
- TAUB0 receive input selection register (TRXSLTA0) 466
- TAUB1 input selections 469
- TAUBnTTINm Edge Detection 500
- TAUBnTTOUTm Output and INTTAUBnIm Generation when Counter Starts or Restarts 498
- Timer Array Unit J (TAUJ) 693
 - <TAUJn_base> 693
 - Base addresses 693
 - Channel counter register (TAUJnCNTm) 794
 - Channel data register (TAUJnCDRm) 793
 - Channel enable status register (TAUJnTE) 802
 - Channel index m 693
 - Channel mode user register (TAUJnCMURm) 799
 - Channel output configuration register (TAUJnTOC) 805
 - Channel output enable register (TAUJnTOE) 803
 - Channel output level register (TAUJnTOL) 805
 - Channel output mode register (TAUJnTOM) 804
 - Channel Output Modes 711
 - Channel output register (TAUJnTO) 803
 - Channel reload data enable register (TAUJnRDE) 806
 - Channel reload data mode register (TAUJnRDM) 806
 - Channel reload data trigger register (TAUJnRDT) 807
 - Channel reload status register (TAUJnRSF) 807

- Channel start trigger register (TAUJnTS) 801
 - Channel status clear register (TAUJnCSCm) 801
 - Channel status register (TAUJnCSRm) 800
 - Channel stop trigger register (TAUJnTT) 802
 - Clock supply 694
 - Concepts of Synchronous Channel Operation 703
 - Emulation register (TAUJnEMU) 808
 - Functional Description 699
 - Functional Overview 696
 - General Operating Procedure 701
 - channel mode OS register (TAUJnCMORm) 796
 - I/O signals 695
 - Independent Channel Interrupt Functions 725
 - Independent Channel Signal Measurement Functions 739
 - Instances 693
 - Instances index n 693
 - Interrupt Generation upon Overflow 719
 - Interrupts and DMA 694
 - Operation Modes 702
 - Other Independent Channel Functions 770
 - Prescaler baud rate setting register (TAUJnBRS) 792
 - Prescaler clock select register (TAUJnTPS) 790
 - Registers 789
 - Reset 695
 - Simultaneous Rewrite 706
 - Start Timing of Operating Modes 716
 - Synchronous PWM Signal Functions Triggered at Regular Intervals 777
 - TAUJnTTINm Edge Detection 724
 - TAUJnTTOUTm Output and INTTAUJnIm Generation when Counter Starts or Restarts 718
 - TISLTA0 465
 - TRXSLTA0 466
 - TSOSLTA0 467, 468
 - TTAUJnRSF 807
- U**
- UARTEn
 - Base addresses 809
 - see Asynchronous Serial Interface E
- (URTE)
- URTEnCTL0 815
 - URTEnCTL1 817
 - URTEnCTL2 820
 - URTEnEMU 829
 - URTEnRX 827
 - URTEnSTC 826
 - URTEnSTR0 823
 - URTEnSTR1 824
 - URTEnTRG 821
 - URTEnTX 828
- V**
- Variable activation code (WDTA) 444
 - Very-Low-Voltage Indicator (VLVI) 406
 - VLVF 417
 - VLVFC 417
 - VLVI 406
- W**
- Wake-up Sequencer (SEQ) 355
 - <SEQn_base> 355
 - Base addresses 355
 - Clear register (SEQnSCR) 380
 - Clock supply 356
 - Control register (SEQnSCTLR) 378
 - DPIN selection register (SEQnDPINSR) 377
 - Event flag register (SEQnEFR) 379
 - Functional Description 360
 - I/O signals 357
 - Instances 355
 - Instances index n 355
 - Internal signals 357
 - Registers 376
 - Reset 356
 - Watchdog status (WDTA) 449
 - Watchdog Timers reset (WDTAnRES) 410
 - WDTA
 - see Window Watchdog Timer A (WDTA)
 - WDTAnEVAC 453
 - WDTAnMD 455
 - WDTAnREF 454
 - WDTAnRES 410
 - WDTAnWDTE 451
 - Window function (WDTA) 448
 - Window Watchdog Timer A (WDTA) 434
 - <WDTAn_base> 434
 - 75% interrupt output 447
 - Base addresses 434

- Clock supply 435
- Enable register (WDTAnWDTE) 451
- Enable VAC register (WDTAnEVAC) 453
- Error detection 445
- Functional description 440
- Instances 434
- Instances index n 434
- Interrupts and reset outputs 435
- Mode register (WDTAnMD) 455
- Reference value register (WDTAnREF) 454
- Registers 450
- Reset 436
- Start modes 441
- Start-up options 437
- Variable activation code 444
- Watchdog status 449
- WDTA trigger 444
- Window function 448
- Write protected registers 135
 - Clock monitors protection cluster registers 143
 - Clock/stand-by/reset protection cluster registers 141
 - Control protection clusters registers 141
 - OCD control protection cluster registers 146
 - Port protection cluster registers 144
 - Protection command register m (PROTCMDm) 141
 - Protection registers overview 139
 - Protection status register m (PROTSm) 142
 - Register protection clusters 135
 - Self-programming protection cluster registers 145
- WUF 351
- WUFC 353
- WUFMSK 352
- WUOSCSTA 326

V850E2/Fx4-G User Manual

Publication Date: Rev. 1.00 February 28, 2013

Published by: Renesas Electronics Corporation



SALES OFFICES**Renesas Electronics Corporation**<http://www.renesas.com>Refer to "<http://www.renesas.com/>" for the latest and detailed information.**Renesas Electronics America Inc.**2880 Scott Boulevard Santa Clara, CA 95050-2554, U.S.A.
Tel: +1-408-588-6000, Fax: +1-408-588-6130**Renesas Electronics Canada Limited**1101 Nicholson Road, Newmarket, Ontario L3Y 9C3, Canada
Tel: +1-905-898-5441, Fax: +1-905-898-3220**Renesas Electronics Europe Limited**Dukes Meadow, Millboard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K
Tel: +44-1628-651-700, Fax: +44-1628-651-804**Renesas Electronics Europe GmbH**Arcadiastrasse 10, 40472 Düsseldorf, Germany
Tel: +49-211-65030, Fax: +49-211-6503-1327**Renesas Electronics (China) Co., Ltd.**7th Floor, Quantum Plaza, No.27 ZhiChunLu Haidian District, Beijing 100083, P.R.China
Tel: +86-10-8235-1155, Fax: +86-10-8235-7679**Renesas Electronics (Shanghai) Co., Ltd.**Unit 204, 205, AZIA Center, No.1233 Lujiazui Ring Rd., Pudong District, Shanghai 200120, China
Tel: +86-21-5877-1818, Fax: +86-21-6887-7858 / -7898**Renesas Electronics Hong Kong Limited**Unit 1601-1613, 16/F., Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong
Tel: +852-2886-9318, Fax: +852 2886-9022/9044**Renesas Electronics Taiwan Co., Ltd.**13F, No. 363, Fu Shing North Road, Taipei, Taiwan
Tel: +886-2-8175-9600, Fax: +886 2-8175-9670**Renesas Electronics Singapore Pte. Ltd.**80 Bendemeer Road, Unit #06-02 Hyflux Innovation Centre Singapore 339949
Tel: +65-6213-0200, Fax: +65-6213-0300**Renesas Electronics Malaysia Sdn.Bhd.**Unit 906, Block B, Menara Amcorp, Amcorp Trade Centre, No. 18, Jln Persiaran Barat, 46050 Petaling Jaya, Selangor Darul Ehsan, Malaysia
Tel: +60-3-7955-9390, Fax: +60-3-7955-9510**Renesas Electronics Korea Co., Ltd.**11F., Samik Laved' or Bldg., 720-2 Yeoksam-Dong, Kangnam-Ku, Seoul 135-080, Korea
Tel: +82-2-558-3737, Fax: +82-2-558-5141

V850E2/Fx4-G