



Atmel SAM4S-WPIR-RD

User Guide

Section 1

1.1	Scope	1-1
1.2	References and Applicable Documents	1-2

Section 2

2.1	Deliverables	2-3
2.2	Board Specifications	2-3
2.3	Electrostatic Warning	2-4

Section 3

3.1	Power Up the Board.....	3-5
3.2	Sample Code and Technical Support	3-5

Section 4

4.1	Introduction	4-6
4.2	Function Blocks	4-6
4.2.1	Processor.....	4-6
4.2.2	Clock Circuitry.....	4-7
4.2.3	Reset Circuitry	4-7
4.2.4	Push Button Switches.....	4-7
4.2.5	Power Supplies	4-7
4.2.6	Memory	4-8
4.2.7	JTAG/ICE.....	4-9
4.2.8	Image Sensor	4-9
4.2.9	PIR sensor	4-9
4.2.10	ZigBee	4-11
4.2.11	LED Indicators	4-11
4.2.12	LCD.....	4-11
4.2.13	Backlight Control.....	4-12
4.3	Connectors.....	4-13
4.3.1	JTAG/ICE Connector	4-13
4.3.2	USB Micro AB.....	4-14
4.3.3	ZigBee Socket J5.....	4-15
4.3.4	LCD/TSC Socket J4.....	4-15
4.4	Schematics.....	4-17

Section 5

5.1	Revision History	5-20
-----	------------------------	------

Section 1

Introduction


1.1 Scope

The SAM4S-WPIR-RD Reference Design Kit is based on SAM4S16C device. It introduces the application of Passive InfraRed Motion Detector Camera.

This User Guide gives design details on the Reference Design Kit and is made up of 4 sections:

- Section 1 includes a photo of the board, references and applicable documents.
- Section 2 describes the contents and the main features of the Reference Design Kit.
- Section 3 provides instructions to power up the board and describes how to use it.
- Section 4 describes the hardware resources, function blocks, connectors and schematics.

Figure 1-1. Board Photo



1.2 References and Applicable Documents

Table 1-1. References and Applicable Documents

Title	Comment
SAM4S datasheet	http://www.atmel.com/products/microcontrollers/arm/sam4s.aspx?tab=documents

Section 2

Kit Contents

2.1 Deliverables

The Atmel® SAM4S-WPIR-RD Reference Design Kit includes:

- Board
 - One SAM4S-WPIR-RD board
- Power supply
 - USB supply
- Cables
 - One USB cable, type A to type Micro-B

Unpack and inspect the kit carefully. Contact your local Atmel distributor, should there be issues concerning the contents of the kit.

2.2 Board Specifications

Table 2-1. SAM4S-WPIR-RD Board Specifications

Characteristics	Specifications
Clock speed	48 MHz MCK
Ports	USB, JTAG
Board supply voltage	5V DC from USB or 3 x AAA Alkaline cells
Temperature <ul style="list-style-type: none">- operating- storage	<ul style="list-style-type: none">-10° to +50° C-40° to +85° C
Relative humidity	0 to 90% (non condensing)
Dimensions	136 mm x 90mm
RoHS status	Compliant

2.3 Electrostatic Warning

The SAM4S-WPIR-RD board is shipped in a protective anti-static package. The board system must not be subjected to high electrostatic potentials. A grounding strap or similar ESD protective device should be worn when handling the board in hostile ESD environments (offices with synthetic carpet, for example). Avoid touching the component pins or any other metallic element on the board.

3.1 Power Up the Board

Unpack the board taking care to avoid electrostatic discharge. Connect the board to PC with the USB cable, or insert 3 x AAA Alkaline cells on U4 Battery Holder, and then the board should be powered on.


Note: Jumpers JP1, JP4, JP7, JP8, JP9, JP10 must be closed and JP2, JP3 must be open for start-up.

3.2 Sample Code and Technical Support

Users can download sample code and get technical support from the Atmel web site:

<http://www.atmel.com/products/microcontrollers/arm/sam4s.aspx?tab=tools>


Figure 3-1. Atmel Web Site for SAM4S Products



4.1 Introduction

The SAM4S-WPIR-RD block diagram includes battery holder, LDO, image sensor, 1M byte SRAM, PIR sensor, JTAG connector, LCD, ZigBee connector, as shown in Figure 4-1.

Figure 4-1. SAM4S-WPIR-RD Block Diagram



4.2 Function Blocks

4.2.1 Processor

The board is equipped with a SAM4S16 device in a LQFP100 package.

4.2.2 Clock Circuitry

The board includes 2 clock sources:

- One 12 MHz Crystal for Internal Clock (Y2)
- One 32.768 kHz Crystal for RTC Clock (Y1)

4.2.3 Reset Circuitry

The reset sources for the board are:

- Power on reset
- JTAG reset from an in-circuit emulator (JTAG interface is equipped on the board)

4.2.4 Push Button Switches

- User interface (BP1)

4.2.5 Power Supplies

The Board is driven by 5V input power rail from USB cable or 3 x AAA battery.


The Board embeds all the necessary power rails required for the microcontroller

[Table 4-1](#) summarizes the power specifications.

Table 4-1. Power Rails Associated with the Systems

Nominal	Name	Powers	Component
3.0V	VDDIO	Partial Peripheral I/O lines	on board
3.0V	+3V_PERIPH	SRAM and image sensor	on board
3.0V	+3V_LCD	LCD and backlight driver	on board
1.2V	VDDPLL	the PLL cell	From SAM4S internal LDO
1.2V	VDDCORE	the core, including the processor, the embedded memories and the peripherals	From SAM4S internal LDO
3.0V	ADVREF	analog	on board


Figure 4-6. PIR Sensor



4.2.10 ZigBee

The board has a 10-pin male connector for the Atmel RZ600 ZigBee module.

Figure 4-7. ZigBee Interface



4.2.11 LED Indicators

The board has one LED indicator for purposes shown below:


Table 4-2. LED Indicators

Reference	Color	Function
D1	Blue	PIR indicator

4.2.12 LCD

The LCD module gets reset from the NRST signal. As explained, this NRST is shared with the JTAG port. The LCD chip select signal is connected to NCS2. The SAM4S communicates with the LCD through PIOC where an 8-bit parallel “8080-like” protocol data bus has to be implemented by software.


Figure 4-8. LCD Block



4.2.13 Backlight Control

The LCD backlight is made of four integrated white chip-LEDs arranged in parallel. These are driven by an AAT3155 charge pump, MN10. The AAT3155 is controlled by the SAM4S through a single PIO line PC13 interface; the 0 Ohm resistor R59 is mounted in series on this line, which permits to use it for other custom purposes. In that case, the pull-up resistor R58 maintains the charge pump permanently enabled by default.

Figure 4-9. Backlight Control



4.3 Connectors

4.3.1 JTAG/ICE Connector

Figure 4-10. JTAG J2




Table 4-3. JTAG/ICE Connector J2 Signal Descriptions

Pin	Mnemonic	Description
1	VTref. 3.3V power	This is the target reference voltage. It is used to check if the target has power, to create the logic-level reference for the input comparators, and to control the output logic levels to the target. It is normally fed from VDD on the target board and must not have a series resistor.
2	Vsupply. 3.3V power	This pin is not connected in SAM-ICE. It is reserved for compatibility with other equipment. Connect to VDD or leave open in target system.
3	nTRST TARGET RESET - Active-low output signal that resets the target	JTAG Reset. Output from SAM-ICE to the Reset signal on the target JTAG port. Typically connected to nTRST on the target CPU. This pin is normally pulled HIGH on the target to avoid unintentional resets when there is no connection.
4	GND	Common ground
5	TDI TEST DATA INPUT - Serial data output line, sampled on the rising edge of the TCK signal.	JTAG data input of target CPU. It is recommended that this pin is pulled to a defined state on the target board. Typically connected to TDI on target CPU.
6	GND	Common ground
7	TMS TEST MODE SELECT	JTAG mode set input of target CPU. This pin should be pulled up on the target. Typically connected to TMS on target CPU. Output signal that sequences the target's JTAG state machine, sampled on the rising edge of the TCK signal.
8	GND	Common ground
9	TCK TEST CLOCK - Output timing signal, for synchronizing test logic and control register access.	JTAG clock signal to target CPU. It is recommended that this pin is pulled to a defined state on the target board. Typically connected to TCK on target CPU.

Pin	Mnemonic	Description
10	GND	Common ground
11	RTCK - Input Return test clock signal from the target.	Some targets must synchronize the JTAG inputs to internal clocks. To assist in meeting this requirement, a returned and retimed TCK can be used to dynamically control the TCK rate. SAM-ICE supports adaptive clocking which waits for TCK changes to be echoed correctly before making further changes. Connect to RTCK if available, otherwise to GND.
12	GND	Common ground
13	TDO JTAG TEST DATA OUTPUT - Serial data input from the target.	JTAG data output from target CPU. Typically connected to TDO on target CPU.
14	GND	Common ground
15	nSRST RESET	Active-low reset signal. Target CPU reset signal.
16	GND	Common ground
17	RFU	This pin is not connected in SAM-ICE.
18	GND	Common ground
19	RFU	This pin is not connected in SAM-ICE.
20	GND	Common ground

4.3.2 USB Micro AB

Figure 4-11. USB Device Micro-B Connector J1




Table 4-4. USB Device Micro-B Connector J1 Signal Descriptions

Pin	Mnemonic	Description
1	Vbus	5v power
2	DM	Data minus
3	DP	Data plus
4	ID	Not used
5	GND	Common ground

4.3.3 ZigBee Socket J5

Figure 4-12. ZigBee Socket J5




Table 4-5. ZigBee Socket J5 Signal Descriptions

Function	Signal Name	Port	Pin	Pin	Port	Signal Name	Function
Reset	/RST		1	2		Misc.	Interrupt Request
Interrupt Request	IRQ1		3	4		SLP_TR	SLP_TR
SPI chip select	/SEL		5	6		MOSI	SPI MOSI
SPI MISO	MISO		7	8		SCLK	SPI CLK
Power Supply	GND	GND	9	10	VCC	VCC	VCC

4.3.4 LCD/TSC Socket J4


Figure 4-13. LCD/TSC Socket J4



Table 4-6. LCD/TSC Socket J4 Signal Descriptions

Mnemonic		Pin Num	Pin Num	Mnemonic	
VDD	3V_INTER	1	2	PC7	LCDDAT17
LCDDAT16	PC6	3	4	PC5	LCDDAT15
LCDDAT14	PC4	5	6	PC3	LCDDAT13
LCDDAT12	PC2	7	8	PC1	LCDDAT11
LCDDAT10	PC0	9	10	NC	LCDDAT09
LCDDAT08	NC	11	12	NC	LCDDAT07
LCDDAT06	NC	13	14	NC	LCDDAT05
LCDDAT04	NC	15	16	NC	LCDDAT03
LCDDAT02	NC	17	18	NC	LCDDAT01
LCDDAT00	NC	19	20	3V	VDD

Mnemonic		Pin Num	Pin Num	Mnemonic	
RD	PC11	21	22	PC8	WR
RS	PC19	23	24	PA22	CS
RESET	NRST	25	26	PULL UP	IM0
IM1	PULL DOWN	27	28	GND	GND
LED-A	LED-A	29	30	LED-K1	LED-K1
LED-K2	LED-K2	31	32	LED-K3	LED-K3
LED-K4	LED-K4	33	34	NC	Y UP
Y DOWN	NC	35	36	NC	X RIGHT
X LEFT	NC	37	38	NC	NC
GND	GND	39			



ATMEL	
SAM4S-WPIR-RD	
Microcontroller	
Part Number	SAM4S-WPIR-RD
Scale	1/1
Rev	A
Sheet	2/3

Section 5

Revision History

5.1 Revision History

Document	Comments
42060A	Initial



Enabling Unlimited Possibilities®

Atmel Corporation

1600 Technology Drive
San Jose, CA 95110
USA

Tel: (+1) (408) 441-0311

Fax: (+1) (408) 487-2600

www.atmel.com

Atmel Asia Limited

Unit 01-5 & 16, 19F
BEA Tower, Millennium City 5
418 Kwun Tong Roa
Kwun Tong, Kowloon
HONG KONG

Tel: (+852) 2245-6100

Fax: (+852) 2722-1369

Atmel Munich GmbH

Business Campus
Parkring 4
D-85748 Garching b. Munich
GERMANY

Tel: (+49) 89-31970-0

Fax: (+49) 89-3194621

Atmel Japan G.K.

16F Shin-Osaki Kangyo Bldg
1-6-4 Osaki, Shinagawa-ku
Tokyo 141-0032
JAPAN

Tel: (+81) (3) 6417-0300

Fax: (+81) (3) 6417-0370

© 2012 Atmel Corporation. All rights reserved. / Rev.: 42060A-ATARM-12/2012

Atmel®, Atmel logo and combinations thereof, Enabling Unlimited Possibilities®, and others are registered trademarks or trademarks of Atmel Corporation or its subsidiaries. ARM®, Thumb®, Cortex™ are registered trademarks or trademarks of ARM Ltd. Other terms and product names may be trademarks of others. Other terms and product names may be trademarks of others.

Disclaimer: The information in this document is provided in connection with Atmel products. No license, express or implied, by estoppel or otherwise, to any intellectual property right is granted by this document or in connection with the sale of Atmel products. EXCEPT AS SET FORTH IN THE ATMEL TERMS AND CONDITIONS OF SALES LOCATED ON THE ATMEL WEBSITE, ATMEL ASSUMES NO LIABILITY WHATSOEVER AND DISCLAIMS ANY EXPRESS, IMPLIED OR STATUTORY WARRANTY RELATING TO ITS PRODUCTS INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT. IN NO EVENT SHALL ATMEL BE LIABLE FOR ANY DIRECT, INDIRECT, CONSEQUENTIAL, PUNITIVE, SPECIAL OR INCIDENTAL DAMAGES (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS AND PROFITS, BUSINESS INTERRUPTION, OR LOSS OF INFORMATION) ARISING OUT OF THE USE OR INABILITY TO USE THIS DOCUMENT, EVEN IF ATMEL HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Atmel makes no representations or warranties with respect to the accuracy or completeness of the contents of this document and reserves the right to make changes to specifications and products descriptions at any time without notice. Atmel does not make any commitment to update the information contained herein. Unless specifically provided otherwise, Atmel products are not suitable for, and shall not be used in, automotive applications. Atmel products are not intended, authorized, or warranted for use as components in applications intended to support or sustain life.