

# DVI, DISPLAY PORT, HDMI, VIDEO INTERFACE CONTROLLER FOR TFT PANEL

Model: HX-4096

Part number: 41755012X-3 or up

## INSTRUCTIONS

## **CONTENTS**

Page: 2. Introduction, How to Proceed, Usage Note, Disclaimer

- 3. System design Diagram of a suggested system
- 5. Assembly notes Important information about system elements
- 7. Connection & Operation How to use the controller
- **13. Connectors, pinouts & jumpers** Essential connection information
- 30. Controller dimensions
- 31. Application notes
- 33. Troubleshooting
- 34. Specifications
- **36.** Appendix I Signal support modes table
- 40. Appendix II Network connection
- 43. Appendix III RS-232 control protocols and command set
- 53. Appendix IV Mapping definition
- **55. Appendix V –** DV remote control unit work for HX-4096
- 56. Appendix VI PIP mix table
- **57. Appendix VII** Functions list on browser page
- 60. Warranty, Caution & Limitation of Liability, Trademarks
- 61. Contact details
- **62. Revision History**

It is essential that these instructions are read and understood before connecting or powering up this controller.

#### Introduction

Designed for LCD monitor and other flat panel display applications, the HX-4096 is a feature rich interface controller for :

- > TFT (active matrix) LCD panels of 4096x2160 resolutions in 60Hz with V-by-One, eDP or LVDS interface.
- Support true 10 bits panel
- > Support HDMI, DVI and Display Port input.

#### **HOW TO PROCEED**

- > Ensure you have all parts & that they are correct, refer to:
  - Connection diagram

#### **Controller Solution Generator**

Full web resource matching controllers & panels with **connection diagrams** for download. See at : <a href="http://www.digitalview.com/csg">http://www.digitalview.com/csg</a>

- Connector reference (in following section)
- Assembly notes
- Check controller switch & jumper settings (errors may damage the panel)
- Prepare the signal sources
- Connect the parts
- Understand the operation & functions

#### **IMPORTANT USAGE NOTE**

This equipment is for use by developers and integrators, the manufacturer accepts no liability for damage or injury caused by the use of this product. It is the responsibility of the developer, integrators or other user of this product to:


- Ensure that all necessary and appropriate safety measures are taken.
- Obtain suitable regulatory approvals as may be required.
- · Check power settings to all component parts before connection.


#### DISCLAIMER

There is no implied or expressed warranty regarding this material.

#### SYSTEM DESIGN

A typical LCD based display system utilizing this controller is likely to comprise the following:





#### **ASSEMBLY NOTES**

This controller is designed for monitor and custom display projects using 4096x2160 resolution with V-by-One interface, eDP interface or LVDS TFT panels. The following provides some guidelines for installation and preparation of a finished display solution.

**Preparation**: Before proceeding it is important to familiarize yourself with the parts making up the system and the various connectors, mounting holes and general layout of the controller. As much as possible connectors have been labeled. Guides to connectors and mounting holes are shown in the following relevant sections.

- 1. LCD Panel: This controller is designed for typical V-by-One (8 lanes), eDP (HBR/HBR2) and LVDS interfaced panels with panel voltage 3.3V(4A), 5V(4A), 10V(4A), 12V(4A) or 18V(3A), External for 10V, 12V and 18V interface. Due to the variation between manufacturers of panels signal timing and other panel characteristics, factory setup and confirmation should be obtained before connecting to a panel. (NOTE: Check panel power jumper settings before connection)
- 2. LCD Controller: Handle the controller with care as static charge may damage electronic components. Make sure correct jumper to match the target LCD panel.
- 3. Panel cable: In order to provide a clean signal it is recommended that all panel cables (V-by-One signal, eDP and LVDS) supplied by Digital View. Care should be taken when placing the cables to avoid signal interference.
- 4. Inverter/Backlight driver: This will be required for the backlight of an LCD, some LCD panels have an inverter/backlight driver built in. As LCD panels may have 1 or more backlight tubes and the power requirements for different panel backlights may vary it is important to match the inverter/backlight driver in order to obtain optimum performance. See Application notes page 31 for more information on connection.
- 5. Inverter/backlight cables: Different inverter/backlight models require different cables and different pin assignment. Make sure correct cable pin out to match the inverter/backlight. Using wrong cable pin out may damage the inverter/backlight.
- 6. Function Controls: The following section discusses the controls required and the section on connectors provides the detail. The controls are minimal: On/Off, Backlight Brightness (depends on inverter), OSD (5 momentary buttons) analog VR type or (8 momentary buttons) digital type.
- 7. Function controls cable: The cables to the function switches should be of suitable quality and length so that impedance does not affect performance. Generally lengths up to 1 meter (3 feet) should be acceptable.
- 8. Optional LED: The pin direction of the LED should be corrected for right color indication. Red color stands for standby. Green colors stands for signal on. The status LED is an optional part only, can be unconnected.
- 9. Optional IR sensor: It is an optional part only, can be unconnected if not using IR remote control.
- 10. RS-232 control interface: Serial control via this interface port.
- 11. External panel power output: User for specific panel model.
- 12. Panel control signal: Use for specific panel model.
- 13. SPDIF Audio output: This port support SPDIF audio output from the HDMI / Display Port audio source inputted.
- 14. Ambient light sensor connection: 3 ways connector provides interface for ambient light sensor connection by using Kit 70220-3.
- 15. Backlight status input: 2 ways connector provides interface for connection with the specific panel type which support the panel with backlight status monitoring function.
- 16. On board LED backlight driver: The on board LED driver supports 4 LED strings max 50V total LED backlight via J10 connector.
- 17. DVI-I input cable: Plug the DVI cable to the connector P1 on the controller board.
- 18. HDMI input: Plug the HDMI cable to the connector P2(HDMI 1.4) / P3(HDMI 1.4) / P4(HDMI 2.0) on the controller board. This port is not supported when CN5/CN16 are connected.
- 19. Alternate HDMI input: This port gives alternate HDMI input support.
- 20. Alternate DVI-I input: This port gives alternate DVI-I input support.
- 21. Control over network connection: This is a network device that allow to control RS-232 enable devices over a TCP/IP based Ethernet and the Internet using a web browser. Please refer to Appendix V in details.
- 22. Reserved for Audio adaptor board P/N 416940020-3: The audio add-on board gives the audio input and output signal connection. It is an optional and reserved part only, can be unconnected if not using audio. It requires an audio cable P/N 426451800-3 to connect HX-4096 (CN14) to the Audio Add-on Board (CN2).
  CAUTION: The Audio Add-on Board P/N 416940020-3 can only operate with 12VDC power input environment.

- 23. Reserved for Audio extend cable: The audio extend cable P/N 426009700-3 designs for connection between audio add on board P/N 416940020-3 and the controller. It is an optional and reserved part only, can be unconnected if not using audio.
- 24. Additional panel power input: Provide additional (+10V/+12V/+18V) panel power input for driving high power consumption panels.
- 25. Power Input: 12V/24VDC is required, this should be a regulated supply. It allows 12V (5A) or 24V (5A) via PP5 power input connector. The power rating is depending on the panel and inverter used. Although the controller provides power regulation for the LCD power this does not relate to the power supplied to the backlight inverter.
  If an unregulated power supply is provided to an inverter any fluctuations in power may affect operation, performance and lifetime of the inverter and or backlight tubes.
- **26.** External panel power input: Allow to supply external power to the panel separately for max 3.3V (7A) or 5V (7A) or 10V (5A) or 12V (5A) or 18V (3.5A) via PP4 power input connector. Corresponding jumper setting of JA3, JA5 & JA6 are required for each panel power input by referring to page 16.
- **Power output**: Note the controller has an overall 3Amp current limit and the current available from the auxiliary power output will be dependent on the power input and other system requirements.
- Power Safety: Note that although only 12V / 24VDC is required as 'power-in' a backlight inverter for panel backlighting produces significantly higher voltages (the inverter does not connect to the ground plane). We strongly advise appropriate insulation for all circuitry.
- EMI: Shielding will be required for passing certain regulatory emissions tests. Also the choice of external Controller to PC signal cable can affect the result.
- Ground: The various PCB mounting holes are connected to the ground plane.
- Servicing: The board is not user serviceable or repairable. Warranty does not cover user error in connecting up to the controller
  and is invalidated by unauthorized modification or repairs.
- Controller Mounting: It is recommended that a clearance of at least 10mm is provided above and 5mm below the controller when mounted. Additionally consideration should be given to:
  - Electrical insulation.
  - Grounding.
  - EMI shielding
  - Cable management. Note: It is important to keep panel signal cables apart from the inverter & backlight cables to prevent signal interference.
  - Heat & Ventilation: Heat generated from other sources, for example the backlight of a very high brightness panel may generate significant heat which could adversely affect the controller.
  - Other issues that may affect safety or performance.
- PC Graphics Output: A few guidelines:
  - Signal quality is very important, if there is noise or instability in the PC graphics output this may result in visible noise on the display.
  - Refer to graphics modes table in specifications section for supported modes.
  - Non-interlaced & interlaced video input is acceptable.

IMPORTANT: Please read the Application Notes section for more information.

#### **CONNECTION & OPERATION**

CAUTION: Never connect or disconnect parts of the display system when the system is powered up as this may cause serious damage.

#### CONNECTION

Connection and usage is quite straight forward (it is useful to have the relevant connection diagram available at this time):

- LCD panel & Inverter: Connect the inverter/Backlight driver (if it is not built-in the panel) to the inverter/backlight connector of the LCD panel.
- 2. **V-by-One interface panels:** The controller board supports V-by-One interface 4K panel. Plug the cable to J7 for driving 4K 60Hz panel. And make sure the matching panel timings and correct jumper settings (JB13 & JB14) by referring to the panel support table and jumper settings table in page 13-16.
- 3. **eDP interface panels:** The controller board supports eDP(1.1) or eDP(1.2) interface 4K panel. For eDP(1.1) panel, plug the cable to J7. For eDP(1.2) panel, plug the cable to J6. And make sure the matching panel timings and correct jumper settings (JB13 & JB14) by referring to the panel support table and jumper settings table in page 13-16.
- 4. LVDS interface panels: The controller board supports LVDS interface 4K panel. Plug the cable to J2/J3/J4 for driving 4K 60Hz panel. And make sure the matching panel timings and correct jumper settings (JB13 & JB14) by referring to the panel support table and jumper settings table in page 13-16.
- Inverter/Backlight driver: Plug the inverter/backlight cable to CNB1 and CNA1 (if necessary). Plug another end to the connector
  on the inverter/backlight of panel side.
- 6. **Function switch & Controller:** Plug the OSD switch mount cable to CNC1 on the controller board and another to the OSD switch mount.
- 7. LED & Controller: Plug in a 3-way with dual color LED to connector LED1 on the controller board.
- 8. IR & Controller: Plug in a 3-way with IR sensor to connector IR1 on the controller board.
- Jumpers & Inverter & Panel voltage: Particularly pay attention to the settings of JA3, JA5, JA6, JB2 and JB3. JB2 & JB3 are
  used for inverter control (read inverter specification and information on the jumper table to define the correct settings). JA3 &
  JA5 & JA6 is used for panel voltage input (read panel specification and information on the jumper table to define the correct
  settings).
- 10. Input signal cable & Controller: Plug the corresponding signal input to the connector on the controller board.
- 11. **Power supply & Controller:** Plug the DC 12V/24V power in to the connector PP2 or PP5. You can consider to use DigitalView mating power cable P/N 426013710-3, 1000mm for PP5 connection.
- 12. External panel power input: Plug power cable: P/N 426013710-3 for external panel power input (3.3 (max 7A) / 5V (max 7A) / 10V (max. 5A) / 12V (max 5A) / 18V (max3.5)) for PP4 connection.
- 13. Power on: Switch on the controller board and panel by using the OSD switch mount.

#### General:

- If you are using supplied cables & accessories, ensure they are correct for the model of panel and controller.
- If you are making your own cables & connectors refer carefully to both the panel & inverter specifications and the section in this
  manual, "Connectors, Pinouts & Jumpers" to ensure the correct pin to pin wiring.

#### DC SETTINGS

The controller has been designed to take a very wide range of input signals however to optimize the PC's graphics performance we recommend choosing 60Hz vertical refresh rate – this will not cause screen flicker.


#### **OPERATION**

Once the system has been connected and switched on there are a number of functions available to adjust the display image as summarized in the following sections. The settings chosen will be saved for each mode independently.

#### LCD DISPLAY SYSTEM SETTINGS

NOTE: By way of explanation the following refers to a set of sample buttons that may be obtained as an option. In addition to power on/off and connection for backlight brightness the controller provides an On Screen Display of certain functions which are controlled by 5 momentary type buttons (analog VR type) or 8 momentary type buttons (digital type):

Controls	Analog VR type	Digital type
On/Off – turns controller board power on	VR toggle switch	On/Off button
Brightness – controls backlight brightness	Rotary VR	Brightness +/- buttons
Menu	Menu button	Menu button
Turns OSD menu On or Off (it will auto time off)		
Select up	SEL UP	SEL UP
<ul> <li>Moves the selector to the previous level function (up)</li> </ul>		
Select down	SEL DN	SEL DN
<ul> <li>Moves the selector to the next level function</li> </ul>		
(down)		
Confirm the OSD selection		
+	+	+
<ul> <li>Increase the OSD parameter values</li> </ul>		
<ul> <li>Moves the selector to next function (forward)</li> </ul>		
,		
-	-	-
<ul> <li>Decrease the OSD parameter values</li> </ul>		
<ul> <li>Moves the selector to previous function</li> </ul>		
(backward)		




12V / 24VDC power input: Analog 10K VR Type OSD switch mount uses P/N 410680550-3 or up

12V / 24VDC power input:

Digital 10K Type OSD switch


Analog VR type



Digital type

mount uses P/N 416100520-3 or up

\* Sequence of Input source selection (Press "+" Button to change source, Press "SEL DN" to confirm)





#### Display Mode:









[Default]



## Display Function:

1P: Disp Rotate: 0 [Default]

180 270

2P LR: Input Swap

2P TB: Input Swap

2P PIP: PIP Position : Top-left

Top-right Bottom-left

Bottom-right [Default]

PIP Transparency : [0 - 10] [Default 0] PIP Size : [0 - 10] [Default 10]

**Input Swap** 



Picture:

Backlight [0-100] [Default 100] Brightness [0-100] [Default 50] Contrast [0-100] [Default 50] Sharpness [0-4] [Default 2]



## VGA Setup:

**Auto Adjust** 

H Position [0-100] [Default 50] V Position [0-100] [Default 50] Clock [0-100] [Default 50] Phase [0-100] [Default 0]

Color Gain : Set Reset



Color:

Gamma: 1.8 2.0

2.2 [Default]

2.4

Temperature: 9300

7500

6500 [Default]

5800 3200 sRGB

User : R [0-255] G [0-255] B [0-255]

Color Effect: Standard [Default]

Game Movie Photo Vivid

Specifications subject to change without notice

```
User: R:
                                    Hue [0-100]
                                    Sat [0-100]
                                    Hue [0-100]
                                    Sat [0-100]
                                 G:
                                    Hue [0-100]
                                    Sat [0-100]
                                 C:
                                    Hue [0-100]
                                    Sat [0-100]
                                 B:
                                    Hue [0-100]
                                    Sat [0-100]
                                 M:
                                    Hue [0-100]
                                    Sat [0-100]
              Hue:
                          [0-100]
                                     [Default 50]
              Saturation [0-100]
                                     [Default 50]
              Advanced:
              Aspect Ratio: Full
                                   [Default]
                            16:9
                            4:3
Advanced
                            5:4
                            1:1
              Over Scan: ON
                             [Default]
                          OFF
              Over Drive: ONOFF: ON
                                  OFF
                                             [Default]
                          OD Gain [0-100]
                                             [Default 50]
              Communication: RS-232
                                         [Default]
                                Network
              Auto Source Seek: OFF
                                      [Default]
                                 ON
              Hot Key: Hot Key 1 (< | >): Input
                                        Backlight
                                        Brightness
                                        Contrast
                                        Sharpness
                                        Hue
                                        Saturation
                                        Aspect Ratio
                                        Display Mode
                                        Input Śwap
                                        PIP Size
                                        Auto Adjust
                                        Volume
                                        No Function [Default]
              Hot Key: Hot Key 1 (Up | Dn) : Input
                                           Backlight
                                           Brightness
                                           Contrast
                                           Sharpness
                                           Hue
                                           Saturation
                                           Aspect Ratio
                                           Display Mode
                                           Input Śwap
                                           PIP Size
                                           Auto Adjust
                                           Volume
                                           No Function [Default]
```

**Power Save: OFF** 

ON [Default]

**Default Power: OFF** 

ON [Default]



Input:

(For all display modes: 1P/ 2R LR / 2P TB / 2P PIP / 4P)

A0 : VGA D0 : DP D1 : HDMI D2 : HDMI D3 : HDMI

Audio

Audio:

D4: DVI

Volume [0-100] [Default 50]

Mute: ON

OFF [Default]

Audio Source (1P): Analog [Default]

Digital (region 1)

Audio Source (2P LR) : Analog [Default]

Digital (region 1) - Left Digital (region 2) - Right

Audio Source (2P TB) : Analog [Default]

Digital (region 1) - Top Digital (region 2) - Bottom

Audio Source (2P PIP) : Analog [Default]

Digital (region 1) - Main Digital (region 2) - Sub

Audio Source (4P) : Analog [Default]

Digital (region 1) - Upper left Digital (region 2) - Lower left Digital (region 3) - Upper right Digital (region 4) - Lower right



Other:

Reset

Menu Time [On, 11-60] [Default 11]

OSD H Position [0-100] [Default 50]

OSD V Position [0-100] [Default 50]

Language

Transparency [0-255] [Default 0]

Rotate: 0 [Default 0]

90 270

Border Width: [0-10] [Default 0]

Border Color: R [Default]

G B

W



#### Information:

D1: HDMI 3840×2160@60.1Hz H:135.1KHz PCLK: 594.4MHz HDCP Disabled



Factory:

Backlight Setup: Invert : OFF [Default]

ON

D/A / PWM : PWM [Default]

D/A

Frequency: [100Hz - 440Hz] [Default 160Hz]

Min. Level : [0% - 50%] [Default 5%]

VBy1 Setup : Pin 15 : Low [Default]

High

Pin 16 : Low [Default]

High

Pin 17 : Low [Default]

High

Pin 18 : Low [Default]

High

Pin 19 : Low [Default]

High

Pin 20 : Low [Default]

High

Pin 21 : Low [Default]

High

Pin 22 : Low [Default]

High

Pin 23 : Low [Default]

High


Pin 24 : Low [Default]

High

**EDID Setup : Reset** 

## **CONNECTORS, PINOUTS & JUMPERS**

The various connectors are:



**Summary: Connectors** 

Ref	Purpose	Description			
CN1	Reserved for second RS-232 serial control	JST 6-way, B6B-XH-A	(Matching type : XHP-6)		
CN2	On board internal connector for DVI		(Mating type: SHDR-20V-S-B) Matching extend cable P/N: 426302900-3)		
CN3	Reserved for external temperature sensor	JST 3-way, B3B-XH-A	(Matching type : XHP-3)		
CN5	On board internal connector for HDMI	JST BM20B-SRDS	(Matching type: SHDR-20V-S-B)		
CN6	Reserved for light sensor	DF13 2 ways	(Matching type: DF13-2S-1.25C)		
CN7	Audio board connector	Dual pin header 5x2, 0.1" p (Matching audio add-on bo			
CN8	RS-232 serial control	JST 6-way, B6B-XH-A	(Matching type: XHP-6)		
CN9	Ambient light sensor connector	JST 3-way, B3B-PH-K	(Matching type : PHR-3)		
CN10	Reserved for Fan & backlight power monitoring connector	Hirose DF13-9P-1.25 DSA	(Mating type : DF13-9S-1.25C)		
CN11	SPDIF Audio output	JST B2B-ZR	(Matching type: ZHR-2) (Matching extend cable P/N 426007400-3)		
CN12	Reserved for engineering use	Reserved			
CN13	Audio line in	JST B4B-ZR	(Matching type : ZHR-4)		
CN14	Audio line out	JST B4B-ZR	(Matching type : ZHR-4)		
		(Use audio cable P/N 4264 P/N 416940020-3)	451800-3 to connect with audio add-on bard		
CN15	Power connector for IE-2000	Yeonho SMH200-04	(Matching type : SMH200-04)		
			(Matching extend cable P/N:426307100-3)		
CN16	On board internal connector for HDMI	JST BM20B-SRDS	(Matching type: SHDR-20V-S-B)		
CN19	Additional panel power output	JST B10B-PH-K	(Matching type: PHR-10)		
CNA1	Auxiliary power output	JST 4-way, B4B-XH-A	(Matching type: XHP-4) (Matching cable P/N 426040200-3)		
CNB1	Backlight inverter	JST 5-way, B5B-XH-A	(Matching type: XHP-5) (Matching cable P/N 426058300-3)		
CNB2	Backlight status input connector	JST 2 way, B2B-XH-A	(Matching type : XHP-2)		
CNC1	OSD control	Hirose DF13A-12P-1.25H	(Mating type : DF13-12S-1.25C) unt cable P/N 426122200-3 (150mm) or		
CP2	Reserved	Reserved			

IR1	Infra-red sensor connector	JST 3-way, B3B-XH-A (Matching type : XHP-3)
J1	Ethernet	RJ-45 connector
J2	LVDS 3	JAE FI-RE51S-HF (Matching type: FI-RE51HL)
J3	LVDS 1	JAE FI-RE51S-HF (Matching type : FI-RE51HL)
J4	LVDS 2	JAE FI-RE41S-HF (Matching type : FI-RE41HL)
J5	Panel power output	JS-1147A-08 Top 1.25mm (Matching type : JS-1146-08)
J6	eDP (1.2) connector	I-PEX 20455-030E-12 (Matching type: I-PEX 20454-030T)
J7	V-by-One panel signal output	JAE FI-RE51S-HF (Matching type : FI-RE51HL)
J10	On board LED backlight driver	Molex 53261-1000 (Matching type : Molex 51021-1000)
	connector	
LED1	Power LED connector	3-pins header
P1	DVI-I D4 / VGA A0	DVI-I connector
P2	HDMI (1.4) D3	HDMI connector
P3	HDMI (1.4) D2	HDMI connector
P4	HDMI (2.0) D1	HDMI connector
P5	Display Port (1.2) D0	Display Port connector
PP2	Power input (alternative)	DC power Molex 2 pin 0.156" pitch
PP4	External panel power input	Molex 43045-0400 compatible
		(Matching connector type: Molex 43025-0400 compatible)
		(Matching power cable: P/N 426013710-3)
PP5	12V/24VDC input power	Molex 43045-0400 compatible
		(Matching connector type: Molex 43025-0400 compatible)
		(Matching power cable: P/N 426013710-3)
S1	Reset button (for Ethernet function)	Tact switch button
S2	Reserved	Tact switch button
S4	Config Menu button (for Ethernet	Tact switch button
	function)	
SW3	Panel selection	8-way DIP Switch
SW4	Function selection	6-way DIP Switch

Summary: Jumpers setting

Summary: Jum	i -		
Ref	Purpose	Note	
JA3	Panel power voltage select  CAUTION: Incorrect setting can damage panel	See panel voltage setting table 1	
JA5	Panel power voltage select  CAUTION: Incorrect setting will cause panel damage	See panel voltage setting table 1	
JA6	Panel power voltage select CAUTION: Incorrect setting will cause panel damage	See panel voltage setting table 1	
JA15	Panel power output control via J7 (pin 1-8) and J6 (pin 5-9)	1-3, 2-4 = Enable panel power (3.3/5V) output on J7 and J6 3-5, 4-6 = Enable panel power (10/12/18/24V) output on J7 and J6 Open = Disable panel power output on J7 and J6	
JB1	Backlight brightness voltage range	1-2 = 5V max 2-3 = 3.3V max	
JB2	Backlight inverter on/off control – signal level	2-3 = On/Off control signal 'High' = +5V 1-2 = On/Off control signal 'High' = +3.3V Open = On/Off control signal 'High' = Open collector CAUTION: Incorrect setting can damage inverter.	
JB3	Backlight inverter on/off control – polarity	1-2 = control signal 'high' = Backlight ON 2-3 = control signal 'low' = Backlight ON	
JB4	Reserved for LVDS (J3) GPIO pins voltage selection	1-2 = 3.3V 2-3 = 5V	
JB5	Backlight control type selection	1-2 = VR/Digital switch mount control 3-4 = Analog backlight brightness - voltage range 0~5V 5-6 = PWM (Pulse Width Modulation) brightness	
JB7	Backlight control voltage on CNB1 pin 4  (Function when JB5 sets 1-2 closed)	Open = For OSD switch mount control (Default) 1-2 = 0V 2-3 = 3.3V / 5V controlled by JB1	
JB8	LED backlight current selection	150mA 120mA 110mA 100mA 90mA	
JB9	On board LED backlight driver function	Open = Disable Closed = Enable	
JB13	V-by-One / eDP selection on J7	1-2 = V-by-One 2-3 = eDP (1.1)	
JB14	V-by-One / eDP selection on J7	1-2 = V-by-One 2-3 = eDP (1.1)	
JC1 and JC2	Panel Specification (V-by-One's pin assignment)  Pin Name Description  12 GND Ground 13 GND Ground 14 GND Ground 15 NC NO CONNECTION 16 NC NO CONNECTION 17 NC NO CONNECTION 18 NC NO CONNECTION 19 NC NO CONNECTION 20 NC NO CONNECTION 21 NC NO CONNECTION 22 NC NO CONNECTION 22 NC NO CONNECTION 23 NC NO CONNECTION 23 NC NO CONNECTION 22 NC NO CONNECTION 23 NC NO CONNECTION	Open = Low / GND / NC* Close = High	
	24 GND Ground 25 HTPDN Hot plug detect 26 LOCKN Lock detect	* The setting of NC (No connection) is subject to the NC's state defined in panel specification.	
JP1	Factory use	Default Open	
JP2	V-by-One power output configuration	1-2 = All pin 44 ~ pin 51 on J7 have power output Open = Only the upper four pins have power output	
		(Refer to power output enabled/disabled on JA15. But not applicable if JA15 is set to OPEN)	
JP6	Input power control	Short = External switch control and fix the board ON Open = Switch mount control	

Table 1 : Panel voltage setting table :

Input voltage via PP2/PP5	Panel Voltage	JA3	JA5	JA6	Jumper on board
	3.3V	3V3 closed	1-3 & 2-4	1-3 & 2-4	JA6 2 18V 0 12V 0 12V 0 10V 5V 10V 5V 10V JA3
12VDC	5V	5V closed	1-3 & 2-4	1-3 & 2-4	JA6 2 18V 0 12V 12V 11V 5V 5V 5V 5V 3.3V 9 1A3
	12V	OPEN	1-3 & 2-4	5-7 & 6-8	JA6 2 0 18V 0 12V 0 12V 0 10V 5 5V 0 3.3V 9 10 JA3

CAUTION: Incorrect setting can damage panel & controller

Input voltage via PP2/PP5	Panal Valtaga	JA3	JA5	JA6	lumper on board
FFZ/FF3	Panel Voltage	JAS	JAJ	JAO	Jumper on board
	3.3V	3V3 closed	1-3 & 2-4	1-3 & 2-4	JA6 2 18V 0 12V 0 10V 10V 5 5V JA3
	5V	5V closed	1-3 & 2-4	1-3 & 2-4	JA6 1 18V 10V 10V 10V 10V 10V 10V 10V 10V 10V 10
24VDC**	10V	10V closed	1-3 & 2-4	3-5 & 4-6	JA6 2 18V 12V 12V 10V 12V 10V 15V 10V 15V 10V 14V 10V 14V 15V 15V 15V 15V 15V 15V 15V 15V 15V 15
	12V	12V closed	1-3 & 2-4	3-5 & 4-6	JA6 2 18V 12V 10V 10V 10V 5V 3 10V JA3
	18V	18V closed	1-3 & 2-4	3-5 & 4-6	JA6 2 18V 10V 10V 10V 10V 10V 10V 10V 10V 10V 10

CAUTION: Incorrect setting can damage panel & controller

<sup>\*\*</sup> Ensure that the backlight inverter supports 24V operation prior to connecting a 24VDC input. Because CNA1 pin 1 and CNB1 pin 2 will output 24VDC if input 24VDC via PP5 or PP2.

Input voltage via PP4	Input voltage via PP2 / PP5	Panel Voltage	JA3	JA5	JA6	Jumper on board
		3.3V	OPEN	3-5 & 4-6	1-3 & 2-4	JA6 2 18V 0 12V 0 10V 0 10V 0 5V 0 3.3V 9 10 JA3
	12V / 24VDC	5V	OPEN	3-5 & 4-6	1-3 & 2-4	JA6 2 18V 0 12V 0 10V 0 10V 0 5V 0 3.3V JA3
3.3 / 5 / 10 /12 / 18VDC*		10V	OPEN	3-5 & 4-6	3-5 & 4-6	JA6 2 0 18V 0 12V 0 10V 0 10V 0 5V 0 3.3V JA3
		12V	OPEN	3-5 & 4-6	3-5 & 4-6	JA6 2 0 18V 0 12V 0 10V 10V 10V 10V 10V 10V 10V 10V 10V
		18V	OPEN	3-5 & 4-6	3-5 & 4-6	JA6 2 0 18V 0 12V 0 10V 0 10V 5V 0 3.3V 9 10 JA3

<sup>\*</sup> Maximum current for 3.3V, 5V = 7A, Maximum current for 10V, 12V = 5A, Maximum current for 18V = 3.5A

JA3, JA5 & JA6 location on board : (Please pay attention to the jumper settings on JA3, JA5 & JA6 which are red in color)




Table 2: DIP Switch selection - SW3

Pos #1	Pos #2	Pos #3	Pos.#4	Description	Panel resolution
				For 4K UHD panels	
OFF	OFF	OFF	OFF	IE-2000 (120Hz FRC)	3840 x 2160
OFF	OFF	OFF	OFF	V-By-One panel	3840 x 2160
ON	OFF	OFF	OFF	Reserved	3840 x 2160
OFF	ON	OFF	OFF	Reserved	3840 x 2160
ON	ON	OFF	OFF	Reserved	3840 x 2160
OFF	OFF	ON	OFF	eDP1.2 panel	3840 x 2160
OFF	OFF	OFF	ON	Reserved	3840 x 2160
For WUXGA panels					
OFF	OFF	OFF	OFF	LVDS panel	1920 x 1200
ON	OFF	OFF	OFF	LVDS panel	1920 x 1080

Remark : The above panel timings are generated based on the panel specification. Some of the panel timings settings may not exactly to match the panel model we specified in this table.

Pos #5	Pos #6	Pos #7	Description
OFF	OFF	OFF	WUXGA (1920 x 1200 / 1080)
ON	OFF	OFF	Reserved
OFF	ON	OFF	Reserved
ON	ON	OFF	Reserved
OFF	OFF	ON	Reserved
ON	OFF	ON	Reserved
OFF	ON	ON	4K UHD (3840 x 2160)
ON	ON	ON	Others
Pos. #8		•	Reserved

Table 3: DIP switch selection - SW4

Pos #	Function	Description				
1	LVDS data mapping	OFF: VESA ON: JEIDA				
2 and 3	Panel display division	Pos#3 Pos#2 OFF OFF 1 division (Non-division) OFF ON 2 division ON OFF 4 division ON ON 8 division				
4	Output display bit mode	OFF: 10-bit ON: 8-bit				
5	Reserved	Reserved				
6	V-by-One settings	OFF: Determine by JC1 and JC2 ON: Determine by OSD menu  Note: For setting definition, please refer to V-by-One's pin#15 to pin#24 of panel specification.				

#### Panel support

	4K 60Hz panel	
Manufacturer	Panel model	Panel resolution
AU Optronics	M270DAN02.3	2560 x 1440
AU Optronics	M320QAN01.0	3840 x 2160
AU Optronics	P550QVN01.0	3840 x 2160
AU Optronics	P750QVN01.1	3840 x 2160
BOE	MV238QUM-N20	3840 x 2160
Innolux	M238DCJ-E50	3840 x 2160
Innolux	M280DGJ-L30*	3840 x 2160
Innolux	M315DJJ-K30	3840 x 2160
Innolux	N173DSE-G31	3840 x 2160
Innolux	S400DJ1-KS5	3840 x 2160
Innolux	V400DK2-KS5	3840 x 2160
Innolux	V420DK1-KS1	3840 x 2160
Innolux	V500DK1-LS1	3840 x 2160
Innolux	V500DK2-KS1	3840 x 2160
LG	LC430EQE-FHM1	3840 x 2160
LG	LC490EQE-FHM2	3840 x 2160
LG	LC550EQE-FHM1	3840 x 2160
LG	LD550EGE-FHM1	3840 x 2160
LG	LD750DGN-FKH1	3840 x 2160
LG	LM238WR1-SLA1	3840 x 2160
LG	LM238WR2-SLC1	3840 x 2160
LG	LM270WR2-SPA1	3840 x 2160
LG	LM300WQ6-SLA1	2560 x 1600
LG	LM315WR1-SSA1	3840 x 2160
Samsung	LTM236FL01	3840 x 2160
Samsung	LTM270FL01*	3840 x 2160

4K 120Hz panel						
Manufacturer	Panel model	Panel resolution				
AU Optronics	P650QVN01.0*	3840 x 2160				
AU Optronics	P750QVN01.0	3840 x 2160				
Innolux	V400DK2-KS5	3840 x 2160				
Innolux	V500DK1-KS2	3840 x 2160				
Innolux	V500DK1-KS5	3840 x 2160				
Innolux	V850DK1-KD1	3840 x 2160				
LG	LC550EQD-FGF2	3840 x 2160				
LG	LD750EQF-FJM1	3840 x 2160				
LG	LD840EQD-SEM1	3840 x 2160				
LG	LD860EQD-FJM1	3840 x 2160				
LG	LD980DQD-FGM1	3840 x 2160				
LG	ND840EQD-SADX1	3840 x 2160				

#### Remark:

- The panel model marked with (\*) means the model has been verified by DigitalView.
   The panel model without marked with (\*) means the model has not been tested and verified but have a suggested connection diagram provide.
   For the 4K 120Hz panel connection, IE-2000 is required.

CN1 - RS-232 serial control (2nd): JST B6B-XH-A (Matching type: XHP-6)

PIN	SYMBOL	DESCRIPTION
1	NC	No connection
2	NC	No connection
3	VCC	+5V
4	TXD	RS-232 Tx data
5	GND	Ground
6	RXD	RS-232 Rx data

CN2 - Alternate DVI connector: JST BM20B-SRDS (Matching type: SHDR-20V-S-B)

PIN	SYMBOL	DESCRIPTION
1	GND	Digital Ground
2	GND	Digital Ground
3	RXC	TMDS Clock+
4	/RXC	TMDS Clock-
5	RX0	TMDS Data 0+
6	/RX0	TMDS Data 0-
7	RX1	TMDS Data 1+
8	/RX1	TMDS Data 1-
9	RX2	TMDS Data 2+
10	/RX2	TMDS Data 2-
11	GND	Ground (+5, Analog H/V Sync)
12	GND	Digital Ground
13	EXT_SCL	Reserved
14	EXT_SDA	Reserved
15	DDC_5V	+5V power supply for DDC (optional)
16	HPD	Hot plug detect
17	DDC_CLK	DDC Clock
18	DDC_DAT	DDC Data
19	NC	No connection
20	VCC	+5V

CN3 - Temperature sensor connector: JST B3B-XH-A (Matching type: XHP-3)

PIN	SYMBOL	DESCRIPTION
1	GND	Ground
2	VDD	+3.3V
3	EX_TMP_SENSOR	Temperature sensor input

CN5 - Alternate HDMI connector : JST BM20B-SRDS (Matching type : SHDR-20V-S-B)

PIN	SYMBOL	DESCRIPTION
1	GND	Ground
2	GND	Ground
3	RXC+	TMDS Data C+
4	RXC-	TMDS Data C-
5	RX0+	TMDS Data 0+
6	RX0-	TMDS Data 0-
7	RX1+	TMDS Data 1+
8	RX1-	TMDS Data 1-
9	RX2+	TMDS Data 2+
10	RX2-	TMDS Data 2-
11	GND	Ground
12	GND	Ground
13	EXT_SCL	Reserved
14	EXT_SDA	Reserved
15	DDC_5V	+5V power supply for DDC (optional)
16	HPD	Hot plug detection
17	DDC_SCL	DDC serial clock
18	DDC_SDA	DDC Data
19	NC	No connection
20	VCC	+5V

CN6 - Light sensor connector : DF13 2-ways (Matching type : DF13-2S-1.25C)

PIN	SYMBOL	DESCRIPTION
1	SENSOR	Light sensor input
2	VDD	+3.3V

## CN7 - Audio line out : 2x5 right angled header (Matching audio add-on board P/N 416940020-3 & Audio extend cable P/N 426009700-3)

PIN	SYMBOL	DESCRIPTION
1	VCC	Audio board logic power supply, +5V
2	VOLSEL0	Reserved
3	VOLSEL1	Reversed
4	TUNAUDSEL	Reserved
5	CLK/CNT	Reserved
6	GND	Ground
7	+12V/+24V	Audio board power supply, +12V/+24V
8	NC	No connection
9	NC	No connection
10	GND	Ground

CN8 - RS-232 serial control: JST B6B-XH-A (Matching type: XHP-6)

	,	3-71
PIN	SYMBOL	DESCRIPTION
1	EXT_SCL	Reserved
2	EXT_SDA	Reserved
3	VCC	+5V
4	TXD	RS-232 Tx data
5	GND	Ground
6	RXD	RS-232 Rx data

CN9 - Ambient light sensor connector : JST B3B-PH-K (Matching type : PHR-3)

		1 0 11 /
PIN	SYMBOL	DESCRIPTION
1	GND	Ground
2	VCC_5V	VCC 5V
3	ALSF	Ambient light sensing feedback

CN10 - Fan and backlight power monitoring connector : Hirose DF13-9P-1.25 DSA (Matching type : DF13-9S-1.25C)

The same and the same same same same same same same sam	Jin ponoi monitoring co.	model i imode bi io di inzo bort (matering type i bi io de inzo)
PIN	SYMBOL	DESCRIPTION
1	GND	Ground
2	TACH1_IN	Tachometer IN of Fan 1
3	GND	Ground
4	TACH2_IN	Tachometer IN of Fan 2
5	GND	Ground
6	PS_V1_IN	Power sense input 1
7	GND	Ground
8	PS_V2_IN	Power sense input 2
9	AUX	Reserved

CN11 - SPDIF audio output connector : JST B2B-ZR (Matching type : ZHR-2)

PIN	SYMBOL	DESCRIPTION
1	SPDIF	SPDIF Digital audio output
2	GND	Ground

#### CN12 - Reserved

#### CN13 - Audio line in: JST B4B-ZR (Matching type: ZHR-4)

PIN	SYMBOL	DESCRIPTION
1	GND	Ground
2	LINE_IN_L	Line in (Left)
3	GND	Ground
4	LINE_IN_R	Line in (Right)

CN14 - Audio line out: JST B4B-ZR (Matching type : ZHR-4)

PIN	SYMBOL	DESCRIPTION
1	GND	Ground
2	AUDIO_OUT_L	Audio out (Left)
3	GND	Ground
4	AUDIO_OUT_R	Audio out (Right)

CN15 - Power connector for IE-2000: Yeonho SMH200-04 (Matching type: SMH200-04)

PIN	SYMBOL	DESCRIPTION
1	12/24VA	+12/24 VDC
2	12/24VA	+12/24 VDC
3	GND	Ground
4	GND	Ground

CN16 - Alternate HDMI connector : JST BM20B-SRDS (Matching type : SHDR-20V-S-B)

PIN	SYMBOL	DESCRIPTION
1	GND	Ground
2	GND	Ground
3	RXC+	TMDS Data C+
4	RXC-	TMDS Data C-
5	RX0+	TMDS Data 0+
6	RX0-	TMDS Data 0-
7	RX1+	TMDS Data 1+
8	RX1-	TMDS Data 1-
9	RX2+	TMDS Data 2+
10	RX2-	TMDS Data 2-
11	GND	Ground
12	GND	Ground
13	EXT_SCL	Reserved
14	EXT_SDA	Reserved
15	DDC_5V	+5V power supply for DDC (optional)
16	NC	No connection
17	DDC_SCL	DDC serial clock
18	DDC_SDA	DDC Data
19	CEC	Consumer Electronics Control(CEC) pin
20	VCC	+5V

CN19 - Additional panel power output: JST B10B-PH-K (Matching type: PHR-10)

PIN	SYMBOL	DESCRIPTION
1	PVLCD_High	Panel power supply (+10V / 12V / 18V) (selected by JA3, JA5 & JA6)
2	PVLCD_High	Panel power supply (+10V / 12V / 18V) (selected by JA3, JA5 & JA6)
3	PVLCD_High	Panel power supply (+10V / 12V / 18V) (selected by JA3, JA5 & JA6)
4	PVLCD_High	Panel power supply (+10V / 12V / 18V) (selected by JA3, JA5 & JA6)
5	PVLCD_High	Panel power supply (+10V / 12V / 18V) (selected by JA3, JA5 & JA6)
6	GND	Ground
7	GND	Ground
8	GND	Ground
9	GND	Ground
10	GND	Ground

CNA1 - Auxiliary power output: JST B4B-XH-A (Matching type : XHP-4)

PIN	SYMBOL	DESCRIPTION
1	AUX 12V / 24V	+12V / +24V DC
2	GND	Ground
3	GND	Ground
4	AUX 5V	+5V DC, 500mA max

CNB1 - Backlight inverter connector: JST B5B-XH-A (Matching type : XHP-5)

PIN	SYMBOL	DESCRIPTION
1	GND	Ground
2	VBKL	+12V / +24V DC, backlight power supply
3	BLCTRL	On/Off control (enable) - see JB2 & JB3
4	BVR_WIP	Brightness VR – WIP
5	BVR_A	Brightness VR A

CNB2 - Backlight status input inverter connector: JST B2B-XH-A (Matching type: XHP-2)

PIN	SYMBOL	DESCRIPTION
1	BL_STATUS	Backlight status (Normal = High)
2	GND	Ground

CNC1 – OSD switch mount control, Hirose DF13A-12P-1.25H (Mating type : DF13-12S-1.25C)

ito: OOD omiton in	Cant Control, Illicoc Di 10	7. 12. 112011 (maxing type 1 51 10 120 11200)
PIN	SYMBOL	DESCRIPTION
1	PSWIN	Power button A
2	SW_ON	Power button B
3	BVR_A	Backlight Brightness VR pin A
4	BVR_WIP	Backlight Brightness R pin WIP
5	BVR_B	Backlight Brightness VR pin B (470 ohm resistor to +5V Vcc)
6	GND	Ground
7	MENU	OSD menu
8	-/LEFT	OSD -/Left
9	+/RIGHT	OSD +/Right
10	SEL_DN	OSD Select down
11	SEL_UP	OSD Select up
12	NC	No connection

#### CP2 - Reserved

IR1 - Infra-Red sensor connector: JST B3B-XH-A (Matching type : XHP-3)

PIN	SYMBOL	DESCRIPTION
1	GND	Ground
2	VCC	+3.3V
3	IR Data	IR data

#### J1 - Ethernet connector: RJ-45 connector

PIN	SYMBOL	DESCRIPTION
1	TX+	Transmit data +
2	TX-	Transmit data -
3	RX+	Receive data +
4	CMT1	Network use
5	CMT1	Network use
6	RX-	Receive data -
7	CMT3	Network use
8	CMT3	Network use

J2 - LVDS\_3 output connector: JAE FI-RE51S-HF (Matching type : JAE FI-RE51HL)

PIN	SYMBOL	DESCRIPTION
	GND	Ground
1 2	LVDS_OUT3_D4+	
		Positive differential LVDS data bit D4
3 4	LVDS_OUT3_D4- LVDS_OUT3_D3+	Negative differential LVDS data bit D4 Positive differential LVDS data bit D3
5	LVDS_OUT3_D3-	Negative differential LVDS data bit D3
6	LVDS_OUT3_DG+	Positive LVDS clock for D channel
7	LVDS_OUT3_DC+	Negative LVDS clock for D channel
8	LVDS_OUT3_DO=	Positive differential LVDS data bit D2
9	LVDS OUT3 D2-	Negative differential LVDS data bit D2
10	LVDS OUT3 D1+	Positive differential LVDS data bit D1
11	LVDS_OUT3_D1-	Negative differential LVDS data bit D1
12	LVDS OUT3 D0+	Positive differential LVDS data bit D0
13	LVDS OUT3 D0-	Negative differential LVDS data bit D0
14	LVDS_OUT3_C4+	Positive differential LVDS data bit C4
15	LVDS OUT3 C4-	Negative differential LVDS data bit C4
16	LVDS OUT3 C3+	Positive differential LVDS data bit C3
17	LVDS OUT3 C3-	Negative differential LVDS data bit C3
18	LVDS OUT3 CC+	Positive LVDS clock for C channel
19	LVDS_OUT3_CC-	Negative LVDS clock for C channel
20	LVDS OUT3 C2+	Positive differential LVDS data bit C2
21	LVDS OUT3 C2-	Negative differential LVDS data bit C2
22	LVDS_OUT3_C1+	Positive differential LVDS data bit C1
23	LVDS_OUT3_C1-	Negative differential LVDS data bit C1
24	LVDS_OUT3_C0+	Positive differential LVDS data bit C0
25	LVDS_OUT3_C0-	Negative differential LVDS data bit C0
26	 GND	Ground
27	LVDS OUT3 B4+	Positive differential LVDS data bit B4
28	LVDS OUT3 B4-	Negative differential LVDS data bit B4
29	LVDS OUT3 B3+	Positive differential LVDS data bit B3
30	LVDS_OUT3_B3-	Negative differential LVDS data bit B3
31	LVDS OUT3 BC+	Positive LVDS clock for B channel
32	LVDS OUT3 BC-	Negative LVDS clock for B channel
33	LVDS OUT3 B2+	Positive differential LVDS data bit B2
34	LVDS OUT3 B2-	Negative differential LVDS data bit B2
35	LVDS OUT3 B1+	Positive differential LVDS data bit B1
36	LVDS OUT3 B1-	Negative differential LVDS data bit B1
37	LVDS OUT3 B0+	Positive differential LVDS data bit B0
38	LVDS_OUT3_B0-	Negative differential LVDS data bit B0
39	LVDS_OUT3_A4+	Positive differential LVDS data bit A4
40	LVDS_OUT3_A4-	Negative differential LVDS data bit A4
41	LVDS OUT3 A3+	Positive differential LVDS data bit A3
42	LVDS OUT3 A3-	Negative differential LVDS data bit A3
43	LVDS_OUT3_AG+	Positive LVDS clock for A channel
44	LVDS_OUT3_AC-	Negative LVDS clock for A channel
45	LVDS_OUT3_AC+	Positive differential LVDS data bit A2
46	LVDS_OUTS_A2+	Negative differential LVDS data bit A2
46	LVDS_OUT3_A2-	Positive differential LVDS data bit A2
48	LVDS_OUT3_A1-	Negative differential LVDS data bit A1
49	LVDS_OUT3_A0+	
		Positive differential LVDS data bit A0
50	LVDS_OUT3_A0-	Negative differential LVDS data bit A0

Specifications subject to change without notice

51 GND Ground

J3 - LVDS\_1 output connector: JAE FI-RE51S-HF (Matching type : JAE FI-RE51HL)

PIN	SYMBOL	DESCRIPTION
1	VLCD HV	Panel power supply (+10V / 12V / 18V)
2	VLCD HV	Panel power supply (+10V / 12V / 18V)
3	VLCD HV	Panel power supply (+10V / 12V / 18V)
4	VLCD HV	Panel power supply (+10V / 12V / 18V)
5	VLCD HV	Panel power supply (+10V / 12V / 18V)
6	VLCD LV	Panel power supply (3,3V/5V)
7	VLCD LV	Panel power supply (3,3V/5V)
8	VLCD LV	Panel power supply (3,3V/5V)
9	VLCD LV	Panel power supply (3,3V/5V)
10	VLCD LV	Panel power supply (3,3V/5V)
11	GND	Ground
12	GND	Ground
13	GND	Ground
14	GND	Ground
15	GND	Ground
16	OP1	-
17	OP2	-
18	OP3	-
19	OP4	-
20	GND	Ground
21	GND	Ground
22	LVDS_OUT1_A4+	Positive differential LVDS data bit A4
23	LVDS_OUT1_A4-	Negative differential LVDS data bit A4
24	LVDS_OUT1_A3+	Positive differential LVDS data bit A3
25	LVDS_OUT1_A3-	Negative differential LVDS data bit A3
26	GND	Ground
27	LVDS_OUT1_AC+	Positive LVDS clock for A channel
28	LVDS_OUT1_AC-	Negative LVDS clock for A channel
29	GND	Ground
30	LVDS_OUT1_A2+	Positive differential LVDS data bit A2
31	LVDS_OUT1_A2-	Negative differential LVDS data bit A2
32	LVDS_OUT1_A1+	Positive differential LVDS data bit A1
33	LVDS_OUT1_A1-	Negative differential LVDS data bit A1
34	LVDS_OUT1_A0+	Positive differential LVDS data bit A0
35	LVDS_OUT1_A0-	Negative differential LVDS data bit A0
36	GND	Ground
37	LVDS_OUT1_B4+	Positive differential LVDS data bit B4
38	LVDS_OUT1_B4-	Negative differential LVDS data bit B4
39	LVDS_OUT1_B3+	Positive differential LVDS data bit B3
40	LVDS_OUT1_B3-	Negative differential LVDS data bit B3
41	GND	Ground
42	LVDS_OUT1_BC+	Positive LVDS clock for B channel
43	LVDS_OUT1_BC-	Negative LVDS clock for B channel
44	GND	Ground
45	LVDS_OUT1_B2+	Positive differential LVDS data bit B2
46	LVDS_OUT1_B2-	Negative differential LVDS data bit B2
47	LVDS_OUT1_B1+	Positive differential LVDS data bit B1
48	LVDS_OUT1_B1-	Negative differential LVDS data bit B1
49	LVDS_OUT1_B0+	Positive differential LVDS data bit B0
50	LVDS OUT1 B0-	Negative differential LVDS data bit B0
51	GND	Ground

J4 - LVDS 2 output connector: JAE FI-RE41S-HF (Matching type : .IAF FI-RE41HI )

PIN	SYMBOL	F (Matching type : JAE FI-RE41HL)
		DESCRIPTION
1	GND	Ground
2	LVDS_OUT2_B0-	Negative differential LVDS data bit B0
3	LVDS_OUT2_B0+	Positive differential LVDS data bit B0
4	LVDS_OUT2_B1-	Negative differential LVDS data bit B1
5	LVDS_OUT2_B1+	Positive differential LVDS data bit B1
6	LVDS_OUT2_B2-	Negative differential LVDS data bit B2
7	LVDS_OUT2_B2+	Positive differential LVDS data bit B2
8	LVDS_OUT2_BC-	Negative LVDS clock for B channel
9	LVDS_OUT2_BC+	Positive LVDS clock for B channel
10	GND	Ground
11	LVDS_OUT2_B3-	Negative differential LVDS data bit B3
12	LVDS_OUT2_B3+	Positive differential LVDS data bit B3
13	GND	Ground
14	LVDS_OUT2_B4-	Negative differential LVDS data bit B4
15	LVDS_OUT2_B4+	Positive differential LVDS data bit B4
16	GND	Ground
17	LVDS_OUT2_A0-	Negative differential LVDS data bit A0
18	LVDS_OUT2_A0+	Positive differential LVDS data bit A0
19	LVDS_OUT2_A1-	Negative differential LVDS data bit A1
20	LVDS_OUT2_A1+	Positive differential LVDS data bit A1
21	LVDS_OUT2_A2-	Negative differential LVDS data bit A2
22	LVDS_OUT2_A2+	Positive differential LVDS data bit A2
23	LVDS OUT2 AC-	Negative LVDS clock for A channel
24	LVDS OUT2 AC+	Positive LVDS clock for A channel
25	GND	Ground
26	LVDS OUT2 A3-	Negative differential LVDS data bit A3
27	LVDS OUT2 A3+	Positive differential LVDS data bit A3
28	GND	Ground
29	LVDS OUT2 A4-	Negative differential LVDS data bit A4
30	LVDS OUT2 A4+	Positive differential LVDS data bit A4
31	GND	Ground
32	GND	Ground
33	GND	Ground
34	GND	Ground
35	GND	Ground
36	GND	Ground
37	NC	No connection
38	NC NC	No connection
39		No connection
40	NC NC	No connection
41	NC	No connection

J5 - Panel power output connector: JS-1147A-08 Top 1.25mm (Matching type: JS-1146-08)

<u> </u>	i unci powci output	CONTINUOUS TITTA CO	Top 1:2011111 (Matching type: 00 1140 00)
	PIN	SYMBOL	DESCRIPTION
	1	PVLCD_Low (3,3V/5V)	Panel power supply (3,3V/5V)
	2	PVLCD_Low (3,3V/5V)	Panel power supply (3,3V/5V)
	3	GND	Ground
	4	GND	Ground
	5	GND	Ground
	6	PVLCD_High	Panel power supply (+10V / 12V / 18V)
	7	PVLCD_High	Panel power supply (+10V / 12V / 18V)
	8	PVLCD High	Panel power supply (+10V / 12V / 18V)

J6 - eDP (1.2) connector: I-PEX 20455-030E-12 (Matching type: I-PEX 20454-030T)

PIN	SYMBOL	DESCRIPTION
1	GND	Ground
2	GND	Ground
3	GND	Ground
4	GND	Ground
5	PANEL_VCC	Panel power selected by JA15
6	PANEL_VCC	Panel power selected by JA15
7	PANEL_VCC	Panel power selected by JA15
8	PANEL_VCC	Panel power selected by JA15
9	NC	NC
10	DP_TX_33V	Power for connector (3.3V 500mA)
11	GND	Ground
12	DPTX_HPD	Hot Plug Detect
13	DPTX_AUX_N	Auxiliary Channel (negative)
14	GND	Ground

15	DPTX_AUX_P	Auxiliary Channel (positive)
16	GND	Connected to Ground
17	GND	Connected to Ground
18	DPTX_L3N	Lane 3 (negative)
19	GND	Ground
20	DPTX_L3P	Lane 3 (positive)
21	DPTX_L2N	Lane 2 (negative)
22	GND	Ground
23	DPTX_L2P	Lane 2 (positive)
24	DPTX_L1N	Lane 1 (negative)
25	GND	Ground
26	DPTX_L1P	Lane 1 (positive)
27	DPTX_L0N	Lane 0 (negative)
28	GND	Ground
29	DPTX_L0P	Lane 0 (positive)
30	GND	Ground

J7 – V-by-One panel signal output connector: JAE FI-RE51S-HF (Matching type : JAE FI-RE51HL)

J <u>7 – V-by-One panel</u>	sign		E FI-RE51S-HF (Matching type : JAE FI-RE51HL)
PIN		SYMBOL	DESCRIPTION
1	(51)	GND	Ground
2	(50)	VB1_TX7P	V-by-One HS Data Lane 7
3	(49)	VB1_TX7N	V-by-One HS Data Lane 7
4	(48)	GND	Ground
5	(47)	VB1_TX6P	V-by-One HS Data Lane 6
6	(46)	VB1_TX6N	V-by-One HS Data Lane 6
7	(45)	GND	Ground
8	(44)	VB1_TX5P	V-by-One HS Data Lane 5
9	(43)	VB1_TX5N	V-by-One HS Data Lane 5
10	(42)	GND	Ground
11	(41)	VB1_TX4P	V-by-One HS Data Lane 4
12	(40)	VB1_TX4N	V-by-One HS Data Lane 4
	(39)	GND	Ground
14	(38)	VB1_TX3P	V-by-One HS Data Lane 3
	(37)	VB1_TX3N	V-by-One HS Data Lane 3
16	(36)	GND	Ground
17	(35)	VB1_TX2P	V-by-One HS Data Lane 2
18	(34)	VB1_TX2N	V-by-One HS Data Lane 2
19	(33)	GND	Ground
20	(32)	VB1_TX1P	V-by-One HS Data Lane 1
21	(31)	VB1_TX1N	V-by-One HS Data Lane 1
22	(30)	GND	Ground
23	(29)	VB1_TX0P	V-by-One HS Data Lane 0
24	(28)	VB1_TX0N	V-by-One HS Data Lane 0
25	(27)	GND	Ground
26	(26)	LOCKN	V-by-One LOCK
27	(25)	HTPDN	V-by-One HTPDN
28	(24)	OP10	High/Low state control
29	(23)	OP9	High/Low state control
30	(22)	OP8	High/Low state control
31	(21)	OP7	High/Low state control
32	(20)	OP6	High/Low state control
33	(19)	OP5 / PANEL_SCL	High/Low state control / Panel I <sup>2</sup> C SCL
34	(18)	OP4 / PANEL_SDA	High/Low state control / Panel I <sup>2</sup> C SDA
35	(17)	OP3	High/Low state control
36	(16)	OP2	High/Low state control
37	(15)	OP1	High/Low state control
38	(14)	GND	Ground
39	(13)	GND	Ground
40	(12)	GND	Ground
	(11)	GND	Ground
42	(10)	GND	Ground
43	(9)	NC	No Connection
44	(8)	PVLCD_High	Panel power supply (selected by JA15 & JP2)
45	(7)	PVLCD_High	Panel power supply (selected by JA15 & JP2)
46	(6)	PVLCD_High	Panel power supply (selected by JA15 & JP2)
47	(5)	PVLCD_High	Panel power supply (selected by JA15 & JP2)
48	(4)	PVLCD High	Panel power supply (selected by JA15 & JP2)
49	(3)	PVLCD_High	Panel power supply (selected by JA15 & JP2)
50	(2)	PVLCD_High	Panel power supply (selected by JA15 & JP2)
51	(1)	PVLCD_High	Panel power supply (selected by JA15 & JP2)
(1) (51): Pin# road on	_ \ /		i and power supply (selected by Unit & di Z)

<sup>(1) - (51):</sup> Pin# read on panel side.

J10 - On-board LED backlight driver connection: Molex 53261-1000 (Matching type: Molex 51021-1000)

	<u> </u>	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \
PIN	SYMBOL	DESCRIPTION
1	LED_VLED1+	Channel A – Anode
2	LED_VLED1+	Channel A – Anode
3	LED_CH4	Channel A – Cathode 1
4	LED_CH3	Channel A – Cathode 2
5	LED_CH2	Channel A – Cathode 3
6	LED_CH1	Channel A – Cathode 4
7	NC	No Connection
8	NC	No Connection
9	NC	No Connection
10	NC	No Connection

LED1 - Status LED connector: 3-pin header

PIN	DESCRIPTION
1	Green LED pin (anode)
2	LED pin common (cathode)
3	Red LED pin (anode)

P1 - DVI-I (Dual link) in

PIN	SYMBOL	DESCRIPTION
1	/RX2	TMDS Data 2-
2	RX2	TMDS Data 2+
3	GND	Digital Ground
4	/Rx4	TMDS Data 4-
5	Rx4	TMDS Data 4+
6	DDC_CLK	DDC Clock
7	DDC_DAT	DDC Data
8	VS_IN	Analog Vertical Sync
9	/RX1	TMDS Data 1-
10	RX1	TMDS Data 1+
11	GND	Digital Ground
12	/Rx3	TMDS Data 3-
13	Rx3	TMDS Data 3+
14	DDC_5V	+5V power supply for DDC (optional)
15	GND	Ground
16	HPD	Hot Plug Detect
17	/RX0	TMDS Data 0-
18	RX0	TMDS Data 0+
19	GND	Digital Ground
20	/Rx5	TMDS Data 5-
21	Rx5	TMDS Data 5+
22	GND	Digital Ground
23	RXC	TMDS Clock+
24	/RXC	TMDS Clock-
C1	RIN	Analog Red
C2	GIN	Analog Green
C3	BIN	Analog Blue
C4	HS_IN	Analog horizontal sync
C5	GND	Ground
C6	NC	No connection

P2 - HDMI (1.4) connector

PIN	SYMBOL	DESCRIPTION
1	DATA2+	TMDS Data2+
2	DATA2S	TMDS Data2 Shield
3	DATA2-	TMDS Data2-
4	DATA1+	TMDS Data1+
5	DATA1S	TMDS Data1 Shield
6	DATA1-	TMDS Data1-
7	DATA0+	TMDS Data0+
8	DATA0S	TMDS Data0 Shield
9	DATA0-	TMDS Data0-
10	CLK+	TMDS Clock+
11	CLK@	TMDS Clock Shield
12	CLK-	TMDS Clock-
13	NC	No connection
14	NC	No connection
15	SCL	SCL (I <sup>2</sup> C Serial Clock for DDC)
16	SDA	SDA (I <sup>2</sup> C Serial Data Line for DDC)
17	GND	Ground

18	+5V	+5 V Power (max 50 mA)
19	HPDET	Hot Plug Detect

P3 - HDMI (1.4) connector

PIN	SYMBOL	DESCRIPTION
1	DATA2+	TMDS Data2+
2	DATA2S	TMDS Data2 Shield
3	DATA2-	TMDS Data2-
4	DATA1+	TMDS Data1+
5	DATA1S	TMDS Data1 Shield
6	DATA1-	TMDS Data1-
7	DATA0+	TMDS Data0+
8	DATA0S	TMDS Data0 Shield
9	DATA0-	TMDS Data0-
10	CLK+	TMDS Clock+
11	CLK@	TMDS Clock Shield
12	CLK-	TMDS Clock-
13	NC	No connection
14	NC	No connection
15	SCL	SCL (I <sup>2</sup> C Serial Clock for DDC)
16	SDA	SDA (I <sup>2</sup> C Serial Data Line for DDC)
17	GND	Ground
18	+5V	+5 V Power (max 50 mA)
19	HPDET	Hot Plug Detect

P4 - HDMI (2.0) connector

PIN	SYMBOL	DESCRIPTION
1	DATA2+	TMDS Data2+
2	DATA2S	TMDS Data2 Shield
3	DATA2-	TMDS Data2-
4	DATA1+	TMDS Data1+
5	DATA1S	TMDS Data1 Shield
6	DATA1-	TMDS Data1-
7	DATA0+	TMDS Data0+
8	DATA0S	TMDS Data0 Shield
9	DATA0-	TMDS Data0-
10	CLK+	TMDS Clock+
11	CLK@	TMDS Clock Shield
12	CLK-	TMDS Clock-
13	NC	No connection
14	NC	No connection
15	SCL	SCL (I <sup>2</sup> C Serial Clock for DDC)
16	SDA	SDA (I <sup>2</sup> C Serial Data Line for DDC)
17	GND	Ground
18	+5V	+5 V Power (max 50 mA)
19	HPDET	Hot Plug Detect

P5 - Display Port (1.2) connector

PIN	SYMBOL	DESCRIPTION
1	ML_Lane 0 (p)	Lane 0 (positive)
2	GND	Ground
3	ML_Lane 0 (n)	Lane 0 (negative)
4	ML_Lane 1 (p)	Lane 1 (positive)
5	GND	Ground
6	ML_Lane 1 (n)	Lane 1 (negative)
7	ML_Lane 2 (p)	Lane 2 (positive)
8	GND	Ground
9	ML_Lane 2 (n)	Lane 2 (negative)
10	ML_Lane 3 (p)	Lane 3 (positive)
11	GND	Ground
12	ML_Lane 3 (n)	Lane 3 (negative)
13	CONFIG1	connected to Ground
14	CONFIG2	connected to Ground
15	AUX CH (p)	Auxiliary Channel (positive)
16	GND	Ground
17	AUX CH (n)	Auxiliary Channel (negative)
18	Hot Plug	Hot Plug Detect
19	GND	Ground
20	DP_PWR	Power for connector (3.3 V 500 mA)

PP5 - 12V/24VDC input power: Molex 43045-0400 or compatible (Matching type: Molex 43025-0400 or compatible

PIN	DESCRIPTION
1	+12VDC / 24VDC in
2	Ground
3	+12VDC / 24VDC in
4	Ground


PP2 - Alternate 12V/24VDC input power: Molex 2 pin 0.156" pitch

PIN	DESCRIPTION	
1	+12VDC / 24VDC in	
2	Ground	

PP4 - External panel power input: Molex 43045-0400 or compatible (Matching type: Molex 43025-0400 or compatible)

PIN	DESCRIPTION	
1	External panel power	
2	Ground	
3	External panel power	
4	Ground	

#### **CONTROLLER DIMENSIONS**



**Ready-made 3D Pro-E (SLDPRT) drawing files -** Save time and effort for your system volumetric analysis design. Includes jpg file previews. Please go to download at http://www.digitalview.com/products/HX-4096-lcd-controller

The maximum thickness of the controller is 18.93mm with or without video add-on board (measured from bottom of PCB to top of components, including any underside components & leads). We recommend clearances of:

- 5mm from bottom of PCB if mounting on a metal plate we also recommend a layer of suitable insulation material is added to the mounting plate surface.
- 10mm above the components
- 3~5mm around the edges

Any of the holes shown above can be used for mounting the PCB, they are 3.2mm in diameter.

CAUTION: Ensure adequate insulation is provided for all areas of the PCB with special attention to high voltage parts such as the inverter.

#### **APPLICATION NOTES**

#### USING THE CONTROLLER WITHOUT BUTTONS ATTACHED

This is very straightforward:

- Firstly setup the controller/display system with the buttons. With controls attached and display system active make any settings for color, tint and image position as required then switch everything off.
- Remove the control switches, the 12-way (CNC1) cable.
- Use a jumper or similar to connect pins 1 & 2 on JP6, this will fix the board On.
- Refer to inverter specifications for details as to fixing brightness to a desired level, this may require a resistor, an open circuit or closed circuit depending on inverter.

**Summary:** On CNC1 the only pins that are used are for On/Off and Brightness (if controller mounted inverter is used). On CNC1 the pins are for momentary type buttons so it doesn't matter that no buttons are attached.

#### **INVERTER CONNECTION**

There are potentially 3 issues to consider with inverter connection:

- Power
- Enable
- Brightness

Please read the following sections for a guide to these issues.

**Inverter Power**: As per the table for CNB1 pin 1 is ground and pin 2 provides 12V/24V DC. This should be matched with the inverter specification: see table.

#### CNB<sub>1</sub>

PIN	DESCRIPTION
1	Ground
2	+12V/+24VDC

Remark: For higher power inverter, more current (for 12V/24V) can be taken from CNA1 pin 1.

**Enable**: This is a pin provided on some inverters for On/Off function and is used by this panel controller for VESA DPMS compliance. If the inverter does not have an enable pin or the enable pin is not used then DPMS will not be operational. Pin 3 should be matched to the inverters specification for the 'enable' or 'disable' pin.

#### CNB<sub>1</sub>

<u> </u>	
PIN	DESCRIPTION
3	Enable

Further, jumpers JB2 & JB3 should be set to match the inverters specification for the enable pin power and High or Low setting: see table.

Ref	Purpose	Note
JB2	Inverter enable voltage	1-2 H = 3.3V, 2-3 H = 5V, OPEN H = open collector
JB3	Inverter control	1-2 H = On, 2-3 L = On

**Brightness**: There are various methods for brightness control and it is important to consider the specifications for the inverter to be used. Generally the situation is:

- Brightness can control by using a resistor or VR (Variable Resistor).
- Brightness controlled by adding a circuit such as PWM (Pulse Width Modulation).
- · No adjustment of brightness is possible.

CNB1 pins 4 & 5 are available for connecting to an inverter or circuit where VR control is supported.

#### CNB1


PIN	DESCRIPTION
4	VR WIP
5	VR A

This can then be matched with function controls connected to CNC1 pins 4 & 3 or 5: see table.

## CNC1

PIN	DESCRIPTION
3	VR A
4	VR WIP
5	VR B

#### **Design Guideline for making VR circuitry:**



## Signal description / Notes:

1) R1: 470ohm on board

2) RPOT is an external potentiometer (in-line dip style) that can be plugged directly into CNC1 pins 3,4,5. RPOT must be supplied / installed by user.

3) BVR\_B: Voltage tapped from "top" of potentiometer, the node of R1 and RPOT.

4) BVR\_WIP: Voltage tapped from wiper arm of RPOT.

5) BVR\_A: Voltage tapped from "bottom" of RPOT.

Note: BVR\_A voltage is left floating on the controller board. To use this circuit, you need to tie this point to a potential (usually GND, available at CNC1 pin 6).

CNB1 - Backlight inverter connector: JST B5B-XH-A (Matching type: XHP-5)

PIN	SYMBOL	DESCRIPTION
1	GND	Ground
2	VBKL	+12V/24VDC, backlight power supply
3	BLCTRL	On/Off control (enable) - see JB2 & JB3
4	BVR_WIP	Brightness VR - WIP
5	BVR_A	Brightness VR A

CNC1 - OSD switch mount control, Hirose DF13A-12P-1.25H (Mating type: DF13-12S-1.25C)

Citor Cob switch mount control, throse by tox 121 1.2011 (mating type: b) to 120 1.200)		A 121 1:2011 (Mating type : Di 10 120 1:200)
PIN	SYMBOL	DESCRIPTION
1	PSWIN	Power button A
2	SW_ON	Power button B
3	BVR_A	Backlight Brightness VR pin A
4	BVR_WIP	Backlight Brightness R pin WIP
5	BVR_B	Backlight Brightness VR pin B (470 ohm resistor to +5V Vcc)
6	GND	Ground
7	MENU	OSD menu
8	-/LEFT	OSD -/Left
9	+/RIGHT	OSD +/Right
10	SEL_DN	OSD Select down
11	SEL_UP	OSD Select up
12	NC	No connection

The VR for brightness depends on the inverter. The main power load for On/Off is handled by a relay on the controller.

#### Example for circuit design:

- 1.)Choose RPOT = 10K
- 2.) Tie BVR A to GND
- 3.) Circuit analysis gives BVR\_WIP as the following (see Figure 1)

 $BVR\_WIP = 5 x (Rbc/10.47)$ 


where BVR\_WIP is in Volts.

And Rbc is the resistance from the wiper arm to bottom of pot in Kohms.

To evaluate, plug in different values of Rbc:

Rbc	BVR_WIP
0	0 V
2.5 K	1.2 V
5 K	2.4 V
7.5 K	3.6 V
10 K	4.8 V

So this circuit could provide Brightness adjust voltage ranging from 0V to 5V.



Specifications subject to change without notice

#### **TROUBLESHOOTING**

#### General

A general guide to troubleshooting a flat panel display system it is worth considering the system as separate elements, such as:

- Controller (jumpers, PC settings)
- Panel (controller, cabling, connection, panel, PC settings)
- Backlight (inverter, cabling, backlight tubes)
- Cabling
- Computer system (display settings, operating system)

Through step by step cross checking with instruction manuals and a process of elimination to isolate the problem it is usually possible to clearly identify the problem area.

#### No image:

- If the panel backlight is not working it may still be possible to just see some image on the display.
- A lack of image is most likely to be caused by incorrect connection, lack of power, failure to provide a signal or incorrect graphic card settings

#### Image position:

If it is impossible to position the image correctly, i.e. the image adjustment controls will not move the image far enough, then test using another graphics card. This situation can occur with a custom graphics card that is not close to standard timings or if something is in the graphics line that may be affecting the signal such as a signal splitter (please note that normally a signal splitter will not have any adverse effect).

#### Image appearance:

- A faulty panel can have blank lines, failed sections, flickering or flashing display
- > Incorrect graphics card refresh rate, resolution or interlaced mode will probably cause the image to be the wrong size, to scroll, flicker badly or possibly even no image.
- > Incorrect jumper settings on the controller may cause everything from total failure to incorrect image. CAUTION: Do not set the panel power input incorrectly.
- Sparkling on the display: faulty panel signal cable.

#### Backlight:

Items to check include: Power input, Controls, Inverter and Tubes generally in this order.

If half the screen is dimmer than the other half:

- > Check cabling for the inverter.
- For a specific backlight tube check the AC pins orientation (CAUTION: Never reverse any DC power pins).

#### Also:

- If adjusting brightness control has no effect the chances are that the VR rating or method of adjusting brightness is not compatible or correctly connected to the inverter.
- > If system does not power down when there is a loss of signal

#### Continued failure:

If unit after unit keeps failing consider and investigate whether you are short circuiting the equipment or doing something else seriously wrong.

Generally after common sense issues have been resolved we recommend step by step substitution of known working parts to isolate the problem.

The following are some of LED indicators onboard that can help to know the health status of the controller board:

#### LED1A

Green : Valid video signal received on the selected input port.
 Red : No video signal received on the selected input port.

• Green + Red : The board is fail to boot up. Suggest to send it back to factory for check.

• Off : The board is not powered on.

#### LED2

Red : +10V / +12V / +18V power is supplied to panel.
 Green : +3.3V / +5V power is supplied to panel.
 Off : No power is supplied to panel.

D1 (for V-by-One panel only)

Green : V-by-One's LOCKN signal is set LOW by panel when CDR (clock data recovery) taining is done and CDR

is locked.

Off : No V-by-One's signal is detected and locked.

## **SPECIFICATIONS**

Panel compatibility	Compatible with 4096x2160 resolutions of TFT LCD panels with V-by-One /eDP/LVDS panel interface.
	A specified BIOS and some factory adjustment is required for individual panel timings.
No. of colors	Up to 3 x 10 bit providing 1.06 billion colors.
Panel power	DC 3.3V, 5V, 10V, 12V, 18V
Panel signal	V-by-One (8 Lane) eDP (1.1 HBR) / (1.2 HBR2) LVDS (8 channel)
Video inputs	DVI-I (Dual Link) Display Port 1.2 HDMI 1.4 HDMI 2.0
Functions display	On screen display (OSD) of functions
OSD menu functions	Image controls: Panel brightness/contrast, Saturation, Hue, Color temperature, Sharpness, Aspect ratio, Rotate, Gamma, PIP/PBP.
OSD menu controls available	Power On/Off OSD Menu OSD Select up OSD Select down Setting + Setting -
Control interface	Buttons, RS-232, IR Remote control, Ethernet control
Audio	Digital audio line out (from header) with OSD volume control. (not amplified)
Settings memory	Settings are stored in non volatile memory
PC Connectivity	VGA / SVGA / XGA / SXGA / UXGA / WUXGA analog or digital
Controller dimensions	203.2mm x 154mm (8" x 6.06")
Power consumption	10W approx. (not including panel power consumption)
Power load maximum	The controller has an overall 3Amp current limit.
Input voltage	12V/24VDC +/- 5%
On board battery lifetime	3 years at storage (without applying power to the unit). The battery is not rechargeable.
Power protection	Fuse fitted (Resettable)
DC Power handling	Reverse power polarity protection is equipped on the board
Storage temperature limits	-40°C to +85°C
Operating temperature limits	0°C to +80°C
Use of memory on board	Volatile memory - 64KB SRAM (Parameters settings) - 128KB SRAM (OSD) - 1Gb SDRAM (Video buffer)
	Non-Volatile memory - 512KB Flash (Program data) - 12KB Flash (Parameters settings) - 16Mb Flash (System program) - 2Mb Flash (Web page data) - 512KB EEPROM (System settings)

- 2Kb EEPROM (Video input paramaters)	

## NOTES

- Please note the following:
  For specific panel setup a sample of an LCD may be required (this will be returned) and a copy of the full technical specifications for the panel from the manufacturer.
  Re-layout and custom development services are available.

## APPENDIX I - SIGNAL SUPPORT MODE TABLE

ARGB input port (P1): (with DVI to VGA adapter)

Resolution
Nesolution
640x480 60Hz
640x480 75Hz
800x600 56Hz
800x600 60Hz
800x600 72Hz
800x600 75Hz
1024x768 60Hz
1024x768 70Hz
1024x768 75Hz
1280x768 60Hz
1280x768 75Hz
1280x1024 60Hz
1280x1024 75Hz
1360x768 60Hz
1440x900 60Hz
1600x900 60Hz
1600x1200 60Hz
1680x1050 60Hz
1920x1080 60Hz
1920x1200 60Hz

## DVI input port (P1):

Resolution
640x480 60Hz
640x480 75Hz
800x600 56Hz
800x600 60Hz
800x600 72Hz
800x600 75Hz
1024x768 60Hz
1024x768 70Hz
1024x768 75Hz
1280x768 75Hz
1280x800 75Hz
1280x1024 60Hz
1280x1024 75Hz
1360x768 60Hz
1366x768 60Hz
1440x900 75Hz
1600x1200 75Hz
1680x1050 75Hz
1920x1080 60Hz
1920x1200 60Hz
2560x1600 60Hz
3840x2160 30Hz

# HDMI 1.4 input port (P2 / P3):

Resolution
640x480 60Hz
640x480 72Hz
640x480 75Hz
800x600 56Hz
800x600 60Hz
800x600 72Hz
800x600 75Hz
1024x768 60Hz
1024x768 70Hz
1024x768 75Hz
1280x768 60Hz
1280x768 75Hz
1280x800 60Hz
1280x800 75Hz
1280x1024 60Hz
1280x1024 75Hz
1360x768 60Hz
1366x768 60Hz
1440x900 75Hz
1600x1200 75Hz
1680x1050 75Hz
1920x1080 60Hz
1920x1200 60Hz
2560x1600 60Hz
3840x2160 30Hz

HDMI 2.0 input port (P4):
Resolution
640x480 60Hz
640x480 72Hz
640x480 75Hz
800x600 56Hz
800x600 60Hz
800x600 72Hz
800x600 75Hz
1024x768 60Hz 1024x768 70Hz
1024x768 75Hz 1280x768 60Hz
1280x768 75Hz
1280x800 60Hz
1280x800 75Hz
1280x1024 60Hz
1280x1024 75Hz
1360x768 60Hz
1366x768 60Hz
1440x900 75Hz
1600x1200 75Hz
1680x1050 75Hz
1920x1080 60Hz
1920x1200 60Hz
2560x1600 60Hz
3840x2160 30Hz
3840x2160 60Hz
4096x2160 60Hz


Display port 1.2 input port (P5):
Resolution
640x480 60Hz
640x480 72Hz
640x480 75Hz
720x480 60Hz
720x576 50Hz
800x600 56Hz
800x600 60Hz
800x600 72Hz
800x600 75Hz
1024x768 60Hz 1024x768 70Hz
1024x768 75Hz
1280x768 60Hz
1280x800 60Hz
1280x1024 60Hz
1280x1024 75Hz
1366x768 60Hz
1400x1050 60Hz
1440x900 60Hz
1600x900 60Hz
1600x1200 60Hz
1680x1050 60Hz
1920x1080 60Hz
1920x1200 60Hz
2560x1600 60Hz
3840x2160 30Hz
3840x2160 60Hz
4096x2160 60Hz

## Appendix II - Network connection

The HX-4096 LCD interface controller has an RJ-45 Ethernet port for control and monitoring over a network. This application note introduces the two user interface modes:

- Command line direct mode
- Browser based web server mode

Before enter the above modes, make sure the Network option has been enabled in OSD menu settings. On OSD menu, go to "Advanced" -> "Communication" -> "Network" -> Press Down key to select and confirm. See below:



#### **QUICK GUIDE**


For experienced users the following quick guide to trying out the network connection and functions may be useful.

Command line direct mode: The RS-232 commands available are the same as documented in Appendix III and writing a control application is very similar to the RS-232 type except the commands must pass through the network. An alternative is to use an application written for RS-232 communication and use a virtual serial port program such as "TCP-COM" (<a href="http://www.taltech.com/products/tcpcom.html">http://www.taltech.com/products/tcpcom.html</a>)


This software can create "Virtual" RS-232 serial ports that are actually connections to a TCP/IP port. This allows you to use existing Windows based serial communications software to send and receive data across TCP/IP network. (Note: The 3<sup>rd</sup> party program is not warranted nor is it the responsibility of Digital View.)

Below are the example of using TCP-COM and serial communication software (e.g. Access Port) to adjust brightness value of HX-4096 over LAN.


1. Open the "TCP-Com" program and set the following settings and then click activate.



2. Open "AccessPort" serial communication software. Tick "Port Switch" and then go to "Tool" → "Configuration" to follow the settings stated below :



 Start to type RS-232 command under serial communication program (e.g AccessPort) to control the HX-4096.



## Some command examples:

C8 30	[Soft power off]
C8 31	[Soft power on]
81 36 34	[Adjust brightness to max. value]
98 50 31	[Jump to Display Port input]

#### Browser based web server mode:



- Works with a normal network with DHCP, i.e. must use a router on LAN.
- Connect the HX-4096 to the LAN network and ensure power is on.
- Use the IP Locator utility available from the IP-60 web-page. http://www.digitalview.com/media/downloads/IPLocator.zip (Windows only)
- Double click on the IP address in the IP Locator window, it will open the HX-4096 browser page in your default browser. Alternatively copy the IP address into your browser address line.
- Test the functions that come up on the browser. The function list on browser can be found in Appendix VII. (Some sensor functions might require alternative firmware version.)

For details, please refer to the separate application note.

## Appendix III - RS-232 control protocols and command set

## RS-232 Serial control (Baud rate 2400), 8 bits, 1 stop bit and no parity

Physical connection:


Controller side Connector interface: CN8 Mating connector : JST XHP-6



Mating face of CN8

Computer side

Connector interface: Serial port Mating connector: DB9 Female



Mating face of RS-232 DB9 Male

PIN#	Description
4	RS-232 Tx Data
5	Ground
6	RS-232 Rx Data

PIN#	Description
2	RS-232 Rx Data
3	RS-232 Tx Data
5	Ground

#### Remark:

(1): RS-232 connection cable, 600mm P/N 426090200-3 can be ordered separately for connection.

Software connection:

The OSD function can be controlled through sending the RS-232 protocol.

The RS-232 program can be custom-made to fit for application or it can be used the serial control program, like Accessport, Telix or Serial Utility program developed by DigitalView. Please contact your local support for information.

## 1. Commands to implement switch mount control buttons

Function	Command	Description	Remark
Menu button	0xf7	Menu button pressed	Button equivalent
Select-down button	0xfa	Select-down button pressed	Button equivalent
Select-up button	0xfb	Select-up button pressed	Button equivalent
Right/+ button	0xfc	Right/+ button pressed	Button equivalent
Left/- button	0xfd	Left/- button pressed	Button equivalent

## 2. Parameter setting - immediate, relative, reset and query

Function	Command	Description	Acknowledge (if enabled)
Volume control -	0x80, "a"   "A",	Set audio (L+R) volume =	nn = 0x00~ 0x64 (0~100%)
left+right channel	nn   "+"   "-"	value/increment/decrement	
	"r"   "R"	Reset	Default: 0x32 (50%)
	"?"	Query	
Volume control -	0x80, "m"   "M",		"0" - audio off (mute).
on/off (mute)	"0"	Disable audio output.	"1" - audio on. (Default)
	"1"	Enable audio output.	
	"r"   "R"   "2"	Reset	
	· ·	Query	
Audio selection	0x80, "P",		"n" =
	"n"	Select Audio Output	"0" - P1 (upper left picture) (Default)
	"?"	Query	"1" - P2 (lower left picture)
	"r"   "R"	Reset	"2 "- P3 (upper right picture)
			"3" - P4 (lower right picture)
			"A/a" – Analog source
			Note: P1~P4 audio source is available
			when video source is either DP or
			HDMI
Brightness control	0x81,	Set brightness =	nn = 0x00~ 0x64 (0~100%)
· ·	nn   "+"   "-"	value/increment/decrement	,
	"r"   "R"	Reset	Default: 0x32 (50%)
	"?"	Query Current Source	
	"m"	Maximum query	
	"n"	Minimum query	
Contrast control	0x82, "a"   "A",	Set contrast =	$nn = 0x00 \sim 0x64 (0 \sim 100\%)$
	nn   "+"   "-"	value/increment/decrement	D ( 11 0 00 (500()
	"r" "R"  "?"	Reset	Default: 0x32 (50%)
	"m"	Query Maximum query	
	"n"	Minimum query	
Color saturation	0x83,	Set color saturation =	nn = 0x00~ 0x64 (0~100%)
control	nn   "+"   "-"	value/increment/decrement	1111 = 00000 0004 (0.0100 %)
CONTROL	"r" "R"	Reset	Default: 0x32 (50%)
	"?"	Query	Boldan: 0x02 (0070)
	"m"	Maximum query	
	"n"	Minimum query	
Hue control	0x84,	Set tint =	nn = 0x00~ 0x64 (0~100%)
	nn   <sup>•</sup> +"   "-"	value/increment/decrement	,
	"r"   "R"	Reset	Default: 0x32 (50%)
	"?"	Query	, ,
	"m"	Maximum query	
	"n"	Minimum query	
Phase control (only	0x85,	Set phase =	$nn = 0x00 \sim 0x64 (0 \sim 100\%)$
for VGA port)	nn   "+"   "-"	value/increment/decrement	
1 11 10	"?"	Query	0.00.004(0.4000)
Image H position	0x86,	Set horizontal position =	$nn = 0x00 \sim 0x64 (0 \sim 100\%)$

( 1 ( ) ( O A 1 )			1
(only for VGA port)	nn   "+"   "-"	value/increment/decrement	
	"r"   "R"   "?"	Reset	
	•	Query	
Image V position	0x87,	Set vertical position =	$nn = 0x00 \sim 0x64 (0 \sim 100\%)$
(only for VGA port)	nnnn   "+"   "-"	value/increment/decrement	
	"r" "R"	Reset	Default: 0x32 (50%)
	"?"	Query	
Sharpness	0x8a,	Set sharpness =	nn = 0x00~ 0x64 (0~100%)
·	n   "+"   "-"	value/increment/decrement	
	"r" "R"	Reset	Default: 0x32 (50%)
	"?"່	Query	, ,
Clock control (only	0x8b,	Set VGA clock=	$nn = 0x00 \sim 0x64 (0 \sim 100\%)$
for VGA port)	nn   "+"   "-"	Value/increment/decrement	(3 22.2)
	"?"	Query	
Aspect Ratio	0x8c,	Set video aspect ratio=	"0" – 1:1
7 topoot i tatio	"0"   "1"   "9"   "A"	Value	"1" - fill screen (Default)
	"F"	Reset	"9" – 4:3
	"r" "R"	Query	"A" – 16:9
	"?"	Query	"F" – 5:4
Set display	0x8e,	Sat display orientation	"0" – normal (0 degree) (Default)
Set display orientation		Set display orientation = value	"4" – rotated 90
onentation	n     "-"   "D"		
	"r"   "R"   "2"	Reset	"5" – rotated 180
	· ·	Query	"6" – rotated 270
			Note: Rotation is only allowed in 1P
D 00D	0.01		mode (D.
Rotate OSD	0x8f,		"0" - normal OSD. (Default)
	"0"	Normal OSD rotate	"1" - rotated 90 OSD.
	"1" [	rotated 90	"3" - rotated 270 OSD.
	"3"	rotated 270	
	"?"	Query	
OSD H position	0x90,	Set OSD horizontal position =	$nn = 0x00 \sim 0x64$ (left $\sim$ right)
	nn   "+"   "-"	value/increment/decrement	
	"r"   "R"	Reset	Default: 0x32 (middle)
	"?"	Query	
OSD V position	0x91,	Set OSD vertical position =	$nn = 0x00 \sim 0x64 \text{ (top } \sim \text{bottom)}$
	nn   <sup>"</sup> +"   "-"	value/increment/decrement	
	"r"   "R"	Reset	Default: 0x32 (middle)
	"?"	Query	
OSD transparency	0x92,	Set OSD transparency =	$nn = 0x00 \sim 0x64 (0 \sim 100\%)$
, ,	nn   "+"   "-"	value/increment/decrement	,
	"r"   "R"	Reset	Default: 0x00 (No transparency)
	"?" <sup>·</sup>	Query	, , , , , , , , , , , , , , , , , , , ,
OSD menu timeout	0x93,	Select menu timeout =	OSD menu timeout value.
	nn   "+"   "-"	value/increment/decrement	nn = 0x0A - Always on
	' ' '		nn = 0x0B - 0x3C (11~60sec)
	"r" "R"	Reset	Default: 0x0B (11sec)
	"?"	Query	
Input main video	0x98,	Select P1 video input =	
(P1) select	nn   "+"   "-"	value/next input/previous input	"nn" =
(. 1) 301001			
Ī	"r"   "R"	I Reset	$\Gamma = (1) \times $
	"r"   "R"	Reset	"0x41,0x31" A0: VGA
	"r" "R"  "?"	Query	"0x50, 0x31"D0: DP (Default)
	"r"   "R"		"0x50, 0x31"D0: DP (Default) "0x48,0x31" D1: HDMI
	"r"   "R"		"0x50, 0x31"D0: DP (Default) "0x48,0x31" D1: HDMI "0x48,0x32" D2: HDMI
	"r"   "R"		"0x50, 0x31"D0: DP (Default) "0x48,0x31" D1: HDMI "0x48,0x32" D2: HDMI "0x48,0x33" D3: HDMI
	"r"   "R"		"0x50, 0x31"D0: DP (Default) "0x48,0x31" D1: HDMI "0x48,0x32" D2: HDMI "0x48,0x33" D3: HDMI "0x45,0x31" D3: HD-SDI (for custom
	"r"   "R"		"0x50, 0x31"D0: DP (Default) "0x48,0x31" D1: HDMI "0x48,0x32" D2: HDMI "0x48,0x33" D3: HDMI "0x45,0x31" D3: HD-SDI (for custom code only)
	"r"   "R"   "?"	Query	"0x50, 0x31"D0: DP (Default) "0x48,0x31" D1: HDMI "0x48,0x32" D2: HDMI "0x48,0x33" D3: HDMI "0x45,0x31" D3: HD-SDI (for custom
Auto source seek	"r"   "R"   "?" 0x99,	Query  Set auto source seek =	"0x50, 0x31"D0: DP (Default) "0x48,0x31" D1: HDMI "0x48,0x32" D2: HDMI "0x48,0x33" D3: HDMI "0x45,0x31" D3: HD-SDI (for custom code only)
Auto source seek	"r"   "R"   "?"  0x99, "0"   "1"	Query  Set auto source seek = Disable/Enable	"0x50, 0x31"D0: DP (Default) "0x48,0x31" D1: HDMI "0x48,0x32" D2: HDMI "0x48,0x33" D3: HDMI "0x45,0x31" D3: HD-SDI (for custom code only) "0x46,0x31" D4: DVI
Auto source seek	"r"   "R"   "?" 0x99,	Query  Set auto source seek =	"0x50, 0x31"D0: DP (Default) "0x48,0x31" D1: HDMI "0x48,0x32" D2: HDMI "0x48,0x33" D3: HDMI "0x45,0x31" D3: HD-SDI (for custom code only)

r	T	T =	T a m
Source Layout	0x9a, n   "r"   "R"   "?"	Select video source layout = Single, PIP, PBP, 4P Reset, Query	"n": "0"- 1P (Single) (Default) "1"- 2P PIP "2"- 2P PBP (Left Right) "3"- 2P PBP (Top Bottom)
			"4"- 4P
GAMMA value select	0x9d, n   "r"   "R" "?"	Select GAMMA value = Value Reset Query	"n": "5" - 1.8, "7" - 2.0, "2" - 2.2, (Default) "A" - 2.4
Auto power off	0x9f, "0"   "1"   "r"   "R"   "?"	Set auto power save option = Disable/Enable Reset Query	"n":  "0" – Disable auto power off  "1" – Enable auto power off (Default)
Hot key 1 (plus and minus keys)	0xa0, "1", n   "r"   "R"   "?"	Set Hot key 1= Value Reset Query	"n": "1" – volume "2" – brightness "3" – contrast "4" – color saturation "5" – input source (P1 source) "9" – PIP size "B" – No hot key function (Default) "D" – PIP Swap "E" – Aspect ratio "G" – Hue "H" – Backlight level "I" – VGA Auto picture adjust "L" - Sharpness "M" - Display mode (select 1P, 2P PIP, 2P PBP or 4P)
Hot key 2 (up and down keys)	0xa0, "2", n   "r"   "R"   "?"	Set Hot key 2= Value Reset Query	"n": "1" - volume "2" - brightness "3" - contrast "4" - color saturation "5" - input source (P1 source) "9" - PIP size "B" - No hot key function (Default) "D" - PIP Swap "E" - Aspect ratio "G" - Hue "H" - Backlight level "I" - VGA Auto picture adjust "L" - Sharpness "M" - Display mode (select 1P, 2P PIP, 2P PBP or 4P)
Runtime counter	0xa1, nnnnn   "r"   "R"   "?"	Set runtime counter value = nnnnn (* 0.5 hour) Reset to zero Query	Runtime = nnnnn.  Max. input = 0x1fffe (0x1fffe * 0.5 hour = 65535 hours)  Runtime counter counts when backlight is on
PIP H position	0xa4, nn   "+"   "-"   "r"   "R"   "?"	Set PIP horizontal position= value/go right/go left Reset Query	PIP window horizontal position. nn: 0x00(left)~0x64(right) Default: 0x64
PIP V position	0xa5, nn   "+"   "-"   "r"   "R"   "?"	Set PIP vertical position= value/go down/go up Reset Query	PIP window vertical position. nn: 0x00(top)~0x64(bottom) Default: 0x64
PIP window size select	0xa6, nn   "r"   "R"	Select PIP window size = PIP window size value Reset	nn: 0x00(smallest)~0x0A (largest) Default: 0x0A

	"?"	Query	
select	0xa7, nn   "r"   "R"   "?"	Select PIP or P2 video source = Video source value Reset Query	P2 is: 2P PBP left right: right window 2P PBP top bottom: bottom window 4P: lower left window
			"nn" = "0x41,0x31" A0: VGA "0x50,0x31" D0: DP "0x48,0x31" D1: HDMI (Default) "0x48,0x32" D2: HDMI "0x48,0x33" D3: HDMI "0x45,0x31" D3: HD-SDI (for custom code only) "0x46,0x31" D4: DVI
D2 course coloct	0,457 "6"	Calcat D2 video acureo	Please note that PIP or PBP mode should be enabled first before select video source.
	0xa7, "c" nn   "r"   "R"	Select P3 video source = Video source value Reset	P3 is upper right window in 4P mode "nn" =
	"?"	Query	"0x41,0x31" A0: VGA "0x50,0x31" D0: DP "0x48,0x31" D1: HDMI "0x48,0x32" D2: HDMI (Default) "0x48,0x33" D3: HDMI "0x45,0x31" D3: HD-SDI (for custom code only) "0x46,0x31" D4: DVI
			Please note that 4P PBP mode should be enabled first before select video source.
	0xa7, "d" nn   "r"   "R"   "?"	Select P4 video source = Video source value Reset Query	P4 is lower right window in 4P mode  "nn" =  "0x41,0x31" A0: VGA  "0x50,0x31" D0: DP  "0x48,0x31" D1: HDMI  "0x48,0x32" D2: HDMI  "0x48,0x33" D3: HDMI (Default)  "0x45,0x31" D3: HD-SDI (Default, for custom code only)  "0x46,0x31" D4: DVI  Please note that 4P PBP mode should
	0.1.0		be enabled first before select video source.
select	0xb3, n   "r"   "R"   "?"	Select colour temperature = value Reset Query	"n" = "2" - 6500K. (Default) "4" - User "5" - 9300K "6" - 7500K "7" - 5800K "8" - sRGB "9" - 3200K "A" - 2600K (custom code)
colour temperature	0xb4, nn   "+"   "-"   "r"   "R"	Set the level of the red channel for the user colour temp. = value/increment/decrement Reset	nn: 0x00~ 0xff (0~255)  Default: 0x80

"?"   Query   Maximum query   Minimum query   Maximum query   Maximum query   Maximum query   Default: 0x80
The colour temperature   Col
The colour temperature   Col
Set the level of the green channel for the user colour temp.   nn: 0x00~ 0xff (0~255)
Colour temperature
In   "+"   "-"
In   "+"   "-"
""   "R"
Pesst
"m"
"n"   Maximum query   Minimum query   Minimum query   Minimum query
"n"   Maximum query   Minimum query   Minimum query   Minimum query
Minimum_query
Blue level of User colour temperature   0xb6,   Set the level of the blue channel for the user colour temp. = value/increment/decrement Reset Query   Maximum query   Minimum query   Minimu
Blue level of User colour temperature   0xb6,   Set the level of the blue channel for the user colour temp. = value/increment/decrement Reset Query   Maximum query   Minimum query   Minimu
colour temperature         nn   "+"   ""   ref   "R"   value/increment/decrement Reset Query         Default: 0x80           Video horizontal resolution enquiry         0xb7         Horizontal resolution (in pixels) in 3 to 4 digit hex number           Video vertical resolution enquiry         0xb8         Vertical resolution (in lines) in 3 digit hex number           Video vertical sync frequency Video vertical sync frequency         0xb9         Horizontal sync frequency (in units of 12) in 3 digit hex number           Video vertical sync frequency         0xba         Vertical sync frequency (in units of 12) in 3 digit hex number and 1 char         nnn = 3 digit hex c=""">"""   """   """   ""   ""   ""   ""
No   '*-'   '*-'
Peset
Peset
"?"   Query   Maximum query   Maximum query   Maximum query   Maximum query   Minimum query
"m"   Maximum query   Minimum query   Minimu
Video horizontal resolution enquiry         "n"         Minimum query           Video horizontal resolution enquiry         0xb7         Horizontal resolution (in pixels) in 3 to 4 digit hex number           Video vertical resolution enquiry         0xb8         Vertical resolution (in lines) in 3 digit hex number           Video horizontal sync frequency         0xb9         Horizontal sync frequency (in units of 100Hz) in 3 digit hex number and 1 char         "nnnc" = vertical frequency nnn = 3 digit hex number           Video vertical sync frequency         0xba         Vertical resolution (in lines) in 3 digit hex number and 1 char         "nnnc" = vertical frequency nnn = 3 digit hex number           Video vertical sync frequency (in units of H2) in 3 digit hex number and 1 char         1 char         3 to 4 digit hex number           Video vertical sync frequency (in units of H2) in 3 digit hex number and 1 char         "nnnc" = vertical frequency nnn = 3 digit hex number           OSD status enquiry         0xbb         Status of OSD         "0" - OSD turned off           "1" - OSD turned off         "1" - OSD turned on         "1" - OSD turned on           Harry of a limit of the interval sync frequency (in units of H2) in 3 digit hex number         "1" - enabled. (Default)           Display video info box shown After switching to a new video source, the video info box is displayed for 5 seconds.         "0" - fail.           Display video info box shown After switching to a new video source in limit of th
Video horizontal resolution enquiry         "n"         Minimum query           Video horizontal resolution enquiry         0xb7         Horizontal resolution (in pixels) in 3 to 4 digit hex number           Video vertical resolution enquiry         0xb8         Vertical resolution (in lines) in 3 digit hex number           Video horizontal sync frequency         0xb9         Horizontal sync frequency (in units of 100Hz) in 3 digit hex number and 1 char         "nnnc" = vertical frequency nnn = 3 digit hex number           Video vertical sync frequency         0xba         Vertical resolution (in lines) in 3 digit hex number and 1 char         "nnnc" = vertical frequency nnn = 3 digit hex number           Video vertical sync frequency (in units of H2) in 3 digit hex number and 1 char         1 char         3 to 4 digit hex number           Video vertical sync frequency (in units of H2) in 3 digit hex number and 1 char         "nnnc" = vertical frequency nnn = 3 digit hex number           OSD status enquiry         0xbb         Status of OSD         "0" - OSD turned off           "1" - OSD turned off         "1" - OSD turned on         "1" - OSD turned on           Harry of a limit of the interval sync frequency (in units of H2) in 3 digit hex number         "1" - enabled. (Default)           Display video info box shown After switching to a new video source, the video info box is displayed for 5 seconds.         "0" - fail.           Display video info box shown After switching to a new video source in limit of th
Video horizontal resolution enquiry   Video horizontal resolution (in pixels) in 3 to 4 digit hex number   Video vertical resolution enquiry   Video horizontal sync frequency   Video horizontal sync frequency   Video vertical sync frequency (in units of 100Hz) in 3 digit hex number and 1 char   Vertical sync frequency (in units of 100Hz) in 3 digit hex number and 1 char   Vertical sync frequency (in units of 100Hz) in 3 digit hex number and 1 char   Vertical sync frequency (in units of 100Hz) in 3 digit hex number and 1 char   Vertical sync frequency (in units of 100Hz) in 3 digit hex number and 1 char   Vertical sync frequency (in units of 100Hz) in 3 digit hex number and 1 char   Vertical sync frequency (in units of 100Hz) in 3 digit hex number and 1 char   Vertical sync frequency (in units of 100Hz) in 3 digit hex number and 1 char   Vertical sync frequency (in units of 100Hz) in 3 digit hex number and 1 char   Vertical sync frequency (in units of 100Hz) in 3 digit hex number and 1 char   Vertical sync frequency (in units of 100Hz) in 3 digit hex number and 1 char   Vertical sync frequency (in units of 100Hz) in 3 digit hex number and 1 char   Vertical sync frequency (in units of 100Hz) in 3 digit hex number and 1 char   Vertical sync frequency (in units of 100Hz) in 3 digit hex number and 1 char   Vertical sync frequency (in units of 100Hz) in 3 digit hex number and 1 char   Vertical sync frequency (in units of 100Hz) in 3 digit hex number and 1 char   Vertical sync frequency (in units of 100Hz) in 3 digit hex number and 1 char   Vertical sync frequency (in units of 100Hz) in 3 digit hex number and 2 digit hex number and 2 in 3 digit hex number and 2 in 4 in 3 digit hex number and 2 in 4 in
Video vertical resolution enquiry   Video vertical resolution (in lines) in 3   vertical sync frequency (in units of 100Hz) in 3 digit hex number   vertical frequency (in units of 100Hz) in 3 digit hex number and 1 char   vertical sync frequency (in units of 100Hz) in 3 digit hex number and 1 char   vertical frequency (in units of 100Hz) in 3 digit hex number and 1 char   vertical frequency (in units of 100Hz) in 3 digit hex number and 1 char   vertical frequency (in units of 100Hz) in 3 digit hex number and 1 char   vertical frequency (in units of 100Hz) in 3 digit hex number and 1 char   vertical frequency (in units of 100Hz)   vertical sync frequency (in units of 120Hz)   vertical sync frequency (in units of 120Hz)   vertical sync frequency (in units of 120Hz)   vertical frequency (in units of 120Hz)   vertical sync frequency (in units of 120Hz)   vertical sync frequency (in units of 120Hz)   v
Note
Vertical resolution (in lines) in 3   digit hex number
Video horizontal sync frequency   Sync
Video horizontal sync frequency   Nove   Horizontal sync frequency   Nove   N
Video horizontal sync frequency   Nove   Horizontal sync frequency   Nove   N
Sync frequency   Units of 100Hz) in 3 digit hex number
Video vertical sync frequency (in units of Hz) in 3 digit hex number and 1 char  OSD status enquiry  Oxbb  Status of OSD  Display video information box  "7"   Oxbd  "1" Oxbd  Oxbd  Oxbc, "7"   Oxbd info box shown After switching to a new video source, the video info box is displayed for 5 seconds.  OSD turn off  Display video  Information box  Oxbd  Oxbd  Turn off the OSD.  Set Backlight level = value/increment/decrement Reset Query  Backlight On/Off  Oxe1, "7"   Backlight Off / Backlight On Reset Query  Swap PIP / 2P PBP video source  Swap PIP / 2P PBP video source  Backlight DA/PWM  Dacklight DA/PWM  Oxe5, "7" Oxe0, Information box shown After switching to a new video info box is displayed for 5 seconds.  Oxe1, "1" - successful. "1" - successful. "1" - successful. "1" - Backlight Off Oxe1, "7" Oyen - Backlight Off Oxe1, "7" Oxe3 Oxe3 Oxed - Oxe
Video vertical sync frequency (in units of Hz) in 3 digit hex number and 1 char  OSD status enquiry  Oxbb  Status of OSD  Display video information box  "7"   Oxbd  "1" Oxbd  Oxbd  Oxbc, "7"   Oxbd info box shown After switching to a new video source, the video info box is displayed for 5 seconds.  OSD turn off  Display video  Information box  Oxbd  Oxbd  Turn off the OSD.  Set Backlight level = value/increment/decrement Reset Query  Backlight On/Off  Oxe1, "7"   Backlight Off / Backlight On Reset Query  Swap PIP / 2P PBP video source  Swap PIP / 2P PBP video source  Backlight DA/PWM  Dacklight DA/PWM  Oxe5, "7" Oxe0, Information box shown After switching to a new video info box is displayed for 5 seconds.  Oxe1, "1" - successful. "1" - successful. "1" - successful. "1" - Backlight Off Oxe1, "7" Oyen - Backlight Off Oxe1, "7" Oxe3 Oxe3 Oxed - Oxe
Vertical sync frequency (in units of Hz) in 3 digit hex number and 1 char   1 char   2 first hex c= "i" (interlace) or "p" (progressive)
OF Hz) in 3 digit hex number and 1 char
OF Hz) in 3 digit hex number and 1 char
1 char   c = ";" (interlace) or "p" (progressive)
OSD status enquiry  Oxbb  Status of OSD  "0" – OSD turned off "1" – OSD turned on  "0" – disabled.  "1" – enabled. (Default)  "1" – enabled. (Default)  Oxeo, "1" – successful.  Backlight control  Oxeo, "nn   "+"   "-"   "R"   "r"   "R"   "r"   "PBP video source  Swap PIP / 2P PBP video source  Swap PIP / 2P PBP video source  Backlight DA/PWM  Oxes "0" – SET Backlight control method: "0" – Fail. "1" – successful.  Nn = 0x00~ 0x64 (0~100%)  "0" – Backlight On  "0" – Backlight Off "1" – Backlight On  Reset Query  "0" – Backlight Off "1" – Backlight Off "1" – Backlight On  Reset Query  "0" – Fail. "1" – Backlight Off "1" – Backlight On  Reset Query  "0" – Backlight Off "1" – Backlight On  Reset Query  "0" – Fail. "1" – Backlight On  "0" – Backlight On  "0" – Backlight On  "0" – Fail. "1" – Backlight On  "0" – Backlight On  "0" – Fail. "1" – Backlight On  "0" – Backlight On  "1" – Backlight On  "0" – Backlight On
Display video   Oxbc,   Query   No video info box shown   After switching to a new video source, the video info box is displayed for 5 seconds.   "0" - fail.   "1" - successful.     Oxeo, nn   "+"   "-"     Reset Query     Oxes     Oxed     Oxes     Oxes     Oxes   Oxer   Oxes
Display video information box  "?"   Query No video info box shown After switching to a new video source, the video info box is displayed for 5 seconds.  OSD turn off  Dxbd  Turn off the OSD.  Set Backlight level = value/increment/decrement Reset Query  Backlight On/Off  Backlight On/Off  """ - Backlight Off / Backlight On Reset Query  Swap PIP / 2P PBP video source  Swap Main and PIP Source (PIP mode), left & right source (PBP LR) or Top & Bottom (PBP TB)  Backlight DA/PWM  Oxe5  """ - disabled. "1" - enabled. (Default)  "0" - fail. "1" - successful.  nn = 0x00~ 0x64 (0~100%)  "1" - Backlight Off "1" - Backlight Off "1" - Backlight Off "1" - Backlight On. (Default)  "0" - fail. "1" - successful. "1" - su
Display video information box  "?"   Query No video info box shown After switching to a new video source, the video info box is displayed for 5 seconds.  OSD turn off  Dxbd  Turn off the OSD.  Set Backlight level = value/increment/decrement Reset Query  Backlight On/Off  Backlight On/Off  """ - Backlight Off / Backlight On Reset Query  Swap PIP / 2P PBP video source  Swap Main and PIP Source (PIP mode), left & right source (PBP LR) or Top & Bottom (PBP TB)  Backlight DA/PWM  Oxe5  """ - disabled. "1" - enabled. (Default)  "0" - fail. "1" - successful.  nn = 0x00~ 0x64 (0~100%)  "1" - Backlight Off "1" - Backlight Off "1" - Backlight Off "1" - Backlight On. (Default)  "0" - fail. "1" - successful. "1" - su
information box  "?"   Query No video info box shown After switching to a new video source, the video info box is displayed for 5 seconds.  OSD turn off  Oxbd  Turn off the OSD.  Backlight control  Oxe0,
"0"   No video info box shown After switching to a new video source, the video info box is displayed for 5 seconds.    OSD turn off
"0"   No video info box shown After switching to a new video source, the video info box is displayed for 5 seconds.    OSD turn off
After switching to a new video source, the video info box is displayed for 5 seconds.  OSD turn off  Oxbd  Turn off the OSD.  Set Backlight level = value/increment/decrement Reset Query  Backlight On/Off  Oxe1, "0"   "1"   Backlight Off / Backlight On Reset Query  Swap PIP / 2P PBP video source  Backlight DA/PWM  Oxe5 "0"   "1"   PBW / DA Reset Query  After switching to a new video source of properties of the video info box is displayed for 5 seconds.  "0" - fail. "1" - successful.  "0" - Backlight Off ("1" - Backlight On ("1" - Backlight O
Source, the video info box is displayed for 5 seconds.  OSD turn off  Oxbd  Turn off the OSD.  Backlight control  Oxe0,  In   "+"   "-"    In   "2"    Oxe1,  In   "8"   "r"    Backlight On/Off  Oxe1,  In   Backlight Off  In
displayed for 5 seconds.
displayed for 5 seconds.
OSD turn off Oxbd Turn off the OSD.  "0" - fail. "1" - successful.  nn = 0x00~ 0x64 (0~100%)  nn   "+"   "-"   "R"   "r"   "O" - Backlight Off Reset Query  Backlight On/Off Oxe1, "0"   "1"   "R"   "r" Reset Query  Swap PIP / 2P PBP video source  Backlight DA/PWM Oxe5 "0"   "1"   "Reset Query  Turn off the OSD. "0" - fail. "1" - Backlight Overwhell "1" - Backlight Off "1" - Backlight On. (Default) "1" - Backlight On. (Default) "1" - Successful. "1" - D/A Reset Query
Backlight control  Backlight control  Backlight control  Backlight Control  Backlight On/Off  Backlight On/Off  Backlight On/Off  Calculate a control over a
Backlight control  Oxe0,
Backlight control  Oxe0,
nn   "+"   "-"   value/increment/decrement   Reset   Query
Backlight On/Off  Backlight On/Off  Oxe1,  "0"   "1"    Reset Query  Backlight Off / Backlight On Reset Query  Swap PIP / 2P PBP video source  Backlight DA/PWM  Backlight DA/PWM  Oxe5  "0"   "1"    Reset Query  Backlight Off / Backlight On Reset Query  Swap Main and PIP Source (PIP mode), left & right source (PBP LR) or Top & Bottom (PBP TB)  Backlight DA/PWM  Oxe5  "0"   "1"   PWM / DA Reset Query  Backlight Control method: PWM / DA Reset Query  Default: 0x64 (100%)  "0" - Backlight Off "1" - Backlight On. (Default) "1" - successful.  "0" - PWM (Default) "1" - D/A "1" - D/A
Backlight On/Off  Oxe1,  "0"   "1"    "R"   "r"  PBP video source  Backlight DA/PWM  Backlight DA/PWM  Oxe5  "0"   "1"    "R"   "r"  Backlight Off / Backlight On  Reset Query  Swap Main and PIP Source (PIP mode), left & right source (PBP LR) or Top & Bottom (PBP TB)  Backlight DA/PWM  Oxe5  "0"   "1"    "R"   "r"  Reset Query  PWM / DA  Reset Query  "0" - PWM (Default)  "1" - D/A  "1" - D/A
Backlight On/Off  Oxe1, "0"   "1"   "R"   "r"  Swap PIP / 2P PBP video source  Backlight DA/PWM  Backlight Off / Backlight On Reset Unery  Cyr  Swap Main and PIP Source (PIP mode), left & right source (PBP LR) or Top & Bottom (PBP TB)  Backlight DA/PWM  Oxe5 "0"   "1"   "R"   "r" Reset Query  Guery  "0" - Fail. "1" - successful. "1" - successful. "1" - D/A "8"   "r" Reset Query
Backlight On/Off  Oxe1,  "0"   "1"    Reset Query  Swap PIP / 2P PBP video source  Backlight Off / Backlight On Reset Query  Swap Main and PIP Source (PIP mode), left & right source (PBP LR) or Top & Bottom (PBP TB)  Backlight DA/PWM  Oxe5  "0"   "1"    "0" - Fail.  "1" - successful.  "1" - successful.  "0" - PWM (Default)  "1" - D/A  Reset Query
Swap PIP / 2P PBP video source  Backlight Off / Backlight On Reset Query  Swap Main and PIP Source (PIP mode), left & right source (PBP LR) or Top & Bottom (PBP TB)  Backlight DA/PWM  Oxe5 O"   "1"   PWM / DA Reset Query  "2"  Backlight Off / Backlight On Reset Guery  "0" – fail. "1" – successful. "1" – successful. "1" – PWM (Default) "1" – D/A "1" – D/A
Swap PIP / 2P PBP video source  Backlight Off / Backlight On Reset Query  Swap Main and PIP Source (PIP mode), left & right source (PBP LR) or Top & Bottom (PBP TB)  Backlight DA/PWM  Oxe5 O"   "1"   PWM / DA Reset Query  "2"  Backlight Off / Backlight On Reset Guery  "0" – fail. "1" – successful. "1" – successful. "1" – PWM (Default) "1" – D/A "1" – D/A
Swap PIP / 2P PBP video source  Backlight DA/PWM Oxe5 O"   "1"   PWM / DA Reset Query  Reset Query  Swap Main and PIP Source (PIP mode), left & right source (PBP LR) or Top & Bottom (PBP TB)  Set backlight control method: PWM / DA Reset Query  "2"   Query
Swap PIP / 2P PBP video source  Backlight DA/PWM Oxe5 O"   "1"   PWM / DA Reset Ouery  Query  Swap Main and PIP Source (PIP mode), left & right source (PBP LR) or Top & Bottom (PBP TB)  Set backlight control method: PWM / DA Reset Query  "2" Query
Swap PIP / 2P PBP video source  Backlight DA/PWM  """  """  Swap Main and PIP Source (PIP mode), left & right source (PBP LR) or Top & Bottom (PBP TB)  Set backlight control method:  """  ""  """  """  """  """  """  "
Swap PIP / 2P PBP video source  Backlight DA/PWM Oxe5 O""   "1"   PWM / DA Reset Ouery  Swap Main and PIP Source (PIP mode), left & right source (PBP LR) or Top & Bottom (PBP TB)  "1" - successful. "1" - successful. "1" - PWM (Default) "1" - D/A "1" - D/A
PBP video source mode), left & right source (PBP LR) or Top & Bottom (PBP TB)  Backlight DA/PWM 0xe5 Set backlight control method: "0" – PWM (Default) "1" – D/A  "R"   "r" Reset Query Query
PBP video source mode), left & right source (PBP LR) or Top & Bottom (PBP TB)  Backlight DA/PWM 0xe5 Set backlight control method: "0" – PWM (Default) "1" – D/A  "R"   "r" Reset Query Query
PBP video source mode), left & right source (PBP LR) or Top & Bottom (PBP TB)  Backlight DA/PWM 0xe5 Set backlight control method: "0" – PWM (Default) "1" – D/A  "R"   "r" Reset Query "1" – D/A
Backlight DA/PWM
Backlight DA/PWM
"0"   "1"   PWM / DA
"0"   "1"   PWM / DA
"R"   "r"   Reset   Query
"?" Query
. Query
Daurnight i vvivi   UACU,   OCT Daurnight F VVIVI    CUUCHUV =
frequency nnn   "+"   "-"   value/increase 20Hz/decrease Value
"R"   "r"   20Hz   100Hz : "0","6","4"
Query 140Hz : "0","8","C"
160Hz: "0","A","0" (Default)
180Hz: "0","B","4"
19NH¥"N" "A""
200Hz: "0","C","8"

			220Hz: "0", "D", "C" 240Hz: "0", "F", "0" 260Hz: "1", "0", "4" 280Hz: "1", "1", "8" 300Hz: "1", "4", "0" 340Hz: "1", "5", "4" 360Hz: "1", "6", "8" 380Hz: "1", "7", "C" 400Hz: "1", "9", "0" 420Hz: "1", "A", "4" 440Hz: "1", "B", "8"
Backlight Invert	0xe7 "0"   "1"   "R"   "r" "?"	Set invert backlight level : Off / On Reset Query	"0" – Off (Default) "1" – On
PIP window transparency Level	0xed, nn   "+"   "-"   "R"   "r"   "?"	Select PIP transparency level = value/increase/decrease Reset Query	nn: 0x00~0x0A (no ~ total transparency) Default: 0x00
Minimum backlight level	0xee, "0x5C" nn   "+"   "-"   "R"   "r"   "?"	Set minimum backlight level= value/increment/decrement Reset Query	Minimum Backlight value. nn: 0x00 ~ 0x32 (0~50%) Default: 5%
OSD switch mount Lock	"0xee", "0x62" "0"  "1" "?"	Unlock / Lock Query	"0"- Unlock (Default) "1"- Lock, no response to OSD switch mount keys
Default Power	"0xee", "0x6B", "0x50" "0"  "1"  "?"	Default power state after supplying power to controller Off On Query	"0" - default power off "1" - default power on
Color Effect	"0xee", "0x71", "0x30" "0" "1" "2" "3" "4"  "5" "?" "r"   "R"	Select Color Effect Value Query Reset	"0" = Standard (Default) "1" = Game "2" = Movie "3" = Photo "4" = Vivid "5" = User
Vby1 pin setting	"0xee", "0x73", 0x30 0x31  0x39, "0"   "1"	Set Vby1 pin state Pin no.: 0x30=pin15, 0x31=pin16,, 0x39=pin24 Pin logic level	"0" = set to low (Default) "1" = set to high
Panel timing setting	"0xee", "0x74",	Panel timing setting	Set panel timing to SRAM of HX-4096. If cmd 2 <sup>nd</sup> parameter is n = 0x3F, it dumps the values of SRAM Please note "n" is BCD decimal value in ASCII. e.g. 610 is set as 0x36 0x31
	0x30, nnn   0x31, nnn   0x32, nnn   0x33, n   0x34, n   0x35, n   0x36, nnnn   0x37, nnnn	0x30= typical frame rate 0x31= max frame rate 0x32= min frame rate 0x33= panel style 0x34= eDP phy rate 0x35=LVDS/Vx1 output ports 0x36=Hsync back porch 0x37=Display horizontal width 0x38=Vertical total typical	0x30 1=Lvds, 3=Vx1, 4=eDP1.1, 5=eDP1.2 1=HBR, 2=HBR2 0=1ports,1=2ports,2=4ports,3=8ports

	0x39, nnnn   0x3A, nnnn   0x3B, nnnn   0x3C, nnnn   0x3C, nnnn   0x3E, nnnn   0x3F, nnnn   0x40, nn   0x41, nn   0x42, nnn   0x43, nnn   0x44, nnn   0x45, nnnn   0x46, nnnn   0x47, nnnn   0x48, nnnn   0x48, nnnn   0x4A, nnnn   0x4B	0x39=Vertical total max 0x3A=Vertical total min 0x3B=Vsync back porch 0x3C=Display vertical height 0x3D=Horizontal total typical 0x3E=Horizontal total max 0x3F=Horizontal total min 0x40=Hsync width 0x41=Vsync height 0x42 = Pixel clock typical 0x43 = Pixel clock max 0x44 = Pixel clock min 0x45 = Panel power on time T1 0x46 = Panel power on time T2 0x47 = Panel power off time T3 0x48 = Panel power off time T4 0x49= Panel power off time T5 0x4A = Panel power off time T6 Read all panel timing checksum  Read all panel timing parameter  Write all panel timing parameters from SRAM into EEPROM	in MHz in MHz in MHz in ms checksum, which is found by adding values of parameter 0x30 to 0x4A  Read all parameters from SRAM and dump each timing starting with 0xEE 0x74 0xYY nnnn to facilitate saving dump data to file for send back to HX- 4096 later  "1": Success "0": Fail
User EDID  EDID Block map for blocks 0 – 128	"S"  "s" "n,n+1(256 BYTE) "	Command Select Port  Send 128 BYTE EDID in ASCII Code Format (256BYTE)	"nn" = "0x41,0x31" A0: VGA "0x50, 0x31"D0: DP "0x48,0x31" D1: HDMI "0x48,0x32" D2: HDMI "0x48,0x33" D3: HDMI "0x45,0x31" D3: HD-SDI (custom code) "0x46,0x31" D4: DVI return "1" Success return "0" Fail
EDID Block map for blocks 129 – 254 if more than 128 blocks used Reset	"E"  "e" "n,n+1(256 BYTE) "  "R"   "r"	Send 128 BYTE EDID in ASCII Code Format (256BYTE)  Reset to use pre-defined EDID instead of user EDID of selected port	return "1" Success return "0" Fail  return "1" Success return "0" Fail

## 3. Other control

Function	Command	Description	Acknowledge (if enabled)		
Select RS-232	0xc1, "0"   "1"	Disable/enable command	"0" - acknowledge disabled.		
acknowledge		acknowledge.	"1" - acknowledge enabled. (Default)		
VGA auto adjust	0xc3	Start VGA auto adjust	"0" – fail.		
			"1" – successful.		
Command	0xc4, nn / nnnn	Check whether a command is	"0" – not available.		
availability		available.	"1" – available.		
			e.g "0x81" command		
			send		
			"0xc4 0x38 0x31"		
			feedback "0xc4 0x38 0x31 0x31"		
			0.004 0.000 0.001 0.001		
			e.g "0xee 0x5c" command		
			send		
			"0xc4 0x45 0x45 0x35 0x43"		
			feedback		
			"0xc4 0x45 0x45 0x35 0x43 0x31"		
VGA auto color	0xc5	Start VGA auto-calibration of	"0" — fail.		
gain		gain of the RGB amplifier.	"1" - successful.		
Power On/Off	0xc8,	Soft power on/off	"0" – soft power off.		
	"0"   "1"	off/on	"1" – soft power on.		
	"?" ່	query			
Query video input	0xc9	Query the status of the	Input status nn nn:		
status		displaying video windows source	"0","0": no video source / disabled		
			"A","1" A0: VGA		
			"F","1" D4: DVI		
			"H,"1" D1: HDMI "H,"2" D2: HDMI		
			H, Z DZ. HDMI   "H,"3" D3: HDMI		
			"E,"1" D3: HD-SDI (for custom code)		
			"P,"1" D0: DP		
			1, 1 50.51		
			Feedback 4 video windows status in		
			form of:		
			nn nn, nn nn, nn nn, nn nn (P1, P2,		
			P3, P4)		
Query BIOS	0xcb, "0"	Read BIOS version	BIOS version "VV.YY.ZZ"		
version			VV = Vx or $Ex$ , (x is version digit)		
			V = Release version		
			E = Engineering Sample		
			YY= Version Number		
			77 Customer Number		
Ouery BCDA	0xcb, "1"	Pood PCPA number	ZZ= Customer Number "nnnnn" = PCBA number		
Query PCBA number	UXCD, I	Read PCBA number	HX-4096-120= "41759"		
Query Revision	0xcb, "3"	Read Revision Number	"nn" = Revision number AA in firmware		
Number	UNCD, U	Ticad Ficvision Number	version no. "VV.YY.ZZ.AA"		
Reset parameters	0xce	Reset all parameters to default	"1" – successful.		
riosoi parameters	0,00	value	i — Successiui.		
Reset all	0xcf	Reset all parameters, including	"1" - successful.		
parameters		user color temperature setting,			
		for all video modes to default			
		value			

n = 1-byte ascii-coded hex number, e.g., parameter value of 0x1 is represented by "1" (0x31). mn or nn = 2-byte ascii-coded hex number, e.g., parameter value of 0x1e is represented by "1", "e" | "E" (0x31, 0x6e|0x4e).

The RS-232 command strings sent in one time can support up to 380 bytes via CN8 port The RS-232 command string sent in one time can support up to 50 bytes via CN1 or J1 port.


n = 1-byte ascii-coded hex number, e.g., parameter value of 0x1 is represented by "1" (0x31). mn or nn = 2-byte ascii-coded hex number, e.g., parameter value of 0x1e is represented by "1", "e" | "E" (0x31, 0x6e|0x4e). Please refer to the ASCII to Hex convert table below.

## Hex to ASCII conversion table


Hex	ASCII	Hex	ASCII	Hex	ASCII	Hex	ASCII
0x30	0	0x41	Α	0x61	а	0x2B	+
0x31	1	0x42	В	0x62	b	0x2D	-
0x32	2	0x43	С	0x63	С	0x3F	?
0x33	3	0x44	D	0x64	d		
0x34	4	0x45	E	0x65	е		
0x35	5	0x46	F	0x66	f		
0x36	6	0x47	G	0x67	g		
0x37	7	0x48	Н	0x68	h		
0x38	8	0x49	1	0x69	i		
0x39	9	0x4A	J	0x6A	j		
		0x4B	K	0x6B	k		
		0x4C	L	0x6C	1		
		0x4D	M	0x6D	m		
		0x4E	N	0x6E	n		
		0x4F	0	0x6F	0		
		0x50	Р	0x70	р		
		0x51	Q	0x71	q		
		0x52	R	0x72	r		
		0x53	S	0x73	S		
		0x54	Т	0x74	t		
		0x55	U	0x75	u		
		0x56	V	0x76	V		
		0x57	W	0x77	W		
		0x58	Χ	0x78	Х		
		0x59	Υ	0x79	у		
		0x5A	Z	0x7A	Z		

# Appendix IV - Mapping definition


## Definition of division




1 Division (Non-Division)



2 Division





4 Division




8 Division

## Input data mapping





JEIDA Format (LVDS)



# Appendix V - DV remote control unit work for HX-4096

## P/N 559000106-3:

DigitalView remote control unit (without DV logo silk screen printing)


### P/N 559000105-3:

DigitalView remote control unit (with DigitalView logo silk screen printing)



BUTTON	FUNCTION
POWER BUTTON	Soft power ON/OFF button.
SEL UP ( ) / SEL DN ( )	In OSD menu, pressing "SEL UP" button to move previous level of selection.     In OSD menu, pressing "SEL DN" button to move next level of selection or to CONFIRM the selection.
+ BUTTON	When OSD menu displayed, press this button to select functions (forward) or increase the values.
- BUTTON	When OSD menu displayed, press this button to select functions (backward) or decrease the values.
AV/TV	Show input source selection menu.
OSD NEXT BUTTON	1. Use to turn on/off the OSD menu.
Mute	1. Mute / Un-mute audio (if external audio board is connected)
PIP	1. Toggle between PIP mode and 1P mode.

<sup>\*</sup> Sequence of Input source selection (Press "+" Button to change source, Press "SEL DN" to confirm)



# Appendix VI – PIP mix table

PIP \MAIN	DVI (P1/CN2)	HDMI (P2/CN16)	HDMI (P3/CN5)	HDMI (P4)	DisplayPort (P5)
DVI (P1/CN2)	Yes	Yes	Yes	Yes	Yes
HDMI (P2/CN16)	Yes	Yes	Yes	Yes	Yes
HDMI (P3/CN5)	Yes	Yes	Yes	Yes	Yes
HDMI (P4)	Yes	Yes	Yes	Yes	Yes
DisplayPort (P5)	Yes	Yes	Yes	Yes	Yes

## Appendix VII - Functions list on browser page

Below is a summary of functions list on IP-60's browser page.

## Main

#### Network

Network Configure

Firmware Version MAC Address Host Name

DHCP On /Off

**IP Address** 

Subnet Mask Address Default Gateway Address Primary DNS Address

**Sensor Setting** 

Fan Setting

 Fan 1
 On / Off

 Fan 2
 On / Off

Fan 1 min rpm Fan 2 min rpm

**Light Sensor Setting** 

Light Sensor On / Off

Min. Value

Power Detect Setting

Power Source 1 (PS1) On / Off Power Source 2 (PS2) On / Off

PS1 Value PS2 Value

Temperature Setting

Internal Temp. Sensor On /Off
External Temp. Sensor On /Off
Int. Temp. Warning Value
Ext. Temp. Warning Value
Value

<u>Monitor Status</u>

Fans Monitor (Fan 1)
Fans Monitor (Fan 2)

Temperture Monitor (Int. Temp.)
Temperture Monitor (Ext. Temp.)

Power Monitor (PS 1) Power Monitor (PS 2) Light Monitor (Light1)

#### **Direct Control**

Picture Setting

Brightness Value
Contrast Value
Saturation Value
Sharpness Value
Hue Value

**Backlight Control** 

Soft Power On / Off
Backlight Status On / Off
Backlight Control Value

Backlight PWM Frequency PWM (100Hz-440Hz)

Display Mode

1P / 2P\_LR / 2P\_TB / 2P\_PIP / 4P

Check Main & PIP Source

<u>Input Source Selection</u> P1 Input Source Display Port/HDMI 1/HDMI 2/HDMI 3/DVI/VGA

P2 Input Source Display Port/HDMI 1/HDMI 2/HDMI 3/DVI/VGA
P3 Input Source Display Port/HDMI 1/HDMI 2/HDMI 3/DVI/VGA
P4 Input Source Display Port/HDMI 1/HDMI 2/HDMI 3/DVI/VGA

P4 Input Source

<u>Check Input Status</u>

Invalid/ARGB/HD/SD Component/DVI/HDMI/Display Port

**Audio Setting** 

Mute On / Off Volume Value

Source Selection P1/P2/P3/P4/Analog

**Color Setting** 

Color Temperature 3200K/5800K/6500K/7500K/9300K/sRGB/User

User - Red Level Color Temp. Value
User - Green Level Color Temp. Value
User - Blue Level Color Temp. Value

Color Effect Standard/Game/Movie/Photo/Vivid/User

Gamma Off/1.8/2.0/2.2/2.4

**Advanced Setting** 

Aspect Ratio Full/16:9/4:3/5:4/1:1

Display Orientation Normal/Anti-Clockwise 90/Rotate 180/Anti-Clockwise 270

## PIP Setting

Swap

PIP Size (0 - 10)
PIP Horizontal Position Value
PIP Vertical Position Value

## OSD Setting

OSD Status On / Off
OSD Turn On / Off
OSD Horizontal Position Value
OSD Vertical Position Value
OSD Menu Timeout Value

### Key Control

Menu/Down/Up/Left(-)/Right(+)

## **Display Information**

**BIOS Version** 

Horizontal Resolution Vertical Resolution Horizontal Frequency Vertical Frequency

## Load Default

Reset All Parameters Reset all parameters to default value

Reset Parameters Reset all parameters for all video mode to defualt value

#### **WARRANTY**

The products are warranted against defects in workmanship and material for a period of three (3) year from the date of purchase provided no modifications are made to it and it is operated under normal conditions and in compliance with the instruction manual.

The warranty does not apply to:

- Product that has been installed incorrectly, this specifically includes but is not limited to cases where electrical short circuit is caused.
- · Product that has been altered or repaired except by the manufacturer (or with the manufacturer's consent).
- · Product that has subjected to misuse, accidents, abuse, negligence or unusual stress whether physical or electrical.
- Ordinary wear and tear.

Except for the above express warranties, the manufacturer disclaims all warranties on products furnished hereunder, including all implied warranties of merchantability and fitness for a particular application or purpose. The stated express warranties are in lieu of all obligations or liabilities on the part of the manufacturer for damages, including but not limited to special, indirect consequential damages arising out of or in connection with the use of or performance of the products.

#### **CAUTION**

Whilst care has been taken to provide as much detail as possible for use of this product it cannot be relied upon as an exhaustive source of information. This product is for use by suitably qualified persons who understand the nature of the work they are doing and are able to take suitable precautions and design and produce a product that is safe and meets regulatory requirements.

#### LIMITATION OF LIABILITY

The manufacturer's liability for damages to customer or others resulting from the use of any product supplied hereunder shall in no event exceed the purchase price of said product.

## **TRADEMARKS**

The following are trademarks of Digital View Ltd:

- Digital View
- HX-4096

### **CONTACT DETAILS**

Digital View has offices in Asia, Europe and USA:

#### USA

Digital View Inc. 18440 Technology Drive Building 130 Morgan Hill, California, 95037 USA

Sales: ussales@digitalview.com

### **EUROPE**

Digital View Ltd. The Lake House Knebworth Park Herts, SG3 6PY UK

Sales: uksales@digitalview.com

#### **ASIA**

Digital View Ltd 705-708, 7/F Texwood Plaza 6 How Ming St. Kwun Tong Hong Kong

Sales: hksales@digitalview.com

### WEBSITE

www.digitalview.com

# **Revision History**

Date	Rev No.	Page	Summary
19 February 2016	1.0	All	First issued.
23 March 2016	1.1	1,6,7, 23	Info updated.
10 August 2016	1.2	4,9-12, 13,15,18, 19,20-22, 27,35, 39-49	OSD, Diagram, JC1/JC2, SW4, P1- P4 pins assignment/mode, RS-232 Commands, Appendix III-V.
19 August 2016	2.0	3-4,13-17	Added jumper for 10V. Removed CN4. Added 110mA/100mA/90mA LED current.
26 January 2017	2.1	10, 15, 33-34, 47-48, 55-57, 59	LED definition, OSD menu Office address changed Added RS-232 commands Pin correction in JC1, Use of memory Functions list of browser page
20 September 2017	2.2	33, 40-42	LED definition, Use of Network connection