

# 25-000 Series

## **Product Facts**

- Function 81 O/U
- ANSI/IEEE C37.90-1978

The output contacts of frequency relays are energized when the frequency exceeds the adjustable set point. Overfrequency and underfrequency relays are available in 50, 60 and 400Hz. Combination over/underfrequency "band pass" relays are also available. These are energized at rated frequency and de-energized during overfrequency or underfrequency conditions. Frequency Differential relays are energized above the preset frequency. The pick-up and drop-out frequency settings are independently adjustable.

### Operation

The normally open contacts close, and the normally closed contacts open, at nominal frequency. The contacts are de-energize at underfrequency, overfrequency or no input voltage.



Product Specifications

Input Voltage (±10%) — 120 VAC Frequency Range (adjustable) — See Ordering Information

Trip Points — Screwdriver adjustable Temperature Range —

-20°C to +85°C

 $\begin{array}{l} \textbf{Temperature Drift} \longrightarrow \pm 1\% \text{ frequency} \\ \text{error over temperature range} \end{array}$ 

**Voltage Drift** —  $\pm$  1% frequency error input voltage variation of  $\pm$  10%

Contact Ratings — 5 Amp resistive at 120 VAC or 28VDC

Output Contacts — One set N.O., One set N.C.

#### Notes:

1. The contacts are shown in the de-energized position.

 Remove screws for access to the underfrequency and overfrequency trip adjustments.

 Clockwise rotation of the adjustment potentiometer will raise the frequency trip points.





## **Ordering Information**



Consult factory for additional models.

For additional support numbers

please visit www.te.com

Catalog 5-1773450-5 Revised 3-13

Dimensions are shown for reference purposes only. Specifications subject to change. Dimensions are in millimeters unless otherwise specified.

USA: +1 800 522 6752 Asia Pacific: +86 0 400 820 6015 UK: +44 800 267 666

www.te.com