


ADS8350EVM-PDK



ADS8350EVM-PDK

This user's guide describes the characteristics, operation and use of the ADS8350EVM performance demonstration kit (PDK). This kit is an evaluation platform for the ADS8350, dual-channel, 16-bit, simultaneous sampling, successive approximation register (SAR) analog-to-digital converter (ADC) that supports pseudo-differential analog inputs. This EVM eases the evaluation of the ADS8350 device with hardware and software for computer connectivity through a universal serial bus (USB). This user's guide includes complete circuit descriptions, a schematic diagram, and a bill of materials.

Throughout this document, the terms demonstration kit, evaluation board, evaluation module are synonymous with the ADS8350EVM-PDK.

The following related documents are available through the Texas Instruments web site at <http://www.ti.com>.

Related Documentation

| Device | Literature Number |
|----------------------------|-------------------------|
| ADS8350 | SBAS580 |
| REF5025 | SBOS410 |
| OPA2350 | SBOS099 |
| OPA376 | SBOS432 |
| OPA2836 | SLOS712 |
| TPS3836E18 | SLVS292 |
| TPS7A4700 | SBVS204 |
| REG71055 | SBAS221 |

Windows XP, Windows 7, Windows 8, Excel are registered trademarks of Microsoft Corporation.
 SPI is a trademark of Motorola Inc.
 I²C is a trademark of NXP Semiconductors.
 All other trademarks are the property of their respective owners.

Contents

| | | |
|---|--|----|
| 1 | Overview | 3 |
| 2 | EVM Analog Interface | 3 |
| 3 | Digital Interface | 7 |
| 4 | Power Supplies | 8 |
| 5 | ADS8350EVM-PDK Initial Setup | 9 |
| 6 | ADS8350EVM-PDK Kit Operation | 16 |
| 7 | Bill of Materials, PCB Layout, and Schematics..... | 25 |

List of Figures

| | | |
|----|---|----|
| 1 | ADS8350EVM Analog Interface Input Connections | 4 |
| 2 | Bipolar Input Signal Configuration | 5 |
| 3 | Unipolar Input Signal Configuration | 5 |
| 4 | REFIN_A and REFIN_B Reference Connections | 6 |
| 5 | ADS8350EVM Default Jumper Settings | 9 |
| 6 | Bottom View of Simple Capture Card Board with microSD Memory Card Installed | 11 |
| 7 | Bottom View of ADS8350EVM Rev B with microSD Card Installed | 11 |
| 8 | Connecting ADS8350EVM Board to Simple Capture Card Controller Board | 12 |
| 9 | LED Indicators on the Simple Capture Card Board..... | 12 |
| 10 | Welcome Screen and Destination Directory Screens | 13 |
| 11 | License Agreement and Start Installation Screens | 13 |
| 12 | Progress Bar and Installation Complete Screens | 14 |
| 13 | Windows 7 Driver Installation Warning | 14 |
| 14 | Simple Capture Card Device Driver Installation..... | 15 |
| 15 | Simple Capture Card Device Driver Completion | 15 |
| 16 | GUI Display Prompt..... | 16 |
| 17 | Open the ADS8350EVM Settings Page..... | 17 |
| 18 | ADS8350EVM Settings Page..... | 17 |
| 19 | Bipolar or Unipolar Signal Jumper Settings Description on the GUI | 18 |
| 20 | Open the Data Monitor page on the GUI | 18 |
| 21 | Data Monitor Page | 19 |
| 22 | Saving Data to a Text File | 20 |
| 23 | FFT Performance Analysis Page..... | 21 |
| 24 | Histogram Analysis Page..... | 23 |
| 25 | Open the GUI Settings page..... | 24 |
| 26 | Set Capture Mode to SDCC Interface While Using the EVM Hardware | 24 |
| 27 | ADS8350EVM PCB: Top Layer | 27 |
| 28 | ADS8350EVM PCB: Ground Layer | 27 |
| 29 | ADS8350EVM PCB: Power Layer | 28 |
| 30 | ADS8350EVM PCB: Bottom Layer | 28 |

List of Tables

| | | |
|---|--|----|
| 1 | JP1 and JP2: Analog Interface Connections..... | 4 |
| 2 | SMA Analog Interface Connections | 4 |
| 3 | Connector J6 Pinout..... | 7 |
| 4 | Power-Supply Jumpers | 8 |
| 5 | Default Jumper Configuration | 9 |
| 6 | ADS8350EVM Bill of Materials | 25 |

1 Overview

The ADS8350EVM-PDK is a platform for evaluation of the ADS8350 analog-to-digital converter (ADC). The evaluation kit combines the ADS8350EVM board with a simple capture card controller board. The simple capture card controller board consists of a TI Sitara embedded microcontroller ([AM3352](#)) and a field programmable gate array (FPGA). The simple capture card controller board provides an interface from the EVM to the computer through a universal serial bus (USB) port. The included software communicates with the simple capture card controller board platform, and the simple capture card board provides the power and digital signals used to communicate with the ADS8350EVM board. These demonstration kits include the ADS8350EVM board, the simple capture card controller board, a microSD memory card, and an A-to-micro-B USB cable.

1.1 ADS8350EVM Features

- Contains support circuitry as a design example to match ADC performance
- 3.3-V slave serial peripheral interface (SPI™)
- Onboard 5-V analog supply
- Onboard [REF5025](#) (2.5-V) reference
- Voltage reference buffering with [OPA2350](#)
- Onboard [OPA2836](#) (205-MHz BW, 1-mA quiescent current) ADC operational amplifier input drivers

1.2 ADS8350EVM-PDK Features

- USB port for computer interfacing
- Easy-to-use evaluation software for Windows XP®, Windows 7®, Windows 8® operating systems
- Data collection to text files
- Built-in analysis tools including scope, FFT, and histogram displays
- Complete control of board settings

2 EVM Analog Interface

The ADS8350 is a dual-channel, simultaneous-sampling ADC that supports pseudo-differential analog inputs. Each channel of the ADS8350 uses a OPA2836 dual operational amplifier to drive the inputs of the ADC; see [Figure 1](#). The positive input terminals of each ADC are driven by the OPA836 operational amplifier configured in the inverting configuration. The negative input terminals of each ADC are driven by the OPA836 in the buffer configuration and biased at the 2.5-V, onboard reference voltage ($+V_{ref}$). The ADS8350EVM is designed for easy interfacing to multiple analog sources. SMA connectors allow the EVM to have input signals connected through coaxial cables. In addition, header connectors JP1 and JP2 provide a convenient way to connect input signals.



Figure 1. ADS8350EVM Analog Interface Input Connections

Table 1 summarizes the JP1 and JP2 analog interface connectors.

Table 1. JP1 and JP2: Analog Interface Connections

| Terminal Number | Signal | Description |
|-----------------|--------|--|
| JP1.2 | AIN_A | Channel A inverted input. The signal is routed through an OPA836 in the inverting configuration. |
| JP2.2 | AIN_B | Channel B inverted input. The signal is routed through an OPA836 in the inverting configuration. |

Table 2 lists the SMA analog inputs.

Table 2. SMA Analog Interface Connections

| Terminal Number | Signal | Description |
|-----------------|--------|--|
| J1 | AIN_A | Channel A inverted input. The signal is routed through an OPA836 in the inverting configuration. |
| J2 | AIN_B | Channel B inverted input. The signal is routed through an OPA836 in the inverting configuration. |

2.1 Bipolar Input Signal Configuration

When jumpers JP9 and JP10 are closed, the inverting amplifier positive input is biased with +1.25 V. This bias voltage is created by dividing the ADS8350EVM 2.5-V onboard reference by two. The bias voltage at the input results in a 2.5-V offset at the amplifier output. In this configuration, apply a bipolar input signal with 0-V common-mode voltage.

To keep the OPA836 distortion as low as possible, the input signal swing is limited from -2.3 V to +2.3 V, as shown in Figure 2.




Figure 2. Bipolar Input Signal Configuration

2.2 Unipolar Input Signal Configuration

When jumpers JP9 and JP10 are open, the inverting amplifier positive input is biased with +2.5 V. This bias voltage is created using the ADS8350EVM 2.5-V onboard reference. In this configuration, apply a unipolar input signal with 2.5-V common-mode voltage. To keep the OPA836 distortion as low as possible, the input signal swing is limited from +0.2 V to +4.8 V, as shown in Figure 3.




Figure 3. Unipolar Input Signal Configuration

2.3 ADS8350EVM Onboard Reference

The ADS8350 dual, simultaneous ADC operates with reference voltages V_{ref_A} and V_{ref_B} present on pins REFIN_A and REFIN_B, respectively. The ADS8350EVM provides an onboard 2.5-V reference source, REF5025 (U5), buffered with a dual OPA2350 amplifier and routed through jumpers JP5 and JP6. By default, the EVM is set up with jumpers JP5 and JP6 installed, as shown in Figure 4.




Figure 4. REFIN_A and REFIN_B Reference Connections

3 Digital Interface

Socket strip connector J6 provides the digital I/O connections between the ADS8350EVM board and the simple capture card board.

Table 3 summarizes the pinout for connector J6.

Table 3. Connector J6 Pinout

| Terminal Number | Signal | Description |
|-------------------------------------|-----------------------|--|
| J6.2, J6.10, J6.15, J6.16, J6.18 | GND | Ground connections |
| J6.4 | EVM PRESENT | EVM present, active low |
| J6.11, J6.12 | I ² C™ bus | I ² C bus; used only used to program the U7 EEPROM on the EVM board |
| J6.13 | DVDD | 3.3-V digital supply from simple capture card controller board |
| J6.34 | \overline{CS} | Chip select, active low |
| J6.36 | SCLK | Serial interface clock |
| J6.40 | SDO_A | Serial data output for channel A |
| J6.42 | SDO_B | Serial data output for channel B |

3.1 Serial Peripheral Interface (SPI)

The ADS8350 digital output is available in SPI-compatible format, which makes interfacing with microprocessors, digital signal processors (DSPs), and FPGAs easy. The ADS8350EVM offers 47- Ω resistors between the SPI signals and connector J6 to aid with signal integrity. Typically, in high-speed SPI communication, fast signal edges can cause overshoot; these 47- Ω resistors slow down the signal edges in order to minimize signal overshoot.

3.2 I²C Bus for Onboard EEPROM

The ADS8350EVM has an I²C bus to communicate with the onboard EEPROM that records the board name and assembly date. It is not used in any form by the ADS8350 converter.

4 Power Supplies

The analog portion of the ADS8350EVM-PDK requires a 5-V supply. The ADS8350EVM-PDK is configured at the factory using the onboard regulated analog 5-V supply (+VA); and an onboard 3.3-V digital supply. Alternatively, set the AVDD analog supply voltage by connecting an external power source through two-terminal connector J5. [Table 4](#) lists the configuration details for P3.

Table 4. Power-Supply Jumpers

| Terminal Number | Position | Function |
|-----------------|---------------------|---|
| JP12 | Shunt 2-3 (default) | Onboard 5-V AVDD analog supply selected |
| | Shunt 1-2 | External 5-V AVDD connected through two-terminal block J5 |
| JP11 | Open (default) | Open sets onboard AVDD supply to 5 V |
| | Closed | Closed sets onboard AVDD supply to 5.2 V |

CAUTION

The external AVDD supply applied to external two-terminal connector J5 must not exceed 5.5 V or device damage may occur. The external AVDD supply must be in the range of 5.0 V to 5.5 V for proper ADS8350EVM operation.

5 ADS8350EVM-PDK Initial Setup

This section presents the steps required to set up the ADS8350EVM-PDK kit before operation.

5.1 Default Jumper Settings

A silkscreen plot detailing the default jumper settings is shown in [Figure 5](#). [Table 5](#) explains the configuration for these jumpers.




Figure 5. ADS8350EVM Default Jumper Settings

Table 5. Default Jumper Configuration

| Terminal Number | Default Position | Switch Description |
|-----------------|------------------|--|
| JP1 | Open | JP1.2 header connector to inverted channel A input |
| JP2 | Open | JP1.2 header connector to inverted channel B input |
| JP3 | N/A | JP3 not installed on PCB board |
| JP4 | N/A | JP4 not installed on PCB board |
| JP5 | Closed | Closed to connect onboard 2.5-V reference to REFIN_A |
| JP6 | Closed | Closed to connect onboard 2.5-V reference to REFIN_B |
| JP7 | Short 2-3 | Short 2-3 connects AINM_A(-) to 2.5-V |
| JP8 | Short 2-3 | Short 2-3 connects AINM_B(-) to 2.5-V |
| JP9 | Closed | Open for channel A unipolar input signals at SMA connector; closed for channel A bipolar input signals at SMA connector. |
| JP10 | Closed | Open for channel B unipolar input signals at SMA connector; closed for channel B bipolar input signals at SMA connector. |
| JP11 | Open | Open sets onboard AVDD to 5 V; closed sets onboard AVDD to 5.2 V. |
| JP12 | Short 2-3 | Short 2-3 selects onboard regulated AVDD supply; short 1-2 selects external AVDD through J5. |

5.2 Software Installation

This section presents the steps required to install the software. [Section 6](#) explains how to operate the software to acquire data.

NOTE: The ADS8350EVM-PDK with ADS8350 PWB Board revision A includes (1) microSD card. Ensure the microSD memory card included in the kit is installed in the microSD socket on the back of the simple capture card board before connecting the EVM to the PC. Otherwise, as a result of improper boot up, Windows cannot recognize the ADS8350EVM-PDK as a connected device.

The ADS8350EVM-PDK with ADS8350 PWB Board revision B includes (2) microSD cards. Ensure both microSD memory cards that contain the software are installed in the microSD sockets on the back of the simple capture card board and on the back of ADS8350EVM board respectively. Otherwise, as a result of improper boot up, Windows cannot recognize the ADS8350EVM-PDK as a connected device.

Complete the following steps to install the software:

- Step 1. Verify the microSD memory card(s) are installed:
- ADS8350EVM PWB revision A: This PDK kit version includes (1) microSD Card. Verify the microSD memory card is installed on the simple capture card controller board
 - ADS8350EVM PWB revision B: This PDK kit version includes (2) microSD Cards. Ensure both microSD memory cards are installed in the microSD sockets on the back of the simple capture card board and ADS8350EVM board respectively
- Step 2. Verify jumpers are in the factory-default position and connect the hardware.
- Step 3. Install the ADS8350EVM-PDK software.
- Step 4. Complete the simple capture card device driver installation.

Each task is described in the following subsections.

5.2.1 Verify the microSD Memory Card is Installed on the Simple Capture Card Controller Board

The ADS8350EVM-PDK includes the microSD card(s) that contain the EVM software and simple capture card controller board firmware required for the EVM operation.

NOTE: Ensure the microSD memory card that contains the software is installed in the microSD socket (P6) on the back of the simple capture card board.

[Figure 6](#) illustrates the bottom view of the simple capture card controller board with the microSD card installed.




Figure 6. Bottom View of Simple Capture Card Board with microSD Memory Card Installed

NOTE: ADS8350EVM-PDK with ADS8350EVM PWB Board revision B (only):
 This ADS8350EVM PWB version includes two (2) microSD cards. Ensure both microSD memory cards are installed in the microSD sockets on the back of the simple capture card board and on the back of the ADS8350EVM, as shown in [Figure 6](#) and [Figure 7](#) respectively.




Figure 7. Bottom View of ADS8350EVM Rev B with microSD Card Installed

The microSD cards are formatted from the factory with the necessary firmware files for the simple capture card controller board to boot properly. In addition to the simple capture card firmware files (*app* and *MLO* files), the microSD cards contain the ADS8350EVM-PDK software installation files inside the *ADS8350EVM V#.#.#* folder. *<V#.#.#>* refers to the installation software version number, and increments with software installer releases.

5.2.2 Verify Jumpers are in the Factory-Default Position and Connect the Hardware

The ADS8350EVM-PDK includes both the ADS8350EVM and the simple capture card controller board; however, the devices are shipped unconnected. Follow these steps to verify that ADS8350EVM-PDK kit is configured and connected properly.

- Step 1. Verify the microSD card is installed on the back of the simple capture card board; see [Figure 6](#).
- Step 2. Verify the ADS8350EVM jumpers are configured; see [Figure 5](#).
- Step 3. Connect the ADS8350EVM board to the simple capture card controller board as [Figure 8](#) shows.




Figure 8. Connecting ADS8350EVM Board to Simple Capture Card Controller Board

- Step 4. Connect the simple capture card controller board to the PC through the micro USB cable.
- Step 5. Verify that the LED D5 *Power Good* indicator is illuminated. Wait approximately ten seconds and verify that diode D2 blinks, indicating that USB communication with the host PC is functioning properly. [Figure 9](#) shows the location of the LED indicators in the simple capture card controller board.




Figure 9. LED Indicators on the Simple Capture Card Board

5.2.3 Install the ADS8350EVM-PDK Software

The ADS8350 EVM V#.#.# software must be installed on the PC. This software supports the ADS8350EVM-PDK. The user must have administrator privileges to install the EVM software. The following steps list the directions to install the software.

1. Open Windows explorer and find the microSD memory card in the browser as a storage device.
2. Navigate to the ...|ADS8350 EVM Vx.x.x|Volume1 folder.
3. Run the installer by right-clicking the *setup.exe* and selecting *Run as Administrator*. This action installs the EVM GUI software and the required simple capture card device driver components.
4. After the installer begins, a welcome screen displays. Click *Next* to continue.
5. A prompt appears with the destination directory; select the default directory under: ...|Program Files(x86)|Texas Instruments|ADS8350evm), as shown in [Figure 10](#).




Figure 10. Welcome Screen and Destination Directory Screens

6. One or more software license agreements appear. Select *I Accept the License Agreement* and click *Next*.
7. The *Start Installation* screen appears, as shown in [Figure 11](#). Click *Next*.




Figure 11. License Agreement and Start Installation Screens

8. A progress bar appears; this step takes a few minutes.
9. The progress bar is followed by an installation complete notice, as shown in [Figure 12](#).




Figure 12. Progress Bar and Installation Complete Screens

5.2.4 Complete the Simple Capture Card Device Driver Installation

During installation of the simple capture card device driver, a prompt may appear with the Windows security message shown in [Figure 13](#). Select *Install this driver software anyway* to install the driver required for proper operation of the software. The drivers contained within the installers are safe for installation to your system.



Figure 13. Windows 7 Driver Installation Warning

NOTE: Driver installation prompts do not appear if the simple capture card device driver is installed on your system previously.

The following steps describe how to install the simple capture card device driver.

- Step 1. Immediately after the ADS8350 EVM software installation is complete, prompts appear to install the simple capture card device driver, as shown in [Figure 14](#) and [Figure 15](#)
- Step 2. A computer restart may be required to finish the software installation. If prompted, restart the PC to complete the installation.



Figure 14. Simple Capture Card Device Driver Installation



Figure 15. Simple Capture Card Device Driver Completion

6 ADS8350EVM-PDK Kit Operation

This section describes how to use ADS8350EVM-PDK and the ADS8350EVM software to configure the EVM and acquire data.

6.1 About the Simple Capture Card Controller Board

The simple capture card controller board provides the USB interface between the PC and the ADS8350EVM. The controller board is designed around the AM335x processor, a USB 2.0 high-speed capability, 32-bit ARM core. The simple capture card controller board incorporates an onboard FPGA subsystem and 256MB of onboard DDR SRAM memory.

The simple capture card controller board is not sold as a development board, and it is not available separately. TI cannot offer support for the simple capture card controller board except as part of this EVM kit.

6.2 Loading the ADS8350EVM-PDK Software

The ADS8350 EVM software provides control over the settings of the ADS8350. Adjust the ADS8350EVM settings when the EVM is not acquiring data. During acquisition, all controls are disabled and settings cannot be changed.

Settings on the ADS8350EVM correspond to settings described in the [ADS8350 product data sheet](http://www.ti.com) (available for download at <http://www.ti.com>); see the product data sheet for details.

To load the *ADS8350 EVM* software, follow these steps:

- Step 1. Make sure the EVM kit is configured and powered up as explained in [Section 5](#).
- Step 2. Start the ADS8350 EVM software. Go to *Start* → *All Programs* → *Texas Instruments* → *ADS8350 EVM* and run the software by right-clicking *ADS8350 EVM* and selecting *Run as Administrator*.
- Step 3. Verify that the software detects the ADS8350EVM. The GUI identifies the EVM hardware that is connected to the controller board and displays *Loading the ADS8350evm Settings*. After the settings are loaded, *ADS8350EVM GUI* displays at the top of the GUI screen, as shown in [Figure 16](#).




Figure 16. GUI Display Prompt

6.3 ADS8350EVM Settings

Configure the ADS8350EVM for evaluation. The *ADS8350EVM Settings* page explains in detail the analog input connections available on the evaluation board. In order to configure the EVM analog input connections, follow these steps:

1. Load the *ADS8350EVM Settings* page in the GUI. Hover the cursor over the red arrow at the left-center side of the GUI screen; a menu with different GUI pages appears. Click on *ADS8350 EVM Settings*, as shown in [Figure 17](#).



Figure 17. Open the *ADS8350EVM Settings* Page

2. The ADS8350 dual, simultaneous ADC requires reference voltages V_{ref_A} and V_{ref_B} present on pins REFIN-A and REFIN_B, respectively. The ADS8350EVM provides an onboard 2.5-V reference source, REF5025 (U5), buffered with a dual OPA2350 amplifier and routed through jumpers JP5 and JP6. Therefore, jumpers JP5 and JP6 must be installed. [Figure 18](#) shows the reference connections as described on the *ADS8350EVM Settings* page of the GUI.




Figure 18. *ADS8350EVM Settings* Page

3. Scroll down in the *ADS8350EVM Settings* page and find the *ADS8350 Analog Inputs* connections descriptions on the GUI. The ADS8350EVM can be driven with a signal generator producing a bipolar source signal centered on GND or a unipolar signal centered at $+V_{ref} / 2$. Jumpers JP9 and JP10 are installed when supporting a bipolar signal centered at GND. Jumpers JP9 and JP10 must be removed when supporting a unipolar signal source signal centered at 2.5-V. [Figure 19](#) shows jumpers JP9 and JP10 on the *ADS8350EVM Settings* page of the GUI.




Figure 19. Bipolar or Unipolar Signal Jumper Settings Description on the GUI

6.4 Capturing Data with the ADS8350EVM-PDK

Access the *Data Monitor* page in the GUI to monitor data acquired by the ADS8350. This GUI page displays the acquired data versus time. To access the *Data Monitor* page, hover the cursor over the red arrow at the left center side of the GUI screen; a menu with different GUI pages appear. Click on the *Data Monitor* option in the menu, as shown in [Figure 20](#).




Figure 20. Open the *Data Monitor* page on the GUI

Figure 21 shows the *Data Monitor* page of the EVM GUI. Configure the device sampling rate and capture settings by using the *Capture Settings* portion of the *Data Monitor* page. The change in configuration settings are executed immediately after pressing the *Configure Device* button. The following list describes the different options available on the *Data Monitor* page.

No. of Samples— This option is used to select the number of samples captured in a block.

The number of samples captured in a block are contiguous. The drop-down menu is used to select a data block in the range of 1024 samples to 1,048,576 samples per channel. This control provides a drop-down list for values restricted to 2^n , where n is an integer.

SCLK— This control sets the clock frequency used by the SPI interface to capture data.

By configuring the SCLK frequency, the data rate of the ADS8350 is configured. The ADS8351EVM-PDK software supports SCLK frequencies of 24 MHz, 20 MHz, and 16.2 MHz. These SCLK frequencies correspond to data rates of 750 kSPS, 625 kSPS, and 506.2 kSPS respectively.

Device Status— This panel shows the current clock frequency and data rate of the ADS8350.




Figure 21. Data Monitor Page

6.4.1 Data Collection to Text Files

The *Data Monitor* page of the GUI allows data to be saved in a tab-delimited text file format that can be imported into Excel®, or other spreadsheet software tools. The text file contains the raw ADC data of both channel A and channel B in decimal data format. Information such as the device name, date and time, the sampling frequency, and number of samples of the data record are also stored. In order to save any data captured by the EVM, click on the *Save Data* button and specify the file path and file name of the data file, as shown in [Figure 22](#).




Figure 22. Saving Data to a Text File

6.5 FFT Analysis

The *Performance Analysis* page in the GUI performs the fast fourier transform (FFT) of the captured data, and displays the resulting frequency domain plots of channel A and channel B of the ADS8350. This page also calculates key ADC dynamic performance parameters, such as signal-to-noise ratio (SNR), total harmonic distortion (THD), signal-to-noise and distortion ratio (SINAD), and spurious-free dynamic range (SFDR). Figure 23 shows the FFT performance analysis display. The FFT calculated parameters are shown on the right side of the display.




Figure 23. FFT Performance Analysis Page

6.5.1 FFT Analysis Settings and Controls

Sample Rate (kHz)— This field indicates the sampling frequency of the ADC data (kHz).

Samples (No.)— The FFT requires a time domain record with a number of samples that is a power of 2. The Samples (#) drop-down menu provides a list of values that satisfy this requirement.

Fi Calculated— This field displays the frequency of the largest amplitude input signal computed from the FFT data, typically the fundamental frequency.

Window— The window function is a mathematical function that reduces the signal to zero at the end points of the data block.

In applications where coherent sampling cannot be achieved, a window-weighting function can be applied to the data to minimize spectral leakage. The following options are available:

- None (no window weighting function applied; use for coherent data)
- Hanning
- Hamming
- Blackman-Harris
- Exact Blackman
- Blackman
- Flat Top
- 4-Term Blackman-Harris
- 7-Term Blackman-Harris
- Low Sidelobe

For a more thorough discussion of windowing, refer to IEEE1241-2000.

Harmonics— This field sets the number of harmonics that are included in the FFT performance calculations.

Leakage Bins— These fields provide for the removal of the unwanted frequency bins that may be the result of noncoherent data sampling.

Set the *Fundamental Leakage Bins* and *Harmonic Leakage Bins* fields to the number of adjacent bins on either side of the fundamental or harmonic frequencies to include the main frequency power. The *DC Leakage Bins* field allows the number of frequency bins that are a result of the dc portion of the measurement to be excluded from the calculations.

6.6 Histogram Analysis

Histogram testing is commonly used when characterizing ADCs. A histogram is merely a count of the number of times a code has occurred in a particular data set. The *Histogram Analysis* page of the GUI creates a histogram of the data of the acquired data set and displays it. Figure 24 shows the *Histogram Analysis* page of the GUI.




Figure 24. Histogram Analysis Page

The *DC Analysis* table shown in Figure 24 displays several parameters of the captured data set:

- The *StDev* column displays the standard deviation of the data set. This value is equivalent to the RMS noise of the signal when analyzing a dc data set.
- The *Codes(pp)* column shows the peak-to-peak spread of the codes in the data set; for a dc data set, this range would be the peak-to-peak noise.
- The *Mean* column displays the average value of the data set.
- The *ENOB(StDev)* column displays the effective number of bits of the converter, as calculated from the standard deviation or RMS noise.
- The *Noise Free Bits* column displays the effective bits of the converter when calculated using the peak-to-peak noise.

6.7 Troubleshooting

If the ADS8350EVM software stops responding while the ADS8350EVM-PDK is connected, unplug the USB cable from the EVM, unload the ADS8350EVM-PDK software, reconnect the ADS8350EVM-PDK to the PC, and reload the ADS8350EVM software.

When initially setting up the ADS8350 GUI, the software detects the EVM hardware, and loads the appropriate hardware settings. If the EVM hardware is not detected, the GUI defaults to the *Capture Mode: Software Debug* mode of operation using a preloaded captured data file for demonstration purposes.

While using the EVM-PDK hardware for data acquisition, keep the GUI in the *Capture Mode: SDCC interface* mode of operation. The GUI indicates the selected mode of operation on the top-right corner of the GUI display. In order to select the simple capture card interface mode of operation, navigate to the *GUI Settings* page and select the *SDCC Interface* option on the *Capture Mode* drop-down menu, as shown in [Figure 25](#) and [Figure 26](#).



Figure 25. Open the *GUI Settings* page




Figure 26. Set Capture Mode to *SDCC Interface* While Using the EVM Hardware

7 Bill of Materials, PCB Layout, and Schematics

Table 6 lists the bill of materials. Section 7.2 provides the PCB layout for the ADS8350EVM. The schematics for the ADS8350EVM are appended to the end of this user's guide.

7.1 Bill of Materials

NOTE: All components must be compliant with the European Union Restriction on Use of Hazardous Substances (RoHS) Directive. Some part numbers may be either leaded or RoHS. Verify that purchased components are RoHS-compliant.

Table 6. ADS8350EVM Bill of Materials

| Item No. | Qty | Ref Des | Description | Vendor | Part Number |
|----------|-----|--|---|---------------------------------|--|
| 1 | 11 | C1, C20, C21, C39, C41, C42, C43, C44, C45, C46, C54 | CAP, CERM, 10uF, 16V, +/-10%, X5R, 0805 | Murata | GRM21BR61C106KE15L |
| 2 | 11 | C2, C5, C9, C10, C12, C13, C14, C15, C28, C30, C40 | CAP, CERM, 1uF, 6.3V, +/-10%, X7R, 0603 | Murata | GRM188R70J105KA01D |
| 3 | 0 | C3, C4, C7, C8, C18, C19, C22, C23 | Not Install | Not Install | Not Install |
| 4 | 4 | C6, C26, C27, C51 | CAP, CERM, 10uF, 6.3V, +/-20%, X5R, 0603 | TDK | C1608X5R0J106M |
| 5 | 8 | C11, C16, C17, C29, C31, C48, C52, C53 | CAP, CERM, 0.1uF, 16V, +/-5%, X7R, 0603 | AVX | 0603YC104JAT2A6 |
| 6 | 2 | C24, C25 | CAP CER 8200PF 50V 5% NP0 0805 | TDK | C2012C0G1H822J060AA |
| 7 | 2 | C47, C50 | CAP, CERM, 2.2uF, 16V, +/-10%, X5R, 0603 | Murata | GRM188R61C225KE15D |
| 8 | 1 | C49 | CAP, CERM, 0.22uF, 16V, +/-10%, X5R, 0603 | TDK | GRM188R61C224KA88D |
| 9 | 1 | D1 | DIODE ZENER 5.9V 250MW SOT23 | NXP Semiconductors | PLVA659A.215 |
| 10 | 2 | J1, J2 | Connector, TH, SMA | TE Connectivity | 142-0701-201 |
| 11 | 1 | J5 | 2 Terminal Block 3.5MM 2POS PCB | On Shore Technology Inc | ED555/2DS |
| 12 | 1 | J6 | SAMTEC, dual-row, right-angle, female, latching | SAMTEC | ERF8-025-01-L-D-RA-L-TR |
| 13 | 1 | J7 | Note: Connector Not Installed on PWB Rev.A. MOLEX connector for microSD card | Molex Inc | Note: Connector Not Installed on PWB Rev. A MOLEX 502570-0893 |
| 14 | 0 | JP3, JP4 | Header, TH, 100mil, 2x1, Gold plated, 230 mil above insulator | SAMTEC | TSW-102-07-G-S |
| 15 | 7 | JP1, JP2, JP5, JP6, JP9, JP10, JP11 | Header, TH, 100mil, 2x1, Gold plated, 230 mil above insulator | SAMTEC | TSW-102-07-G-S |
| 16 | 3 | JP7, JP8, JP12 | Header, TH, 100mil, 3x1, Gold plated, 230 mil above insulator | SAMTEC | TSW-103-07-G-S |
| 17 | 1 | R3 | RES, 0.22 ohm, 1%, 0.1W, 0603 | Panasonic Electronic Components | ERJ-3RQFR22V |
| 18 | 7 | R4, R14, R16, R36, R37, R89, R90 | RES, 0 ohm, 5%, 0.1W, 0603 | Vishay Dale | CRCW06030000Z0EA |
| 19 | 2 | R6, R7 | RES, 100 ohm, 1%, 0.1W, 0603 | Vishay Dale | CRCW0603100RFKEA |
| 20 | 8 | R9, R15, R31, R39, R40, R41, R42, R43 | RES, 47.0 ohm, 1%, 0.1W, 0603 | Yageo America | RC0603FR-0747RL |
| 21 | 8 | R10, R12, R17, R18, R20, R25, R46, R47 | RES, 1.00k ohm, 0.1%, 0.1W, 0603 | Susumu | RG1608P-102-B-T5 |
| 22 | 2 | R11, R13 | RES, 1.00k ohm, 1%, 0.1W, 0603 | Vishay Dale | CRCW06031K00FKEA |
| 23 | 4 | R21, R22, R23, R24 | RES, 20.0k ohm, 1%, 0.1W, 0603 | Vishay Dale | CRCW060320K0FKEA |
| 24 | 2 | R26, R27 | RES, 1.00 ohm, 1%, 0.1W, 0603 | Vishay Dale | CRCW06031R00FKEA |

Table 6. ADS8350EVM Bill of Materials (continued)

| Item No. | Qty | Ref Des | Description | Vendor | Part Number |
|----------|-----|------------------------------|---|---------------------------------|------------------|
| 25 | 2 | R28, R29 | RES, 0.1 ohm, 1%, 0.1W, 0603 | Panasonic Electronic Components | ERJ-3RSFR10V |
| 26 | 4 | R32, R33, R34, R35 | RES, 10.0 ohm, 1%, 0.1W, 0603 | Yageo America | RC0603FR-0710RL |
| 27 | 2 | R38, R86 | RES, 100k ohm, 5%, 0.1W, 0603 | Vishay-Dale | CRCW0603100KJNEA |
| 28 | 6 | R70, R71, R72, R73, R74, R75 | RES, 10k ohm, 5%, 0.063W, 0402 | Vishay Dale | CRCW040210K0JNED |
| 29 | 1 | R76 | RES, 10.0k ohm, 1%, 0.1W, 0603 | Vishay Dale | CRCW060310K0FKEA |
| 30 | 2 | R80, R84 | RES, 0 ohm, 5%, 0.125W, 0805 | Vishay Dale | CRCW08050000Z0EA |
| 31 | 0 | R1, R2, R5, R8, R19, R30 | Not Install | | Not Install |
| 32 | 0 | R83, R87, R88, R91 | Not Install | | Not Install |
| 33 | 1 | U1 | Dual, 750kSPS, 16 BIT Simultaneous Sampling ADC | Texas Instruments | ADS8350IRTE |
| 34 | 1 | U2 | High-Speed, Single-Supply, Rail-to-Rail OPA | Texas Instruments | OPA2350EA |
| 35 | 2 | U3, U4 | Very Low-Power, Rail-to-Rail Out, Negative Rail In, VFB Op Amp 205MHz | Texas Instruments | OPA2836IDGS |
| 36 | 1 | U5 | Low Noise, Low Drift, Precision Voltage Reference | Texas Instruments | REF5025IDGK |
| 37 | 1 | U7 | Atmel I2C Compatible (2-Wire) Serial EEPROM | Atmel | AT24C02C-XHM |
| 38 | 1 | U8 | 36-vA, 1-A, 4.17uVRMS RF LDO Voltage Regulator | Texas Instruments | TPS7A4700RGW |
| 39 | 1 | U9 | 60mA, 5.5V, Buck/Boost Charge Pump | Texas Instruments | REG71055DDC |
| 40 | 1 | U14 | NanoPower Supervisory Circuit | Texas Instruments | TPS3836E18DBVT |
| 41 | 2 | U15, U16 | Low Noise, Low Quiescent Current, Precision OPA | Texas Instruments | OPA376AIDBVT |
| 42 | 7 | N/A | Conn Shunt, Pitch 0.100"; Height 0.240" , Gold Plated | SAMTEC | SNT-100-BK-G |
| 43 | 5 | TP0, TP7, TP8, TP9, TP10 | TEST POINT PC MINI .040"D BLACK | Keystone Electronics | 5001 |
| 44 | 0 | TP1, TP2, TP3, TP4, TP5, TP6 | Not Install | Keystone Electronics | Not Install |
| 45 | 2 | N/A | BUMPON CYLINDRICAL .375X.135 BLK | 3M | SJ61A8 |

7.2 PCB Layout

Figure 27 through Figure 30 show the PCB layouts for the ADS8350EVM.

NOTE: Board layouts are not to scale. These figures are intended to show how the board is laid out; they are not intended to be used for manufacturing ADS8350EVM PCBs.




Figure 27. ADS8350EVM PCB: Top Layer




Figure 28. ADS8350EVM PCB: Ground Layer




Figure 29. ADS8350EVM PCB: Power Layer




Figure 30. ADS8350EVM PCB: Bottom Layer


7.3 Schematics

The schematics for the ADS8350EVM are appended to the end of this user's guide.

Revision History

| Changes from Original (April 2014) to A Revision | Page |
|---|-------------|
| • Changed SDCC controller to Simple Capture Card controller where applicable throughout document | 1 |
| • Deleted J6.38 (SDI) row from Table 3 | 7 |
| • Changed Section 5.2 : changed ADS8350EVM rev B requirement to two microSD cards, added Figure 7 | 10 |
| • Added Figure 7 | 11 |
| • Changed Table 6 : J7 is installed for ADS8350EVM rev B, added TP7, TP8, TP9, TP10 for ADS8350EVM rev B | 25 |

NOTE: Page numbers for previous revisions may differ from page numbers in the current version.



Do Not Install

JP9, JP10, JP5, JP6 Normally Installed

Do Not Install

Do Not Install


Note: Pin 8 to GND for ADSxx50; SDI for ADSxx53

Texas Instruments and/or its licensors do not warrant the accuracy or completeness of this specification or any information contained therein. Texas Instruments and/or its licensors do not warrant that this design will meet the specifications, will be suitable for your application or fit for any particular purpose, or will operate in an implementation. Texas Instruments and/or its licensors do not warrant that the design is production worthy. You should completely validate and test your design implementation to confirm the system functionality for your application.

| | | | |
|---------------------------------|--------|--|---------------|
| Designed for: Public Release | | Mod. Date: 10/13/2014 | |
| Project Title: ADS8350EVM | | Sheet Title: | |
| Number: | Rev: B | Assembly Variant: Variant name not interpreted | Sheet: 1 of 1 |
| SVN Rev: Not in version control | | File: Main_ADS8350EVM_RevB_SchDoc | Size: B |
| Drawn By: Luis Chiove | | Contact: http://www.ti.com/support | |
| Engineer: L. Chiove | | ©Texas Instruments 2014 | |

+3.3V SDCC Digital Supply

+5.5V Charge Pump



Texas Instruments and/or its licensors do not warrant the accuracy or completeness of this specification or any information contained therein. Texas Instruments and/or its licensors do not warrant that this design will meet the specifications, will be suitable for your application or fit for any particular purpose, or will operate in an implementation. Texas Instruments and/or its licensors do not warrant that the design is production worthy. You should completely validate and test your design implementation to confirm the system functionality for your application.

| | | | |
|---------------------------------|---------------------------|--|----------------------|
| Number: | Rev: B | Designed for: Public Release | Mod. Date: 9/11/2014 |
| SVN Rev: Not in version control | Project Title: ADS8350EVM | Sheet Title: | Sheet: 1 of 1 |
| Drawn By: | Engineer: L. Chiove | File: Connector_ADS8350EVM_RevB.SchDoc | Size: B |
| | | Contact: http://www.ti.com/support | |

STANDARD TERMS AND CONDITIONS FOR EVALUATION MODULES

1. *Delivery:* TI delivers TI evaluation boards, kits, or modules, including any accompanying demonstration software, components, or documentation (collectively, an "EVM" or "EVMs") to the User ("User") in accordance with the terms and conditions set forth herein. Acceptance of the EVM is expressly subject to the following terms and conditions.
 - 1.1 EVMs are intended solely for product or software developers for use in a research and development setting to facilitate feasibility evaluation, experimentation, or scientific analysis of TI semiconductors products. EVMs have no direct function and are not finished products. EVMs shall not be directly or indirectly assembled as a part or subassembly in any finished product. For clarification, any software or software tools provided with the EVM ("Software") shall not be subject to the terms and conditions set forth herein but rather shall be subject to the applicable terms and conditions that accompany such Software
 - 1.2 EVMs are not intended for consumer or household use. EVMs may not be sold, sublicensed, leased, rented, loaned, assigned, or otherwise distributed for commercial purposes by Users, in whole or in part, or used in any finished product or production system.
2. *Limited Warranty and Related Remedies/Disclaimers:*
 - 2.1 These terms and conditions do not apply to Software. The warranty, if any, for Software is covered in the applicable Software License Agreement.
 - 2.2 TI warrants that the TI EVM will conform to TI's published specifications for ninety (90) days after the date TI delivers such EVM to User. Notwithstanding the foregoing, TI shall not be liable for any defects that are caused by neglect, misuse or mistreatment by an entity other than TI, including improper installation or testing, or for any EVMs that have been altered or modified in any way by an entity other than TI. Moreover, TI shall not be liable for any defects that result from User's design, specifications or instructions for such EVMs. Testing and other quality control techniques are used to the extent TI deems necessary or as mandated by government requirements. TI does not test all parameters of each EVM.
 - 2.3 If any EVM fails to conform to the warranty set forth above, TI's sole liability shall be at its option to repair or replace such EVM, or credit User's account for such EVM. TI's liability under this warranty shall be limited to EVMs that are returned during the warranty period to the address designated by TI and that are determined by TI not to conform to such warranty. If TI elects to repair or replace such EVM, TI shall have a reasonable time to repair such EVM or provide replacements. Repaired EVMs shall be warranted for the remainder of the original warranty period. Replaced EVMs shall be warranted for a new full ninety (90) day warranty period.
3. *Regulatory Notices:*
 - 3.1 *United States*
 - 3.1.1 *Notice applicable to EVMs not FCC-Approved:*

This kit is designed to allow product developers to evaluate electronic components, circuitry, or software associated with the kit to determine whether to incorporate such items in a finished product and software developers to write software applications for use with the end product. This kit is not a finished product and when assembled may not be resold or otherwise marketed unless all required FCC equipment authorizations are first obtained. Operation is subject to the condition that this product not cause harmful interference to licensed radio stations and that this product accept harmful interference. Unless the assembled kit is designed to operate under part 15, part 18 or part 95 of this chapter, the operator of the kit must operate under the authority of an FCC license holder or must secure an experimental authorization under part 5 of this chapter.
 - 3.1.2 *For EVMs annotated as FCC – FEDERAL COMMUNICATIONS COMMISSION Part 15 Compliant:*

CAUTION

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Interference Statement for Class A EVM devices

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

FCC Interference Statement for Class B EVM devices

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

3.2 Canada

3.2.1 For EVMs issued with an Industry Canada Certificate of Conformance to RSS-210

Concerning EVMs Including Radio Transmitters:

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Concernant les EVMs avec appareils radio:

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Concerning EVMs Including Detachable Antennas:

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication. This radio transmitter has been approved by Industry Canada to operate with the antenna types listed in the user guide with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Concernant les EVMs avec antennes détachables

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante. Le présent émetteur radio a été approuvé par Industrie Canada pour fonctionner avec les types d'antenne énumérés dans le manuel d'usage et ayant un gain admissible maximal et l'impédance requise pour chaque type d'antenne. Les types d'antenne non inclus dans cette liste, ou dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur.

3.3 Japan

3.3.1 *Notice for EVMs delivered in Japan:* Please see http://www.tij.co.jp/lstds/ti_ja/general/eStore/notice_01.page 日本国内に輸入される評価用キット、ボードについては、次のところをご覧ください。
http://www.tij.co.jp/lstds/ti_ja/general/eStore/notice_01.page

3.3.2 *Notice for Users of EVMs Considered "Radio Frequency Products" in Japan:* EVMs entering Japan are NOT certified by TI as conforming to Technical Regulations of Radio Law of Japan.

If User uses EVMs in Japan, User is required by Radio Law of Japan to follow the instructions below with respect to EVMs:

1. Use EVMs in a shielded room or any other test facility as defined in the notification #173 issued by Ministry of Internal Affairs and Communications on March 28, 2006, based on Sub-section 1.1 of Article 6 of the Ministry's Rule for Enforcement of Radio Law of Japan,
2. Use EVMs only after User obtains the license of Test Radio Station as provided in Radio Law of Japan with respect to EVMs, or
3. Use of EVMs only after User obtains the Technical Regulations Conformity Certification as provided in Radio Law of Japan with respect to EVMs. Also, do not transfer EVMs, unless User gives the same notice above to the transferee. Please note that if User does not follow the instructions above, User will be subject to penalties of Radio Law of Japan.

【無線電波を送信する製品の開発キットをお使いになる際の注意事項】

本開発キットは技術基準適合証明を受けておりません。

本製品のご使用に際しては、電波法遵守のため、以下のいずれかの措置を取っていただく必要がありますのでご注意ください。

1. 電波法施行規則第6条第1項第1号に基づく平成18年3月28日総務省告示第173号で定められた電波暗室等の試験設備でご使用いただく。
2. 実験局の免許を取得後ご使用いただく。
3. 技術基準適合証明を取得後ご使用いただく。

なお、本製品は、上記の「ご使用にあたっての注意」を譲渡先、移転先に通知しない限り、譲渡、移転できないものとします。

上記を遵守頂けない場合は、電波法の罰則が適用される可能性があることをご留意ください。

日本テキサス・インスツルメンツ株式会社

東京都新宿区西新宿 6 丁目 2 4 番 1 号

西新宿三井ビル

3.3.3 *Notice for EVMs for Power Line Communication:* Please see http://www.tij.co.jp/llds/ti_ja/general/eStore/notice_02.page

電力線搬送波通信についての開発キットをお使いになる際の注意事項については、次のところをご覧ください。http://www.tij.co.jp/llds/ti_ja/general/eStore/notice_02.page

4 *EVM Use Restrictions and Warnings:*

4.1 EVMS ARE NOT FOR USE IN FUNCTIONAL SAFETY AND/OR SAFETY CRITICAL EVALUATIONS, INCLUDING BUT NOT LIMITED TO EVALUATIONS OF LIFE SUPPORT APPLICATIONS.

4.2 User must read and apply the user guide and other available documentation provided by TI regarding the EVM prior to handling or using the EVM, including without limitation any warning or restriction notices. The notices contain important safety information related to, for example, temperatures and voltages.

4.3 *Safety-Related Warnings and Restrictions:*

4.3.1 User shall operate the EVM within TI's recommended specifications and environmental considerations stated in the user guide, other available documentation provided by TI, and any other applicable requirements and employ reasonable and customary safeguards. Exceeding the specified performance ratings and specifications (including but not limited to input and output voltage, current, power, and environmental ranges) for the EVM may cause personal injury or death, or property damage. If there are questions concerning performance ratings and specifications, User should contact a TI field representative prior to connecting interface electronics including input power and intended loads. Any loads applied outside of the specified output range may also result in unintended and/or inaccurate operation and/or possible permanent damage to the EVM and/or interface electronics. Please consult the EVM user guide prior to connecting any load to the EVM output. If there is uncertainty as to the load specification, please contact a TI field representative. During normal operation, even with the inputs and outputs kept within the specified allowable ranges, some circuit components may have elevated case temperatures. These components include but are not limited to linear regulators, switching transistors, pass transistors, current sense resistors, and heat sinks, which can be identified using the information in the associated documentation. When working with the EVM, please be aware that the EVM may become very warm.

4.3.2 EVMs are intended solely for use by technically qualified, professional electronics experts who are familiar with the dangers and application risks associated with handling electrical mechanical components, systems, and subsystems. User assumes all responsibility and liability for proper and safe handling and use of the EVM by User or its employees, affiliates, contractors or designees. User assumes all responsibility and liability to ensure that any interfaces (electronic and/or mechanical) between the EVM and any human body are designed with suitable isolation and means to safely limit accessible leakage currents to minimize the risk of electrical shock hazard. User assumes all responsibility and liability for any improper or unsafe handling or use of the EVM by User or its employees, affiliates, contractors or designees.

4.4 User assumes all responsibility and liability to determine whether the EVM is subject to any applicable international, federal, state, or local laws and regulations related to User's handling and use of the EVM and, if applicable, User assumes all responsibility and liability for compliance in all respects with such laws and regulations. User assumes all responsibility and liability for proper disposal and recycling of the EVM consistent with all applicable international, federal, state, and local requirements.

5. *Accuracy of Information:* To the extent TI provides information on the availability and function of EVMs, TI attempts to be as accurate as possible. However, TI does not warrant the accuracy of EVM descriptions, EVM availability or other information on its websites as accurate, complete, reliable, current, or error-free.

6. *Disclaimers:*
- 6.1 EXCEPT AS SET FORTH ABOVE, EVMS AND ANY WRITTEN DESIGN MATERIALS PROVIDED WITH THE EVM (AND THE DESIGN OF THE EVM ITSELF) ARE PROVIDED "AS IS" AND "WITH ALL FAULTS." TI DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, REGARDING SUCH ITEMS, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF ANY THIRD PARTY PATENTS, COPYRIGHTS, TRADE SECRETS OR OTHER INTELLECTUAL PROPERTY RIGHTS.
- 6.2 EXCEPT FOR THE LIMITED RIGHT TO USE THE EVM SET FORTH HEREIN, NOTHING IN THESE TERMS AND CONDITIONS SHALL BE CONSTRUED AS GRANTING OR CONFERRING ANY RIGHTS BY LICENSE, PATENT, OR ANY OTHER INDUSTRIAL OR INTELLECTUAL PROPERTY RIGHT OF TI, ITS SUPPLIERS/LICENSORS OR ANY OTHER THIRD PARTY, TO USE THE EVM IN ANY FINISHED END-USER OR READY-TO-USE FINAL PRODUCT, OR FOR ANY INVENTION, DISCOVERY OR IMPROVEMENT MADE, CONCEIVED OR ACQUIRED PRIOR TO OR AFTER DELIVERY OF THE EVM.
7. *USER'S INDEMNITY OBLIGATIONS AND REPRESENTATIONS.* USER WILL DEFEND, INDEMNIFY AND HOLD TI, ITS LICENSORS AND THEIR REPRESENTATIVES HARMLESS FROM AND AGAINST ANY AND ALL CLAIMS, DAMAGES, LOSSES, EXPENSES, COSTS AND LIABILITIES (COLLECTIVELY, "CLAIMS") ARISING OUT OF OR IN CONNECTION WITH ANY HANDLING OR USE OF THE EVM THAT IS NOT IN ACCORDANCE WITH THESE TERMS AND CONDITIONS. THIS OBLIGATION SHALL APPLY WHETHER CLAIMS ARISE UNDER STATUTE, REGULATION, OR THE LAW OF TORT, CONTRACT OR ANY OTHER LEGAL THEORY, AND EVEN IF THE EVM FAILS TO PERFORM AS DESCRIBED OR EXPECTED.
8. *Limitations on Damages and Liability:*
- 8.1 *General Limitations.* IN NO EVENT SHALL TI BE LIABLE FOR ANY SPECIAL, COLLATERAL, INDIRECT, PUNITIVE, INCIDENTAL, CONSEQUENTIAL, OR EXEMPLARY DAMAGES IN CONNECTION WITH OR ARISING OUT OF THESE TERMS AND CONDITIONS OR THE USE OF THE EVMS PROVIDED HEREUNDER, REGARDLESS OF WHETHER TI HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. EXCLUDED DAMAGES INCLUDE, BUT ARE NOT LIMITED TO, COST OF REMOVAL OR REINSTALLATION, ANCILLARY COSTS TO THE PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES, RETESTING, OUTSIDE COMPUTER TIME, LABOR COSTS, LOSS OF GOODWILL, LOSS OF PROFITS, LOSS OF SAVINGS, LOSS OF USE, LOSS OF DATA, OR BUSINESS INTERRUPTION. NO CLAIM, SUIT OR ACTION SHALL BE BROUGHT AGAINST TI MORE THAN ONE YEAR AFTER THE RELATED CAUSE OF ACTION HAS OCCURRED.
- 8.2 *Specific Limitations.* IN NO EVENT SHALL TI'S AGGREGATE LIABILITY FROM ANY WARRANTY OR OTHER OBLIGATION ARISING OUT OF OR IN CONNECTION WITH THESE TERMS AND CONDITIONS, OR ANY USE OF ANY TI EVM PROVIDED HEREUNDER, EXCEED THE TOTAL AMOUNT PAID TO TI FOR THE PARTICULAR UNITS SOLD UNDER THESE TERMS AND CONDITIONS WITH RESPECT TO WHICH LOSSES OR DAMAGES ARE CLAIMED. THE EXISTENCE OF MORE THAN ONE CLAIM AGAINST THE PARTICULAR UNITS SOLD TO USER UNDER THESE TERMS AND CONDITIONS SHALL NOT ENLARGE OR EXTEND THIS LIMIT.
9. *Return Policy.* Except as otherwise provided, TI does not offer any refunds, returns, or exchanges. Furthermore, no return of EVM(s) will be accepted if the package has been opened and no return of the EVM(s) will be accepted if they are damaged or otherwise not in a resalable condition. If User feels it has been incorrectly charged for the EVM(s) it ordered or that delivery violates the applicable order, User should contact TI. All refunds will be made in full within thirty (30) working days from the return of the components(s), excluding any postage or packaging costs.
10. *Governing Law:* These terms and conditions shall be governed by and interpreted in accordance with the laws of the State of Texas, without reference to conflict-of-laws principles. User agrees that non-exclusive jurisdiction for any dispute arising out of or relating to these terms and conditions lies within courts located in the State of Texas and consents to venue in Dallas County, Texas. Notwithstanding the foregoing, any judgment may be enforced in any United States or foreign court, and TI may seek injunctive relief in any United States or foreign court.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265
Copyright © 2014, Texas Instruments Incorporated

IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, enhancements, improvements and other changes to its semiconductor products and services per JESD46, latest issue, and to discontinue any product or service per JESD48, latest issue. Buyers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All semiconductor products (also referred to herein as "components") are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its components to the specifications applicable at the time of sale, in accordance with the warranty in TI's terms and conditions of sale of semiconductor products. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by applicable law, testing of all parameters of each component is not necessarily performed.

TI assumes no liability for applications assistance or the design of Buyers' products. Buyers are responsible for their products and applications using TI components. To minimize the risks associated with Buyers' products and applications, Buyers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any patent right, copyright, mask work right, or other intellectual property right relating to any combination, machine, or process in which TI components or services are used. Information published by TI regarding third-party products or services does not constitute a license to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of significant portions of TI information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. TI is not responsible or liable for such altered documentation. Information of third parties may be subject to additional restrictions.

Resale of TI components or services with statements different from or beyond the parameters stated by TI for that component or service voids all express and any implied warranties for the associated TI component or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

Buyer acknowledges and agrees that it is solely responsible for compliance with all legal, regulatory and safety-related requirements concerning its products, and any use of TI components in its applications, notwithstanding any applications-related information or support that may be provided by TI. Buyer represents and agrees that it has all the necessary expertise to create and implement safeguards which anticipate dangerous consequences of failures, monitor failures and their consequences, lessen the likelihood of failures that might cause harm and take appropriate remedial actions. Buyer will fully indemnify TI and its representatives against any damages arising out of the use of any TI components in safety-critical applications.

In some cases, TI components may be promoted specifically to facilitate safety-related applications. With such components, TI's goal is to help enable customers to design and create their own end-product solutions that meet applicable functional safety standards and requirements. Nonetheless, such components are subject to these terms.

No TI components are authorized for use in FDA Class III (or similar life-critical medical equipment) unless authorized officers of the parties have executed a special agreement specifically governing such use.

Only those TI components which TI has specifically designated as military grade or "enhanced plastic" are designed and intended for use in military/aerospace applications or environments. Buyer acknowledges and agrees that any military or aerospace use of TI components which have **not** been so designated is solely at the Buyer's risk, and that Buyer is solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI has specifically designated certain components as meeting ISO/TS16949 requirements, mainly for automotive use. In any case of use of non-designated products, TI will not be responsible for any failure to meet ISO/TS16949.

Products

| | |
|------------------------------|--|
| Audio | www.ti.com/audio |
| Amplifiers | amplifier.ti.com |
| Data Converters | dataconverter.ti.com |
| DLP® Products | www.dlp.com |
| DSP | dsp.ti.com |
| Clocks and Timers | www.ti.com/clocks |
| Interface | interface.ti.com |
| Logic | logic.ti.com |
| Power Mgmt | power.ti.com |
| Microcontrollers | microcontroller.ti.com |
| RFID | www.ti-rfid.com |
| OMAP Applications Processors | www.ti.com/omap |
| Wireless Connectivity | www.ti.com/wirelessconnectivity |

Applications

| | |
|-------------------------------|--|
| Automotive and Transportation | www.ti.com/automotive |
| Communications and Telecom | www.ti.com/communications |
| Computers and Peripherals | www.ti.com/computers |
| Consumer Electronics | www.ti.com/consumer-apps |
| Energy and Lighting | www.ti.com/energy |
| Industrial | www.ti.com/industrial |
| Medical | www.ti.com/medical |
| Security | www.ti.com/security |
| Space, Avionics and Defense | www.ti.com/space-avionics-defense |
| Video and Imaging | www.ti.com/video |

TI E2E Community

e2e.ti.com